Study Questions (Chapter 03 – Part 5)

- 1. Question 3.10 on page 224: Why does the ARM provide a reverse subtract instruction RSB **r0**, r1, r2, that implements [r0] = [r2] [r1], when the normal subtraction instruction SUB **r0**, r2, r1, will do exactly the same job?
- 2. Question 3.20 on page 224: What is the difference between the TEQ, TST, CMP and CMN comparison instructions?
- 3. Question 3.47 on page 226: What is wrong with the following instruction? MLA r0, r0, r1, r2
- 4. How to extend ARM arithmetic capabilities to make it able to add two extended precisions integer values (64-bits each). Give an example. Write down all assumptions you will make.
- 5. How to extend ARM arithmetic capabilities to make it able to add two extended precisions integer values (96-bits each). Give an example. Write down all assumptions you will make.
- 6. What are the main differences between ADD, ADDS, ADC, and ADCS? Provide numeric examples to demonstrate the differences.
- 7. What are the main differences between SUB, SUBS, SBC, and SBCS? Provide numeric examples to demonstrate the differences.
- 8. What are the differences between NEG and MVN?
 Provide numeric examples to demonstrate the differences.
- 9. What are the main differences between RSB, RSBS, RSC, and RSCS? Provide numeric examples to demonstrate the differences.
- 10. What are the main differences between SUB, SUBS, RSB, and RSBS? Provide numeric examples to demonstrate the differences.
- 11. What are the main differences between MUL, MULS, MLA, and MLAS? Provide numeric examples to demonstrate the differences.
- 12. NEG is a pseudo instruction. How does ARM implement it?
- 13. LSL is a pseudo instruction. How does ARM implement it?
- 14. LSR is a pseudo instruction. How does ARM implement it?
- 15. ASR is a pseudo instruction. How does ARM implement it?
- 16. ROR is a pseudo instruction. How does ARM implement it?
- 17. RRX is a pseudo instruction. How does ARM implement it?
- 18. Question 3.11 on page 224: If r1 = 11110000111000101010000011111101, and r2 = 000000001111111110000111100001111, what is the value of r3 after executing BIC **r3**,r1,r2?

- 19. Question 3.18 on page 224: Write one or more ARM instructions that will clear bits 20 to 25 inclusive in register r0. All the other bits of r0 should remain unchanged.
- 20. What are the main differences between AND, ANDS, BIC, and BICS? Provide numeric examples to demonstrate the differences.
- 21. Question 3.12 on page 224: If $r1 = 0FFF_{16}$, and r2 = 4, what is the value of r3 after each of the following instructions has been executed (assume that each instruction uses the same data).
 - a. MOV r3,r1, LSL r2
 - b. MOV **r3**,r1, LSR r2
 - c. MVN **r3**,r1, LSL r2
 - d. MVN **r3**,r1, LSR r2
- 22. Question 3.13 on page 224: If $r1 = 00FF_{16}$, what is the value of r0 after each of the following instructions has been executed (assume that each instruction uses the same data)?
 - a. ADD **r0**,r1,r1, LSL #2
 - b. ADD r0,r1,r1, LSL #4
 - c. ADD r0,r1,r1, ROR #4
- 23. Question 3.14 on page 224: What is the effect of the instruction MOV r0,r0, ASR #31?
- 24. Question 3.36 on page 225: Without using the ARM's multiplication instruction, write one or more instructions (using ADD, SUB, and shifting) to multiply by the following integers:
 - a. 33
 - b. 1025
 - c. 4095
- 25. In ARM assembly language, how the RRX shift is encoded?
- 26. In ARM assembly language, how is the arithmetic shift left operation synthesized? Give an example.
- 27. In ARM assembly language, how is the rotate shift left operation synthesized? Give an example.
- 28. In ARM assembly language, how is the rotate shift left through carry operation synthesized? Give an example.