
Part A

CHAPTER 3

Architecture and Organization



Alan Clements

1

These slides are provided with permission from the copyright for CS2208 use only. The slides must not be reproduced or provided to anyone outside the class.

All downloaded copies of the slides are for personal use only.

Students must destroy these copies within 30 days after receiving the course's final assessment.



Example 1: Calculating the Absolute Value

- □ To calculate $x \leftarrow |x|$, where x is a signed integer, we can implement if x < 0 then x = -x
- ☐ In ARM

```
TEQ \mathbf{r0}, #0 ; compare r0 with zero
RSBMI \mathbf{r0}, r0, #0 ; if negative (MInus) r0 \leftarrow 0 - r0
```


☐ What is the difference between TEQ and CMP? •

- To know the difference, read slide #72
- ☐ What is the difference between RSBMI and RSBLT? • •
- To know the difference, read slide #83
- ☐ Can we use RSBMI r0, #0 instead of RSBMI r0, r0, #0 ?
- ☐ Can we use NEGMI ro, ro instead of RSBMI ro, ro, #0.?

To know the answer, read slide #59

To know the answer, read slide #59

□ Suppose we have r0, r1, and r2 as follow:




and we want to rearrange r2 as follow:

r2.


Note that: we can not do: BIC **r2**, r2, #0xFFFF00000 To know the reason, read Slides 105-110

```
AND r0, r0, #0xFF
AND r1, r1, #0xFF
BIC r2, r2, #0xFF0000
BIC r2, r2, #0xFF000000
ADD r2, r2, r1, LSL#16
```

```
;cle all high order 3 bytes
                             o; clear all high order 3 bytes
                          ; clear the 3rd byte
                              ; clear the 4th byte
                              ;LSL r1 by 2 bytes & add it to r2
ADD \mathbf{r2}, \mathbf{r2}, \mathbf{r0}, LSL#24 ;LSL \mathbf{r0} by 3 bytes & add it to \mathbf{r2}
```




□ Suppose we have r0, r1, and r2 as follow:




□ Another solution in 5 instructions


```
AND r0, r0, #0xFF ; clear r0 all high order 3 bytes AND r1, r1, #0xFF ; clear r1 all high order 3 bytes ADD r2, r1, r2, LSL#16 ; LSL r2 by 2 bytes & add r1 to it ADD r2, r2, r0, LSL#8 ; LSL r0 by 1 byte & add it to r2 MOV r2, r2, ROR#16 ; Swap the two r2 16 bits together
```



Example 3: Byte Reversal (Big-endian \Leftrightarrow Little-endian)

- ☐ Suppose that **0xAB** CD **EF** GH is stored in r0
- ☐ We want to reverse the content of r0, i.e., store $0xGH ext{ EF CD AB in } r0$
- ☐ Let us review the XOR truth table
 - x ⊕ x = 0
 - \blacksquare $X \oplus 0 = X$
 - \blacksquare $x \oplus y \oplus y = x$





☐ We will use r1 as a working register

```
EOR \mathbf{r1}, \mathbf{r0}, \mathbf{r0}, \mathbf{ROR}#16 ; \mathbf{A} \oplus \mathbf{E}, \mathbf{B} \oplus \mathbf{F}, \mathbf{C} \oplus \mathbf{G}, \mathbf{D} \oplus \mathbf{H}, \mathbf{E} \oplus \mathbf{A}, \mathbf{F} \oplus \mathbf{B}, \mathbf{G} \oplus \mathbf{C}, \mathbf{H} \oplus \mathbf{D} BIC \mathbf{r1}, \mathbf{r1}, #0x00FF0000 ; \mathbf{A} \oplus \mathbf{E}, \mathbf{B} \oplus \mathbf{F}, 0, 0, \mathbf{E} \oplus \mathbf{A}, \mathbf{F} \oplus \mathbf{B}, \mathbf{G} \oplus \mathbf{C}, \mathbf{H} \oplus \mathbf{D} MOV \mathbf{r0}, \mathbf{r0}, \mathbf{ROR} \# 8 ; \mathbf{G}, \mathbf{H}, \mathbf{A}, \mathbf{B}, \mathbf{C}, \mathbf{D}, \mathbf{E}, \mathbf{F} EOR \mathbf{r0}, \mathbf{r0}, \mathbf{r1}, \mathbf{LSR} \# 8 ; \mathbf{r1} after \mathbf{LSR} \# 8 is
```

Α	В	$C = A \oplus B$
0	0	0
0	1	1
1	0	1
1	1	0

```
; G , H , A , B , C , D , E , F

;r1 after LSR#8 is

; O , O ,A⊕E,B⊕F, O , O ,E⊕A,F⊕B

;The final result will be

;G⊕O,H⊕O,A⊕A⊕E,B⊕B⊕F,C⊕O,D⊕O,E⊕E⊕A,F⊕F⊕B

; G , H ,E ,F ,C ,D ,A ,B
```

Example 4: Variable Swapping

- ☐ Assume that we have two variables stored in **r0** and **r1**
- ☐ We wants to swap these two variables

```
[r2] \leftarrow [r0]
[r0] \leftarrow [r1]
[r1] \leftarrow [r2]
```

 \square Now, we want to do the same thing without using r2

The red values are the originals.

```
ADD r0,r0,r1 ; [r0] ← [r0] + [r1]...

SUB r1,r0,r1 ; [r1] ← [r0] - [r1] ; [r1] ← ([r0] + [r1]) - [r1] ; [r1] ← [r0] + [r0] + [r1]) - [r1] ; [r0] ← [r0] + [r1] + [r1]) - [r0] ; [r0] ← [r1] ; [r0] ← [r1] ; [r0] ← [r1] ; [r0] ← [r1]
```

 $C = A \oplus B$

Example 4: Variable Swapping

- ☐ Assume that we have two variables stored in **r0** and **r1**
- ☐ We wants to swap these two variables

```
 [r2] \leftarrow [r0] 
 [r0] \leftarrow [r1] 
 [r1] \leftarrow [r2]
```

- \square Now, we want to do the same thing without using r2
- □ Another solution

Let us review the XOR truth table

```
\blacksquare X \oplus X = 0
```

$$\blacksquare$$
 $x \oplus 0 = x$

$$\mathbf{x} \oplus \mathbf{y} \oplus \mathbf{y} = \mathbf{x}$$

1 1 0

The red values are the originals.

```
EOR r0, r0, r1 ; [r0] \leftarrow [r0] \oplus [r1].

EOR r1, r0, r1 ; [r1] \leftarrow [r0] \oplus [r1] ; [r1] \leftarrow ([r0] \oplus [r1]) \oplus [r1] ; [r1] \leftarrow [r0] \oplus [r1] ; [r1] \leftarrow [r0] \oplus [r1] ; [r0] \leftarrow [r0] \oplus [r1] ; [r0] \leftarrow ([r0] \oplus [r1]) \oplus [r0] ; [r0] \leftarrow [r1]
```

 $X \leftarrow X \oplus Y$

$$Y \leftarrow X \oplus Y$$

XThis slide iX m bied Yersion of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka

Example 5: Multiplication by $2^n - 1$, 2^n , or $2^n + 1$

- ☐ Multiplying by 2ⁿ can be implemented using MOV instruction and LSL#n
- ☐ Example:

Write one ARM instruction to store r1 × 16 into r2

MOV **r2**, r1, LSL#4 ; $[r2] \leftarrow [r1] \times 2^4$

- ☐ Multiplying by 2ⁿ + 1 can be implemented using ADD instruction and LSL#n
- ☐ Example

Write one ARM instruction to store $r1 \times 17$ into r2

ADD **r2**, r1, r1, LSL#4; [r2] \leftarrow [r1] + [r1] × 2^4

- ☐ Multiplying by 2ⁿ 1 can be implemented using RSB instruction and LSL#n
- ☐ Example

Write one ARM instruction to store $r1 \times 15$ into r2

RSB **r2**, r1, r1, LSL#4; [r2] \leftarrow [r1] × 2^4 - [r1]

Example 5: Multiplication by $2^n - 1$, 2^n , or $2^n + 1$

☐ Let us translate the following C code

```
if(x > y)
  p = 17 * q;
else
{ if(x == y)
    p = 16 * q;
  else /* i.e., x < y */
    p = 15 * q;
}</pre>
```

☐ Assume that x and y are stored in r2 and r3, and also that p and q are r4 and r1

Not correct in the book page 200

Example 6: Dividing by D

- ☐ Dividing by **D** can be implemented using MUL and ASR instructions
- ☐ Example:

Write ARM instructions to divide r0 by D and store the result in r1 i.e., $[r1] \leftarrow [r0] / D$

☐ The result can be written as:

```
[r0] / D = [r0] \times (1 / D)
= [r0] \times (2^N/D) / 2^N
```

- ✓ Select N to be a large integer at the same time not to cause an overflow when evaluating [r0] × (2^N/D)
- ✓ Evaluate [r0] × (2^N/D)
- ✓ Arithmetic shift right the result N time

```
\square If D = 5 and r0 = 32004, we can pick N = 16
```

$$\square$$
 2^N / D = 2^16 / 5 = 1024 × 64 / 5 = 13107.2

round(13107.2) = 13107

Note that 13107 / 2¹6 = 0.199997 ≈ 0.2

LDR **r2**,=13107; (2^N/D)

MUL r1, r2, r0; $[r0] \times (2^N/D)$

ASR r1, #16; $[r0] \times (2^N/D) / 2^N = [r0] / D$

This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka

Example 7: Converting Capital Letter -> Small Letter

- ☐ Let us convert any capital letter to small letter
- ☐ Capital letters begins by 'A' and end by 'Z'
- \square Assume that the character to be converted in r0; and r1 is a working register


```
CMP r0, #'A' ; Is it in the range of the capital?


RSBGES r1, r0, #'Z' ; If >= 'A',

; then check with 'Z'
; and update the flags

ORRGE r0, r0, #2_100000 ; If between 'A' and 'Z' inclusive,

; then set bit 5 to force lower case
```





This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka

Example 8: If Statement in One Instruction!!

☐ Let us translate the following C code


$$if(x < 0)$$

 $x = 0;$

□ Assume that x is stored in r0

BIC **r0**, r0, r0, ASR#31; only one instruction!!

- ☐ ASR#31 will fill all bits of r0 with the sign bit
 - o If positive, the result will be 0x00000000



Example 9: Simple Bit-level Logical Operations

- □ Assume #2_0000 0000 0000 0000 0000 0000 0000 **pqrs** is stored in r0
- ☐ We wish to implement the following statement

```
if ((p == 1) && (r == 1))

s = 1;
```

```
TST r0,#0x8 ; check the value of bit p TSTNE r0,#0x2 ; if p == 1, ; check the value of bit r ORRNE r0,r0,#1 ; if r == 1, ; set s \leftarrow 1
```

In this situation, you can not replace the ORRNE by ADDNE as soriginally might be 1.

Example 10: Hexadecimal Character Conversion

```
☐ We would like to convert 4 binary bits to hexadecimal digits
                                                                     0000 -> '0'
☐ Assume that these 4 bits are stored at the LSBs of r0 and
  the rest of the bits are zeros
                                                                     0010 - 12'
□ Note that the ASCII code of
    o '0' is 48, i.e., 0 \times 30 (difference from 0000_2 is = 0 \times 30)
       '1' is 49, i.e., 0 \times 31 (difference from 0001_2 is = 0 \times 30)
                                                                               151
                                                                               16'
       '9' is 57, i.e., 0 \times 39 (difference from 1001_2 is = 0 \times 30)
□ Note also that the ASCII code of
                                                                               181
    o 'A' is 65, i.e., 0 \times 41 (difference from 1010_2 is = 0 \times 37)
                                                                               191
       'B' is 66, i.e., 0 \times 42 (difference from 1011_2 is = 0 \times 37)
                                                                               'A'
                                                                     1010 →
                                                                     1011
                                                                               'B'
       'F' is 70, i.e., 0 \times 46 (difference from 1111_2 is = 0 \times 37)
                                                                               'C'
                                                                     1100 →
☐ The conversion algorithm is:
                                                                     1101 →
                                                                               'D'
  character = the4BitBinaryValue + 0x30
                                                                     1110
                                                                                'E'
     if(character > 0x39)_
                                    ADDGT not ADDGE
                                                                                \F/
                                                                     1111 -
        character += 7
                                Not correct in the book page 202
       r0, r0, #0x30; add 0x30 to convert 0 through 9 to ASCII
ADD
                                                                                157
     r0, #0x39 ; check for A to F hex values
CMP
ADDGT r0, r0, #7 ; If A to F, then add 7 to get the ASCII
```

This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka.

Example 10: Hexadecimal Character Conversion

```
☐ We would like to convert 4 binary bits to hexadecimal digits
                                                                     0000 -> '0'
Assume that these 4 bits are stored at the LSBs of r0 and
  the rest of the bits are zeros
□ Note that the ASCII code of
    o '0' is 48, i.e., 0 \times 30 (difference from 0000_2 is = 0 \times 30)
       '1' is 49, i.e., 0 \times 31 (difference from 0001_2 is = 0 \times 30)
                                                                               15/
                                                                               16'
       '9' is 57, i.e., 0 \times 39 (difference from 1001_2 is = 0 \times 30)
□ Note also that the ASCII code of
                                                                               181
    o 'A' is 65, i.e., 0 \times 41 (difference from 1010_2 is = 0 \times 37)
                                                                               191
       'B' is 66, i.e., 0 \times 42 (difference from 1011_2 is = 0 \times 37)
                                                                              \A'
                                                                     1010 →
                                                                               'B'
                                                                     1011
       'F' is 70, i.e., 0 \times 46 (difference from 1111_2 is = 0 \times 37)
                                                                     1100 →
                                                                               'C'
■ Another algorithm
                                                                               'D'
  using conditional operator (i.e., ?:)
                                           variable = Expression1 ? Expression2 : Expression3
                                                                     1110
                                                                                'E'
  1111 -
        +(the4BitBinaryValue \leq 0x9)? 0x30 : 0x37;
                  ; is it 0-9 or A-F hex values?
       r0, #0x9
CMP
                                                                                158
ADDLE r0, r0, \#0x30; if it is 0-9, add 0x30 to convert to ASCTI
ADDGT r0, r0, #0x37; if it is A-F, add 0x37 to convert to ASCII
```

This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka.

Example 11: Multiple Selection


```
☐ Let us translate the following C code
     switch (i)
     { case 0: do action; break;
       case 1: do action; break;
       case N: do action; break;
       default: do something;
Assume that r0 contains the selector i
          TEQ r0, 0; is the switch variable == 0?
          BEQ case0 ; If i == 0, jump to the case0 code
          TEQ r0, 1; is the switch variable == 1?
          BEQ case1; If i == 1, jump to the case1 code
          TEQ r0, N; is the switch variable == N?
          BEQ caseN ; If i == N, jump to the caseN code
          B default
case0
          do action of case 0
          B AfterCase
case1
          do action of case 1
          B AfterCase
          do action of case N
caseN
          B AfterCase
default do action of default
AfterCase
```

Example 12: Finding the Longest Sequence of Repeated Digits

☐ In Chapter one, we attempted to find the longest sequence of repeated digits.

FIGURE 1.7

A string of digits



- ☐ Let us revisit this problem and implement the solution using ARM assembly language.
- ☐ If you recall, we proposed 13 steps to solve this problem:
 - 1. Read the first digit in the string and call it New_Digit
 - 2. Set the Current_Run_Value to New_Digit
 - 3. Set the Current_Run_Length to 1
 - 4. Set the Max Run to 1
 - 5. REPEAT
 - 6. Read the next digit in the sequence (i.e., read a New_Digit)
 - 7. IF its value is the same as Current_Run_Value
 - 8. THEN Current_Run_Length = Current_Run_Length + 1
 - 9. ELSE {Current_Run_Length = 1
 - 10. Current_Run_Value = New_Digit}
 - 11. IF Current_Run_Length > Max_Run
 - 12. THEN Max_Run = Current_Run_Length
 - This slide is 13. UNTIL The last digit is read

Example 12: Finding the Longest Sequence of Repeated Digits

```
RunLength, CODE, READONLY
        AREA
                                                        FIGURE 1.7
                                                                 A string of digits
        ENTRY
                                                                          String of 17 digits
               r9, String; r9 points to the sting
                                                              23277366664792211
        ADR
        LDRB
               rO, EoS ; rO is the EoS symbol
                                                                   Run of four consecutive
              r1, [r9], #1; Step-01: r1 is New Digit
        LDRB
                                                                  digits with the same value
                                                                                  digits with the same value @
              r2, r1 ;Step-02: r2 is the Current Run Value
        MOV
              r3,#1 ;Step-03: r3 is the Current_Run_Length (set to 1)
        MOV
        MOV \mathbf{r4}, #1 ;Step-04: r4 is the Max Run Length (set to 1)
Repeat LDRB r1, [r9], #1; Step-05 & 06: REPEAT: Read next digit (i.e., New Digit)
              r1, r2
                      ;Step-07: Compare New Digit and Current Run Value
        CMP
        ADDEQ r3, r3, #1 ;Step-08: IF same THEN Current Length=Current Length+1
        MOVNE r3, #1
                           ;Step-09:
                                                 ELSE Current Run Length = 1
        MOVNE r2, r1
                           ;Step-10:
                                                       Current Run Value = New Digit
              r3,r4
                           ;Step-11: IF Current Run Length > Max Run
        CMP
        MOVGT r4, r3
                           ;Step-12: THEN Max Run = Current Run Length
                           ;Step-13: Testing the end of string
              r0,r1
        TEO
                           ;Step-13: UNTIL all digits tested
        BNE Repeat
                           ; parking loop
        B Park
Park
String DCB 2,3,2,7,7
                                Read the first digit in the string and call it New Digit
        DCB 3,6,6,6,6,4
                                Set the Current Run Value to New Digit
        DCB 7,9,2,2,1
                                Set the Current Run Length to 1
                                Set the Max Run to 1
        DCB OxFF
EoS
                           5.
                                REPEAT
        END
                           6.
                                     Read the next digit in the sequence (i.e., read a New_Digit)
                           7.
                                     IF its value is the same as Current_Run_Value
                           8.
                                         THEN Current_Run_Length = Current_Run_Length + 1
                                                                                       161
                           9.
                                         ELSE {Current_Run_Length = 1
                                               Current Run Value = New Digit
                           10.
                                     IF Current_Run_Length > Max_Run
                           11.
                                         THEN Max_Run = Current_Run Length
                           12.
                                UNTIL The last digit is read
 This slide is a modified version of the original aut 13.
                                                                                      R. El-Sakka
```