
Part 0x4

CHAPTER 3

Architecture and Organization



Alan Clements

These slides are being provided with permission from the copyright for in-class (CS2208B) use only. The slides must not be reproduced or provided to anyone outside of the class.

All download copies of the slides and/or lecture recordings are for personal use only. Students must destroy these copies within 30 days after receipt of final course evaluations.

CENGAGE Learning

Music: "Corporate Success" by Scott Holmes, used under <u>Attribution-NonCommercial License</u>

Pseudo instructions

- □ A *pseudo instruction* is an operation that the programmer can use when <u>writing code</u>.
 - o The actual instruction <u>does not</u> have a <u>direct</u> machine language equivalent.
 - For example, you <u>can't</u> write MOV r0,#0x12345678 to load register r0 with the 32-bit value 0x12345678 because the instruction is only 32 bits long in total.
 - Instead, you can use LDR $\mathbf{r0}$, $\mathbf{\subseteq}0$ x12345678 pseudo instruction, Yes, it is = not # It is NOT MOV $\mathbf{r0}$ = 0x12345678
 - the assembler will generate suitable code to carry out the same action.
 - o store the constant 12345678₁₆ in a so-called literal pool or constant pool somewhere in memory after the program
 - o *generates suitable code* to load the stored constant 12345678₁₆ to r0

Pseudo instructions

- □ Another *pseudo instruction* is <u>ADR</u> **r0**, label, which loads the <u>32-bit address</u> of the line 'label' into register r0, using the appropriate code generated by the assembler
- ☐ The following fragment demonstrates the use of the ADR pseudo instruction.

This LDR instruction here is **NOT** a pseudo instruction

ADR r1, MyArray; set up r1 to point to MyArray

; loads register r1 with the 32-bit address of MyArray

LDR **r3**,[r1]

;read an element using the pointer

MyArray DCD 0x12345678; the address of this data will be loaded to r1

- ☐ The programmer does not have to know how the assembler generates suitable code to implement such *pseudo instructions*But as a student, you need to know it!!
- ☐ All this is done automatically.

☐ This can be realized by utilizing the *program counter relative addressing*

Program Counter Relative Addressing

- □ Register *indirect relative addressing allows* us to

o specify the location of an operand with respect to a register value.

Set the value of ri, use it as a pointer to the memory and more in the memory and more in the memory and more in the present in the present in the specifies that the operand address is in ri ☐ LDR **r0,**[r1]


- □ LDR **r0**, [r1, #16] specifies that the operand is 16 bytes onward from r1.
 - uppose that we use r15, i.e., the PC, to generate an address by writing

LDR ro, [PC, #16]. current position + offset+8

- o The operand is 16 bytes onward from the PC
- o i.e., (8 +) 16 = 24 bytes from the current instruction.
 - The ARM's PC in most of the cases is 8 bytes

initialized to be the current instruction to be executed, once the projection to pipelining (automatically fetches is excuted, the next instruction before the current one

it been secuted).



Memory address registe Register File Path taken by the instruction when it is Register r0 Register r1

