VISCA Command/ACK Protocol

Command	Command Message	Reply Message	Comments
General Command	81 01 04 38 02 FF (Example)	90 41 FF (ACK)+90 51 FF (Completion) 90 42 FF 90 52 FF	Returns ACK when a command has been accepted, and Completion when a command has been executed.
	81 01 04 38 FF (Example)	90 60 02 FF (Syntax Error)	Accepted a command which is not supported or a command lacking parameters.
	81 01 04 38 02 FF (Example)	90 60 03 FF (Command Buffer Full)	There are two commands currently being executed, and the command could not be accepted.
	81 01 04 08 02 FF (Example)	90 61 41 FF (Command Not Executable) 90 62 41FF	Could not execute the command in the current mode.
Inquiry Command	81 09 04 38 FF (Example)	90 50 02 FF (Completion)	ACK is not returned for the inquiry command.
	81 09 05 38 FF (Example)	90 60 02 FF (Syntax Error)	Accepted an incompatible command.
Address Set	88 30 01 FF	88 30 02 FF	Returned the device address to +1.
IF_Clear(Broadcast)	88 01 00 01 FF	88 01 00 01 FF	Returned the same command.
IF_Clear (For x)	8x 01 00 01 FF	z0 50 FF (Completion)	ACK is not returned for this command.
Command Cancel	8x 2y FF	z0 6y 04 FF (Command Canceled)	Returned when the command of the socket specified is canceled. Completion for the command canceled is not returned.
		z0 6y 05 FF (No Socket)	Returned when the command of the specified socket has already been completed or when the socket number specified is wrong.

VISCA Camera-Issued Messages

ACK/Completion Messages

	Command Messages	Comments
ACK	z0 4y FF	Returned when the command is accepted.
	(y:Socket No.)	
Completion	z0 5y FF	Returned when the command has been executed.
	(y:Socket No.)	

z = Device address + 8

Error Messages

	Command Messages	Comments
Syntax Error	z0 60 02 FF	Returned when the command format is different or when a command with illegal command parameters is accepted.
Command Buffer Full	z0 60 03 FF	Indicates that two sockets are already being used (executing two commands) and the command could not be accepted when received.
Command Canceled	z0 6y 04 FF (y:Socket No.)	Returned when a command which is being executed in a socket specified by the cancel command is canceled. The completion message for the command is not returned.
No Socket	z0 6y 05 FF (y:Socket No.)	Returned when no command is executed in a socket specified by the cancel command, or when an invalid socket number is specified.
Command Not Executable	z0 6y 41 FF (y:Socket No.)	Returned when a command cannot be executed due to current conditions. For example, when commands controlling the focus manually are received during auto focus.

Network Change Message

	Command Message	Comments
Network Change	z0 38 FF	Issued when power is being routed to the camera, or when the VISCA device is
		connected to or disconnected from the VISCA RS-232C/RS-422 OUT connector
		used for communication.

EVI-D70/P Commands

EVI-D70/P Command List (1/4)

Command Set	Command	Command Packet	Comments
AddressSet	Broadcast	88 30 01 FF	Address setting
IF_Clear	Broadcast	88 01 00 01 FF	I/F Clear
CommandCancel		8x 2p FF	p: Socket No.(=1or2)
CAM_Power	On	8x 01 04 00 02 FF	Power ON/OFF
	Off	8x 01 04 00 03 FF	
CAM_AutoPowerOff	Direct	8x 01 04 40 0p 0q 0r 0s FF	Auto Power Off
			pqrs: Power Off Timer 0000 (Timer Off) to FFFF
			(65535min)
			Initial value: 0000
			The power automatically turns off if the camera does not receive any VISCA commands or any signals from the
			Remote Commander for the duration you set in the timer.
CAM_NightPoweroff	Direct	8x 01 04 41 0p 0q 0r 0s FF	Pgrs: Power Off Timer 0000~FFFF (Units: Min.)
<u>-</u> <u></u>			A setting of 0 (zero min.) is equivalent to OFF, and the
			smallest value that can be set is 1 min.
			When the Day/Night function is in effect and the Night
			setting has been made, if an operation is not attempted via
			either a VISCA command or the remote controller, the unit
			will continue to operate for the time set in the timer, and will then shut off automatically.
CAM_Zoom	Stop	8x 01 04 07 00 FF	their state on automateury.
	Tele(Standard)	8x 01 04 07 02 FF	
	Wide(Standard)	8x 01 04 07 03 FF	
	Tele(Variable)	8x 01 04 07 2p FF	p=0 (Low) to 7 (High)
	Wide(Variable)	8x 01 04 07 3p FF	p=0 (Bow) to 7 (High)
	Direct	8x 01 04 47 0p 0q 0r 0s FF	pqrs: Zoom Position
CAM_DZoom	On	8x 01 04 06 02 FF	Digital zoom ON/OFF
	Off	8x 01 04 06 03 FF	
	Combine Mode	8x 01 04 36 00 FF	Optical/Digital Zoom Combined
	Separate Mode	8x 01 04 36 01 FF	Optical/Digital Zoom Separate
	Stop	8x 01 04 06 00 FF	Spireus 2 i State 200 in Separate
	Tele(Variable)	8x 01 04 06 2p FF	p=0 (Low) to 7 (High)
	Wide(Variable)	8x 01 04 06 3p FF	p=0 (200) to 7 (High)
	x1/Max	8x 01 04 06 10 FF	x1/MAX Magnification Switchover
	Direct	8x 01 04 46 00 00 0p 0q FF	pq: D-Zoom Position
CAM_Focus	Stop	8x 01 04 08 00 FF	pq. D-250m Fosition
C/IN_I ocus	Far(Standard)	8x 01 04 08 02 FF	
	Near(Standard)	8x 01 04 08 03 FF	
	Far(Variable)	8x 01 04 08 2p FF	p=0 (Low) to 7 (High)
	Near(Variable)		p=0 (Low) to 7 (Trigh)
	` '	8x 01 04 08 3p FF	many Feavy Position
	Direct Auto Focus	8x 01 04 48 0p 0q 0r 0s FF	pqrs: Focus Position AF ON/OFF
		8x 01 04 38 02 FF 8x 01 04 38 03 FF	A SIVOIT
	Manual Focus		-
	Auto/Manual	8x 01 04 38 10 FF	One Duch AE Trioner
	One Push Trigger	8x 01 04 18 01 FF	One Push AF Trigger
	Infinity	8x 01 04 18 02 FF	Forced infinity
	Near Limit	8x 01 04 28 0p 0q 0r 0s FF	pqrs: Focus Near Limit Position

EVI-D70/P Command List (2/4)

Command Set	Command	Command Packet	Comments
AF Sensitivity	Normal	8x 01 04 58 02 FF	AF Sensitivity Normal/Low
	Low	8x 01 04 58 03 FF	
CAM_AFMode	Normal AF	8x 01 04 57 00 FF	AF Movement Mode
	Interval AF	8x 01 04 57 01 FF	
	Zoom Trigger AF	8x 01 04 57 02 FF	
	Active/Interval Time	8x 01 04 27 0p 0q 0r 0s FF	pq: Movement Time, rs: Interval
CAM_ZoomFocus	Direct	8x 01 04 47 0p 0q 0r 0s	pqrs: Zoom Position
		0t 0u 0v 0w FF	tuvw: Focus Position
CAM_Initialize	Lens	8x 01 04 19 01 FF	Lens Initialization Start
	Comp Scan	8x 01 04 19 02 FF	Correction of CCD pixel blemishes
CAM_WB	Auto	8x 01 04 35 00 FF	Normal Auto
	Indoor	8x 01 04 35 01 FF	Indoor mode
	Outdoor	8x 01 04 35 02 FF	Outdoor mode
	One Push WB	8x 01 04 35 03 FF	One Push WB mode
	ATW	8x 01 04 35 04 FF	Auto Tracing White Balance
	Manual	8x 01 04 35 05 FF	Manual Control mode
	One Push Trigger	8x 01 04 10 05 FF	One Push WB Trigger
CAM_RGain	Reset	8x 01 04 03 00 FF	Manual Control of R Gain
	Up	8x 01 04 03 02 FF	
	Down	8x 01 04 03 03 FF	
	Direct	8x 01 04 43 00 00 0p 0q FF	pq: R Gain
CAM_BGain	Reset	8x 01 04 04 00 FF	Manual Control of B Gain
	Up	8x 01 04 04 02 FF	
	Down	8x 01 04 04 03 FF	
	Direct	8x 01 04 44 00 00 0p 0q FF	pq: B Gain
CAM_AE	Full Auto	8x 01 04 39 00 FF	Automatic Exposure mode
	Manual	8x 01 04 39 03 FF	Manual Control mode
	Shutter Priority	8x 01 04 39 0A FF	Shutter Priority Automatic Exposure mode
	Iris Priority	8x 01 04 39 0B FF	Iris Priority Automatic Exposure mode
	Bright	8x 01 04 39 0D FF	Bright Mode (Manual control)
CAM_SlowShutter	Auto	8x 01 04 5A 02 FF	Auto Slow Shutter ON/OFF
	Manual	8x 01 04 5A 03 FF	
CAM_Shutter	Reset	8x 01 04 0A 00 FF	Shutter Setting
	Up	8x 01 04 0A 02 FF	
	Down	8x 01 04 0A 03 FF	
	Direct	8x 01 04 4A 00 00 0p 0q FF	pq: Shutter Position
CAM_Iris	Reset	8x 01 04 0B 00 FF	Iris Setting
	Up	8x 01 04 0B 02 FF	
	Down	8x 01 04 0B 03 FF	
	Direct	8x 01 04 4B 00 00 0p 0q FF	pq: Iris Position
CAM_Gain	Reset	8x 01 04 0C 00 FF	Gain Setting
	Up	8x 01 04 0C 02 FF	_
	Down	8x 01 04 0C 03 FF	
	Direct	8x 01 04 4C 00 00 0p 0q FF	pq: Gain Position
CAM_Bright	Reset	8x 01 04 0D 00 FF	Bright Setting
	Up	8x 01 04 0D 02 FF	_
	Down	8x 01 04 0D 03 FF	
	Direct	8x 01 04 4D 00 00 0p 0q FF	pq: Bright Position

EVI-D70/P Command List (3/4)

Command Set	Command	Command Packet	Comments
CAM_ExpComp	On	8x 01 04 3E 02 FF	Exposure Compensation ON/OFF
	Off	8x 01 04 3E 03 FF	
	Reset	8x 01 04 0E 00 FF	Exposure Compensation Amount Setting
	Up	8x 01 04 0E 02 FF	
	Down	8x 01 04 0E 03 FF	
	Direct	8x 01 04 4E 00 00 0p 0q FF	pq: ExpComp Position
CAM_Backlight	On	8x 01 04 33 02 FF	Back Light Compensation ON/OFF
	Off	8x 01 04 33 03 FF	
CAM_SpotAE	On	8x 01 04 59 02 FF	Spot Automatic Exposure Setting
	Off	8x 01 04 59 03 FF	
	Position	8x 01 04 29 0p 0q 0r 0s FF	pq: X (0 to F), rs: Y (0 to F)
CAM_Aperture	Reset	8x 01 04 02 00 FF	Aperture Control
	Up	8x 01 04 02 02 FF	
	Down	8x 01 04 02 03 FF	
	Direct	8x 01 04 42 00 00 0p 0q FF	pq: Aperture Gain
CAM_LR_Reverse	On	8x 01 04 61 02 FF	Mirror Image ON/OFF
	Off	8x 01 04 61 03 FF	
CAM_Freeze	On	8x 01 04 62 02 FF	Still Image ON/OFF
	Off	8x 01 04 62 03 FF	
CAM_PictureEffect	Off	8x 01 04 63 00 FF	Picture Effect Setting
	Neg.Art	8x 01 04 63 02 FF	
	B&W	8x 01 04 63 04 FF	
CAM_ICR	On	8x 01 04 01 02 FF	Infrared Mode ON/OFF
	Off	8x 01 04 01 03 FF	
CAM_AutoICR	On	8x 01 04 51 02 FF	Auto Infrared Mode ON/OFF
	Off	8x 01 04 51 03 FF	
CAM_Memory	Reset	8x 01 04 3F 00 0p FF	p: Memory Number (=0 to 5)
	Set	8x 01 04 3F 01 0p FF	Corresponds to 1 to 6 on the Remote Commander.
	Recall	8x 01 04 3F 02 0p FF	
CAM_Display	On	8x 01 04 15 02 FF	Display ON/OFF
		(8x 01 06 06 02 FF)	
	Off	8x 01 04 15 03 FF	
		(8x 01 06 06 03 FF)	
	On/Off	8x 01 04 15 10 FF	
		(8x 01 06 06 10 FF)	
CAM_Title	Title Set1	8x 01 04 73 00 mm nn pp	mm: Vposition, nn: Hposition
		qq 00 00 00 00 00 00 FF	pp: Color, qq: Blink
	Title Set2	8x 01 04 73 01 mm nn pp	mnpqrstuvw: Setting of Display Characters
		qq rr ss tt uu vv ww FF	(1st to 10th Character)
	Title Set3	8x 01 04 73 02 mm nn pp	mnpqrstuvw: Setting of Display Characters
		qq rr ss tt uu vv ww FF	(11th to 20th Character)
	Title Clear	8x 01 04 74 00 FF	Title Setting Clear
	On	8x 01 04 74 02 FF	Title Display ON/OFF
	Off	8x 01 04 74 03 FF	
CAM_Mute	On	8x 01 04 75 02 FF	Mute ON/OFF
	Off	8x 01 04 75 03 FF	
	On/Off	8x 01 04 75 10 FF	

EVI-D70/P Command List (4/4)

Command Set	Command	Command Packet	Comments
CAM_KeyLock	Off	8x 01 04 17 00 FF	Camera Control Enable/Disable
	On	8x 01 04 17 02 FF	
CAM_IDWrite		8x 01 04 22 0p 0q 0r 0s FF	pqrs: Camera ID (=0000 to FFFF)
CAM_Alarm	On	8x 01 04 6B 02 FF	Alarm ON/OFF
	Off	8x 01 04 6B 03 FF	
	SetMode	8x 01 04 6C pp FF	PP: Mode Settings 00 Focus Move Detection (The rest position is fixed.) 01 Focus Move Detection (The rest position is reset.) 02 AE Move Detection (The rest value is fixed.) 01 AE Move Detection (The rest value is reset.)
	SetDayNightLevel	8x 01 04 6D 0p 0p 0p 0q 0q 0q FF	ppp: Day distinction AE level qqq: Night distinction AE level.
	Alarm (Reply)	y0 07 04 6B 01 FF	Detect Level "Low" → "High"
		y0 07 04 6B 00 FF	Detect Level "High" → "Low"
IR_Receive	On	8x 01 06 08 02 FF	IR(remote commander) receive ON/OFF
	Off	8x 01 06 08 03 FF	
	On/Off	8x 01 06 08 10 FF	
IR_ReceiveReturn	On	8x 01 7D 01 03 00 00 FF	IR(remote commander) receive message ON/OFF
	Off	8x 01 7D 01 13 00 00 FF	
Pan-tiltDrive	Up	8x 01 06 01 VV WW 03 01 FF	VV: Pan speed 01 to 18
	Down	8x 01 06 01 VV WW 03 02 FF	WW: Tilt Speed 01 to 17
	Left	8x 01 06 01 VV WW 01 03 FF	YYYY: Pan Position F725 to 08DB (center 0000)
	Right	8x 01 06 01 VV WW 02 03 FF	ZZZZ: Tilt Position FE70 to 04B0 (Image Flip: OFF)
	UpLeft	8x 01 06 01 VV WW 01 01 FF	(center 0000)
	UpRight	8x 01 06 01 VV WW 02 01 FF	Tilt Position FB50 to 0190 (Image Flip: ON) (center 0000)
	DownLeft	8x 01 06 01 VV WW 01 02 FF	See page 51.
	DownRight	8x 01 06 01 VV WW 02 02 FF	
	Stop	8x 01 06 01 VV WW 03 03 FF	
	AbsolutePosition	8x 01 06 02 VV WW 0Y 0Y 0Y 0Y 0Z 0Z 0Z 0Z FF	
	RelativePosition	8x 01 06 03 VV WW 0Y 0Y 0Y 0Y 0Z 0Z 0Z 0Z FF	
	Home	8x 01 06 04 FF	
	Reset	8x 01 06 05 FF	
Pan-tiltLimitSet	LimitSet	8x 01 06 07 00 0W 0Y 0Y 0Y 0Y 0Z 0Z 0Z 0Z FF	W: 1 UpRight YYYY: Pan Limit Position 0001~08DB
	LimitClear	8x 01 06 07 01 0W 07 0F 0F 0F 07 0F 0F 0F FF	ZZZZ: Tilt Limit Position 0001~04B0 (Image Flip: OFF) Tilt Limit Position 0001~0190 (Image Flip: ON) W: 0 DownLeft YYYY: Pan Limit Position F725~FFFF ZZZZ: Tilt Limit Position FE70~FFFF (Image Flip: OFF)

EVI-D70/P Inquiry Command List (1/2)

Inquiry Command	Command Packet	Inquiry Packet	Comments
CAM_PowerInq	8x 09 04 00 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_AutoPowerOffInq	8x 09 04 40 FF	y0 50 0p 0q 0r 0s FF	pqrs: PowerOff Timer
CAM_NightPowerOff Inq	8x 09 04 41 FF	y0 50 0p 0q 0r 0s FF	pqrs: NightPowerOff Timer
CAM_ZoomPosInq	8x 09 04 47 FF	y0 50 0p 0q 0r 0s FF	pqrs: Zoom Position
CAM_DZoomModeInq	8x 09 04 06 FF	y0 50 02 FF	D-Zoom On
		y0 50 03 FF	D-Zoom Off
CAM_DZoomC/SModeInq	8x 09 04 36 FF	y0 50 00 FF	Combine Mode
		y0 50 01 FF	Separate Mode
CAM_DZoomPosInq	8x 09 04 46 FF	y0 50 00 00 0p 0q FF	pq: D-Zoom Position
CAM_FocusModeInq	8x 09 04 38 FF	y0 50 02 FF	Auto Focus
		y0 50 03 FF	Manual Focus
CAM_FocusPosInq	8x 09 04 48 FF	y0 50 0p 0q 0r 0s FF	pqrs: Focus Position
CAM_FocusNearLimitInq	8x 09 04 28 FF	y0 50 0p 0q 0r 0s FF	pqrs: Focus Near Limit Position
CAM_AFSensitivityInq	8x 09 04 58 FF	y0 50 02 FF	AF Sensitivity Normal
		y0 50 03 FF	AF Sensitivity Low
CAM_AFModeInq	8x 09 04 57 FF	y0 50 00 FF	Normal AF
		y0 50 01 FF	Interval AF
		y0 50 02 FF	Zoom Trigger AF
CAM_AFTimeSettingInq	8x 09 04 27 FF	y0 50 0p 0q 0r 0s FF	pq: Movement Time, rs: Interval
CAM_WBModeInq	8x 09 04 35 FF	y0 50 00 FF	Auto
		y0 50 01 FF	In Door
		y0 50 02 FF	Out Door
		y0 50 03 FF	One Push WB
		y0 50 04 FF	ATW
		y0 50 05 FF	Manual
CAM_RGainInq	8x 09 04 43 FF	y0 50 00 00 0p 0q FF	pq: R Gain
CAM_BGainInq	8x 09 04 44 FF	y0 50 00 00 0p 0q FF	pq: B Gain
CAM_AEModeInq	8x 09 04 39 FF	y0 50 00 FF	Full Auto
		y0 50 03 FF	Manual
		y0 50 0A FF	Shutter Priority
		y0 50 0B FF	Iris Priority
		y0 50 0D FF	Bright
CAM_SlowShutterModeInq	8x 09 04 5A FF	y0 50 02 FF	Auto
		y0 50 03 FF	Manual
CAM_ShutterPosInq	8x 09 04 4A FF	y0 50 00 00 0p 0q FF	pq: Shutter Position
CAM_IrisPosInq	8x 09 04 4B FF	y0 50 00 00 0p 0q FF	pq: Iris Position
CAM_GainPosInq	8x 09 04 4C FF	y0 50 00 00 0p 0q FF	pq: Gain Position
CAM_BrightPosInq	8x 09 04 4D FF	y0 50 00 00 0p 0q FF	pq: Bright Position
CAM_ExpCompModeInq	8x 09 04 3E FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_ExpCompPosInq	8x 09 04 4E FF	y0 50 00 00 0p 0q FF	pq: ExpComp Position
CAM_BacklightModeInq	8x 09 04 33 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_SpotAEModeInq	8x 09 04 59 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_SpotAEPosInq	8x 09 04 29 FF	y0 50 0p 0q 0r 0s FF	pq: X position, rs: Y position
CAM_ApertureInq	8x 09 04 42 FF	y0 50 00 00 0p 0q FF	pq: Aperture Gain

EVI-D70/P Inquiry Command List (2/2)

Inquiry Command	Command Packet	Inquiry Packet	Comments
CAM_LR_ReverseModeInq	8x 09 04 61 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_FreezeModeInq	8x 09 04 62 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_PictureEffectModeInq	8x 09 04 63 FF	y0 50 00 FF	Off
-		y0 50 02 FF	Neg.Art
		y0 50 04 FF	B&W
CAM_ICRModeInq	8x 09 04 01 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_AutoICRModeInq	8x 09 04 51 FF	y0 50 02 FF	On
·		y0 50 03 FF	Off
CAM_MemoryInq	8x 09 04 3F FF	y0 50 pp FF	pp: Last Recall Memory No.
CAM_DisplayModeInq	8x 09 04 15 FF	y0 50 02 FF	On
_ 1	(8x 09 06 06 FF)	y0 50 03 FF	Off
CAM_TitleDisplayModeInq	8x 09 04 74 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_MuteModeInq	8x 09 04 75 FF	y0 50 02 FF	On
orm_material	0.000017511	y0 50 03 FF	Off
CAM_KeyLockIng	8x 09 04 17 FF	y0 50 00 FF	Off
Ormi_ncyEockinq	0.0 0 0 1 1 / 11	y0 50 02 FF	On
CAM_IDInq	8x 09 04 22 FF	y0 50 0p 0q 0r 0s FF	pqrs: Camera ID
CAM VersionIng	8x 09 00 02 FF	y0 50 00 01	mnpq: Model Code (04xx)
CAM_versioning	82 09 00 02 11	mn pq rs tu vw FF	rstu: ROM version
		r 1	vw: Socket Number (=02)
			See page 34.
CAM_AlarmInq	8x 09 04 6B FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_AlarmModeInq	8x 09 04 6C FF	y0 50 pp FF	pp: Alarm Mode
CAM_AlarmDayNightLevelInq	8x 09 04 6D FF	y0 50 0p 0p 0p	ppp: Day setting AE Level
		0q 0q 0q 0r 0r 0r FF	qqq: Night setting AE Level
			rrr: Now AE Level
CAM_PictureFlipModeInq	8x 09 04 66 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_AlarmDetectLevelInq	8x 09 04 6E FF	y0 50 01 FF	Detect Level "High"
		y0 50 00 FF	Detect Level "Low"
Pan-tiltModeInq	8x 09 06 10 FF	y0 50 pq rs FF	pqrs: Pan/Tilter Status See page 51.
Pan-tiltMaxSpeedInq	8x 09 06 11 FF	y0 50 ww zz FF	ww = Pan Max Speed
			zz = Tilt Max Speed
Pan-tiltPosInq	8x 09 06 12 FF	y0 50 0w 0w 0w 0w	wwww = Pan Position
		0z 0z 0z 0z FF	zzzz = Tilt Position See page 51.
IR_ReceiveReturn		y0 07 7D 01 04 00 FF	Power ON/OFF
		y0 07 7D 01 04 07 FF	Zoom tele/wide
		y0 07 7D 01 04 38 FF	AF On/Off
		y0 07 7D 01 04 33 FF	CAM_Backlight
		y0 07 7D 01 04 3F FF	CAM_Memory
		y0 07 7D 01 06 01 FF	Pan_tiltDrive

EVI-D70/P Block Inquiry Command List

Lens control system inquiry commands Command Packet 8x 09 7E 7E 00 FF

Byte	Bit	Comments	
	7		
	6	Destination Address	
	5	Destination Address	
0	4		
	3		
	2	Source Address	
	1	Source radices	
	0		
	7	0 Completion Message (50h)	
	6	1	
	5	0	
1	4	1	
	3	0	
	2	0	
	1	0	
	0	0	
	7	0	
	6	0	
	5	0	
2	4	0	
	3		
	2	Zoom Position (HH)	
	0		
	7	0	
	6	0	
	5	0	
	4	0	
3	3	-	
	2		
	1	Zoom Position (HL)	
	0		
	7	0	
	6	0	
	5	0	
4	4	0	
4	3		
	2	Zoom Position (LII)	
	1	Zoom Position (LH)	
	0		
	7	0	
	6	0	
	5	0	
5	4	0	
	3		
	2	Zoom Position (LL)	
	1	2000 200000 (22)	
	0		

Byte	Bit	Comments
	7	0
	6	0
	5	0
	4	0
6	3	
	2	
	1	Focus Near Limit (H)
	0	
	7	0
	6	0
	5	0
	4	0
7	3	0
	-	
	2	Focus Near Limit (L)
	1	
	0	0
	7	0
	6	0
	5	0
8	4	0
	3	
	2	Focus Position (HH)
	1	
	0	0
	7	0
	5	0
	4	0
9	3	0
	2	
	1	Focus Position (HL)
	0	
	7	0
	6	0
	5	0
	4	0
10	3	- V
	2	
	1	Focus Position (LH)
	0	
	7	0
	6	0
	5	0
	4	0
11	3	U
	-	
	2	Focus Position (LL)
	1	
	0	

Byte	Bit	Comments		
	7	0		
	6	0		
	5	0		
10	4	0		
12	3	0		
	2	0		
	1	0		
	0	0		
	7	0		
	6	0		
	5	DZoomMode 1: Separate 0: Combine		
13	4	0: Normal Interval 1: Zoom		
	3	0: Normal Interval Zoom O: Trigger		
	2	AF Sensitivity 1: Normal 0: Slow		
	1	Digital Zoom 1:On 0:Off		
	0	Focus Mode 1:Auto 0:Manual		
	7	0		
	6	0		
	5	0		
	4	0		
	3	Low Contrast Detection 1: Yes 0: No		
14	2	Camera Memory Recall 1: Executing 0: Stopped		
	1	Focus Command 1: Executing 0: Stopped		
	0	Zoom Command 1: Executing 0: Stopped		
	7	1 Terminator (FFh)		
	6	1		
	5	1		
	4	1		
15	3	1		
	2	1		
	1	1		
	0	1		

Camera control system inquiry commands .. Command Packet 8x 09 7E 7E 01 FF

Byte	Bit	Comments		
	7			
	6	5		
	5	Destination Address		
	4			
0	3			
	2			
	1	Source Address		
	0			
	7	0 Completion Message (50h)		
	6	1		
	5	0		
,	4	1		
1	3	0		
	2	0		
	1	0		
	0	0		
	7	0		
	6	0		
	5	0		
	4	0		
2	3			
	2	P.C.: (II)		
	1	R Gain (H)		
	0			
	7	0		
	6	0		
	5	0		
	4	0		
3	3			
	2	D.C. (I.)		
	1	R Gain (L)		
	0			
	7	0		
	6	0		
	5	0		
4	4	0		
-	3			
	2	B Gain (H)		
	1	D Galli (H)		
	0			
	7	0		
	6	0		
	5	0		
5	4	0		
,	3			
	2	B Gain (L)		
	1	D Galli (L)		
	0			

Byte	Bit	Comments
	7	0
	6	0
	5	0
	4	0
6	3	0
	2	
	1	WB Mode
	0	
	7	0
	6	0
	5	0
_	4	0
7	3	
	2	
	1	Aperture Gain
	0	
	7	0
	6	0
	5	0
	4	
8	3	
	2	Exposure Mode
	1	—-г
	0	
	7	0
	6	0
	5	0
	4	0
9	3	Spot AE 1: On 0: Off
	2	Back Light 1:On 0:Off
	1	Exposure Comp. 1:On 0:Off
	0	Slow Shutter 1:Auto 0:Manual
	7	0
	6	0
	5	0
	4	
10	3	
	2	Shutter Position
	1	
	0	
	7	0
	6	0
	5	0
	4	
11	3	
	2	Iris Position
	1	
	-	i e e e e e e e e e e e e e e e e e e e

Byte	Bit	Comments	
	7	0	
	6	0	
	5	0	
12	4	0	
12	3		
	2	Gain Position	
	1	Gain Position	
	0		
	7	0	
	6	0	
	5	0	
13	4		
15	3		
	2	Bright Position	
	1		
	0		
	7	0	
	6	0	
	5	0	
14	4	0	
14	3		
	2	Exposure Comp. Position	
	1	Exposure Comp. Fosition	
	0		
	7	1 Terminator (FFh)	
	6	1	
	5	1	
15	4	1	
15	3	1	
	2	1	
	1	1	
	0	1	

Other inquiry commands...... Command Packet 8x 09 7E 7E 02 FF

7	
5 Destination Address	
0 5 4 3 2 Source Address 0	
0 3 2 1 Source Address 0	
Source Address	
Source Address 0	
0	
7 0 Completion Message (50h)	
	1
6 1	
5 0	
4 1	
1 3 0	
2 0	
1 0	
0 0	
7 0	
6 0	
5 0	
4 0	
2 3 0	
2 Auto ICR 1: On 0: Off	
1 0	
0 Power 1: On 0: Off	
7 0	
6 0	
5 0	
4 ICR 1: On 0: Off	
3 Freeze 1:On 0:Off	
2 LR Reverse 1:On 0:Off	
1 0	
0 0	
7 0	
6 0	
5 0	
4 Mute 1: On 0: Off	
4 3 Title Display 1: On 0: Off	
2 Display 1: On 0: Off	
1 0	
0 0	
7 0	
6 0	
5 0	
4 0	
5 3	
2	
Picture Effect Mode	
0	

Byte	Bit	Comments
	7	0
	6	0
	5	0
	4	0
6	3	0
	2	0
	1	0
	0	0
	7	0
	6	0
	5	0
	4	0
7	3	0
	2	0
	1	0
	0	0
	7	0
	6	0
	5	0
8	4	0
	3	·
	2	
	1	Camera ID (HH)
	0	
	7	0
	6	0
	5	0
	4	0
9	3	0
	2	
	1	Camera ID (HL)
	0	
	7	0
	6	0
	5	0
	4	0
10	3	V
	2	
	1	Camera ID (LH)
	0	
		0
	7 6	0
	-	
	5	0
11	4	0
	3	
	2	Camera ID (LL)
	1	
	0	

Byte	Bit	Comments
	7	0
	6	0
	5	0
	4	1
12	3	0
	2	1
	1	0
	0	System 1:PAL 0:NTSC
	7	0
	6	0
	5	0
10	4	0
13	3	0
	2	0
	1	0
	0	0
	7	0
	6	0
	5	0
	4	0
14	3	0
	2	0
	1	0
	0	0
	7	1 Terminator (FFh)
	6	1
	5	1
1.5	4	1
15	3	1
	2	1
	1	1
	0	1

Enlargement Function Query Command Command Packet 8x 09 7E 7E 03 FF

Byte	Bit	Comments	
	7		
	6	D 2 2 4 11	
	5	Destination Address	
	4		
0	3		
	2	C A 11	
	1	Source Address	
	0		
	7	0 Completion Message (50h)	
	6	1	
	5	0	
1	4	1	
•	3	0	
	2	0	
	1	0	
	0	0	
	7	0	
	6	0	
	5	0	
2	4	0	
	3		
	2	Digital Zoom Position (H)	
	1		
	0		
	7	0	
	6	0	
	5	0	
3	3	0	
	2		
	1	Digital Zoom Position (L)	
	0		
	7	0	
	6	0	
	5	0	
	4	0	
4	3	<u> </u>	
	2		
	1	AF Activation Time (H)	
	0		
	7	0	
	6	0	
	5	0	
	4	0	
5	3		
	2		
	1	AF Activation Time (L)	
	0		

Byte Bit		Comments
-	7	0
	6	0
	5	0
	4	0
6	3	
	2	
	1	AF Interval Time (H)
	0	
	7	0
	6	0
	5	0
7	4	0
7	3	
	2	AFILM ATT' (I)
	1	AF Interval Time (L)
	0	
	7	0
	6	0
	5	0
8	4	0
0	3	
	2	SpotAE Position (X)
	1	SpotAL Fosition (X)
	0	
	7	0
	6	0
	5	0
9	4	0
	3	
	2	SpotAE Position (Y)
	1	*
	0	
	7	0
	6	0
	5	0
10	4	0
	3	0
	2	0
	1	Alarm (1: On, 0: Off)
	0	Image flip (1: On, 0: Off)
	7	0 0
	5	0
	4	0
11	3	0
	2	0
	1	1
	0	1
	_ <u> </u>	1

Byte	Bit	Comments
	7	0
	6	0
	5	0
10	4	0
12	3	0
	2	0
	1	0
	0	0
	7	0
	6	0
	5	0
1.2	4	0
13	3	0
	2	0
	1	0
	0	0
	7	0
	6	0
	5	0
1.4	4	0
14	3	0
	2	0
	1	0
	0	0
	7	1 Terminator (FFh)
	6	1
	5	1
15	4	1
13	3	1
	2	1
	1	1
	0	1

VISCA Command Setting Values

Exposure Control (1/2)

		NTSC	PAL
Shutter Speed	15	10000	10000
	14	6000	6000
	13	4000	3500
	12	3000	2500
	11	2000	1750
	10	1500	1250
	0F	1000	1000
	0E	725	600
	0D	500	425
	0C	350	300
	0B	250	215
	0A	180	150
	09	125	120
	08	100	100
	07	90	75
	06	60	50
	05	30	25
	04	15	12
	03	8	6
	02	4	3
	01	2	2
	00	1	1
Iris	11	F1.4	
	10	F1.6	
	0F	F2.0	
	0E	F2.4	
	0D	F2.8	
	0C	F3.4	
	0B	F4.0	
	0A	F4.8	
	09	F5.6	
	08	F6.8	
	07	F8.0	
	06	F9.6	
	05	F11	
	04	F14	
	03	F16	
	02	F19	
	01	F22	
	00	CLOSE	

0F	28 dB
0E	26 dB
0D	24 dB
0C	22 dB
0B	20 dB
0A	18 dB
09	16 dB
08	14 dB
07	12 dB
06	10 dB
05	8 dB
04	6 d B
03	4 dB
02	+2 dB
01	0
00	−3 dB
	0E 0D 0C 0B 0A 09 08 07 06 05 04 03 02 01

Exposure Control (2/2)

		IRIS	GAIN
Bright	1F	F1.4	28 dB
	1E	F1.4	26 dB
	1D	F1.4	24 dB
	1C	F1.4	22 dB
	1B	F1.4	20 dB
	1A	F1.4	18 dB
	19	F1.4	16 dB
	18	F1.4	14 dB
	17	F1.4	12 dB
	16	F1.4	10 dB
	15	F1.4	8 dB
	14	F1.4	6 dB
	13	F1.4	4 dB
	12	F1.4	2 dB
	11	F1.4	0
	10	F1.6	0
	0F	F2.0	0
	0E	F2.4	0
	0D	F2.8	0
	0C	F3.4	0
	0B	F4.0	0
	0A	F4.8	0
	09	F5.6	0
	08	F6.8	0
	07	F8.0	0
	06	F9.6	0
	05	F11	0
	04	F14	0
-	03	F16	0
	02	F19	0
-	01	F22	0
	00	CLOSE	0
Exposure Comp.	0E	7	10.5 dB
Exposure comp.	0D	6	9 dB
	0C	5	7.5 dB
-	0B	4	6 dB
	0A	3	4.5 dB
	09	2	3 dB
}	09	1	1.5 dB
	08	0	0 dB
-	06	-1	-1.5 dB
	05	-2	-1.3 dB
	03	-2 -3	-3 dB -4.5 dB
}	03	-3 -4	-4.5 dB -6 dB
}			
	02	-5	-7.5 dB
-	01	-6	-9 dB
	00	_7	-10.5 dB

Zoom Ratio and Zoom Position (for reference)

Zoom Ratio ×18 Lens	Optical Zoom Position Data
×1	0000
×2	1606
×3	2151
×4	2860
×5	2CB5
×6	3060
×7	32D3
×8	3545
×9	3727
×10	38A9
×11	3A42
×12	3B4B
×13	3C85
×14	3D75
×15	3E4E
×16	3EF7
×17	3FA0
×18	4000

When using Combine Mode (CAM_ZoomPos Inq)

Digital Zoom Ratio	Digital Zoom Position Data
×1	4000
×2	6000
×3	6A80
×4	7000
×5	7340
×6	7540
×7	76C0
×8	7800
×9	7900
×10	7980
×11	7A40
×12	7AC0

When using Digital Zoom Separate Mode (CAM_DZoomPos Inq)

Magnification	Position Data
×1	00
×2	80
×3	AA
×4	C0
×5	CC
×6	D5
×7	DB
×8	E0
×9	E3
×10	E6
×11	E8
×12	EB

Lens Control

Zaam Daaitian	0000	to 4000 to 74		7AC0		
Zoom Position	Wide end	ΟĮ	Optical Tele end Digital Tele			Digital Tele end
F 5 32	1000	to	C	2000		
Focus Position	Far end		Ne	ar end		
	1000: Over Inf					
	2000: 8.0 m					
	3000: 3.5 m					
	4000: 2.0 m	As the distance on the lower will differ due to temperature characterist etc., use as approximate values.		nce on the left		
	5000: 1.4 m			lue to		
Focus Near	6000: 1 m			characteristics,		
Limit	7000: 80 cm			approximate		
	8000: 29 cm					
	9000: 10 cm			* The lower 1 byte is fi at 00.		1 byte is fixed
	A000: 4.7 cm					
	B000: 2.3 cm					
	C000: 1.0 cm					

Pan/Tilt Position (Reference values)

		Pan Position Data	Tilt Position Data	Tilt Position Data
			(Image Flip: OFF)	(Image Flip: ON)
Angle	+170°	08DB	_	_
	+150°	07DB	_	_
	+90°	04B0	04B0	-
	+30°	0190	0190	0190
	+10°	0085	0085	0085
	+0.075°	0001	0001	0001
	0°	0000	0000	0000
	-0.075°	FFFF	FFFF	FFFF
	-10°	FF7B	FF7B	FF7B
	-30°	FE70	FE70	FE70
	-90°	FB50	_	FB50
	-150°	F830	_	_
	-170°	F725	=	=

Others

R,B gain	00~FF
Aperture	00~0F

Title Setting

Vposition	00	to 0A
Hposition	00	to 17
DI:-1	00: Doe	es not blink
Blink	01: Blin	ıks
	00	White
	01	Yellow
	02	Violet
Color	03	Red
	04	Cyan
	05	Green
	06	Blue

Pan/Tilt Status Code List

	s	R	Q	P
all the way to the left	1	0		0
all the way to the right	1-	0		0
all the way up	- 1	0		0
all the way down	1	0		0
correct		00		0
ot be detected		01		0
sm is abnormal		10		0
nt is correct		0	00	0
cannot be detected		0	01	0
m is abnormal		0	10	0
tructions		0	00	0
Pan/Tilt		0	01	0
d		0	10	0
		0	11	0
		0		0 - 0 0
		0		0 - 0 1
pleted		0		0 - 1 0
d		0		0 - 1 1
ent is correct cannot be detected m is abnormal tructions can/Tilt d		0 - 0 -	00 01 10 00 01 11 	0 0 0 0 0 0 0 0 - 0 0 0 - 0 1 0 - 1 0

^{(-:} optional)

A + indicates a pan to the right and a tilt upward on the monitor screen.

A – indicates a pan to the left and a tilt downward on the monitor screen.