# HW#4 RTOS Analysis



Chun-Jen Tsai NYCU 11/17/2023

#### Homework Goal

- □ In this homework, you will analyze the performance of a real-time OS (RTOS), FreeRTOS, for multithreading
- □ Your tasks:
  - Trace the OS kernel code and analyze how thread management and synchronization are done
  - Measure the context-switching overhead of the application (need to add counters in Aquila)
  - Measure the synchronization overhead of the application (better to add counters in Aquila)
- □ You should upload your report to E3 by 12/8, 17:00.
  - Report is 4 pages max, PDF format only. No demo this time.

#### **FreeRTOS**

- □ FreeRTOS is a C-based real-time operating system kernel for embedded devices
  - Developed by Richard Barry in 2003
  - Barry joined Amazon Web Services (AWS) and passed the stewardship of the project to AWS in 2017
  - The project adopts MIT License
- □ We used FreeRTOS v202111.00 in this HW:
  - All RISC-V unrelated sources are removed (way too big)
  - The original source available at <a href="https://www.freertos.org/">https://www.freertos.org/</a>
  - No need to modify source code of FreeRTOS for Aquila

## FreeRTOS Multithreading API

- Unlike other programming languages, C does not have a standard API for multithreading
  - ISO C11 has a multithreading API since 2011, but the most popular API is still the non-standard pthread API
- □ FreeRTOS Multithreading API is quite simple:


```
/* Two threads creation for FreeRTOS */
int main(void)
{
   int prm1 = 1, prm2 = 2;
   xTaskCreate(Task_Handler, "Task1", 256, (void *) &prm1, 3, NULL);
   xTaskCreate(Task_Handler, "Task2", 256, (void *) &prm2, 4, NULL);
   vTaskStartScheduler();
}

void Task_Handler(void *pvParam)
{
   for (int idx = 0; idx < 10/(int) *pvParam; idx++) {
      printf("\nThis is Task%d.\n", (int) *pvParam);
      vTaskDelay(1000/portTICK_PERIOD_MS); // sleep a while.
   }

vTaskDelete(NULL); /* Thread ends, delete it from the task queue. */
}</pre>
```


## Target Application: rtos\_run

□ Download rtos run.tgz from E3:



## Application Behavior of rtos\_run

☐ There are three visible threads and two invisible threads in the rtos run application:



#### Protection of Shared Resources

☐ In a preemptive multi-tasking OS, shared resources cannot be modified without protection:

```
volatile int
    shared_counter = 0,
    done = 0;

Task1()
{
    while (!done)
    {
        shared_counter++;
    }
}

Task2()
{
    while (!done)
    {
        shared_counter++;
    }
}
```

```
80000030 <Task1>:
80000030: lui a3, 0x80008
80000034: lw a5, 8(a3) # <done>
80000038: bnez a5, 80000054 <Task1+0x24>
8000003c: lui a4, 0x80008
80000040: lw a5, 12(a4) # <shared_counter>
80000044: addi a5, a5, 1
80000048: sw a5, 12(a4)
8000004c: lw a5, 8(a3)
80000050: beqz a5, 80000040 <Task1+0x10>
80000054: ret
```

#### **Default Execution**

- □ When you compile and run the application you should see the following output
  - The result is bad because we did not enable mutex protection

```
Copyright (c) 2019-2023, EISL@NYCU, Hsinchu, Taiwan.
The Aquila SoC is ready.
Waiting for an ELF file to be sent from the UART ...

Program entry point at 0x8000144C, size = 0xAE60.

Task 1 start running ...

Task 2 start running ...

At the end, the shared counter = 10000
Task1 local counter = 10000
Task2 local counter = 9263
Task1 counter + Task2 counter != Shared counter, the counter is corrupted.
```

#### Application with Mutex Protection

- □ With mutex protection of the shared variable, the output would be good
  - Made the change: "#define USE\_MUTEX 1" in rtos\_run.c

```
Copyright (c) 2019-2023, EISL@NYCU, Hsinchu, Taiwan.
The Aquila SoC is ready.
Waiting for an ELF file to be sent from the UART ...

Program entry point at 0x800014C4, size = 0xAE60.

Task 1 start running ...

Task 2 start running ...

At the end, the shared counter = 10000
Task1 local counter = 3065
Task2 local counter = 6935
The shared counter is protected well.
```

## Context-Switching Overhead

- □ A preemptive multi-tasking OS uses timer interrupts to assign CPU usage from one thread to the other
  - The context-switching overhead is inversely proportional to the time quantum (slice)
  - The default of FreeRTOS time quantum is 10 msec
- ☐ To measure the context-switching overhead, you must count the number of cycles between:
  - A timer interrupt arrives
  - A new thread begins execution
- □ You can change the time quantum size down to 5 msec to see its impact on the overhead

### The Timer Interrupt Device

- □ In Aquila, the module clint is used to provide timer interrupts and software interrupts
- □ Clint has three registers
  - mtime: 64-bit counter of timer ticks
  - mtimecmp: Upper-threshold to trigger a timer interrupt
  - msip: a 32-bit register to trigger a software interrupt
- □ FreeRTOS will update mtimecmp to setup the next context-switch time (based on time quantum duration)

## **Changing Time Quantum**

- □ In FreeRTOS, time quantum is configured by the header file: FreeRTOSConfig.h
  - The default time quantum is 10 msec:

```
#define CLINT_CTRL_ADDR
#define configMTIME_BASE_ADDRESS (CLINT_CTRL_ADDR + 0x0UL)
#define configMTIMECMP_BASE_ADDRESS (CLINT_CTRL_ADDR + 0x8UL)

#define configUSE_PREEMPTION 1
#define configUSE_IDLE_HOOK 0
#define configUSE_TICK_HOOK 1
#define configCPU_CLOCK_HZ ((uint32_t) (41666667))
#define configTICK_RATE_HZ ((TickType_t) 100)
#define configMAX_PRIORITIES (7)
#define configMINIMAL_STACK_SIZE ((uint32_t) 100)
#define configTOTAL_HEAP_SIZE ((size_t) (12 * 1024))
```

## Mutex for Synchronization

□ A mutex is a variable to indicate two states: "locked" and "unlocked" of a shared resource:

```
int mutex;

Execution blocked here if the mutex has been taken by other threads.

mutex_take(mutex);

code that uses the shared resource.

mutex_give(mutex);
```

☐ There are several approaches to implement a mutex: ISA-independent SW, ISA-dependent SW, or hardware

### Mutex Implementation

- □ Software mutex implementation techniques
  - Software algorithms (e.g. the Peterson's algorithm)
    - Drawback: time-consuming
  - Atomic test-and-set
    - Drawback: less efficient for multi-core systems
  - Conditional load-store
    - Drawback: only supported by new ISAs & CPUs
- □ Hardware mutex approach
  - A HW mutex is a device that contains a list of mutex registers
    - An unlocked register has zero in it
    - Each thread write their ID to the register to lock the mutex
    - Each register conditionally accepts the write requests
  - Suitable for synchronization even between HW and SW

## Peterson's Mutex Algorithm

- $\square$  Peterson's algorithm<sup>†</sup> guarantees exclusive accesses to a shared resource among n threads (running on n cores) without special assembly instructions
- ☐ A two-thread version is as follows:

#### CPU 0

```
/* trying protocol for T_1 */
Q1 = true; /* request to enter */
TURN = 1; /* who's turn to wait */
wait until not Q2 or TURN == 2;
Critical Section;
/* exit protocol for T_1 */
Q1 = false;
```

#### CPU 1

```
/* trying protocol for T<sub>2</sub> */
Q2 = true; /* request to enter  */
TURN = 2; /* who's turn to wait */
wait until not Q1 or TURN == 1;
Critical Section;
/* exit protocol for T<sub>2</sub> */
Q2 = false;
```

<sup>†</sup> G. L. Peterson, "Myth about the Mutual Exclusion Problem," *Information Processing Letters*, **12**, no 3, June 30, 1981.

#### Test-and-Set Atomic Instructions

□ For synchronization, a thread must execute the following code before entering a critical section:

```
int mutex; /* '0' means unlocked, '1' means locked */
while ( test_and_set(mutex) == 1) /* busy waiting */
   Code that uses the shared resource.
mutex = 0;
```

□ A 'SWAP' instruction (amoswap.w in RSIC-V) can be used to implement the test-and-set function:

```
int test_and_set(int mutex)
{
    temp = mutex;
    mutex = 1;
    return temp;
}
The first two lines cannot be interrupted during execution!
```

#### Conditional Load/Store Instructions

- Conditional load/store allows atomic operation without locking the buses
  - In RISC-V, we have LR/SC instructions
  - In ARM, we have LDREX/STREX instructions
- ☐ In this HW, you should try to use the atomic instructions (either lock-based or lock-free) to implement mutex and measure the overhead
  - The atomic operations are implemented in atomic\_unit.v

### Example Code:

■ Mutex take:

```
asm volatile ("lui t0, %hi(lock_addr)");
asm volatile ("lw t3, %lo(lock_addr)(t0)");
asm volatile ("li t0, 1");
asm volatile ("0:");
asm volatile ("lw t1, (t3)");
asm volatile ("bnez t1, 0b");
asm volatile ("amoswap.w.aq t1, t0, (t3)");
asm volatile ("bnez t1, 0b");
```

■ Mutex give:

```
asm volatile ("lui t0, %hi(lock_addr)");
asm volatile ("lw t3, %lo(lock_addr)(t0)");
asm volatile ("amoswap.w.rl x0, x0, (t3)");
```

#### Mutex Take/Give in FreeRTOS

- Note that, for FreeRTOS, most of the overhead in mutex take and give operations are spent in handling priority inversion
  - Queue structures are used to avoid a low priority task to block high priority tasks
  - We do not have different priorities for the two threads in the sample program
- □ Removing priority inversion processing reduces the synchronization overhead significantly, but it is not the right thing to do.

## Synchronization Overhead

- □ In the sample application, we use two synchronization schemes of FreeRTOS: critical sections and mutex
  - Critical sections are used to protect the UART device so that different threads can print concurrent messages properly
  - A mutex is use to protect a shared variable so that both threads can modify the variable without corrupting it
  - In FreeRTOS, mutex is a special type of semaphore.
- □ You should measure the overhead of these synchronization schemes and put that in your report
  - The cycles to enter & leave a critical section
  - The cycles to take & give a mutex

#### Comments on the Homework

- □ The key point of this homework is RTOS multithreading analysis
  - Performance optimization is not required
- ☐ Your grade will be totally based on your analysis of the RTOS behavior:
  - The context switching behavior analysis
    - The algorithmic description
    - Context switching overhead vs. time quantum
  - The synchronization behavior analysis
    - The algorithmic description
    - The overhead (cycles required for mutex task & give, respectively)
  - Any additional analyses you can think of regarding multithreading (e.g. impact on I\$/D\$)