Semiconductor Physics Documentation

Y.G

CONTENTS

1	Index				
	1.1	Basic physics of semiconductors	1		
		Basic equations			
	1.3	MIS structure	2		
	1.4	Bipolar transistor	3		
		MOSFET	-		

CHAPTER

ONE

INDEX

1.1 Basic physics of semiconductors

1.1.1 Strain calculation

1.1.2 Band theory

1.2 Basic equations

In this section, we introduce some basic equations related to semiconductor devices.

Index

- Basic equations
 - Poisson equation
 - Current-density equations
 - Continuity equations

1.2.1 Poisson equation

The electrostatic potential can be calculated with the corresponding charge distribution ρ with Poisson equation.

$$\nabla \cdot (\varepsilon_s \nabla \Psi) = -\rho, \tag{1.1}$$

where ε_s is the dielectric permittivity and $\varepsilon_s=11.9\varepsilon_0$ for Si. Ψ is the electrostatic potential. The electric charge density in a semiconductor is given by the summation of the electron charge density n, the hole charge density p, and the ionized impurity doping density D. Therefore,

$$\rho = q(n - p + D),\tag{1.2}$$

where q is the elementary charge. Note that D consists of the ionized acceptor and donor type impurity densities, which mean $D = N_A - N_D$.

Thus, (1.1) can be expressed as following,

$$\nabla^2 \Psi = -\frac{q(n-p+N_A-N_D)}{\varepsilon_s}.$$
(1.3)

The left side can be rewritten in the orthogonal coordinate system,

$$\nabla^2 \Psi(x, y, z) = \frac{\partial^2 \Psi}{\partial x^2} + \frac{\partial^2 \Psi}{\partial y^2} + \frac{\partial^2 \Psi}{\partial z^2}.$$
 (1.4)

For a 1D problem, (1.4) can be reduced to

$$\frac{d^2\Psi_i}{dx^2} = -\frac{d\xi}{dx} = -\frac{\rho}{\varepsilon_s} = -\frac{q(n-p+N_A-N_D)}{\varepsilon_s},\tag{1.5}$$

Of course, $\xi = -\nabla \Psi$ holds in (1.5).

Poisson equation is often used to determine the distributions of electrostatic potential and electric field caused by a charge density ρ .

1.2.2 Current-density equations

The common current equation consists of the drift component, caused by the electric field, and the diffusion component, caused by the gradient of the carrier concentration. The current density equations are below,

$$\mathbf{J_n} = q\mu_n n\xi + qD_n \nabla n,\tag{1.6}$$

$$\mathbf{J}_{\mathbf{p}} = q\mu_p p\xi - qD_p \nabla p \tag{1.7}$$

and

$$\mathbf{J_{conduction}} = \mathbf{J_n} + \mathbf{J_p},\tag{1.8}$$

where J_n and J_p are the electron and hole current densities, respectively. μ_n and μ_p are the electron and hole mobilities. For nondegenerate semiconductors, the carrier diffusion constants $(D_n$ and $D_p)$ and the mobilities are given by the Einstein relation,

$$D_n = \frac{kT}{q}\mu_n,\tag{1.9}$$

$$D_p = \frac{kT}{q}\mu_p. ag{1.10}$$

Therefore, for a 1D case, (1.6) and (1.7) can be reduced to

$$J_n = q\mu_n n\xi + qD_n \frac{dn}{dx} = q\mu_n \left(n\xi + \frac{kT}{q} \frac{dn}{dx} \right) = \mu_n n \frac{dE_{Fn}}{dx}, \tag{1.11}$$

and

$$J_p = q\mu_p p\xi - qD_p \frac{dp}{dx} = q\mu_p \left(p\xi - \frac{kT}{q} \frac{dp}{dx} \right) = \mu_p p \frac{dE_{Fp}}{dx}, \tag{1.12}$$

where E_{Fn} and E_{Fp} are quasi Fermi levels for electrons and holes, respectively.

Note that these equations are valid for low electric field ξ . If the electric field is sufficiently high, the term $\mu_n \xi$ or $\mu_p \xi$ should be replaced by the saturation velocity v_s . The last equalities about E_{Fn} and E_{Fp} do not hold any more either.

1.2.3 Continuity equations

While the above current-density equations hold for steady-state conditions, the continuity equations deal with time-dependent states such as low-level injection, generation, and recombination.

1.3 MIS structure

This document is in progress

2 Chapter 1. Index

1.4 Bipolar transistor

This document is in progress

1.5 MOSFET

This document is in progress

This documentation explains semiconuctor physics. There will be updates soon!! Stay tuned.

download