### VIETNAM NATIONAL UNIVERSITY HO CHI MINH CITY HO CHI MINH CITY UNIVERSITY OF TECHNOLOGY Faculty of Computer Science and Engineering



# MICROCONTROLLER - MICROPROCESSOR

LAB 5

# **UART**

INSTRUCTOR: Huỳnh Phúc Nghị STUDENT: Tạ Gia Bảo - 2110795

GitHub submission: github.com/zabao-qt/GIT\_LAB5


# Contents

1	$\operatorname{\mathbf{Sch}}$	nematic
	1.1	Proteus UART
2		irce code
		global.h
	2.2	FSM implementation
		2.2.1 uart_communiation_fsm() design
		2.2.2 uart_communiation_fsm()
		2.2.3 command_parser_fsm() design
		2.2.4 command_parser_fsm()
	2.3	main(void)



# 1 Schematic

#### 1.1 Proteus UART



# 2 Source code

# 2.1 global.h


Listing all the global variables.



```
17 extern int status_uart;
19 // Variables to read data
20 extern uint8_t temp;
21 extern uint8_t buffer[MAX_BUFFER_SIZE];
22 extern uint8_t index_buffer;
23 extern uint8_t buffer_flag;
24
^{25} // Variables to read command
26 extern uint8_t command_flag;
27 extern uint8_t command[MAX_BUFFER_SIZE];
28 extern uint8_t command_index;
30 // String to display console
31 extern char str[50];
32 // ADC Value
33 extern uint32_t ADC_value;
34
35 #endif /* INC_GLOBAL_H_ */
```

### 2.2 FSM implementation

#### 2.2.1 uart\_communiation\_fsm() design



#### 2.2.2 uart\_communiation\_fsm()

This FSM has 3 states: WAIT\_RST, SEND\_ADC, and WAIT\_OK. We begin at the initial state WAIT\_RST, checks command "RST". If true, update the ADC value, send to UART, set timer for 3s and move to SEND\_ADC state.

```
case WAIT_RST:
    if (command_flag == 1) {
        command_flag = 0;
        if (command[0] == 'R' && command[1] == 'S' && command[2] == 'T') {
            // Get ADC value
            HAL_ADC_Start(&hadc1);
            ADC_value = HAL_ADC_GetValue(&hadc1);
            HAL_ADC_Stop(&hadc1);
            HAL_UART_Transmit(&huart2, (void*)str, sprintf(str, "\r\n"), 1000);
            status_uart = SEND_ADC;
            setTimer(1, 3000);
}
```



```
break;
```


Then, the state transmit ADC value to UART.

```
case SEND_ADC:
// Display ADC Value console, status = WAIT_OK
HAL_UART_Transmit(&huart2, (void*)str, sprintf(str, "!ADC=%lu#\r\n", ADC_value
), 1000);
status_uart = WAIT_OK;
break;
```

Next, it checks if a command has been completed and if the command is "OK". If true, it sends a newline character over UART, transitions to the WAIT\_RST state, and clears the timer. If false, it checks if a timer flag is set. If true, it transitions to the SEND\_ADC state and sets the timer for another 3s.

```
case WAIT_OK:
       if (command_flag == 1) {
           command_flag = 0;
if (command[0] == '0' && command[1] == 'K') {
3
                HAL_UART_Transmit(&huart2, (void*)str, sprintf(str, "\r\n"), 1000);
5
6
                status_uart = WAIT_RST;
                clearTimer(1);
           }
8
9
10
       if(timer_flag[1] == 1) {
           status_uart = SEND_ADC;
11
           setTimer(1, 3000);
12
13
14
      break;
```

#### 2.2.3 command\_parser\_fsm() design



#### 2.2.4 command\_parser\_fsm()

This FSM has 2 states: INIT\_STR and WAIT\_END. It processes characters received over UART and assembles them into a command until it detects the end marker "#". It begins with INIT\_STR as the initial state. Then checks if temp is "#" to start new command. If true, switch to WAIT\_END state and reset.

```
case INIT_STR:
if(temp == '!') {
    status_parser = WAIT_END;
    command_index = 0;
}
break;
```



WAIT\_END state processes characters until the end marker "#" is received. If "#" is detected, switch back to initial state, else check if there is "!" to start new command.

```
case WAIT_END:
      if(temp == '#') {
          status_parser = INIT_STR;
          command[command_index] = '\0';
5
          command_flag = 1;
      }
6
      else {
          if (temp == '!')
8
              command_index = 0;
9
          else {
              command[command_index++] = temp;
11
              if (command_index == MAX_BUFFER_SIZE) command_index = 0;
12
13
      }
14
15
      break;
```

#### 2.3 main(void)

In the main infinite loop, we toggle LED Blinky and call two FSMs.

```
int main(void)
2 {
      // Other function calls
3
      while (1)
      {
5
          if (timer_flag[0] == 1) {
6
7
                 HAL_GPIO_TogglePin(LED_GPIO_Port, LED_Pin);
                 setTimer(0, 1000);
9
          if (buffer_flag == 1) {
10
            command_parser_fsm();
11
12
            buffer_flag = 0;
13
          uart_communiation_fsm(hadc1, huart2);
14
15
16 }
```