# Module Interface Specification for Mechatronics Engineering



Team #1, Back End Developers
Jessica Bae
Oliver Foote
Jonathan Hai
Anish Rangarajan
Nish Shah
Labeeb Zaker

April 5, 2023

# 1 Revision History

Date	Version	Notes
2023-01-18	1.0	Initial documentation
2023-03-15	2.0	Minor improvements and proof reading for revision 1
2023-04-03	2.1	Incorporated TA feedback
2023-04-03	2.2	Included logo and added style to the document

# 2 Symbols, Abbreviations and Acronyms

Please refer to the System Requirements Specifications document at this link for relevant symbols, abbreviations.

# Contents

1	Revision History						
2	Sym	nbols, Abbreviations and Acronyms					
3	Intro	Introduction 1					
4	Nota	ation					
5	Mod	Iule Decomposition					
6	MIS	of Battery Module					
	6.1	Module					
	6.2	Uses					
	6.3	Syntax					
		6.3.1 Exported Constants					
		6.3.2 Exported Access Programs					
	6.4	Semantics					
		6.4.1 State Variables					
		6.4.2 Environment Variables					
		6.4.3 Assumptions					
		6.4.4 Access Routine Semantics					
		6.4.5 Local Functions					
7		of microSD Module					
	7.1	Module					
	7.2	Uses					
	7.3	Syntax					
		7.3.1 Exported Constants					
		7.3.2 Exported Access Programs					
	7.4	Semantics					
		7.4.1 State Variables					
		7.4.2 Environment Variables					
		7.4.3 Assumptions					
		7.4.4 Access Routine Semantics					
		7.4.5 Local Functions					
8	MIS	of Local Database Module					
	8.1	Module					
	8.2	Uses					
	8.3	Syntax					
	5.5	8.3.1 Exported Constants					
		8.3.2 Exported Access Programs					
	8.4	Semantics					
	0.4	Ochianilos					

		8.4.1	State Variables																7
		8.4.2	<b>Environment Va</b>	riables															8
		8.4.3	Assumptions .																8
		8.4.4	Access Routine																8
		8.4.5	Local Functions																8
		0. 1.0	Local Fallotiono		•	•	•	•	•	•	•	•	 •	•	•	•	•	•	Ŭ
9	MIS	of Rea	ding Sensor Mo	dule															9
	9.1																		9
	9.2	Uses .																	9
	9.3																		9
		9.3.1	<b>Exported Const</b>																9
		9.3.2	Exported Acces																9
	9.4		ntics																9
		9.4.1	State Variables																9
		9.4.2	Environment Va																9
		9.4.3	Assumptions .																10
		9.4.4	Access Routine																10
		9.4.5	Local Functions																10
		3.4.3	Local i unctions		•				•			•	 •	• •	•	•	• •	•	10
10	MIS	of Sen	sor Data Proces	sina Modu	le														11
			9									_							11
																			11
			· · · · · · · · · · · · · · · · · · ·																11
		•	Exported Const																11
			Exported Acces																11
	10.4		ntics	_															11
	10.4		State Variables																11
			Environment Va																11
			Assumptions .																
			•																
			Access Routine																
		10.4.5	Local Functions		•				•		٠.	•	 •		٠	•		•	12
11	MIS	of Pror	npt Validity Mod	lule															13
•																			13
																			13
																			13
	11.5	-	Experted Const																13
			Exported Const																
			Exported Acces	•															13
	11.4		ntics																13
			State Variables																13
			Environment Va																13
			Assumptions .																13
			Access Routine																13
		11 1 5	Local Functions																12

<b>12</b>		of Display System Module	14
	12.1	Module	14
	12.2	Uses	14
	12.3	Syntax	14
		12.3.1 Exported Constants	14
		12.3.2 Exported Access Programs	14
	12.4	Semantics	14
		12.4.1 State Variables	14
		12.4.2 Environment Variables	14
		12.4.3 Assumptions	
		12.4.4 Access Routine Semantics	14
		12.4.5 Local Functions	
		12.4.3 Local Functions	17
13	MIS	of Prompt Generation Module	15
		Module	15
		Uses	
		Syntax	15
		13.3.1 Exported Constants	15
		13.3.2 Exported Access Programs	15
	13 4	Semantics	15
		13.4.1 State Variables	15
		13.4.2 Environment Variables	15
		13.4.3 Assumptions	_
		13.4.4 Access Routine Semantics	15
		13.4.5 Local Functions	15
		To.4.5 Local Functions	10
14	MIS	of Real Time Clock Module	16
	14.1	Module	16
	14.2	Uses	16
		Syntax	16
		14.3.1 Exported Constants	16
		14.3.2 Exported Access Programs	
	14.4	Semantics	16
		14.4.1 State Variables	16
		14.4.2 Environment Variables	16
		14.4.3 Assumptions	16
		14.4.4 Access Routine Semantics	16
		14.4.5 Local Functions	16
		14.4.3 Local i unctions	10
15	MIS	of Create New User Module	17
_	_	Module	17
		Uses	17
		Syntax	17
	. 3.3	15.3.1 Exported Constants	17
		15.3.2 Exported Access Programs	

	15.4	Semantics	17
			17
			17
			17
			17
			. <i>.</i> 17
		To the Education of the Control of t	•
16	MIS	of Configuration Module 1	18
			18
			18
			18
			18
		The state of the s	18
	16.4		18
	10.4		18
			10 18
			-
		to the first of th	18
			18
		16.4.5 Local Functions	18
17	NAIC	of Croph Plotter	19
17			19 19
			19 19
			_
	17.3	<b>/</b>	19
		Francisco de la companya del companya de la companya del companya de la companya	19
		- 1	19
	17.4		19
			19
		17.4.2 Environment Variables	19
		17.4.3 Assumptions	19
		17.4.4 Access Routine Semantics	19
			19
18		· · · · · · · · · · · · · · · · · · ·	20
	18.1	Module	20
	18.2	Uses	20
	18.3	Syntax	20
		18.3.1 Exported Constants	20
		·	20
	18 4		20
	10.1		-0 20
			20 20
			20 20
		I to the second of the second	20 20
		18.4.5 Local Functions	20

19	MIS of Watch Case Module
	19.1 Module
	19.2 Uses
	19.3 Syntax
	19.3.1 Exported Constants
	19.3.2 Exported Access Programs
	19.4 Semantics
	19.4.1 State Variables
	19.4.2 Environment Variables
	19.4.3 Assumptions
	19.4.4 Access Routine Semantics
	19.4.5 Local Functions

## 3 Introduction

The following document details the Module Interface Specifications for the EMAnator; the system currently being developed by the Back End Developers designed to aid in Ecological Momentary Assessment research. This document describes the various relevant details of interfacing with each module. These details include module descriptions, the uses of each module, the syntax of each module, and the semantics associated with each module.

Complementary documents include the System Requirement Specifications and the Module Guide. The Back End Developers highly recommend a thorough read-through of each document prior to a reading of this document to attain the prerequisite knowledge necessary to fully understand this MIS. The System Requirements Specifications can be found at this link, and the Module Guide can be found at this link.

## 4 Notation

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol := is used for a multiple assignment statement and conditional rules follow the form  $(c_1 \Rightarrow r_1 | c_2 \Rightarrow r_2 | ... | c_n \Rightarrow r_n)$ .

The following table summarizes the primitive data types used by Mechatronics Engineering.

Data Type	Notation	Description
Character	char	A single symbol or digit
Integer	$\mathbb{Z}$	A number without a fractional component in $(-\infty, \infty)$
Natural number	N	A number without a fractional component in $[1, \infty)$
Real	$\mathbb{R}$	Any number in $(-\infty, \infty)$

The specification of Mechatronics Engineering uses some derived data types: sequences, strings, and tuples. Sequences are lists filled with elements of the same data type. Strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, Mechatronics Engineering uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

# 5 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1	Level 2	Level 3		
	Battery Management	Battery		
	Data Storage	microSD Database		
Hardware-Hiding Module	Sensor Array	Sensor Reading Sensor Data Processing Sensor Prompt Validity		
	Physical Design	Watch Straps Watch Case		
	Display System	Display Screen		
Behaviour-Hiding Module	Prompt Generation	Prompt Generation		
	Real Time Clock	RTC		
Software Decision Module	Parameter Selection	Create New User Configuration		
Conward Decision Module	Data Processing	Graph Data Display		

Table 1: Module Hierarchy

# 6 MIS of Battery Module

#### 6.1 Module

Bat\_Man

## 6.2 Uses

None.

## 6.3 Syntax

## 6.3.1 Exported Constants

- · Minimum battery threshold for voltage
- Maximum battery limit for voltage
- Low charge indicator for 10% limit

## **6.3.2 Exported Access Programs**

Name	In	Out	Exceptions
bed_getBatteryLev	Bat₋Raw	$\mathbb Z$	BED_ERR_BAT

## 6.4 Semantics

#### 6.4.1 State Variables

None.

#### 6.4.2 Environment Variables

- battery level
- low\_Flag

## 6.4.3 Assumptions

System responds instantaneously to changes in flags (exported constants).

## 6.4.4 Access Routine Semantics

bed\_getBatteryLev:

• Transition: Extracts the current battery level

• Output: Integer percentage value of the battery level.

• Exception: BED\_ERR\_BAT = Z

## 6.4.5 Local Functions

• bed\_lowIndicator: boolean

# 7 MIS of microSD Module

## 7.1 Module

microSD\_Stor

## 7.2 Uses

Sensor Prompt Validity Module (Section 11), Real Time Clock Module (Section 14)

## 7.3 Syntax

## 7.3.1 Exported Constants

None.

#### 7.3.2 Exported Access Programs

Name	In	Out	Exceptions
listDir	FS, const char*,	dirname: string	$BED_{-}ERR_{-}SD$ : $\mathbb Z$
	uint8_t		
createDir	FS, const char *	-	$BED_{-}ERR_{-}SD$ : $\mathbb{Z}$
removeDir	FS, const char *	-	$BED_{-}ERR_{-}SD;\mathbb{Z}$

## 7.4 Semantics

#### 7.4.1 State Variables

None.

#### 7.4.2 Environment Variables

• fs: A text file.

## 7.4.3 Assumptions

- · MicroSD card is formatted correctly.
- MicroSD card is inserted correctly.

#### 7.4.4 Access Routine Semantics

## 7.4.5 Local Functions

- readFile
- writeFile
- appendFile
- renameFile
- deleteFile

# 8 MIS of Local Database Module

## 8.1 Module

Database\_Stor

## 8.2 Uses

microSD Module (Section 7)

## 8.3 Syntax

## 8.3.1 Exported Constants

• Size of the field: First Name = 25

• Size of the field: Last Name = 25

• Size of the field: Gender = 25

• Size of the field: Phone Number = 20

• Size of the field: Email = 25

• Size of the field: Address = 255

• Size of the field: Device model number = 50

## 8.3.2 Exported Access Programs

Name	In	Out	Exceptions
object.connect	-	Read_Data: string, integer	BED_ERR_DB: Z
object.cursor	Write_Data: string, integer	BED_ERR_DB: ℤ	
object.execute	Write_Data: string, integer	BED_ERR_DB: ℤ	
object.commit	Write_Data: string, integer	BED_ERR_DB: ℤ	
object.close	Write_Data: string, integer	BED_ERR_DB: ℤ	

#### 8.4 Semantics

#### 8.4.1 State Variables

#### 8.4.2 Environment Variables

- First Name
- Last Name
- Gender
- Phone Number
- Email
- Address
- Device Model Number

## 8.4.3 Assumptions

None.

#### 8.4.4 Access Routine Semantics

- object.connect(): Connects to the database.
- object.cursor(): Establishes connection between the database and the query.
- object.execute():
- object.commit():
- object.close(): Disconnects from the database.

## 8.4.5 Local Functions

# 9 MIS of Reading Sensor Module

## 9.1 Module

Sensor\_Reding

## 9.2 Uses

Battery Management (Section 6)

## 9.3 Syntax

## 9.3.1 Exported Constants

• ACCEL\_SENSITIVITY: Z

• GYRO\_SENSITIVITY: Z

• Threshold: Z

• MPU\_CALIBRATION: Z

## 9.3.2 Exported Access Programs

• bed\_mpu\_detect

• bed\_hr\_detect

## 9.4 Semantics

#### 9.4.1 State Variables

 $currTime: \mathbb{R}$ 

#### 9.4.2 Environment Variables

- curr\_ax
- curr\_ay
- curr\_az
- curr\_gx
- curr\_gy
- curr\_gz

## 9.4.3 Assumptions

• All activity thresholds are provided from the configuration file.

## 9.4.4 Access Routine Semantics

- bed\_mpu\_detect: Returns the current values of the accelerometer and gyroscope.
- bed\_hr\_detect: Returns the current values of heartrate sensor.

#### 9.4.5 Local Functions

- bed\_mpu\_setup
- bed\_hr\_setup

# 10 MIS of Sensor Data Processing Module

#### 10.1 Module

Sensor\_Data

## 10.2 Uses

Sensor Reading (Section 9)

## 10.3 Syntax

## 10.3.1 Exported Constants

- ACTIVITY\_STEPS
- ACTIVITY\_IDLE\_RESET
- ACTIVITY\_IDLE\_WAIT

## 10.3.2 Exported Access Programs

Name	ln	Out	Exceptions
HeartRate_Read	-	Read_Data: integer	BED_ERR_SE: ℤ
MPU_Read	-	Read_Data: integer	$BED_{-}ERR_{-}SE \colon \mathbb{Z}$
Touch_Read	-	Read_Data: bool	$BED_{-}ERR_{-}SE\colon \mathbb{Z}$

## 10.4 Semantics

#### 10.4.1 State Variables

None.

#### 10.4.2 Environment Variables

None.

## 10.4.3 Assumptions

• There is space available in microSD card.

#### 10.4.4 Access Routine Semantics

## 10.4.5 Local Functions

data\_smoothing\_filter(): The purpose of this function is to make sure that the data coming from all the sensors is smoothed, in order to prevent a prompt from being generated erroneously and disturbing the user.

# 11 MIS of Prompt Validity Module

## 11.1 Module

Sensor\_Prompt

## 11.2 Uses

Sensor Data Processing (Section 10)

## 11.3 Syntax

## 11.3.1 Exported Constants

## 11.3.2 Exported Access Programs

Name	In	Out	Exceptions
Check_Validity	Read_Data	Prompt_Valid: bool	$BED_ERR_SE \colon \mathbb{Z}$

## 11.4 Semantics

#### 11.4.1 State Variables

None.

#### 11.4.2 Environment Variables

None.

## 11.4.3 Assumptions

None.

#### 11.4.4 Access Routine Semantics

None.

#### 11.4.5 Local Functions

# 12 MIS of Display System Module

#### 12.1 Module

Disp\_Sys

## 12.2 Uses

Prompt Generation Module (Section 13), Real Time Clock Module (Section 14), Battery Management (Section 6)

## 12.3 Syntax

## 12.3.1 Exported Constants

None.

## 12.3.2 Exported Access Programs

Name	In	Out	Exceptions
Disp_Time	-	-	$BED_{L}ERR_{L}DISP$ : $\mathbb{Z}$
Disp_Prompt	Prompt: string	Response: string	BED_ERR_DISP: Z
Switch_Window	Window: $\mathbb{Z}$	-	$BED\_ERR\_DISP\colon \mathbb{Z}$

#### 12.4 Semantics

#### 12.4.1 State Variables

None.

#### 12.4.2 Environment Variables

None.

## 12.4.3 Assumptions

None.

#### 12.4.4 Access Routine Semantics

None.

#### 12.4.5 Local Functions

# 13 MIS of Prompt Generation Module

## 13.1 Module

 $Prompt\_Gen$ 

## 13.2 Uses

Sensor Array Module (Section ??)

## 13.3 Syntax

## 13.3.1 Exported Constants

 $max\_prompts: \mathbb{Z}$ 

## 13.3.2 Exported Access Programs

Name	In	Out	Exceptions
Access_Prompt	$Prompt_{\scriptscriptstyle{-}}: \mathbb{Z}$	Prompt: Struct	BED_ERR_PG: Z

## 13.4 Semantics

#### 13.4.1 State Variables

None.

#### 13.4.2 Environment Variables

None.

## 13.4.3 Assumptions

None.

#### 13.4.4 Access Routine Semantics

None.

#### 13.4.5 Local Functions

# 14 MIS of Real Time Clock Module

## 14.1 Module

**RTC** 

## 14.2 Uses

None.

## 14.3 Syntax

## 14.3.1 Exported Constants

None.

## 14.3.2 Exported Access Programs

Name	In	Out	Exceptions
Get_DateTime	-	$\mathbb{R}$	BED_ERR_RTC: ℤ

### 14.4 Semantics

#### 14.4.1 State Variables

Date: string Time: string

#### 14.4.2 Environment Variables

None.

## 14.4.3 Assumptions

• Initial date and time is correctly set.

#### 14.4.4 Access Routine Semantics

None.

#### 14.4.5 Local Functions

# 15 MIS of Create New User Module

#### 15.1 Module

NewUser\_Enter

## 15.2 Uses

Local Database Module (Section 12)

## 15.3 Syntax

## 15.3.1 Exported Constants

None.

#### 15.3.2 Exported Access Programs

None.

#### 15.4 Semantics

#### 15.4.1 State Variables

param\_input: string, integer

#### 15.4.2 Environment Variables

File: A new information line in database.

## 15.4.3 Assumptions

• All configuration parameters within acceptable limits.

#### 15.4.4 Access Routine Semantics

None.

#### 15.4.5 Local Functions

# 16 MIS of Configuration Module

#### 16.1 Module

Config\_Param

## 16.2 Uses

MicroSD Module (Section 7)

## 16.3 Syntax

## 16.3.1 Exported Constants

None.

#### 16.3.2 Exported Access Programs

None.

#### 16.4 Semantics

#### 16.4.1 State Variables

param\_input: string

#### 16.4.2 Environment Variables

None.

## 16.4.3 Assumptions

• All configuration parameters within acceptable limits.

#### 16.4.4 Access Routine Semantics

None.

#### 16.4.5 Local Functions

# 17 MIS of Graph Plotter

#### 17.1 Module

Graph\_Plot

#### 17.2 Uses

Device Manager Module (Section ??)

## 17.3 Syntax

## 17.3.1 Exported Constants

None.

## 17.3.2 Exported Access Programs

None.

#### 17.4 Semantics

#### 17.4.1 State Variables

graph\_select: bool

#### 17.4.2 Environment Variables

File: A database on the host computer.

## 17.4.3 Assumptions

• Data is in proper format and not corrupted.

#### 17.4.4 Access Routine Semantics

None.

#### 17.4.5 Local Functions

 $graph\_stat$ : Statistical analysis function.

# 18 MIS of Watch Strap Module

#### 18.1 Module

Watch\_Strap

#### 18.2 Uses

Watch Case Module (Section 19)

## 18.3 Syntax

Velcro straps going tied to the watch case.

## 18.3.1 Exported Constants

None.

## 18.3.2 Exported Access Programs

None.

#### 18.4 Semantics

Allow the device to be strapped onto the user.

#### 18.4.1 State Variables

None.

#### 18.4.2 Environment Variables

None.

## 18.4.3 Assumptions

Will not impact the functionality of any other components.

#### 18.4.4 Access Routine Semantics

None.

#### 18.4.5 Local Functions

# 19 MIS of Watch Case Module

#### 19.1 Module

Watch\_Case

#### 19.2 Uses

None.

## 19.3 Syntax

CAD model and 3D printed.

## 19.3.1 Exported Constants

None.

## 19.3.2 Exported Access Programs

None.

#### 19.4 Semantics

Holds the display screen, touch bezels, and display screen together into 1 single device.

#### 19.4.1 State Variables

None.

#### 19.4.2 Environment Variables

None.

## 19.4.3 Assumptions

Will not impact the functionality of any other components.

#### 19.4.4 Access Routine Semantics

None.

#### 19.4.5 Local Functions

## **References**

Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. *Fundamentals of Software Engineering*. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.

Daniel M. Hoffman and Paul A. Strooper. *Software Design, Automated Testing, and Maintenance: A Practical Approach.* International Thomson Computer Press, New York, NY, USA, 1995. URL http://citeseer.ist.psu.edu/428727.html.