# Equations

### zavier

## August 2015

# 1 Variables

Temperature (K)	T
Heat Capacity $(\frac{J}{K})$	
Heat Energy (J)	C
Internal Energy (J)	Q
Volume (m <sup>3</sup> )	E
, ,	V
Mass (Kg)	m
Density $\left(\frac{\text{Kg}}{\text{m}^3}\right)$	ho
Mass-specific heat capacity $\left(\frac{J}{kg\cdot K}\right)$	
	$c_m$
Thickness (m)	L
Area (m <sup>2</sup> )	A
Thermal Conductivity (K-Value $\frac{W}{m \cdot K})$	
Th T. T	K
Thermal Transmittance (U-Value m	U
	-

Thermal Resistance (R-Value 
$$\frac{m^2 \cdot K}{W})$$

R

Thermal Conductance 
$$(\frac{W}{K})$$

UA

## 2 Formulas

Definition of Mass-specific Heat capacity

$$c_m = \frac{C}{m}$$

Definition of Heat capacity

$$C = \frac{Q}{\Delta T}$$

Definition of Density

$$\rho = \frac{m}{V}$$

Definition of Internal energy

$$E = c_m \cdot T$$

Definition of Thermal Transmittance

$$U = \frac{1}{R} = \frac{K}{L}$$

Definition of Thermal Conductance

$$UA = U \cdot A$$

#### 3 Simulation

Rate of Energy Transmission

$$\dot{Q}_{a\to b} = T_a \cdot U A_{a\leftrightarrow b}$$

$$\dot{Q}_{b\to a} = T_b \cdot U A_{a \leftrightarrow b}$$

**Energy Transmitted** 

$$Q_{a\to b} = \dot{Q}_{a\to b} \cdot \Delta t$$

$$Q_{b\to a} = \dot{Q}_{b\to a} \cdot \Delta t$$

New Total Energy

$$E_a = E_a + Q_{b \to a} - Q_{a \to b}$$

$$E_b = E_b + Q_{a \to b} - Q_{b \to a}$$

New Temperature

$$T_a = \frac{E_a}{C_a}$$

$$T_b = \frac{E_b}{C_b}$$

#### 4 Matrix

Substitution into base variables

$$T_{a-new} = \frac{\left(C_a \cdot T_a - \left(UA_{a \leftrightarrow b} \cdot T_a \cdot \Delta t\right) + \left(UA_{a \leftrightarrow b} \cdot T_b \cdot \Delta t\right)\right)}{C_a}$$

$$T_{b-new} = \frac{\left(C_b \cdot T_b + \left(U A_{a \leftrightarrow b} \cdot T_a \cdot \Delta t\right) - \left(U A_{a \leftrightarrow b} \cdot T_b \cdot \Delta t\right)\right)}{C_b}$$

Turning into matrix format

$$T_{a-new} = T_a(1 - UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_a}) + T_b \cdot (UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_a})$$

$$T_{b-new} = T_a \cdot (UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_b}) + T_b(1 - (UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_b}))$$

Matrix Equation

$$\begin{bmatrix} T_{a-new} \\ T_{b-new} \end{bmatrix} = \begin{bmatrix} 1 - UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_a} & UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_a} \\ UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_b} & 1 - UA_{a \leftrightarrow b} \cdot \Delta t \cdot \frac{1}{C_b} \end{bmatrix} \cdot \begin{bmatrix} T_a \\ T_b \end{bmatrix}$$

$$\vec{t}_{new} = M \cdot \vec{t}$$

#### 5 Time Step Matrix (M)

$$M = C \cdot (M_{adjacency} + E_{lost}) \cdot \Delta t + I$$

Identity Matrix (I)

$$\begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix}$$

Weighted Adjacency Matrix/Rate of Energy Transmitted into the mass  $(M_{adjacency})$ 

$$\begin{bmatrix} 0 & UA_{a\leftrightarrow b} \\ UA_{a\leftrightarrow b} & 0 \end{bmatrix}$$

Loosing Energy Matrix/Rate of Energy Transmitted out of the mass  $(E_{lost})$ 

$$\begin{bmatrix} -UA_{a\leftrightarrow b} & 0 \\ 0 & -UA_{a\leftrightarrow b} \end{bmatrix} = \begin{pmatrix} M_{adjacency} \cdot \begin{bmatrix} -1 \\ -1 \end{bmatrix} \end{pmatrix}.diag$$

Thermal Capacity Matrix (C)

$$\begin{bmatrix} C_a & 0 \\ 0 & C_b \end{bmatrix} = \begin{bmatrix} C_a \\ C_b \end{bmatrix} .diag$$

### 6 References

https://en.wikipedia.org/wiki/R-value(insulation)

 $https://en.wikipedia.org/wiki/Heat_capacity \\$ 

 $https://translate.google user content.com/translate_c?depth = 1hl = enprev = 1.00 +$ 

searchrurl = translate.google.co.nzsl = fru =

 $https://fr.wikipedia.org/wiki/Conductance_thermiqueusg = ALkJrhjnzh3i$ 

 $ZXRMkw7LNXSG4Mzmh8hfTQ \\ \text{http://heat-simulation.appspot.com/}$