# Week 2 – Physical Layer

#### COMP90007

Internet Technologies


1

## What is the Physical Layer?

- Recall the layer hierarchy from network reference models
  - The physical layer is the lowest Layer in OSI model
  - The physical layer's properties in TCP/IP model are in the "host-tonetwork" division.
- The physical layer is concerned with the mechanical, electrical and timing interfaces of the network
- Various physical media can be used to transmit data, but all of them are affected by a range of physical properties and hence have distinct differences
- How many different types of physical media can you think of?

### Link Model

- Simplified Link Model: Consider the network as a connected link between computers
- We can abstract the physical channel as a link



3

### Link Model

- <u>Bandwidth</u> is usually treated as rate of transmission in bits/second
- <u>Delay</u> (in seconds) is the time required for the first bit to travel from computer A to computer B.

## Example

- We need about 1 kbit/sec to transmit voice.
- Bandwidth of single mode fibre can reach
   1 Tbit/sec.
- How many voice calls can be transmitted through an Fiber Optic Cable?

$$10^{12} / 10^3 = 1$$
 billion calls

Tbit/s kbit/s

5

## Message Latency

- Latency is the time delay associated with sending a message over a link
- This is made of up two parts
  - Transmission delay:
    - T-delay = Message in bits / Rate of transmission
    - = M/R seconds
  - Propagation delay
    - P-delay = length of the channel/ speed of signals
    - Length / Speed of signal (2/3 of speed of light for wire)
  - □ Latency = L = M/R + P-delay

## Example -1

- A home computer is connected to an ISP server through 56 K bps modem. Assuming a frame size of 5600 bits, compute P-Delay and T-Delay for the link. Assume speed of signal = 2/3 C and length of the link is 5 K metres.
- T-delay = 5600 (bits)/ 56 000 (kbps) = 100 m sec
- P-delay = 5 (km)/200000 (km/s) = 0.025 m sec
- Latency = 100.025 m sec

7

### Example-2

- Now for the previous question, assume a countrywide optical broadband link of length 1000 kms of bandwidth 100 M bits/sec. Assuming a frame size of 5600 bits, compute P-Delay and T-Delay for the link. Assume speed of signal = C = 300000 km/sec.
- T-delay = 5600 (bits)/ 100 000 000 (bits/s) = 0.056 m sec
- P-delay = 1000 (km) /300000 (km/s) = 3.33 m sec
- Latency = 3.386 m sec

### Thinking about Networks for Data Transfer

- While networks are increasingly by default the means by which data is transferred, there are other options for data transfer – consider removable media such as tapes, CD ROMs, DVDs
  - Cost-wise, such removable media are often more efficient on a per Mb/Gb basis
  - However, using such media to transfer data introduces a significant delay "never underestimate the bandwidth of a car boot full of DVD's":
    - 1000 DVD's x 4300Mb at 100km/h over distance of 100 kms = 4.3Tb / hr or 1.2 Gbps
    - At \$5/DVD, plus say \$20,000 for the car, that's \$25,000 for a 1.2 Gbps data transfer over 100kms - to build a 1 Gbps network over 100km costs in the order of \$1 million
- Data transfer over a network is not always the most efficient method to use

9

### The Bandwidth Revolution?

- Evolutionary steps in available bandwidth:
  - □ CPU speeds increase by a factor of ~20 per decade
    - 1981: PC 4.77Mhz vs 2001: PC 2 Ghz
- Bandwidth speeds increase by a factor of ~125 per decade (1981: Modem 56kbps vs 2001: Net 1Gbps)
- Current CPU speed now approaching physical limits constrained by physical properties pertaining to granularity of engraving on silicon
- Current bandwidth available up to 50Tbps vastly exceeding the rate at which we can convert electrical impulses to optical pulses


## Signal Attenuation

- How far and how much data a medium can carry has a lot to do with signal attenuation:
  - "<u>Attenuation</u> is the loss or reduction in the amplitude (strength) of a signal as it passes through a medium."

11

## Wires – Twisted Pair

- Two insulated copper wires, twisted in helical (DNA) form.
- Twisting reduces radiance of waves from effectively parallel antennae
- Distance up to <5km, repeaters can extend this distance (large buildings often have km's of cabling)
- twisting reduces interference




## Properties and Types of Twisted Pair

- Bandwidth dependent on distance, wire quality/density
- Cat 3 2 wires, 4 pairs in sheath, 16Mhz
- Cat 5 2 wires, 4 pair in sheath, more twists = less interference, higher quality over longer distance, 100 Mhz
- Cat 6 250 Mhz
- Cat 7...

## Coaxial Cable ("Co-ax")


- Better shielding than twisted pair = higher speeds over greater distances
- Copper core with insulation, mesh, and sheath
- Bandwidth approaches 1Ghz
- Still widely used for cable TV/Internet

A diagram of a coaxial cable



## Fiber Optics

- Optical transmission has 3 components: light source, transmission medium, detector
- Semantics: light = 1, no light = 0 (basic binary system)
- Data transmission over a fibre of glass
- A detector generates electrical pulse when light hits it
- Refraction between air/silica boundary is compensated for by design - total internal reflection distance ISP links, Fiber-tothe-Home
- Common for high rates and long distances



## Transmission of Light Through Fibre

Fiber has enormous bandwidth (THz) and tiny signal loss – hence high rates over long distances


## Fiber Optic Cables

#### Single-mode

- Core so narrow (10um) light can't even bounce around
- Used with lasers for long distances, e.g., 100km


#### Multi-mode

- Other main type of fiber
- Light can bounce (50um core)
- Used with LEDs for cheaper, shorter distance links




## Fiber Optic Connections

- Connectors and Fiber Sockets (10-20% loss, but easy to configure)
- Mechanical Splice (10% loss, labour intensive)
- Fusion (<1% loss, but specialised)</li>
- Signalling using LED's or semiconductor lasers



## Fiber Optic Networks

- Fiber optic cable is a scalable network media LAN, WAN, long haul
- Fibre optic cable can be considered either as a ring or as a bus network type (series of point to point connections)



Comparison: Wires and Fiber

Comparison of the properties of wires and fiber:

Property	Wires	Fiber
Distance	Short (100s of m)	Long (tens of km)
Bandwidth	Moderate	Very High
Cost	Inexpensive	More Expensive
Convenience	Easy to use	Harder to use
Security	Easy to tap	Hard to tap


#### Wireless Transmission

- Mobile users requires a mobility enabled network contrast with the wired networks
- Wireless networks can provide advantages even in fixed location environments
- There are many types of wireless data transmission networks, but they all have a common basis - radio wave propagation
- Unlike previous mediums wireless signals are broadcasted over a region
- Potential signal collisions Need regulations

21

### ElectroMagnetic Spectrum


- Number of oscillations per second of a wave is called frequency, measured in Hertz (Hz).
- Distance between two consecutive minima or maxima is called wavelength.
- All EM waves travel at same speed (speed of light)
- Fundamental relationship:
  - Wavelength x Frequency = Speed of Light
  - □ Units: (m) x (1/s) = (m/s)



## Electromagnetic Spectrum

#### Different bands have different uses:

- Radio: wide-area broadcast;
- Infrared/Light: line-of-sight
- Microwave: LANs and 3G/4G;



### Wireless vs. Wires/Fiber

#### Wireless:

- + Easy and inexpensive to deploy
- + Naturally supports mobility
- Naturally supports broadcast
- Transmissions interfere and must be managed
- Signal strengths hence data rates vary greatly

#### Wires/Fiber:

- Easy to engineer a fixed data rate over point-to-point links
- Can be expensive to deploy, esp. over distances
- Doesn't readily support mobility or broadcast

### Communication Satellites


Satellites are effective for broadcast distribution and anywhere/anytime communications

- Kinds of Satellites
- Geostationary (GEO) Satellites
- Medium-Earth Orbit (MEO) Satellites
- Low-Earth Orbit (LEO) Satellites
- Satellites vs. Fiber

### Kinds of Satellites

Satellites and their properties vary by altitude:


Geostationary (GEO), Medium-Earth Orbit



## Geostationary Satellites


#### GEO satellites orbit 35,000 km above a fixed location

- VSAT (computers) can communicate with the help of a hub
- Different bands (L, S, C, Ku, Ka) in the GHz are in use but may be crowded or susceptible to rain.



### Low-Earth Orbit Satellites

Systems such as Iridium use many low-latency satellites for coverage and route communications via them



## Satellite vs. Fiber

#### Satellite:

- Can rapidly set up anywhere/anytime communications (after satellites have been launched)
- + Can broadcast to large regions
- Limited bandwidth and interference to manage

#### Fiber:

- + Enormous bandwidth over long distances
- Installation can be more expensive/difficult

## Link Terminology

#### Full-duplex link

- Used for transmission in both directions at once
- e.g., use different twisted pairs for each direction

#### Half-duplex link

- Both directions, but not at the same time
- e.g., senders take turns on a wireless channel

#### Simplex link

Only one fixed direction at all times; not common


## Multiplexing

- When multiple sources want to access the medium
  - Time Division Multiplexing
  - Frequency Division Multiplexing
  - Statistical Multiplexing (for curious readers)
  - Code Division Multiple Access

31


## Time Division Multiplexing

- Users can send according to a fixed schedule
- Slotted access to the full speed of the media



## Frequency Division Multiplexing

- Users can only use specific frequencies to send their data
- Continuous access with lower speed



33

## Digital Modulation

#### Modulation schemes send bits as signals

- Baseband Transmission
  - Signal that run from 0 up to a maximum frequency
  - E.g., Telephone system: 0 ~ 4kHz
- Passband Transmission
  - Signals that are shifted to occupy a higher range of frequencies
     ADSL


O4kHz 25.875kHz 138kHz 1104kHz 2208kHz

Upstream Downstream ADSL2+ Downstream

Example


## Electrical Analogue Signal to Digital

- Information on wire transmitted by variance of a physical property eg voltage, current.
  - Generating a periodic function, imagine a Sine function
- Sine function: c\*sin(ax+b): Three things can change the behaviour of the function:
  - □ C: Amplitude, A:Frequency and B:Phase



## Modulation Types

Modulating the amplitude, frequency/phase of a carrier signal sends bits in a (non-zero) frequency range



## Harry Nyquist



 Early theoretical work on determining fundamental limits for the bandwidth required for communication-heralded digital revolution

#### Data Communications Theory

- How to transform continuous signals into digital values?
  - Sampling the amplitude values of the signal
- Symbol Rate (Baud Rate): number of signal changes per second

### Maximum Data Rate of a Channel

 Nyquist's theorem relates the data rate to the bandwidth (B) and number of signal levels (V) (channel without noise):

Max. data rate =  $2B log_2 V bits/sec$ 

- If a signal has bandwidth B, then the signal can be fully reconstructed by sampling with 2B rate.
- If signal has V levels, each symbol can be represented by log<sub>2</sub>V bits.

### Claude Shannon



- Father of Information theory.
- 1948 monograph –"The mathematical theory of communication" defined a new area;
- 1949 monograph"Communication Theory of Secrecy Systems" is another foundational work on modern Cryptography

41

### Maximum Data Rate of a Channel

 Shannon's theorem relates the data rate to the bandwidth (B) and signal strength (S) relative to the noise (N):

Max. data rate = 
$$B log_2(1 + S/N)$$
 bits/sec

| how fast signal How many levels can change can be seen

## Example 1

**Q**: Given the signal-to-noise ratio (SNR) of 20 dB, and the bandwidth of 4kHz (telephone communications), what is the maximum data rate according to Shannon's theorem?

#### Ans:

 $C = 4000 \log 2(1 + 100) = 4000 \log 2 (101) = 26.63$  kbit/s. Note that the value of S/N = 100 is equivalent to the SNR of 20 dB

43

### Example 2

**Q**: If a binary signal is sent over a 3-kHz channel whose signal-to-noise ratio is 20 dB, what is the maximum achievable data rate?

#### <u>Ans</u>:

SNR of 20 dB = S/N = 100.

Since  $log_2(101)$  is about 6.658, the Shannon limit is about 19.975 kbps but the Nyquist limit is 6 kbps.

The bottleneck is therefore the Nyquist limit, giving a maximum channel capacity of 6 kbps