2016/4/13 MIPS Quick Tutorial

MIPS Architecture and Assembly Language Overview

Adapted from: http://edge.mcs.dre.g.el.edu/GICL/people/sevy/architecture/MIPSRef(SPIM).html

[Register Description] [I/O Description]

Data Types and Literals

Data types:

- Instructions are all 32 bits
- byte(8 bits), halfword (2 bytes), word (4 bytes)
- a character requires 1 byte of storage
- an integer requires 1 word (4 bytes) of storage

Literals:

- numbers entered as is. <u>e.g.</u> 4
 characters enclosed in single quotes. <u>e.g.</u> 'b'
- strings enclosed in double quotes. e.g. "A string"

Registers

- 32 general-purpose registers
- register preceded by \$ in assembly language instruction two formats for addressing:

 - using register number <u>e.g.</u> \$0 through \$31
 - using equivalent names <u>e.g.</u> \$t1, \$sp
- special registers Lo and Hi used to store result of multiplication and division
 not directly addressable; contents accessed with special instruction mfhi ("move from Hi") and mflo ("move from Lo")
- $\bullet\,$ stack grows from high memory to low memory

This is from Figure 9.9 in the Goodman&Miller text

Register Number	Alternative Name	Description	
0	zero	the value 0	
1	\$at	(assembler temporary) reserved by the assembler	
2-3	\$v0 - \$v1	(values) from expression evaluation and function results	
4-7	\$a0 - \$a3	(arguments) First four parameters for subroutine. Not preserved across procedure calls	
8-15	\$t0 - \$t7	(temporaries) Caller saved if needed. Subroutines can use w/out saving. Not preserved across procedure calls	
16-23	\$s0 - \$s7	(saved values) - Callee saved. A subroutine using one of these must save original and restore it before exiting. Preserved across procedure calls	
24-25	\$t8 - \$t9	(temporaries) Caller saved if needed. Subroutines can use w/out saving. These are in addition to \$t0 - \$t7 above. Not preserved across procedure calls.	
26-27	\$k0 - \$k1	reserved for use by the interrupt/trap handler	
28	\$gp	global pointer. Points to the middle of the 64K block of memory in the static data segment.	
29	\$sp	stack pointer Points to last location on the stack.	
30	\$s8/\$fp	saved value / frame pointer Preserved across procedure calls	
31	\$ra	return address	

See also Britton section 1.9, Sweetman section 2.21, Larus Appendix section A.6

Program Structure

- just plain text file with data declarations, program code (name of file should end in suffix .s to be used with SPIM simulator)
- · data declaration section followed by program code section

Data Declarations

- ullet placed in section of program identified with assembler directive .data
- declares variable names used in program; storage allocated in main memory (RAM)

Code

- placed in section of text identified with assembler directive .text
- contains program code (instructions)
- starting point for code e.g. ecution given label main:
- ending point of main code should use exit system call (see below under System Calls)

- anything following # on a line
- # This stuff would be considered a comment
- Template for a MIPS assembly language program:
 - $\mbox{\tt\#}$ Comment giving name of program and description of function
 - # Template.s
 - # Bare-bones outline of MIPS assembly language program
 - . data # variable declarations follow this line

2016/4/13 MIPS Quick Tutorial

instructions follow this line

indicates start of code (first instruction to execute)

.text

main:

```
# End of program, leave a blank line afterwards to make SPIM happy
Data Declarations
       format for declarations:
             name: storage_type
                                      value(s)
           • create storage for variable of specified type with given name and specified value
           • value(s) usually gives initial value(s); for storage type .space, gives number of spaces to be allocated
       Note: labels always followed by colon ( : )
              example
                                       3  # create a single integer variable with initial value 3 'a','b' # create a 2-element character array with elements initialized
              var1:
                              .word
             arrav1:
                              .byte
                                                 to a and b
                                               # allocate 40 consecutive bytes, with storage uninitialized
              arrav2:
                              .space 40
                                                  could be used as a 40-element character array, or a
                                               Ħ
                                                   10-element integer array; a comment should indicate which!
Load / Store Instructions
           • RAM access only allowed with load and store instructions
           • all other instructions use register operands
       load:
                              register destination, RAM_source
                      1 w
                           #copy word (4 bytes) at source RAM location to destination register.
                              register_destination, RAM_source
                           #copy byte at source RAM location to low-order byte of destination register,
                           # and sign-e.g. tend to higher-order bytes
       store word:
                              register\_source,\ RAM\_destination
                           #store word in source register into RAM destination
                              register source, RAM destination
                           #store byte (low-order) in source register into RAM destination
       load immediate:
                              register_destination, value
                           #load immediate value into destination register
       example:
              .data
       var1:
              .word
                                        # declare storage for var1; initial value is 23
               . text
        start:
                       $t0, var1
                                                # load contents of RAM location into register $t0: $t0 = var1
               1i
                                        \# t1 = 5 ("load immediate")
                       $t1, 5
                       $t1, var1
                                                # store contents of register $t1 into RAM: var1 = $t1
               done
```

Indirect and Based Addressing

• Used only with load and store instructions

load address:

\$t0, var1

• copy RAM address of varl (presumably a label defined in the program) into register \$t0

indirect addressing:

\$t2, (\$t0)

· load word at RAM address contained in \$t0 into \$t2

\$t2. (\$t0)

• store word in register \$t2 into RAM at address contained in \$t0

based or indexed addressing:

1 w \$t2, 4(\$t0)

- load word at RAM address (\$t0+4) into register \$t2 "4" gives offset from address in register \$t0

2016/4/13 MIPS Quick Tutorial

```
$t2, -12($t0)
```

- store word in register \$t2 into RAM at address (\$t0 12)
- · negative offsets are fine

Note: based addressing is especially useful for:

- · arrays: access elements as offset from base address
- · stacks: easy to access elements at offset from stack pointer or frame pointer

example

```
. data
                .space 12
                                       \# declare 12 bytes of storage to hold array of 3 integers
arrav1:
                . text
               la
                       $t0, array1
_start:
                                               # load base address of array into register $t0
                                       # t1 = 5 ("load immediate")
                li
                       $t1, 5
                sw $t1, ($t0)
                                       # first array element set to 5; indirect addressing
                li $t1, 13
                                          t1 = 13
                sw $t1, 4($t0)
                                       \# second array element set to 13
                li $t1, -7
                                           $t1 = -7
                sw $t1, 8($t0)
                                       \# third array element set to -7
                done
```

Arithmetic Instructions

- most use 3 operands
- all operands are registers; no RAM or indirect addressing
- operand size is word (4 bytes)

```
# $t0 = $t1 + $t2; add as signed (2's complement) integers
add
          $t0, $t1, $t2
                              # $t0 = $t1 + $t2,

# $t2 = $t3 D $t4

# $t2 = $t3 + 5; "add immediate" (no sub immediate)

# $t1 = $t6 + $t7; add as unsigned integers
          $t2, $t3, $t4
sub
addi
          $t2,$t3, 5
addu
          $t1, $t6, $t7
subu
          $t1, $t6, $t7
mult
          $t3, $t4
                               \mbox{\#} multiply 32-bit quantities in $t3 and $t4, and store 64-bit
                               # result in special registers Lo and Hi: (Hi,Lo) = $t3 * $t4
# Lo = $t5 / $t6 (integer quotient)
# Hi = $t5 mod $t6 (remainder)
div
          $t5, $t6
          $t0
                               # move quantity in special register Hi to $t0: $t0 = Hi
mfhi
mflo
          $t1
                               # move quantity in special register Lo to $t1:
                                                                                               t1 = Lo
                               \# used to get at result of product or quotient
          $t2, $t3 # $t2 = $t3
move
```

Control Structures

Branches

ullet comparison for conditional branches is built into instruction

```
# unconditional branch to program label target
beq
         $t0, $t1, target # branch to target if $t0 = $t1 $t0, $t1, target # branch to target if $t0 < $t1
h1t
         $t0, $t1, target # branch to target if $t0 <= $t1
ble
         $t0,$t1,target # branch to target if $t0 > $t1
bgt
         t0, t1, target # branch to target if t0 >= t1
bge
         $t0,$t1,target # branch to target if $t0 \Leftrightarrow $t1
```

Tumps

```
target # unconditional jump to program label target
jr
       $t3
                       # jump to address contained in $t3 ("jump register")
```

Subroutine Calls

```
subroutine call: "jump and link" instruction
```

```
sub_label
                      # "jump and link"
jal
```

- copy program counter (return address) to register \$ra (return address register)
- jump to program statement at sub_label

subroutine return: "jump register" instruction

```
# "jump register"
```

• jump to return address in \$ra (stored by jal instruction)

Note: return address stored in register \$ra; if subroutine will call other subroutines, or is recursive, return address should be copied from \$ra onto stack to preserve it, since jal always places return address in this register and hence will overwrite previous value

System Calls and I/O (SPIM Simulator)

- used to read or print values or strings from input/output window, and indicate program end
- use syscall operating system routine call
- first supply appropriate values in registers 0 and a0-a1 result value (if any) returned in register v0

The following table lists the possible syscall services.

Service	Code	Arguments	Results
Service	in \$v0	Arguments	Results

2016/4/13 MIPS Quick Tutorial

print_int	1	\$a0 = integer to be printed	
print_float	2	\$f12 = float to be printed	
print_double	3	\$f12 = double to be printed	
print_string	4	\$a0 = address of string in memory	
read_int	5		integer returned in \$v0
read_float	6		float returned in \$v0
read_double	7		double returned in \$v0
read_string	8	\$a0 = memory address of string input buffer \$a1 = length of string buffer (n)	
sbrk	9	\$a0 = amount	address in \$v0
exit	10		

- The print_string service expects the address to start a null-terminated character string. The directive .asciiz creates a null-terminated character string.
- The read_int, read_float and read_double services read an entire line of input up to and including the newline character.
- The read_string service has the same semantices as the UNIX library routine fgets.
 - ullet It reads up to n-1 characters into a buffer and terminates the string with a null character.
 - If fewer than n-1 characters are in the current line, it reads up to and including the newline and terminates the string with a null character.
- The sbrk service returns the address to a block of memory containing n additional bytes. This would be used for dynamic memory allocation.
- The exit service stops a program from running.
- e.g. Print out integer value contained in register \$t2

```
li $v0, 1  # load appropriate system call code into register $v0;
  # code for printing integer is 1
move $a0, $t2  # move integer to be printed into $a0: $a0 = $t2
syscall  # call operating system to perform operation
```

e.g. Read integer value, store in RAM location with label int_value (presumably declared in data section)

```
li $v0, 5  # load appropriate system call code into register $v0; syscall sw $v0, int_value  # value read from keyboard returned in register $v0; # store this in desired location
```

e.g. Print out string (useful for prompts)

e.g. To indicate end of program, use exit system call; thus last lines of program should be: