Primary source: Arduino Language Reference

https://arduino.cc/en/Reference/

## Structure & Flow

```
Basic Program Structure
void setup() {
 // Runs once when sketch starts
void loop() {
 // Runs repeatedly
Control Structures
if (x < 5) { ... } else { ... }
while (x < 5) \{ ... \}
for (int i = 0; i < 10; i++) { ... }
break;
           // Exit a loop immediately
continue; // Go to next iteration
switch (var) {
  case 1:
    • • •
    break;
  case 2:
    • • •
    break;
  default:
    • • •
return x; // x must match return type
          // For void return type
return;
Function Definitions
<ret. type> <name>(<params>) { ... }
```

e.g. int double(int x) {return x\*2;}

true | false

0 - 255

0 - 255

0 - 65535

0 - 65535

0 - 4294967295

-32768 - 32767

-2147483648 - 2147483647

-3.4028e+38 - 3.4028e+38

currently same as float

{'A','r','d','u','i','n','o','\0'};

// Includes \0 null termination

i.e., no return value

-128 - 127, 'a' '\$' etc.

Data Types

unsigned char

unsigned int

unsigned long

char str1[8] =

boolean

char

byte

int

word

float

void

double

Strings

## Operators

## General Operators

```
= assignment
             subtract
   multiply
                divide
  modulo
            != not equal to
== equal to
< less than > greater than
<= less than or equal to</pre>
>= greater than or equal to
&& and or
  not
```

### Compound Operators

```
++ increment
-- decrement
+= compound addition
```

-= compound subtraction

\*= compound multiplication /= compound division

**&=** compound bitwise and = compound bitwise or

#### Bitwise Operators

& bitwise and bitwise or ^ bitwise xor bitwise not >> shift right << shift left

#### Pointer Access

**Numeric Constants** 

Variables, Arrays, and Data

123

**0**173

**0**x7B

**123U** 

123**L** 

123**UL** 

123.0

1.23**e**6

static

const

**PROGMEM** 

Arrays

volatile

Qualifiers

**0**b01111011

- & reference: get a pointer
- \* dereference: follow a pointer

decimal

octal - base 8

force unsigned

force long

read-only

in flash

int myPins[] =  $\{2, 4, 8, 3, 6\}$ ;

hexadecimal - base 16

force unsigned long

force floating point

persists between calls

in RAM (nice for ISR)

 $1.23*10^6 = 1230000$ 

binary

tone(pin, freq\_Hz) noTone(pin) shiftOut(dataPin, clockPin,

unsigned long pulseIn(pin, [HIGH, LOW])

### Time

unsigned long millis() // Overflows at 50 days unsigned long micros() // Overflows at 70 minutes delay(msec) delayMicroseconds(usec)

sugg. 7-12V

limit 6-20V

## Built-in Functions

```
Pin Input/Output
                                      Math
Digital I/O - pins 0-13 A0-A5
                                      min(x, y)
                                                 max(x, y)
                                                             abs(x)
 pinMode(pin,
                                      sin(rad)
                                                 cos(rad)
                                                             tan(rad)
    [INPUT, OUTPUT, INPUT_PULLUP])
                                      sqrt(x)
                                                 pow(base, exponent)
  int digitalRead(pin)
                                      constrain(x, minval, maxval)
 digitalWrite(pin, [HIGH, LOW])
                                      map(val, fromL, fromH, toL, toH)
Analog In - pins A0-A5
                                      Random Numbers
  int analogRead(pin)
                                      randomSeed(seed) // long or int
  analogReference(
                                      long random(max) // 0 to max-1
    [DEFAULT, INTERNAL, EXTERNAL])
                                      long random(min, max)
PWM Out - pins 3 5 6 9 10 11
                                      Bits and Bytes
  analogWrite(pin, value)
                                                   highByte(x)
                                      lowByte(x)
                                      bitRead(x, bitn)
Advanced I/O
                                      bitWrite(x, bitn, bit)
                                      bitSet(x, bitn)
tone(pin, freq_Hz, duration_ms)
                                      bitClear(x, bitn)
                                      bit(bitn) // bitn: 0=LSB 7=MSB
  [MSBFIRST, LSBFIRST], value)
                                      Type Conversions
                                      char(val)
                                                     byte(val)
                                      int(val)
                                                     word(val)
                                      long(val)
                                                     float(val)
```

External Interrupts attachInterrupt(interrupt, func, [LOW, CHANGE, RISING, FALLING]) detachInterrupt(interrupt) interrupts() noInterrupts()

1

SDA SCL

```
Serial - comm. with PC or via RX/TX
begin(long speed) // Up to 115200
end()
int available() // #bytes available
           // -1 if none available
int read()
int peek()
            // Read w/o removing
flush()
              println(data)
print(data)
              write(char * string)
write(byte)
write(byte * data, size)
SerialEvent() // Called if data rdy
SoftwareSerial.h - comm. on any pin
SoftwareSerial(rxPin, txPin)
begin(long speed) // Up to 115200
listen()
             // Only 1 can listen
isListening() // at a time.
read, peek, print, println, write
  // Equivalent to Serial library
```

Libraries

```
EEPROM.h - access non-volatile memory
byte read(addr)
write(addr, byte)
EEPROM[index] // Access as array
```

attach(pin, [min\_uS, max\_uS]) write(angle) // 0 to 180 writeMicroseconds(uS) // 1000-2000; 1500 is midpoint int **read()** // 0 to 180 bool attached() detach()

Servo.h - control servo motors

Wire.h - I<sup>2</sup>C communication begin() // Join a master

begin(addr) // Join a slave @ addr requestFrom(address, count) beginTransmission(addr) // Step 1

send(byte) send(char \* string)

send(byte \* data, size) endTransmission()

// Step 3 int available() // #bytes available byte receive() // Get next byte

onReceive(handler) onRequest(handler)



### by Mark Liffiton version: 2017-04-10

// Step 2

source: https://github.com/liffiton/Arduino-Cheat-Sheet/

- Arduino board drawing: Fritzing.org

# Adapted from:

- Original: Gavin Smith
- SVG version: Frederic Dufourg
- **RESET** DIGITAL (PWM~) ARDUINO UNO TX ON RX **ICSP** WWW.ARDUINO.CC - Made in Italy ATmega382: 16MHz, 32KB Flash (program), 2KB SRAM, 1KB EEPROM DC in ANALOG IN POWER

#### char str2[8] =int myInts[6]; // Array of 6 ints {'A','r','d','u','i','n','o'}; myInts[0] = 42; // Assigning first // Compiler adds null termination // index of myInts char str3[] = "Arduino"; myInts[6] = 12; // ERROR! Indexes

char str4[8] = "Arduino"; // are 0 though 5