

AN 826: Hierarchical Partial Reconfiguration Tutorial for Stratix® 10 GX FPGA Development Board

Updated for Intel® Quartus® Prime Design Suite: **18.0**



Subscribe



Send Feedback

AN-826 | 2018.05.07

Latest document on the web: [PDF](#) | [HTML](#)



Contents

Hierarchical Partial Reconfiguration Tutorial for Stratix® 10 GX FPGA Development Board.....	3
Reference Design Requirements.....	4
Reference Design Overview.....	4
Reference Design Files.....	4
Reference Design Walkthrough.....	6
Step 1: Getting Started.....	6
Step 2: Creating a Child Level Sub-module.....	6
Step 3: Creating Design Partitions.....	8
Step 4: Allocating Placement and Routing Region for PR Partitions.....	9
Step 5: Defining Personas.....	10
Step 6: Creating Revisions	12
Step 7: Compiling the Base Revision and Exporting the Static Region.....	15
Step 8: Preparing the PR Implementation Revisions for Parent PR Partition.....	17
Step 9: Preparing the PR Implementation Revisions for Child PR Partitions.....	19
Step 10: Programming the Board.....	22
Modifying an Existing Persona.....	24
Adding a New Persona to the Design.....	24
Document Revision History for AN 826: Hierarchical Partial Reconfiguration Tutorial for Stratix 10 GX FPGA Development Board.....	25



Hierarchical Partial Reconfiguration Tutorial for Stratix® 10 GX FPGA Development Board

This application note demonstrates transforming a simple design into a hierarchically partially reconfigurable design, and implementing the design on the Stratix® 10 GX FPGA development board.

Hierarchical partial reconfiguration (HPR) is an extension of the traditional partial reconfiguration (PR), where you contain a PR region within another PR region. You can create multiple personas for both the child and parent partitions. You nest the child partitions within their parent partitions. Reconfiguring a parent partition does not impact the operation in the static region, but replaces the child partitions of the parent region with default child partition personas. This methodology is effective in systems where multiple functions time-share the same FPGA device resources.

Partial reconfiguration provides the following advancements to a flat design:

- Allows run-time design reconfiguration
- Increases scalability of the design
- Reduces system down-time
- Supports dynamic time-multiplexing functions in the design
- Lowers cost and power consumption through efficient use of board space

The current version of the Intel® Quartus® Prime Pro Edition software introduces a new and simplified compilation flow for partial reconfiguration.

Implementation of this reference design requires basic familiarity with the Intel Quartus Prime FPGA implementation flow and knowledge of the primary Intel Quartus Prime project files. This tutorial uses the Stratix 10 GX FPGA development board on the bench, outside of the PCIe* slot in your workstation.

Related Information

- [Stratix 10 FPGA Development Kit User Guide](#)
- [Partial Reconfiguration Concepts](#)
- [Partial Reconfiguration Design Flow](#)
- [Partial Reconfiguration Design Considerations](#)
- [Partial Reconfiguration Design Guidelines](#)

Reference Design Requirements


This reference design requires the following:

- Intel Quartus Prime Pro Edition software version 18.0 for the design implementation.
- Stratix 10 GX FPGA development kit for the FPGA implementation.

Reference Design Overview

This reference design consists of one 32-bit counter. At the board level, the design connects the clock to a 50MHz source, and connects the output to four LEDs on the FPGA. Selecting the output from the counter bits in a specific sequence causes the LEDs to blink at a specific frequency.

Figure 1. Flat Reference Design without PR Partitioning



Reference Design Files

The partial reconfiguration tutorial is available in the following location:

<https://github.com/intel/fpga-partial-reconfig>

To download the tutorial:

1. Click **Clone or download**.
2. Click **Download ZIP**. Unzip the `fpga-partial-reconfig-master.zip` file.
3. Navigate to the `tutorials/s10_pcie_devkit_blinking_led_hpr` sub-folder to access the reference design.

The `flat` folder consists of the following files:





Table 1. Reference Design Files

File Name	Description
top.sv	Top-level file containing the flat implementation of the design. This module instantiates the <code>blinking_led</code> sub-partition and the <code>top_counter</code> module.
top_counter.sv	Top-level 32-bit counter that controls <code>LED[1]</code> directly. The registered output of the counter controls <code>LED[0]</code> , and also powers <code>LED[2]</code> and <code>LED[3]</code> via the <code>blinking_led</code> module.
blinking_led.sdc	Defines the timing constraints for the project.
blinking_led.sv	In this tutorial, you convert this module into a parent PR partition. The module receives the registered output of <code>top_counter</code> module, which controls <code>LED[2]</code> and <code>LED[3]</code> .
blinking_led.qpf	Intel Quartus Prime project file containing the list of all the revisions in the project.
blinking_led.qsf	Intel Quartus Prime settings file containing the assignments and settings for the project.

Note: The `hpr` folder contains the complete set of files you create using this application note. Reference these files at any point during the walkthrough.

Figure 2. Reference Design Files





Reference Design Walkthrough

The following steps describe the application of partial reconfiguration to a flat design. The tutorial uses the Intel Quartus Prime Pro Edition software for the Stratix 10 GX FPGA development board:

- [Step 1: Getting Started](#) on page 6
- [Step 2: Creating a Child Level Sub-module](#) on page 6
- [Step 3: Creating Design Partitions](#) on page 8
- [Step 4: Allocating Placement and Routing Region for PR Partitions](#) on page 9
- [Step 5: Defining Personas](#) on page 10
- [Step 6: Creating Revisions](#) on page 12
- [Step 7: Compiling the Base Revision and Exporting the Static Region](#) on page 15
- [Step 8: Preparing the PR Implementation Revisions for Parent PR Partition](#) on page 17
- [Step 9: Preparing the PR Implementation Revisions for Child PR Partitions](#) on page 19
- [Step 10: Programming the Board](#) on page 22

Note:

Unlike *AN 806: Hierarchical Partial Reconfiguration a Design Tutorial for Intel Arria® 10 GX FPGA Development Board*, this tutorial does not require addition of a Partial Reconfiguration Controller IP core. This difference is because Intel Stratix 10 supports PR over JTAG using the hard JTAG pins of the FPGA.

Related Information

[AN 806: Hierarchical Partial Reconfiguration a Design Tutorial for Intel Arria 10 GX FPGA Development Board](#)

Step 1: Getting Started

To copy the reference design files to your working environment and compile the `blinking_led` flat design:

1. Create a directory in your working environment, `s10_pcie_devkit_blinking_led_hpr`.
2. Copy the downloaded `tutorials/s10_pcie_devkit_blinking_led_hpr/flat` sub-folder to the directory, `s10_pcie_devkit_blinking_led_hpr`.
3. In the Intel Quartus Prime Pro Edition software, click **File ► Open Project** and select `blinking_led.qpf`.
4. To compile the flat design, click **Processing ► Start Compilation**.

Step 2: Creating a Child Level Sub-module

To convert this flat design into a hierarchical PR design, you must create a child sub-module (`blinking_led_child.sv`) that is nested within the parent sub-module (`blinking_led.sv`).



1. Create a new design file, `blinking_led_child.sv`, and add the following lines of code to this file:

```
`timescale 1 ps / 1 ps
`default_nettype none

module blinking_led_child (

    // clock
    input wire clock,
    input wire [31:0] counter,

    // Control signals for the LEDs
    output wire led_three_on

);
    localparam COUNTER_TAP = 23;
    reg led_three_on_r;

    assign led_three_on    = led_three_on_r;

    always_ff @(posedge clock) begin
        led_three_on_r    <= counter[COUNTER_TAP];
    end

endmodule
```

2. Modify the `blinking_led.sv` file to connect the `led_two_on` to bit 23 of the counter from the static region, and instantiate the `blinking_led_child` module. After modifications, your `blinking_led.sv` file must appear as follows:

```
`timescale 1 ps / 1 ps
`default_nettype none

module blinking_led(
    // clock
    input wire clock,
    input wire [31:0] counter,
    // Control signals for the LEDs
    output wire led_two_on,
    output wire led_three_on
);

    localparam COUNTER_TAP = 23;

    reg led_two_on_r;
    assign led_two_on    = led_two_on_r;

    // The counter:
    always_ff @(posedge clock) begin
        led_two_on_r <= counter[COUNTER_TAP];
    end

    blinking_led_child u_blinking_led_child (
        .led_three_on    (led_three_on),
        .counter          (counter),
        .clock            (clock)
    );

endmodule
```

3. On modifying all the design files, recompile the project by clicking **Processing ► Start Compilation**


Step 3: Creating Design Partitions

You must create design partitions for each PR region that you want to partially reconfigure. You can create any number of independent partitions or PR regions in your design. This tutorial creates two design partitions for the `u_blinking_led_child` and `u_blinking_led` instances.

To create design partitions for hierarchical partial reconfiguration:

1. Right-click the `u_blinking_led_child` instance in the **Project Navigator** and click **Design Partition ► Set as Design Partition**. A design partition icon appears next to each instance that is set as a partition.

Figure 3. Creating Design Partitions from Project Navigator



2. To define the partition **Type**, right-click the `u_blinking_led_child` instance in the **Hierarchy** tab, click **Design Partition ► Reconfigurable**. You can only define the partition **Type** after setting the instance as a partition.

The design partition appears on the **Assignments View** tab of the Design Partitions Window.

Figure 4. Design Partitions Window

Assignments View		Compilation View					
Partition Name	Hierarchy Path	Type	Preservation Level	Empty	Partition Database File	Entity Re-binding	Color
<<new>>							
root_partiti...							
pr_parent_...	u_blinking_led	Rec...	Not Set	No			
pr_partition	u_blinking_le...	Rec...	Not Set	No			

3. Edit the partition name in the Design Partitions Window by double-clicking the name. For this reference design, rename the partition name to `pr_partition`.

Note: When you create a partition, the Intel Quartus Prime software automatically generates a partition name, based on the instance name and hierarchy path. This default partition name can vary with each instance.

4. Repeat steps 1 and 2 to assign reconfigurable design partitions to the `u_blinking_led` instance. Rename this partition to `pr_parent_partition`.



Verify that the `blinking_led.qsf` contains the following assignments, corresponding to your reconfigurable design partitions:

```
set_instance_assignment -name PARTITION pr_partition -to \
    u_blinking_led|u_blinking_led_child
set_instance_assignment -name PARTIAL_RECONFIGURATION_PARTITION ON -to \
    u_blinking_led|u_blinking_led_child

set_instance_assignment -name PARTITION pr_parent_partition -to \
    u_blinking_led
set_instance_assignment -name PARTIAL_RECONFIGURATION_PARTITION ON -to \
    u_blinking_led
```

Related Information

Defining PR Partitions


Step 4: Allocating Placement and Routing Region for PR Partitions

When you create the base revision, the PR design flow uses your PR partition region allocation to place the corresponding persona core in the reserved region. To locate and assign the PR region in the device floorplan for your base revision:

1. Right-click the `u_blinking_led_child` instance in the **Project Navigator** and click **Logic Lock Region** ► **Create New Logic Lock Region**. The region appears on the Logic Lock Regions Window.
2. Your placement region must enclose the `blinking_led_child` logic. Select the placement region by locating the node in Chip Planner. Right-click the `u_blinking_led_child` region name in the **Project Navigator** and click **Locate Node** ► **Locate in Chip Planner**.

The `u_blinking_led_child` region is color-coded.

Figure 5. Chip Planner Node Location for `blinking_led`



3. In the Logic Lock Regions window, specify the placement region co-ordinates in the **Origin** column. The origin corresponds to the lower-left corner of the region. For example, to set a placement region with (X1 Y1) co-ordinates as (174 415), specify the **Origin** as X174_Y415. The Intel Quartus Prime software automatically calculates the (X2 Y2) co-ordinates (top-right) for the placement region, based on the height and width you specify.

Note: This tutorial uses the (X1 Y1) co-ordinates - (174 415), a height of 6 and a width of 13 for the placement region. Define any value for the placement region. Ensure that the region covers the `blinking_led_child` logic.

4. Enable the **Reserved** and **Core-Only** options.
5. Double-click the **Routing Region** option. The **Logic Lock Routing Region Settings** dialog box appears.
6. Select **Fixed with expansion** for the **Routing type**. Selecting this option automatically assigns an expansion length of 1.

Note: The routing region must be larger than the placement region, to provide extra flexibility for the routing engine when the engine routes different personas.

7. Repeat steps 1 -6 for the `u_blinking_led` instance. The parent-level placement region must fully enclose the corresponding child-level placement and routing regions, while allowing sufficient space for the parent-level logic placement. This tutorial uses the (X1 Y1) co-ordinates - (172 410), a height of 6, and width of 17 for the placement region of the `u_blinking_led` instance.

Figure 6. Logic Lock Regions Window

Region Name	Members	Width	Height	Origin	Reserved	Core-Only	Size/State	Routing Region
Logic Lock Regions								
u_blinking_led	u_blinking_led	17	20	X172_Y410	On	On	Fixed/Locked	Fixed with expansion 1
u_blinking_led u_blinking_led_child	u_blinking_led u_blinking_led_child	13	6	X174_Y415	On	On	Fixed/Locked	Fixed with expansion 1
<<tree>>								

Verify that the `blinking_led.qsf` contains the following assignments, corresponding to your floorplanning:

```
set_instance_assignment -name PLACE_REGION "69 10 88 29" -to \
    u_blinking_led|u_blinking_led_child
set_instance_assignment -name RESERVE_PLACE_REGION ON -to \
    u_blinking_led|u_blinking_led_child
set_instance_assignment -name CORE_ONLY_PLACE_REGION ON -to \
    u_blinking_led|u_blinking_led_child
set_instance_assignment -name ROUTE_REGION "173 414 187 421" -to \
    u_blinking_led|u_blinking_led_child

set_instance_assignment -name PLACE_REGION "172 410 188 429" -to \
    u_blinking_led
set_instance_assignment -name RESERVE_PLACE_REGION ON -to \
    u_blinking_led
set_instance_assignment -name CORE_ONLY_PLACE_REGION ON -to \
    u_blinking_led
set_instance_assignment -name ROUTE_REGION "171 409 189 430" -to \
    u_blinking_led
```

Related Information

- [Floorplan the Partial Reconfiguration Design](#)
- [Applying Floorplan Constraints Incrementally](#)

Step 5: Defining Personas

This reference design defines five separate personas for the parent and child PR partitions. To define and include the personas in your project:



1. Create four SystemVerilog files, `blinking_led_child.sv`, `blinking_led_child_slow.sv`, `blinking_led_child_empty.sv`, and `blinking_led_slow.sv` in your working directory for the five personas.

Note: If you create the SystemVerilog files from the Intel Quartus Prime Text Editor, disable the **Add file to current project** option, when saving the files.

Table 2. Reference Design Personas

File Name	Description	Code
<code>blinking_led_child.sv</code>	Default persona for the child-level design	<pre> `timescale 1 ps / 1 ps `default_nettype none module blinking_led_child (// clock input wire clock, input wire [31:0] counter, // Control signals for the LEDs output wire led_three_on); localparam COUNTER_TAP = 23; reg led_three_on_r; assign led_three_on = led_three_on_r; always_ff @(posedge clock) begin led_three_on_r <= counter[COUNTER_TAP]; end endmodule </pre>
<code>blinking_led_child_slow.sv</code>	The LED_THREE blinks slower	<pre> `timescale 1 ps / 1 ps `default_nettype none module blinking_led_child_slow (// clock input wire clock, input wire [31:0] counter, // Control signals for the LEDs output wire led_three_on); localparam COUNTER_TAP = 27; reg led_three_on_r; assign led_three_on = led_three_on_r; always_ff @(posedge clock) begin led_three_on_r <= counter[COUNTER_TAP]; end endmodule </pre>
<code>blinking_led_child_empty.sv</code>	The LED_THREE stays ON	<pre> `timescale 1 ps / 1 ps `default_nettype none module blinking_led_child_empty (// clock input wire clock, input wire [31:0] counter, // Control signals for the LEDs output wire led_three_on); </pre>

continued...



File Name	Description	Code
		<pre>// LED is active low assign led_three_on = 1'b0; endmodule</pre>
blinking_led_slow.sv	The LED_TWO blinks slower.	<pre>`timescale 1 ps / 1 ps `default_nettype none module blinking_led_slow(// clock input wire clock, input wire [31:0] counter, // Control signals for the LEDs output wire led_two_on, output wire led_three_on); localparam COUNTER_TAP = 27; reg led_two_on_r; assign led_two_on = led_two_on_r; // The counter: always_ff @(posedge clock) begin led_two_on_r <= counter[COUNTER_TAP]; end blinking_led_child u_blinking_led_child(.led_three_on (led_three_on), .counter (counter), .clock (clock)); endmodule</pre>

Related Information

[Step 3: Creating Design Partitions](#) on page 8

Step 6: Creating Revisions

The PR design flow uses the project revisions feature in the Intel Quartus Prime software. Your initial design is the base revision, where you define the static region boundaries and reconfigurable regions on the FPGA.

From the base revision, you create multiple revisions. These revisions contain the different implementations for the PR regions. However, all PR implementation revisions use the same top-level placement and routing results from the base revision.

To compile a PR design, you must create a PR implementation revision for each persona. In addition, you must assign revision types for each of the revisions. There are the following revision types:

- Partial Reconfiguration - Base
- Partial Reconfiguration - Persona Implementation

Note:

The new simplified PR flow introduced in the current version of the Intel Quartus Prime Pro Edition software does not require a separate synthesis and implementation revision for additional PR personas.



The following table lists the revision name and the revision type for each of the revisions:

Table 3. Revision Names and Types

Revision Name	Revision Type
blinking_led.qsf	Partial Reconfiguration - Base
hpr_child_default.qsf	Partial Reconfiguration - Persona Implementation
hpr_child_slow.qsf	Partial Reconfiguration - Persona Implementation
hpr_child_empty.qsf	Partial Reconfiguration - Persona Implementation
hpr_parent_slow_child_default.qsf	Partial Reconfiguration - Persona Implementation
hpr_parent_slow_child_slow.qsf	Partial Reconfiguration - Persona Implementation

Table 4. Parent and Child Persona Revisions

Revision Name	Parent Persona Behavior	Child Persona Behavior
hpr_child_default.qsf	Fast Blinking	Fast Blinking
hpr_child_slow.qsf	Fast Blinking	Slow Blinking
hpr_child_empty.qsf	Fast Blinking	No Blinking (Always ON)
hpr_parent_slow_child_default.qsf	Slow Blinking	Fast Blinking
hpr_parent_slow_child_slow.qsf	Slow Blinking	Fast Blinking

Setting the Base Revision Type

1. Click **Project > Revisions**.
2. In **Revision Name**, select the **blinking_led** revision, and then click **Set Current**.
3. Click **Apply**. The **blinking_led** revision displays as the current revision.
4. To set the **Revision Type** for **blinking_led**, click **Assignments > Settings > General**.
5. For **Revision Type**, select **Partial Reconfiguration - Base**, and then click **OK**.
6. Verify that the **blinking_led.qsf** now contains the following assignment:


```
##blinking_led.qsf
set_global_assignment -name REVISION_TYPE PR_BASE
```

Creating Implementation Revisions

1. To open the **Revisions** dialog box, click **Project > Revisions**.
2. To create a new revision, double-click **<<new revision>>**.
3. In **Revision name**, specify **hpr_child_default** and select **blinking_led** for **Based on revision**.
4. For the **Revision type**, select **Partial Reconfiguration - Persona Implementation**.

5. Enable **This project uses a Partition Database (.qdb) file for the root partition**. You do not need to specify the **Root Partition Database file** at this point. You can input this name at a later stage from the **Design Partitions Window**.

Figure 7. Creating Revisions




6. Similarly, set the **Revision type** for the other revisions:

- hpr_child_slow
- hpr_child_empty
- hpr_parent_slow_child_default
- hpr_parent_slow_child_slow

Note: Do not specify the above revisions as current revision.

7. Verify that each .qsf file now contains the following assignment:

```
set_global_assignment -name REVISION_TYPE PR_IMPL
```



Step 7: Compiling the Base Revision and Exporting the Static Region

To compile the base revision and export the static region:


1. To compile the base revision, click **Processing > Start Compilation**.
Alternatively, the following command compiles the base revision:

```
quartus_sh --flow compile blinking_led -c blinking_led
```

2. To export the root partition, click **Project > Export Design Partition**, and then specify the following options for the partition:

Option	Setting
Partition name	root_partition
Partition database file	<project>/blinking_led_static.qdb
Include entity-bound SDC files	Enable
Snapshot	Final

Figure 8. Exporting the Static Region




Alternatively, the following command exports the root partition:

```
quartus_cdb -r blinking_led -c blinking_led --export_block \
root_partition --snapshot final --file blinking_led_static.qdb \
--include_sdc_entity_in_partition
```

3. To export the parent PR partition, click **Project > Export Design Partition**, and then specify the following options for the partition:

Option	Setting
Partition name	pr_parent_partition
Partition database file	<project>/ pr_parent_partition_default_final.qdb
Include entity-bound SDC files	Enable
Snapshot	Final

Figure 9. Exporting the Parent PR Region



Alternatively, the following command exports the parent PR region:

```
quartus_cdb -r blinking_led -c blinking_led --export_block \
  root_partition --snapshot final --file blinking_led_static.qdb \
  --include_sdc_entity_in_partition
```

4. Inspect the bitstream files generated to the output_files directory.



Table 5. Generated Bitstream Files

Name	Type	Description
blinking_led.sof	Base programming file	Used to program the FPGA with the static logic, along with the default personas for the parent and child PR regions.
blinking_led.pr_parent_partition.rbf	PR bitstream file for parent PR partition	Used to program the default persona for the parent PR region.
blinking_led.pr_child_partition.rbf	PR bitstream file for child PR partition	Used to program the default persona for the child PR region.


Related Information

- [Floorplan the Partial Reconfiguration Design](#)
- [Applying Floorplan Constraints Incrementally](#)

Step 8: Preparing the PR Implementation Revisions for Parent PR Partition

You must prepare the parent and child PR implementation revisions before you can generate the PR bitstream for device programming. This setup includes mapping the new PR logic to the preexisting parent PR partition.

1. To set the current revision, click **Project > Revisions**, select **hpr_parent_slow_child_default** as the **Revision name**, and then click **Set Current**.
2. To verify the correct source for each implementation revision, click **Project > Add/Remove Files in Project**. The **blinking_led_child.sv** file appears in the file list.



3. Repeat steps 1 through 2 to verify the other implementation revision source files:

Implementation Revision Name	Parent Persona Source File	Child Persona Source File
hpr_parent_slow_child_default	blinking_led_slow.sv	blinking_led_child.sv



- To verify the .qdb file associated with the root partition, click **Assignments** ➤ **Design Partitions Window**. Specify the .qdb file associated with the static region by double-clicking the **Partition Database File** cell and navigating to the blinking_led_static.qdb file.

Partition Name	Hierarchy Path	Type	Preservation Level	Empty	Partition Database File	Entity Re-binding
<<new>>						
root_partition					blinking_led_static.qdb	

Alternatively, the following command assigns this file:

```
set_instance_assignment -name QDB_FILE_PARTITION \
    blinking_led_static.qdb -to |
```

- In the **Entity** cell, specify the entity name the PR parent partition. For this implementation revision, the entity name is blinking_led_slow. blinking_led_slow is the name of the entity that you are partially reconfiguring. u_blinking_led is the name of the instance that your entity overwrites during PR. Verify that the following line now exists in the .qsf:

Partition Name	Hierarchy Path	Type	Preservation Level	Empty	Partition Database File	Entity Re-binding	Color
<<new>>							
root_partiti...					blinking_led_static.qdb		
pr_parent...	u_blinking_led	Reconfigurable	Not Set	No		blinking_led_slow	
pr_partition	u_blinking_le...	Reconfigurable	Not Set	No			

```
#hpr_parent_slow_child_default.qsf
set_instance_assignment -name ENTITY_REBINDING blinking_led_slow -to
u_blinking_led
```

Note: Because the child PR logic is already defined by the parent PR partition, whose entity name is rebound, do not use an entity rebinding assignment for the child PR partition.

- To compile the design, click **Processing** ➤ **Start Compilation**. Alternatively, the following command compiles this project:


```
quartus_sh --flow compile blinking_led -c hpr_parent_slow_child_default
```

- To export this new parent PR partition as a finalized .qdb, click **Project** ➤ **Export Design Partition**, and then specify the following options for the partition:

Option	Setting
Partition name	pr_parent_partition
Partition database file	<project>/pr_parent_partition_slow_final.qdb
Include entity-bound SDC files	Enable
Snapshot	Final



Figure 10. Exporting the Modified Parent PR Region



Alternatively, the following command exports the parent PR region:

```
quartus_cdb -r blinking_led -c blinking_led --export_block \
root_partition --snapshot final --file blinking_led_static.qdb \
--include_sdc_entity_in_partition
```


8. Inspect the bitstream files generated to the output_files directory.

Table 6. Generated Bitstream Files


Name	Type	Description
hpr_parent_slow_child_default.pr_parent_partition.rbf	PR bitstream file for parent PR partition	Used to program the default persona for the parent PR region. Causes the led_two_on to blink at a lower rate.
hpr_parent_slow_child_default.pr_parent_partition.pr_partition.rbf	PR bitstream file for child PR partition	Used to program the default persona for the child PR region. Causes the led_three_on to blink at the default rate.

Step 9: Preparing the PR Implementation Revisions for Child PR Partitions

This setup includes adding the static region .qdb file as the source file for each implementation revision. In addition, you must import the parent PR partition .qdb file and specify the corresponding entity of the PR region.




1. To set the current revision, click **Project > Revisions**, select **hpr_child_default** as the **Revision name**, and then click **Set Current**.
2. To verify the correct source for each implementation revision, click **Project > Add/Remove Files in Project**. The **blinking_led_child.sv** file appears in the file list.



3. Repeat steps 1 through 2 to verify the other implementation revision source files:

Implementation Revision Name	Child Persona Source File
hpr_child_default	blinking_led_child.sv
hpr_child_slow	blinking_led_child_slow.sv
hpr_child_empty	blinking_led_child_empty.sv
hpr_parent_slow_child_slow	blinking_led_child_slow.sv

4. To verify the .qdb file associated with the root partition, click **Assignments > Design Partitions Window**. Specify the .qdb file associated with the static region by double-clicking the **Partition Database File** cell and navigating to the **blinking_led_static.qdb** file.



Alternatively, the following command assigns this file:

```
set_instance_assignment -name QDB_FILE_PARTITION \  
    blinking_led_static.qdb -to |
```

5. To specify the parent PR partition .qdb file, click **Assignments > Design Partitions Window**. Double-click the **Partition Database File** for the **parent_pr_partition** and specify the respective .qdb file.



Implementation Revision Name	Parent Persona .qdb File
hpr_child_default	pr_parent_partition_default_final.qdb
hpr_child_slow	pr_parent_partition_default_final.qdb
hpr_child_empty	pr_parent_partition_default_final.qdb
hpr_parent_slow_child_slow	pr_parent_partition_slow_final.qdb

verify the following line exists in the .qsf:

```
# To use the default parent PR persona:
set_instance_assignment -name QDB_FILE_PARTITION \
    pr_parent_partition_default_final.qdb -to u_blinking_led

# To use the slow parent PR persona:
set_instance_assignment -name QDB_FILE_PARTITION \
    pr_parent_partition_slow_final.qdb -to u_blinking_led
```

- In the **Entity Re-binding** cell, specify the entity name of the child PR partition. For the default persona, the entity name is `blinking_led`. For this implementation revision, `blinking_led_child` is the name of the entity that you are partially reconfiguring. `u_blinking_led|u_blinking_led_child` is the name of the instance that your entity overwrites during PR. Verify that the following line now exists in the .qsf:

Partition Name	Hierarchy Path	Type	Preservation Level	Empty	Partition Database File	Entity Re-binding	Color
<<new>>							
root_partition					blinking_led_static.qdb		
pr_parent_partition	u_blinking_led	Reconfigurable	Not Set	No	pr_parent_partition_default_final.qdb		
pr_partition	u_blinking_led u_blinking_led_child	Reconfigurable	Not Set	No		blinking_led_child	

```
#hpr_child_default.qsf
set_instance_assignment -name ENTITY_REBINDING \
    blinking_led_child -to u_blinking_led|u_blinking_led_child

#hpr_child_slow.qsf and hpr_parent_slow_child_slow.qsf
set_instance_assignment -name ENTITY_REBINDING \
    blinking_led_child_slow -to u_blinking_led|u_blinking_led_child

#hpr_child_empty.qsf
set_instance_assignment -name ENTITY_REBINDING \
    blinking_led_child_empty -to u_blinking_led|u_blinking_led_child
```

- To compile the design, click **Processing ► Start Compilation**. Alternatively, the following command compiles this project:

```
quartus_sh --flow compile blinking_led -c hpr_child_default
```

- Repeat the above steps to prepare `hpr_child_slow`, `hpr_child_empty`, and `hpr_parent_slow_child_slow` revisions.

Note: You can specify any Fitter specific settings that you want to apply during the PR implementation compilation. Fitter specific settings impact only the fit of the persona, without affecting the imported static region.

- Inspect the bitstream files generated to the `output_files` directory.

Note: Since you imported the parent PR partition as a finalized .qdb file, and used entity-rebinding only on the child PR region, the software generates the PR bitstream only for the child PR partition.



Verify that the `output_files` directory contains the following generated `.rbf` files after compiling all the implementation revisions:

- `hpr_child_default.pr_parent_partition.pr_partition.rbf`
- `hpr_child_slow.pr_parent_partition.pr_partition.rbf`
- `hpr_child_empty.pr_parent_partition.pr_partition.rbf`
- `hpr_parent_slow_child_slow.pr_parent_partition.pr_partition.rbf`

Step 10: Programming the Board

Before you begin:

1. Connect the power supply to the Stratix 10 GX FPGA development board.
2. Connect the USB Blaster cable between your PC USB port and the USB Blaster port on the development board.

Note: This tutorial utilizes the Stratix 10 GX FPGA development board on the bench, outside of the PCIe slot in your host machine.


To run the design on the Stratix 10 GX FPGA development board:

1. Open the Intel Quartus Prime software and click **Tools > Programmer**.
2. In the Programmer, click **Hardware Setup** and select **USB-Blaster**.
3. Click **Auto Detect** and select the device, **1SG280LU5S1**.
4. Click **OK**. The Intel Quartus Prime software detects and updates the Programmer with the three FPGA chips on the board.
5. Select the 1SG280LU5S1 device, click **Change File** and load the `blinking_led.sof` file.
6. Enable **Program/Configure** for `blinking_led.sof` file.
7. Click **Start** and wait for the progress bar to reach 100%.
8. Observe the LEDs on the board blinking at the same frequency as the original flat design.
9. To program only the child PR region, right-click the `blinking_led.sof` file in the Programmer and click **Add PR Programming File**.
10. Select the `hpr_child_slow.pr_parent_partition.pr_partition.rbf` file.
11. Disable **Program/Configure** for `blinking_led.sof` file.
12. Enable **Program/Configure** for `hpr_child_slow.pr_parent_partition.pr_partition.rbf` file and click **Start**. On the board, observe `LED[0]` and `LED[1]` continuing to blink. When the progress bar reaches 100%, `LED[2]` blinks at the same rate, and `LED[3]` blinks slower.
13. To program both the parent and child PR region, right-click the `.rbf` file in the Programmer and click **Change PR Programming File**.



14. Select the `hpr_parent_slow_child_slow.pr_parent_partition.rbf` file.
15. Click **Start**. On the board, observe that `LED[0]` and `LED[1]` continuing to blink. When the progress bar reaches 100%, both `LED[2]` and `LED[3]` blink slower.
16. Repeat the above steps to dynamically re-program just the child PR region, or both the parent and child PR regions simultaneously.

Figure 11. Programming the Stratix 10 GX FPGA Development Board



If you face any PR programming errors, refer to the *Troubleshooting PR Programming Errors* section in the Partial Reconfiguration User Guide.

Related Information

[Troubleshooting PR Programming Errors](#)

Programming the Child PR Region

The current version of the Intel Quartus Prime Pro Edition software does not provide a mechanism to check for incompatible child PR bitstreams for Stratix 10 devices. So, it is very important that you program the correct child persona to match the parent persona. Programming an incompatible bitstream on Stratix 10 FPGA can result in one of the following:

- Successful PR programming, but corrupted FPGA functionality
- Unsuccessful PR programming, and corrupted FPGA functionality

If you wish to reprogram a child PR region on the FPGA, you must ensure that the child PR `.rbf` is generated from an implementation revision compile whose parent PR persona matches the persona currently on the FPGA. For example, when you program the base `blinking_led.sof` onto the FPGA, the parent PR persona is `default`. The child PR persona is `default` as well. To change the child PR persona to `slow` persona, you have the choice of using the following bitstreams:



1. `hpr_child_slow.pr_parent_partition.pr_partition.rbf`
2. `hpr_parent_slow_child_slow.pr_parent_partition.pr_partition.rbf`

In this case, you must choose the former, as the `hpr_child_slow.pr_parent_partition.pr_partition.rbf` is generated by an implementation revision that has the default parent persona. Choosing `hpr_parent_slow_child_slow.pr_parent_partition.pr_partition.rbf` results in unsuccessful PR programming, corrupted FPGA functionality, or both.

Modifying an Existing Persona

You can change an existing persona, even after fully compiling the base revision.

For example, to cause the `blinking_led_child_slow` persona to blink even slower:

1. In the `blinking_led_child_slow.sv` file, modify the `COUNTER_TAP` parameter from 27 to 28.
2. Recompile any implementation revision that uses this source file, such as `hpr_child_slow` or `hpr_parent_slow_child_slow`.
3. Regenerate the PR bitstreams from the `.pmsf` files.
4. Follow the steps in [Step 10: Programming the Board](#) on page 22 to program the resulting RBF file into the FPGA.

Adding a New Persona to the Design

After fully compiling your base revisions, you can still add new personas and individually compile these personas.

For example, to define a new persona that causes `led_two` (parent) to blink at a slower rate, while keeping `led_three` (child) on:

1. Create an implementation revision, `hpr_parent_slow_child_empty`, by following the steps in [Creating Implementation Revisions](#) on page 13.
2. Compile the revision by clicking **Processing > Start Compilation**.

For complete information on hierarchical partial reconfiguration for Stratix 10 devices, refer to *Creating a Partial Reconfiguration Design* in Volume 1 of the *Intel Quartus Prime Pro Edition Handbook*.

Related Information

- [Creating a Partial Reconfiguration Design](#)
- [Partial Reconfiguration Online Training](#)



Document Revision History for AN 826: Hierarchical Partial Reconfiguration Tutorial for Stratix 10 GX FPGA Development Board

Document Version	Intel Quartus Prime Version	Changes
2018.05.07	18.0.0	<ul style="list-style-type: none">• Compilation flow change• Other minor text edits
2017.11.06	17.1.0	Initial release of the document