

Command	Description	Usage	Argument types
ADDNODES	Add a simulation instance/node	ADDNODES number	int
ADDWPT	Add a waypoint to route of aircraft (FMS)	ADDWPT acid, (wpname/lat,lon),[alt],[spd],[afterwp]	acid,wpt,[alt,spd,txt]
ALT	Altitude command (autopilot)	ALT acid, alt, [vspd]	acid,alt,[vspd]
AREA	Define experiment area (area of interest)	AREA Shapename/OFF or AREA lat,lon,lat,lon,[top,bottom]	[float/txt,float,float,float,alt,alt]
ASAS	Airborne Separation Assurance System switch	ASAS ON/OFF	[onoff]
BATCH	Start a scenario file as batch simulation	BATCH filename	string
BENCHMARK	Run benchmark	BENCHMARK [scenfile,time]	[txt,time]
BOX	Define a box-shaped area	BOX name,lat,lon,lat,lon,[top,bottom]	txt,latlon,latlon,[alt,alt]
CALC	Simple in-line math calculator, evaluates expression	CALC expression	string
CDMETHOD	Set conflict detection method	CDMETHOD [method]	[txt]
CIRCLE	Define a circle-shaped area	CIRCLE name,lat,lon,radius,[top,bottom]	txt,latlon,float,[alt,alt]
CRE	Create an aircraft	CRE acid,type,lat,lon,hdg,alt,spd	txt,txt,latlon,hdg,alt,spd
DATAFEED	Select an ADS-B data source for traffic	DATAFEED [ON/OFF]	[onoff]
DEL	Delete command (aircraft, wind, area)	DEL acid/WIND/shape	txt
DELWPT	Delete a waypoint from a route (FMS)	DELWPT acid,wpname	acid,txt
DEST	Set destination of aircraft, aircraft wil fly to this airport	DEST acid, latlon/airport	acid,wpt/latlon
DIRECT	Go direct to specified waypoint in route (FMS)	DIRECT acid wpname	acid,txt
DIST	Distance and direction calculation between two positions	DIST lat0, lon0, lat1, lon1	latlon,latlon
DT	Set simulation time step	DT dt	float
DTLOOK	Set lookahead time in seconds for conflict detection	DTLOOK [time]	[float]
DTMULT	Sel multiplication factor for fast-time simulation	DTMULT multiplier	float
DTNOLOOK	Set interval for conflict detection	DTNOLOOK [time]	[float]
DUMP RTE	Write route to output/routelog.txt	DUMP RTE acid	acid
ECHO	Show a text in command window for user to read	ECHO txt	string
ENG	Specify a different engine type	ENG acid,[engine_id]	acid,[txt]
FF	Fast forward the simulation	FF [tend]	[time]
FIXDT	Fix the time step	FIXDT ON/OFF [tend]	onoff,[time]
GETWIND	Get wind at a specified position (and optionally at altitude)	GETWIND lat,lon,[alt]	latlon,[alt]
HDG	Heading command (autopilot)	HDG acid,hdg (deg,True)	acid,float
HELP	Show help on a command, a pdf or write commands to file	HELP [command] or PDF or >filename	[txt]
HOLD	Pause(hold) simulation	HOLD	
IC	Initial condition: (re)start simulation and open scenario file	IC [IC/filename]	[string]
INSEdit	Insert text op edit line in command window	INSEdit txt	string
INSTLOG	INSTLOG data logging on	INSTLOG ON/OFF,[dt] or LISTVARS or SELECTVARS var1,...,varn	[txt,float/txt,...]
LINE	Draw a line on the radar screen	LINE name,lat,lon,lat,lon	txt,latlon,latlon
LIST RTE	Show list of route in window per page of 5 waypoints	LIST RTE acid, [pagenr]	acid,[int]
LNAV	LNAV (lateral FMS mode) switch for autopilot	LNAV acid,[ON/OFF]	acid,[onoff]
MCRE	Multiple random create of n aircraft in current view	MCRE n, [type/* , alt/* , spd/* , dest/*]	int,[txt,alt,spd,txt]
METRIC	Complexity metrics module	METRIC OFF/0/1/2, [dt]	onoff/int,[float]
MOVE	Move an aircraft to a new position	MOVE acid,lat,lon,[alt,hdg,spd,vspd]	acid,latlon,[alt,hdg,spd,vspd]
ND	Show navigation display with CDTI	ND acid	txt
NOISE	Turbulence/noise switch	NOISE [ON/OFF]	[onoff]
NOM	Set nominal acceleration for this aircraft (perf model)	NOM acid	acid
NORESO	Switch off conflict resolution for this aircraft	NORESO [acid]	[string]
OP	Start/Run simulation or continue after pause	OP	
ORIG	Set origin airport of aircraft	ORIG acid, latlon/airport	acid,wpt/latlon
PAN	Pan screen (move view) to a waypoint, direction or aircraft	PAN latlon/acid/airport/waypoint/LEFT/RIGHT/ ABOVE/DOWN	pandir/latlon
PCALL	Call commands in another scenario file	PCALL filename [REL/ABS]	txt,[txt]
POLY	Define a polygon-shaped area	POLY name,lat,lon,lat,lon, ...	txt,latlon,...
POLYALT	Define a polygon-shaped area in 3D: between two altitudes	POLY name,top,bottom,lat,lon,lat,lon, ...	txt,alt,alt,latlon,...
POS	Get info on aircraft	POS acid	txt
PRIORULES	Define priority rules (right of way) for conflict resolution	PRIORULES [ON/OFF PRIORCODE]	[onoff, txt]
QUIT	Quit program/Stop simulation	QUIT	
RESET	Reset simulation	RESET	
RESO	Set resolution method	RESO [method]	[txt]
RESOOFF	Switch for conflict resolution module	RESOOFF [acid]	[string]
RFACH	Set resolution factor horizontal (to add a margin)	RFACH [factor]	[float]
RFACV	Set resolution factor vertical (to add a margin)	RFACV [factor]	[float]

RMETHH	Set resolution method to be used horizontally	RMETHH [method]	[txt]
RMETHV	Set resolution method to be used vertically	RMETHV [method]	[txt]
RSZONEDH	Set half of vertical dimension of resolution zone in ft	RSZONEDH [height]	[float]
RSZONER	Set horizontal radius of resolution zone in nm	RSZONER [radius]	[float]
RUNWAYS	List available runways on an airport	RUNWAYS ICAO	txt
SAVEIC	Save current situation as IC	SAVEIC filename	string
SCEN	Give current situation a scenario name	SCEN scenname	string
SEED	Set seed for all functions using a randomizer (e.g.mcre,noise)	SEED value	int
SKYLOG	SKYLOG data logging on	SKYLOG ON/OFF,[dt] or LISTVARS or SELECTVARS var1,...,varn	[txt,float/txt,...]
SNAPLOG	SNAPLOG data logging on	SNAPLOG ON/OFF,[dt] or LISTVARS or SELECTVARS var1,...,varn	[txt,float/txt,...]
SPD	Speed command (autopilot)	SPD acid,spd (CAS-kts/Mach)	acid,spd
SSD	Show state-space diagram (=conflict prevention display/predictive ASAS)	SSD acid/ALL/OFF	txt
SWRAD	Switch on/off elements and background of map/radar view	SWRAD GEO/GRID/APT/VOR/WPT/LABEL/ADSBCO VERAGE/TRAIL [dt]/[value]	txt,[float]
SYMBOL	Toggle aircraft symbol	SYMBOL	
SYN	Macro for generating synthetic (geometric) traffic scenarios	SYN: Possible subcommands: HELP, SIMPLE, SIMPLD, DIFG, SUPER,MATRIX, FLOOR, TAKEOVER, WALL, ROW, COLUMN, DISP	txt,[...]
TAXI	Switch on/off ground/low altitude mode, prevents auto-delete at 1500 ft	TAXI ON/OFF : OFF auto deletes traffic below 1500 ft	onoff
TIME	Set simulated clock time	TIME RUN(default) / HH:MM:SS.hh / REAL / UTC	[txt]
TRAIL	Toggle aircraft trails on/off	TRAIL ON/OFF, [dt] OR TRAIL acid color	acid/bool,[float/txt]
VNAV	Switch on/off VNAV mode, the vertical FMS mode (autopilot)	VNAV acid,[ON/OFF]	acid,[onoff]
VS	Vertical speed command (autopilot)	VS acid,vspd (ft/min)	acid,vspd
WIND	Define a wind vector as part of the 2D or 3D wind field	WIND lat,lon,alt/*,dir,spd[,alt,dir,spd,alt,...]	latlon,[alt],float,float,...,.....
ZONEDH	Set half of the vertical protected zone dimensions in ft	ZONEDH [height]	[float]
ZONER	Set the radius of the horizontal protected zone dimensions in nm	ZONER [radius]	[float]
ZOOM	Zoom display in/out, you can also use +++ or ----	ZOOM IN/OUT or factor	float/txt

Synonyms	Equivalent command	Description
?	HELP	Show help in a command or write list of commands to file
CLOSE	QUIT	Quit program/Stop simulation
CONTINUE	OP	Start/Run simulation or continue after pause
CREATE	CRE	Create an aircraft
DELETE	DEL	Delete command (aircraft, wind, area)
DIRECTTO	DIRECT	Go direct to specified waypoint in route (FMS)
DIRTO	DIRECT	Go direct to specified waypoint in route (FMS)
DISP	SWRAD	Switch on/off elements and background of map/radar view
END	QUIT	Quit program/Stop simulation
EXIT	QUIT	Quit program/Stop simulation
FWD	FF	Fast forward the simulation
HMETH	RMETHH	Set resolution method to be used horizontally
HRESOM	RMETHH	Set resolution method to be used horizontally
HRESOMETH	RMETHH	Set resolution method to be used horizontally
LOAD	IC	Initial condition: (re)start simulation and open scenario file
OPEN	IC	Initial condition: (re)start simulation and open scenario file
PAUSE	HOLD	Pause(hold) simulation
Q	QUIT	Quit program/Stop simulation
RESOFACH	RFACH	Set resolution factor horizontal (to add a margin)
RESOFACV	RFACV	Set resolution factor vertical (to add a margin)
RUN	OP	Start/Run simulation or continue after pause
START	OP	Start/Run simulation or continue after pause
STOP	QUIT	Quit program/Stop simulation
TURN	HDG	Heading command (autopilot)
VMETH	RMETHV	Set resolution method to be used vertically
VRESOM	RMETHV	Set resolution method to be used vertically
VRESOMETH	RMETHV	Set resolution method to be used vertically