

NAME

mbm_makesvp – Macro to extract sound speed and depth data from a datalist of swath files, and generate a sound velocity profile model from averages of the sound speed values in regular depth ranges.

VERSION

Version 5.0

SYNOPSIS

mbm_makesvp *-Inputfile* [**-A** **-D***depthinterval* **-H** **-M***mode* **-O***outputfile* **-V**]

DESCRIPTION

mbm_makesvp is a macro to extract sound speed and depth data from a datalist of swath files, and generate a sound velocity profile model from averages of the sound speed values in regular depth ranges. This macro is intended for use with mapping data from submerged platforms (e.g. ROVs and AUVs) carrying CTD or SSV sensors. If **-M0** is used, then sound speed values are extracted directly from data records containing CTD or SSV values. If **-M1** is used, then sound speed values are extracted from the sonar survey data records (e.g. the sound speed values used for beamforming). The sound speed and sonar depth value pairs are binned according to the *depthinterval* value, and average sound speed values are reported for bins with at least one value. If **-A** is specified, the sound speed profile is prepended with a zero depth value equal to the shallowest calculated value, and appended with a full ocean depth (11000 meters) value equal to the deepest calculated corrected for pressure using a correction of $0.0167 * \text{delta_depth}$ in m/sec. The **-O** option specifies the output filename; by default the model is output to the stdout stream.

MB-SYSTEM AUTHORSHIP

David W. Caress
 Monterey Bay Aquarium Research Institute
 Dale N. Chayes
 Center for Coastal and Ocean Mapping
 University of New Hampshire
 Christian do Santos Ferreira
 MARUM - Center for Marine Environmental Sciences
 University of Bremen

OPTIONS

- A** If **-A** is specified, the sound speed profile is prepended with a zero depth value equal to the shallowest calculated value, and appended with a full ocean depth (11000 meters) value equal to the deepest calculated corrected for pressure using a correction of $0.0167 * \text{delta_depth}$ in m/sec.
- D** *depthinterval*
 Sets the size in meters of the depth bins used to calculate an average sound speed versus depth model. The default value is 25 meters.
- F** *format*
 Sets the data format for the input data. If *format* < 0, then the input file specified with the **-I** option will actually contain a list of input swath sonar data files. This program uses the **MBIO** library and will read or write any swath sonar format supported by **MBIO**. A list of the swath sonar data formats currently supported by **MBIO** and their identifier values is given in the **MBIO** manual page. Default: *format* = -1.
- H** This "help" flag cause the program to print out a description of its operation and then exit immediately.
- I** *inputfile*
 Sets the input filename. If *format* > 0 (set with the **-f** option) then the swath sonar data contained in *infile* is read and processed. If *format* < 0 (the default), then *infile* is assumed to be an ascii file

containing a list of the input swath sonar data files to be processed and their formats. The program will read the data in each one of these files. In the *inputfile* file, each data file should be followed by a data format identifier, e.g.:

```
datafile1 11
datafile2 24
```

This program uses the **MBIO** library and will read any swath sonar format supported by **MBIO**. However, not all formats contain sound speed or CTD information, and useful results can only be expected from data actually including the relevant values. A list of the swath sonar data formats currently supported by **MBIO** and their identifier values is given in the **MBIO** manual page. The default input filename is "datalist.mb-1".

- M** *mode*
If **-M0** is used, then sound speed values are extracted directly from data records containing CTD or SSV values. If **-M1** is used, then sound speed values are extracted from the sonar survey data records (e.g. the sound speed values used for beamforming). Default: *mode=0*.
- O** *output*
Sets the name of the output file for the sound speed versus depth model. By default, the model is output to the stdout stream.
- V** The **-V** option causes **mbm_makesvp** to print out status messages.

EXAMPLES

Suppose we have a set of swath files from an AUV-based survey in a directory and we want to construct an average sound speed versus depth model from these data. The command:

```
mbm_makesvp -Idatalist.mb-1 -D25 -Osvp.txt -V
```

will generate a model of sound speed versus depth in the output file "svp.txt".

SEE ALSO

mbsystem(1), **mbctdlist**(1)

BUGS

Likely yes.