

Phone Application Interface						
HMI Area				Design Notes		
Automation - Service Manager - Page 1						
Selet tts_1 Speaker				Required for Audio Notification and Text-To-Speech to work on Speakers and older soundbars. Tap to set. Your installed LAN SamsungAudio speakers will display. Pick one for each LAN SamsungAudio speaker you have installed Once the device is installed, match the number here in on the preferences page of the device handler.		
Selet tts_2 Speaker						
Selet tts_3 Speaker						
Selet tts_4 Speaker						
Selet tts_5 Speaker						
My Home - Device - Details Page						
<div>Media Player Interface</div> <div>Previous // Play-Pause // Next</div> <div>MuteMarqueeVolume</div>				<div>Previous: Command sent twice to go to beginning then to previous song. CP - Program limited to Amazon, Amazon Prime. DLNA - Send commands. Works IAW the player capabilities. Others - Program disabled with error message. Next: Same as Previous, but add Pandora and 8tracks to CP capable. Play/Pause: Works for cp and dlna players. Disabled (No message) for other modes. Mute: Mutes the audio. Volume: In percent of maximum. Programmed for soundbar to be max of 60. For speaker max is 30. Marquee: Display song or station (CP and DLNA modes) or mode for non-WiFi modes.</div>		
				<div>On/Off: Soundbar turns 'off'. Speaker - stops player. Blue is ON. Source: Toggles between sources available for device. Update Display: Refreshes display states of Power, Source, Play Status, Volume, Mute, and Marquee. Recommend pressing before creating a preset. Equalizer Mode: From presets defined in Multiroom App. Shuffle / Repeat Modes: Displays when available on playing channel. Otherwise displays "No Shuffle" or "No Repeat".</div>		
On/Off	Source	Update Display	Equalizer Mode	Shuffle Mode	Repeat Mode	
				<div>Presets: Will be "- - - -" if preset is not defined. Displays preset short name (first 25 characters). Creating Preset: Select channel in Multiroom App. Press "REFRESH:; Press a "--" preset. Will display "Add Preset". Press again to add. Do not press - time out add in about 15 seconds. Delete Preset: To delete a preset (a. press "Delete Preset". (b) press preset to be deleted. (c) ress this button again to delete the preset. Will time out after about 15 seconds.</div>		
Player Preset 1		Player Preset 2		Player Preset 3		
Player Preset 4		Player Preset 5		Player Preset 6		
Player Preset 7		Player Preset 8		Delete Preset		
Latest Message (press to clear)			Current Group Title		<div>Latest Message: Message generated by Device Handler. Will clear after about 30 sec. Current Group Title: Displays selected group. When displaying, pressing will turn off the group.</div>	
Group Preset 1		Group Preset 2		Group Preset 3		
Group Master Volume Label		Speaker Control Toggle			<div>Speaker Control Toggle: "-" when a group is not enables. Toggles between the speakers in the group.</div>	
Group Master Volume Slider		Speaker Volume Slider		Speaker EQVol Slider		
<div>Volume Sliders: Work same as volume, using same scales (see Volume). EQ Vol: Used in Surround Sound. Provides +/- 6 scale to volume for device. Used to fine tune volume in Surround/Stereo mode.</div>						
My Home - Device - Preferences Page						
SOUNDBAR ONLY: Rear Speaker				Selected = slider to right, blue color. If selected - you have a Soundbar rear speaker connected and want to control it's level.		
SOUNDBAR ONLY: Rear Speaker Level				Level from -6 to +6 for rear speakers.		
SPEAKER ONLY: Surrogate for TTS				When running service manager, you identified up to 5 TTS speakers that are the "LAN SamsungAudio" speakers that will play TTS and Audio Notifications. Here, you match that selection to the explicit speaker.		
SPEAKER ONLY: TTS Voice				Select the voice for TTS announcements. Language of voice must match the language of your TTS text.		
MS SOUNDBAR ONLY: Text-To-Speech Key				The soundbar uses a different TTS engine than the LAN SamsungAudio (the Amazon engine does not work for this handler). This is the key you obtain from voicerss.org. Limit: 350 calls per day free.		
MS SOUNDBAR ONLY: TTS Language				The soundbar TTS language. Must match the language of the text entered. Voice chanches dependent on language (I.e., US is different from Australian).		