

# FIFO Collection - Quick Reference

## UVVM Support Component

The FIFO Collection is a memory buffer that can be used to hold one or more FIFOs. Each FIFO will be allocated a chosen size and ID number. This allows a selectable number of FIFOs to operate individually and be independently accessed.

### **uvvm\_fifo\_init ( [buffer\_idx, ] buffer\_size\_in\_bits )**

**Example:** v\_buffer\_idx := uvvm\_fifo\_init(C\_BUFFER\_SIZE-1); -- returns a buffer index on initialization

**Example:** uvvm\_fifo\_init(C\_BUFFER\_IDX\_1, C\_BUFFER\_SIZE-1); -- buffer index is selected

### **uvvm\_fifo\_put ( buffer\_idx, data )**

**Example:** uvvm\_fifo\_put(C\_BUFFER\_IDX\_1, v\_rx\_data);

### **uvvm\_fifo\_get ( buffer\_idx, entry\_size\_in\_bits )**

**Example:** v\_rx\_data := uvvm\_fifo\_get (C\_BUFFER\_IDX\_1, C\_ENTRY\_SIZE\_1);

### **uvvm\_fifo\_flush ( buffer\_idx )**

**Example:** uvvm\_fifo\_flush(C\_BUFFER\_IDX\_1);

### **uvvm\_fifo\_peek ( buffer\_idx, entry\_size\_in\_bits )**

**Example:** v\_rx\_data := uvvm\_fifo\_peek(C\_BUFFER\_IDX\_1, C\_ENTRY\_SIZE\_1);

### **uvvm\_fifo\_get\_count ( buffer\_idx )**

**Example:** v\_num\_elements := uvvm\_fifo\_get\_count(C\_BUFFER\_IDX\_1);

### **uvvm\_fifo\_get\_max\_count ( buffer\_idx )**

**Example:** v\_max\_fifo\_elements := uvvm\_fifo\_get\_max\_count(C\_BUFFER\_IDX\_1);

### **uvvm\_fifo\_is\_full ( buffer\_idx )**

**Example:** v\_fifo\_is\_full := uvvm\_fifo\_is\_full (C\_BUFFER\_IDX\_1);

## FIFO Collection – Functional parameters

Name	Type	Example(s)	Description
buffer_idx	natural	1	The index of the FIFO that shall be initialized.
buffer_size_in_bits	natural	1024	The size of the FIFO.
data	SLV	v_rx_data	The data that shall be pushed to the FIFO.

## FIFO Collection details

All FIFO functions and procedures are defined in the UVVM Data FIFO package, `ti_data_fifo_pkg.vhd`

### 1 FIFO Collection details and examples

Method	Description
<b>uvvm_fifo_init()</b>	<p><b>uvvm_fifo_init([buffer_idx,] buffer_size_in_bits)</b></p> <p>This UVVM FIFO call will allocate space in the FIFO buffer. If no <code>buffer_idx</code> is given, the call will return a buffer index for use when addressing the FIFO. Note that 0 will be returned on error. If a <code>buffer_idx</code> is given, the FIFO is initialized with this index.</p> <p>Example:</p> <pre>uvvm_fifo_init(C_BUFFER_IDX_1, C_BUFFER_SIZE-1); -- initialize buffer with index C_BUFFER_IDX_1 v_fifo_idx := uvvm_fifo_init(C_BUFFER_SIZE-1);</pre>
<b>uvvm_fifo_put()</b>	<p><b>uvvm_fifo_put(buffer_idx, data)</b></p> <p>This procedure puts data into a FIFO with index <code>buffer_idx</code>. The size of the data is unconstrained, meaning that it can be any size. Pushing data with a size that is larger than the FIFO size results in wrapping, i.e., that when reaching the end that data remaining will overwrite the data that was first written.</p> <p>Example:</p> <pre>uvvm_fifo_put(C_BUFFER_IDX_1, v_rx_data);</pre>
<b>uvvm_fifo_get()</b>	<p><b>uvvm_fifo_get(buffer_idx, entry_size_in_bits)</b></p> <p>This function returns the data from the FIFO and removes the returned data from the FIFO.</p> <p>Note that <code>buffer_idx</code> is the index of the FIFO that shall be read, and that <code>entry_size_in_bits</code> is the size of the returned data as SLV.</p> <p>Attempting to get data from an empty FIFO is allowed but triggers a <code>TB_WARNING</code> and returns garbage data. Attempting to get a larger value than the FIFO size is allowed but triggers a <code>TB_WARNING</code>.</p> <p>Example:</p> <pre>v_rx_data := uvvm_fifo_get(C_BUFFER_IDX_1, C_ENTRY_SIZE-1);</pre>

---

**uvvm\_fifo\_flush()****uvvm\_fifo\_flush(buffer\_idx)**

This procedure empties the FIFO given by buffer\_idx.

Example:

```
uvvm_fifo_flush(C_BUFFER_IDX_1);
```

---

**uvvm\_fifo\_peek()****uvvm\_fifo\_peek(buffer\_idx, entry\_size\_in\_bits)**

This function returns the data from the FIFO without removing it.

Note that, apart from not removing the data, this function will behave in the same way as the uvvm\_fifo\_get() function.

Example:

```
v_rx_data := uvvm_fifo_peek(C_BUFFER_IDX_1, C_ENTRY_SIZE-1);
```

---

**uvvm\_fifo\_get\_count()****uvvm\_fifo\_get\_count(buffer\_idx)**

This function returns a natural indicating the number of elements currently occupying the FIFO given by buffer\_idx.

Example:

```
v_num_elements := uvvm_fifo_get_count(C_BUFFER_IDX);
```

---

**uvvm\_fifo\_get\_max\_count()****uvvm\_fifo\_get\_max\_count(buffer\_idx)**

This function returns a natural indicating the maximum number of elements that can occupy the FIFO given by buffer\_idx.

Example:

```
v_max_elements := uvvm_fifo_get_max_count(C_BUFFER_IDX);
```

---

**uvvm\_fifo\_is\_full()****uvvm\_fifo\_is\_full(buffer\_idx)**

This function returns a boolean indicating if the FIFO is full or not.

Example:

```
v_fifo_is_full := uvvm_fifo_is_full(C_BUFFER_IDX);
```

---