

# SPI VVC – Quick Reference

For general information see UVVM Essential Mechanisms located in `uvvm_vvc_framework/doc`.

**SPI Master** (see page 2 for SPI Slave)

**spi\_master\_transmit\_and\_receive** (VVCT, vvc\_instance\_idx, data, msg, [see options below])

**Options:** action\_when\_transfer\_is\_done, action\_between\_words

**Master example:** spi\_master\_transmit\_and\_receive(SPI\_VVCT, 1, x"AF", "Sending data to Peripheral 1 and receiving data from Peripheral 1");

**spi\_master\_transmit\_only** (VVCT, vvc\_instance\_idx, data, msg, [see options below])

**Options:** action\_when\_transfer\_is\_done, action\_between\_words

**Master example:** spi\_master\_transmit\_only(SPI\_VVCT, 1, x"AF", "Sending data to Peripheral 1");

**spi\_master\_receive\_only** (VVCT, vvc\_instance\_idx, msg, [see options below])

**Options:** num\_words, action\_when\_transfer\_is\_done, action\_between\_words

**Master example:** spi\_master\_receive\_only(SPI\_VVCT, 1, "Receive from Peripheral 1");

**spi\_master\_transmit\_and\_check** (VVCT, vvc\_instance\_idx, data, data\_exp, msg, [see options below])

**Options:** alert\_level, action\_when\_transfer\_is\_done, action\_between\_words

**Master example:** spi\_master\_transmit\_and\_check(SPI\_VVCT, 1, x"42", x"AF", "Sending data to Peripheral 1 and expecting data from Peripheral 1");

**spi\_master\_check\_only** (VVCT, vvc\_instance\_idx, data\_exp, msg, [see options below])

**Options:** alert\_level, action\_when\_transfer\_is\_done, action\_between\_words

**Master example:** spi\_master\_check\_only(SPI\_VVCT, 1, x"42", "Expect data from Peripheral 1");



**VVC**

spi\_vvc.vhd



**UVVM™**

# SPI VVC – Quick Reference

SPI Slave (see page 1 for SPI Master)

## **spi\_slave\_transmit\_and\_receive (VVCT, vvc\_instance\_idx, data, msg, [see options below])**

**Options:** when\_to\_start\_transfer

**Slave example:** spi\_slave\_transmit\_and\_receive(SPI\_VVCT, 1, x"AF", "Sending data to Peripheral 1 and receiving data from Peripheral 1");

## **spi\_slave\_transmit\_only (VVCT, vvc\_instance\_idx, data, msg, [see options below])**

**Options:** when\_to\_start\_transfer

**Slave example:** spi\_slave\_transmit\_only(SPI\_VVCT, 1, x"AF", "Sending data to Peripheral 1");

## **spi\_slave\_receive\_only (VVCT, vvc\_instance\_idx, msg, [see options below])**

**Options:** num\_words, when\_to\_start\_transfer

**Slave example:** spi\_slave\_receive\_only(SPI\_VVCT, 1, "Receive from Peripheral 1");

## **spi\_slave\_transmit\_and\_check (VVCT, vvc\_instance\_idx, data, data\_exp, msg, [see options below])**

**Options:** alert\_level, when\_to\_start\_transfer

**Slave example:** spi\_slave\_transmit\_and\_check(SPI\_VVCT, 1, x"42", x"AF", "Sending data to Peripheral 1 and expecting data from Peripheral 1");

## **spi\_slave\_check\_only (VVCT, vvc\_instance\_idx, data\_exp, msg, [see options below])**

**Options:** alert\_level, when\_to\_start\_transfer

**Slave example:** spi\_slave\_check\_only(SPI\_VVCT, 1, x"42", "Expect data from Peripheral 1");



**VVC**  
spi\_vvc.vhd



## Common VVC procedures applicable for this VVC

- See UVVM Methods QuickRef for details.

Name
await_completion()
await_any_completion()
enable_log_msg()
disable_log_msg()
flush_command_queue()
terminate_current_command()
fetch_result()
insert_delay()

## SPI VVC Configuration record 't\_vvc\_config'

- Accessible via `shared_spi_vvc_config` – see section 2.

Record element
inter_bfm_delay
[cmd/result]_queue_count_max
[cmd/result]_queue_count_threshold
[cmd/result]_queue_count_threshold_severity
bfm_config
msg_id_panel

## SPI VVC Status record signal 't\_vvc\_status'

- Accessible via `shared_spi_vvc_status` – see section 3.

Record element
current_cmd_idx
previous_cmd_idx
pending_cmd_idx

## VVC target parameters

Name	Type	Example(s)	Description
VVCT	t_vvc_target_record	SPI_VVCT	VVC target type compiled into each VVC in order to differentiate between VVCs.
vvc_instance_idx	integer	1	Instance number of the VVC

## VVC functional parameters

Name	Type	Example(s)	Description
data	std_logic_vector or t_slv_array	x"FF"	The data to be transmitted (in spi_<master/slave>_transmit_and_check or spi_<master/slave>_transmit_only).
data_exp	std_logic_vector or t_slv_array	x"FF"	The expected data to be received (in spi_<master/slave>_transmit_and_check or spi_<master/slave>_check_only).
msg	string	"Send to peripheral 1"	A custom message to be appended in the log/alert
num_words	positive	1, 2, 10	Number of words that shall be received. Default is 1.
action_when_transfer_is_done	t_action_when_transfer_is_done	RELEASE_LINE_AFTER_TRANSFER or HOLD_LINE_AFTER_TRANSFER	Determines if SPI master shall release or hold ss_n after the transfer is done. Default is RELEASE_LINE_AFTER_TRANSFER
action_between_words	t_action_between_words	HOLD_LINE_BETWEEN_WORDS or RELEASE_LINE_BETWEEN_WORDS	Determines if SPI master shall release or hold ss_n between words when transmitting a t_slv_array. Default is HOLD_LINE_BETWEEN_WORDS.
when_to_start_transfer	t_when_to_start_transfer	START_TRANSFER_ON_NEXT_SS or START_TRANSFER_IMMEDIATE	Determines if SPI slave shall wait for next ss_n if a transfer has already started. Default is STAR_TRANSFER_ON_NEXT_SS.
alert_level	t_alert_level	ERROR or TB_WARNING	Set the severity for the alert that may be asserted by the method.

## VVC entity signals

Name	Type	Direction	Description
spl_vvc_if	t_spi_if	Inout	See SPI BFM documentation

## VVC entity generic constants

Name	Type	Default	Description
GC_DATA_WIDTH	natural	8	Bits in the SPI data word
GC_DATA_ARRAY_WIDTH	natural	32	Number of SPI data words in a data word array of type t_slv_array.
GC_INSTANCE_IDX	natural	1	Instance number to assign the VVC
GC_MASTER_MODE	boolean	TRUE	Whether the VVC shall act as an SPI master or an SPI slave on the bus.
GC_SPI_CONFIG	t_spi_bfm_config	C_SPI_BFM_CONFIG_DEFAULT	Configuration for the SPI BFM, see SPI BFM documentation.
GC_CMD_QUEUE_COUNT_MAX	natural	1000	Absolute maximum number of commands in the VVC command queue
GC_CMD_QUEUE_COUNT_THRESHOLD	natural	950	An alert will be generated when reaching this threshold to indicate that the command queue is almost full. The queue will still accept new commands until it reaches GC_CMD_QUEUE_COUNT_MAX.
GC_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY	t_alert_level	WARNING	Alert severity which will be used when command queue reaches GC_CMD_QUEUE_COUNT_THRESHOLD.
GC_RESULT_QUEUE_COUNT_MAX	natural	1000	Maximum number of unfetched results before result_queue is full.
GC_RESULT_QUEUE_COUNT_THRESHOLD	natural	950	An alert with severity 'result_queue_count_threshold_severity' will be issued if result queue exceeds this count. Used for early warning if result queue is almost full. Will be ignored if set to 0.
GC_RESULT_QUEUE_COUNT_THRESHOLD_SEVERITY	t_alert_level	WARNING	Severity of alert to be initiated if exceeding result_queue_count_threshold

# VVC details

All VVC procedures are defined in `vvc_methods_pkg` (dedicated this VVC), and `uvvm_vvc_framework.td_vvc_framework_common_methods_pkg` (common VVC procedures). It is also possible to send a multicast to all instances of a VVC with `ALL_INSTANCES` as parameter for `vvc_instance_idx`.

## 1 VVC procedure details and examples

Procedure	Description
<b><code>spi_master_transmit_and_receive()</code></b>	<p><b><code>spi_master_transmit_and_receive (VVCT, vvc_instance_idx, data, msg, [see options below])</code></b></p> <p><b>Options:</b> <code>action_when_transfer_is_done</code>, <code>action_between_words</code></p> <p>The <code>spi_master_transmit_and_receive()</code> VVC procedure adds a transmit and receive command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the transmit and receive command is scheduled to run, the executor calls the SPI BFM <code>spi_master_transmit_and_receive()</code> procedure, described in the SPI BFM QuickRef. Note that <code>action_between_words</code> only apply for <code>t_slv_array</code> multi-word transfers.</p> <p>There is one requirement for running the <code>spi_master_transmit_and_receive()</code> procedure:</p> <ul style="list-style-type: none"> <li>- The VVC entity with instance index corresponding to the '<code>vvc_instance_idx</code>' parameter must have the generic constant <code>GC_MASTER_MODE</code> set to <code>TRUE</code>.</li> </ul> <p>Examples:</p> <pre>spi_master_transmit_and_receive (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1 and receiving data from Peripheral 1"); spi_master_transmit_and_receive (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1 and receiving data from Peripheral 1", RELEASE_LINE_AFTER_TRANSFER, HOLD_LINE_BETWEEN_WORDS)</pre>
<b><code>spi_master_transmit_only()</code></b>	<p><b><code>spi_master_transmit_only (VVCT, vvc_instance_idx, data, msg, [see options below])</code></b></p> <p><b>Options:</b> <code>action_when_transfer_is_done</code>, <code>action_between_words</code></p> <p>The <code>spi_master_transmit_only()</code> VVC procedure adds a transmit command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the transmit command is scheduled to run, the executor calls the SPI BFM <code>spi_master_transmit()</code> procedure, described in the SPI BFM QuickRef.</p> <p>The SPI BFM <code>spi_master_transmit ()</code> procedure will ignore the received data from the slave DUT. Note that <code>action_between_words</code> only apply for <code>t_slv_array</code> multi-word transfers.</p> <p>There is one requirement for running the <code>spi_master_transmit_only()</code> procedure:</p> <ul style="list-style-type: none"> <li>- The VVC entity with instance index corresponding to the '<code>vvc_instance_idx</code>' parameter must have the generic constant <code>GC_MASTER_MODE</code> set to <code>TRUE</code>.</li> </ul> <p>Examples:</p> <pre>spi_master_transmit_only (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1"); spi_master_transmit_only (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1", RELEASE_LINE_AFTER_TRANSFER, HOLD_LINE_BETWEEN_WORDS);</pre>

---

## **spi\_master\_receive\_only()**

**spi\_master\_receive\_only (VVCT, vvc\_instance\_idx, data, msg, [see options below])**

**Options:** num\_words, action\_when\_transfer\_is\_done, action\_between\_words

The spi\_master\_receive\_only() VVC procedure adds a receive command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the receive command is scheduled to run, the executor calls the SPI BFM spi\_master\_receive() procedure, described in the SPI BFM QuickRef. The received data from DUT will not be returned in this procedure call since it is non-blocking for the sequencer/caller, but the received data will be stored in the VVC for a potential future fetch (see example with fetch\_result below). When receiving multiple words, each word must be fetched separately with the same command index. The SPI BFM spi\_master\_transmit() procedure will transmit dummy data (0x0) while receiving data from the slave DUT.

There is one requirement for running the spi\_master\_receive\_only() procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to TRUE.

Note: The data returned from fetch\_result is of type t\_vvc\_result. It is a SLV with length C\_VVC\_CMD\_DATA\_MAX\_LENGTH. The received data is located at indices (GC\_DATA\_WIDTH-1 downto 0).

Examples:

```
spi_master_receive_only (SPI_VVCT, 1, "Receiving from Peripheral 1");
spi_master_receive_only (SPI_VVCT, 1, "Receiving from Peripheral 1", 6, RELEASE_LINE_AFTER_TRANSFER, RELEASE_LINE_BETWEEN_WORDS);
```

Example with fetch\_result() call: - result is placed in **v\_data**

```
variable v_cmd_idx      : natural;          -- Command index for the last read
variable v_data          : t_vvc_result;    -- Result from read
(...)
spi_master_receive_only(SPI_VVCT, 1, "Receiving from Peripheral 1");
v_cmd_idx := shared_cmd_idx;
await_completion(SPI_VVCT,1, v_cmd_idx, 1 us, "Wait for receive to finish");
fetch_result(SPI_VVCT,1, v_cmd_idx, v_data, "Fetching result from receive operation");
```

---

## **spi\_master\_transmit\_and\_check()**

**spi\_master\_transmit\_and\_check (VVCT, vvc\_instance\_idx, data, data\_exp, msg, [see options below])**

**Options:** alert\_level, action\_when\_transfer\_is\_done, action\_between\_words

The spi\_master\_transmit\_and\_check() VVC procedure adds a transmit and a check command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the transmit and the check command is scheduled to run, the executor calls the SPI BFM spi\_master\_transmit\_and\_check() procedure, described in the SPI BFM QuickRef. Note that action\_between\_words only apply to t\_slv\_array multi-word transfers and the default value of alert\_level is ERROR.

There is one requirement for running the spi\_master\_transmit\_and\_check() procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to TRUE.

Examples:

```
spi_master_transmit_and_check (SPI_VVCT, 1, x"0D", x"5F", "Transmitting carriage return to Peripheral 1 and expecting data from Peripheral 1");
spi_master_transmit_and_check (SPI_VVCT, 1, C_CR_BYTE, x"5F", "Transmitting carriage return to Peripheral 1 and expecting data from Peripheral 1", ERROR, RELEASE_LINE_AFTER_TRANSFER, HOLD_LINE_BETWEEN_WORDS);
```

---

---

## **spi\_master\_check\_only()**

**spi\_master\_check\_only (VVCT, vvc\_instance\_idx, data, msg, [see options below])**

**Options:** alert\_level, action\_when\_transfer\_is\_done, action\_between\_words

The spi\_master\_check\_only() VVC procedure adds a check command to the SPI VVC executor queue, which will run as soon as all preceding commands have completed. When the check command is scheduled to run, the executor calls the SPI BFM spi\_master\_check() procedure, described in the SPI BFM QuickRef. The received data will not be stored by this procedure and the SPI BFM spi\_master\_check() procedure will transmit dummy data (0x0) while receiving data from the slave DUT.

Note that action\_between\_words only apply to t\_slv\_array multi-word transfers and the default value of alert\_level is ERROR.

There is one requirement for running the spi\_master\_check\_only() procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to TRUE.

Examples:

```
spi_master_check_only (SPI_VVCT, 1, x"0D", "Expecting carriage return from Peripheral 1");
spi_master_check_only (SPI_VVCT, 1, C_CR_BYTE, "Expecting carriage return from Peripheral 1", ERROR,
RELEASE_LINE_AFTER_TRANSFER, HOLD_LINE_BETWEEN_WORDS);
```

---

## **spi\_slave\_transmit\_and\_receive()**

**spi\_slave\_transmit\_and\_receive (VVCT, vvc\_instance\_idx, data, msg, [see options below])**

**Options:** when\_to\_start\_transfer

The spi\_slave\_transmit\_and\_receive() VVC procedure adds a transmit and receive command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the transmit and receive command is scheduled to run, the executor calls the SPI BFM spi\_slave\_transmit\_and\_receive () procedure, described in the SPI BFM QuickRef.

There is one requirement for running the spi\_slave\_transmit\_and\_receive () procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to FALSE.

Examples:

```
spi_slave_transmit_and_receive (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1 and receiving data from
Peripheral 1");
spi_slave_transmit_and_receive (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1 and receiving data from
Peripheral 1", START_TRANSFER_ON_NEXT_SS);
```

---

## **spi\_slave\_transmit\_only()**

**spi\_slave\_transmit\_only (VVCT, vvc\_instance\_idx, data, msg, [see options below])**

**Options:** when\_to\_start\_transfer

The spi\_slave\_transmit\_only() VVC procedure adds a transmit command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the transmit command is scheduled to run, the executor calls the SPI BFM spi\_slave\_transmit () procedure, described in the SPI BFM QuickRef. The SPI BFM spi\_slave\_transmit() procedure will ignore the data received from the master DUT.

There is one requirement for running the spi\_slave\_transmit () procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to FALSE.

Examples:

```
spi_slave_transmit_only (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1");
spi_slave_transmit_only (SPI_VVCT, 1, x"0D", "Transmitting carriage return to Peripheral 1", START_TRANSFER_ON_NEXT_SS);
```

## **spi\_slave\_receive\_only()**

**spi\_slave\_receive\_only (VVCT, vvc\_instance\_idx, msg, [see options below])**

**Options:** num\_words, when\_to\_start\_transfer

The spi\_slave\_receive\_only() VVC procedure adds a receive command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the receive command is scheduled to run, the executor calls the SPI BFM spi\_slave\_receive () procedure, described in the SPI BFM QuickRef.

The received data will not be returned in this procedure call since it is non-blocking for the sequencer/caller, but the received data will be stored in the VVC for a potential future fetch (see example with *fetch\_result* below). When receiving multiple words, each word must be fetched separately with the same command index. The SPI BFM spi\_slave\_receive() procedure will transmit dummy data (0x0) while receiving data from the master DUT.

There is one requirement for running the spi\_slave\_receive\_only() procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to FALSE.

Note: The data returned from fetch\_result is of type t\_vvc\_result. It is a SLV with length C\_VVC\_CMD\_DATA\_MAX\_LENGTH. The received data is located at indices (GC\_DATA\_WIDTH-1 downto 0).

Example:

```
spl_slave_receive_only (SPI_VVCT, 1, "Receiving from Peripheral 1");
spl_slave_receive_only (SPI_VVCT, 1, "Receiving from Peripheral 1", 6, START_TRANSFER_IMMEDIATE);
```

Examples with fetch\_result() call: - result is placed in **v\_data**

```
variable v_cmd_idx      : natural;      -- Command index for the last read
variable v_data         : t_vvc_result; -- Result from read
(...)
spl_slave_receive_only(SPI_VVCT, 1, "Receiving from Peripheral 1");
v_cmd_idx := shared_cmd_idx;
await_completion(SPI_VVCT,1, v_cmd_idx, 1 us, "Wait for receive to finish");
fetch_result(SPI_VVCT,1, v_cmd_idx, v_data, "Fetching result from receive operation");
```

## **spl\_slave\_transmit\_and\_check()**

**spl\_slave\_transmit\_and\_check (VVCT, vvc\_instance\_idx, data, data\_exp, msg, [see options below])**

**Options:** alert\_level, when\_to\_start\_transfer

The spl\_slave\_transmit\_and\_check() VVC procedure adds a transmit and a check command to the SPI VVC executor queue, that will run as soon as all preceding commands have completed. When the transmit and the check command is scheduled to run, the executor calls the SPI BFM spl\_slave\_transmit\_and\_check() procedure, described in the SPI BFM QuickRef. Note that the default value of alert\_level is ERROR.

There is one requirement for running the spl\_slave\_transmit\_and\_check() procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to FALSE.

Example:

```
spl_slave_transmit_and_check (SPI_VVCT, 1, x"0D", x"5F", "Transmitting carriage return to Peripheral 1 and expecting data from
Peripheral 1");
```



## spi\_slave\_check\_only()

**spi\_slave\_check\_only** (VVCT, vvc\_instance\_idx, data, msg, [see options below])

**Options:** alert\_level, when\_to\_start\_transfer

The spi\_slave\_check\_only() VVC procedure adds a check command to the SPI VVC executor queue, which will run as soon as all preceding commands have completed. When the check command is scheduled to run, the executor calls the SPI BFM spi\_slave\_check() procedure, described in the SPI BFM QuickRef. The received data will not be stored by this procedure and the SPI BFM spi\_slave\_check() procedure will transmit dummy data (0x0) while receiving data from the master DUT.

There is one requirement for running the spi\_slave\_check\_only() procedure:

- The VVC entity with instance index corresponding to the 'vvc\_instance\_idx' parameter must have the generic constant GC\_MASTER\_MODE set to FALSE.

Examples.

```
spi_slave_check_only(SPI_VVCT, 1, x"0D", "Expecting carriage return from Peripheral 1");
spi_slave_check_only(SPI_VVCT, 1, C_CR_BYTE, "Expecting carriage return from Peripheral 1", ERROR, START_TRANSFER_ON_NEXT_SS);
```

## 2 VVC Configuration

Record element	Type	C_SPI_VVC_CONFIG_DEFAULT	Description
inter_bfm_delay	t_inter_bfm_delay	C_SPI_INTER_BFM_DELAY_DEFAULT	Delay between any requested BFM accesses towards the DUT. - TIME_START2START: Time from a BFM start to the next BFM start (A TB_WARNING will be issued if access takes longer than TIME_START2START). - TIME_FINISH2START: Time from a BFM end to the next BFM start. Any insert_delay() command will add to the above minimum delays, giving for instance the ability to skew the BFM starting time.
cmd_queue_count_max	natural	C_MAX_COMMAND_QUEUE	Maximum pending number in command queue before queue is full. Adding additional commands will result in an ERROR.
cmd_queue_count_threshold	natural	C_CMD_QUEUE_COUNT_THRESHOLD	An alert with severity "cmd_queue_count_threshold_severity" will be issued if command queue exceeds this count. Used for early warning if command queue is almost full. Will be ignored if set to 0.
cmd_queue_count_threshold_severity	t_alert_level	C_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY	Severity of alert to be triggered if command count exceeding cmd_queue_count_threshold
result_queue_count_max	natural	C_RESULT_QUEUE_COUNT_MAX	Maximum number of unfetched results before result_queue is full.
result_queue_count_threshold	natural	C_RESULT_QUEUE_COUNT_THRESHOLD	An alert with severity 'result_queue_count_threshold_severity' will be issued if result queue exceeds this count. Used for early warning if result queue is almost full. Will be ignored if set to 0.
result_queue_count_threshold_severity	t_alert_level	C_RESULT_QUEUE_COUNT_THRESHOLD_SEVERITY	Severity of alert to be initiated if exceeding result_queue_count_threshold
bfm_config	t_spi_bfm_config	C_SPI_BFM_CONFIG_DEFAULT	Configuration for SPI BFM. See QuickRef for SPI BFM
msg_id_panel	t_msg_id_panel	C_VVC_MSG_ID_PANEL_DEFAULT	VVC dedicated message ID panel

The configuration record can be accessed from the Central Testbench Sequencer through the shared variable array, e.g.:

```
shared_spi_vvc_config(C_VVC_IDX_MASTER_1).inter_bfm_delay.delay_in_time := 10 ms;
shared_spi_vvc_config(C_VVC_IDX_SLAVE_1).bfm_config.CPOL := '1';
```

### 3 VVC Status

The current status of the VVC can be retrieved during simulation. This is done by reading from the shared variable `shared_spi_vvc_status` record from the test sequencer. The record contains status for both channels, specified with the channel axis of the `shared_spi_vvc_status` array. The record contents can be seen below:

Record element	Type	Description
<code>current_cmd_idx</code>	natural	Command index currently running
<code>previous_cmd_idx</code>	natural	Previous command index to run
<code>pending_cmd_cnt</code>	natural	Pending number of commands in the command queue

### 4 Additional Documentation

Additional documentation about UVVM and its features can be found under `"/uvvm_vvc_framework/doc/".`

For additional documentation on the SPI protocol, please see the SPI specification, e.g. "ST TN0897 Technical note ST SPI protocol. ID 023176 Rev 2".

### 5 Compilation

The SPI VVC must be compiled with VHDL 2008.

It is dependent on the following libraries

- **UVVM Utility Library (UVVM-Util), version 2.2.0 and up**
- **UVVM VVC Framework, version 2.1.0 and up**
- **SPI BFM**

Before compiling the SPI VVC, make sure that `uvvm_vvc_framework` and `uvvm_util` have been compiled.

See UVVM Essential Mechanisms located in `uvvm_vvc_framework/doc` for information about compile scripts.

**Compile order for the SPI VVC:**

Compile to library	File	Comment
<code>bitvis_vip_spi</code>	<code>spi_bfm_pkg.vhd</code>	SPI BFM
<code>bitvis_vip_spi</code>	<code>vvc_cmd_pkg.vhd</code>	SPI VVC command types and operations
<code>bitvis_vip_spi</code>	<code>../uvvm_vvc_framework/src_target_dependent/td_target_support_pkg.vhd</code>	UVVM VVC target support package, compiled into the SPI VVC library.
<code>bitvis_vip_spi</code>	<code>../uvvm_vvc_framework/src_target_dependent/td_vvc_framework_common_methods_pkg.vhd</code>	UVVM framework common methods compiled into the SPI VVC library
<code>bitvis_vip_spi</code>	<code>vvc_methods_pkg.vhd</code>	SPI VVC methods
<code>bitvis_vip_spi</code>	<code>../uvvm_vvc_framework/src_target_dependent/td_queue_pkg.vhd</code>	UVVM queue package for the VVC
<code>bitvis_vip_spi</code>	<code>../uvvm_vvc_framework/src_target_dependent/td_vvc_entity_support_pkg.vhd</code>	UVVM VVC entity methods compiled into the SPI VVC library
<code>bitvis_vip_spi</code>	<code>spi_vvc.vhd</code>	SPI VVC

## 6 Simulator compatibility and setup

This VVC has been compiled and tested with Modelsim version 10.3d and Riviera-PRO version 2015.10.85.  
For required simulator setup see *UVVM-Util* Quick reference.

### IMPORTANT

This is a simplified Verification IP (VIP) for SPI.

The given VIP complies with the basic SPI protocol and thus allows a normal access towards a SPI interface. This VIP is not a SPI protocol checker.

For a more advanced VIP please contact Bitvis AS at [support@bitvis.no](mailto:support@bitvis.no)

### INTELLECTUAL PROPERTY

Disclaimer: This IP and any part thereof are provided "as is", without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose and noninfringement.  
In no event shall the authors or copyright holders be liable for any claim, damages or other liability, whether in an action of contract, tort or otherwise, arising from, out of or in connection with this IP.