

Avalon-MM VVC – Quick Reference

avalon_mm_write (VVCT, vvc_instance_idx, addr, data, [byte_enable,] msg)

Example: avalon_mm_write(AVALON_MM_VVCT, 1, x"00006000", x"AABBF102", "Writing to Peripheral 1");

avalon_mm_read (VVCT, vvc_instance_idx, addr, msg)

Example: avalon_mm_read(AVALON_MM_VVCT, 1, x"10056000", "Reading from Peripheral 1");

avalon_mm_check (VVCT, vvc_instance_idx, addr, data, msg, [alert_level])

Example: avalon_mm_check(AVALON_MM_VVCT, 1, x"FF113000", x"0000393B", "Check data from Peripheral 1");

avalon_mm_reset (VVCT, vvc_instance_idx, num_rst_cycles, msg)

Example: avalon_mm_reset(AVALON_MM_VVCT, 1, 5, "Resetting Avalon-MM interface for 5 cycles");

avalon_mm_lock (VVCT, vvc_instance_idx, msg)

Example: avalon_mm_lock(AVALON_MM_VVCT, 1, "Locking Avalon MM Interface");

avalon_mm_unlock (VVCT, vvc_instance_idx, msg)

Example: avalon_mm_unlock(AVALON_MM_VVCT, 1, "Unlocking Avalon MM Interface");

Avalon-MM VVC Configuration record 'vvc_config'

Parameter name	Type	C_AVALON_MM_VVC_CONFIG_DEFAULT
inter_bfm_delay	t_inter_bfm_delay	C_AVALON_MM_INTER_BFM_DELAY_DEFAULT
cmd_queue_count_max	natural	C_CMD_QUEUE_COUNT_MAX
cmd_queue_count_threshold	natural	C_CMD_QUEUE_COUNT_THRESHOLD
cmd_queue_count_threshold_severity	t_alert_level	C_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY
bfm_config	t_avalon_mm_bfm_config	C_AVALON_MM_BFM_CONFIG_DEFAULT
msg_id_panel	t_msg_id_panel	C_VVC_MSG_ID_PANEL_DEFAULT

Avalon-MM VVC Status record signal 'vvc_status'

Parameter name	Type
current_cmd_idx	natural
previous_cmd_idx	natural
pending_cmd_cnt	natural

VVC



avalon_mm_vvc.vhd

Common VVC procedures applicable for this VVC

- See UVVM Methods QuickRef for details.

await_completion()

enable_log_msg()

disable_log_msg()

fetch_result()

flush_command_queue()

terminate_current_command()

terminate_all_commands()

insert_delay()



UVVM™

VVC target parameters

Name	Type	Example(s)	Description
VVCT	t_vvc_target_record	AVALON_MM_VVCT	VVC target type compiled into each VVC in order to differentiate between VVCs.
vvc_instance_idx	integer	1	Instance number of the VVC

VVC functional parameters

Name	Type	Example(s)	Description
addr	unsigned	x"0000325A"	The address of a Avalon-MM accessible register. Could be offset or full address depending on the DUT
data	std_logic_vector	x"F1A332D3"	The data to be written (in avalon_mm_write) or the expected data (in avalon_mm_check).
byte_enable	std_logic_vector	(others => '1')	This argument selects which bytes to use (all '1' means all bytes are updated)
msg	string	"Send to peripheral 1"	A custom message to be appended in the log/alert
alert_level	t_alert_level	ERROR or TB_WARNING	Set the severity for the alert that may be asserted by the method.

VVC entity signals

Name	Type	Description
clk	std_logic	VVC Clock signal
avalon_mm_vvc_master_if	t_avalon_mm_if	See Avalon-MM BFM documentation

VVC entity generic constants

Name	Type	Default	Description
GC_ADDR_WIDTH	integer	8	Width of the Avalon-MM address bus
GC_DATA_WIDTH	integer	32	Width of the Avalon-MM data bus
GC_INSTANCE_IDX	natural	1	Instance number to assign the VVC
GC_AVALON_MM_CONFIG	t_avalon_mm_bfm_config	C_AVALON_MM_BFM_CONFIG_DEFAULT	Configuration for the Avalon-MM BFM, see Avalon-MM BFM documentation.
GC_CMD_QUEUE_COUNT_MAX	natural	1000	Absolute maximum number of commands in the VVC command queue
GC_CMD_QUEUE_COUNT_THRESHOLD	natural	950	An alert will be generated when reaching this threshold to indicate that the command queue is almost full. The queue will still accept new commands until it reaches C_CMD_QUEUE_COUNT_MAX.
GC_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY	t_alert_level	WARNING	Alert severity which will be used when command queue reaches GC_CMD_QUEUE_COUNT_THRESHOLD.

VVC details

All VVC procedures are defined in `vvm_methods_pkg` (dedicated this VVC), and `uvvm_vvc_framework.uvvm_methods_pkg` and `uvvm_vvc_framework.uvvm_support_pkg` (common VVC procedures)

1 VVC procedure details and examples

Procedure	Description
avalon_mm_write()	<p>The <code>avalon_mm_write()</code> VVC procedure adds a write command to the Avalon-MM VVC executor queue, which will run as soon as all preceding commands have completed. When the write command is scheduled to run, the executor calls the Avalon-MM BFM <code>avalon_mm_write()</code> procedure, described in the Avalon-MM BFM QuickRef. <code>avalon_mm_write</code> can be called with or without <code>byte_enable</code> constant. When not set, <code>byte_enable</code> is interpreted as all '1', indicating that all bytes are valid.</p> <p>avalon_mm_write(VVCT, vvc_instance_idx, addr, data, [byte_enable,] msg)</p> <p>e.g.:</p> <ul style="list-style-type: none"> - <code>avalon_mm_write(AVALON_MM_VVCT, 1, x"11221100", x"0000F102", "Writing to Peripheral 1");</code> - <code>avalon_mm_write(AVALON_MM_VVCT, 1, C_ADDR_DMA, x"F102", "1111", "Writing to DMA");</code>
avalon_mm_read()	<p>The <code>avalon_mm_read()</code> VVC procedure adds a read command to the Avalon-MM VVC executor queue, which will run as soon as all preceding commands have completed. When the read command is scheduled to run, the executor calls the Avalon-MM BFM <code>avalon_mm_read()</code> procedure, described in the Avalon-MM BFM QuickRef. The read value will not be returned in this procedure call since it is non-blocking for the sequencer/caller, but the read data will be stored in the VVC for a potential future fetch (see example below). The data will be available until overwritten by new read-data depending on the read-data buffer size.</p> <p><i>For Avalon-MM Full Access using read pipeline:</i></p> <p>If <code>vvm_config.use_read_pipeline</code> has been set to true, the VVC will perform the read transaction using the BFM procedures <code>avalon_mm_read_request</code> and <code>avalon_mm_read_response</code>. First, the VVC executor will check if the number of pending commands in the pipeline will exceed the number of pipeline stages. If this is the case, the VVC executor will stall the read transaction until a command in the pipeline has been executed. The command executor will then let the BFM start the read request. After the read request has completed, the command will be added to the command response queue, which will run the BFM procedure <code>avalon_mm_read_response</code>.</p> <p>avalon_mm_read(VVCT, vvc_instance_idx, addr, msg)</p> <p><u>Example with <code>fetch_result()</code> call (Result is placed in <code>v_data</code>)</u></p> <pre>variable v_cmd_idx : natural; variable v_data : std_logic_vector(31 downto 0); variable v_is_ok : boolean; variable v_is_new : boolean; (...) avalon_mm_read(AVALON_MM_VVCT, 1, x"112252AA", "Read from Peripheral 1"); v_cmd_idx := shared_cmd_idx; -- Store the command index (integer) for the last read await_completion(AVALON_MM_VVCT, 1, v_cmd_idx, 100 ns, "Wait for read to finish"); fetch_result(AVALON_MM_VVCT, 1, v_cmd_idx, v_data, v_is_ok, v_is_new, "Fetching result from read operation"); check_value(v_is_ok, ERROR, "Readback OK via fetch_result()");</pre>

avalon_mm_check()

The `avalon_mm_check()` VVC procedure adds a check command to the Avalon-MM VVC executor queue, which will run as soon as all preceding commands have completed. When the check command is scheduled to run, the executor calls the Avalon-MM BFM `avalon_mm_check()` procedure, described in the Avalon-MM BFM QuickRef. The `avalon_mm_check()` procedure will perform a read operation, then check if the read data is equal to the 'data' parameter. If the read data is not equal to the expected 'data' parameter, an alert with severity 'alert_level' will be issued. The read data will not be stored by this procedure.

For Avalon-MM Full Access using read pipeline:

If `vvc_config.use_read_pipeline` has been set to true, the VVC will perform the check transaction using the BFM procedures `avalon_mm_read_request` and `avalon_mm_check_response`, similar to the procedure described in `avalon_mm_read`.

avalon_mm_check(VVCT, vvc_instance_idx, addr, data, msg, [alert_level])

e.g.

- `avalon_mm_check(AVALON_MM_VVCT, 1, x"11A49800", x"0000393B", "Check data from Peripheral 1", ERROR);`

The procedure can also be called without using the optional parameters, e.g.:

- `avalon_mm_check(AVALON_MM_VVCT, 1, C_ADDR_IO, x"393B", "Check data from IO device");`

avalon_mm_reset()

The `avalon_mm_reset()` VVC procedure adds a reset command to the Avalon-MM VVC executor queue, which will run as soon as all preceding commands have completed. When the reset command is scheduled to run, the executor calls the Avalon-MM BFM `avalon_mm_reset()` procedure, described in the Avalon-MM BFM QuickRef.

avalon_mm_reset(VVCT, vvc_instance_idx, num_rst_cycles, msg)

e.g.

- `avalon_mm_reset(AVALON_MM_VVCT, 1, 5, "Resetting Avalon MM Interface");`

avalon_mm_lock()

The `avalon_mm_lock()` VVC procedure adds a lock command to the Avalon-MM VVC executor queue, which will run as soon as all preceding commands have completed. When the lock command is scheduled to run, the executor calls the Avalon-MM BFM `avalon_mm_lock()` procedure, described in the Avalon-MM BFM QuickRef.

avalon_mm_lock(VVCT, vvc_instance_idx, msg)

e.g.

`avalon_mm_lock(AVALON_MM_VVCT, 1, "Locking Avalon MM Interface");`

avalon_mm_unlock()

The `avalon_mm_unlock()` VVC procedure adds an unlock command to the Avalon-MM VVC executor queue, which will run as soon as all preceding commands have completed. When the lock command is scheduled to run, the executor calls the Avalon-MM BFM `avalon_mm_unlock()` procedure, described in the Avalon-MM BFM QuickRef.

avalon_mm_unlock(VVCT, vvc_instance_idx, msg)

e.g.

`avalon_mm_unlock(AVALON_MM_VVCT, 1, "Locking Avalon MM Interface");`

2 VVC Configuration

Name	Type	C_AVALON_MM_BFM_CONFIG_DEFAULT	Description
<code>inter_bfm_delay</code>	<code>t_inter_bfm_delay</code>	<code>C_AVALON_MM_INTER_BFM_DELAY_DEFAULT</code>	Minimum delay between BFM accesses from the VVC. If parameter <code>delay_type</code> is set to <code>NO_DELAY</code> , BFM accesses will be back to back, i.e. no delay.

cmd_queue_count_max	natural	C_MAX_COMMAND_QUEUE	Maximum pending number in command queue before queue is full. Adding additional commands will result in an ERROR.
cmd_queue_count_threshold	natural	C_CMD_QUEUE_COUNT_THRESHOLD	An alert with severity "cmd_queue_count_threshold_severity" will be issued if command queue exceeds this count. Used for early warning if command queue is almost full. Will be ignored if set to 0.
cmd_queue_count_threshold_severity	t_alert_level	C_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY	Severity of alert to be initiated if exceeding cmd_queue_count_threshold
bfm_config	t_avalon_mm_bfm_config	C_AVALON_MM_BFM_CONFIG_DEFAULT	Configuration for Avalon-MM BFM. See quick reference for Avalon-MM BFM
msg_id_panel	t_msg_id_panel	C_VVC_MSG_ID_PANEL_DEFAULT	VVC dedicated message ID panel

The configuration record can be accessed from the Central Testbench Sequencer through the shared variable array, e.g.:

```
shared_avalon_mm_vvc_config(1).inter_bfm_delay.delay_in_time := 50 ns;
shared_avalon_mm_vvc_config(1).bfm_config.use_waitrequest    := true;
```

3 VVC Status

The current status of the VVC can be retrieved during simulation. This is achieved by reading from the shared variable shared_avalon_mm_vvc_status record from the test sequencer. The record contents can be seen below:

Name	Type	Description
current_cmd_idx	natural	Command index currently running
previous_cmd_idx	natural	Previous command index to run
pending_cmd_cnt	natural	Pending number of commands in the command queue

4 VVC Interface

In this VVC, the interface has been encapsulated in a signal record of type *t_avalon_mm_if* in order to improve readability of the code. Since the Avalon-MM interface busses can be of arbitrary size, the interface std_logic_vectors have been left unconstrained. These unconstrained SLVs needs to be constrained when the interface signals are instantiated. For this interface, this could look like:

```
signal avalon_mm_if_1 : t_avalon_mm_if( address(C_ADDR_WIDTH-1 downto 0),
                                         byte_enable((C_DATA_WIDTH/8)-1 downto 0),
                                         writedata(C_DATA_WIDTH-1 downto 0),
                                         readdata(C_DATA_WIDTH-1 downto 0) );
```

5 Additional Documentation

Additional documentation about UVVM and its features can be found under "uvvm_vvc_framework/doc".

For additional documentation on the Avalon-MM standard, please see the Avalon specification "Avalon Interface Specifications, MNL-AVABUSREF", available from Altera.

6 Compilation

Avalon-MM VVC must be compiled with VHDL 2008.

It is dependent on the following libraries

- **UVVM Utility Library (UVVM-Util), version 1.0.0 and up**
- **UVVM VVC Framework, version 1.0.0 and up**
- **Avalon-MM BFM**

Before compiling the Avalon-MM VVC, assure that uvvm_vvc_framework and uvvm_util have been compiled.

Compile order for the Avalon-MM VVC:

Compile to library	File	Comment
bitvis_vip_avalon_mm	avalon_mm_bfm_pkg.vhd	Avalon-MM BFM
bitvis_vip_avalon_mm	vvc_cmd_pkg.vhd	Avalon-MM VVC command types and operations
bitvis_vip_avalon_mm	../uvvm_vvc_framework/src_target_dependent/td_target_support_pkg.vhd	UVVM VVC target support package, compiled into the Avalon-MM VVC library.
bitvis_vip_avalon_mm	../uvvm_vvc_framework/src_target_dependent/td_vvc_framework_common_methods_pkg.vhd	UVVM VVC framework common methods compiled into the Avalon-MM VVC library
bitvis_vip_avalon_mm	vvc_methods_pkg.vhd	Avalon-MM VVC methods
bitvis_vip_avalon_mm	../uvvm_vvc_framework/src_target_dependent/td_queue_pkg.vhd	UVVM queue package for the VVC
bitvis_vip_avalon_mm	../uvvm_vvc_framework/src_target_dependent/td_vvc_entity_support_pkg.vhd	UVVM VVC entity support compiled into the Avalon-MM VVC library
bitvis_vip_avalon_mm	avalon_mm_vvc.vhd	Avalon-MM VVC

7 Simulator compatibility and setup

This VVC has been compiled and tested with Modelsim version 10.4b and Riviera-PRO version 2015.10.85.

For required simulator setup see **UVVM-Util** Quick reference.

IMPORTANT

This is a simplified Verification IP (VIP) for Avalon-MM. The given VIP complies with the basic Avalon-MM protocol and thus allows a normal access towards an Avalon-MM interface. This VIP is not an Avalon-MM protocol checker. For a more advanced VIP please contact Bitvis AS at support@bitvis.no

INTELLECTUAL PROPERTY

Disclaimer: This IP and any part thereof are provided "as is", without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose and noninfringement. In no event shall the authors or copyright holders be liable for any claim, damages or other liability, whether in an action of contract, tort or otherwise, arising from, out of or in connection with this IP.