

ADPRES V.1.1

USER MANUAL

1. Introduction

Abu Dhabi Polytechnic Reactor Simulator (ADPRES) solves static diffusion equation in two or three dimensional rectangular geometry. ADPRES uses 4-th order Nodal Expansion Method (NEM) where the transverse leakage moments are approximated using quadratic leakage fit to solve the diffusion equation. ADPRES can solve either forward or adjoint problems as well as fixed source problems. Among the feature of ADPRES is it can handle problem with Assembly Discontinuity Factor (ADF). Currently ADPRES is under extensive development to make it enable solving transient reactor problems.

2. Theory

Users who are interested in the theoretical background of NEM used in ADPRES can refer to MOSRA Manual [1].

3. Program Compilation and Execution

In UNIX environment such as GNU-LINUX or CYGWIN where the gfortran is already installed, the source codes can be compiled using command

```
gfortran mod_data.f90 mod_InpOutput.f90 mod_nodal.f90 ADPRES.f90 -O4 -o adpres
```

This command will produce executable file called “adpres”. This executable file can be run by

```
./adpres
```

Then the program will ask input file name. Type the input file name, then the program runs and produce output file. The output file name will be similar to input file name but with “out” extension.

4. Input Description

The input is designed to be problem-descriptive for the convenient of users. The input is grouped into several cards which depend on the nature of the problems.

4.1 General Rules

Some general rules for the ADPRES inputs:

1. Comments are marked by !. Example:

```
! COMPOSITION 1
0.20574  0.00654  0.00415  0.00415  1.0  0.0  0.01462  !Group 1
0.68866  0.04850  0.06099  0.06099  0.0  0.0  0.00000  !Group 2
```

2. Currently ADPRES has ten input cards. Cards' name shall be uppercase and marked by %.
Example:

```

%MODE
FORWARD
%XSEC
2 4      ! Number of groups and number of materials
...
...
%GEOM
12 12 2  !nx, ny, nz
...
...

```

3. Numbers can be repeated using * mark. For example

10.0 8*20.0 is equivalent to 10.0 20.0 20.0 20.0 20.0 20.0 20.0 20.0 20.0

4.2 Cards Description

ADPRES has 10 input cards. Each card can be placed arbitrarily in the input deck. Some cards are obligatory for any problems, while some cards are conditionally-mandatory depend on the problem being solved and some cards are optional. The description of input for each card is explained in this subsection. The ten input cards as well as their description are listed in Table 4-1.

Table 4-1. Input Card Description

| No. | Cards | Description | Remark |
|-----|-------|-------------------------------|-------------------------|
| 1. | %MODE | Calculation mode | Mandatory |
| 2. | %XSEC | Cross Sections | Mandatory |
| 3. | %GEOM | Geometry of the problem | Mandatory |
| 4. | %CASE | Problem case | Optional |
| 5. | %ESRC | Extra source | Conditionally-mandatory |
| 6. | %WRST | Write restart file | Optional |
| 7. | %RRST | Read restart file | Optional |
| 8. | %ITER | Iteration Control | Optional |
| 9. | %PRNT | Output print control | Optional |
| 10. | %ADF | Assembly Discontinuity Factor | Optional |

The input for each card is described in the followings subsections

4.2.1 Calculation Mode

This card tells ADPRES the calculation mode. The calculation mode can be either forward, adjoint or fixed source.

Table 4-2. Calculation mode card

| |
|-------|
| %MODE |
|-------|

| | | | |
|--------|------|------------------|---|
| LINE 1 | MODE | Calculation mode | FORWARD : Forward Calculation ADJOINT : Adjoint Calculation FIXEDSRC : Fixed Source Calculation |
|--------|------|------------------|---|

4.2.2 Cross Section Data

This card describes to ADPRES the few-group cross section data as well as number of group and materials used in the problem.

Table 4-3. Cross section data card

| %XSEC | | | |
|--------|--------------|--|---|
| LINE 1 | NG | Number of groups | 2 4 ! Number of groups and number of materials |
| | NMAT | Number materials | |
| LINE 2 | SIGTR(g) | Transport macroscopic XS for group g | Repeat LINE 2 NG times. And again repeat this input segment NMAT times. (See example in the provided sample inputs) |
| | SIGA(g) | Absorption macroscopic XS for group g | |
| | NUF(g) | Nu * Fission macroscopic XS for group g | |
| | SIGF(g) | Fission macroscopic XS for group g | |
| | CHI(g) | Fission neutron spectrum for group g | |
| | SIGS(g,1:NG) | Scattering macroscopic XS from group g to other groups | |

4.2.3 Geometry

Geometry of the reactor core is described in this card. The coordinate system used in ADPRES is shown in Figure 4-1. The point of origin is located between west, bottom and south sides. Figure 4-2 shows the coordinate system seen from top which typically used for two-dimensional problems.




Figure 4-1. Coordinate system used in ADPRES




Figure 4-2. Coordinate system seen from top (typically used for two-dimensional problems)

Table 4-4. Geometry card

| %GEOM | | | |
|--------|-------------|--|---|
| LINE 1 | NX | Number of assemblies along X-direction | Example: 9 9 19 !NX,NY,NZ |
| | NY | Number of assemblies along Y-direction | |
| | NZ | Number of assemblies along Z-direction | |
| LINE 2 | XSIZE(1:NX) | Assembly size along X-direction (from west to east) | Example: 10.0 8*20.0 !X-direction assembly size |
| LINE 3 | XDIV(1:NX) | Assembly division along X-direction (from west to east) | Example: 1 8*2 !Last 8 assemblies divided into 2 along Y-direction |
| LINE 4 | YSIZE(1:NY) | Assembly size along Y-direction (from south to north) | Example: 10.0 8*20.0 !Y-direction assembly size |
| LINE 5 | YDIV(1:NY) | Assembly division along Y-direction (from south to north) | Example: 1 8*2 !Last 8 assemblies divided into 2 along Y-direction |
| LINE 6 | ZSIZE(1:NZ) | Assembly size along Z-direction (from bottom to top) | Example: 19*20.0 !Uniform assembly size along Z-direction |
| LINE 7 | ZDIV(1:NZ) | Assembly division along Z-direction (from bottom to top) | Example: 19*1 !Assembly along Z-direction is not divided |

| | | | |
|---------|---|---|---|
| LINE 8 | NP | Number of different core planar with different material composition | Example: 4 !There are four different planar |
| LINE 9 | ZPLN(1:NZ) | Planar assignment along Z-direction from bottom to top | Example: 1 13*2 4*3 4 !planar assignment (from bottom to top) |
| LINE 10 | DO j = NY, 1, -1 ASM(1:NX) END DO | Planar material map | Repeat this LINE NP times in order, from planar number 1 to NP. (See example in the provided sample inputs) |
| LINE 11 | XEAST | East boundary conditions | 0 = Zero flux 1 = Zero incoming current 2 = Reflective Example: 0 2 0 2 2 2 !BC |
| | XWEST | West boundary conditions | |
| | YNORTH | North boundary conditions | |
| | YSOUTH | South boundary conditions | |
| | ZBOTT | Bottom boundary conditions | |
| | ZTOP | Top boundary conditions | |

4.2.4 Problem Case

This card describes the problem case if necessary.

Table 4-5. Problem case card

| | | | |
|--------|----------|------------------|------------------------------|
| %CASE | | | |
| LINE 1 | CASE_ID | Case name | Example: DVP |
| LINE 2 | CASE_EXP | Case Description | Example: DVP Problem Test |

4.2.5 Extra Source

This card shall be present only if the calculation mode is fixed source.

Table 4-6. Extra source card

| | | | |
|--------|------|-------------------|---|
| %ESRC | | | |
| LINE 1 | NSRC | Number of sources | Example: 2 ! Number of extra sources |
| LINE 2 | SDEN | Source density | Repeat LINE 2 through LINE 7 NSRC times |

| | | | |
|--------|------------|---|---|
| LINE 3 | SPEC(1:NG) | Source energy spectrum (normalized to 1.0) | Example LINE 2 through LINE 3: Example: 1.0 !Source density 1 1.0 0.0 ! Spectrum 1 2.0 !Source density 2 0.9 0.1 ! Spectrum 2 |
| LINE 4 | ZPOS | Axial position of the source (between 1 to NZ) | This line must be followed by XPOS and YPOS. And then this input segment can be repeated as many as desired until 0 (LINE 7) is entered |
| LINE 5 | XPOS | Radial position of the source (along X axis) for current axial position | Repeat this line as many as desired until 0 (LINE 6) is entered |
| | YPOS | Radial position of the source (along Y axis) for current axial position | |
| LINE 6 | 0 | Zero numbers are entered to end XPOS and YPOS | |
| | 0 | | |
| LINE 7 | 0 | Zero number to end ZPOS | Example for LINE 4 through LINE 7 together: 10 !zpos of source 2 9 !xpos-ypos of source 2 8 !xpos-ypos of source 0 0 !x-y position ends 11 !zpos of the source 2 9 !xpos-ypos of source 2 8 !xpos-ypos of source 0 0 !x-y position ends 0 !z-position ends |

4.2.6 Writing Restart File

It is often useful to write restart file, which stores flux, flux moments and other parameters, to solve large problem repetitively with minor changes in the cross section data.

Table 4-7. Restart file card (writing)

| |
|-------|
| %WRST |
|-------|

| | | | |
|--------|-------|---|------------------------|
| LINE 1 | FNAME | Restart file name (max. 20 characters) to be produced | Example: IAEA3D.res |
|--------|-------|---|------------------------|

4.2.7 Reading Restart File

In order to read the restart file this card must be present. Note that the problem being solved shall have identical geometry as the restart file.

Table 4-8. Restart file card (reading)

| | | | |
|--------|-------|---|------------------------|
| %RRST | | | |
| LINE 1 | FNAME | Restart file name (max. 20 characters) to be read | Example: IAEA3D.res |

4.2.8 Iteration Control

If the user wishes, he or she can alter the iteration parameters.

Table 4-9. Iteration control card

| | | | |
|--------|------|---------------------------------------|--|
| %ITER | | | |
| LINE 1 | NOUT | Maximum number of outer iteration | Default: 300 |
| | NIN | Maximum number of inner iteration | Default: 2 |
| | SERC | Fission source error criteria | Default: 1.0e-5 |
| | FERC | Flux error criteria | Default: 1.0e-5 |
| | IERC | Inner iteration error criteria | Default: 1.0e-5 |
| | NAC | Fission source extrapolation interval | Default: 5 |
| | | | Example: 500 5 1.0e-6 1.0e- 6 1.0e-6 3 !Iteration control |

4.2.9 Print Option

This card can be used to choose the specific output that the users want.

Table 4-10. Output print option card

| | | | |
|--------|--------|---|--|
| %PRNT | | | |
| LINE 1 | CAPRAD | Radial assembly power distribution print option | 1 = YES 0 = NO Default for all = YES Example: 1 1 0 !Print output |
| | CAPAXI | Axial assembly power distribution print option | |
| | CAFRAD | Radial Flux Power Distribution | |

4.2.10 Assembly Discontinuity Factor

ADF can be incorporated into ADPRES input, if any, to make the solution more accurate.

Table 4-11. Assembly Discontinuity Factor card

| %ADF | | | |
|--------|-------|---|--|
| LINE 1 | DC(1) | East side discontinuity factor | Repeat LINE 2 NG times. And again repeat this input segment NMAT times. (See example in the provided sample inputs) |
| | DC(2) | West side discontinuity factor | |
| | DC(3) | North side discontinuity factor | |
| | DC(4) | South side discontinuity factor | |
| | DC(5) | Bottom side discontinuity factor | |
| | DC(6) | Top side discontinuity factor | |
| LINE 2 | ROT | Direction for ADF rotation | This line is optional. Necessary if the value of discontinuity factor is not fully symmetric. Repeat this line followed by LINE 3 as many as desired until zero number (LINE 5) is entered. 1 = 90 degree counter clockwise 2 = 180 degree counter clockwise 3 = 270 degree counter clockwise |
| LINE 3 | X1 | Start assembly position in X-direction | This line follows LINE 2 which tells the position of assembly being rotated. Repeat this line as many as desired until zero numbers (LINE 4). Followings are value limits for these line 1 <= X1 <= NX; 1 <= X2 <= NX; 1 <= Y1 <= NY; 1 <= Y2 <= NY; 1 <= Z1 <= NZ; 1 <= Z2 <= NZ; X1 <= X2; Y1 <= Y2; Z1 <= Z2 |
| | X2 | End assembly position in X-direction | |
| | Y1 | Start assembly position in Y-direction | |
| | Y2 | End assembly position in Y-direction | |
| | Z1 | Start assembly position in Z-direction | |
| | Z2 | End assembly position in Z-direction | |
| LINE 4 | 0 | Zero numbers entered to end X1 through Z2 | Example LINE 2 through LINE 6: 1 ! 90 degree counter clock-wise 2 2 1 1 1 2 2 2 3 3 1 2 0 0 0 0 0 0 2 ! 180 degree |
| | 0 | | |
| | 0 | | |
| | 0 | | |
| | 0 | | |
| | 0 | | |
| LINE 5 | 0 | Zero number to end ROT | |

| | | | |
|--------|----|------------------|--|
| | | | counter clock-wise 2 2 2 2 1 2 2 2 4 4 1 2 0 0 0 0 0 0 3 ! 270 degree counter clock-wise 1 1 2 2 1 2 1 1 4 4 1 2 0 0 0 0 0 0 0 ! ADF INPUTS END ! ADF PRINT(OPTIONAL) 1 |
| LINE 6 | ZP | ADF print option | This line is optional. |

5. References

1. Okumura K (1998) MOSRA-light: high speed three-dimensional nodal diffusion code for vector computers, JAERI-Data/Code 98-025. Japan Atomic Energy Research Institute, Tokaimura (in Japanese)