

# Yocto with LSDK Components User Guide



## Table of Contents

Introduction .....	3
Supported Boards .....	3
Download Yocto Layer.....	4
• Get the Yocto layers from repo manifest.....	4
○ Install the repo utility:.....	4
○ Download the Yocto layers .....	4
• Get Yocto layers from community repository.....	4
Build Image .....	6
Boot boards with Yocto image.....	7
• Prerequisites .....	7
• Boot with ramdisk rootfs image .....	7
• Booting with full rootfs from large storage device.....	9
• Secure boot .....	11
Prebuilt Toolchain .....	11
Known Issue .....	13
Reference .....	14

## Introduction

Yocto with LSDK components provides recipes for the last Yocto release to use the latest and greatest components from LSDK as they get released. This eventually makes its way into the next community Yocto release at [yoctoproject.org](http://yoctoproject.org).

## Supported Boards

The following table Yocto with LSDK components release supports the following QorIQ targets.

Target Type	Board	LE		BE	
		32b	64b	32b	64b
QorIQ LS Series Communications Processors	ls1012ardb	✓	✓	X	X
	ls1012afrwy	✓	✓	X	X
	ls1021atwr	✓	X	X	X
	ls1043ardb	✓	✓	X	✓
	ls1046ardb	✓	✓	X	✓
	ls1088ardb	X	✓	X	✓
	ls1088ardb-pb	X	✓	X	X
	ls2088ardb	X	✓	X	✓
QorIQ T Series Communications Processors	t1024rdb	X	X	✓	✓
	t1042d4rdb	X	X	✓	✓
	t2080rdb	X	X	✓	✓
	t4240rdb	X	X	✓	✓
QorIQ P Series Communications Processors	p1020rdb	X	X	✓	X
	p2020rdb	X	X	✓	X
	p2041rdb	X	X	✓	X
	p3041ds	X	X	✓	X
	p4080ds	X	X	✓	X
	p5040ds	X	X	✓	✓
QorIQ MPC Series Communications Processors	mpc8548cds	X	X	✓	X

## Download Yocto Layer

To make sure the build host is prepared for Yocto running and build, please follow below guide to prepare the build environment.

<https://www.yoctoproject.org/docs/2.6/brief-yoctoprojectqs/brief-yoctoprojectqs.html>

- Get the Yocto layers from repo manifest

The following is the step of how to use repo utility to download all Yocto layers according to the repo manifest.

- Install the repo utility:

```
$: mkdir ~/bin
```

```
$: curl https://storage.googleapis.com/git-repo-downloads/repo >  
~/bin/repo
```

```
$: chmod a+x ~/bin/repo
```

- Download the Yocto layers

```
$: export PATH=${PATH}:~/bin
```

```
$: mkdir yocto-sdk
```

```
$: cd yocto-sdk
```

```
$: repo init -u
```

```
https://source.codeaurora.org/external/qorik/qorik-  
components/yocto-sdk -b warrior
```

```
$: repo sync --no-clone-bundle
```

- Get Yocto layers from community repository

The following is the step of how to download all Yocto layers through git commands.

```
$: mkdir yocto-sdk
```

```
$: cd yocto-sdk
```

```
$: mkdir sources
```

```
$: cd sources
```

```
$: git clone git://git.yoctoproject.org/poky
```

```
$: cd poky
```

```
$: git reset --hard 0e392026ffefee098a890c39bc3ca1f697bacb52
```

```
$: cd ..
```

```
$: git clone git://git.openembedded.org/meta-openembedded
```

```
$: cd meta-openembedded
```

---

```
$: git reset --hard 0477c76116cd1dc479d0df0e9721cbbd729ac4d2
$: cd ..
$: git clone git://git.yoctoproject.org/meta-freescale
$: cd meta-freescale
$: git reset --hard 3cf8e849e501c1243c0710889e97d14477688784
$: cd ..
$: git clone git://git.yoctoproject.org/meta-virtualization
$: cd meta-virtualization
$: git reset --hard abcd5841dffffc1ff4410f6c149dc304d4ac5e42
$: cd ..
$: git clone git://git.yoctoproject.org/meta-cloud-services
$: cd meta-cloud-services
$: git reset --hard 215b97571f52d43915eda1fdc5cd80719687abcd
$: cd ..
$: git clone git://git.yoctoproject.org/meta-security
$: cd meta-security
$: git reset --hard 5959e4f4bf6120edf82c71e6c7a0b6118f275419
$: cd ..
$: git clone https://github.com/Freescale/meta-freescale-distro
$: cd meta-freescale-distro
$: git reset --hard 8fbf269e32650cd9392603c1c81d8ace4111f89b
$: cd ..
$: git clone https://source.codeaurora.org/external/qoriq/qoriq-components/meta-qoriq-demos
$: cd meta-qoriq-demos
$: git reset --hard 62ccd769d5a6a9f7255e1626a4d0ba7229355f18
$: cd ..
$: cp sources/meta-qoriq-demos/scripts/setup-env ./
```

## Build Image

The build steps are common for all platforms, the document takes ls1046ardb for an example.

```
$ cd yocto-sdk
$: . ./setup-env -m ls1046ardb
$: bitbake fsl-image-networking
$: bitbake fsl-image-networking-full
```

### Note:

1. The images will be available in yocto-sdk/build\_ls1046ardb/tmp/deploy/images/ls1046ardb/ folder.
2. The following kernel config options are used for enabling the upstream version of DPAA driver for PowerPC targets:

CONFIG\_FSL\_DPAA, CONFIG\_FSL\_FMAN and CONFIG\_FSL\_DPAA\_ETH need to be enabled in kernel menuconfig as below:

```
Device Drivers --->
  SOC (System On Chip) specific Drivers --->
    [*] Freescale DPAA 1.x support --->
      Device Drivers --->
        [*] Network device support --->
          [*] Ethernet driver support --->
            <*> FMan support
            <*> DPAA Ethernet ----
```

## Boot boards with Yocto image

### • Prerequisites

- The tftp server is setup for image download
- A serial cable is connected from your PC to UART1
- The ethernet cable is connected to the first ethernet port on the board.

### • Boot with ramdisk rootfs image

- Power up or reset the board and press a key on the terminal when prompted to get to the U-Boot command line
- Set up the environment in U-Boot

=> setenv ipaddr <board\_ipaddr>

=> setenv serverip <tftp\_serverip>

Board	Bootargs
ls1021atwr	=> setenv bootargs root=/dev/ram0 rw console=ttyS0,115200 ramdisk_size=0x1000000
ls1012a	=> setenv bootargs root=/dev/ram0 rw console=ttyS0,115200 earlycon=uart8250,mmio,0x21c0500 ramdisk_size=0x10000000
ls1043a	=> setenv bootargs root=/dev/ram0 rw console=ttyS0,115200 earlycon=uart8250,mmio,0x21c0500 ramdisk_size=0x10000000
ls1046a	=> setenv bootargs root=/dev/ram0 rw console=ttyS0,115200 earlycon=uart8250,mmio,0x21c0500 ramdisk_size=0x10000000
ls1088ardb	=> setenv bootargs root=/dev/ram0 rw console=ttyS0,115200 earlycon=uart8250,mmio,0x21c0500 ramdisk_size=0x2000000 default_hugepagesz=2m hugepagesz=2m hugepages=512
ls2088ardb	=> setenv bootargs root=/dev/ram0 rw console=ttyS1,115200 earlycon=uart8250,mmio,0x21c0600 ramdisk_size=0x2000000 default_hugepagesz=1024m hugepagesz=1024m hugepages=8
mpc8548cds	=> setenv bootargs root=/dev/ram rw console=ttyS1,115200 ramdisk_size=1000000 log_buf_len=128K
t1024rdb	=> setenv bootargs root=/dev/ram rw console=ttyS1,115200 ramdisk_size=1000000 log_buf_len=128K

Other PPC targets	=> setenv bootargs root=/dev/ram rw console=ttyS0,115200 ramdisk_size=1000000 log_buf_len=128K
-------------------	--

- The ls1088ardb and ls2088ardb need the below commands to enable DPAA2 ethernet in Linux

Board	Commands
ls1088ardb	=> sf probe 0:0 => sf read 0x80000000 0xA00000 0x100000 => sf read 0x80100000 0xE00000 0x100000 => fsl_mc start mc 0x80000000 0x80100000 => sf read 0x80200000 0xd00000 0x100000 => fsl_mc lazyapply dpl 0x80200000
ls2088ardb	=> fsl_mc start mc 0x580a00000 0x580e00000 => fsl_mc lazyapply dpl 0x580d00000

- Download Images and bootup

Board	Commands
ls1021atwr	=> tftp 82000000 uImage-ls1021atwr.bin => tftp 88000000 fsl-image-networking-ls1021atwr.ext2.gz.u-boot => tftp 8f000000 uImage-ls1021a-twr.dtb => bootm 82000000 88000000 8f000000
mpc8548cds	=> tftpboot 0x01000000 uImage-mpc8548cds.bin => tftpboot 0x03000000 fsl-image-networking-mpc8548cds.ext2.gz.u-boot => tftpboot 0x02000000 uImage-



	mpc8548cds_32b.dtb => bootm 0x01000000 0x03000000 0x02000000
p1020rdb p2020rdb p2041rdb p3041ds p4080ds p5040ds	=> tftpboot 0x01000000 uImage-<board>.bin => tftpboot 0x02000000 fsl-image-networking-<board>.ext2.gz.u-boot => tftpboot 0x00c00000 uImage-<board>.dtb => bootm 0x01000000 0x04000000 0x02000000
t1024rdb t1042d4rdb t2080rdb t4240rdb	=> tftpboot 0x01000000 uImage-<board>.bin => tftpboot 0x05000000 fsl-image-networking-<board>.ext2.gz.u-boot => tftpboot 0x02000000 uImage-<board>.dtb => bootm 0x01000000 0x05000000 0x02000000
ls1012afrwy ls1012ardb ls1021atwr ls1043ardb ls1046ardb ls1088ardb ls1088ardb-pb ls2080ardb ls2088ardb	=> tftp a0000000 fitImage-fsl-image-networking-<board>.bin => bootm a0000000

## • Booting with full rootfs from large storage device

- Prepare the media (SATA/SD/USB) and format it to ext2 format, mount the ext2 partition and extract a full rootfs into this partition, unmount this partition.
- Power up or reset the board and press a key on the terminal when prompted and get to the U-Boot command line.
- Set up the environment in u-boot:

```
=> setenv ipaddr <board_ipaddr>
```

```
=> setenv serverip <tftp_serverip>
```

Board	Commands
ls1021atwr	=> setenv bootargs root=/dev/sda* rootdelay=5 rw console=ttyS0,115200 earlycon=uart8250,mmio,0x21c0500
ls1012a series ls1043a series ls1046a series	=> setenv bootargs root=/dev/sda* rootdelay=5 rw console=ttyS0,115200 earlycon=uart8250,mmio,0x21c0500

ls1088ardb	=> setenv bootargs root=/dev/sda* rootdelay=5 rw console=ttyS0,115200 earlycon=uart8250,mmio,0x21c0500 default_hugepagesz=2m hugepagesz=2m hugepages=512
ls2088ardb	=> setenv bootargs root=/dev/sda* rootdelay=5 rw console=ttyS1,115200 earlycon=uart8250,mmio,0x21c0600 default_hugepagesz=1024m hugepagesz=1024m hugepages=8
mpc8548cds	=> setenv bootargs root=/dev/sda* rootdelay=5 rw console=ttyS1,115200 log_buf_len=128K
P and T series	=> setenv bootargs root=/dev/sda* rootdelay=5 rw console=ttyS0,115200 log_buf_len=128K

- For ls1088ardb and ls2088ardb, please run below commands to enable DPAA2 ethernet in Linux:

Board	Commands
ls1088ardb	=> sf probe 0:0 => sf read 0x80000000 0xA00000 0x100000 => sf read 0x80100000 0xE00000 0x100000 => fsl_mc start mc 0x80000000 0x80100000 => sf read 0x80200000 0xd00000 0x100000 => fsl_mc lazyapply dpl 0x80200000
ls2088ardb	=> fsl_mc start mc 0x580a00000 0x580e00000 => fsl_mc lazyapply dpl 0x580d00000

- Download Image and bootup

Board	Commands
ls1021atwr	=> tftp 82000000 uImage-ls1021atwr.bin => tftp 8f000000 uImage-ls1021a-twr.dtb => bootm 82000000 - 8f000000
mpc8548cds	=> tftpboot 0x01000000 uImage-mpc8548cds.bin => tftpboot 0x02000000 uImage-mpc8548cds_32b.dtb => bootm 0x01000000 - 0x02000000
p2020rdb	=> tftpboot 0x01000000 uImage-p2020rdb.bin => tftpboot 0x00c00000 uImage-p2020rdb- pc_32b.dtb => bootm 0x01000000 - 0x00c00000
p1020rdb p2041rdb p3041ds p4080ds p5040ds t1024rdb t1042d4rdb t2080rdb t4240rdb	=> tftpboot 0x01000000 uImage-<board>.bin => tftpboot 0x02000000 uImage-<board>.dtb => bootm 0x01000000 - 0x02000000

ls1012afrwy ls1012ardb ls1021atwr ls1043ardb ls1046ardb ls1088ardb ls1088ardb- pb ls2080ardb ls2088ardb	<pre>=&gt; tftp a0000000 fitImage-&lt;board&gt;.bin =&gt; bootm a0000000:kernel@1 - a0000000:&lt;fdt name&gt;</pre> <p>NOTE: &lt;fdt name&gt; can be got by the following command:</p> <pre>\$: grep fdt@ fitImage-its-&lt;board&gt;.its</pre>
--	--

- Secure boot

To enable the secure boot on QorIQ platforms, please refer to the "6.1 Secure boot" section of the following LSDK documentation.

<https://www.nxp.com/support/developer-resources/run-time-software/linux-software-and-development-tools/layercape-software-development-kit:LAYERSCAPE-SDK?tab=Documentation+Tab>

## Prebuilt Toolchain

The prebuilt toolchain for support targets are available in NXP official image mirror.

ARM32: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86\\_64-fsl-toolchain-cortexa7hf-neon-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86_64-fsl-toolchain-cortexa7hf-neon-toolchain-2.6.sh)

ARM64: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86\\_64-fsl-toolchain-aarch64-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86_64-fsl-toolchain-aarch64-toolchain-2.6.sh)

ARM64-BE: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86\\_64-fsl-toolchain-aarch64\\_be-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86_64-fsl-toolchain-aarch64_be-toolchain-2.6.sh)

PPCE500V2: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86\\_64-fsl-toolchain-ppce500v2-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86_64-fsl-toolchain-ppce500v2-toolchain-2.6.sh)

PPCE500MC: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86\\_64-fsl-toolchain-ppce500mc-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86_64-fsl-toolchain-ppce500mc-toolchain-2.6.sh)

PPCE5500: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86\\_64-fsl-toolchain-ppce5500-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qorIQ-glibc-x86_64-fsl-toolchain-ppce5500-toolchain-2.6.sh)

PPCE5500-64B: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qoriq-glibc-x86\\_64-fsl-toolchain-ppc64e5500-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qoriq-glibc-x86_64-fsl-toolchain-ppc64e5500-toolchain-2.6.sh)

PPCE6500: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qoriq-glibc-x86\\_64-fsl-toolchain-ppce6500-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qoriq-glibc-x86_64-fsl-toolchain-ppce6500-toolchain-2.6.sh)

PPCE6500-64B: [https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qoriq-glibc-x86\\_64-fsl-toolchain-ppc64e6500-toolchain-2.6.sh](https://www.nxp.com/lgfiles/sdk/lSDK1809-yocto26/fsl-qoriq-glibc-x86_64-fsl-toolchain-ppc64e6500-toolchain-2.6.sh)

## Known Issue

ID	Description	Disposition	Opened In	Workarounds
QLINUX-10188	PM sleep test failed on T1042D4RDB	Open	LSDK-1809	
QLINUX-9692	T2 optical_xfi port not Works	Open	LSDK-1809	<pre> update t2080rdb.dts ethernet@f0000 { -   phy-handle = &lt;&amp;xg_cs4315_phy1&gt;; +   phy-handle = &lt;&amp;xg_cs4315_phy2&gt;; phy-connection-type = "xgmii"; }; ethernet@f2000 { -   phy-handle = &lt;&amp;xg_cs4315_phy2&gt;; +   phy-handle = &lt;&amp;xg_cs4315_phy1&gt;; phy-connection-type = "xgmii"; }; </pre>
QLINUX-10670	Guest rootfs boot failed on Text2.gz rootfs 2080RDB and T4240RDB with	Open	LSDK-1809	
QSDK-5118	Openssl offload : asymmetric_ciphers_rsa_caam_jr failed to work	Open	LSDK-1809	

## Reference

- NXP LSDK official website: <https://www.nxp.com/products/processors-and-microcontrollers/arm-based-processors-and-mcus/qoriq-layerscape-arm-processors/layerscape-software-development-kit-v18.09:LAYERSCAPE-SDK>
- NXP LSDK github portal: <https://lsdk.github.io/>
- Yocto Open Source User Guide: <https://www.yoctoproject.org/docs/>