



RealMan Robotic Arm rm_moveit2_config User Manual V1.0



RealMan Intelligent Technology (Beijing) Co., Ltd.



Revision History:

No.	Date	Comment
V1.0	11/22/2023	Draft



Content

1 rm_moveit2_config Description	3
2 . rm_moveit2_config Use	3
2.1moveit2 Controlling Virtual Robotic Arm	3
2.2moveit2 Controlling Real Robotic Arm	5
3. rm_moveit2_config Architecture Description	6
3.1 Overview of Package Files	6
4 rm_moveit2_config Topic Description	9



1 rm_moveit2_config Description

rm_moveit2_config folder is a function package for realizing the moveit2 control of a real robotic arm. The package is mainly used to call the official moveit2 framework and generate the configuration and launch file of moveit2 suitable for our robotic arm combined with the URDF of the robotic arm. Through this package, we can realize the moveit2 control of the virtual robotic arm and control of the real robotic arm. This package is introduced in detail in the following aspects.

1. Package use.
2. Package architecture description.
3. Package topic description.

Through the introduction of the three parts, it can help you:

1. Understand the package use.
2. Familiar with the file structure and function of the package.
3. Familiar with the topic related to the package for easy development and use.

Source code address: https://github.com/RealManRobot/ros2_rm_robot.git.

2 . rm_moveit2_config Use

2.1moveit2 Controlling Virtual Robotic Arm

First, after configuring the environment and completing the connection, we can directly launch the node through the following command.


```
rm@rm-desktop:~$ ros2 launch rm_<arm_type>_config demo.launch.py
```

In practice, the above <arm_type> needs to be replaced by the actual model of the robotic arm. The available models of the robotic arm are 65, 63, eco65, and 75.


For example, the launch command of 65 robotic arm:

```
rm@rm-desktop:~$ ros2 launch rm_65_config demo.launch.py
```


The following screen appears in the interface after successful node startup.



Next, we can make the robotic arm reach the target position by dragging the control ball and then clicking Plan Execution.



Execute the plan.



2.2moveit2 Controlling Real Robotic Arm

There are relatively more control commands required to control a real robotic arm, and the following is a detailed control method.

First, run the chassis driver node.

```
rm@rm-desktop:~$ ros2 launch rm_driver rm_<arm_type>_driver.launch.py
```

Next, run the rm_description package file.

```
rm@rm-desktop:~$ ros2 launch rm_description rm_<arm_type>_display.launch.py
```

Then, run the relevant nodes of the intermediate package rm_control.


```
rm@rm-desktop:~$ ros2 launch rm_control rm_<arm_type>_control.launch.py
```

Finally, launch the moveit2 node that controls the real robotic arm.

```
rm@rm-desktop:~$ ros2 launch rm_<arm_type>_config real_moveit_demo.launch.py
```

Note that the above commands need to replace <arm_type> with the corresponding robotic arm model, which can be selected as 65, 63, eco65, and 75.

After completing the above operations, the following interface appears, and we can control the movement of the robotic arm by dragging the control ball.



3. rm_moveit2_config Architecture Description

3.1 Overview of package files


The current rm_driver package is composed of the following files.

rm_63_config	#63 robotic arm moveit2 package
CMakeLists.txt	#63 robotic arm moveit2 package
compilation rules	
config	#63 robotic arm moveit2 package
parameter folder	
initial_positions.yaml	#63 robotic arm moveit2 initial position
joint_limits.yaml	#63 robotic arm joint limits
kinematics.yaml	#63 robotic arm kinematics parameters
moveit_controllers.yaml	#63 robotic arm moveit2 controller
moveit.rviz	#63 robotic arm rviz2 display
configuration file	
pilz_cartesian_limits.yaml	
rml_63_description.ros2_control.xacro	#63 robotic arm xacro description file
rml_63_description.srdf	#63 robotic arm moveit2 control
configuration file	
rml_63_description.urdf.xacro	#63 robotic arm xacro description file
ros2_controllers.yaml	#63 robotic arm move controller
launch	
demo.launch.py	#63 virtual robotic arm moveit2 launch
file	



```
| | | — gazebo_moveit_demo.launch.py          #63 simulation robotic arm moveit2
launch file
| | | — move_group.launch.py
| | | — moveit_rviz.launch.py
| | | — real_moveit_demo.launch.py          #63 real robotic arm moveit2 launch
file
| | | — rsp.launch.py
| | | — setup_assistant.launch.py
| | | — spawn_controllers.launch.py
| | | — static_virtual_joint_tfs.launch.py
| | | — warehouse_db.launch.py
| | — package.xml
| — rm_65_config          #65 robotic arm moveit2 package (file explanation
reference 63)
| | — CMakeLists.txt
| | — config
| | | — initial_positions.yaml
| | | — joint_limits.yaml
| | | — kinematics.yaml
| | | — moveit_controllers.yaml
| | | — moveit.rviz
| | | — pilz_cartesian_limits.yaml
| | | — rm_65_description.ros2_control.xacro
| | | — rm_65_description.srdf
| | | — rm_65_description.urdf.xacro
| | | — ros2_controllers.yaml
| | — launch
| | | — demo.launch.py
| | | — gazebo_moveit_demo.launch.py
| | | — move_group.launch.py
| | | — moveit_rviz.launch.py
| | | — real_moveit_demo.launch.py
| | | — rsp.launch.py
| | | — setup_assistant.launch.py
| | | — spawn_controllers.launch.py
| | | — static_virtual_joint_tfs.launch.py
| | | — warehouse_db.launch.py
| | — package.xml
| — rm_75_config          #75 robotic arm moveit2 package (file explanation
reference 63)
| | — CMakeLists.txt
| | — config
| | | — initial_positions.yaml
| | | — joint_limits.yaml
```




About the topic description of moveit2, to make its topic structure clearer, we will view and explain it here in the form of a data flow graph of node topics.

```
rm@rm-desktop:~$ ros2 run rqt_graph rqt_graph
```


As we can see from the figure, `rm_driver` also subscribes to the topic of `/rm_driver/movej_canfd_cmd` of `rm_control`, which is the topic of the transmission function of the



robotic arm. Through this topic, `rm_control` publishes the planned joint nodes to `rm_driver` node to control the movement of the robotic arm.



`rm_control` is the bridge of communication between `rm_driver` and `moveit2`. It communicates with `/moveit_simple_controller_manager` through the action of `/rm_group_controller/follow_joint_trajectory` to obtain the planned points and perform interpolation operations. Give interpolated data to `rm_driver` through transmission.



The nodes involved in `moveit2` include `move_group`, `move_group_private` and `moveit_simple_controller_manager`. The main function is to realize the movement planning of the robotic arm and to display the planning information and other data in `rviz`. On the other hand, the planning data need to be passed to `rm_control` for further subdivision.