


Fundamental of Cognitive Interaction with Robots

Lecture 2

Getting Started with Raspberry Pi

What do you need?


- **Raspberry Pi, which version?**
- **Power supply:**
 - USB-C for Raspberry Pi 4
 - micro USB for Raspberry Pi 3, 2, and 1.
 - You need a power supply that provides:
 - At least 3.0 amps for Raspberry Pi 4
 - At least 2.5 amps for Raspberry Pi 3
- **A keyboard and a mouse**



Getting Started with Raspberry Pi (Cont.)


What do you need?

- **A microSD card**
 - at least 8GB
- **A TV or computer screen**
- **HDMI cable**
 - Raspberry Pi 4 has two micro HDMI ports, so you need a micro HDMI to HDMI cable.
 - Raspberry Pi 1, 2, and 3 have a single full-size HDMI port, so you can connect them to a screen using a standard HDMI to HDMI cable.



microHDMI to HDMI Cable

Monitor






Raspberry Pi OS

- Raspberry Pi needs an operating system to work.
- The OS for Raspberry Pi is called “Raspberry Pi OS” (previously known as Raspbian), which is the official operating system for Raspberry Pi.
- The Raspberry Pi OS is a custom version of Debian, which is a Linux version.
- A microSD card is used to store the files and the Raspberry Pi OS.
- Then, “Raspberry Pi Imager” is used to download the OS to the microSD card.
- Download the Raspberry Pi Imager from:

<https://www.raspberrypi.com/software/>


Raspberry Pi Imager

- Download and install Raspberry Pi Imager to a computer with an SD card reader.
- Put the SD card you'll use with your Raspberry Pi into the reader and run Raspberry Pi Imager.
- Select OS
- Select SD card
- Click Write button




Raspberry Pi Imager (Cont.)

- Wait for the Raspberry Pi Imager to finish writing. It needs Internet to download the OS.
- Once you get the following message, you can eject your SD card.




Connect your Raspberry Pi

- It's important to do this in the right order, so that all your components are safe.
- Insert the SD card you've set up with Raspberry Pi OS into the microSD card slot.
- Connect the mouse and keyboard
- Connect the screen, and make sure it is powered on.
- For Raspberry Pi 4, connect the screen to the first HDMI port, labelled HDMI0 (nearest the power in port).
- You can connect an optional second screen to HDMI1.
- Connect Ethernet, camera, and speakers





Power up the Raspberry Pi

- Raspberry Pi doesn't have a power switch. As soon as you connect it to a power outlet, it will turn on.
- Plug the power supply into a socket and connect it to your Raspberry Pi's power port.
- After that, the Raspberry Pi is booting, raspberries appear at the top of the screen. After a few seconds the Raspberrv Pi OS desktop will appear.



Booting



Finishing the setup

- When you start the Raspberry Pi for the first time, the Welcome to Raspberry Pi screen will appear.



Choose country and language




*Necessary step to configure the WiFi

Finishing the setup

Change the password

- The default username is 'pi', and the default password is 'raspberry'. You can change the default password in this screen, and clicking on Next.




The screenshot shows a window titled "Welcome to Raspberry Pi" with standard window controls. Inside, the section "Change Password" contains the following text: "The default 'pi' user account currently has the password 'raspberry'. It is strongly recommended that you change this to a different password that only you know." Below this text are two input fields: "Enter new password:" and "Confirm new password:". To the right of these fields is a checkbox labeled "Hide characters" which is checked. At the bottom, there is a prompt: "Press 'Next' to activate your new password." and two buttons: "Back" and "Next". The "Next" button is highlighted with a dashed border.

Finishing the setup

Connect to a WiFi Network


- You can connect to your wireless network by selecting its name, entering the password, and clicking on Next.



Finishing the setup

Update the software


- After successful connection to a WiFi network, the system will check for updates to Raspberry Pi OS and install them.



- Click on Restart to finish the setup.

Finishing the setup



Raspberry Pi OS desktop



Enable VNC



- VNC is a tool for accessing your Raspberry Pi desktop remotely.
- By using VNC, you don't have to connect a screen to the Raspberry Pi, you can access from another computer that is on the same network as your Raspberry Pi.

Enabling VNC Server on the Raspberry Pi:




Installing VNC Viewer on your Computer

- There are a number of viewers available, but the easiest to set up is Real VNC Viewer.
- You can download Windows, Mac, Android, and IOS installers from here: <https://www.realvnc.com/en/connect/download/viewer/>
- After installation, you can connect using the IP address, or the local address of the Raspberry Pi: “raspberrypi.local:0”



The Terminal

- The Raspberry Pi OS is a Linux based OS and comes with a GUI with limited features.
- So very often you need to type commands using the Terminal
- The Linux terminal is a powerful tool for executing operations on the OS



Update Raspberry Pi OS

Run the following commands in the Terminal window:

- First,

```
sudo apt update
```

- Then,

```
sudo apt full-upgrade
```

- `sudo apt update` **downloads the update,**
- `sudo apt upgrade` **installs the update.**
- **It is a good idea to do a `sudo reboot` after upgrading.**



sudo

- sudo is a program for Linux OS that allows users to run programs with the security privileges of the superuser.
- It originally stood for "superuser do"
- Some commands that make permanent changes to the state of your system require you to have root privileges to run.
- The command sudo temporarily gives your account (if you're not already logged in as root) the ability to run these commands
- You typically use it in your Terminal window for installing/upgrading software, etc.

Shut-down Raspberry Pi

- Unlike your other electronic devices, Raspberry Pi doesn't come with an "off" switch.
- You should not just "pull out the plug"

To shutdown Raspberry Pi , select the Raspberry Pi icon in upper left corner and select "Logout"





Or enter the following in the Terminal: `sudo poweroff`

After that, you can unplug the Raspberry Pi .

Python with Raspberry Pi


- Today, Python has become one of the most popular Programming Languages.
- The Raspberry Pi OS comes with a basic Python Editor called “Thonny”



- But you can install and use other Python Editors if you prefer


Hello World

- Write a python code:
print ("Hello")
- Click Run



Python Packages with Thonny

- Tools -> Manage packages...



Installing Python Packages

There are multiple ways to install Python Libraries/ Packages on Raspberry Pi

- apt (advanced package tool): Some Python packages can be found in the Raspberry Pi OS archives and can be installed using apt. Example:

```
sudo apt update  
sudo apt install python3-picamera
```
- pip: Not all Python packages are available in the Raspberry Pi OS archives, and those that are can sometimes be out-of-date. If you can't find a suitable version in the Raspberry Pi OS archives, you can install packages from the Python Package Index (PyPI) or piwheels. To do so, use the pip tool. Example:

```
sudo pip install libraryname
```
- piwheels: piwheels is a Python package repository specifically for the Raspberry Pi



Any Questions