

Classification Level: Top Secret () Secret () Internal () Public (√)

RK3399Pro_Linux&Android_RKNN_API_V0. 9.3_20190124

(Technology Department, Graphic Display Platform Center)

| | | |
|--------------|----------------|------------|
| Mark: | Version | V0.9.3 |
| [] Editing | Author | Kevin Du |
| [√] Released | Completed Date | 2019-01-24 |
| | Reviewer | Randall |
| | Reviewed Date | 2019-01-24 |

福州瑞芯微电子股份有限公司

Fuzhou Rockchip Electronics Co., Ltd.

(Copyright Reserved)

Revision History

| Version | Modifier | Date | Modify description | Reviewer |
|---------|----------|------------|---|----------|
| V0.9.1 | Kevin Du | 2018-11-27 | Initial release. | Randall |
| V0.9.2 | Kevin Du | 2018-12-19 | Mainly modify the API definition of input and output. | Randall |
| V0.9.3 | Kevin Du | 2019-01-24 | Add API migration instruction from v0.9.1 to v0.9.2. | Randall |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Table of Contents

| | | |
|----------|---|----------|
| 1 | OVERVIEW | 4 |
| 2 | SYSTEM DEPENDENCIES DESCRIPTION..... | 4 |
| 2.1 | LINUX PLATFORM DEPENDENCIES | 4 |
| 2.2 | ANDROID PLATFORM DEPENDENCIES | 4 |
| 3 | API INSTRUCTIONS..... | 4 |
| 3.1 | RKNN API DETAILS..... | 5 |
| 3.1.1 | <i>rknn_init</i> | 5 |
| 3.1.2 | <i>rknn_destroy</i> | 7 |
| 3.1.3 | <i>rknn_query</i> | 7 |
| 3.1.4 | <i>rknn_inputs_set</i> | 11 |
| 3.1.5 | <i>rknn_run</i> | 12 |
| 3.1.6 | <i>rknn_outputs_get</i> | 12 |
| 3.1.7 | <i>rknn_outputs_release</i> | 14 |
| 3.2 | RKNN DATA STRUCTURE DEFINITION..... | 14 |
| 3.2.1 | <i>rknn_input_output_num</i> | 14 |
| 3.2.2 | <i>rknn_tensor_attr</i> | 15 |
| 3.2.3 | <i>rknn_input</i> | 16 |
| 3.2.4 | <i>rknn_output</i> | 17 |
| 3.2.5 | <i>rknn_perf_detail</i> | 18 |
| 3.2.6 | <i>rknn_perf_run</i> | 18 |
| 3.2.7 | <i>rknn_run_extend</i> | 18 |
| 3.2.8 | <i>rknn_output_extend</i> | 19 |
| 3.2.9 | <i>rknn_sdk_version</i> | 19 |
| 3.2.10 | <i>Error Code</i> | 19 |

| | | |
|----------|---------------------------------------|-----------|
| 3.3 | RKNN API BASIC CALL FLOW | 20 |
| 4 | DEMO INSTRUCTIONS | 26 |
| 4.1 | LINUX DEMO | 26 |
| 4.1.1 | <i>Compilation Instructions</i> | 26 |
| 4.1.2 | <i>Run Instructions</i> | 27 |
| 4.2 | ANDROID DEMO | 28 |
| 4.2.1 | <i>Compilation Instructions</i> | 28 |
| 4.2.2 | <i>Run Instructions</i> | 29 |
| 5 | APPENDIX | 30 |
| 5.1 | API MIGRATION INSTRUCTIONS..... | 30 |

1 Overview

The RKNN API is an NPU(Neural Network Unit) acceleration interface based on RK3339Pro Linux/Android. It provides general acceleration support for AI related applications.

This manual mainly consists of three parts.

- 1) RKNN API: Detailed API definition and instructions for using.
- 2) Linux Demo: Compile the Mobilenet classifier demo and SSD object detection demo on the Linux platform using hardware acceleration.
- 3) Android Demo: Compile the SSD object detection demo on the Android platform using hardware acceleration.

2 System Dependencies Description

2.1 Linux Platform Dependencies

This API SDK is developed based on RK3399Pro 64-bit Linux, needs to be used on RK3399Pro 64-bit Linux system.

2.2 Android Platform Dependencies

This API SDK is developed based on RK3399Pro Android8.1, needs to be used on RK3399Pro Android8.1 system or higher.

3 API Instructions

RKNN API is a set of application programming interfaces (APIs) that based on RK3399Pro NPU hardware acceleration, developers can use this API to develop AI related applications, the API will call the NPU hardware accelerator.

Currently the RKNN API on the Linux and Android platforms are the same.

On the Linux platform, The API SDK provides two demos that use RKNN API, one is image classifier demo based on MobileNet model, the other is object detection demo based on SSD model.

On the Android platform, The API SDK provides one object detection demo based on SSD model.

3.1 RKNN API Details

RKNN API is a set of generic APIs designed by Rockchip for RK3399Pro NPU hardware accelerator. This API need to be used in conjunction with RKNN-Toolkit provided by Rockchip. The RKNN-Toolkit can convert common model formats into RKNN models, such as TensorFlow models, Caffe models, etc.

A detailed description of the RKNN-Toolkit can be found in the <RKNN-Toolkit User Guide>.

The RKNN-Toolkit can generate a model file with the rknn suffix, such as *mobilenet_v1-tf.rknn*.

On the Linux platform, enter the *<rknn-api>/Linux/rknn_api_sdk* directory, the API definition is in *<rknn_api_sdk>/rknn_api/include/rknn_api.h*, and the dynamic library path of RKNN API is *<rknn_api_sdk>/rknn_api/lib(64)/librknn_api.so*. Users only need to use the header file and dynamic library in the AI application.

On the Android platform, enter the *<rknn-api>/Android/rknn_api* directory, the API definition is in *<rknn_api>/include/rknn_api*, the dynamic library path of RKNN API is *<rknn_api>/lib(64)/librknn_api.so*. Users only need to use the header file and dynamic library in the JNI library of the AI application. Currently, only JNI development methods are supported on Android.

The following section is a description of RKNN API.

3.1.1 rknn_init

| | |
|-------------|--|
| API | <code>int rknn_init(rknn_context* context, void* model, uint32_t size, uint32_t flag)</code> |
| Description | Create a context and load the rknn model. |
| Parameter | <code>rknn_context* context</code> : The pointer of context object. Used to return the created context |

| | |
|--------|---|
| | object. |
| | void* model: A pointer to the rknn model. |
| | uint32_t size: The size of the rknn model. |
| | <p>uint32_t flag: Extended flag:</p> <p>RKNN_FLAG_PRIOR_HIGH: Create a high priority context.</p> <p>RKNN_FLAG_PRIOR_MEDIUM: Create a medium priority context.</p> <p>RKNN_FLAG_PRIOR_LOW: Create a low priority context.</p> <p>RKNN_FLAG_ASYNC_MASK: Enable Asynchronous mode. When enable, <i>rknn_outputs_get</i> will not block for too long, because it returns the inference result of the previous frame directly (except for the inference result of the first frame), which will significantly improve the inference frame rate in single-thread mode, but the cost is that <i>rknn_outputs_get</i> return not the inference results of the current frame. When <i>rknn_run</i> and <i>rknn_outputs_get</i> are in different threads, there is no need to enable the Asynchronous mode.</p> <p>RKNN_FLAG_COLLECT_PERF_MASK: Enable performance collection debug mode. When enable, you can query the running time of each layer of network through the <i>rknn_query</i> interface. It should be noted that the total time spent in inferring one frame is longer than <i>RKNN_FLAG_COLLECT_PERF_MASK</i> unset, because the execution of each layer needs to be synchronized.</p> |
| Return | Error code (see Error Code). |

The sample code is as follow:

```
rknn_context ctx;
int ret = rknn_init(&ctx, model_data, model_data_size, 0);
```

3.1.2 rknn_destroy

| | |
|-------------|--|
| API | int rknn_destroy(rknn_context context) |
| Description | Unload the rknn model and destroy the context and its associated resource. |
| Parameter | rknn_context context: The object of context. |
| Return | Error code (see Error Code). |

The sample code is as follow:

```
int ret = rknn_destroy (ctx);
```

3.1.3 rknn_query

| | |
|-------------|---|
| API | int rknn_query(rknn_context context, rknn_query_cmd cmd, void* info, uint32_t size) |
| Description | Query the related information of RKNN Model and SDK. |
| Parameter | rknn_context context: The object of context. |
| | rknn_query_cmd cmd: The command of query. |
| | void* info: The structure variable that store the returned result. |
| | uint32_t size: The size of the structure variable corresponding to <i>info</i> . |
| Return | Error code (see Error Code). |

The supported query commands of current SDK are shown in the following table:

| Command of Query | Returned Structure | Description |
|------------------------|---------------------------------------|--|
| RKNN_QUERY_IN_OUT_NUM | rknn_input_output_num | Query the number of input and output tensor. |
| RKNN_QUERY_INPUT_ATTR | rknn_tensor_attr | Query the attribute of input tensor. |
| RKNN_QUERY_OUTPUT_ATTR | rknn_tensor_attr | Query the attribute of output tensor. |
| RKNN_QUERY_PERF_DETAIL | rknn_perf_detail | Query the running time of each layer of the network. |

| | | |
|------------------------|----------------------------------|--|
| | | <p>This query requires use the <i>RKNN_FLAG_COLLECT_PERF_MASK</i> in <i>rknn_init</i>, otherwise no detailed layer performance information can be obtained.</p> <p>In addition, the <i>rknn_perf_detail.perf_data</i> returned by the <i>RKNN_QUERY_PERF_DETAIL</i> query does not require the user to free actively.</p> <p>Pay attention that the query can only return the correct query result after the <i>rknn_outputs_get</i> function is called.</p> |
| RKNN_QUERY_PERF_RUN | rknn_perf_run | <p>Query the hardware execution time of single inference.</p> <p>Pay attention that the query can only return the correct query result after the <i>rknn_outputs_get</i> function is called.</p> |
| RKNN_QUERY_SDK_VERSION | rknn_sdk_version | Query the SDK version. |

The next section will explain in detail how each query command should be used.

3.1.3.1 Query the number of input/output tensor

The *RKNN_QUERY_IN_OUT_NUM* command can be used to query the number of input/output tensor. The object of *rknn_input_output_num* structure needs to be created first.

The sample code is as follows:

```
rknn_input_output_num io_num;
ret = rknn_query(ctx, RKNN_QUERY_IN_OUT_NUM, &io_num, sizeof(io_num));
printf("model input num: %d, output num: %d\n", io_num.n_input,
        io_num.n_output);
```

3.1.3.2 Query the attribute of input tensor

The *RKNN_QUERY_INPUT_ATTR* command can be used to query the attribute of input tensor. The object of *rknn_tensor_attr* structure needs to be created first.

The sample code is as follows:

```
rknn_tensor_attr input_attrs[io_num.n_input];
memset(input_attrs, 0, sizeof(input_attrs));
for (int i = 0; i < io_num.n_input; i++) {
    input_attrs[i].index = i;
    ret = rknn_query(ctx, RKNN_QUERY_INPUT_ATTR, &(input_attrs[i]),
                    sizeof(rknn_tensor_attr));
}
```

3.1.3.3 Query the attribute of output tensor

The *RKNN_QUERY_OUTPUT_ATTR* command can be used to query the attribute of output tensor. The object of *rknn_tensor_attr* structure needs to be created first.

The sample code is as follows:

```
rknn_tensor_attr output_attrs[io_num.n_output];
memset(output_attrs, 0, sizeof(output_attrs));
for (int i = 0; i < io_num.n_output; i++) {
    output_attrs[i].index = i;
    ret = rknn_query(ctx, RKNN_QUERY_OUTPUT_ATTR, &(output_attrs[i]),
                    sizeof(rknn_tensor_attr));
}
```

3.1.3.4 Query the running time of each layer of the network

If you have set *RKNN_FLAG_COLLECT_PERF_MASK* flag when *rknn_init* function is called, then

you can use *RKNN_QUERY_PERF_DETAIL* to query the running time of each layer of the network after the *rknn_outputs_get* execution completed.

The object of *rknn_perf_detail* structure needs to be created first.

In addition, the *rknn_perf_detail.perf_data* returned by the *RKNN_QUERY_PERF_DETAIL* query does not require the user to free it.

Pay attention that the query can only return the correct query result after the *rknn_outputs_get* function is called.

The sample code is as follows:

```
rknn_perf_detail perf_detail;  
ret = rknn_query(ctx, RKNN_QUERY_PERF_DETAIL, &perf_detail,  
                sizeof(rknn_perf_detail));  
printf("%s", perf_detail.perf_data);
```

3.1.3.5 Query the hardware execution time of single inference.

The *RKNN_QUERY_PERF_RUN* command can be used to query the hardware execution time of single inference. The object of *rknn_perf_run* structure needs to be created first.

Pay attention that the query can only return the correct query result after the *rknn_outputs_get* function is called.

The sample code is as follows:

```
rknn_perf_run perf_run;  
ret = rknn_query(ctx, RKNN_QUERY_PERF_RUN, &perf_run,  
                sizeof(rknn_perf_run));  
printf("%ld", perf_run.run_duration);
```

3.1.3.6 Query the SDK version

The *RKNN_QUERY_SDK_VERSION* command can be used to query the SDK version. The object of *rknn_sdk_version* structure needs to be created first.

The sample code is as follows:

```
rknn_sdk_version version;
ret = rknn_query(ctx, RKNN_QUERY_SDK_VERSION, &version,
                sizeof(rknn_sdk_version));
printf("api version: %s\n", version.api_version);
printf("driver version: %s\n", version.drv_version);
```

3.1.4 rknn_inputs_set

| | |
|-------------|--|
| API | int rknn_inputs_set(rknn_context context, uint32_t n_inputs, rknn_input inputs[]) |
| Description | <p>Set the buffer pointer and other parameters of inputs.</p> <p>The buffer pointer and parameters of single input need to be stored in <i>rknn_input</i>. This function can support multiple inputs.</p> |
| Parameter | <p>rknn_context context: the object of context.</p> <p>uint32_t n_inputs: the number of inputs.</p> <p>rknn_input inputs[]: the arrays of inputs information, each element of the array is a <i>rknn_input</i> structure object.</p> |
| Return | Error code (see Error Code). |

The sample code is as follows:

```
rknn_input inputs[1];
memset(inputs, 0, sizeof(inputs));
inputs[0].index = 0;
inputs[0].type = RKNN_TENSOR_UINT8;
inputs[0].size = img_width*img_height*img_channels;
inputs[0].pass_through = FALSE;
inputs[0].fmt = RKNN_TENSOR_NHWC;
inputs[0].buf = in_data;

ret = rknn_inputs_set(ctx, 1, inputs);
```

For more detailed usage, see the step 4 of the [\[RKNN API Basic Call Flow\]](#) section.

3.1.5 rknn_run

| | |
|-------------|---|
| API | int rknn_run(rknn_context context, rknn_run_extend* extend) |
| Description | <p>Perform a model inference.</p> <p>The input data need to be set by <i>rknn_inputs_set</i> function before calling <i>rknn_run</i>.</p> <p>The <i>rknn_run</i> will not block normally, but it will block when there are more than 3 inference results not obtained by <i>rknn_outputs_get</i>.</p> |
| Parameter | rknn_context context: the object of context. |
| | rknn_run_extend* extend: the pointer of extend information. Used to set or get information about the frame corresponding to the current <i>rknn_run</i> , such as <i>frame_id</i> (see the rknn_run_extend definition for details). If not used, can be set to NULL. |
| Return | Error code (see Error Code). |

The sample code is as follows:

```
ret = rknn_run(ctx, NULL);
```

3.1.6 rknn_outputs_get

| | |
|-------------|--|
| API | int rknn_outputs_get(rknn_context context, uint32_t n_outputs, rknn_output outputs[], rknn_output_extend* extend) |
| Description | <p>Waiting for the inference operation to completed and get the output results.</p> <p>This function can obtain multiple output data at one time. Each output corresponds to a rknn_output structure object, you need to create and set each rknn_output object in turn before the function is called. In addition, the function will block until the inference completed (unless there is an exception error). The output results will eventually be stored in the array of <i>outputs[]</i>.</p> <p>There are two ways to use the buffer of the output data:</p> |

| | |
|-----------|--|
| | <p>1. Users malloc and free the output buffer themselves. In this mode, the <i>is_prealloc</i> of the <i>rknn_output</i> object needs to be set to TRUE, and the <i>rknn_output.buf</i> also needs to be set by user.</p> <p>2. The output buffer malloc and free by rknn api. In this mode, the <i>is_prealloc</i> of the <i>rknn_output</i> object needs to be set to FALSE, and <i>rknn_output.buf</i> will point to output data after the function is called.</p> |
| Parameter | <p>rknn_context context: the object of context.</p> <p>uint32_t n_outputs: the number of output arrays. This number must be the same as the number of outputs of rknn model. (the number of outputs of rknn model can be queried by <i>rknn_query</i>.)</p> <p>rknn_output outputs[]: the arrays of outputs information. Each element of array is a <i>rknn_output</i> structure object, representing an output of the model.</p> <p>rknn_output_extend* extend: the pointer of extend information. Used to set or get information about the frame corresponding to the current <i>rknn_outputs_get</i>, such as <i>frame_id</i> (see the rknn_output_extend definition for details). If not used, can be set to NULL.</p> |
| Return | Error code (see Error Code). |

The sample code is as follows:

```
rknn_output outputs[io_num.n_output];
memset(outputs, 0, sizeof(outputs));
for (int i = 0; i < io_num.n_output; i++) {
    outputs[i].want_float = TRUE;
    outputs[i].is_prealloc = FALSE;
}
ret = rknn_outputs_get(ctx, io_num.n_output, outputs, NULL);
```

For more detailed usage, see the step 6 of the [\[RKNN API Basic Call Flow\]](#) section.

3.1.7 rknn_outputs_release

| | |
|-------------|---|
| API | int rknn_outputs_release(rknn_context context, uint32_t n_outputs, rknn_output outputs[]) |
| Description | <p>Release outputs that obtained by <i>rknn_outputs_get</i>.</p> <p>When the outputs are no longer used, you need to call the function to release it. (Whether <i>rknn_output[x].is_prealloc</i> is TRUE or FALSE, you need to call the function to release the outputs.)</p> <p>After the function is called:</p> <p>when <i>rknn_output[x].is_prealloc</i> = FALSE, the <i>rknn_output[x].buf</i> obtained by <i>rknn_outputs_get</i> is also released automatically;</p> <p>when <i>rknn_output[x].is_prealloc</i> = TURE, the <i>rknn_output[x].buf</i> requires user to free it.</p> |
| Parameter | rknn_context context: the object of context. |
| | uint32_t n_outputs: the number of output arrays. This number must be the same as the number of outputs of rknn model. (the number of outputs of rknn model can be queried by <i>rknn_query</i> .) |
| | rknn_output outputs[]: the arrays of outputs information. |
| Return | Error code (see Error Code). |

The sample code is as follows:

```
ret = rknn_outputs_release(ctx, io_num.n_output, outputs);
```

3.2 RKNN Data Structure Definition

3.2.1 rknn_input_output_num

The structure *rknn_input_output_num* represents the number of tensors of input and output. The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|----------|-----------|------------------------------|
| n_input | uint32_t | The number of input tensor. |
| n_output | uint32_t | The number of output tensor. |

3.2.2 rknn_tensor_attr

The structure *rknn_tensor_attr* represents the tensor attribute of rknn model, The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|----------|----------------------|--|
| index | uint32_t | The index of input or output tensor. The index needs to be set before calling the <i>rknn_query</i> . |
| n_dims | uint32_t | The number of tensor dimensions. |
| dims | uint32_t[] | Each dimension value of tensor. |
| name | char[] | Name of tensor. |
| n_elems | uint32_t | The number of tensor elements. |
| size | uint32_t | The memory size of tensor data. |
| fmt | rknn_tensor_format | The dimension format of tensor, as follows: <i>RKNN_TENSOR_NCHW</i> <i>RKNN_TENSOR_NHWC</i> |
| type | rknn_tensor_type | The data type of tensor, as follows: <i>RKNN_TENSOR_FLOAT32</i> <i>RKNN_TENSOR_FLOAT16</i> <i>RKNN_TENSOR_INT8</i> <i>RKNN_TENSOR_UINT8</i> <i>RKNN_TENSOR_INT16</i> |
| qnt_type | rknn_tensor_qnt_type | The quantization type of tensor, ds: |

| | | |
|-------|----------|--|
| | | <p><i>RKNN_TENSOR_QNT_NONE:</i></p> <p>none quantization.</p> <p><i>RKNN_TENSOR_QNT_DFP:</i></p> <p>Dynamic fixed-point quantization.</p> <p><i>RKNN_TENSOR_QNT_AFFINE_ASYMMETRIC:</i></p> <p><i>C:</i></p> <p>Asymmetric affine quantization.</p> |
| fl | int8_t | Fractional length for <i>RKNN_TENSOR_QNT_DFP</i> . |
| zp | uint32_t | Zero point for <i>RKNN_TENSOR_QNT_AFFINE_ASYMMETRIC</i> . |
| scale | float | Scale for <i>RKNN_TENSOR_QNT_AFFINE_ASYMMETRIC</i> . |

3.2.3 rknn_input

The structure *rknn_input* represents an input data of model, used as a parameter to the *rknn_inputs_set* function. The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|--------------|-----------|---|
| index | uint32_t | The index of input tensor. |
| buf | void* | The buffer point of input data. |
| size | uint32_t | The memory size of input data buffer. |
| pass_through | uint8_t | <p>The pass-through mode of input.</p> <p>TRUE: The input data is passed directly to the input node of rknn model without any conversion, therefore the following <i>type</i> and <i>fmt</i> do not need to be set.</p> <p>FALSE: The input data will convert to the same</p> |

| | | |
|------|--------------------|---|
| | | data type and format as the input node of the rknn mode according to the following <i>type</i> and <i>fmt</i> , therefore the following <i>type</i> and <i>fmt</i> need to be set. |
| type | rknn_tensor_type | The data type of input tensor, as follow: <i>RKNN_TENSOR_FLOAT32</i> <i>RKNN_TENSOR_FLOAT16</i> <i>RKNN_TENSOR_INT8</i> <i>RKNN_TENSOR_UINT8</i> <i>RKNN_TENSOR_INT16</i> |
| fmt | rknn_tensor_format | The dimension format of input tensor, as follow: <i>RKNN_TENSOR_NCHW</i> <i>RKNN_TENSOR_NHWC</i> |

3.2.4 rknn_output

The structure *rknn_output* represents an output data of the model, used as a parameter to the *rknn_outputs_get* function. The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|-------------|-----------|--|
| want_float | uint8_t | Identifies whether the output data needs to be converted to float32 type. |
| is_prealloc | uint8_t | Identifies whether the buffer that holds the output data is pre-allocated. |
| index | uint32_t | The index of output tensor. |
| buf | void* | The buffer pointer of output. |
| size | uint32_t | The memory size of output data buffer. |

When the *is_prealloc* is FALSE, the *index/buf/size* of *rknn_output* will be set after *rknn_outputs_get* is called, therefore the three members do not need to be pre-set.

When the *is_prealloc* is TRUE, the *index/buf/size* of *rknn_output* need to be set before calling *rknn_outputs_get*, otherwise the *rknn_outputs_get* function will fail with an error.

3.2.5 rknn_perf_detail

The structure *rknn_perf_detail* represents the performance details of rknn model. The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|-----------|-----------|--|
| perf_data | char* | Contains the running time of each layer of the network, can be printed directly for viewing. |
| data_len | uint64_t | The string length of <i>perf_data</i> . |

3.2.6 rknn_perf_run

The structure *rknn_perf_run* represents the execution time of a single inference of rknn model.

The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|--------------|-----------|--|
| run_duration | int64_t | The hardware execution time of a single inference of rknn model. |

3.2.7 rknn_run_extend

The structure *rknn_run_extend* represents the extended information of *rknn_run*, used as parameter to *rknn_run* function.

The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|----------|-----------|---|
| frame_id | uint64_t | Used to get the frame id after the <i>rknn_run</i> function is called. The <i>frame_id</i> corresponds to <i>rknn_output_extend.frame_id</i> one by one, In the |

| | | |
|--|--|---|
| | | case where <i>rknn_run</i> and <i>rknn_outputs_get</i> are in different threads, it can be used to determine the correspondence of frame. |
|--|--|---|

3.2.8 rknn_output_extend

The structure *rknn_output_extend* represents the extend information of *rknn_outputs_get*, used as parameter to *rknn_outputs_get* function. The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|----------|-----------|--|
| frame_id | uint64_t | Used to get the frame id after the <i>rknn_outputs_get</i> function is called. The <i>frame_id</i> corresponds to <i>rknn_run_extend.frame_id</i> one by one, In the case where <i>rknn_run</i> and <i>rknn_outputs_get</i> are in different threads, it can be used to determine the correspondence of frame. |

3.2.9 rknn_sdk_version

The structure *rknn_sdk_version* represents the version information of RKNN SDK. The following table shows the definition of the structure:

| Field | Data Type | Meaning |
|-------------|-----------|--|
| api_version | char[] | The version of RKNN API. |
| drv_version | char[] | The driver version on which RKNN API is based. |

3.2.10 Error Code

The return error code of RKNN API. The following table shows the definition:

| Error Code | Meaning |
|------------|--------------------------|
| RKNN_SUCC | Execution is successful. |

| | |
|-----------------------------|---------------------------------------|
| RKNN_ERR_FAIL | Execution is failed. |
| RKNN_ERR_TIMEOUT | Execution timeout. |
| RKNN_ERR_DEVICE_UNAVAILABLE | The NPU device is unavailable. |
| RKNN_ERR_MALLOC_FAIL | Memory allocation is failed. |
| RKNN_ERR_PARAM_INVALID | The parameter is invalid. |
| RKNN_ERR_MODEL_INVALID | The RKNN model is invalid. |
| RKNN_ERR_CTX_INVALID | The rknn_context is invalid. |
| RKNN_ERR_INPUT_INVALID | The object of rknn_input is invalid. |
| RKNN_ERR_OUTPUT_INVALID | The object of rknn_output is invalid. |
| RKNN_ERR_DEVICE_UNMATCH | The device version does not match. |

3.3 RKNN API Basic Call Flow

- 1) Load the file of rknn model into memory, the file of rknn model is a model file with the rknn suffix generated by the RKNN-Toolkit that described above, such as *mobilenet_v1-tf.rknn*.
- 2) Call the *rknn_init* to initialize the context and load the rknn model, code is as follows:

```
rknn_context ctx = 0;
ret = rknn_init(&ctx, model, model_len, RKNN_FLAG_PRIOR_MEDIUM);
if(ret < 0) {
    printf("rknn_init fail! ret=%d\n", ret);
    goto Error;
}
```

The *ctx* is the context object; the *model* is the pointer of rknn model in memory; the *model_len* is size of model; the *RKNN_FLAG_PRIOR_MEDIUM* is the priority flag.

- 3) The attributes of input/output of rknn model may be different from the original model (pb or caffe), so you need to get the new attributes of input/output through *rknn_query* function, as

follows:

```
rknn_input_output_num io_num;
ret = rknn_query(ctx, RKNN_QUERY_IN_OUT_NUM, &io_num, sizeof(io_num));
if(ret < 0) {
    printf("rknn_query fail! ret=%d\n",ret);
    goto Error;
}
```

The above code used to get the number of input and output, the number will store in *io_num.n_input* and *io_num.n_output*.

Next get the attribute of output:

```
rknn_tensor_attr output0_attr;
output0_attr.index = 0;
ret = rknn_query(ctx, RKNN_QUERY_OUTPUT_ATTR, &output0_attr,
sizeof(output0_attr));
if(ret < 0) {
    printf("rknn_query fail! ret=%d\n",ret);
    goto Error;
}
```

The above code used to get the attribute of an output, remember to set the index of *rknn_tensor_attr* (the index cannot be greater than or equal to the number of outputs that obtained earlier).

Obtaining an input attribute method is similar to getting the output attribute method.

- 4) Call *rknn_input_set* to set the inputs according to the input parameter/format of rknn model, code is as follows:

```
rknn_input inputs[1];
inputs[0].index = input_index;
inputs[0].buf = img.data;
inputs[0].size = img_width * img_height * img_channels;
inputs[0].pass_through = FALSE;
inputs[0].type = RKNN_TENSOR_UINT8;
inputs[0].fmt = RKNN_TENSOR_NHWC;
ret = rknn_inputs_set(ctx, 1, inputs);
if(ret < 0) {
    printf("rknn_input_set fail! ret=%d\n", ret);
    goto Error;
}
```

First create an array of *rknn_input* (here assumes that there is only one input, so the array size is set to 1), then fill each member of each array item:

inputs[0].index Index of input node.

inputs[0].buf Buffer pointer that can be accessed by cpu, generally pointer to image data that generated by camera, such as RGB888 data.

inputs[0].size The size of buffer.

inputs[0].pass_through Pass-through mode:

TRUE: If the attributes (mainly *type*, *fmt* and the quantization parameter) of input data are consistent with the input attributes obtained by the *rknn_query*, then the *pass_through* can be set to TRUE, and the following *type* and *fmt* don't need to be set. In this mode, *rknn_inputs_set* will pass the input data directly to the input node of rknn model. This mode is used by user to know the input attribute of the rknn model, and has converted the original input data to the data that consistent with the rknn model input.

FALSE: If the attributes (mainly *type*, *fmt* and the quantization parameter) of input data are inconsistent with the input attributes obtained by the *rknn_query*, then the *pass_through* needs to be set to FALSE, and the following *type* and *fmt* also need to be set by user. In this mode, the *rknn_inputs_set* function will perform type and format conversion and quantization processing automatically. Note that this mode

does not support dynamic fixed point (DFP) or asymmetric affine (AFFINE ASYMMETRIC) input data passed by user.

`inputs[0].type` Data type of buffer, if it is RGB888 data, then set to `RKNN_TENSOR_UINT8`.

`inputs[0].fmt` Data format of buffer, that is NHWC or NCHW, the data format that obtained by camera is generally `RKNN_TENSOR_NHWC`.

- 5) Call `rknn_run` to trigger the inference operation after the input parameter was set. The function will return immediately (but when there are more than 3 inference results not obtained by `rknn_outputs_get`, the `rknn_run` will block until the `rknn_outputs_get` is called). Code is as follows:

```
ret = rknn_run(ctx, NULL);
if(ret < 0) {
    printf("rknn_run fail! ret=%d\n", ret);
    goto Error;
}
```

- 6) Now you can call `rknn_outputs_get` to wait for the inference to complete after `rknn_run` is called, the `rknn_outputs_get` will block until the inference is completed, and then the inference results can be obtained. Code is as follows:

```
rknn_output outputs[1];
outputs[0].want_float = TRUE;
outputs[0].is_prealloc = FALSE;
ret = rknn_outputs_get(ctx, 1, outputs, NULL);
if(ret < 0) {
    printf("rknn_outputs_get fail! ret=%d\n", ret);
    goto Error;
}
```

First create the array of `rknn_output` (assume there is only one output, so the size of array set to 1). The first two members of `rknn_output` need to be set, namely `outputs[0].want_float`

and *outputs[0].is_prealloc*.

want_float: Since the output type of the rknn model may be inconsistent with the output type of the original model. In general, the output type of rknn model is UINT8 or FP16 (the output specific attribute of rknn model can be obtained by *rknn_query*). If the user wants to obtain the FP32 output data, the **want_float** can be set to TRUE; If the user wants to get the raw output data of rknn model, set it to FALSE.

is_prealloc = FALSE: If the user does not pre-allocate the buffer of each output, the *is_prealloc* flag can be set to FALSE, and the remaining member of *outputs[0]* do not need to be set. The inference results will be stored in *output[0]* after *rknn_outputs_get* returned, the results contain:

| | |
|-------------------------|---|
| <i>outputs[0].index</i> | Index of output node. |
| <i>outputs[0].buf</i> | Buffer pointer that store inference result. |
| <i>outputs[0].size</i> | Size of buffer. |

In addition, the other attribute of inference result of *output[0]* can be obtained by *rknn_query*. It should be noted that the *outputs[0].buf* is automatically released when the *rknn_output_release* is called, so there is no need to free it by user.

is_prealloc = TRUE: If the user has pre-allocate the buffer of each output, the *is_prealloc* flag can be set to TRUE, and the remaining member of *output[0]* also need to be set Code is as follows:

```
rknn_output outputs[1];
outputs[0].want_float = TRUE;
outputs[0].is_prealloc = TRUE;
outputs[0].index = 0;
outputs[0].buf = output0_buf;
outputs[0].size = output0_attr.n_elems * sizeof(float);
ret = rknn_outputs_get(ctx, 1, outputs, NULL);
if(ret < 0) {
    printf("rknn_outputs_get fail! ret=%d\n", ret);
    goto Error;
}
```

The remaining member of *output[0]* is:

outputs[0].index Index of output node. The user needs to specify the index of the output, and the index must be smaller than the number of outputs of rknn model. (the number of outputs of rknn model can be obtained by *rknn_query*.)

outputs[0].buf Buffer pointer for store inference result. The buf need to be pre-created by user.

outputs[0].size Size of buffer. The size needs to be calculated according to the corresponding output attribute and the ***want_float*** flag.

When ***want_float*** is FALSE, the **size** equal to the *output0_attr.size*;

When ***want_float*** is TRUE, the **size** equal to:

*output0_attr.n_elems * sizeof(float).*

(*output0_attr* is attribute of output 0 that obtained by *rknn_query*.)

After the *rknn_outputs_get* is returned, the inference result of corresponding index will be stored in the *output[0].buf*, since the buf is created by user, so the user needs to free it to avoid memory leak when it is no longer needed.

- 7) When all the outputs obtained by *rknn_outputs_get* are no longer needed, you need to call *rknn_outputs_release* to release the outputs, otherwise it will cause a memory leak. Code is as follows:

```
rknn_outputs_release(ctx, 1, outputs);
```

The way of passing parameter is similar to *rknn_outputs_get*.

It should be noted that whether the *rknn_output[x].is_prealloc* is TRUE or FALSE, this function needs to be called to release the output finally.

- 8) If you need to make multiple inferences, you can jump back to step 4 for next inference.
- 9) When the program needs to exit, you need to call *rknn_destroy* to unload model and destroy the context, code is as follows:

```
rknn_destroy(ctx);
```

For more detailed code, please refer to the file of API SDK under the Linux directory:

<Linux>/rknn_api_sdk/rknn_mobilenet.cpp

<Linux>/rknn_api_sdk/rknn_ssd.cpp

or under the Android directory:

<Android>/rk_ssd_demo/app/src/main/jni/ssd_image.cc

4 Demo Instructions

4.1 Linux Demo

4.1.1 Compilation Instructions

Two demos using RKNN API are provided in Linux directory of API SDK, one is image classifier demo based on MobileNet, the other is object detection demo based on SSD.

Enter the <Linux>/rknn_api_sdk directory, the main source file for these two demos is

<rknn_api_sdk>/rknn_mobilenet.cpp and <rknn_api_sdk>/rknn_ssd.cpp, the specific compile method is as follows:

- 1) Install the cross-compilation tool:

```
sudo apt install gcc-aarch64-linux-gnu  
sudo apt install g++-aarch64-linux-gnu
```

- 2) `cd rknn_api_sdk; mkdir build; cd build; cmake ..`

- 3) `make`

You can get *rknn_mobilenet* and *rknn_ssd* executable file in <rknn_api_sdk>/build/ after the make is finished.

Note: Currently the demo is only available for the RK3399Pro Linux 64-bit system, so only 64-bit rknn api library is provided. The compilation is verified on the Ubuntu 16.04 64-bit system.

4.1.2 Run Instructions

For running the *rknn_mobilenet* and *rknn_ssd*, you need to copy the dependencies library to <RK3399Pro Root>/usr/lib64/ and copy the relevant resource files to the <RK3399Pro Root>/tmp directory. The specific steps are as follows:

- 1) Copy the contents in the <Linux>/rknn_api_sdk/3rdparty/opencv/lib64 directory and <Linux>/rknn_api_sdk/rknn_api/lib64 directory to the /usr/lib64/ directory on the RK3399Pro target board.
- 2) Copy the contents in the <Linux>/tmp/ directory of the API SDK package to the /tmp/ directory of the RK3399Pro target board.
- 3) Copy the *rknn_mobilenet* and *rknn_ssd* compiled in <Linux>/rknn_api_sdk/build directory to the /tmp/ directory of the RK3399Pro target board.
- 4) Go to the /tmp directory of the RK3399Pro target board to execute:

```
./rknn_mobilenet
```

After the execution is successful, it will print the execution time and results.

Go to the `/tmp` directory of the RK3399Pro target board to execute:

```
./rknn_ssd
```

After the execution is successful, it will print the execution time and results. At the same time, the image `out.jpg` containing the detection result will be generated in the `/tmp` directory of the RK3399Pro target board, you can export the `out.jpg` to view the detection result.

4.2 Android Demo

4.2.1 Compilation Instructions

There are `<Android>/rknn_api` directory and `<Android>/rk_ssd_demo` directory under the Android directory of API SDK.

`rknn_api` directory:

If you want to use RKNN API directly to develop your own JNI library, the JNI library can include the `<Android>/rknn_api/include/rknn_api.h` and `<Android>/rknn_api/lib(64)/librknn_api.so` to call RKNN API.

`rk_ssd_demo` directory:

The directory is an object detection demo based on the SSD using RKNN API. The demo contains the java and JNI parts. The JNI directory is `<Android>/rk_ssd_demo/app/src/main/jni`, the `rknn_api.h` header file and the `librknn_api.so` library file are already included in the JNI directory.

The specific compilation method of `rk_ssd_demo` is as follows:

- 1) Enter the `<Android>/rk_ssd_demo` directory, and open the project file by Android Studio.
- 2) Build and generate apk (need NDK support, verified on `android-ndk-r16b`).

4.2.2 Run Instructions

Run the apk directly on Android of RK3399Pro. (The demo needs an onboard camera or an external USB camera support.)

5 Appendix

5.1 API Migration Instructions

Since the API changes made from v0.9.1 to v0.9.2 are relatively large, users can migrate the codes according to the following migration steps and the above API description. The general steps are as follows:

- 1) Since the definition of the context handle is changed from *int* type to the *rknn_context* type, so the context variable and the use of *rknn_init* are slightly changed. The codes can be modified from:

```
int ret = 0;
int ctx = rknn_init(model, model_len, RKNN_FLAG_PRIOR_MEDIUM);
if(ctx < 0) {
    printf("rknn_init fail! ret=%d\n", ctx);
    goto Error;
}

...

if(ctx >= 0)      rknn_destroy(ctx);
```

To:

```
int ret = 0;
rknn_context ctx = 0;
ret = rknn_init(&ctx, model, model_len, RKNN_FLAG_PRIOR_MEDIUM);
if(ret < 0) {
    printf("rknn_init fail! ret=%d\n", ret);
    goto Error;
}

...

if(ctx)          rknn_destroy(ctx);
```

Note: Parts in red are changed.

- 2) Since the *rknn_input_set* function needs to support data types and formats other than *INT8*, so

the definition of function has also been adjusted. The codes can be modified from:

```
ret = rknn_input_set(ctx, input_index, img.data, img_width * img_height * img_channels,
RKNN_INPUT_ORDER_012);
if(ret < 0) {
    printf("rknn_input_set fail! ret=%d\n", ret);
    goto Error;
}
```

To:

```
rknn_input inputs[1];
inputs[0].index = input_index;
inputs[0].buf = img.data;
inputs[0].size = img_width * img_height * img_channels;
inputs[0].pass_through = false;
inputs[0].type = RKNN_TENSOR_UINT8;
inputs[0].fmt = RKNN_TENSOR_NHWC;
ret = rknn_inputs_set(ctx, 1, inputs);
if(ret < 0) {
    printf("rknn_input_set fail! ret=%d\n", ret);
    goto Error;
}
```

Note: Parts in **red** are changed. In addition, the parameter *RKNN_INPUT_ORDER_012* does not need to be used, and the *rknn_inputs_set* also has an additional **s**.

- 3) The *rknn_outputs_get* and *rknn_output_to_float* function are merged in v0.9.2, and added a new way to use the memory, so the change is great. The codes can be modified from:

```
int h_output = -1;
struct rknn_output outputs[2];
h_output = rknn_outputs_get(ctx, 2, outputs, nullptr);
if(h_output < 0) {
    printf("rknn_outputs_get fail! ret=%d\n", ret);
    goto Error;
}
```

To:


```
rknn_output outputs[2];
outputs[0].want_float = true;
outputs[0].is_prealloc = false;
outputs[1].want_float = true;
outputs[1].is_prealloc = false;
ret = rknn_outputs_get(ctx, 2, outputs, nullptr);
if(ret < 0) {
    printf("rknn_outputs_get fail! ret=%d\n", ret);
    goto Error;
}
```

Note: Parts in **red** are changed. The number of outputs above is 2 for example, and other models can be modified based on actual conditions.

- 4) Since the *rknn_outputs_get* has merged the functions of *rknn_output_to_float* (that is the *want_float* flag above), so the call step of *rknn_output_to_float* can be removed. The codes can be modified from:

```
float *predictions = (float*)(outputs[0].buf);
if(outputs_attr[0].type != RKNN_TENSOR_FLOAT32) {
    predictions = (float*)malloc(output_size1);
    rknn_output_to_float(ctx, outputs[0], (void*)predictions, output_size1);
}
float *outputClasses = (float*)(outputs[1].buf);
if(outputs_attr[1].type != RKNN_TENSOR_FLOAT32) {
    outputClasses = (float*)malloc(output_size2);
    rknn_output_to_float(ctx, outputs[1], (void*)outputClasses, output_size2);
}

...

if(outputs_attr[0].type != RKNN_TENSOR_FLOAT32) {
    free(predictions);
}
if(outputs_attr[1].type != RKNN_TENSOR_FLOAT32) {
    free(outputClasses);
}
```

To:

```
float *predictions = (float*)(outputs[0].buf);
float *outputClasses = (float*)(outputs[1].buf);
```

Note: Parts in **red** are changed. The above is based on the post-processing of SSD, and other models can be modified based on actual conditions.

- 5) Because the above *want_float* is set to True when *rknn_outputs_get* is called, so the value of *outputs[x].size* may be inconsistent with the value of *outputs_attr[x].size* that queried by *rknn_query*, therefore the judgement condition that judges whether *output[x].size* is consistent with the attribute of query needs to be modified. The codes can be modified from:

```
// Process output
if(outputs[0].size == outputs_attr[0].size && outputs[1].size == outputs_attr[1].size)
{
    ...
}
```

To:

```
// Process output
if(outputs[0].size == outputs_attr[0].n_elems*sizeof(float) && outputs[1].size ==
outputs_attr[1].n_elems*sizeof(float))
{
    ...
}
```

Note: Parts in **red** are changed. The number of outputs above is 2 for example, and other models can be modified based on actual conditions.

- 6) The use of *rknn_outputs_release* has also been adjusted, the way of parameter are passed consistent with the *rknn_outputs_get* (the *h_output* does not need to use). The codes can be modified from:

```
rknn_outputs_release(ctx, h_output);
```

To:

```
rknn_outputs_release(ctx, 2, outputs);
```

Note: Parts in **red** are changed.