



Course Title: Working with Qemu

Faculty: Rajesh Sola, Dr. Vivek Kaundal, Bharath G & Bhargav N



L&T Technology Services



LTTS

GLOBAL
ENGINEERING
ACADEMY



Agenda



Setting up Qemu

Building Custom Kernel

Cross Compilation Techniques

Bootimg Techniques

Version

Version	Reviewed by	Approved by	Remarks
1.0			





Qemu Based Emulation



Clean Workspace

- “ Choose a clean directory for all the work,
- “ You may choose directory like workspace/eworkspace/kworkspace/ebuildws/ews or with any sensible name under home directory
- “ Don't use Desktop, Downloads, Documents, Music, Videos, Pictures etc, which are meant for other purpose.
- “ Avoid spaces or special symbols in path names
- “ Under this workspace keep different sub directories for downloaded packages, extracted source to build, configuration files, examples etc.

Setup Qemu

// Install Qemu, a full system emulator for ARM target architecture

```
sudo apt install qemu-system-arm
qemu-system-arm -v
qemu-system-arm -M ?
qemu-system-aarch64 -v
```

// Alternative – Build from sources

```
Download latest stable version of Qemu source from
https://www.qemu.org/download/#source
tar -xvf qemu-5.x.y.tar.xz # replace 5.x.y by suitable version
cd qemu-5.x.y
./configure --targetlist=armsoftmmu, armlinuxuser
                                     --enable-sdl  --prefix=/opt/qemu-5.x.y
make && make install
export PATH=/opt/qemu-4.x.y/bin:$PATH # you may add this to ~/.bashrc
```

Rootfs

// Download core-image-minimal-qemuarm.ext4 from

<http://downloads.yoctoproject.org/releases/yocto/yocto-2.5/machines/qemu/qemuarm/>

// Rename core-image-minimal-qemuarm.ext4 as rootfs.img

// Align the size of rootfs

```
e2fsck -f rootfs.img  
resize2fs rootfs.img 16M
```

// Alternative

```
# Download core-image-minimal-qemuarm.tar.bz2 from same link  
qemu-img create -f raw rootfs.img 64M  
mkfs.ext4 rootfs.img  
mount -o loop,rw,sync rootfs.img /mnt/image # mkdir for first time  
tar -jxvf core-image-minimal-qemuarm.tar.bz2 -C /mnt/image  
umount /mnt/image
```

Toolchain

// Install linaro toolchain from ubuntu package manager

```
sudo apt install gcc-arm-linux-gnueabi          # soft float
sudo apt install gcc-arm-linux-gnueabihf        # hard float
```

// We'll go for soft float for now, due rootfs compatability

// Alternatively, download latest pre-built linaro toolchain from as per host architecture

// From <https://releases.linaro.org/components/toolchain/binaries/latest-7/arm-linux-gnueabi/>, say v7.5.0

```
tar -xvf gcc-linaro-7.5.0-2019.12-x86_64_arm-linux-gnueabi.tar.xz -C /opt
export PATH=/opt/gcc-linaro-linux-gnueabi-7.5.0-2019.12_linux/bin:$PATH
```

// Similarly gcc-linaro-7.5.0-2019.12-x86_64_arm-linux-gnueabihf.tar.xz for hard float

Your First Boot (Emulation)

- // Collect prebuilt zImage, vexpress-v2p-ca9.dtb from faculty
- // Ensure rootfs.img is also in same location
- // Emulate using Qemu – sdcard approach

```
qemu-system-arm -M vexpress-a9 -m 1024 -serial stdio \  
-kernel zImage -dtb vexpress-v2p-ca9.dtb \  
-sd rootfs.img -append "console=ttyAMA0 root=/dev/mmcblk0 rw"
```

- // Emulate using Qemu – initrd approach

```
qemu-system-arm -M vexpress-a9 -m 1024 -serial stdio \  
-kernel zImage -dtb vexpress-v2p-ca9.dtb \  
-initrd rootfs.img -append "console=ttyAMA0 root=/dev/ram0 rw"
```

First Steps on Target

```
uname -r  
uname -v  
uname -a  
cat /proc/cpuinfo  
free -m  
df -kh  
mount  
dmesg
```

Building Custom Kernel (Qemu)



Download Kernel Source

- // Download any recent LTS version of kernel source
- // Let's go with 4.14.x for now, for better compatibility with Qemu

```
wget https://cdn.kernel.org/pub/linux/kernel/v4.x/linux-4.14.202.tar.xz  
tar -xvf linux-4.14.202.tar.xz
```

- // Or you can checkout kernel source from git.kernel.org, and switch to desired branch

```
git clone https://git.kernel.org/pub/scm/linux/kernel/git/torvalds/linux.git  
cd linux  
git checkout tags/v4.14 -b v4.14
```

- // Let's call extracted content (or) checked out content as KSRC

Obtain Configuration File

- “ Locate default config available in KSRC/arch/arm/configs, we'll refer vexpress_defconfig for Versatil Express target being used for Qemu emulation
- “ Or collect any well tested configuration file as base config

```
make ARCH=arm mrproper  
make ARCH=arm vexpress_defonfig  
(or)  
# copy custom config file as .config under KSRC
```

- “ Please note that mrproper will remove built files, including the configuration. So run this only for any new build.

Further Customization

- // Run menuconfig for further customization
- // Resolve any host dependencies at this stage, e.g. libncurses5-dev, flex, bison etc.

```
make ARCH=arm menuconfig
```

- // Let's do these minimal changes for now
 - // General Setup -> Local Version -> "-custom"
 - // Device Drivers -> Block Devices ->
 - // Enable RAM Block device support
 - // Increase default RAM disk size to suitable limit, say 65536
 - // Enable the block layer
 - // Support for large (2TB+)

Build the kernel

// Run menuconfig for further customization

// Build kernel image

```
make ARCH=arm CROSS_COMPILE=arm-linux-gnueabi- zImage -j <n>
```

// Build Device Tree Binaries

```
make ARCH=arm CROSS_COMPILE=arm-linux-gnueabi- dtbs firmware
```

// Build dynamic modules (can skip for now)

```
make ARCH=arm CROSS_COMPILE=arm-linux-gnueabi- modules  
make ARCH=arm CROSS_COMPILE=arm-linux-gnueabi- modules_install \  
INSTALL_MOD_PATH=<tempdir> # or mount point of target rootfs
```

Test the Built outcome

// Collect built outcome to a temporary location

```
# switch to KSRC
cp $KSRC/arch/arm/boot/zImage      <path-of-temp-boot-dir>
cp $KSRC/arch/arm/boot/dts/*.dtb  <path-of-temp-boot-dir>
```

// Ensure rootfs.img is also in same location

// Emulate using Qemu

```
qemu-system-arm -M vexpress-a9 -m 1024 -serial stdio \
    -kernel zImage -dtb vexpress-v2p-ca9.dtb \
    -sd rootfs.img -append "console=ttyAMA0 root=/dev/mmcblk0 rw"
```


In Target

uname -r

uname -v

ls /boot # observe new entry

ls /lib/modules # observe new entry

In Host

ls -lh \$KSRC/arch/arm/boot/zImage

ls -lh \$KSRC/vmlinux



Cross Compiling Code



Simple Hello Hello Module

```
#include<stdio.h>
```

```
int main() {  
    printf("Hello World\n");  
    return 0;  
}
```

```
arm-linux-gnueabi-gcc hello.c -o h1.out
```

```
arm-linux-gnueabi-gcc hello.c -o h2.out -o static
```

```
file h1.out h2.out
```

```
ls -lh h1.out h2.out
```

```
ldd h1.out
```

```
ldd h2.out
```

```
# copy h1.out, h2.out to target rootfs
```

```
sudo mount -o loop,rw.sync rootfs.img /mnt/rootfs
```

```
sudo cp h1.out h2.out /mnt/rootfs/home/root
```

```
sudo umount /mnt/rootfs
```

Multifile Programming

```
//test.c
int main() {
    int a,b,c,d;
    a=10,b=20;
    c=sum(a,b);
    d=square(a);
    //print c,d
}
```

```
//sum.c
int sum(int x,int y)
{
    return x + y;
}
```

```
//sqr.c
int square(int x)
{
    return x * x;
}
```

```
arm-linux-gnueabi-gcc test.c -c
arm-linux-gnueabi-gcc sum.c -c
arm-linux-gnueabi-gcc sqr.c -c
arm-linux-gnueabi-gcc test.o sum.o sqr.o \
                        -o all.out
# copy all.out to target rootfs and test
```

TODO:- Write a Makefile for above steps

Static Library

```
# prepare the source code and generate .o files as earlier
arm-linux-gnueabi-ar sum.o sqr.o -o libsample.a
```

```
arm-linux-gnueabi-gcc -L. test.o -lsample -o s1.out
arm-linux-gnueabi-gcc -L. test.o -lsample -o s2.out -static
# copy s1.out, s2.out to target rootfs and test
```

```
file s1.out s2.out
# compare size of s1.out, s2.out
ldd s1.out s2.out
```

```
# check size of s2.out before strip
arm-linux-gnueabi-strip s2.out
# check size of s2.out after strip
```

- ☐ Do .a file to be shipped along with executable.
- ☐ Can we use [nm](#), [objdump](#) on stripped executable?
- ☐ What if .a file is in one directory and test.o is in other directory?
- ☐ Necessary support from toolchain for static linking of std libraries
- ☐ Write a Makefile for above steps

Dynamic Linking

On Host

```
arm-linux-gnueabi-gcc -shared libsample.so sum.o sqr.o
```

```
arm-linux-gnueabi-gcc -L. test.o -lsample -o d1.out
```

copy libsample.so, d1.out to target rootfs and execute

On Target

```
LD_LIBRARY_PATH=. ./d1.out
```

file d1.out

check size of d1.out

```
ldd d1.out
```

- ☐ Do .so file to be shipped along with executable.
- ☐ What if .so file is in one directory and test.o is in other directory on host?
- ☐ What if .so file is one directory and d1.out is in other directory on target.
- ☐ Usage of LD_LIBRARY_PATH environment variable.
- ☐ Significance of /etc/ld.so.conf entries and ldconfig command
- ☐ Write a Makefile for all the steps

Versioned so files

On Host

```
arm-linux-gnueabi-gcc -shared -Wl,-soname,libsample.so \
    -o libsample.so.1.0.1 sum.o sqr.o
ln -s libsample.so.1.0.1 libsample.so
arm-linux-gnueabi-gcc -L. test.o -lsample -o d1.out
# copy d1.out to target rootfs
# copy libsample.so.1.0.1 to /mnt/rootfs/opt/mylibs
# add an entry to /opt/mylibs in /mnt/rootfs/etc/ld.so.conf
```

On Target

```
ls /opt/mylibs./d1.out # will give error initially
Ldconfig
./d1.out
ls /opt/mylibs          # observer generated symlink
```

Working with U-Boot



U-Boot Sources

- // Download tarball from <ftp://ftp.denx.de/pub/u-boot/> and extract, choose any stable version like [u-boot-2020.10.tar.bz2](#)
- // Let's call the cloned/extracted source as USRC
- // Alternative:-
 - // Checkout U-Boot source from <https://gitlab.denx.de/u-boot/u-boot>
 - // Switch to any stable branch like v2020.10
- // You may also download offline tarball from [gitlab.denx.de](https://gitlab.denx.de/u-boot/u-boot)

Cross Building

```
make ARCH=arm vexpress_ca9x4_defconfig  
make ARCH=arm CROSS_COMPILE=arm-linux-gnueabi-  
# Locate generated u-boot and copy to a tempdir
```

Simple Boot – Rootfs in SD Card

```
qemu-img create simplesd.img 64M
sudo mkfs.vfat simplesd.img
sudo mount -o loop,rw,sync simplesd.img /mnt/sdcard
# copy zImage, vexpress-v2p-ca9.dtb, rootfs.img to /mnt/sdcard
umount /mnt/sdcard
# copy simplesd.img to tempdir, where generated u-boot is copied
```

```
qemu-system-arm -M vexpress-a9 -m 1024 -serial stdio -kernel u-boot -sd sdcard.img
# Stop autoboot by hitting any key, Run the following commands in U-Boot shell
mmcinfo fatls mmc 0:0
fatload mmc 0:0 0x60200000 zImage
fatload mmc 0:0 0x60100000 vexpress-v2p-ca9.dtb
fatload mmc 0:0 0x62000000 rootfs.img
setenv bootargs 'console=ttyAMA0 root=/dev/ram0 rw rootfstype=ext4
                 initrd=0x62000000, 16777216'
bootz 0x60200000 - 0x60100000
# 16777216 is size of loaded rootfs image
# for this method ramdisk support should be enabled at kernel level (menuconfig --> Device Drivers
--> Block Devices --> RAM Block Device Support)
```

Prepare Partitioned SD Card

```
dd if=/dev/zero of=sdcard.img bs=1M count=128
# create two primary partitions in sdcard.img using cfdisk
# Keep first partition size as small as possible, say 16M
sudo fdisk -l sdcard.img # 1048576 is 2048x512, 2048 is start of first
partition # 17825792 is 34816x512, 34816 is start of second partition
sudo losetup -o 1048576 /dev/loop20 sdcard.img
sudo losetup -o 17825792 /dev/loop21 sdcard.img
sudo mkfs.vfat /dev/loop20 sudo mkfs.ext4 /dev/loop21
sudo mount -o loop,rw,sync /dev/loop20 /mnt/boot
sudo mount -o loop,rw,sync /dev/loop21 /mnt/rootfs
#copy zImage, vexpress-v2p-ca9.dtb to /mnt/boot
# extract core-image-minimal-qemuarm.tar.bz2 to /mnt/rootfs
tar -jxvf core-image-minimal-qemuarm.tar.bz2 -C /mnt/rootfs
sudo umount /mnt/boot
sudo umount /mnt/rootfs
sudo losetup -d /dev/loop20
sudo losetup -d /dev/loop21
```

Rootfs in partitioned SD Card

```
qemu-system-arm -M vexpress-a9 -m 1024 -serial stdio -kernel u-boot -sd sdcard.img
#Stop autoboot by hitting any key, Run the following commands in U-Boot shell
mmcinfo
Fatls mmc 0:1
fatload mmc 0:1 0x60200000 zImage
fatload mmc 0:1 0x60100000 vexpress-v2p-ca9.dtb
setenv bootargs 'console=ttyAMA0 root=/dev/mmcblk0p2 rw rootfstype=ext4'
bootz 0x60200000 - 0x60100000
```

Setup TFTP on Host

```
sudo apt install tftpd
# create /etc/xinetd.d/tftp
# with specified content
# replace server_args as per your machine
/etc/init.d/xinetd restart
```

```
service tftp
{
    protocol          = udp
    port              = 69
    socket_type       = dgram
    wait              = yes
    user              = nobody
    server             = /usr/sbin/in.tftpd
    server_args       = /* */
    disable            = no
}
```

```
sudo modprobe tun
sudo ifconfig tap0 192.168.0.1
```

TFTP Boot on Target

```
sudo qemu-system-arm -M vexpress-a9 -m 256 -kernel u-boot -serial stdio \  
-sd sdcard.img -net nic -net tap,ifname=tap0
```

```
setenv ipaddr 192.168.0.2  
setenv serverip 192.168.0.1  
ping 192.168.0.1  
tftp 0x60200000 zImage  
tftp 0x60100000 vexpress-v2p-ca9.dtb  
setenv bootargs 'console=ttyAMA0 root=/dev/mmcblk0p2 rootfstype=ext4'  
bootz 0x60200000 - 0x60100000
```



Thank You !



L&T Technology Services

