

Si4735 Arduino Library

AUTHOR
Version 1.1.8
02/04/2020

Table of Contents

Table of contents

Deprecated List

Global [SI4735::analogPowerUp](#) (void)

Consider use radioPowerUp instead

Module Index

Modules

Here is a list of all modules:

Deal with Interrupt.....	1
Deal with Interrupt and I2C bus.....	1
Host and slave MCU setup.....	54
RDS Data types.....	58
Receiver Status and Setup.....	65
SI473X data types.....	69
SI47XX device Mode, Band and Frequency setup.....	75
SI47XX device information and start up.....	81

File Index

File List

Here is a list of all files with brief descriptions:

SI4735/SI4735.cpp	83
SI4735/SI4735.h	83

Module Documentation

Deal with Interrupt

Detailed Description

Deal with Interrupt

Deal with Interrupt and I2C bus

Data Structures

class [SI4735](#)

[SI4735](#) Class. [More...](#)

Functions

[SI4735::SI4735](#) ()

Construct a new [SI4735::SI4735](#) object.

void [SI4735::waitInterrupt](#) (void)

Interrupt handle.

int16_t [SI4735::getDeviceI2CAddress](#) (uint8_t [resetPin](#))

I2C bus address setup.

void [SI4735::setDeviceI2CAddress](#) (uint8_t [senPin](#))

Sets the I2C Bus Address.

void [SI4735::setDeviceOtherI2CAddress](#) (uint8_t [i2cAddr](#))

Sets the onther I2C Bus Address (for Si470X)

Detailed Description

This is a library for the [SI4735](#), BROADCAST AM/FM/SW RADIO RECEIVER, IC from Silicon Labs for the Arduino development environment. It works with I2C protocol. This library is intended to provide an easier interface for controlling the [SI4735](#).

See also

documentation on <https://github.com/pu2clr/SI4735>.

Si47XX PROGRAMMING GUIDE; AN332

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; AMENDMENT FOR SI4735-D60
SSB AND NBFM PATCHES

ATTENTION: According to Si47XX PROGRAMMING GUIDE; AN332; page 207, "For write operations, the system controller next sends a data byte on SDIO, which is captured by the device on rising edges of SCLK. The device acknowledges each data byte by driving SDIO low for one cycle on the next falling edge of SCLK. The system controller may write up to 8 data bytes in a single 2-wire transaction. The first byte is a command, and the next seven bytes are arguments. Writing more than 8 bytes results in unpredictable device behavior". So, If you are extending this library, consider that restriction presented earlier.

ATTENTION: Some methods were implemented usin inline resource. Inline methods are implemented in [SI4735.h](#)

Author

PU2CLR - Ricardo Lima Caratti

By Ricardo Lima Caratti, Nov 2019.

Data Structure Documentation

class SI4735

[SI4735](#) Class.

[SI4735](#) Class definition

This class implements all functions to help you to control the Si47XX devices. This library was built based on “Si47XX PROGRAMMING GUIDE; AN332 ”. It also can be used on all members of the SI473X family respecting, of course, the features available for each IC version. These functionalities can be seen in the comparison matrix shown in table 1 (Product Family Function); pages 2 and 3 of the programming guide.

Author

PU2CLR - Ricardo Lima Caratti

Definition at line 873 of file SI4735.h.

Public Member Functions

[SI4735](#) ()

Construct a new [SI4735::SI4735](#) object.

void [reset](#) (void)

Reset the SI473X

void [waitToSend](#) (void)

Wait for the si473x is ready (Clear to Send (CTS) status bit have to be 1).

void [setup](#) (uint8_t [resetPin](#), uint8_t defaultFunction)

Starts the Si473X device.

void [setup](#) (uint8_t [resetPin](#), int [interruptPin](#), uint8_t defaultFunction, uint8_t audioMode=[SI473X_ANALOG_AUDIO](#))

Starts the Si473X device.

void [setPowerUp](#) (uint8_t CTSIEN, uint8_t GPO2OEN, uint8_t PATCH, uint8_t XOSCEN, uint8_t FUNC, uint8_t OPMODE)

Set the Power Up parameters for si473X.

void [radioPowerUp](#) (void)

Powerup the Si47XX.

void [analogPowerUp](#) (void)

You have to call setPowerUp method before.

void [powerDown](#) (void)

Moves the device from powerup to powerdown mode.

void [setFrequency](#) (uint16_t)

Set the frequency to the corrent function of the Si4735 (FM, AM or SSB)

void [getStatus](#) ()

void [getStatus](#) (uint8_t, uint8_t)

uint16_t [getFrequency](#) (void)
 uint16_t [getCurrentFrequency](#) ()
 bool [getSignalQualityInterrupt](#) ()
 bool [getRadioDataSystemInterrupt](#) ()
 Gets Received Signal Quality Interrupt(RSQINT)

bool [getTuneCompleteTriggered](#) ()
 Gets Radio Data System (RDS) Interrupt.

bool [getStatusError](#) ()
 Seek/Tune Complete Interrupt; 1 = Tune complete has been triggered.

bool [getStatusCTS](#) ()
 Return the Error flag (true or false) of status of the least Tune or Seek.

bool [getACFIndicator](#) ()
 Gets the Error flag of status response.

bool [getBandLimit](#) ()
 Returns true if the AFC rails (AFC Rail Indicator).

bool [getStatusValid](#) ()
 Returns true if a seek hit the band limit (WRAP = 0 in FM_START_SEEK) or wrapped to the original frequency(WRAP = 1).

uint8_t [getReceivedSignalStrengthIndicator](#) ()
 Returns true if the channel is currently valid as determined by the seek/tune properties (0x1403, 0x1404, 0x1108)

uint8_t [getStatusSNR](#) ()
 Returns integer Received Signal Strength Indicator (dB $\hat{1}/4V$).

uint8_t [getStatusMULT](#) ()
 Returns integer containing the SNR metric when tune is complete (dB).

uint8_t [getAntennaTuningCapacitor](#) ()
 Returns integer containing the multipath metric when tune is complete.

void [getAutomaticGainControl](#) ()
 Returns integer containing the current antenna tuning capacitor value.

void [setAvcAmMaxGain](#) (uint8_t gain)
 void [setAvcAmMaxGain](#) ()
 uint8_t [getCurrentAvcAmMaxGain](#) ()
 void [setAmSoftMuteMaxAttenuation](#) (uint8_t smattn)
 void [setAmSoftMuteMaxAttenuation](#) ()
 void [setSsbSoftMuteMaxAttenuation](#) (uint8_t smattn)
 void [setSsbSoftMuteMaxAttenuation](#) ()
 bool [isAgcEnabled](#) ()

uint8_t [getAgcGainIndex](#) ()
 void [setAutomaticGainControl](#) (uint8_t AGCDIS, uint8_t AGCIDX)
 void [getCurrentReceivedSignalQuality](#) (uint8_t INTACK)
 void [getCurrentReceivedSignalQuality](#) (void)
 uint8_t [getCurrentRSSI](#) ()
 uint8_t [getCurrentSNR](#) ()
current receive signal strength (0â€“127 dB $\frac{1}{4}$ V).

bool [getCurrentRssiDetectLow](#) ()
current SNR metric (0–127 dB).

bool [getCurrentRssiDetectHigh](#) ()
RSSI Detect Low.

bool [getCurrentSnrDetectLow](#) ()
RSSI Detect High.

bool [getCurrentSnrDetectHigh](#) ()
SNR Detect Low.

bool [getCurrentValidChannel](#) ()
SNR Detect High.

bool [getCurrentAfcRailIndicator](#) ()
Valid Channel.

bool [getCurrentSoftMuteIndicator](#) ()
AFC Rail Indicator.

uint8_t [getCurrentStereoBlend](#) ()
Soft Mute Indicator. Indicates soft mute is engaged.

bool [getCurrentPilot](#) ()
Indicates amount of stereo blend in % (100 = full stereo, 0 = full mono).

uint8_t [getCurrentMultipath](#) ()
Indicates stereo pilot presence.

uint8_t [getCurrentSignedFrequencyOffset](#) ()
Contains the current multipath metric. (0 = no multipath; 100 = full multipath)

bool [getCurrentMultipathDetectLow](#) ()
Signed frequency offset (kHz).

bool [getCurrentMultipathDetectHigh](#) ()
Multipath Detect Low.

bool [getCurrentBlendDetectInterrupt](#) ()

Multipath Detect High.

uint8_t [getFirmwarePN](#) ()

Blend Detect Interrupt.

uint8_t [getFirmwareFWMAJOR](#) ()

RESP1 - Part Number (HEX)

uint8_t [getFirmwareFWMINOR](#) ()

RESP2 - Returns the Firmware Major Revision (ASCII).

uint8_t [getFirmwarePATCHH](#) ()

RESP3 - Returns the Firmware Minor Revision (ASCII).

uint8_t [getFirmwarePATCHL](#) ()

RESP4 - Returns the Patch ID High byte (HEX).

uint8_t [getFirmwareCMPMAJOR](#) ()

RESP5 - Returns the Patch ID Low byte (HEX).

uint8_t [getFirmwareCMPMINOR](#) ()

RESP6 - Returns the Component Major Revision (ASCII).

uint8_t [getFirmwareCHIPREV](#) ()

RESP7 - Returns the Component Minor Revision (ASCII).

void [setVolume](#) (uint8_t [volume](#))

RESP8 - Returns the Chip Revision (ASCII).

uint8_t [getVolume](#) ()

void [volumeDown](#) ()

void [volumeUp](#) ()

uint8_t [getCurrentVolume](#) ()

void [setAudioMute](#) (bool off)

Returns the current volume level.

void [digitalOutputFormat](#) (uint8_t OSIZE, uint8_t OMONO, uint8_t OMODE, uint8_t OFALL)

void [digitalOutputSampleRate](#) (uint16_t DOSR)

void [setAM](#) ()

Sets the radio to AM function. It means: LW MW and SW.

void [setFM](#) ()

Sets the radio to FM function.

void [setAM](#) (uint16_t fromFreq, uint16_t toFreq, uint16_t initialFreq, uint16_t step)

Sets the radio to AM (LW/MW/SW) function.

void [setFM](#) (uint16_t fromFreq, uint16_t toFreq, uint16_t initialFreq, uint16_t step)

Sets the radio to FM function.

void [setBandwidth](#) (uint8_t AMCHFLT, uint8_t AMPLFLT)

void [setFrequencyStep](#) (uint16_t step)

Sets the current step value.

uint8_t [getTuneFrequencyFast](#) ()

void [setTuneFrequencyFast](#) (uint8_t FAST)

Returns the FAST tuning status.

uint8_t [getTuneFrequencyFreeze](#) ()

FAST Tuning. If set, executes fast and invalidated tune. The tune status will not be accurate.

void [setTuneFrequencyFreeze](#) (uint8_t FREEZE)

Returns the FREEZE status.

void [setTuneFrequencyAntennaCapacitor](#) (uint16_t capacitor)

Only FM. Freeze Metrics During Alternate Frequency Jump.

void [frequencyUp](#) ()

Increments the current frequency on current band/function by using the current step.

void [frequencyDown](#) ()

Decrements the current frequency on current band/function by using the current step.

bool [isCurrentTuneFM](#) ()

void [getFirmware](#) (void)

Gets firmware information.

void [setFunction](#) (uint8_t FUNC)

void [seekStation](#) (uint8_t SEEKUP, uint8_t WRAP)

void [seekStationUp](#) ()

void [seekStationDown](#) ()

void [setSeekAmLimits](#) (uint16_t bottom, uint16_t top)

void [setSeekAmSpacing](#) (uint16_t spacing)

void [setSeekSrnThreshold](#) (uint16_t value)

void [setSeekRssiThreshold](#) (uint16_t value)

void [setFmBlendStereoThreshold](#) (uint8_t parameter)

void [setFmBlendMonoThreshold](#) (uint8_t parameter)

void [setFmBlendRssiStereoThreshold](#) (uint8_t parameter)

void [setFmBlendRssiMonoThreshold](#) (uint8_t parameter)

void [setFmBlendSnrStereoThreshold](#) (uint8_t parameter)

void [setFmBlendSnrMonoThreshold](#) (uint8_t parameter)

void [setFmBlendMultiPathStereoThreshold](#) (uint8_t parameter)

void [setFmBlendMultiPathMonoThreshold](#) (uint8_t parameter)

void [setFmStereoOn](#) ()

void [setFmStereoOff](#) ()

void [RdsInit](#) ()

void [setRdsIntSource](#) (uint8_t RDSNEWBLOCKB, uint8_t RDSNEWBLOCKA, uint8_t RDSSYNCFDFOUND, uint8_t RDSSYNCLDST, uint8_t RDSRECV)

void [getRdsStatus](#) (uint8_t INTACK, uint8_t MTFIFO, uint8_t STATUSONLY)

```

void getRdsStatus ()
bool getRdsReceived ()
bool getRdsSyncLost ()
    1 = FIFO filled to minimum number of groups

bool getRdsSyncFound ()
    1 = Lost RDS synchronization

bool getRdsNewBlockA ()
    1 = Found RDS synchronization

bool getRdsNewBlockB ()
    1 = Valid Block A data has been received.

bool getRdsSync ()
    1 = Valid Block B data has been received.

bool getGroupLost ()
    1 = RDS currently synchronized.

uint8_t getNumRdsFifoUsed ()
    1 = One or more RDS groups discarded due to FIFO overrun.

void setRdsConfig (uint8_t RDSEN, uint8_t BLETHA, uint8_t BLETHB, uint8_t BLETHC, uint8_t
    BLETHD)
    RESP3 - RDS FIFO Used; Number of groups remaining in the RDS FIFO (0 if empty).

uint16_t getRdsPI (void)
uint8_t getRdsGroupType (void)
uint8_t getRdsFlagAB (void)
uint8_t getRdsVersionCode (void)
uint8_t getRdsProgramType (void)
uint8_t getRdsTextSegmentAddress (void)
char * getRdsText (void)
char * getRdsText0A (void)
char * getRdsText2A (void)
char * getRdsText2B (void)
char * getRdsTime (void)
void getNext2Block (char *)
void getNext4Block (char *)
void ssbSetup ()
void setSSBBfo (int offset)
void setSSBConfig (uint8_t AUDIOBW, uint8_t SBCUTFLT, uint8_t AVC_DIVIDER, uint8_t
    AVCEN, uint8_t SMUTESEL, uint8_t DSP_AFCDIS)
void setSSB (uint16_t fromFreq, uint16_t toFreq, uint16_t intialFreq, uint16_t step, uint8_t usblsb)
void setSSB (uint8_t usblsb)
void setSSBAudioBandwidth (uint8_t AUDIOBW)
void setSSBAutomaticVolumeControl (uint8_t AVCEN)
void setSSBSidebandCutoffFilter (uint8_t SBCUTFLT)
void setSSBAvcDivider (uint8_t AVC_DIVIDER)
void setSSBDspAfc (uint8_t DSP_AFCDIS)
void setSSBSoftMute (uint8_t SMUTESEL)
si47x\_firmware\_query\_library\_queryLibraryId ()

```

```

void patchPowerUp ()
bool downloadPatch (const uint8_t *ssb_patch_content, const uint16_t ssb_patch_content_size)
bool downloadPatch (int eeprom_i2c_address)
void ssbPowerUp ()
void setI2CLowSpeedMode (void)
void setI2CStandardMode (void)
    Sets I2C buss to 10KHz.

void setI2CFastMode (void)
    Sets I2C buss to 100KHz.

void setI2CFastModeCustom (long value=500000)
    Sets I2C buss to 400KHz.

void setDeviceI2CAddress (uint8_t senPin)
    Sets the I2C Bus Address.

int16_t getDeviceI2CAddress (uint8_t resetPin)
    I2C bus address setup.

void setDeviceOtherI2CAddress (uint8_t i2cAddr)
    Sets the onther I2C Bus Address (for Si470X)

```

Protected Member Functions

```

void waitInterrupr (void)
    Interrupt handle.

void sendProperty (uint16_t propertyValue, uint16_t param)
void sendSSBModeProperty ()
void disableFmDebug ()
void clearRdsBuffer2A ()
void clearRdsBuffer2B ()
void clearRdsBuffer0A ()

```

Protected Attributes

```

char rds\_buffer2A [65]
char rds\_buffer2B [33]
    RDS Radio Text buffer - Program Information.

char rds\_buffer0A [9]
    RDS Radio Text buffer - Station Informaation.

char rds\_time [20]
    RDS Basic tuning and switching information (Type 0 groups)

int rdsTextAddress2A
    RDS date time received information

int rdsTextAddress2B

```

rds_buffer2A current position

int [rdsTextAddress0A](#)

rds_buffer2B current position

int16_t [deviceAddress](#) = [SI473X_ADDR_SEN_LOW](#)

rds_buffer0A current position

uint8_t [lastTextFlagAB](#)

current I2C buss address

uint8_t [resetPin](#)

uint8_t [interruptPin](#)

pin used on Arduino Board to RESET the Si47XX device

uint8_t [currentTune](#)

pin used on Arduino Board to control interrupt. If -1, interrupt is no used.

uint16_t [currentMinimumFrequency](#)

tell the current tune (FM, AM or SSB)

uint16_t [currentMaximumFrequency](#)

minimum frequency of the current band

uint16_t [currentWorkFrequency](#)

maximum frequency of the current band

uint16_t [currentStep](#)

current frequency

uint8_t [lastMode](#) = -1

current steps

uint8_t [currentAvcAmMaxGain](#) = 48

Store the last mode used.

[si47x_frequency](#) [currentFrequency](#)

Automatic Volume Control Gain for AM - Default 48.

[si47x_set_frequency](#) [currentFrequencyParams](#)

data structure to get current frequency

[si47x_rqs_status](#) [currentRqsStatus](#)

[si47x_response_status](#) [currentStatus](#)

current Radio Signal Quality status

[si47x_firmware_information](#) [firmwareInfo](#)

current device status

[si47x_rds_status](#) [currentRdsStatus](#)

firmware information

[si47x_agc_status](#) [currentAgcStatus](#)

current RDS status

[si47x_ssb_mode](#) [currentSSBMode](#)

current AGC status

[si473x_powerup](#) [powerUp](#)

indicates if USB or LSB

uint8_t [volume](#) = 32

uint8_t [currentSsbStatus](#)

Member Function Documentation

void SI4735::clearRdsBuffer0A () [protected]

Clear RDS buffer 0A (text)

Definition at line 1307 of file SI4735.cpp.

```
01308 {  
01309     for (int i = 0; i < 9; i++)  
01310         rds\_buffer0A[i] = ' '; // Station Name buffer  
01311 }
```

References [rds_buffer0A](#).

Referenced by [getRdsStatus\(\)](#), and [RdsInit\(\)](#).

void SI4735::clearRdsBuffer2A () [protected]

Clear RDS buffer 2A (text)

Definition at line 1288 of file SI4735.cpp.

```
01289 {  
01290     for (int i = 0; i < 65; i++)  
01291         rds\_buffer2A[i] = ' '; // Radio Text buffer - Program Information  
01292 }
```

References [rds_buffer2A](#).

Referenced by [getRdsStatus\(\)](#), and [RdsInit\(\)](#).

void SI4735::clearRdsBuffer2B () [protected]

Clear RDS buffer 2B (text)

Definition at line 1298 of file SI4735.cpp.

```
01299 {  
01300     for (int i = 0; i < 33; i++)  
01301         rds\_buffer2B[i] = ' '; // Radio Text buffer - Station Informaation  
01302 }
```

References [rds_buffer2B](#).

Referenced by [getRdsStatus\(\)](#), and [RdsInit\(\)](#).

void SI4735::digitalOutputFormat (uint8_t OSIZE, uint8_t OMONO, uint8_t OMODE, uint8_t OFALL)

Digital Audio Setup Configures the digital audio output format. Options: DCLK edge, data format, force mono, and sample precision.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 195.

Parameters

<i>uint8_t</i>	OSIZE Digital Output Audio Sample Precision (0=16 bits, 1=20 bits, 2=24 bits, 3=8bits).
<i>uint8_t</i>	OMONO Digital Output Mono Mode (0=Use mono/stereo blend).
<i>uint8_t</i>	OMODE Digital Output Mode (0=I2S, 6 = Left-justified, 8 = MSB at second DCLK after DFS pulse, 12 = MSB at first DCLK after DFS pulse).
<i>uint8_t</i>	OFALL Digital Output DCLK Edge (0 = use DCLK rising edge, 1 = use DCLK falling edge)

Definition at line 852 of file SI4735.cpp.

```
00853 {
00854     si4735\_digital\_output\_format df;
00855     df.refined.OSIZE = OSIZE;
00856     df.refined.OMONO = OMONO;
00857     df.refined.OMODE = OMODE;
00858     df.refined.OFALL = OFALL;
00859     sendProperty(DIGITAL\_OUTPUT\_FORMAT, df.raw);
00860 }
```

References [DIGITAL_OUTPUT_FORMAT](#), [si4735_digital_output_format::raw](#), [si4735_digital_output_format::refined](#), and [sendProperty\(\)](#).

void SI4735::digitalOutputSampleRate (uint16_t DOSR)

Enables digital audio output and configures digital audio output sample rate in samples per second (sps).

See also

Si47XX PROGRAMMING GUIDE; AN332; page 196.

Parameters

<i>uint16_t</i>	DOSR Digital Output Sample Rate(32–48 ksps .0 to disable digital audio output).
-----------------	---

Definition at line 869 of file SI4735.cpp.

```
00870 {
00871     sendProperty(DIGITAL\_OUTPUT\_SAMPLE\_RATE, DOSR);
00872 }
```

References [DIGITAL_OUTPUT_SAMPLE_RATE](#), and [sendProperty\(\)](#).

void SI4735::disableFmDebug () [protected]

There is a debug feature that remains active in Si4704/05/3x-D60 firmware which can create periodic noise in audio. Silicon Labs recommends you disable this feature by sending the following bytes (shown here in hexadecimal form): 0x12 0x00 0xFF 0x00 0x00 0x00.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 299.

Definition at line 824 of file SI4735.cpp.

```
00825 {
00826     Wire.beginTransaction(deviceAddress);
00827     Wire.write(0x12);
00828     Wire.write(0x00);
00829     Wire.write(0xFF);
00830     Wire.write(0x00);
00831     Wire.write(0x00);
00832     Wire.write(0x00);
00833     Wire.endTransmission();
00834     delayMicroseconds(2500);
00835 }
```

References [deviceAddress](#).

Referenced by [setFM\(\)](#).

bool SI4735::downloadPatch (const uint8_t * ssb_patch_content, const uint16_t ssb_patch_content_size)

Transfers the content of a patch stored in a array of bytes to the [SI4735](#) device. You must mount an array as shown below and know the size of that array as well.

It is importante to say that patches to the [SI4735](#) are distributed in binary form and have to be transferred to the internal RAM of the device by the host MCU (in this case Arduino). Since the RAM is volatile memory, the patch stored into the device gets lost when you turn off the system. Consequently, the content of the patch has to be transferred again to the device each time after turn on the system or reset the device.

The disadvantage of this approach is the amount of memory used by the patch content. This may limit the use of other radio functions you want implemented in Arduino.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 64 and 215-220.

Example of content: `const PROGMEM uint8_t ssb_patch_content_full[] = { // SSB patch for whole SSBRX full download 0x15, 0x00, 0x0F, 0xE0, 0xF2, 0x73, 0x76, 0x2F, 0x16, 0x6F, 0x26, 0x1E, 0x00, 0x4B, 0x2C, 0x58, 0x16, 0xA3, 0x74, 0x0F, 0xE0, 0x4C, 0x36, 0xE4, 0x16, 0x3B, 0x1D, 0x4A, 0xEC, 0x36, 0x28, 0xB7, 0x16, 0x00, 0x3A, 0x47, 0x37, 0x00, 0x00, 0x00, 0x15, 0x00, 0x00, 0x00, 0x00, 0x00, 0x9D, 0x29};`

`const int size_content_full = sizeof ssb_patch_content_full;`

Parameters

<code>ssb_patch_content</code>	point to array of bytes content patch.
<code>ssb_patch_content_size</code>	array size (number of bytes). The maximum size allowed for a patch is 15856 bytes

Returns

false if an error is found.

Definition at line 2244 of file SI4735.cpp.

```
02245 {
02246     uint8_t content;
02247     register int i, offset;
02248     // Send patch to the SI4735 device
02249     for (offset = 0; offset < (int) ssb_patch_content_size; offset += 8)
02250     {
02251         Wire.beginTransaction(deviceAddress);
02252         for (i = 0; i < 8; i++)
02253         {
02254             content = pgm_read_byte_near(ssb_patch_content + (i + offset));
02255             Wire.write(content);
02256         }
02257         Wire.endTransmission();
02258
02259         // Testing download performance
02260         // approach 1 - Faster - less secure (it might crash in some
architectures)
02261         delayMicroseconds(MIN\_DELAY\_WAIT\_SEND\_LOOP); // Need check the
minimum value
02262
02263         // approach 2 - More control. A little more secure than approach 1
02264         /*
02265         do
02266         {
02267             delayMicroseconds(150); // Minimum delay founded (Need check the
minimum value)
02268             Wire.requestFrom(deviceAddress, 1);
02269             } while (!(Wire.read() & B10000000));
02270         */
02271
02272         // approach 3 - same approach 2
02273         // waitToSend();
02274
02275         // approach 4 - safer
02276         /*
```



```

02277         waitToSend();
02278         uint8_t cmd_status;
02279         Uncomment the lines below if you want to check erro.
02280         Wire.requestFrom(deviceAddress, 1);
02281         cmd_status = Wire.read();
02282         The SI4735 issues a status after each 8 byte transfered.
02283         Just the bit 7 (CTS) should be seted. if bit 6 (ERR) is seted, the
system halts.
02284         if (cmd_status != 0x80)
02285             return false;
02286         */
02287     }
02288     delayMicroseconds(250);
02289     return true;
02290 }

```

References deviceAddress, and MIN_DELAY_WAIT_SEND_LOOP.

bool SI4735::downloadPatch (int eeprom_i2c_address)

Under construction... Transfers the content of a patch stored in a eeprom to the [SI4735](#) device.

TO USE THIS METHOD YOU HAVE TO HAVE A EEPROM WRITEN WITH THE PATCH CONTENT

See also

the sketch write_ssb_patch_eeprom.ino (TO DO)

Parameters

eeprom_i2c_addre ss	
------------------------	--

Returns

false if an error is found.

Definition at line 2303 of file SI4735.cpp.

```

02304 {
02305     int ssb_patch_content_size;
02306     uint8_t cmd_status;
02307     int i, offset;
02308     uint8_t eepromPage[8];
02309
02310     union {
02311         struct
02312         {
02313             uint8_t lowByte;
02314             uint8_t highByte;
02315         } raw;
02316         uint16_t value;
02317     } eeprom;
02318
02319     // The first two bytes are the size of the patches
02320     // Set the position in the eeprom to read the size of the patch content
02321     Wire.beginTransmission(eeprom_i2c_address);
02322     Wire.write(0); // writes the most significant byte
02323     Wire.write(0); // writes the less significant byte
02324     Wire.endTransmission();
02325     Wire.requestFrom(eeprom_i2c_address, 2);
02326     eeprom.raw.highByte = Wire.read();
02327     eeprom.raw.lowByte = Wire.read();
02328
02329     ssb_patch_content_size = eeprom.value;
02330
02331     // the patch content starts on position 2 (the first two bytes are the
size of the patch)
02332     for (offset = 2; offset < ssb_patch_content_size; offset += 8)
02333     {
02334         // Set the position in the eeprom to read next 8 bytes
eeprom.value = offset;
02335         Wire.beginTransmission(eeprom_i2c_address);
02336         Wire.write(eeprom.raw.highByte); // writes the most significant byte
02337         Wire.write(eeprom.raw.lowByte); // writes the less significant byte
02338         Wire.endTransmission();
02339
02340

```

```

02341         // Reads the next 8 bytes from eeprom
02342         Wire.requestFrom(eeprom_i2c_address, 8);
02343         for (i = 0; i < 8; i++)
02344             eepromPage[i] = Wire.read();
02345
02346         // sends the page (8 bytes) to the SI4735
02347         Wire.beginTransaction(deviceAddress);
02348         for (i = 0; i < 8; i++)
02349             Wire.write(eepromPage[i]);
02350         Wire.endTransmission();
02351
02352         waitToSend();
02353
02354         Wire.requestFrom(deviceAddress, 1);
02355         cmd_status = Wire.read();
02356         // The SI4735 issues a status after each 8 byte transfered.
02357         // Just the bit 7 (CTS) should be seted. if bit 6 (ERR) is seted,
the system halts.
02358         if (cmd_status != 0x80)
02359             return false;
02360     }
02361     delayMicroseconds(250);
02362     return true;
02363 }

```

References deviceAddress, and waitToSend().

bool SI4735::getACFIndicator () [inline]

Gets the Error flag of status response.

Definition at line 961 of file SI4735.h.

```
00961 { return currentStatus.resp.AFCRL; };
```

References currentStatus, and si47x_response_status::resp.

uint8_t SI4735::getAgcGainIndex () [inline]

Definition at line 983 of file SI4735.h.

```
00983 { return currentAgcStatus.refined.AGCIDX; }; // Returns the current AGC gain
index.
```

References currentAgcStatus, and si47x_agc_status::refined.

uint8_t SI4735::getAntennaTuningCapacitor () [inline]

Returns integer containing the multipath metric when tune is complete.

Definition at line 967 of file SI4735.h.

```
00967 { return currentStatus.resp.READANTCAP; };
```

References currentStatus, and si47x_response_status::resp.

void SI4735::getAutomaticGainControl ()

Returns integer containing the current antenna tuning capacitor value.

Queries AGC STATUS

See also

Si47XX PROGRAMMING GUIDE; AN332; For FM page 80; for AM page 142.

AN332 REV 0.8 Universal Programming Guide Amendment for SI4735-D60 SSB and NBFM patches; page 18.

After call this method, you can call isAgcEnabled to know the AGC status and getAgcGainIndex to know the gain index value.

Definition at line 960 of file SI4735.cpp.

```
00961 {
00962     uint8_t cmd;
```

```

00963
00964     if (currentTune == FM_TUNE_FREQ)
00965     { // FM TUNE
00966         cmd = FM_AGC_STATUS;
00967     }
00968     else
00969     { // AM TUNE - SAME COMMAND used on SSB mode
00970         cmd = AM_AGC_STATUS;
00971     }
00972
00973     waitToSend();
00974
00975     Wire.beginTransaction(deviceAddress);
00976     Wire.write(cmd);
00977     Wire.endTransmission();
00978
00979     do
00980     {
00981         waitToSend();
00982         Wire.requestFrom(deviceAddress, 3);
00983         currentAgcStatus.raw[0] = Wire.read(); // STATUS response
00984         currentAgcStatus.raw[1] = Wire.read(); // RESP 1
00985         currentAgcStatus.raw[2] = Wire.read(); // RESP 2
00986     } while (currentAgcStatus.refined.ERR); // If error, try get AGC
status again.
00987 }

```

References AM_AGC_STATUS, currentAgcStatus, currentTune, deviceAddress, FM_AGC_STATUS, FM_TUNE_FREQ, si47x_agc_status::raw, si47x_agc_status::refined, and waitToSend().

bool SI4735::getBandLimit () [inline]

Returns true if the AFC rails (AFC Rail Indicator).

Definition at line 962 of file SI4735.h.

```
00962 { return currentStatus.resp.BLTF; };
```

References currentStatus, and si47x_response_status::resp.

bool SI4735::getCurrentAfcRailIndicator () [inline]

Valid Channel.

Definition at line 997 of file SI4735.h.

```
00997 { return currentRqsStatus.resp.AFCRL; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

uint8_t SI4735::getCurrentAvcAmMaxGain () [inline]

Definition at line 973 of file SI4735.h.

```
00973 {return currentAvcAmMaxGain; };
```

References currentAvcAmMaxGain.

bool SI4735::getCurrentBlendDetectInterrupt () [inline]

Multipath Detect High.

Definition at line 1006 of file SI4735.h.

```
01006 { return currentRqsStatus.resp.BLENDINT; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

uint16_t SI4735::getCurrentFrequency ()

Gets the current frequency saved in memory. Unlike getFrequency, this method gets the current frequency recorded after the last setFrequency command. This method avoids bus traffic and CI processing. However, you can not get others status information like RSSI.

See also

[getFrequency\(\)](#)

Definition at line 904 of file SI4735.cpp.

```
00905 {  
00906     return currentWorkFrequency;  
00907 }
```

References [currentWorkFrequency](#).

uint8_t SI4735::getCurrentMultipath () [inline]

Indicates stereo pilot presence.

Definition at line 1002 of file SI4735.h.

```
01002 { return currentRqsStatus.resp.MULT; };
```

References [currentRqsStatus](#), and [si47x_rqs_status::resp](#).

bool SI4735::getCurrentMultipathDetectHigh () [inline]

Multipath Detect Low.

Definition at line 1005 of file SI4735.h.

```
01005 { return currentRqsStatus.resp.MULTHINT; };
```

References [currentRqsStatus](#), and [si47x_rqs_status::resp](#).

bool SI4735::getCurrentMultipathDetectLow () [inline]

Signed frequency offset (kHz).

Definition at line 1004 of file SI4735.h.

```
01004 { return currentRqsStatus.resp.MULTLINT; };
```

References [currentRqsStatus](#), and [si47x_rqs_status::resp](#).

bool SI4735::getCurrentPilot () [inline]

Indicates amount of stereo blend in % (100 = full stereo, 0 = full mono).

Definition at line 1001 of file SI4735.h.

```
01001 { return currentRqsStatus.resp.PILOT; };
```

References [currentRqsStatus](#), and [si47x_rqs_status::resp](#).

void SI4735::getCurrentReceivedSignalQuality (uint8_t INTACK)

Queries the status of the Received Signal Quality (RSQ) of the current channel. This method should be called before call [getCurrentRSSI\(\)](#), [getCurrentSNR\(\)](#) etc. Command FM_RSQ_STATUS

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 75 and 141

Parameters

<i>INTACK</i>	Interrupt Acknowledge. 0 = Interrupt status preserved; 1 = Clears RSQINT, BLENDINT, SNRHINT, SNRLINT, RSSIHINT, RSSILINT, MULTHINT, MULTLINT.
---------------	---

Definition at line 1049 of file SI4735.cpp.

```
01050 {  
01051     uint8_t arg;  
01052     uint8_t cmd;  
01053     int sizeResponse;  
01054  
01055     if (currentTune == FM\_TUNE\_FREQ)  
01056     { // FM TUNE  
01057         cmd = FM\_RSQ\_STATUS;
```

```

01058         sizeResponse = 8; // Check it
01059     }
01060     else
01061     { // AM TUNE
01062         cmd = AM\_RSQ\_STATUS;
01063         sizeResponse = 6; // Check it
01064     }
01065
01066     waitToSend();
01067
01068     arg = INTACK;
01069     Wire.beginTransaction(deviceAddress);
01070     Wire.write(cmd);
01071     Wire.write(arg); // send B00000001
01072     Wire.endTransmission();
01073
01074     // Check it
01075     // do
01076     //{
01077         waitToSend();
01078         Wire.requestFrom(deviceAddress, sizeResponse);
01079         // Gets response information
01080         for (uint8_t i = 0; i < sizeResponse; i++)
01081             currentRqsStatus.raw[i] = Wire.read();
01082         //} while (currentRqsStatus.resp.ERR); // Try again if error found
01083     }

```

References [AM_RSQ_STATUS](#), [currentRqsStatus](#), [currentTune](#), [deviceAddress](#), [FM_RSQ_STATUS](#), [FM_TUNE_FREQ](#), [si47x_rqs_status::raw](#), and [waitToSend\(\)](#).

void SI4735::getCurrentReceivedSignalQuality (void)

Queries the status of the Received Signal Quality (RSQ) of the current channel Command [FM_RSQ_STATUS](#)

See also

[Si47XX PROGRAMMING GUIDE; AN332](#); pages 75 and 141

Parameters

<i>INTACK</i>	Interrupt Acknowledge. 0 = Interrupt status preserved; 1 = Clears RSQINT, BLENDINT, SNRHINT, SNRLINT, RSSIHINT, RSSILINT, MULTHINT, MULTLINT.
---------------	---

Definition at line 1095 of file [SI4735.cpp](#).

```

01096 {
01097     getCurrentReceivedSignalQuality(0);
01098 }

```

uint8_t SI4735::getCurrentRSSI () [inline]

Definition at line 990 of file [SI4735.h](#).

```

00990 { return currentRqsStatus.resp.RSSI; };

```

References [currentRqsStatus](#), and [si47x_rqs_status::resp](#).

bool SI4735::getCurrentRssiDetectHigh () [inline]

RSSI Detect Low.

Definition at line 993 of file [SI4735.h](#).

```

00993 { return currentRqsStatus.resp.RSSIHINT; };

```

References [currentRqsStatus](#), and [si47x_rqs_status::resp](#).

bool SI4735::getCurrentRssiDetectLow () [inline]

current SNR metric (0–127 dB).

Definition at line 992 of file [SI4735.h](#).

```

00992 { return currentRqsStatus.resp.RSSIILINT; };

```

References [currentRqsStatus](#), and [si47x_rqs_status::resp](#).

uint8_t SI4735::getCurrentSignedFrequencyOffset () [inline]

Contains the current multipath metric. (0 = no multipath; 100 = full multipath)

Definition at line 1003 of file SI4735.h.

```
01003 { return currentRqsStatus.resp.FREQOFF; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

uint8_t SI4735::getCurrentSNR () [inline]

current receive signal strength (0â€“127 dB¹/₄V).

Definition at line 991 of file SI4735.h.

```
00991 { return currentRqsStatus.resp.SNR; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

bool SI4735::getCurrentSnrDetectHigh () [inline]

SNR Detect Low.

Definition at line 995 of file SI4735.h.

```
00995 { return currentRqsStatus.resp.SNRHINT; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

bool SI4735::getCurrentSnrDetectLow () [inline]

RSSI Detect High.

Definition at line 994 of file SI4735.h.

```
00994 { return currentRqsStatus.resp.SNRLINT; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

bool SI4735::getCurrentSoftMuteIndicator () [inline]

AFC Rail Indicator.

Definition at line 998 of file SI4735.h.

```
00998 { return currentRqsStatus.resp.SMUTE; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

uint8_t SI4735::getCurrentStereoBlend () [inline]

Soft Mute Indicator. Indicates soft mute is engaged.

Definition at line 1000 of file SI4735.h.

```
01000 { return currentRqsStatus.resp.STBLEND; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

bool SI4735::getCurrentValidChannel () [inline]

SNR Detect High.

Definition at line 996 of file SI4735.h.

```
00996 { return currentRqsStatus.resp.VALID; };
```

References currentRqsStatus, and si47x_rqs_status::resp.

uint8_t SI4735::getCurrentVolume () [inline]

Definition at line 1028 of file SI4735.h.

```
01028 { return volume; };
```

References [volume](#).

uint8_t SI4735::getFirmwareCHIPREV () [inline]

RESP7 - Returns the Component Minor Revision (ASCII).

Definition at line 1021 of file SI4735.h.

```
01021 { return firmwareInfo.resp.CHIPREV; };
```

References [firmwareInfo](#), and [si47x_firmware_information::resp](#).

uint8_t SI4735::getFirmwareCMPMAJOR () [inline]

RESP5 - Returns the Patch ID Low byte (HEX).

Definition at line 1019 of file SI4735.h.

```
01019 { return firmwareInfo.resp.CMPMAJOR; };
```

References [firmwareInfo](#), and [si47x_firmware_information::resp](#).

uint8_t SI4735::getFirmwareCMPMINOR () [inline]

RESP6 - Returns the Component Major Revision (ASCII).

Definition at line 1020 of file SI4735.h.

```
01020 { return firmwareInfo.resp.CMPMINOR; };
```

References [firmwareInfo](#), and [si47x_firmware_information::resp](#).

uint8_t SI4735::getFirmwareFWMAJOR () [inline]

RESP1 - Part Number (HEX)

Definition at line 1015 of file SI4735.h.

```
01015 { return firmwareInfo.resp.FWMAJOR; };
```

References [firmwareInfo](#), and [si47x_firmware_information::resp](#).

uint8_t SI4735::getFirmwareFWMINOR () [inline]

RESP2 - Returns the Firmware Major Revision (ASCII).

Definition at line 1016 of file SI4735.h.

```
01016 { return firmwareInfo.resp.FWMINOR; };
```

References [firmwareInfo](#), and [si47x_firmware_information::resp](#).

uint8_t SI4735::getFirmwarePATCHH () [inline]

RESP3 - Returns the Firmware Minor Revision (ASCII).

Definition at line 1017 of file SI4735.h.

```
01017 { return firmwareInfo.resp.PATCHH; };
```

References [firmwareInfo](#), and [si47x_firmware_information::resp](#).

uint8_t SI4735::getFirmwarePATCHL () [inline]

RESP4 - Returns the Patch ID High byte (HEX).

Definition at line 1018 of file SI4735.h.

```
01018 { return firmwareInfo.resp.PATCHL; };
```

References [firmwareInfo](#), and [si47x_firmware_information::resp](#).

uint8_t SI4735::getFirmwarePN () [inline]

Blend Detect Interrupt.

Definition at line 1014 of file SI4735.h.

```
01014 { return firmwareInfo.resp.PN; };
```

References firmwareInfo, and si47x_firmware_information::resp.

uint16_t SI4735::getFrequency (void)

Device Status Information Gets the current frequency of the Si4735 (AM or FM) The method status do it an more. See getStatus below.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 73 (FM) and 139 (AM)

Definition at line 884 of file SI4735.cpp.

```
00885 {
00886     si47x_frequency freq;
00887     getStatus(0, 1);
00888
00889     freq.raw.FREQ_L = currentStatus.resp.READFREQ_L;
00890     freq.raw.FREQ_H = currentStatus.resp.READFREQ_H;
00891
00892     currentWorkFrequency = freq.value;
00893     return freq.value;
00894 }
```

References currentStatus, currentWorkFrequency, getStatus(), si47x_frequency::raw, si47x_response_status::resp, and si47x_frequency::value.

Referenced by seekStationDown(), and seekStationUp().

bool SI4735::getGroupLost () [inline]

1 = RDS currently synchronized.

Definition at line 1087 of file SI4735.h.

```
01087 { return currentRdsStatus.resp.GRPLOST; };
```

References currentRdsStatus, and si47x_rds_status::resp.

void SI4735::getNext2Block (char * c)

Process data received from group 2B

Parameters

<i>c</i>	char array reference to the "group 2B" text
----------	---

Definition at line 1581 of file SI4735.cpp.

```
01582 {
01583     char raw[2];
01584     int i, j;
01585
01586     raw[1] = currentRdsStatus.resp.BLOCKDL;
01587     raw[0] = currentRdsStatus.resp.BLOCKDH;
01588
01589     for (i = j = 0; i < 2; i++)
01590     {
01591         if (raw[i] == 0xD || raw[i] == 0xA)
01592         {
01593             c[j] = '\0';
01594             return;
01595         }
01596         if (raw[i] >= 32)
01597         {
01598             c[j] = raw[i];
01599             j++;
01600         }
01601         else
01602         {
01603             c[i] = ' ';
```



```

01604     }
01605 }
01606 }

```

References `currentRdsStatus`, and `si47x_rds_status::resp`.

Referenced by `getRdsText0A()`, and `getRdsText2B()`.

void SI4735::getNext4Block (char * c)

Process data received from group 2A

Parameters

<code>c</code>	char array reference to the "group 2A" text
----------------	---

Definition at line 1613 of file `SI4735.cpp`.

```

01614 {
01615     char raw[4];
01616     int i, j;
01617
01618     raw[0] = currentRdsStatus.resp.BLOCKCH;
01619     raw[1] = currentRdsStatus.resp.BLOCKCL;
01620     raw[2] = currentRdsStatus.resp.BLOCKDH;
01621     raw[3] = currentRdsStatus.resp.BLOCKDL;
01622     for (i = j = 0; i < 4; i++)
01623     {
01624         if (raw[i] == 0xD || raw[i] == 0xA)
01625         {
01626             c[j] = '\0';
01627             return;
01628         }
01629         if (raw[i] >= 32)
01630         {
01631             c[j] = raw[i];
01632             j++;
01633         }
01634         else
01635         {
01636             c[i] = ' ';
01637         }
01638     }
01639 }

```

References `currentRdsStatus`, and `si47x_rds_status::resp`.

Referenced by `getRdsText()`, and `getRdsText2A()`.

uint8_t SI4735::getNumRdsFifoUsed () [inline]

1 = One or more RDS groups discarded due to FIFO overrun.

Definition at line 1088 of file `SI4735.h`.

```

01088 { return currentRdsStatus.resp.RDSFIFOUSED; };

```

References `currentRdsStatus`, and `si47x_rds_status::resp`.

bool SI4735::getRadioDataSystemInterrupt () [inline]

Gets Received Signal Quality Interrupt(RSQINT)

Definition at line 957 of file `SI4735.h`.

```

00957 { return currentStatus.resp.RDSINT; };

```

References `currentStatus`, and `si47x_response_status::resp`.

uint8_t SI4735::getRdsFlagAB (void)

Returns the current Text Flag A/B

Returns

`uint8_t`

Definition at line 1515 of file `SI4735.cpp`.

```

01516 {
01517     si47x\_rds\_blockb blk;

```

```

01518
01519     blkb.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01520     blkb.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01521
01522     return blkb.refined.textABFlag;
01523 }

```

References currentRdsStatus, si47x_rds_blockb::raw, si47x_rds_blockb::refined, and si47x_rds_status::resp.

uint8_t SI4735::getRdsGroupType (void)

Returns the Group Type (extracted from the Block B)

Definition at line 1499 of file SI4735.cpp.

```

01500 {
01501     si47x_rds_blockb blkb;
01502
01503     blkb.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01504     blkb.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01505
01506     return blkb.refined.groupType;
01507 }

```

References currentRdsStatus, si47x_rds_blockb::raw, si47x_rds_blockb::refined, and si47x_rds_status::resp.

Referenced by getRdsText0A(), getRdsText2A(), getRdsText2B(), and getRdsTime().

bool SI4735::getRdsNewBlockA () [inline]

1 = Found RDS synchronization

Definition at line 1084 of file SI4735.h.

```

01084 { return currentRdsStatus.resp.RDSNEWBLOCKA; };

```

References currentRdsStatus, and si47x_rds_status::resp.

Referenced by getRdsPI().

bool SI4735::getRdsNewBlockB () [inline]

1 = Valid Block A data has been received.

Definition at line 1085 of file SI4735.h.

```

01085 { return currentRdsStatus.resp.RDSNEWBLOCKB; };

```

References currentRdsStatus, and si47x_rds_status::resp.

uint16_t SI4735::getRdsPI (void)

Returns the programa type. Read the Block A content

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 77 and 78

Returns

BLOCKAL

Definition at line 1487 of file SI4735.cpp.

```

01488 {
01489     if (getRdsReceived() && getRdsNewBlockA())
01490     {
01491         return currentRdsStatus.resp.BLOCKAL;
01492     }
01493     return 0;
01494 }

```

References currentRdsStatus, getRdsNewBlockA(), getRdsReceived(), and si47x_rds_status::resp.

uint8_t SI4735::getRdsProgramType (void)

Returns the Program Type (extracted from the Block B)

See also

https://en.wikipedia.org/wiki/Radio_Data_System

Returns

program type (an integer between 0 and 31)

Definition at line 1566 of file SI4735.cpp.

```
01567 {
01568     si47x\_rds\_blockb blk;
01569
01570     blk.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01571     blk.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01572
01573     return blk.refined.programType;
01574 }
```

References [currentRdsStatus](#), [si47x_rds_blockb::raw](#), [si47x_rds_blockb::refined](#), and [si47x_rds_status::resp](#).

bool SI4735::getRdsReceived () [inline]

Definition at line 1081 of file SI4735.h.

```
01081 { return currentRdsStatus.resp.RDSRECV; };
```

References [currentRdsStatus](#), and [si47x_rds_status::resp](#).

Referenced by [getRdsPI\(\)](#), [getRdsText0A\(\)](#), and [getRdsText2A\(\)](#).

void SI4735::getRdsStatus ()

Gets RDS Status. Same result of calling [getRdsStatus\(0,0,0\)](#);

See also

[SI4735::getRdsStatus\(uint8_t INTACK, uint8_t MTFIFO, uint8_t STATUSONLY\)](#)

Please, call [getRdsStatus\(uint8_t INTACK, uint8_t MTFIFO, uint8_t STATUSONLY\)](#) instead [getRdsStatus\(\)](#) if you want other behaviour

Definition at line 1472 of file SI4735.cpp.

```
01473 {
01474     getRdsStatus(0, 0, 0);
01475 }
```

void SI4735::getRdsStatus (uint8_t INTACK, uint8_t MTFIFO, uint8_t STATUSONLY)

Gets the RDS status. Store the status in [currentRdsStatus](#) member. RDS COMMAND FM_RDS_STATUS

See also

SI47XX PROGRAMMING GUIDE; AN332; pages 55 and 77

Parameters

<i>INTACK</i>	Interrupt Acknowledge; 0 = RDSINT status preserved. 1 = Clears RDSINT.
<i>MTFIFO</i>	0 = If FIFO not empty, read and remove oldest FIFO entry; 1 = Clear RDS Receive FIFO.
<i>STATUSONLY</i>	Determines if data should be removed from the RDS FIFO.

Definition at line 1425 of file SI4735.cpp.

```
01426 {
01427     si47x\_rds\_command rds_cmd;
01428     static uint16_t lastFreq;
01429     // checking current FUNC (Am or FM)
01430     if (currentTune != FM\_TUNE\_FREQ)
01431         return;
01432
01433     if (lastFreq != currentWorkFrequency)
01434     {
01435         lastFreq = currentWorkFrequency;
01436         clearRdsBuffer2A();
01437         clearRdsBuffer2B();
01438         clearRdsBuffer0A();
01439     }
```

```

01439     }
01440
01441     waitToSend();
01442
01443     rds_cmd.arg.INTACK = INTACK;
01444     rds_cmd.arg.MTFIFO = MTFIFO;
01445     rds_cmd.arg.STATUSONLY = STATUSONLY;
01446
01447     Wire.beginTransaction(deviceAddress);
01448     Wire.write(FM_RDS_STATUS);
01449     Wire.write(rds_cmd.raw);
01450     Wire.endTransmission();
01451
01452     do
01453     {
01454         waitToSend();
01455         // Gets response information
01456         Wire.requestFrom(deviceAddress, 13);
01457         for (uint8_t i = 0; i < 13; i++)
01458             currentRdsStatus.raw[i] = Wire.read();
01459     } while (currentRdsStatus.resp.ERR);
01460     delayMicroseconds(550);
01461 }

```

References si47x_rds_command::arg, clearRdsBuffer0A(), clearRdsBuffer2A(), clearRdsBuffer2B(), currentRdsStatus, currentTune, currentWorkFrequency, deviceAddress, FM_RDS_STATUS, FM_TUNE_FREQ, si47x_rds_command::raw, si47x_rds_status::raw, si47x_rds_status::resp, and waitToSend().

bool SI4735::getRdsSync () [inline]

1 = Valid Block B data has been received.

Definition at line 1086 of file SI4735.h.

```
01086 { return currentRdsStatus.resp.RDSSYNC; };
```

References currentRdsStatus, and si47x_rds_status::resp.

bool SI4735::getRdsSyncFound () [inline]

1 = Lost RDS synchronization

Definition at line 1083 of file SI4735.h.

```
01083 { return currentRdsStatus.resp.RDSSYNCFFOUND; };
```

References currentRdsStatus, and si47x_rds_status::resp.

bool SI4735::getRdsSyncLost () [inline]

1 = FIFO filled to minimum number of groups

Definition at line 1082 of file SI4735.h.

```
01082 { return currentRdsStatus.resp.RDSSYNCLOST; };
```

References currentRdsStatus, and si47x_rds_status::resp.

char * SI4735::getRdsText (void)

Gets the RDS Text when the message is of the Group Type 2 version A

Returns

char* The string (char array) with the content (Text) received from group 2A

Definition at line 1647 of file SI4735.cpp.

```

01648 {
01649
01650     // Needs to get the "Text segment address code".
01651     // Each message should be ended by the code 0D (Hex)
01652
01653     if (rdsTextAddress2A >= 16)
01654         rdsTextAddress2A = 0;
01655 }

```

```

01656     getNext4Block(&rds_buffer2A[rdsTextAddress2A * 4]);
01657
01658     rdsTextAddress2A += 4;
01659
01660     return rds_buffer2A;
01661 }

```

References getNext4Block(), rds_buffer2A, and rdsTextAddress2A.

char * SI4735::getRdsText0A (void)

Gets the station name and other messages.

Returns

char* should return a string with the station name. However, some stations send other kind of messages

Definition at line 1669 of file SI4735.cpp.

```

01670 {
01671     si47x_rds_blockb blkB;
01672
01673     // getRdsStatus();
01674
01675     if (getRdsReceived())
01676     {
01677         if (getRdsGroupType() == 0)
01678         {
01679             // Process group type 0
01680             blkB.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01681             blkB.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01682
01683             rdsTextAddress0A = blkB.group0.address;
01684             if (rdsTextAddress0A >= 0 && rdsTextAddress0A < 4)
01685             {
01686                 getNext2Block(&rds_buffer0A[rdsTextAddress0A * 2]);
01687                 rds_buffer0A[8] = '\0';
01688                 return rds_buffer0A;
01689             }
01690         }
01691     }
01692     return NULL;
01693 }

```

References currentRdsStatus, getNext2Block(), getRdsGroupType(), getRdsReceived(), si47x_rds_blockb::group0, si47x_rds_blockb::raw, rds_buffer0A, rdsTextAddress0A, and si47x_rds_status::resp.

char * SI4735::getRdsText2A (void)

Gets the Text processed for the 2A group

Returns

char* string with the Text of the group A2

Definition at line 1700 of file SI4735.cpp.

```

01701 {
01702     si47x_rds_blockb blkB;
01703
01704     // getRdsStatus();
01705     if (getRdsReceived())
01706     {
01707         if (getRdsGroupType() == 2 /* && getRdsVersionCode() == 0 */)
01708         {
01709             // Process group 2A
01710             // Decode B block information
01711             blkB.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01712             blkB.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01713             rdsTextAddress2A = blkB.group2.address;
01714
01715             if (rdsTextAddress2A >= 0 && rdsTextAddress2A < 16)
01716             {
01717                 getNext4Block(&rds_buffer2A[rdsTextAddress2A * 4]);
01718                 rds_buffer2A[63] = '\0';
01719                 return rds_buffer2A;
01720             }
01721         }
01722     }
01723 }

```

```

01720         }
01721     }
01722 }
01723     return NULL;
01724 }

```

References `currentRdsStatus`, `getNext4Block()`, `getRdsGroupType()`, `getRdsReceived()`, `si47x_rds_blockb::group2`, `si47x_rds_blockb::raw`, `rds_buffer2A`, `rdsTextAdress2A`, and `si47x_rds_status::resp`.

char * SI4735::getRdsText2B (void)

Gets the Text processed for the 2B group

Returns

char* string with the Text of the group AB

Definition at line 1732 of file SI4735.cpp.

```

01733 {
01734     si47x\_rds\_blockb blkB;
01735
01736     // getRdsStatus\(\);
01737     // if (getRdsReceived\(\))
01738     // {
01739     // if (getRdsNewBlockB\(\))
01740     // {
01741     if (getRdsGroupType\(\) == 2 /* && getRdsVersionCode\(\) == 1 */)
01742     {
01743         // Process group 2B
01744         blkB.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01745         blkB.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01746         rdsTextAdress2B = blkB.group2.address;
01747         if (rdsTextAdress2B >= 0 && rdsTextAdress2B < 16)
01748         {
01749             getNext2Block(&rds\_buffer2B[rdsTextAdress2B * 2]);
01750             return rds\_buffer2B;
01751         }
01752     }
01753     // }
01754     // }
01755     return NULL;
01756 }

```

References `currentRdsStatus`, `getNext2Block()`, `getRdsGroupType()`, `si47x_rds_blockb::group2`, `si47x_rds_blockb::raw`, `rds_buffer2B`, `rdsTextAdress2B`, and `si47x_rds_status::resp`.

uint8_t SI4735::getRdsTextSegmentAddress (void)

Returns the address of the text segment. 2A - Each text segment in version 2A groups consists of four characters. A messages of this group can be have up to 64 characters. 2B - In version 2B groups, each text segment consists of only two characters. When the current RDS status is using this version, the maximum message length will be 32 characters.

Returns

uint8_t the address of the text segment.

Definition at line 1535 of file SI4735.cpp.

```

01536 {
01537     si47x\_rds\_blockb blkb;
01538     blkb.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01539     blkb.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01540
01541     return blkb.refined.content;
01542 }

```

References `currentRdsStatus`, `si47x_rds_blockb::raw`, `si47x_rds_blockb::refined`, and `si47x_rds_status::resp`.

char * SI4735::getRdsTime (void)

Gets the RDS time and date when the Group type is 4

Returns

char* a string with hh:mm +/- offset

Definition at line 1763 of file SI4735.cpp.

```
01764 {
01765     // Under Test and construction
01766     // Need to check the Group Type before.
01767     si47x\_rds\_date\_time dt;
01768
01769     uint16_t minute;
01770     uint16_t hour;
01771
01772     if (getRdsGroupType() == 4)
01773     {
01774         char offset_sign;
01775         int offset_h;
01776         int offset_m;
01777
01778         // uint16_t y, m, d;
01779
01780         dt.raw[4] = currentRdsStatus.resp.BLOCKBL;
01781         dt.raw[5] = currentRdsStatus.resp.BLOCKBH;
01782         dt.raw[2] = currentRdsStatus.resp.BLOCKCL;
01783         dt.raw[3] = currentRdsStatus.resp.BLOCKCH;
01784         dt.raw[0] = currentRdsStatus.resp.BLOCKDL;
01785         dt.raw[1] = currentRdsStatus.resp.BLOCKDH;
01786
01787         // Unfortunately it was necessary to work well on the GCC compiler
01788         // on 32-bit platforms. See si47x_rds_date_time (typedef union) and CGG
01789         // "Crosses boundary" issue/features.
01790         // Now it is working on Atmega328, STM32, Arduino DUE, ESP32 and
01791         // more.
01792         minute = (dt.refined.minute2 << 2) | dt.refined.minute1;
01793         hour = (dt.refined.hour2 << 4) | dt.refined.hour1;
01794
01795         offset_sign = (dt.refined.offset_sense == 1) ? '+' : '-';
01796         offset_h = (dt.refined.offset * 30) / 60;
01797         offset_m = (dt.refined.offset * 30) - (offset_h * 60);
01798         // sprintf(rds\_time, "%02u:%02u %c%02u:%02u", dt.refined.hour,
01799         dt.refined.minute, offset_sign, offset_h, offset_m);
01800         sprintf(rds\_time, "%02u:%02u %c%02u:%02u", hour, minute,
01801         offset_sign, offset_h, offset_m);
01802         return rds\_time;
01803     }
01804     return NULL;
01805 }
```

References [currentRdsStatus](#), [getRdsGroupType\(\)](#), [si47x_rds_date_time::raw](#), [rds_time](#), [si47x_rds_date_time::refined](#), and [si47x_rds_status::resp](#).

uint8_t SI4735::getRdsVersionCode (void)

Gets the version code (extracted from the Block B)

Returns

0=A or 1=B

Definition at line 1549 of file SI4735.cpp.

```
01550 {
01551     si47x\_rds\_blockb blk;
01552
01553     blk.raw.lowValue = currentRdsStatus.resp.BLOCKBL;
01554     blk.raw.highValue = currentRdsStatus.resp.BLOCKBH;
01555
01556     return blk.refined.versionCode;
01557 }
```

References [currentRdsStatus](#), [si47x_rds_blockb::raw](#), [si47x_rds_blockb::refined](#), and [si47x_rds_status::resp](#).

uint8_t SI4735::getReceivedSignalStrengthIndicator () [inline]

Returns true if the channel is currently valid as determined by the seek/tune properties (0x1403, 0x1404, 0x1108)

Definition at line 964 of file SI4735.h.

```
00964 { return currentStatus.resp.RSSI; };
```

References `currentStatus`, and `si47x_response_status::resp`.

bool SI4735::getSignalQualityInterrupt () [inline]

STATUS RESPONSE Set of methods to get current status information. Call them after `getStatus` or `getFrequency` or `seekStation` See Si47XX PROGRAMMING GUIDE; AN332; pages 63

Definition at line 956 of file SI4735.h.

```
00956 { return currentStatus.resp.RSQINT; };
```

References `currentStatus`, and `si47x_response_status::resp`.

void SI4735::getStatus ()

Gets the current status of the Si4735 (AM or FM)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 73 (FM) and 139 (AM)

Definition at line 947 of file SI4735.cpp.

```
00948 {  
00949     getStatus(0, 1);  
00950 }
```

Referenced by `getFrequency()`.

void SI4735::getStatus (uint8_t INTACK, uint8_t CANCEL)

Gets the current status of the Si4735 (AM or FM)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 73 (FM) and 139 (AM)

Parameters

<i>uint8_t</i>	INTACK Seek/Tune Interrupt Clear. If set, clears the seek/tune complete interrupt status indicator;
<i>uint8_t</i>	CANCEL Cancel seek. If set, aborts a seek currently in progress;

Definition at line 916 of file SI4735.cpp.

```
00917 {  
00918     si47x\_tune\_status status;  
00919     uint8_t cmd = (currentTune == FM\_TUNE\_FREQ) ? FM\_TUNE\_STATUS :  
AM\_TUNE\_STATUS;  
00920  
00921     waitToSend();  
00922  
00923     status.arg.INTACK = INTACK;  
00924     status.arg.CANCEL = CANCEL;  
00925  
00926     Wire.beginTransaction(deviceAddress);  
00927     Wire.write(cmd);  
00928     Wire.write(status.raw);  
00929     Wire.endTransmission();  
00930     // Reads the current status (including current frequency).  
00931     do  
00932     {  
00933         waitToSend();  
00934         Wire.requestFrom(deviceAddress, 8); // Check it  
00935         // Gets response information  
00936         for (uint8_t i = 0; i < 8; i++)  
00937             currentStatus.raw[i] = Wire.read();  
00938     } while (currentStatus.resp.ERR); // If error, try it again  
00939     waitToSend();  
00940 }
```


References AM_TUNE_STATUS, si47x_tune_status::arg, currentStatus, currentTune, deviceAddress, FM_TUNE_FREQ, FM_TUNE_STATUS, si47x_response_status::raw, si47x_tune_status::raw, si47x_response_status::resp, and waitToSend().

bool SI4735::getStatusCTS () [inline]

Return the Error flag (true or false) of status of the least Tune or Seek.

Definition at line 960 of file SI4735.h.

```
00960 { return currentStatus.resp.CTS; };
```

References currentStatus, and si47x_response_status::resp.

bool SI4735::getStatusError () [inline]

Seek/Tune Complete Interrupt; 1 = Tune complete has been triggered.

Definition at line 959 of file SI4735.h.

```
00959 { return currentStatus.resp.ERR; };
```

References currentStatus, and si47x_response_status::resp.

uint8_t SI4735::getStatusMULT () [inline]

Returns integer containing the SNR metric when tune is complete (dB).

Definition at line 966 of file SI4735.h.

```
00966 { return currentStatus.resp.MULT; };
```

References currentStatus, and si47x_response_status::resp.

uint8_t SI4735::getStatusSNR () [inline]

Returns integer Received Signal Strength Indicator (dB $\hat{1}/4$ V).

Definition at line 965 of file SI4735.h.

```
00965 { return currentStatus.resp.SNR; };
```

References currentStatus, and si47x_response_status::resp.

bool SI4735::getStatusValid () [inline]

Returns true if a seek hit the band limit (WRAP = 0 in FM_START_SEEK) or wrapped to the original frequency (WRAP = 1).

Definition at line 963 of file SI4735.h.

```
00963 { return currentStatus.resp.VALID; };
```

References currentStatus, and si47x_response_status::resp.

bool SI4735::getTuneCompleteTriggered () [inline]

Gets Radio Data System (RDS) Interrupt.

Definition at line 958 of file SI4735.h.

```
00958 { return currentStatus.resp.STCINT; };
```

References currentStatus, and si47x_response_status::resp.

uint8_t SI4735::getTuneFrequencyFast () [inline]

Definition at line 1045 of file SI4735.h.

```
01045 { return currentFrequencyParams.arg.FAST; };
```

References si47x_set_frequency::arg, and currentFrequencyParams.

uint8_t SI4735::getTuneFrequencyFreeze () [inline]

FAST Tuning. If set, executes fast and invalidated tune. The tune status will not be accurate.

Definition at line 1047 of file SI4735.h.

```
01047 { return currentFrequencyParams.arg.FREEZE; };
```

References [si47x_set_frequency::arg](#), and [currentFrequencyParams](#).

uint8_t SI4735::getVolume ()

Gets the current volume level.

See also

[setVolume\(\)](#)

Returns

volume (domain: 0 - 63)

Definition at line 1240 of file SI4735.cpp.

```
01241 {  
01242     return this->volume;  
01243 }
```

References [volume](#).

bool SI4735::isAgcEnabled () [inline]

Definition at line 982 of file SI4735.h.

```
00982 { return !currentAgcStatus.refined.AGCDIS; }; // Returns true if the  
AGC is enabled
```

References [currentAgcStatus](#), and [si47x_agc_status::refined](#).

bool SI4735::isCurrentTuneFM ()

Returns true if the current function is FM (FM_TUNE_FREQ).

Returns

true if the current function is FM (FM_TUNE_FREQ).

Definition at line 667 of file SI4735.cpp.

```
00668 {  
00669     return (currentTune == FM\_TUNE\_FREQ);  
00670 }
```

References [currentTune](#), and [FM_TUNE_FREQ](#).

void SI4735::patchPowerUp ()

This method can be used to prepare the device to apply SSBRX patch Call [queryLibraryId](#) before call this method. Powerup the device by issuing the POWER_UP command with FUNC = 1 (AM/SW/LW Receive)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 64 and 215-220 and

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE AMENDMENT FOR SI4735-D60
SSB AND NBFM PATCHES; page 7.

Definition at line 2165 of file SI4735.cpp.

```
02166 {  
02167     waitToSend();  
02168     Wire.beginTransaction(deviceAddress);  
02169     Wire.write(POWER\_UP);  
02170     Wire.write(0b00110001); // Set to AM, Enable External Crystal  
Oscillator; Set patch enable; GP02 output disabled; CTS interrupt disabled.  
02171     Wire.write(SI473X\_ANALOG\_AUDIO); // Set to Analog Output  
02172     Wire.endTransmission();  
02173     delayMicroseconds(2500);
```

02174 }

References deviceAddress, POWER_UP, SI473X_ANALOG_AUDIO, and waitToSend().

si47x_firmware_query_library SI4735::queryLibraryId ()

SI47XX PATCH RESOURCES Call it first if you are applying a patch on [SI4735](#). Used to confirm if the patch is compatible with the internal device library revision. See SI47XX PROGRAMMING GUIDE; AN332; pages 64 and 215-220.

Returns

a struct [si47x_firmware_query_library](#) (see it in [SI4735.h](#)) Query the library information

You have to call this function if you are applying a patch on SI47XX (SI4735-D60)

The first command that is sent to the device is the POWER_UP command to confirm that the patch is compatible with the internal device library revision. The device moves into the powerup mode, returns the reply, and moves into the powerdown mode. The POWER_UP command is sent to the device again to configure the mode of the device and additionally is used to start the patching process. When applying the patch, the PATCH bit in ARG1 of the POWER_UP command must be set to 1 to begin the patching process. [AN332 page 219].

See also

SI47XX PROGRAMMING GUIDE; AN332; pages 214, 215, 216, 219

[si47x_firmware_query_library](#) in [SI4735.h](#)

Returns

[si47x_firmware_query_library](#) Library Identification

Definition at line 2128 of file SI4735.cpp.

```
02129 {
02130     si47x\_firmware\_query\_library libraryID;
02131
02132     powerDown(); // Is it necessary
02133
02134     // delay(500);
02135
02136     waitToSend();
02137     Wire.beginTransaction(deviceAddress);
02138     Wire.write(POWER\_UP);
02139     Wire.write(0b00011111); // Set to Read Library ID, disable
interrupt; disable GPO2OEN; boot normally; enable External Crystal Oscillator .
02140     Wire.write(SI473X\_ANALOG\_AUDIO); // Set to Analog Line Input.
02141     Wire.endTransmission();
02142
02143     do
02144     {
02145         waitToSend();
02146         Wire.requestFrom(deviceAddress, 8);
02147         for (int i = 0; i < 8; i++)
02148             libraryID.raw[i] = Wire.read();
02149     } while (libraryID.resp.ERR); // If error found, try it again.
02150
02151     delayMicroseconds(2500);
02152
02153     return libraryID;
02154 }
```

References deviceAddress, POWER_UP, powerDown(), si47x_firmware_query_library::raw, si47x_firmware_query_library::resp, SI473X_ANALOG_AUDIO, and waitToSend().

void SI4735::RdsInit ()

RDS implementation Starts the control variables for RDS.

Definition at line 1276 of file SI4735.cpp.

```
01277 {
01278     clearRdsBuffer2A();
01279     clearRdsBuffer2B();
01280     clearRdsBuffer0A();
```

```

01281     rdsTextAddress2A = rdsTextAddress2B = lastTextFlagAB = rdsTextAddress0A =
0;
01282 }

```

References [clearRdsBuffer0A\(\)](#), [clearRdsBuffer2A\(\)](#), [clearRdsBuffer2B\(\)](#), [lastTextFlagAB](#), [rdsTextAddress0A](#), [rdsTextAddress2A](#), and [rdsTextAddress2B](#).

Referenced by [setRdsConfig\(\)](#).

void SI4735::seekStation (uint8_t *SEEKUP*, uint8_t *WRAP*)

Look for a station

See also

[Si47XX PROGRAMMING GUIDE; AN332](#); pages 55, 72, 125 and 137

Parameters

<i>SEEKUP</i>	Seek Up/Down. Determines the direction of the search, either UP = 1, or DOWN = 0.
<i>Wrap/Halt.</i>	Determines whether the seek should Wrap = 1, or Halt = 0 when it hits the band limit.

Definition at line 1108 of file [SI4735.cpp](#).

```

01109 {
01110     si47x\_seek seek;
01111
01112     // Check which FUNCTION (AM or FM) is working now
01113     uint8_t seek_start = (currentTune == FM\_TUNE\_FREQ) ? FM\_SEEK\_START :
AM\_SEEK\_START;
01114
01115     waitToSend();
01116
01117     seek.arg.SEEKUP = SEEKUP;
01118     seek.arg.WRAP = WRAP;
01119
01120     Wire.beginTransaction(deviceAddress);
01121     Wire.write(seek_start);
01122     Wire.write(seek.raw);
01123
01124     if (seek_start == AM\_SEEK\_START)
01125     {
01126         Wire.write(0x00); // Always 0
01127         Wire.write(0x00); // Always 0
01128         Wire.write(0x00); // Tuning Capacitor: The tuning capacitor value
01129         Wire.write(0x00); // will be selected
01130     }
01131
01132     Wire.endTransmission();
01133     delay(100);
01134 }

```

References [AM_SEEK_START](#), [si47x_seek::arg](#), [currentTune](#), [deviceAddress](#), [FM_SEEK_START](#), [FM_TUNE_FREQ](#), [si47x_seek::raw](#), and [waitToSend\(\)](#).

Referenced by [seekStationDown\(\)](#), and [seekStationUp\(\)](#).

void SI4735::seekStationDown ()

Search the previous station

See also

[seekStation\(uint8_t SEEKUP, uint8_t WRAP\)](#)

Definition at line 1153 of file [SI4735.cpp](#).

```

01154 {
01155     seekStation(0, 1);
01156     delay(50);
01157     getFrequency();
01158 }

```

References [getFrequency\(\)](#), and [seekStation\(\)](#).

void SI4735::seekStationUp ()

Search for the next station

See also

[seekStation\(uint8_t SEEKUP, uint8_t WRAP\)](#)

Definition at line 1141 of file SI4735.cpp.

```
01142 {  
01143     seekStation(1, 1);  
01144     delay(50);  
01145     getFrequency();  
01146 }
```

References [getFrequency\(\)](#), and [seekStation\(\)](#).

void SI4735::sendProperty (uint16_t *propertyValue*, uint16_t *parameter*) [protected]

Sends (sets) property to the SI47XX This method is used for others to send generic properties and params to SI47XX

See also

SI47XX PROGRAMMING GUIDE; AN332; pages 68, 124 and 133.

Definition at line 678 of file SI4735.cpp.

```
00679 {  
00680     si47x\_property property;  
00681     si47x\_property param;  
00682  
00683     property.value = propertyValue;  
00684     param.value = parameter;  
00685     waitToSend();  
00686     Wire.beginTransmission(deviceAddress);  
00687     Wire.write(SET\_PROPERTY);  
00688     Wire.write(0x00);  
00689     Wire.write(property.raw.byteHigh); // Send property - High byte - most  
significant first  
00690     Wire.write(property.raw.byteLow); // Send property - Low byte - less  
significant after  
00691     Wire.write(param.raw.byteHigh); // Send the arguments. High Byte -  
Most significant first  
00692     Wire.write(param.raw.byteLow); // Send the arguments. Low Byte - Less  
significant after  
00693     Wire.endTransmission();  
00694     delayMicroseconds(550);  
00695 }
```

References [deviceAddress](#), [si47x_property::raw](#), [SET_PROPERTY](#), [si47x_property::value](#), and [waitToSend\(\)](#).

Referenced by [digitalOutputFormat\(\)](#), [digitalOutputSampleRate\(\)](#), [setAmSoftMuteMaxAttenuation\(\)](#), [setAudioMute\(\)](#), [setAvcAmMaxGain\(\)](#), [setFmBlendMonoThreshold\(\)](#), [setFmBlendMultiPathMonoThreshold\(\)](#), [setFmBlendMultiPathStereoThreshold\(\)](#), [setFmBlendRssiMonoThreshold\(\)](#), [setFmBlendRssiStereoThreshold\(\)](#), [setFmBlendSnrMonoThreshold\(\)](#), [setFmBlendSnrStereoThreshold\(\)](#), [setFmBlendStereoThreshold\(\)](#), [setSeekAmLimits\(\)](#), [setSeekAmSpacing\(\)](#), [setSeekRssiThreshold\(\)](#), [setSeekSrnThreshold\(\)](#), [setSsbSoftMuteMaxAttenuation\(\)](#), and [setVolume\(\)](#).

void SI4735::sendSSBModeProperty () [protected]

Just send the property SSB_MOD to the device. Internal use (privete method).

Definition at line 2081 of file SI4735.cpp.

```
02082 {  
02083     si47x\_property property;  
02084     property.value = SSB\_MODE;  
02085     waitToSend();  
02086     Wire.beginTransmission(deviceAddress);  
02087     Wire.write(SET\_PROPERTY);  
02088     Wire.write(0x00); // Always 0x00  
02089     Wire.write(property.raw.byteHigh); // High byte first  
02090     Wire.write(property.raw.byteLow); // Low byte after  
02091     Wire.write(currentSSBMode.raw[1]); // SSB MODE params; freq. high byte  
first  
02092     Wire.write(currentSSBMode.raw[0]); // SSB MODE params; freq. low byte  
after  
02093 }
```

```

02094     Wire.endTransmission();
02095     delayMicroseconds(550);
02096 }

```

References currentSSBMode, deviceAddress, si47x_property::raw, si47x_ssb_mode::raw, SET_PROPERTY, SSB_MODE, si47x_property::value, and waitToSend().

Referenced by setSSBSidebandCutoffFilter(), setSSBAudioBandwidth(), setSSBAutomaticVolumeControl(), setSSBAvcDivider(), setSSBConfig(), setSSBDspAfc(), and setSSBSoftMute().

void SI4735::setAmSoftMuteMaxAttenuation () [inline]

Definition at line 976 of file SI4735.h.

```

00976 {sendProperty(AM_SOFT_MUTE_MAX_ATTENUATION, 0)};

```

References AM_SOFT_MUTE_MAX_ATTENUATION, and sendProperty().

void SI4735::setAmSoftMuteMaxAttenuation (uint8_t smattn) [inline]

Definition at line 975 of file SI4735.h.

```

00975 {sendProperty(AM_SOFT_MUTE_MAX_ATTENUATION, smattn)};

```

References AM_SOFT_MUTE_MAX_ATTENUATION, and sendProperty().

void SI4735::setAudioMute (bool off)

Returns the current volume level.

Sets the audio on or off

See also

See Si47XX PROGRAMMING GUIDE; AN332; pages 62, 123, 171

Parameters

<i>value</i>	if true, mute the audio; if false unmute the audio.
--------------	---

Definition at line 1228 of file SI4735.cpp.

```

01228 {
01229     uint16_t value = (off)? 3:0; // 3 means mute; 0 means unmute
01230     sendProperty(RX_HARD_MUTE, value);
01231 }

```

References RX_HARD_MUTE, and sendProperty().

void SI4735::setAutomaticGainControl (uint8_t AGCDIS, uint8_t AGCIDX)

If FM, overrides AGC setting by disabling the AGC and forcing the LNA to have a certain gain that ranges between 0 (minimum attenuation) and 26 (maximum attenuation); If AM/SSB, Overrides the AM AGC setting by disabling the AGC and forcing the gain index that ranges between 0 (minimum attenuation) and 37+ATTN_BACKUP (maximum attenuation);

See also

Si47XX PROGRAMMING GUIDE; AN332; For FM page 81; for AM page 143

Parameters

<i>uint8_t</i>	AGCDIS This param selects whether the AGC is enabled or disabled (0 = AGC enabled; 1 = AGC disabled);
<i>uint8_t</i>	AGCIDX AGC Index (0 = Minimum attenuation (max gain); 1 – 36 = Intermediate attenuation); if > greater than 36 - Maximum attenuation (min gain)).

Definition at line 1001 of file SI4735.cpp.

```

01002 {
01003     si47x_agc_override agc;
01004
01005     uint8_t cmd;

```

```

01006
01007     cmd = (currentTune == FM_TUNE_FREQ) ? FM_AGC_OVERRIDE : AM_AGC_OVERRIDE;
01008
01009     agc.arg.AGCDIS = AGCDIS;
01010     agc.arg.AGCIDX = AGCIDX;
01011
01012     waitToSend();
01013
01014     Wire.beginTransaction(deviceAddress);
01015     Wire.write(cmd);
01016     Wire.write(agc.raw[0]);
01017     Wire.write(agc.raw[1]);
01018     Wire.endTransmission();
01019
01020     waitToSend();
01021 }

```

References AM_AGC_OVERRIDE, si47x_agc_override::arg, currentTune, deviceAddress, FM_AGC_OVERRIDE, FM_TUNE_FREQ, si47x_agc_override::raw, and waitToSend().

void SI4735::setAvcAmMaxGain () [inline]

Definition at line 972 of file SI4735.h.

```

00972 { sendProperty(AM_AUTOMATIC_VOLUME_CONTROL_MAX_GAIN, ((currentAvcAmMaxGain =
48) * 340));};

```

References AM_AUTOMATIC_VOLUME_CONTROL_MAX_GAIN, currentAvcAmMaxGain, and sendProperty().

Referenced by setAM().

void SI4735::setAvcAmMaxGain (uint8_t gain)

Sets the maximum gain for automatic volume control. If no parameter is sent, it will be consider 48dB.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 152

Parameters

<i>uint8_t</i>	gain Select a value between 12 and 192. Defaul value 48dB.
----------------	--

Definition at line 1031 of file SI4735.cpp.

```

01031                                     {
01032     uint16_t aux;
01033     aux = ( gain > 12 && gain < 193 )? (gain * 340) : (48 * 340);
01034     currentAvcAmMaxGain = gain;
01035     sendProperty(AM_AUTOMATIC_VOLUME_CONTROL_MAX_GAIN, aux);
01036 }

```

References AM_AUTOMATIC_VOLUME_CONTROL_MAX_GAIN, currentAvcAmMaxGain, and sendProperty().

void SI4735::setBandwidth (uint8_t AMCHFLT, uint8_t AMPLFLT)

Selects the bandwidth of the channel filter for AM reception. The choices are 6, 4, 3, 2, 2.5, 1.8, or 1 (kHz). The default bandwidth is 2 kHz. Works only in AM / SSB (LW/MW/SW)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 125, 151, 277, 181.

Parameters

<i>AMCHFLT</i>	the choices are: 0 = 6 kHz Bandwidth 1 = 4 kHz Bandwidth 2 = 3 kHz Bandwidth 3 = 2 kHz Bandwidth 4 = 1 kHz Bandwidth 5 = 1.8 kHz Bandwidth 6 = 2.5 kHz Bandwidth, gradual roll off 7–15 = Reserved (Do not use).
<i>AMPLFLT</i>	Enables the AM Power Line Noise Rejection Filter.

Definition at line 632 of file SI4735.cpp.

```

00633 {
00634     si47x_bandwidth_config filter;

```

```

00635     si47x\_property property;
00636
00637     if (currentTune == FM\_TUNE\_FREQ) // Only for AM/SSB mode
00638         return;
00639
00640     if (AMCHFLT > 6)
00641         return;
00642
00643     property.value = AM\_CHANNEL\_FILTER;
00644
00645     filter.param.AMCHFLT = AMCHFLT;
00646     filter.param.AMPLFLT = AMPLFLT;
00647
00648     waitToSend();
00649     this->volume = volume;
00650     Wire.beginTransaction(deviceAddress);
00651     Wire.write(SET\_PROPERTY);
00652     Wire.write(0x00); // Always 0x00
00653     Wire.write(property.raw.byteHigh); // High byte first
00654     Wire.write(property.raw.byteLow); // Low byte after
00655     Wire.write(filter.raw[1]); // Raw data for AMCHFLT and
00656     Wire.write(filter.raw[0]); // AMPLFLT
00657     Wire.endTransmission();
00658     waitToSend();
00659 }

```

References [AM_CHANNEL_FILTER](#), [currentTune](#), [deviceAddress](#), [FM_TUNE_FREQ](#), [si47x_bandwidth_config::param](#), [si47x_property::raw](#), [si47x_bandwidth_config::raw](#), [SET_PROPERTY](#), [si47x_property::value](#), [volume](#), and [waitToSend](#)().

void SI4735::setFmBlendMonoThreshold (uint8_t parameter)

Sets RSSI threshold for mono blend (Full mono below threshold, blend above threshold). To force stereo set this to 0. To force mono set this to 127. Default value is 30 dB $\hat{1}/4$ V.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 56.

Parameters

<i>parameter</i>	valid values: 0 to 127
------------------	------------------------

Definition at line 719 of file SI4735.cpp.

```

00720 {
00721     sendProperty(FM\_BLEND\_MONO\_THRESHOLD, parameter);
00722 }

```

References [FM_BLEND_MONO_THRESHOLD](#), and [sendProperty](#)().

void SI4735::setFmBlendMultiPathMonoThreshold (uint8_t parameter)

Sets Multipath threshold for mono blend (Full mono above threshold, blend below threshold). To force stereo, set to 100. To force mono, set to 0. The default is 60.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 60.

Parameters

<i>parameter</i>	valid values: 0 to 100
------------------	------------------------

Definition at line 796 of file SI4735.cpp.

```

00797 {
00798     sendProperty(FM\_BLEND\_MULTIPATH\_MONO\_THRESHOLD, parameter);
00799 }

```

References [FM_BLEND_MULTIPATH_MONO_THRESHOLD](#), and [sendProperty](#)().

void SI4735::setFmBlendMultiPathStereoThreshold (uint8_t parameter)

Sets multipath threshold for stereo blend (Full stereo below threshold, blend above threshold). To force stereo, set this to 100. To force mono, set this to 0. Default value is 20.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 60.

Parameters

<i>parameter</i>	valid values: 0 to 100
------------------	------------------------

Definition at line 783 of file SI4735.cpp.

```
00784 {  
00785     sendProperty(FM_BLEND_MULTIPATH_STEREO_THRESHOLD, parameter);  
00786 }
```

References FM_BLEND_MULTIPATH_STEREO_THRESHOLD, and [sendProperty](#)().

void SI4735::setFmBLendRssiMonoThreshold (uint8_t *parameter*)

Sets RSSI threshold for mono blend (Full mono below threshold, blend above threshold). To force stereo, set this to 0. To force mono, set this to 127. Default value is 30 dB \hat{I} $\frac{1}{4}$ V.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 59.

Parameters

<i>parameter</i>	valid values: 0 to 127
------------------	------------------------

Definition at line 744 of file SI4735.cpp.

```
00745 {  
00746     sendProperty(FM_BLEND_RSSI_MONO_THRESHOLD, parameter);  
00747 }
```

References FM_BLEND_RSSI_MONO_THRESHOLD, and [sendProperty](#)().

void SI4735::setFmBlendRssiStereoThreshold (uint8_t *parameter*)

Sets RSSI threshold for stereo blend. (Full stereo above threshold, blend below threshold.) To force stereo, set this to 0. To force mono, set this to 127. Default value is 49 dB \hat{I} $\frac{1}{4}$ V.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 59.

Parameters

<i>parameter</i>	valid values: 0 to 127
------------------	------------------------

Definition at line 731 of file SI4735.cpp.

```
00732 {  
00733     sendProperty(FM_BLEND_RSSI_STEREO_THRESHOLD, parameter);  
00734 }
```

References FM_BLEND_RSSI_STEREO_THRESHOLD, and [sendProperty](#)().

void SI4735::setFmBLendSnrMonoThreshold (uint8_t *parameter*)

Sets SNR threshold for mono blend (Full mono below threshold, blend above threshold). To force stereo, set this to 0. To force mono, set this to 127. Default value is 14 dB.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 59.

Parameters

<i>parameter</i>	valid values: 0 to 127
------------------	------------------------

Definition at line 770 of file SI4735.cpp.

```
00771 {  
00772     sendProperty(FM_BLEND_SNR_MONO_THRESHOLD, parameter);  
00773 }
```

References FM_BLEND_SNR_MONO_THRESHOLD, and [sendProperty](#)().

void SI4735::setFmBlendSnrStereoThreshold (uint8_t *parameter*)

Sets SNR threshold for stereo blend (Full stereo above threshold, blend below threshold). To force stereo, set this to 0. To force mono, set this to 127. Default value is 27 dB.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 59.

Parameters

<i>parameter</i>	valid values: 0 to 127
------------------	------------------------

Definition at line 757 of file SI4735.cpp.

```
00758 {  
00759     sendProperty\(FM\_BLEND\_SNR\_STEREO\_THRESHOLD, parameter\);  
00760 }
```

References FM_BLEND_SNR_STEREO_THRESHOLD, and sendProperty().

void SI4735::setFmBlendStereoThreshold (uint8_t *parameter*)

Sets RSSI threshold for stereo blend (Full stereo above threshold, blend below threshold).

To force stereo, set this to 0. To force mono, set this to 127.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 90.

Parameters

<i>parameter</i>	valid values: 0 to 127
------------------	------------------------

Definition at line 706 of file SI4735.cpp.

```
00707 {  
00708     sendProperty\(FM\_BLEND\_STEREO\_THRESHOLD, parameter\);  
00709 }
```

References FM_BLEND_STEREO_THRESHOLD, and sendProperty().

void SI4735::setFmStereoOff ()

Turn Off Stereo operation.

Definition at line 804 of file SI4735.cpp.

```
00805 {  
00806     // TO DO  
00807 }
```

void SI4735::setFmStereoOn ()

Turn Off Stereo operation.

Definition at line 812 of file SI4735.cpp.

```
00813 {  
00814     // TO DO  
00815 }
```

void SI4735::setFunction (uint8_t *FUNC*)

void SI4735::setI2CFastMode (void) [inline]

Sets I2C buss to 100KHz.

Definition at line 1141 of file SI4735.h.

```
01141 { Wire.setClock(400000); };
```

void SI4735::setI2CFastModeCustom (long *value* = 500000) [inline]

Sets I2C buss to 400KHz.

Sets the I2C bus to a given value.

ATTENTION: use this function with cation

Parameters

<i>value</i>	in Hz. For example: The values 500000 sets the bus to 500KHz.
--------------	---

Definition at line 1150 of file SI4735.h.

```
01150 { Wire.setClock(value); };
```

void SI4735::setI2CLowSpeedMode (void) [inline]

Definition at line 1139 of file SI4735.h.

```
01139 { Wire.setClock(10000); };
```

void SI4735::setI2CStandardMode (void) [inline]

Sets I2C buss to 10KHz.

Definition at line 1140 of file SI4735.h.

```
01140 { Wire.setClock(100000); };
```

void SI4735::setRdsConfig (uint8_t *RDSEN*, uint8_t *BLETHA*, uint8_t *BLETHB*, uint8_t *BLETHC*, uint8_t *BLETHD*)

RESP3 - RDS FIFO Used; Number of groups remaining in the RDS FIFO (0 if empty).

Sets RDS property (FM_RDS_CONFIG) Configures RDS settings to enable RDS processing (RDSEN) and set RDS block error thresholds. When a RDS Group is received, all block errors must be less than or equal the associated block error threshold for the group to be stored in the RDS FIFO.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 104

IMPORTANT: All block errors must be less than or equal the associated block error threshold for the group to be stored in the RDS FIFO. 0 = No errors. 1 = 1–2 bit errors detected and corrected. 2 = 3–5 bit errors detected and corrected. 3 = Uncorrectable. Recommended Block Error Threshold options: 2,2,2,2 = No group stored if any errors are uncorrected. 3,3,3,3 = Group stored regardless of errors. 0,0,0,0 = No group stored containing corrected or uncorrected errors. 3,2,3,3 = Group stored with corrected errors on B, regardless of errors on A, C, or D.

Parameters

<i>uint8_t</i>	RDSEN RDS Processing Enable; 1 = RDS processing enabled.
<i>uint8_t</i>	BLETHA Block Error Threshold BLOCKA.
<i>uint8_t</i>	BLETHB Block Error Threshold BLOCKB.
<i>uint8_t</i>	BLETHC Block Error Threshold BLOCKC.
<i>uint8_t</i>	BLETHD Block Error Threshold BLOCKD.

Definition at line 1340 of file SI4735.cpp.

```
01341 {
01342     si47x\_property property;
01343     si47x\_rds\_config config;
01344
01345     waitToSend();
01346
01347     // Set property value
01348     property.value = FM\_RDS\_CONFIG;
01349
01350     // Arguments
01351     config.arg.RDSEN = RDSEN;
01352     config.arg.BLETHA = BLETHA;
01353     config.arg.BLETHB = BLETHB;
01354     config.arg.BLETHC = BLETHC;
01355     config.arg.BLETHD = BLETHD;
01356     config.arg.DUMMY1 = 0;
01357
01358     Wire.beginTransaction(deviceAddress);
01359     Wire.write(SET\_PROPERTY);
01360     Wire.write(0x00); // Always 0x00 (I need to check it)
01361     Wire.write(property.raw.byteHigh); // Send property - High byte - most
significant first
01362     Wire.write(property.raw.byteLow); // Low byte
01363     Wire.write(config.raw[1]); // Send the arguments. Most
significant first
01364     Wire.write(config.raw[0]);
```

```

01365     Wire.endTransmission();
01366     delayMicroseconds(550);
01367
01368     RdsInit();
01369 }

```

References `si47x_rds_config::arg`, `deviceAddress`, `FM_RDS_CONFIG`, `si47x_property::raw`, `si47x_rds_config::raw`, `RdsInit()`, `SET_PROPERTY`, and `waitToSend()`.

void SI4735::setRdsIntSource (uint8_t *RDSNEWBLOCKB*, uint8_t *RDSNEWBLOCKA*, uint8_t *RDSSYNCFFOUND*, uint8_t *RDSSYNCLOST*, uint8_t *RDSRECV*)

Configures interrupt related to RDS

Use this method if want to use interrupt

See also

Si47XX PROGRAMMING GUIDE; AN332; page 103

Parameters

<i>RDSRECV</i>	If set, generate RDSINT when RDS FIFO has at least FM_RDS_INT_FIFO_COUNT entries.
<i>RDSSYNCLOST</i>	If set, generate RDSINT when RDS loses synchronization.
<i>RDSSYNCFFOUND</i>	set, generate RDSINT when RDS gains synchronization.
<i>RDSNEWBLOCKA</i>	If set, generate an interrupt when Block A data is found or subsequently changed
<i>RDSNEWBLOCKB</i>	If set, generate an interrupt when Block B data is found or subsequently changed

Definition at line 1384 of file SI4735.cpp.

```

01385 {
01386     si47x\_property property;
01387     si47x\_rds\_int\_source rds_int_source;
01388
01389     if (currentTune != FM\_TUNE\_FREQ)
01390         return;
01391
01392     rds_int_source.refined.RDSNEWBLOCKB = RDSNEWBLOCKB;
01393     rds_int_source.refined.RDSNEWBLOCKA = RDSNEWBLOCKA;
01394     rds_int_source.refined.RDSSYNCFFOUND = RDSSYNCFFOUND;
01395     rds_int_source.refined.RDSSYNCLOST = RDSSYNCLOST;
01396     rds_int_source.refined.RDSRECV = RDSRECV;
01397     rds_int_source.refined.DUMMY1 = 0;
01398     rds_int_source.refined.DUMMY2 = 0;
01399
01400     property.value = FM\_RDS\_INT\_SOURCE;
01401
01402     waitToSend();
01403
01404     Wire.beginTransaction(deviceAddress);
01405     Wire.write(SET\_PROPERTY);
01406     Wire.write(0x00); // Always 0x00 (I need to check it)
01407     Wire.write(property.raw.byteHigh); // Send property - High byte - most
significant first
01408     Wire.write(property.raw.byteLow); // Low byte
01409     Wire.write(rds_int_source.raw[1]); // Send the arguments. Most
significant first
01410     Wire.write(rds_int_source.raw[0]);
01411     Wire.endTransmission();
01412     waitToSend();
01413 }

```

References `currentTune`, `deviceAddress`, `FM_RDS_INT_SOURCE`, `FM_TUNE_FREQ`, `si47x_property::raw`, `si47x_rds_int_source::raw`, `si47x_rds_int_source::refined`, `SET_PROPERTY`, and `waitToSend()`.

void SI4735::setSBBSidebandCutoffFilter (uint8_t *SBCUTFLT*)

Sets SBB Sideband Cutoff Filter for band pass and low pass filters: 0 = Band pass filter to cutoff both the unwanted side band and high frequency components > 2.0 kHz of the

wanted side band. (default) 1 = Low pass filter to cutoff the unwanted side band. Other values = not allowed.

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Parameters

<i>SBCUTFLT</i>	0 or 1; see above
-----------------	-------------------

Definition at line 1989 of file SI4735.cpp.

```
01990 {  
01991     currentSSBMode.param.SBCUTFLT = SBCUTFLT;  
01992     sendSSBModeProperty();  
01993 }
```

References [currentSSBMode](#), [si47x_ssb_mode::param](#), and [sendSSBModeProperty\(\)](#).

void SI4735::setSeekAmLimits (uint16_t bottom, uint16_t top)

Sets the bottom frequency and top frequency of the AM band for seek. Default is 520 to 1710.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 127, 161, and 162

Parameters

<i>uint16_t</i>	bottom - the bottom of the AM band for seek
<i>uint16_t</i>	top - the top of the AM band for seek

Definition at line 1168 of file SI4735.cpp.

```
01169 {  
01170     sendProperty(AM_SEEK_BAND_BOTTOM, bottom);  
01171     sendProperty(AM_SEEK_BAND_TOP, top);  
01172 }
```

References [AM_SEEK_BAND_BOTTOM](#), [AM_SEEK_BAND_TOP](#), and [sendProperty\(\)](#).

void SI4735::setSeekAmSpacing (uint16_t spacing)

Selects frequency spacing for AM seek. Default is 10 kHz spacing.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 163, 229 and 283

Parameters

<i>uint16_t</i>	spacing - step in KHz
-----------------	-----------------------

Definition at line 1181 of file SI4735.cpp.

```
01182 {  
01183     sendProperty(AM_SEEK_FREQ_SPACING, spacing);  
01184 }
```

References [AM_SEEK_FREQ_SPACING](#), and [sendProperty\(\)](#).

void SI4735::setSeekRssiThreshold (uint16_t value)

Sets the RSSI threshold for a valid AM Seek/Tune. If the value is zero then RSSI threshold is not considered when doing a seek. Default value is 25 dB $\frac{1}{4}$ V.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 127

Definition at line 1203 of file SI4735.cpp.

```
01204 {  
01205     sendProperty(AM_SEEK_RSSI_THRESHOLD, value);  
01206 }
```

References [AM_SEEK_RSSI_THRESHOLD](#), and [sendProperty\(\)](#).

void SI4735::setSeekSrnThreshold (uint16_t value)

Sets the SNR threshold for a valid AM Seek/Tune. If the value is zero then SNR threshold is not considered when doing a seek. Default value is 5 dB.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 127

Definition at line 1192 of file SI4735.cpp.

```
01193 {  
01194     sendProperty(AM\_SEEK\_SNR\_THRESHOLD, value);  
01195 }
```

References [AM_SEEK_SNR_THRESHOLD](#), and [sendProperty\(\)](#).

void SI4735::setSSB (uint16_t fromFreq, uint16_t toFreq, uint16_t initialFreq, uint16_t step, uint8_t usbIsb)

Definition at line 2061 of file SI4735.cpp.

```
02062 {  
02063     currentMinimumFrequency = fromFreq;  
02064     currentMaximumFrequency = toFreq;  
02065     currentStep = step;  
02066  
02067     if (initialFreq < fromFreq || initialFreq > toFreq)  
02068         initialFreq = fromFreq;  
02069  
02070     setSSB(usbIsb);  
02071  
02072     currentWorkFrequency = initialFreq;  
02073     setFrequency(currentWorkFrequency);  
02074     delayMicroseconds(550);  
02075 }
```

References [currentMaximumFrequency](#), [currentMinimumFrequency](#), [currentStep](#), [currentWorkFrequency](#), and [setFrequency\(\)](#).

void SI4735::setSSB (uint8_t usbIsb)

Set the radio to AM function. It means: LW MW and SW.

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; pages 13 and 14

[setAM\(\)](#)

void [SI4735::setFrequency](#)(uint16_t freq)

Parameters

<i>usbIsb</i>	upper or lower side band; 1 = LSB; 2 = USB
---------------	--

Definition at line 2035 of file SI4735.cpp.

```
02036 {  
02037     // Is it needed to load patch when switch to SSB?  
02038     // powerDown();  
02039     // It starts with the same AM parameters.  
02040     setPowerUp(1, 1, 0, 1, 1, SI473X\_ANALOG\_AUDIO);  
02041     radioPowerUp();  
02042     // ssbPowerUp(); // Not used for regular operation  
02043     setVolume(volume); // Set to previous configured volume  
02044     currentSsbStatus = usbIsb;  
02045     lastMode = SSB\_CURRENT\_MODE;  
02046 }
```

References [currentSsbStatus](#), [lastMode](#), [radioPowerUp\(\)](#), [setPowerUp\(\)](#), [setVolume\(\)](#), [SI473X_ANALOG_AUDIO](#), [SSB_CURRENT_MODE](#), and [volume](#).

void SI4735::setSSBAudioBandwidth (uint8_t AUDIOBW)

SSB Audio Bandwidth for SSB mode

0 = 1.2 kHz low-pass filter* . (default) 1 = 2.2 kHz low-pass filter* . 2 = 3.0 kHz low-pass filter. 3 = 4.0 kHz low-pass filter. 4 = 500 Hz band-pass filter for receiving CW signal, i.e. [250 Hz, 750 Hz] with center frequency at 500 Hz when USB is selected or [-250 Hz, -750 1Hz] with center frequency at -500Hz when LSB is selected* . 5 = 1 kHz band-pass filter for receiving CW signal, i.e. [500 Hz, 1500 Hz] with center frequency at 1 kHz when USB is selected or [-500 Hz, -1500 1 Hz] with center frequency at -1kHz

when LSB is selected* . Other values = reserved. Note: If audio bandwidth selected is about 2 kHz or below, it is recommended to set SBCUTFLT[3:0] to 0 to enable the band pass filter for better high- cut performance on the wanted side band. Otherwise, set it to 1.

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Parameters

<i>AUDIOBW</i>	the valid values are 0, 1, 2, 3, 4 or 5; see description above
----------------	--

Definition at line 2018 of file SI4735.cpp.

```
02019 {
02020     // Sets the audio filter property parameter
02021     currentSSBMode.param.AUDIOBW = AUDIOBW;
02022     sendSSBModeProperty\(\);
02023 }
```

References `currentSSBMode`, `si47x_ssb_mode::param`, and `sendSSBModeProperty()`.

void SI4735::setSSBAutomaticVolumeControl (uint8_t *AVCEN*)

Sets SSB Automatic Volume Control (AVC) for SSB mode

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Parameters

<i>AVCEN</i>	0 = Disable AVC; 1 = Enable AVC (default).
--------------	--

Definition at line 1960 of file SI4735.cpp.

```
01961 {
01962     currentSSBMode.param.AVCEN = AVCEN;
01963     sendSSBModeProperty\(\);
01964 }
```

References `currentSSBMode`, `si47x_ssb_mode::param`, and `sendSSBModeProperty()`.

void SI4735::setSSBAvcDivider (uint8_t *AVC_DIVIDER*)

Sets AVC Divider

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Parameters

<i>AVC_DIVIDER</i>	SSB mode, set divider = 0; SYNC mode, set divider = 3; Other values = not allowed.
--------------------	--

Definition at line 1973 of file SI4735.cpp.

```
01974 {
01975     currentSSBMode.param.AVC_DIVIDER = AVC_DIVIDER;
01976     sendSSBModeProperty\(\);
01977 }
```

References `currentSSBMode`, `si47x_ssb_mode::param`, and `sendSSBModeProperty()`.

void SI4735::setSSBBfo (int *offset*)

Single Side Band (SSB) implementation

This implementation was tested only on Si4735-D60 device.

SSB modulation is a refinement of amplitude modulation that one of the side band and the carrier are suppressed.

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; pages 3 and 5

First of all, it is important to say that the SSB patch content is not part of this library. The patches used here were made available by Mr. Vadim Afonkin on his Dropbox repository. It is important to note that the author of this library does not encourage anyone to use the

SSB patches content for commercial purposes. In other words, this library only supports SSB patches, the patches themselves are not part of this library.

What does SSB patch means? In this context, a patch is a piece of software used to change the behavior of the [SI4735](#) device. There is little information available about patching the [SI4735](#).

The following information is the understanding of the author of this project and it is not necessarily correct.

A patch is executed internally (run by internal MCU) of the device. Usually, patches are used to fix bugs or add improvements and new features of the firmware installed in the internal ROM of the device. Patches to the [SI4735](#) are distributed in binary form and have to be transferred to the internal RAM of the device by the host MCU (in this case Arduino boards). Since the RAM is volatile memory, the patch stored into the device gets lost when you turn off the system. Consequently, the content of the patch has to be transferred again to the device each time after turn on the system or reset the device.

I would like to thank Mr Vadim Afonkin for making available the SSBRX patches for SI4735-D60 on his Dropbox repository. On this repository you have two files, `amrx_6_0_1_ssbrx_patch_full_0x9D29.csg` and `amrx_6_0_1_ssbrx_patch_init_0xA902.csg`. It is important to know that the patch content of the original files is constant hexadecimal representation used by the language C/C++. Actually, the original files are in ASCII format (not in binary format). If you are not using C/C++ or if you want to load the files directly to the [SI4735](#), you must convert the values to numeric value of the hexadecimal constants. For example: `0x15 = 21 (00010101)`; `0x16 = 22 (00010110)`; `0x01 = 1 (00000001)`; `0xFF = 255 (11111111)`;

ATTENTION: The author of this project does not guarantee that procedures shown here will work in your development environment. Given this, it is at your own risk to continue with the procedures suggested here. This library works with the I²C communication protocol and it is designed to apply a SSB extension PATCH to CI SI4735-D60. Once again, the author disclaims any liability for any damage this procedure may cause to your [SI4735](#) or other devices that you are using. Sets the SSB Beat Frequency Offset (BFO).

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; pages 5 and 23

Parameters

<i>offset</i>	16-bit signed value (unit in Hz). The valid range is -16383 to +16383 Hz.
---------------	---

Definition at line 1865 of file SI4735.cpp.

```
01866 {
01867
01868     si47x\_property property;
01869     si47x\_frequency bfo_offset;
01870
01871     if (currentTune == FM\_TUNE\_FREQ) // Only for AM/SSB mode
01872         return;
01873
01874     waitToSend();
01875
01876     property.value = SSB\_BFO;
01877     bfo_offset.value = offset;
01878
01879     Wire.beginTransaction(deviceAddress);
01880     Wire.write(SET\_PROPERTY);
01881     Wire.write(0x00); // Always 0x00
01882     Wire.write(property.raw.byteHigh); // High byte first
01883     Wire.write(property.raw.byteLow); // Low byte after
01884     Wire.write(bfo_offset.raw.FREQH); // Offset freq. high byte first
01885     Wire.write(bfo_offset.raw.FREQL); // Offset freq. low byte first
01886
01887     Wire.endTransmission();
01888     delayMicroseconds(550);
01889 }
```


References `currentTune`, `deviceAddress`, `FM_TUNE_FREQ`, `si47x_frequency::raw`, `si47x_property::raw`, `SET_PROPERTY`, `SSB_BFO`, `si47x_frequency::value`, and `waitToSend()`.

void SI4735::setSSBConfig (uint8_t *AUDIOBW*, uint8_t *SBCUTFLT*, uint8_t *AVC_DIVIDER*, uint8_t *AVCEN*, uint8_t *SMUTESEL*, uint8_t *DSP_AFCDIS*)

Set the SSB receiver mode details: 1) Enable or disable AFC track to carrier function for receiving normal AM signals; 2) Set the audio bandwidth; 3) Set the side band cutoff filter; 4) Set soft-mute based on RSSI or SNR; 5) Enable or disable automatic volume control (AVC) function.

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Parameters

<i>AUDIOBW</i>	SSB Audio bandwidth; 0 = 1.2KHz (default); 1=2.2KHz; 2=3KHz; 3=4KHz; 4=500Hz; 5=1KHz.
<i>SBCUTFLT</i>	SSB side band cutoff filter for band pass and low pass filter if 0, the band pass filter to cutoff both the unwanted side band and high frequency component > 2KHz of the wanted side band (default).
<i>AVC_DIVIDER</i>	set 0 for SSB mode; set 3 for SYNC mode.
<i>AVCEN</i>	SSB Automatic Volume Control (AVC) enable; 0=disable; 1=enable (default).
<i>SMUTESEL</i>	SSB Soft-mute Based on RSSI or SNR.
<i>DSP_AFCDIS</i>	DSP AFC Disable or enable; 0=SYNC MODE, AFC enable; 1=SSB MODE, AFC disable.

Definition at line 1910 of file SI4735.cpp.

```

01911 {
01912     if (currentTune == FM_TUNE_FREQ) // Only AM/SSB mode
01913         return;
01914
01915     currentSSBMode.param.AUDIOBW = AUDIOBW;
01916     currentSSBMode.param.SBCUTFLT = SBCUTFLT;
01917     currentSSBMode.param.AVC_DIVIDER = AVC_DIVIDER;
01918     currentSSBMode.param.AVCEN = AVCEN;
01919     currentSSBMode.param.SMUTESEL = SMUTESEL;
01920     currentSSBMode.param.DUMMY1 = 0;
01921     currentSSBMode.param.DSP_AFCDIS = DSP_AFCDIS;
01922
01923     sendSSBModeProperty();
01924 }
```

References `currentSSBMode`, `currentTune`, `FM_TUNE_FREQ`, `si47x_ssb_mode::param`, and `sendSSBModeProperty()`.

void SI4735::setSSBDspAfc (uint8_t *DSP_AFCDIS*)

Sets DSP AFC disable or enable

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Parameters

<i>DSP_AFCDIS</i>	0 = SYNC mode, AFC enable; 1 = SSB mode, AFC disable
-------------------	--

Definition at line 1933 of file SI4735.cpp.

```

01934 {
01935     currentSSBMode.param.DSP_AFCDIS = DSP_AFCDIS;
01936     sendSSBModeProperty();
01937 }
```

References `currentSSBMode`, `si47x_ssb_mode::param`, and `sendSSBModeProperty()`.

void SI4735::setSSBSoftMute (uint8_t *SMUTESEL*)

Sets SSB Soft-mute Based on RSSI or SNR Selection:

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Parameters

<i>SMUTESEL</i>	0 = Soft-mute based on RSSI (default); 1 = Soft-mute based on SNR.
-----------------	--

Definition at line 1947 of file SI4735.cpp.

```
01948 {  
01949     currentSSBMode.param.SMUTESEL = SMUTESEL;  
01950     sendSSBModeProperty();  
01951 }
```

References [currentSSBMode](#), [si47x_ssb_mode::param](#), and [sendSSBModeProperty\(\)](#).

void SI4735::setSsbSoftMuteMaxAttenuation () [inline]

Definition at line 979 of file SI4735.h.

```
00979 { sendProperty(SSB_SOFT_MUTE_MAX_ATTENUATION, 0); };
```

References [sendProperty\(\)](#), and [SSB_SOFT_MUTE_MAX_ATTENUATION](#).

void SI4735::setSsbSoftMuteMaxAttenuation (uint8_t *smattn*) [inline]

Definition at line 978 of file SI4735.h.

```
00978 { sendProperty(SSB_SOFT_MUTE_MAX_ATTENUATION, smattn); };
```

References [sendProperty\(\)](#), and [SSB_SOFT_MUTE_MAX_ATTENUATION](#).

void SI4735::setTuneFrequencyFast (uint8_t *FAST*) [inline]

Returns the FAST tuning status.

Definition at line 1046 of file SI4735.h.

```
01046 { currentFrequencyParams.arg.FAST = FAST; };
```

References [si47x_set_frequency::arg](#), and [currentFrequencyParams](#).

void SI4735::setTuneFrequencyFreeze (uint8_t *FREEZE*) [inline]

Returns the FREEZE status.

Definition at line 1048 of file SI4735.h.

```
01048 { currentFrequencyParams.arg.FREEZE = FREEZE; };
```

References [si47x_set_frequency::arg](#), and [currentFrequencyParams](#).

void SI4735::setVolume (uint8_t *volume*)

RESP8 - Returns the Chip Revision (ASCII).

Sets volume level (0 to 63)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 62, 123, 170, 173 and 204

Parameters

<i>uint8_t</i>	volume (domain: 0 - 63)
----------------	-------------------------

Definition at line 1215 of file SI4735.cpp.

```
01216 {  
01217     sendProperty(RX_VOLUME, volume);  
01218     this->volume = volume;  
01219 }
```

References [RX_VOLUME](#), [sendProperty\(\)](#), and [volume](#).

Referenced by [setAM\(\)](#), [setFM\(\)](#), [setSSB\(\)](#), [volumeDown\(\)](#), and [volumeUp\(\)](#).

void SI4735::ssbPowerUp ()

This function can be useful for debug and teste.

Definition at line 2191 of file SI4735.cpp.

```

02192 {
02193     waitToSend();
02194     Wire.beginTransaction(deviceAddress);
02195     Wire.write(POWER\_UP);
02196     Wire.write(0b00010001); // Set to AM/SSB, disable interrupt; disable
GPO2OEN; boot normally; enable External Crystal Oscillator .
02197     Wire.write(0b00000101); // Set to Analog Line Input.
02198     Wire.endTransmission();
02199     delayMicroseconds(2500);
02200
02201     powerUp.arg.CTSIEN = 0;           // 1 -> Interrupt anabled;
02202     powerUp.arg.GPO2OEN = 0;         // 1 -> GPO2 Output Enable;
02203     powerUp.arg.PATCH = 0;          // 0 -> Boot normally;
02204     powerUp.arg.XOSCEN = 1;          // 1 -> Use external crystal
oscillator;
02205     powerUp.arg.FUNC = 1;             // 0 = FM Receive; 1 = AM/SSB
(LW/MW/SW) Receiver.
02206     powerUp.arg.OPMODE = 0b00000101; // 0x5 = 00000101 = Analog audio
outputs (LOUT/ROUT).
02207 }

```

References [si473x_powerup::arg](#), [deviceAddress](#), [POWER_UP](#), [powerUp](#), and [waitToSend\(\)](#).

void SI4735::ssbSetup ()

Starts the Si473X device on SSB (same AM Mode). Same [SI4735::setup](#) optimized to improve loading patch performance

Definition at line 2180 of file SI4735.cpp.

```

02181 {
02182     // setPowerUp(powerUp.arg.CTSIEN, 0, 0, 1, 1, SI473X_ANALOG_AUDIO);
02183     reset();
02184     // radioPowerUp();
02185 }

```

References [reset\(\)](#).

void SI4735::volumeDown ()

Set sound volume level Down

See also

[setVolume\(\)](#)

Definition at line 1262 of file SI4735.cpp.

```

01263 {
01264     if (volume > 0)
01265         volume--;
01266     setVolume(volume);
01267 }

```

References [setVolume\(\)](#), and [volume](#).

void SI4735::volumeUp ()

Set sound volume level Up

See also

[setVolume\(\)](#)

Definition at line 1250 of file SI4735.cpp.

```

01251 {
01252     if (volume < 63)
01253         volume++;
01254     setVolume(volume);
01255 }

```

References [setVolume\(\)](#), and [volume](#).

Field Documentation

[si47x_agc_status](#) SI4735::currentAgcStatus [protected]

current RDS status

Definition at line 909 of file SI4735.h.

Referenced by getAgcGainIndex(), getAutomaticGainControl(), and isAgcEnabled().

uint8_t SI4735::currentAvcAmMaxGain = 48 [protected]

Store the last mode used.

Definition at line 901 of file SI4735.h.

Referenced by getCurrentAvcAmMaxGain(), setAM(), and setAvcAmMaxGain().

[si47x_frequency](#) **SI4735::currentFrequency [protected]**

Automatic Volume Control Gain for AM - Default 48.

Definition at line 903 of file SI4735.h.

Referenced by setFrequency().

[si47x_set_frequency](#) **SI4735::currentFrequencyParams [protected]**

data structure to get current frequency

Definition at line 904 of file SI4735.h.

Referenced by getTuneFrequencyFast(), getTuneFrequencyFreeze(), setFrequency(), setPowerUp(), setTuneFrequencyAntennaCapacitor(), setTuneFrequencyFast(), and setTuneFrequencyFreeze().

uint16_t SI4735::currentMaximumFrequency [protected]

minimum frequency of the current band

Definition at line 894 of file SI4735.h.

Referenced by frequencyDown(), frequencyUp(), setAM(), setFM(), and setSSB().

uint16_t SI4735::currentMinimumFrequency [protected]

tell the current tune (FM, AM or SSB)

Definition at line 893 of file SI4735.h.

Referenced by frequencyDown(), frequencyUp(), setAM(), setFM(), and setSSB().

[si47x_rds_status](#) **SI4735::currentRdsStatus [protected]**

firmware information

Definition at line 908 of file SI4735.h.

Referenced by getGroupLost(), getNext2Block(), getNext4Block(), getNumRdsFifoUsed(), getRdsFlagAB(), getRdsGroupType(), getRdsNewBlockA(), getRdsNewBlockB(), getRdsPI(), getRdsProgramType(), getRdsReceived(), getRdsStatus(), getRdsSync(), getRdsSyncFound(), getRdsSyncLost(), getRdsText0A(), getRdsText2A(), getRdsText2B(), getRdsTextSegmentAddress(), getRdsTime(), and getRdsVersionCode().

[si47x_rqs_status](#) **SI4735::currentRqsStatus [protected]**

Definition at line 905 of file SI4735.h.

Referenced by getCurrentAfcRailIndicator(), getCurrentBlendDetectInterrupt(), getCurrentMultipath(), getCurrentMultipathDetectHigh(), getCurrentMultipathDetectLow(), getCurrentPilot(), getCurrentReceivedSignalQuality(), getCurrentRSSI(), getCurrentRssiDetectHigh(), getCurrentRssiDetectLow(), getCurrentSignedFrequencyOffset(),

getCurrentSNR(), getCurrentSnrDetectHigh(), getCurrentSnrDetectLow(),
getCurrentSoftMuteIndicator(), getCurrentStereoBlend(), and getCurrentValidChannel().

si47x_ssb_mode SI4735::currentSSBMode [protected]

current AGC status

Definition at line 910 of file SI4735.h.

Referenced by sendSSBModeProperty(), setSBBSidebandCutoffFilter(),
setSSBAudioBandwidth(), setSSBAutomaticVolumeControl(), setSSBAvcDivider(),
setSSBConfig(), setSSBDspAfc(), and setSSBSoftMute().

uint8_t SI4735::currentSsbStatus [protected]

Definition at line 916 of file SI4735.h.

Referenced by setAM(), setFM(), setFrequency(), setSSB(), and SI4735().

si47x_response_status SI4735::currentStatus [protected]

current Radio Signal Quality status

Definition at line 906 of file SI4735.h.

Referenced by getACFIndicator(), getAntennaTuningCapacitor(), getBandLimit(), getFrequency(),
getRadioDataSystemInterrupt(), getReceivedSignalStrengthIndicator(),
getSignalQualityInterrupt(), getStatus(), getStatusCTS(), getStatusError(), getStatusMULT(),
getStatusSNR(), getStatusValid(), and getTuneCompleteTriggered().

uint16_t SI4735::currentStep [protected]

current frequency

Definition at line 897 of file SI4735.h.

Referenced by frequencyDown(), frequencyUp(), setAM(), setFM(), setFrequencyStep(), and
setSSB().

uint8_t SI4735::currentTune [protected]

pin used on Arduino Board to control interrupt. If -1, interrupt is no used.

Definition at line 891 of file SI4735.h.

Referenced by getAutomaticGainControl(), getCurrentReceivedSignalQuality(), getRdsStatus(),
getStatus(), isCurrentTuneFM(), seekStation(), setAutomaticGainControl(), setBandwidth(),
setFrequency(), setPowerUp(), setRdsIntSource(), setSSBBfo(), setSSBConfig(), and
setTuneFrequencyAntennaCapacitor().

uint16_t SI4735::currentWorkFrequency [protected]

maximum frequency of the current band

Definition at line 895 of file SI4735.h.

Referenced by frequencyDown(), frequencyUp(), getCurrentFrequency(), getFrequency(),
getRdsStatus(), setAM(), setFM(), setFrequency(), and setSSB().

int16_t SI4735::deviceAddress = SI473X_ADDR_SEN_LOW [protected]

rds_buffer0A current position

Definition at line 885 of file SI4735.h.

Referenced by disableFmDebug(), downloadPatch(), getAutomaticGainControl(), getCurrentReceivedSignalQuality(), getFirmware(), getRdsStatus(), getStatus(), patchPowerUp(), powerDown(), queryLibraryId(), radioPowerUp(), seekStation(), sendProperty(), sendSSBModeProperty(), setAutomaticGainControl(), setBandwidth(), setDeviceI2CAddress(), setDeviceOtherI2CAddress(), setFrequency(), setRdsConfig(), setRdsIntSource(), setSSBfo(), ssbPowerUp(), and waitToSend().

[si47x_firmware_information](#) **SI4735::firmwareInfo** [protected]

current device status

Definition at line 907 of file SI4735.h.

Referenced by getFirmware(), getFirmwareCHIPREV(), getFirmwareCMPMAJOR(), getFirmwareCMPMINOR(), getFirmwareFWMAJOR(), getFirmwareFWMINOR(), getFirmwarePATCHH(), getFirmwarePATCHL(), and getFirmwarePN().

uint8_t SI4735::interruptPin [protected]

pin used on Arduino Board to RESET the Si47XX device

Definition at line 889 of file SI4735.h.

Referenced by setup().

uint8_t SI4735::lastMode = -1 [protected]

current steps

Definition at line 899 of file SI4735.h.

Referenced by setAM(), setFM(), and setSSB().

uint8_t SI4735::lastTextFlagAB [protected]

current I2C buss address

Definition at line 887 of file SI4735.h.

Referenced by RdsInit().

[si473x_powerup](#) **SI4735::powerUp** [protected]

indicates if USB or LSB

Definition at line 912 of file SI4735.h.

Referenced by radioPowerUp(), setPowerUp(), and ssbPowerUp().

char SI4735::rds_buffer0A[9] [protected]

RDS Radio Text buffer - Station Informaation.

Definition at line 878 of file SI4735.h.

Referenced by clearRdsBuffer0A(), and getRdsText0A().

char SI4735::rds_buffer2A[65] [protected]

Definition at line 876 of file SI4735.h.

Referenced by clearRdsBuffer2A(), getRdsText(), and getRdsText2A().

char SI4735::rds_buffer2B[33] [protected]

RDS Radio Text buffer - Program Information.

Definition at line 877 of file SI4735.h.

Referenced by clearRdsBuffer2B(), and getRdsText2B().

char SI4735::rds_time[20] [protected]

RDS Basic tuning and switching information (Type 0 groups)

Definition at line 879 of file SI4735.h.

Referenced by getRdsTime().

int SI4735::rdsTextAddress0A [protected]

rds_buffer2B current position

Definition at line 883 of file SI4735.h.

Referenced by getRdsText0A(), and RdsInit().

int SI4735::rdsTextAddress2A [protected]

RDS date time received information

Definition at line 881 of file SI4735.h.

Referenced by getRdsText(), getRdsText2A(), and RdsInit().

int SI4735::rdsTextAddress2B [protected]

rds_buffer2A current position

Definition at line 882 of file SI4735.h.

Referenced by getRdsText2B(), and RdsInit().

uint8_t SI4735::resetPin [protected]

Definition at line 888 of file SI4735.h.

Referenced by getDeviceI2CAddress(), reset(), and setup().

uint8_t SI4735::volume = 32 [protected]

Definition at line 914 of file SI4735.h.

Referenced by getCurrentVolume(), getVolume(), setAM(), setBandwidth(), setFM(), setSSB(), setVolume(), volumeDown(), and volumeUp().

Function Documentation

int16_t SI4735::getDeviceI2CAddress (uint8_t resetPin)

I2C bus address setup.

Scans for two possible addresses for the Si47XX (0x11 or 0x63)

This function also sets the system to the found I2C bus address of Si47XX.

You do not need to use this function if the SEN PIN is configured to ground (GND). The default I2C address is 0x11. Use this function if you do not know how the SEN pin is configured.

Parameters

<i>uint8_t</i>	resetPin MCU Mater (Arduino) reset pin
----------------	--

Returns

int16_t 0x11 if the SEN pin of the Si47XX is low or 0x63 if the SEN pin of the Si47XX is HIGH or 0x0 if error.

Definition at line 77 of file SI4735.cpp.

```
00077                                     {
00078     int16_t error;
00079
00080     pinMode(resetPin, OUTPUT);
00081     delay(50);
00082     digitalWrite(resetPin, LOW);
00083     delay(50);
00084     digitalWrite(resetPin, HIGH);
00085
00086     Wire.begin();
00087     // check 0X11 I2C address
00088     Wire.beginTransmission(SI473X_ADDR_SEN_LOW);
00089     error = Wire.endTransmission();
00090     if ( error == 0 ) {
00091         setDeviceI2CAddress(0);
00092         return SI473X_ADDR_SEN_LOW;
00093     }
00094
00095     // check 0X63 I2C address
00096     Wire.beginTransmission(SI473X_ADDR_SEN_HIGH);
00097     error = Wire.endTransmission();
00098     if ( error == 0 ) {
00099         setDeviceI2CAddress(1);
00100         return SI473X_ADDR_SEN_HIGH;
00101     }
00102
00103     // Did find the device
00104     return 0;
00105 }
```

References SI4735::resetPin, SI4735::setDeviceI2CAddress(), SI473X_ADDR_SEN_HIGH, and SI473X_ADDR_SEN_LOW.

void SI4735::setDeviceI2CAddress (uint8_t senPin)

Sets the I2C Bus Address.

The parameter senPin is not the I2C bus address. It is the SEN pin setup of the schematic (eletronic circuit).

If it is connected to the ground, call this function with senPin = 0; else senPin = 1. You do not need to use this function if the SEN PIN configured to ground (GND).

The default value is 0x11 (senPin = 0). In this case you have to ground the pin SEN of the SI473X. If you want to change this address, call this function with senPin = 1

Parameters

<i>senPin</i>	0 - when the pin SEN (16 on SSOP version or pin 6 on QFN version) is set to low (GND - 0V) 1 - when the pin SEN (16 on SSOP version or pin 6 on QFN version) is set to high (+3.3V)
---------------	---

Definition at line 124 of file SI4735.cpp.

```
00124                                     {
00125     deviceAddress = (senPin)? SI473X_ADDR_SEN_HIGH : SI473X_ADDR_SEN_LOW;
00126 };
```


References SI4735::deviceAddress, SI473X_ADDR_SEN_HIGH, and SI473X_ADDR_SEN_LOW.

Referenced by SI4735::getDeviceI2CAddress().

void SI4735::setDeviceOtherI2CAddress (uint8_t i2cAddr)

Sets the onther I2C Bus Address (for Si470X)

You can set another I2C address different of 0x11 and 0x63

Parameters

<code>uint8_t</code>	i2cAddr (example 0x10)
----------------------	------------------------

Definition at line 137 of file SI4735.cpp.

```
00137                                     {
00138     deviceAddress = i2cAddr;
00139 };
```

References SI4735::deviceAddress.

SI4735::SI4735 ()

Construct a new [SI4735::SI4735](#) object.

Definition at line 35 of file SI4735.cpp.

```
00036 {
00037     // 1 = LSB and 2 = USB; 0 = AM, FM or WB
00038     currentSsbStatus = 0;
00039 }
```

References SI4735::currentSsbStatus.

void SI4735::waitInterrupr (void) [protected]

Interrupt handle.

If you setup interrupt, this function will be called whenever the Si4735 changes.

Definition at line 54 of file SI4735.cpp.

```
00055 {
00056     while (!data_from_si4735)
00057     ;
00058 }
```

Host and slave MCU setup

Functions

void [SI4735::reset](#) (void)

Reset the SI473X

void [SI4735::waitToSend](#) (void)

Wait for the si473x is ready (Clear to Send (CTS) status bit have to be 1).

void [SI4735::setPowerUp](#) (uint8_t CTSIEN, uint8_t GPO2OEN, uint8_t PATCH, uint8_t XOSCEN, uint8_t FUNC, uint8_t OPMODE)

Set the Power Up parameters for si473X.

void [SI4735::radioPowerUp](#) (void)
Powerup the Si47XX.

void [SI4735::analogPowerUp](#) (void)
You have to call setPowerUp method before.

void [SI4735::powerDown](#) (void)
Moves the device from powerup to powerdown mode.

Detailed Description

Function Documentation

void SI4735::analogPowerUp (void)

You have to call setPowerUp method before.

Deprecated:

Consider use radioPowerUp instead

See also

[SI4735::setPowerUp\(\)](#)

Si47XX PROGRAMMING GUIDE; AN332; pages 64, 129

Definition at line 265 of file SI4735.cpp.

```
00266 {  
00267     radioPowerUp ();  
00268 }
```

References [SI4735::radioPowerUp\(\)](#).

void SI4735::powerDown (void)

Moves the device from powerup to powerdown mode.

After Power Down command, only the Power Up command is accepted.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 67, 132

[radioPowerUp\(\)](#)

Definition at line 280 of file SI4735.cpp.

```
00281 {  
00282     waitToSend ();  
00283     Wire.beginTransaction(deviceAddress);  
00284     Wire.write(POWER\_DOWN);  
00285     Wire.endTransmission();  
00286     delayMicroseconds(2500);  
00287 }
```

References [SI4735::deviceAddress](#), [POWER_DOWN](#), and [SI4735::waitToSend\(\)](#).

Referenced by SI4735::queryLibraryId(), SI4735::setAM(), and SI4735::setFM().

void SI4735::radioPowerUp (void)

Powerup the Si47XX.

Before call this function call the setPowerUp to set up the parameters.

Parameters you have to set up with setPowerUp

CTSIEEN Interrupt anabled or disabled; GPO2OEN GPO2 Output Enable or disabled; PATCH Boot normally or patch; XOSCEN Use external crystal oscillator; FUNC defaultFunction = 0 = FM Receive; 1 = AM (LW/MW/SW) Receiver. OPMODE SI473X_ANALOG_AUDIO (B00000101) or SI473X_DIGITAL_AUDIO (B00001011)

See also

[SI4735::setPowerUp\(\)](#)

Si47XX PROGRAMMING GUIDE; AN332; pages 64, 129

Definition at line 241 of file SI4735.cpp.

```
00241 {
00242     // delayMicroseconds(1000);
00243     waitToSend();
00244     Wire.beginTransaction(deviceAddress);
00245     Wire.write(PowerUp);
00246     Wire.write(powerUp.raw[0]); // Content of ARG1
00247     Wire.write(powerUp.raw[1]); // Content of ARG2
00248     Wire.endTransmission();
00249     // Delay at least 500 ms between powerup command and first tune command
    to wait for
00250     // the oscillator to stabilize if XOSCEN is set and crystal is used as
    the RCLK.
00251     waitToSend();
00252     delay(10);
00253 }
```

References SI4735::deviceAddress, POWER_UP, SI4735::powerUp, si473x_powerup::raw, and SI4735::waitToSend().

Referenced by SI4735::analogPowerUp(), SI4735::setAM(), SI4735::setFM(), and SI4735::setSSB().

void SI4735::reset (void)

Reset the SI473X

See also

Si47XX PROGRAMMING GUIDE; AN332;

Definition at line 150 of file SI4735.cpp.

```
00151 {
00152     pinMode(resetPin, OUTPUT);
00153     delay(10);
00154     digitalWrite(resetPin, LOW);
00155     delay(10);
00156     digitalWrite(resetPin, HIGH);
00157     delay(10);
00158 }
```

References SI4735::resetPin.

Referenced by SI4735::ssbSetup().

void SI4735::setPowerUp (uint8_t CTSIEN, uint8_t GPO2OEN, uint8_t PATCH, uint8_t XOSCEN, uint8_t FUNC, uint8_t OPMODE)

Set the Power Up parameters for si473X.

Use this method to change the default behavior of the Si473X. Use it before PowerUp()

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 65 and 129

Parameters

uint8_t	CTSIEN sets Interrupt anabled or disabled (1 = anabled and 0 = disabled)
uint8_t	GPO2OEN sets GP02 Si473X pin enabled (1 = anabled and 0 = disabled)
uint8_t	PATCH Used for firmware patch updates. Use it always 0 here.
uint8_t	XOSCEN sets external Crystal enabled or disabled
uint8_t	FUNC sets the receiver function have to be used [0 = FM Receive; 1 = AM (LW/MW/SW) and SSB (if SSB patch appllied)]
uint8_t	OPMODE set the kind of audio mode you want to use.

Definition at line 194 of file SI4735.cpp.

```

00195 {
00196     powerUp.arg.CTSIEN = CTSIEN;    // 1 -> Interrupt anabled;
00197     powerUp.arg.GPO2OEN = GPO2OEN;  // 1 -> GPO2 Output Enable;
00198     powerUp.arg.PATCH = PATCH;      // 0 -> Boot normally;
00199     powerUp.arg.XOSCEN = XOSCEN;    // 1 -> Use external crystal oscillator;
00200     powerUp.arg.FUNC = FUNC;        // 0 = FM Receive; 1 = AM/SSB (LW/MW/SW)
Receiver.
00201     powerUp.arg.OPMODE = OPMODE;    // 0x5 = 00000101 = Analog audio outputs
(LOUT/ROUT) .
00202
00203     // Set the current tuning frequency mode 0x20 = FM and 0x40 = AM (LW/MW/
SW)
00204     // See See Si47XX PROGRAMMING GUIDE; AN332; pages 55 and 124
00205
00206     if (FUNC == 0)
00207     {
00208         currentTune = FM_TUNE_FREQ;
00209         currentFrequencyParams.arg.FREEZE = 1;
00210     }
00211     else
00212     {
00213         currentTune = AM_TUNE_FREQ;
00214         currentFrequencyParams.arg.FREEZE = 0;
00215     }
00216     currentFrequencyParams.arg.FAST = 1;
00217     currentFrequencyParams.arg.DUMMY1 = 0;
00218     currentFrequencyParams.arg.ANTCAPH = 0;
00219     currentFrequencyParams.arg.ANTCAPL = 1;
00220 }

```

References AM_TUNE_FREQ, si473x_powerup::arg, si47x_set_frequency::arg, SI4735::currentFrequencyParams, SI4735::currentTune, FM_TUNE_FREQ, and SI4735::powerUp.

Referenced by SI4735::setAM(), SI4735::setFM(), and SI4735::setSSB().

void SI4735::waitToSend (void)

Wait for the si473x is ready (Clear to Send (CTS) status bit have to be 1).

This function should be used before sending any command to a SI47XX device.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 63, 128

Definition at line 169 of file SI4735.cpp.

```

00170 {
00171     do
00172     {
00173         delayMicroseconds(MIN_DELAY_WAIT_SEND_LOOP); // Need check the
minimum value.
00174         Wire.requestFrom(deviceAddress, 1);
00175     } while (!(Wire.read() & B10000000));
00176 }

```

References SI4735::deviceAddress, and MIN_DELAY_WAIT_SEND_LOOP.

Referenced by SI4735::downloadPatch(), SI4735::getAutomaticGainControl(), SI4735::getCurrentReceivedSignalQuality(), SI4735::getFirmware(), SI4735::getRdsStatus(), SI4735::getStatus(), SI4735::patchPowerUp(), SI4735::powerDown(), SI4735::queryLibraryId(), SI4735::radioPowerUp(), SI4735::seekStation(), SI4735::sendProperty(), SI4735::sendSSBModeProperty(), SI4735::setAutomaticGainControl(), SI4735::setBandwidth(), SI4735::setFrequency(), SI4735::setRdsConfig(), SI4735::setRdsIntSource(), SI4735::setSSBBfo(), and SI4735::ssbPowerUp().

RDS Data types

Data Structures

union [si47x_rqs_status](#)

Radio Signal Quality data representation. [More...](#)

struct [si47x_rqs_status.resp](#)

union [si47x_rds_command](#)

Data type for RDS Status command and response information. [More...](#)

struct [si47x_rds_command.arg](#)

union [si47x_rds_status](#)

Response data type for current channel and reads an entry from the RDS FIFO. [More...](#)

struct [si47x_rds_status.resp](#)

union [si47x_rds_int_source](#)

FM_RDS_INT_SOURCE property data type. [More...](#)

struct [si47x_rds_int_source.refined](#)

union [si47x_rds_config](#)

Data type for FM_RDS_CONFIG Property. [More...](#)

struct [si47x_rds_config.arg](#)

union [si47x_rds_blocka](#)

Block A data type. [More...](#)

struct [si47x_rds_blocka.refined](#)

struct [si47x_rds_blocka.raw](#)

union [si47x_rds_blockb](#)

Block B data type. [More...](#)

struct [si47x_rds_blockb.group0](#)

struct [si47x_rds_blockb.group2](#)

struct [si47x_rds_blockb.refined](#)

struct [si47x_rds_blockb.raw](#)
union [si47x_rds_date_time](#)
struct [si47x_rds_date_time.refined](#)

Detailed Description

Data Structure Documentation

union si47x_rqs_status

Radio Signal Quality data representation.

Data type for status information about the received signal quality (FM_RSQ_STATUS and AM_RSQ_STATUS)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 75 and

Definition at line 414 of file SI4735.h.

Data Fields:

uint8_t	raw[8]	
struct	resp	
si47x_rqs_status		

struct si47x_rqs_status.resp

Definition at line 415 of file SI4735.h.

Data Fields:

uint8_t	AFCRL: 1	Valid Channel.
uint8_t	BLENDINT: 1	
uint8_t	CTS: 1	
uint8_t	DUMMY1: 1	
uint8_t	DUMMY2: 2	
uint8_t	DUMMY3: 1	Multipath Detect High.
uint8_t	DUMMY4: 1	AFC Rail Indicator.
uint8_t	DUMMY5: 4	Soft Mute Indicator. Indicates soft mute is engaged.
uint8_t	ERR: 1	
uint8_t	FREQOFF	RESP6 - Contains the current multipath metric. (0 = no multipath; 100 = full multipath)
uint8_t	MULT	RESP5 - Contains the current SNR metric (0–127 dB).
uint8_t	MULTHINT: 1	Multipath Detect Low.
uint8_t	MULTLINT: 1	SNR Detect High.
uint8_t	PILOT: 1	Indicates amount of stereo blend in% (100 = full stereo, 0 = full mono).
uint8_t	RDSINT: 1	

uint8_t	RSQINT: 1	
uint8_t	RSSI	Indicates stereo pilot presence.
uint8_t	RSSIHINT: 1	RSSI Detect Low.
uint8_t	RSSIILINT: 1	
uint8_t	SMUTE: 1	
uint8_t	SNR	RESP4 - Contains the current receive signal strength (0â€‘127 dBÎ¼V).
uint8_t	SNRHINT: 1	SNR Detect Low.
uint8_t	SNRLINT: 1	RSSI Detect High.
uint8_t	STBLEND: 7	
uint8_t	STCINT: 1	
uint8_t	VALID: 1	Blend Detect Interrupt.

union si47x_rds_command

Data type for RDS Status command and response information.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 77 and 78

Also https://en.wikipedia.org/wiki/Radio_Data_System

Definition at line 460 of file SI4735.h.

Data Fields:

struct si47x_rds_command	arg	
uint8_t	raw	

struct si47x_rds_command.arg

Definition at line 461 of file SI4735.h.

Data Fields:

uint8_t	dummy: 5	
uint8_t	INTACK: 1	
uint8_t	MTFIFO: 1	
uint8_t	STATUSONLY: 1	

union si47x_rds_status

Response data type for current channel and reads an entry from the RDS FIFO.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 77 and 78

Definition at line 478 of file SI4735.h.

Data Fields:

uint8_t	raw[13]	
struct si47x_rds_status	resp	

struct si47x_rds_status.resp

Definition at line 479 of file SI4735.h.

Data Fields:

uint8_t	BLEA: 2	
uint8_t	BLEB: 2	
uint8_t	BLEC: 2	
uint8_t	BLED: 2	RESP11 - RDS Block D; LOW byte.
uint8_t	BLOCKAH	RESP3 - RDS FIFO Used; Number of groups remaining in the RDS FIFO (0 if empty).
uint8_t	BLOCKAL	RESP4 - RDS Block A; HIGH byte.
uint8_t	BLOCKBH	RESP5 - RDS Block A; LOW byte.
uint8_t	BLOCKBL	RESP6 - RDS Block B; HIGH byte.
uint8_t	BLOCKCH	RESP7 - RDS Block B; LOW byte.
uint8_t	BLOCKCL	RESP8 - RDS Block C; HIGH byte.
uint8_t	BLOCKDH	RESP9 - RDS Block C; LOW byte.
uint8_t	BLOCKDL	RESP10 - RDS Block D; HIGH byte.
uint8_t	CTS: 1	
uint8_t	DUMMY1: 1	
uint8_t	DUMMY2: 2	
uint8_t	DUMMY3: 1	RDS Sync Found; 1 = Found RDS synchronization.
uint8_t	DUMMY4: 2	RDS New Block B; 1 = Valid Block B data has been received.
uint8_t	DUMMY5: 1	RDS Sync; 1 = RDS currently synchronized.
uint8_t	DUMMY6: 5	Group Lost; 1 = One or more RDS groups discarded due to FIFO overrun.
uint8_t	ERR: 1	
uint8_t	GRPLOST: 1	
uint8_t	RDSFIFOUSED	
uint8_t	RDSINT: 1	
uint8_t	RDSNEWBLOCKA: 1	
uint8_t	RDSNEWBLOCKB: 1	RDS New Block A; 1 = Valid Block A data has been received.
uint8_t	RDSRECV: 1	
uint8_t	RDSSYNC: 1	
uint8_t	RDSSYNCFFOUND: 1	RDS Sync Lost; 1 = Lost RDS synchronization.
uint8_t	RDSSYNCLOST: 1	RDS Received; 1 = FIFO filled to minimum number of groups set by RDSFIFOCNT.
uint8_t	RSQINT: 1	
uint8_t	STCINT: 1	

union si47x_rds_int_source

FM_RDS_INT_SOURCE property data type.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 103

also https://en.wikipedia.org/wiki/Radio_Data_System

Definition at line 533 of file SI4735.h.

Data Fields:

uint8_t	raw[2]	
struct	refined	
si47x_rds_int_source		

struct si47x_rds_int_source.refined

Definition at line 534 of file SI4735.h.

Data Fields:

uint8_t	DUMMY1: 1	f set, generate RDSINT when RDS gains synchronization.
uint8_t	DUMMY2: 5	If set, generate an interrupt when Block B data is found or subsequently changed.
uint8_t	DUMMY3: 5	Reserved - Always write to 0.
uint8_t	RDSNEWBLOCKA: 1	Always write to 0.
uint8_t	RDSNEWBLOCKB: 1	If set, generate an interrupt when Block A data is found or subsequently changed.
uint8_t	RDSRECV: 1	
uint8_t	RDSSYNCFIND: 1	If set, generate RDSINT when RDS loses synchronization.
uint8_t	RDSSYNCFLOST: 1	If set, generate RDSINT when RDS FIFO has at least FM_RDS_INT_FIFO_COUNT entries.

union si47x_rds_config

Data type for FM_RDS_CONFIG Property.

IMPORTANT: all block errors must be less than or equal the associated block error threshold for the group to be stored in the RDS FIFO. 0 = No errors; 1 = 1–2 bit errors detected and corrected; 2 = 3–5 bit errors detected and corrected; 3 = Uncorrectable. Recommended Block Error Threshold options: 2,2,2,2 = No group stored if any errors are uncorrected. 3,3,3,3 = Group stored regardless of errors. 0,0,0,0 = No group stored containing corrected or uncorrected errors. 3,2,3,3 = Group stored with corrected errors on B, regardless of errors on A, C, or D.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 58 and 104

Definition at line 564 of file SI4735.h.

Data Fields:

struct	arg	
si47x_rds_config		
uint8_t	raw[2]	

struct si47x_rds_config.arg

Definition at line 565 of file SI4735.h.

Data Fields:

uint8_t	BLETHA: 2	Block Error Threshold BLOCKB.
uint8_t	BLETHB: 2	Block Error Threshold BLOCKC.
uint8_t	BLETHC: 2	Block Error Threshold BLOCKD.
uint8_t	BLETHD: 2	
uint8_t	DUMMY1: 7	1 = RDS Processing Enable.
uint8_t	RDSEN: 1	

union si47x_rds_blocka

Block A data type.

Definition at line 582 of file SI4735.h.

Data Fields:

struct si47x_rds_blocka	raw	
struct si47x_rds_blocka	refined	

struct si47x_rds_blocka.refined

Definition at line 583 of file SI4735.h.

Data Fields:

uint16_t	pi	
----------	----	--

struct si47x_rds_blocka.raw

Definition at line 587 of file SI4735.h.

Data Fields:

uint8_t	highValue	
uint8_t	lowValue	

union si47x_rds_blockb

Block B data type.

For GCC on System-V ABI on 386-compatible (32-bit processors), the following stands:

1) Bit-fields are allocated from right to left (least to most significant). 2) A bit-field must entirely reside in a storage unit appropriate for its declared type. Thus a bit-field never crosses its unit boundary. 3) Bit-fields may share a storage unit with other struct/union members, including members that are not bit-fields. Of course, struct members occupy different parts of the storage unit. 4) Unnamed bit-fields' types do not affect the alignment of a structure or union, although individual bit-fields' member offsets obey the alignment constraints.

See also

also Si47XX PROGRAMMING GUIDE; AN332; pages 78 and 79

also https://en.wikipedia.org/wiki/Radio_Data_System

Definition at line 612 of file SI4735.h.

Data Fields:

struct si47x_rds_blockb	group0	
struct si47x_rds_blockb	group2	
struct si47x_rds_blockb	raw	
struct si47x_rds_blockb	refined	

struct si47x_rds_blockb.group0

Definition at line 613 of file SI4735.h.

Data Fields:

uint16_t	address: 2	
uint16_t	DI: 1	
uint16_t	groupType: 4	
uint16_t	MS: 1	
uint16_t	programType: 5	
uint16_t	TA: 1	
uint16_t	trafficProgramCode: 1	
uint16_t	versionCode: 1	

struct si47x_rds_blockb.group2

Definition at line 624 of file SI4735.h.

Data Fields:

uint16_t	address: 4	
uint16_t	groupType: 4	
uint16_t	programType: 5	
uint16_t	textABFlag: 1	
uint16_t	trafficProgramCode: 1	
uint16_t	versionCode: 1	

struct si47x_rds_blockb.refined

Definition at line 633 of file SI4735.h.

Data Fields:

uint16_t	content: 4	
uint16_t	groupType: 4	
uint16_t	programType: 5	
uint16_t	textABFlag: 1	
uint16_t	trafficProgramCode: 1	
uint16_t	versionCode: 1	

struct si47x_rds_blockb.raw

Definition at line 642 of file SI4735.h.

Data Fields:

uint8_t	highValue	
uint8_t	lowValue	

union si47x_rds_date_time

Group type 4A (RDS Date and Time) When group type 4A is used by the station, it shall be transmitted every minute according to EN 50067. This Structure uses blocks 2,3 and 5 (B,C,D)

ATTENTION: To make it compatible with 8, 16 and 32 bits platforms and avoid Crosses boundary, it was necessary to split minute and hour representation.

Definition at line 683 of file SI4735.h.

Data Fields:

uint8_t	raw[6]	
struct	refined	
si47x_rds_date_time		

struct si47x_rds_date_time.refined

Definition at line 684 of file SI4735.h.

Data Fields:

uint8_t	hour1: 4	
uint8_t	hour2: 1	
uint8_t	minute1: 2	
uint8_t	minute2: 4	
uint32_t	mjd: 17	
uint8_t	offset: 5	
uint8_t	offset_sense: 1	

Receiver Status and Setup

Data Structures

union [si47x_agc_status](#)

struct [si47x_agc_status.refined](#)

union [si47x_agc_override](#)

struct [si47x_agc_override.arg](#)

union [si47x_bandwidth_config](#)

struct [si47x_bandwidth_config.param](#)

union [si47x_ssb_mode](#)

struct [si47x_ssb_mode.param](#)

union [si4735_digital_output_format](#)

Digital audio output format data structure (Property 0x0102. DIGITAL_OUTPUT_FORMAT). [More...](#)

struct [si4735_digital_output_format.refined](#)

struct [si4735_digital_output_sample_rate](#)

Digital audio output sample structure (Property 0x0104. DIGITAL_OUTPUT_SAMPLE_RATE). [More...](#)

Detailed Description

Data Structure Documentation

union si47x_agc_status

AGC data types FM / AM and SSB structure to AGC

See also

Si47XX PROGRAMMING GUIDE; AN332; For FM page 80; for AM page 142

AN332 REV 0.8 Universal Programming Guide Amendment for SI4735-D60 SSB and NBFM patches; page 18.

Definition at line 708 of file SI4735.h.

Data Fields:

uint8_t	raw[3]	
struct	refined	
si47x_agc_status		

struct si47x_agc_status.refined

Definition at line 709 of file SI4735.h.

Data Fields:

uint8_t	AGCDIS: 1	
uint8_t	AGCIDX	
uint8_t	CTS: 1	
uint8_t	DUMMY: 7	
uint8_t	DUMMY1: 1	
uint8_t	DUMMY2: 2	
uint8_t	ERR: 1	
uint8_t	RDSINT: 1	
uint8_t	RSQINT: 1	
uint8_t	STCINT: 1	

union si47x_agc_override

If FM, Overrides AGC setting by disabling the AGC and forcing the LNA to have a certain gain that ranges between 0 (minimum attenuation) and 26 (maximum attenuation). If AM, overrides the AGC setting by disabling the AGC and forcing the gain index that ranges between 0

See also

Si47XX PROGRAMMING GUIDE; AN332; For FM page 81; for AM page 143

Definition at line 737 of file SI4735.h.

Data Fields:

struct	arg	
si47x_agc_override		
uint8_t	raw[2]	

struct si47x_agc_override.arg

Definition at line 738 of file SI4735.h.

Data Fields:

uint8_t	AGCDIS: 1	
---------	-----------	--

uint8_t	AGCIDX	
uint8_t	DUMMY: 7	

union si47x_bandwidth_config

The bandwidth of the AM channel filter data type AMCHFLT values: 0 = 6 kHz Bandwidth

1 = 4 kHz Bandwidth 2 = 3 kHz Bandwidth 3 = 2 kHz Bandwidth 4 = 1 kHz Bandwidth 5 = 1.8 kHz Bandwidth 6 = 2.5 kHz Bandwidth, gradual roll off 7–15 = Reserved (Do not use)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 125 and 151

Definition at line 764 of file SI4735.h.

Data Fields:

struct si47x_bandwidth_config	param	
uint8_t	raw[2]	

struct si47x_bandwidth_config.param

Definition at line 765 of file SI4735.h.

Data Fields:

uint8_t	AMCHFLT: 4	
uint8_t	AMPLFLT: 1	
uint8_t	DUMMY1: 4	Selects the bandwidth of the AM channel filter.
uint8_t	DUMMY2: 7	Enables the AM Power Line Noise Rejection Filter.

union si47x_ssb_mode

SSB - datatype for SSB_MODE (property 0x0101)

See also

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 24

Definition at line 782 of file SI4735.h.

Data Fields:

struct si47x_ssb_mode	param	
uint8_t	raw[2]	

struct si47x_ssb_mode.param

Definition at line 783 of file SI4735.h.

Data Fields:

uint8_t	AUDIOBW: 4	
uint8_t	AVC_DIVIDER: 4	SSB side band cutoff filter for band pass and low pass filter.
uint8_t	AVCEN: 1	set 0 for SSB mode; set 3 for SYNC mode;
uint8_t	DSP_AFCDIS: 1	Always write 0;
uint8_t	DUMMY1: 1	SSB Soft-mute Based on RSSI or SNR.

uint8_t	SBCUTFLT: 4	0 = 1.2KHz (default); 1=2.2KHz; 2=3KHz; 3=4KHz; 4=500Hz; 5=1KHz
uint8_t	SMUTESEL: 1	SSB Automatic Volume Control (AVC) enable; 0=disable; 1=enable (default);.

union si4735_digital_output_format

Digital audio output format data structure (Property 0x0102. DIGITAL_OUTPUT_FORMAT).

Used to configure: DCLK edge, data format, force mono, and sample precision.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 195.

Definition at line 805 of file SI4735.h.

Data Fields:

uint16_t	raw	
struct	refined	
si4735_digital_output_format		

struct si4735_digital_output_format.refined

Definition at line 806 of file SI4735.h.

Data Fields:

uint8_t	dummy: 8	Digital Output DCLK Edge (0 = use DCLK rising edge, 1 = use DCLK falling edge)
uint8_t	OFALL: 1	Digital Output Mode (0000=I2S, 0110 = Left-justified, 1000 = MSB at second DCLK after DFS pulse, 1100 = MSB at first DCLK after DFS pulse).
uint8_t	OMODE: 4	Digital Output Mono Mode (0=Use mono/stereo blend).
uint8_t	OMONO: 1	Digital Output Audio Sample Precision (0=16 bits, 1=20 bits, 2=24 bits, 3=8bits).
uint8_t	OSIZE: 2	

struct si4735_digital_output_sample_rate

Digital audio output sample structure (Property 0x0104. DIGITAL_OUTPUT_SAMPLE_RATE).

Used to enable digital audio output and to configure the digital audio output sample rate in samples per second (sps).

See also

Si47XX PROGRAMMING GUIDE; AN332; page 196.

Definition at line 825 of file SI4735.h.

Data Fields:

uint16_t	DOSR	
----------	------	--

SI473X data types

SI473X data representation.

Data Structures

union [si473x_powerup](#)

Power Up arguments data type. [More...](#)

struct [si473x_powerup.arg](#)

union [si47x_frequency](#)

Represents how the frequency is stored in the si4735. [More...](#)

struct [si47x_frequency.raw](#)

union [si47x_antenna_capacitor](#)

Antenna Tuning Capacitor data type manipulation. [More...](#)

struct [si47x_antenna_capacitor.raw](#)

union [si47x_set_frequency](#)

AM Tune frequency data type command (AM_TUNE_FREQ command) [More...](#)

struct [si47x_set_frequency.arg](#)

union [si47x_seek](#)

Seek frequency (automatic tuning) [More...](#)

struct [si47x_seek.arg](#)

union [si47x_response_status](#)

Response status command. [More...](#)

struct [si47x_response_status.resp](#)

union [si47x_firmware_information](#)

Data representation for Firmware Information (GET_REV) [More...](#)

struct [si47x_firmware_information.resp](#)

union [si47x_firmware_query_library](#)

Firmware Query Library ID response. [More...](#)

struct [si47x_firmware_query_library.resp](#)

union [si47x_tune_status](#)

Seek station status. [More...](#)

struct [si47x_tune_status.arg](#)

union [si47x_property](#)

Data type to deal with SET_PROPERTY command. [More...](#)

struct [si47x_property.raw](#)

Detailed Description

SI473X data representation.

The goal here is separate data from code. The Si47XX family works with many internal data that can be represented by data structure or defined data type in C/C++. These C/C++ resources have been used widely here.

This approach made the library easier to build and maintain. Each data structure created here has its reference (name of the document and page on which it was based). In other words, to make the SI47XX device easier to deal, some defined data types were created to handle byte and bits to process commands, properties and responses. These data types will be usefull to deal with SI473X

Data Structure Documentation

union si473x_powerup

Power Up arguments data type.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 64 and 65

Definition at line 175 of file SI4735.h.

Data Fields:

struct si473x_powerup	arg	
uint8_t	raw[2]	

struct si473x_powerup.arg

Definition at line 176 of file SI4735.h.

Data Fields:

uint8_t	CTSIEN: 1	GPO2 Output Enable (0 = GPO2 output disabled; 1 = GPO2 output enabled).
uint8_t	FUNC: 4	
uint8_t	GPO2OEN: 1	Patch Enable (0 = Boot normally; 1 = Copy non-volatile memory to RAM).
uint8_t	OPMODE	CTS Interrupt Enable (0 = CTS interrupt disabled; 1 = CTS interrupt enabled).
uint8_t	PATCH: 1	Crystal Oscillator Enable (0 = crystal oscillator disabled; 1 = Use crystal oscillator and and OPMODE=ANALOG AUDIO) .
uint8_t	XOSCEN: 1	Function (0 = FM Receive; 1–14 = Reserved; 15 = Query Library ID)

union si47x_frequency

Represents how the frequency is stored in the si4735.

It helps to convert frequency in uint16_t to two bytes (uint8_t) (FREQL and FREQH)

Definition at line 196 of file SI4735.h.

Data Fields:

struct si47x_frequency	raw	
uint16_t	value	

struct si47x_frequency.raw

Definition at line 197 of file SI4735.h.

Data Fields:

uint8_t	FREQH	Tune Frequency High byte.
uint8_t	FREQL	

union si47x_antenna_capacitor

Antenna Tuning Capacitor data type manipulation.

Definition at line 209 of file SI4735.h.

Data Fields:

struct si47x_antenna_capacitor	raw	
uint16_t	value	

struct si47x_antenna_capacitor.raw

Definition at line 210 of file SI4735.h.

Data Fields:

uint8_t	ANTCAPH	Antenna Tuning Capacitor High byte.
uint8_t	ANTCAPL	

union si47x_set_frequency

AM Tune frequency data type command (AM_TUNE_FREQ command)

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 135

Definition at line 225 of file SI4735.h.

Data Fields:

struct si47x_set_frequency	arg	
uint8_t	raw[5]	

struct si47x_set_frequency.arg

Definition at line 226 of file SI4735.h.

Data Fields:

uint8_t	ANTCAPH	ARG3 - Tune Frequency Low byte.
uint8_t	ANTCAPL	ARG4 - Antenna Tuning Capacitor High byte.

uint8_t	DUMMY1: 4	Valid only for FM (Must be 0 to AM)
uint8_t	FAST: 1	
uint8_t	FREEZE: 1	ARG1 - FAST Tuning. If set, executes fast and invalidated tune. The tune status will not be accurate.
uint8_t	FREQH	SSB Upper Side Band (USB) and Lower Side Band (LSB) Selection. 10 = USB is selected; 01 = LSB is selected.
uint8_t	FREQL	ARG2 - Tune Frequency High byte.
uint8_t	USBLSB: 2	Always set 0.

union si47x_seek

Seek frequency (automatic tuning)

Represents searching for a valid frequency data type.

Definition at line 247 of file SI4735.h.

Data Fields:

struct si47x_seek	arg	
uint8_t	raw	

struct si47x_seek.arg

Definition at line 248 of file SI4735.h.

Data Fields:

uint8_t	RESERVED1: 2	
uint8_t	RESERVED2: 4	Determines the direction of the search, either UP = 1, or DOWN = 0.
uint8_t	SEEKUP: 1	Determines whether the seek should Wrap = 1, or Halt = 0 when it hits the band limit.
uint8_t	WRAP: 1	

union si47x_response_status

Response status command.

Response data from a query status command

See also

Si47XX PROGRAMMING GUIDE; pages 73 and

Definition at line 267 of file SI4735.h.

Data Fields:

uint8_t	raw[8]	
struct si47x_response_status	resp	

struct si47x_response_status.resp

Definition at line 268 of file SI4735.h.

Data Fields:

uint8_t	AFCRL: 1	Valid Channel.
uint8_t	BLTF: 1	
uint8_t	CTS: 1	Error. 0 = No error 1 = Error.
uint8_t	DUMMY1: 1	Seek/Tune Complete Interrupt; 1 = Tune complete has been triggered.
uint8_t	DUMMY2: 2	Received Signal Quality Interrupt; 0 = interrupt has not been triggered.
uint8_t	DUMMY3: 5	AFC Rail Indicator.
uint8_t	ERR: 1	
uint8_t	MULT	This byte contains the SNR metric when tune is complete (dB).
uint8_t	RDSINT: 1	
uint8_t	READANTCAP	Contains the multipath metric when tune is complete.
uint8_t	READFREQH	Reports if a seek hit the band limit.
uint8_t	READFREQL	Read Frequency High byte.
uint8_t	RSQINT: 1	Radio Data System (RDS) Interrupt; 0 = interrupt has not been triggered.
uint8_t	RSSI	Read Frequency Low byte.
uint8_t	SNR	Received Signal Strength Indicator (dB \hat{I} $\frac{1}{4}$ V)
uint8_t	STCINT: 1	
uint8_t	VALID: 1	Clear to Send.

union si47x_firmware_information

Data representation for Firmware Information (GET_REV)

The part number, chip revision, firmware revision, patch revision and component revision numbers.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 66 and 131

Definition at line 308 of file SI4735.h.

Data Fields:

uint8_t	raw[9]	
struct si47x_firmware_in formation	resp	

struct si47x_firmware_information.resp

Definition at line 309 of file SI4735.h.

Data Fields:

uint8_t	CHIPREV	RESP7 - Component Minor Revision (ASCII).
uint8_t	CMPMAJOR	RESP5 - Patch ID Low byte (HEX).
uint8_t	CMPMINOR	RESP6 - Component Major Revision (ASCII).
uint8_t	CTS: 1	

uint8_t	DUMMY1: 1	
uint8_t	DUMMY2: 2	
uint8_t	ERR: 1	
uint8_t	FWMAJOR	RESP1 - Final 2 digits of Part Number (HEX).
uint8_t	FWMINOR	RESP2 - Firmware Major Revision (ASCII).
uint8_t	PATCHH	RESP3 - Firmware Minor Revision (ASCII).
uint8_t	PATCHL	RESP4 - Patch ID High byte (HEX).
uint8_t	PN	
uint8_t	RDSINT: 1	
uint8_t	RSQINT: 1	
uint8_t	STCINT: 1	

union si47x_firmware_query_library

Firmware Query Library ID response.

Used to represent the response of a power up command with FUNC = 15 (patch)

To confirm that the patch is compatible with the internal device library revision, the library revision should be confirmed by issuing the POWER_UP command with Function = 15 (query library ID)

See also

Si47XX PROGRAMMING GUIDE; AN332; page 12

Definition at line 344 of file SI4735.h.

Data Fields:

uint8_t	raw[8]	
struct	resp	
si47x_firmware_query_library		

struct si47x_firmware_query_library.resp

Definition at line 345 of file SI4735.h.

Data Fields:

uint8_t	CHIPREV	RESP5 - Reserved, various values.
uint8_t	CTS: 1	
uint8_t	DUMMY1: 1	
uint8_t	DUMMY2: 2	
uint8_t	ERR: 1	
uint8_t	FWMAJOR	RESP1 - Final 2 digits of Part Number (HEX).
uint8_t	FWMINOR	RESP2 - Firmware Major Revision (ASCII).
uint8_t	LIBRARYID	RESP6 - Chip Revision (ASCII).
uint8_t	PN	
uint8_t	RDSINT: 1	
uint8_t	RESERVED1	RESP3 - Firmware Minor Revision (ASCII).
uint8_t	RESERVED2	RESP4 - Reserved, various values.
uint8_t	RSQINT: 1	
uint8_t	STCINT: 1	

union si47x_tune_status

Seek station status.

Status of FM_TUNE_FREQ or FM_SEEK_START commands or Status of AM_TUNE_FREQ or AM_SEEK_START commands.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 73 and 139

Definition at line 376 of file SI4735.h.

Data Fields:

struct si47x_tune_status	arg	
uint8_t	raw	

struct si47x_tune_status.arg

Definition at line 377 of file SI4735.h.

Data Fields:

uint8_t	CANCEL: 1	If set, clears the seek/tune complete interrupt status indicator.
uint8_t	INTACK: 1	
uint8_t	RESERVED2: 6	If set, aborts a seek currently in progress.

union si47x_property

Data type to deal with SET_PROPERTY command.

Property Data type (help to deal with SET_PROPERTY command on si473X)

Definition at line 393 of file SI4735.h.

Data Fields:

struct si47x_property	raw	
uint16_t	value	

struct si47x_property.raw

Definition at line 394 of file SI4735.h.

Data Fields:

uint8_t	byteHigh	
uint8_t	byteLow	

Si47XX device Mode, Band and Frequency setup

Functions

void [SI4735::setTuneFrequencyAntennaCapacitor](#) (uint16_t capacitor)

Only FM. Freeze Metrics During Alternate Frequency Jump.

void [SI4735::setFrequency](#) (uint16_t)

Set the frequency to the current function of the Si4735 (FM, AM or SSB)

void [SI4735::setFrequencyStep](#) (uint16_t step)
Sets the current step value.

void [SI4735::frequencyUp](#) ()
Increments the current frequency on current band/function by using the current step.

void [SI4735::frequencyDown](#) ()
Decrements the current frequency on current band/function by using the current step.

void [SI4735::setAM](#) ()
Sets the radio to AM function. It means: LW MW and SW.

void [SI4735::setFM](#) ()
Sets the radio to FM function.

void [SI4735::setAM](#) (uint16_t fromFreq, uint16_t toFreq, uint16_t initialFreq, uint16_t step)
Sets the radio to AM (LW/MW/SW) function.

void [SI4735::setFM](#) (uint16_t fromFreq, uint16_t toFreq, uint16_t initialFreq, uint16_t step)
Sets the radio to FM function.

Detailed Description

Function Documentation

void SI4735::frequencyDown ()

Decrements the current frequency on current band/function by using the current step.

See also

[setFrequencyStep\(\)](#)

Definition at line 505 of file SI4735.cpp.

```
00506 {  
00507  
00508     if (currentWorkFrequency <= currentMinimumFrequency)  
00509         currentWorkFrequency = currentMaximumFrequency;  
00510     else  
00511         currentWorkFrequency -= currentStep;  
00512  
00513     setFrequency (currentWorkFrequency) ;  
00514 }
```

References [SI4735::currentMaximumFrequency](#), [SI4735::currentMinimumFrequency](#), [SI4735::currentStep](#), [SI4735::currentWorkFrequency](#), and [SI4735::setFrequency\(\)](#).

void SI4735::frequencyUp ()

Increments the current frequency on current band/function by using the current step.

See also

[setFrequencyStep\(\)](#)

Definition at line 488 of file SI4735.cpp.

```
00489 {
00490     if (currentWorkFrequency >= currentMaximumFrequency)
00491         currentWorkFrequency = currentMinimumFrequency;
00492     else
00493         currentWorkFrequency += currentStep;
00494     setFrequency(currentWorkFrequency);
00495 }
00496 }
```

References SI4735::currentMaximumFrequency, SI4735::currentMinimumFrequency, SI4735::currentStep, SI4735::currentWorkFrequency, and SI4735::setFrequency().

void SI4735::setAM ()

Sets the radio to AM function. It means: LW MW and SW.

Define the band range you want to use for the AM mode.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 129.

Definition at line 525 of file SI4735.cpp.

```
00526 {
00527     // If you're already using AM mode, it is not necessary to call
00528     // powerDown and radioPowerUp.
00529     // The other properties also should have the same value as the previous
00530     // status.
00531     if (lastMode != AM_CURRENT_MODE) {
00532         powerDown();
00533         setPowerUp(1, 1, 0, 1, 1, SI473X_ANALOG_AUDIO);
00534         radioPowerUp();
00535         setAvcAmMaxGain(currentAvcAmMaxGain); // Set AM Automatic Volume
00536         Gain to 48
00537         setVolume(volume); // Set to previous configured volume
00538     }
00539     currentSsbStatus = 0;
00540     lastMode = AM_CURRENT_MODE;
00541 }
```

References AM_CURRENT_MODE, SI4735::currentAvcAmMaxGain, SI4735::currentSsbStatus, SI4735::lastMode, SI4735::powerDown(), SI4735::radioPowerUp(), SI4735::setAvcAmMaxGain(), SI4735::setPowerUp(), SI4735::setVolume(), SI473X_ANALOG_AUDIO, and SI4735::volume.

Referenced by SI4735::setAM().

void SI4735::setAM (uint16_t fromFreq, uint16_t toFreq, uint16_t initialFreq, uint16_t step)

Sets the radio to AM (LW/MW/SW) function.

See also

[setAM\(\)](#)

Parameters

<i>fromFreq</i>	minimum frequency for the band
<i>toFreq</i>	maximum frequency for the band
<i>initialFreq</i>	initial frequency
<i>step</i>	step used to go to the next channel

Definition at line 570 of file SI4735.cpp.

```
00571 {
00572
00573     currentMinimumFrequency = fromFreq;
00574     currentMaximumFrequency = toFreq;
00575     currentStep = step;
00576
00577     if (initialFreq < fromFreq || initialFreq > toFreq)
00578         initialFreq = fromFreq;
00579
00580     setAM();
00581     currentWorkFrequency = initialFreq;
00582     setFrequency(currentWorkFrequency);
00583 }
```

References SI4735::currentMaximumFrequency, SI4735::currentMinimumFrequency, SI4735::currentStep, SI4735::currentWorkFrequency, SI4735::setAM(), and SI4735::setFrequency().

void SI4735::setFM ()

Sets the radio to FM function.

See also

Si47XX PROGRAMMING GUIDE; AN332; page 64.

Definition at line 547 of file SI4735.cpp.

```
00548 {
00549     powerDown();
00550     setPowerUp(1, 1, 0, 1, 0, SI473X\_ANALOG\_AUDIO);
00551     radioPowerUp();
00552     setVolume(volume); // Set to previous configured volume
00553     currentSsbStatus = 0;
00554     disableFmDebug();
00555     lastMode = FM\_CURRENT\_MODE;
00556 }
```

References SI4735::currentSsbStatus, SI4735::disableFmDebug(), FM_CURRENT_MODE, SI4735::lastMode, SI4735::powerDown(), SI4735::radioPowerUp(), SI4735::setPowerUp(), SI4735::setVolume(), SI473X_ANALOG_AUDIO, and SI4735::volume.

Referenced by SI4735::setFM().

void SI4735::setFM (uint16_t fromFreq, uint16_t toFreq, uint16_t initialFreq, uint16_t step)

Sets the radio to FM function.

Defines the band range you want to use for the FM mode.

See also

[setFM\(\)](#)

Parameters

<i>fromFreq</i>	minimum frequency for the band
<i>toFreq</i>	maximum frequency for the band
<i>initialFreq</i>	initial frequency (default frequency)
<i>step</i>	step used to go to the next channel

Definition at line 599 of file SI4735.cpp.

```
00600 {
00601
00602     currentMinimumFrequency = fromFreq;
00603     currentMaximumFrequency = toFreq;
00604     currentStep = step;
00605
00606     if (initialFreq < fromFreq || initialFreq > toFreq)
00607         initialFreq = fromFreq;
00608
00609     setFM();
00610
00611     currentWorkFrequency = initialFreq;
00612     setFrequency(currentWorkFrequency);
00613 }
```

References SI4735::currentMaximumFrequency, SI4735::currentMinimumFrequency, SI4735::currentStep, SI4735::currentWorkFrequency, SI4735::setFM(), and SI4735::setFrequency().

void SI4735::setFrequency(uint16_t freq)

Set the frequency to the current function of the Si4735 (FM, AM or SSB)

You have to call setup or setPowerUp before call setFrequency.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 70, 135

AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE; page 13

Parameters

<code>uint16_t</code>	freq Is the frequency to change. For example, FM => 10390 = 103.9 MHz; AM => 810 = 810 KHz.
-----------------------	---

Definition at line 434 of file SI4735.cpp.

```
00435 {
00436     waitToSend(); // Wait for the si473x is ready.
00437     currentFrequency.value = freq;
00438     currentFrequencyParams.arg.FREQH = currentFrequency.raw.FREQH;
00439     currentFrequencyParams.arg.FREQL = currentFrequency.raw.FREQL;
00440
00441     if (currentSsbStatus != 0)
00442     {
00443         currentFrequencyParams.arg.DUMMY1 = 0;
00444         currentFrequencyParams.arg.USBLSB = currentSsbStatus; // Set to LSB
00445         or USB
00446         currentFrequencyParams.arg.FAST = 1; // Used just
00447         on AM and FM
00448         currentFrequencyParams.arg.FREEZE = 0; // Used just
00449         on FM
00450     }
00451     Wire.beginTransaction(deviceAddress);
00452     Wire.write(currentTune);
00453     Wire.write(currentFrequencyParams.raw[0]); // Send a byte with FAST and
00454     FREEZE information; if not FM must be 0;
00455     Wire.write(currentFrequencyParams.arg.FREQH);
00456     Wire.write(currentFrequencyParams.arg.FREQL);
00457     Wire.write(currentFrequencyParams.arg.ANTCAPH);
00458     // If current tune is not FM sent one more byte
00459     if (currentTune != FM\_TUNE\_FREQ)
00460         Wire.write(currentFrequencyParams.arg.ANTCAPL);
00461
00462     Wire.endTransmission();
00463     waitToSend(); // Wait for the si473x is ready.
00464     currentWorkFrequency = freq; // check it
00465     delay(MAX\_DELAY\_AFTER\_SET\_FREQUENCY); // For some reason I need to delay
00466     here.
00467 }
```

References si47x_set_frequency::arg, SI4735::currentFrequency, SI4735::currentFrequencyParams, SI4735::currentSsbStatus, SI4735::currentTune,

SI4735::currentWorkFrequency, SI4735::deviceAddress, FM_TUNE_FREQ, MAX_DELAY_AFTER_SET_FREQUENCY, si47x_frequency::raw, si47x_set_frequency::raw, si47x_frequency::value, and SI4735::waitToSend().

Referenced by SI4735::frequencyDown(), SI4735::frequencyUp(), SI4735::setAM(), SI4735::setFM(), and SI4735::setSSB().

void SI4735::setFrequencyStep (uint16_t step)

Sets the current step value.

This function does not check the limits of the current band. Please, don't take a step bigger than your legs.

Parameters

<i>step</i>	if you are using FM, 10 means 100KHz. If you are using AM 10 means 10KHz For AM, 1 (1KHz) to 1000 (1MHz) are valid values. For FM 5 (50KHz) and 10 (100KHz) are valid values.
-------------	--

Definition at line 476 of file SI4735.cpp.

```
00477 {
00478     currentStep = step;
00479 }
```

References SI4735::currentStep.

void SI4735::setTuneFrequencyAntennaCapacitor (uint16_t capacitor)

Only FM. Freeze Metrics During Alternate Frequency Jump.

Selects the tuning capacitor value.

For FM, Antenna Tuning Capacitor is valid only when using TXO/LPI pin as the antenna input.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 71 and 136

Parameters

<i>capacitor</i>	If zero, the tuning capacitor value is selected automatically. If the value is set to anything other than 0: AM - the tuning capacitance is manually set as 95 fF x ANTCAP + 7 pF. ANTCAP manual range is 1–6143; FM - the valid range is 0 to 191. According to Silicon Labs, automatic capacitor tuning is recommended (value 0).
------------------	--

Definition at line 398 of file SI4735.cpp.

```
00399 {
00400     si47x\_antenna\_capacitor cap;
00401
00402     cap.value = capacitor;
00403
00404     currentFrequencyParams.arg.DUMMY1 = 0;
00405
00406     if (currentTune == FM\_TUNE\_FREQ)
00407     {
00408         // For FM, the capacitor value has just one byte
00409         currentFrequencyParams.arg.ANTCAPH = (capacitor <= 191) ?
cap.raw.ANTCAPL : 0;
00410     }
00411     else
00412     {
00413         if (capacitor <= 6143)
00414         {
00415             currentFrequencyParams.arg.FREEZE = 0; // This parameter is not
used for AM
```

```

00416         currentFrequencyParams.arg.ANTCAPH = cap.raw.ANTCAPH;
00417         currentFrequencyParams.arg.ANTCAPL = cap.raw.ANTCAPL;
00418     }
00419 }
00420 }

```

References `si47x_set_frequency::arg`, `SI4735::currentFrequencyParams`, `SI4735::currentTune`, `FM_TUNE_FREQ`, `si47x_antenna_capacitor::raw`, and `si47x_antenna_capacitor::value`.

Si47XX device information and start up

Functions

void [SI4735::getFirmware](#) (void)

Gets firmware information.

void [SI4735::setup](#) (uint8_t [resetPin](#), int [interruptPin](#), uint8_t defaultFunction, uint8_t audioMode=[SI473X_ANALOG_AUDIO](#))

Starts the Si473X device.

void [SI4735::setup](#) (uint8_t [resetPin](#), uint8_t defaultFunction)

Starts the Si473X device.

Detailed Description

Function Documentation

void SI4735::getFirmware (void)

Gets firmware information.

See also

Si47XX PROGRAMMING GUIDE; AN332; pages 66, 131

Definition at line 298 of file SI4735.cpp.

```

00299 {
00300     waitToSend();
00301
00302     Wire.beginTransaction(deviceAddress);
00303     Wire.write(GET\_REV);
00304     Wire.endTransmission();
00305
00306     do
00307     {
00308         waitToSend();
00309         // Request for 9 bytes response
00310         Wire.requestFrom(deviceAddress, 9);
00311         for (int i = 0; i < 9; i++)
00312             firmwareInfo.raw[i] = Wire.read();
00313     } while (firmwareInfo.resp.ERR);
00314 }

```

References SI4735::deviceAddress, SI4735::firmwareInfo, GET_REV, si47x_firmware_information::raw, si47x_firmware_information::resp, and SI4735::waitToSend().

void SI4735::setup (uint8_t resetPin, int interruptPin, uint8_t defaultFunction, uint8_t audioMode = [SI473X_ANALOG_AUDIO](#))

Starts the Si473X device.

If the audio mode parameter is not entered, analog mode will be considered.

Parameters

uint8_t	resetPin Digital Arduino Pin used to RESET command
uint8_t	interruptPin interrupt Arduino Pin (see your Arduino pinout). If less than 0, interrupt disabled
uint8_t	defaultFunction
uint8_t	audioMode default SI473X_ANALOG_AUDIO (Analog Audio). Use SI473X_ANALOG_AUDIO or SI473X_DIGITAL_AUDIO

Definition at line 328 of file SI4735.cpp.

```

00329 {
00330     uint8_t interruptEnable = 0;
00331     Wire.begin();
00332
00333     this->resetPin = resetPin;
00334     this->interruptPin = interruptPin;
00335
00336     // Arduino interrupt setup (you have to know which Arduino Pins can deal
with interrupt).
00337     if (interruptPin >= 0)
00338     {
00339         pinMode(interruptPin, INPUT);
00340         attachInterrupt(digitalPinToInterrupt(interruptPin),
interrupt_hundler, RISING);
00341         interruptEnable = 1;
00342     }
00343
00344     pinMode(resetPin, OUTPUT);
00345     digitalWrite(resetPin, HIGH);
00346
00347     data_from_si4735 = false;
00348
00349     // Set the initial SI473X behavior
00350     // CTSIEN 1 -> Interrupt anabled or disable;
00351     // GPO2OEN 1 -> GPO2 Output Enable;
00352     // PATCH 0 -> Boot normally;
00353     // XOSCEN 1 -> Use external crystal oscillator;
00354     // FUNC defaultFunction = 0 = FM Receive; 1 = AM (LW/MW/SW)
Receiver.
00355     // OPMODE SI473X_ANALOG_AUDIO or SI473X_DIGITAL_AUDIO.
00356     setPowerUp(interruptEnable, 0, 0, 1, defaultFunction, audioMode);
00357
00358     reset();
00359     radioPowerUp();
00360     setVolume(30); // Default volume level.
00361     getFirmware();
00362 }
```

References SI4735::interruptPin, and SI4735::resetPin.

void SI4735::setup (uint8_t resetPin, uint8_t defaultFunction)

Starts the Si473X device.

Use this setup if you are not using interrupt resource

Parameters

uint8_t	resetPin Digital Arduino Pin used to RESET command
---------	--

<code>uint8_t</code>	<code>defaultFunction</code>
----------------------	------------------------------

Definition at line 374 of file SI4735.cpp.

```
00375 {
00376     setup\(resetPin, -1, defaultFunction\);
00377     delay(250);
00378 }
```

References SI4735::resetPin.

File Documentation

SI4735/SI4735.cpp File Reference

```
#include <SI4735.h>
```

SI4735/SI4735.h File Reference

```
#include <Arduino.h>
#include <Wire.h>
```

Data Structures

union [si473x_powerup](#)

Power Up arguments data type. [More...](#)

union [si47x_frequency](#)

Represents how the frequency is stored in the si4735. [More...](#)

union [si47x_antenna_capacitor](#)

Antenna Tuning Capacitor data type manipulation. [More...](#)

union [si47x_set_frequency](#)

AM Tune frequency data type command (AM_TUNE_FREQ command) [More...](#)

union [si47x_seek](#)

Seek frequency (automatic tuning) [More...](#)

union [si47x_response_status](#)

Response status command. [More...](#)

union [si47x_firmware_information](#)

Data representation for Firmware Information (GET_REV) [More...](#)

union [si47x_firmware_query_library](#)

Firmware Query Library ID response. [More...](#)

union [si47x_tune_status](#)

Seek station status. [More...](#)

union [si47x_property](#)
Data type to deal with SET_PROPERTY command. [More...](#)

union [si47x_rqs_status](#)
Radio Signal Quality data representation. [More...](#)

union [si47x_rds_command](#)
Data type for RDS Status command and response information. [More...](#)

union [si47x_rds_status](#)
Response data type for current channel and reads an entry from the RDS FIFO. [More...](#)

union [si47x_rds_int_source](#)
FM_RDS_INT_SOURCE property data type. [More...](#)

union [si47x_rds_config](#)
Data type for FM_RDS_CONFIG Property. [More...](#)

union [si47x_rds_blocka](#)
Block A data type. [More...](#)

union [si47x_rds_blockb](#)
Block B data type. [More...](#)

union [si47x_rds_date_time](#)
union [si47x_agc_status](#)
union [si47x_agc_override](#)
union [si47x_bandwidth_config](#)
union [si47x_ssb_mode](#)
union [si4735_digital_output_format](#)
Digital audio output format data structure (Property 0x0102. DIGITAL_OUTPUT_FORMAT). [More...](#)

struct [si4735_digital_output_sample_rate](#)
Digital audio output sample structure (Property 0x0104. DIGITAL_OUTPUT_SAMPLE_RATE). [More...](#)

class [SI4735](#)
[SI4735](#) Class. [More...](#)

struct [si473x_powerup.arg](#)
struct [si47x_frequency.raw](#)
struct [si47x_antenna_capacitor.raw](#)
struct [si47x_set_frequency.arg](#)
struct [si47x_seek.arg](#)
struct [si47x_response_status.resp](#)
struct [si47x_firmware_information.resp](#)
struct [si47x_firmware_query_library.resp](#)
struct [si47x_tune_status.arg](#)
struct [si47x_property.raw](#)

```

struct si47x\_rqs\_status.resp
struct si47x\_rds\_command.arg
struct si47x\_rds\_status.resp
struct si47x\_rds\_int\_source.refined
struct si47x\_rds\_config.arg
struct si47x\_rds\_blocka.refined
struct si47x\_rds\_blocka.raw
struct si47x\_rds\_blockb.group0
struct si47x\_rds\_blockb.group2
struct si47x\_rds\_blockb.refined
struct si47x\_rds\_blockb.raw
struct si47x\_rds\_date\_time.refined
struct si47x\_agc\_status.refined
struct si47x\_agc\_override.arg
struct si47x\_bandwidth\_config.param
struct si47x\_ssb\_mode.param
struct si4735\_digital\_output\_format.refined

```

Macros

```

#define POWER\_UP\_FM 0
#define POWER\_UP\_AM 1
#define POWER\_UP\_WB 3
#define POWER\_PATCH 15
#define SI473X\_ADDR\_SEN\_LOW 0x11
#define SI473X\_ADDR\_SEN\_HIGH 0x63
#define POWER\_UP 0x01
#define GET\_REV 0x10
#define POWER\_DOWN 0x11
#define SET\_PROPERTY 0x12
#define GET\_PROPERTY 0x13
#define GET\_INT\_STATUS 0x14
#define FM\_TUNE\_FREQ 0x20
#define FM\_SEEK\_START 0x21
#define FM\_TUNE\_STATUS 0x22
#define FM\_AGC\_STATUS 0x27
#define FM\_AGC\_OVERRIDE 0x28
#define FM\_RSQ\_STATUS 0x23
#define FM\_RDS\_STATUS 0x24
#define FM\_RDS\_INT\_SOURCE 0x1500
#define FM\_RDS\_INT\_FIFO\_COUNT 0x1501
#define FM\_RDS\_CONFIG 0x1502
#define FM\_RDS\_CONFIDENCE 0x1503
#define FM\_BLEND\_STEREO\_THRESHOLD 0x1105
#define FM\_BLEND\_MONO\_THRESHOLD 0x1106
#define FM\_BLEND\_RSSI\_STEREO\_THRESHOLD 0x1800
#define FM\_BLEND\_RSSI\_MONO\_THRESHOLD 0x1801
#define FM\_BLEND\_SNR\_STEREO\_THRESHOLD 0x1804
#define FM\_BLEND\_SNR\_MONO\_THRESHOLD 0x1805
#define FM\_BLEND\_MULTIPATH\_STEREO\_THRESHOLD 0x1808
#define FM\_BLEND\_MULTIPATH\_MONO\_THRESHOLD 0x1809
#define AM\_TUNE\_FREQ 0x40
#define AM\_SEEK\_START 0x41
#define AM\_TUNE\_STATUS 0x42
#define AM\_RSQ\_STATUS 0x43
#define AM\_AGC\_STATUS 0x47
#define AM\_AGC\_OVERRIDE 0x48
#define GPIO\_CTL 0x80
#define GPIO\_SET 0x81
#define SSB\_TUNE\_FREQ 0x40
#define SSB\_TUNE\_STATUS 0x42

```



```

#define SSB\_RSQ\_STATUS 0x43
#define SSB\_AGC\_STATUS 0x47
#define SSB\_AGC\_OVERRIDE 0x48
#define DIGITAL\_OUTPUT\_FORMAT 0x0102
#define DIGITAL\_OUTPUT\_SAMPLE\_RATE 0x0104
#define REFCLK\_FREQ 0x0201
#define REFCLK\_PRESCALE 0x0202
#define AM\_DEEMPHASIS 0x3100
#define AM\_CHANNEL\_FILTER 0x3102
#define AM\_AUTOMATIC\_VOLUME\_CONTROL\_MAX\_GAIN 0x3103
#define AM\_MODE\_AFC\_SW\_PULL\_IN\_RANGE 0x3104
#define AM\_MODE\_AFC\_SW\_LOCK\_IN\_RANGE 0x3105
#define AM\_RSQ\_INTERRUPTS 0x3200
#define AM\_RSQ\_SNR\_HIGH\_THRESHOLD 0x3201
#define AM\_RSQ\_SNR\_LOW\_THRESHOLD 0x3202
#define AM\_RSQ\_RSSI\_HIGH\_THRESHOLD 0x3203
#define AM\_RSQ\_RSSI\_LOW\_THRESHOLD 0x3204
#define AM\_SOFT\_MUTE\_RATE 0x3300
#define AM\_SOFT\_MUTE\_SLOPE 0x3301
#define AM\_SOFT\_MUTE\_MAX\_ATTENUATION 0x3302
#define AM\_SOFT\_MUTE\_SNR\_THRESHOLD 0x3303
#define AM\_SOFT\_MUTE\_RELEASE\_RATE 0x3304
#define AM\_SOFT\_MUTE\_ATTACK\_RATE 0x3305
#define AM\_SEEK\_BAND\_BOTTOM 0x3400
#define AM\_SEEK\_BAND\_TOP 0x3401
#define AM\_SEEK\_FREQ\_SPACING 0x3402
#define AM\_SEEK\_SNR\_THRESHOLD 0x3403
#define AM\_SEEK\_RSSI\_THRESHOLD 0x3404
#define AM\_AGC\_ATTACK\_RATE 0x3702
#define AM\_AGC\_RELEASE\_RATE 0x3703
#define AM\_FRONTEND\_AGC\_CONTROL 0x3705
#define AM\_NB\_DETECT\_THRESHOLD 0x3900
#define AM\_NB\_INTERVAL 0x3901
#define AM\_NB\_RATE 0x3902
#define AM\_NB\_IIR\_FILTER 0x3903
#define AM\_NB\_DELAY 0x3904
#define RX\_VOLUME 0x4000
#define RX\_HARD\_MUTE 0x4001
#define GPO\_IEN 0x0001
#define SSB\_BFO 0x0100
#define SSB\_MODE 0x0101
#define SSB\_RSQ\_INTERRUPTS 0x3200
#define SSB\_RSQ\_SNR\_HI\_THRESHOLD 0x3201
#define SSB\_RSQ\_SNR\_LO\_THRESHOLD 0x3202
#define SSB\_RSQ\_RSSI\_HI\_THRESHOLD 0x3203
#define SSB\_RSQ\_RSSI\_LO\_THRESHOLD 0x3204
#define SSB\_SOFT\_MUTE\_RATE 0x3300
#define SSB\_SOFT\_MUTE\_MAX\_ATTENUATION 0x3302
#define SSB\_SOFT\_MUTE\_SNR\_THRESHOLD 0x3303
#define SSB\_RF\_AGC\_ATTACK\_RATE 0x3700
#define SSB\_RF\_AGC\_RELEASE\_RATE 0x3701
#define SSB\_RF\_IF\_AGC\_ATTACK\_RATE 0x3702
#define SSB\_RF\_IF\_AGC\_RELEASE\_RATE 0x3703
#define LSB\_MODE 1
#define USB\_MODE 2
#define SI473X\_ANALOG\_AUDIO 0b00000101
#define SI473X\_DIGITAL\_AUDIO1 0b00001011
#define SI473X\_DIGITAL\_AUDIO2 0b10110000
#define SI473X\_DIGITAL\_AUDIO3 0b10110101
#define FM\_CURRENT\_MODE 0

```

```
#define AM\_CURRENT\_MODE 1  
#define SSB\_CURRENT\_MODE 2  
#define MAX\_DELAY\_AFTER\_SET\_FREQUENCY 30  
#define MIN\_DELAY\_WAIT\_SEND\_LOOP 300
```

Macro Definition Documentation

#define AM_AGC_ATTACK_RATE 0x3702

Definition at line 103 of file SI4735.h.

#define AM_AGC_OVERRIDE 0x48

Definition at line 64 of file SI4735.h.

#define AM_AGC_RELEASE_RATE 0x3703

Definition at line 104 of file SI4735.h.

#define AM_AGC_STATUS 0x47

Definition at line 63 of file SI4735.h.

#define AM_AUTOMATIC_VOLUME_CONTROL_MAX_GAIN 0x3103

Definition at line 84 of file SI4735.h.

#define AM_CHANNEL_FILTER 0x3102

Definition at line 83 of file SI4735.h.

#define AM_CURRENT_MODE 1

Definition at line 149 of file SI4735.h.

#define AM_DEEMPHASIS 0x3100

Definition at line 82 of file SI4735.h.

#define AM_FRONTEND_AGC_CONTROL 0x3705

Definition at line 105 of file SI4735.h.

#define AM_MODE_AFC_SW_LOCK_IN_RANGE 0x3105

Definition at line 86 of file SI4735.h.

#define AM_MODE_AFC_SW_PULL_IN_RANGE 0x3104

Definition at line 85 of file SI4735.h.

#define AM_NB_DELAY 0x3904

Definition at line 110 of file SI4735.h.

#define AM_NB_DETECT_THRESHOLD 0x3900

Definition at line 106 of file SI4735.h.

#define AM_NB_IIR_FILTER 0x3903

Definition at line 109 of file SI4735.h.

#define AM_NB_INTERVAL 0x3901

Definition at line 107 of file SI4735.h.

#define AM_NB_RATE 0x3902

Definition at line 108 of file SI4735.h.

#define AM_RSQ_INTERRUPTS 0x3200

Definition at line 87 of file SI4735.h.

#define AM_RSQ_RSSI_HIGH_THRESHOLD 0x3203

Definition at line 90 of file SI4735.h.

#define AM_RSQ_RSSI_LOW_THRESHOLD 0x3204

Definition at line 91 of file SI4735.h.

#define AM_RSQ_SNR_HIGH_THRESHOLD 0x3201

Definition at line 88 of file SI4735.h.

#define AM_RSQ_SNR_LOW_THRESHOLD 0x3202

Definition at line 89 of file SI4735.h.

#define AM_RSQ_STATUS 0x43

Definition at line 62 of file SI4735.h.

#define AM_SEEK_BAND_BOTTOM 0x3400

Definition at line 98 of file SI4735.h.

#define AM_SEEK_BAND_TOP 0x3401

Definition at line 99 of file SI4735.h.

#define AM_SEEK_FREQ_SPACING 0x3402

Definition at line 100 of file SI4735.h.

#define AM_SEEK_RSSI_THRESHOLD 0x3404

Definition at line 102 of file SI4735.h.

#define AM_SEEK_SNR_THRESHOLD 0x3403

Definition at line 101 of file SI4735.h.

#define AM_SEEK_START 0x41

Definition at line 60 of file SI4735.h.

#define AM_SOFT_MUTE_ATTACK_RATE 0x3305

Definition at line 97 of file SI4735.h.

#define AM_SOFT_MUTE_MAX_ATTENUATION 0x3302

Definition at line 94 of file SI4735.h.

#define AM_SOFT_MUTE_RATE 0x3300

Definition at line 92 of file SI4735.h.

#define AM_SOFT_MUTE_RELEASE_RATE 0x3304

Definition at line 96 of file SI4735.h.

#define AM_SOFT_MUTE_SLOPE 0x3301

Definition at line 93 of file SI4735.h.

#define AM_SOFT_MUTE_SNR_THRESHOLD 0x3303

Definition at line 95 of file SI4735.h.

#define AM_TUNE_FREQ 0x40

Definition at line 59 of file SI4735.h.

#define AM_TUNE_STATUS 0x42

Definition at line 61 of file SI4735.h.

#define DIGITAL_OUTPUT_FORMAT 0x0102

Definition at line 78 of file SI4735.h.

#define DIGITAL_OUTPUT_SAMPLE_RATE 0x0104

Definition at line 79 of file SI4735.h.

#define FM_AGC_OVERRIDE 0x28

Definition at line 39 of file SI4735.h.

#define FM_AGC_STATUS 0x27

Definition at line 38 of file SI4735.h.

#define FM_BLEND_MONO_THRESHOLD 0x1106

Definition at line 50 of file SI4735.h.

#define FM_BLEND_MULTIPATH_MONO_THRESHOLD 0x1809

Definition at line 56 of file SI4735.h.

#define FM_BLEND_MULTIPATH_STEREO_THRESHOLD 0x1808

Definition at line 55 of file SI4735.h.

#define FM_BLEND_RSSI_MONO_THRESHOLD 0x1801

Definition at line 52 of file SI4735.h.

#define FM_BLEND_RSSI_STEREO_THRESHOLD 0x1800

Definition at line 51 of file SI4735.h.

#define FM_BLEND_SNR_MONO_THRESHOLD 0x1805

Definition at line 54 of file SI4735.h.

#define FM_BLEND_SNR_STEREO_THRESHOLD 0x1804

Definition at line 53 of file SI4735.h.

#define FM_BLEND_STEREO_THRESHOLD 0x1105

Definition at line 49 of file SI4735.h.

#define FM_CURRENT_MODE 0

Definition at line 148 of file SI4735.h.

#define FM_RDS_CONFIDENCE 0x1503

Definition at line 47 of file SI4735.h.

#define FM_RDS_CONFIG 0x1502

Definition at line 46 of file SI4735.h.

#define FM_RDS_INT_FIFO_COUNT 0x1501

Definition at line 45 of file SI4735.h.

#define FM_RDS_INT_SOURCE 0x1500

Definition at line 44 of file SI4735.h.

#define FM_RDS_STATUS 0x24

Definition at line 41 of file SI4735.h.

#define FM_RSQ_STATUS 0x23

Definition at line 40 of file SI4735.h.

#define FM_SEEK_START 0x21

Definition at line 36 of file SI4735.h.

#define FM_TUNE_FREQ 0x20

Definition at line 35 of file SI4735.h.

#define FM_TUNE_STATUS 0x22

Definition at line 37 of file SI4735.h.

#define GET_INT_STATUS 0x14

Definition at line 32 of file SI4735.h.

#define GET_PROPERTY 0x13

Definition at line 31 of file SI4735.h.

#define GET_REV 0x10

Definition at line 28 of file SI4735.h.

#define GPIO_CTL 0x80

Definition at line 65 of file SI4735.h.

#define GPIO_SET 0x81

Definition at line 66 of file SI4735.h.

#define GPO_IEN 0x0001

Definition at line 118 of file SI4735.h.

#define LSB_MODE 1

Definition at line 137 of file SI4735.h.

#define MAX_DELAY_AFTER_SET_FREQUENCY 30

Definition at line 151 of file SI4735.h.

#define MIN_DELAY_WAIT_SEND_LOOP 300

Definition at line 152 of file SI4735.h.

#define POWER_DOWN 0x11

Definition at line 29 of file SI4735.h.

#define POWER_PATCH 15

Definition at line 21 of file SI4735.h.

#define POWER_UP 0x01

Definition at line 27 of file SI4735.h.

#define POWER_UP_AM 1

Definition at line 19 of file SI4735.h.

#define POWER_UP_FM 0

[SI4735](#) ARDUINO LIBRARY

Const, Data type and Methods definitions References: Si47XX PROGRAMMING GUIDE AN332 AN332 REV 0.8 UNIVERSAL PROGRAMMING GUIDE

See also

documentation on <https://github.com/pu2clr/SI4735>

Author

PU2CLR - Ricardo Lima Caratti

By Ricardo Lima Caratti, Nov 2019

Definition at line 18 of file SI4735.h.

#define POWER_UP_WB 3

Definition at line 20 of file SI4735.h.

#define REFCLK_FREQ 0x0201

Definition at line 80 of file SI4735.h.

#define REFCLK_PRESCALE 0x0202

Definition at line 81 of file SI4735.h.

#define RX_HARD_MUTE 0x4001

Definition at line 113 of file SI4735.h.

#define RX_VOLUME 0x4000

Definition at line 112 of file SI4735.h.

#define SET_PROPERTY 0x12

Definition at line 30 of file SI4735.h.

#define SI473X_ADDR_SEN_HIGH 0x63

Definition at line 25 of file SI4735.h.

#define SI473X_ADDR_SEN_LOW 0x11

Definition at line 24 of file SI4735.h.

#define SI473X_ANALOG_AUDIO 0b00000101

Definition at line 142 of file SI4735.h.

#define SI473X_DIGITAL_AUDIO1 0b00001011

Definition at line 143 of file SI4735.h.

#define SI473X_DIGITAL_AUDIO2 0b10110000

Definition at line 144 of file SI4735.h.

#define SI473X_DIGITAL_AUDIO3 0b10110101

Definition at line 145 of file SI4735.h.

#define SSB_AGC_OVERRIDE 0x48

Definition at line 74 of file SI4735.h.

#define SSB_AGC_STATUS 0x47

Definition at line 73 of file SI4735.h.

#define SSB_BFO 0x0100

Definition at line 119 of file SI4735.h.

#define SSB_CURRENT_MODE 2

Definition at line 150 of file SI4735.h.

#define SSB_MODE 0x0101

Definition at line 120 of file SI4735.h.

#define SSB_RF_AGC_ATTACK_RATE 0x3700

Definition at line 129 of file SI4735.h.

#define SSB_RF_AGC_RELEASE_RATE 0x3701

Definition at line 130 of file SI4735.h.

#define SSB_RF_IF_AGC_ATTACK_RATE 0x3702

Definition at line 133 of file SI4735.h.

#define SSB_RF_IF_AGC_RELEASE_RATE 0x3703

Definition at line 134 of file SI4735.h.

#define SSB_RSQ_INTERRUPTS 0x3200

Definition at line 121 of file SI4735.h.

#define SSB_RSQ_RSSI_HI_THRESHOLD 0x3203

Definition at line 124 of file SI4735.h.

#define SSB_RSQ_RSSI_LO_THRESHOLD 0x3204

Definition at line 125 of file SI4735.h.

#define SSB_RSQ_SNR_HI_THRESHOLD 0x3201

Definition at line 122 of file SI4735.h.

#define SSB_RSQ_SNR_LO_THRESHOLD 0x3202

Definition at line 123 of file SI4735.h.

#define SSB_RSQ_STATUS 0x43

Definition at line 72 of file SI4735.h.

#define SSB_SOFT_MUTE_MAX_ATTENUATION 0x3302

Definition at line 127 of file SI4735.h.

#define SSB_SOFT_MUTE_RATE 0x3300

Definition at line 126 of file SI4735.h.

#define SSB_SOFT_MUTE_SNR_THRESHOLD 0x3303

Definition at line 128 of file SI4735.h.

#define SSB_TUNE_FREQ 0x40

Definition at line 70 of file SI4735.h.

#define SSB_TUNE_STATUS 0x42

Definition at line 71 of file SI4735.h.

#define USB_MODE 2

Definition at line 138 of file SI4735.h.

Index

INDE