

# Aklot

## Vibratory Metronome User Manual





# **Precautions Before Use**

---

## **1. Water Resistance Warning**

- This product does not have professional waterproof functionality. To avoid fire, electric shock, or device damage, do not use or wear this product during activities such as bathing, swimming, or other water-related activities.

## **2. Environmental Requirements**

- Do not place the product near water sources, high temperatures, direct sunlight, or excessively humid environments.
- Avoid placing the device near strong magnetic fields to prevent performance issues.
- Do not expose the device to extreme temperatures (below 0°C or above 40°C) to avoid damaging internal components.

## **3. Safety Tips**

- Use only the original charging equipment to charge the device. Avoid using non-standard chargers to prevent battery damage or hazards.
- If the device exhibits abnormal heating, unusual odors, or noises, stop using it immediately and contact customer service.

# Device Button Functions

---

## 1. Rotary Knob

- Short Press: In Instrument Mode, switch between adjusting tempo, beat, and rhythm patterns.
- Double Press: Switch between Instrument Mode and Sports Mode.
- Rotate: Adjust the currently selected parameter (e.g., tempo, beat, rhythm pattern).



## 2. Button

- Long Press Power On: Press and hold for 2 seconds.
- Long Press Power Off: Press and hold for 3 seconds.
- Short Press: Start or pause the current function.



# Device Mode Description

---

- This product offers two page modes for different scenarios.

## 1. Music Mode

- Use Case: Suitable for music practice, rhythm training, and other similar scenarios.
- Tempo (BPM): Adjustable range from 40-240 BPM, with 1 BPM precision.
- Beat: Supports various beat types such as 1/4, 2/4, 3/4, and 4/4.
- Rhythm Patterns: Built-in multiple rhythm patterns (e.g., rock, jazz, classical) for selection based on needs.



## 2. Sports Mode

- Use Case: Suitable for outdoor or indoor sports such as running, jumping rope, and fitness.

## 3. Adjustable Parameters

- Speed Frequency: Adjustable range from 40-240 times per minute, allowing customization based on exercise intensity.

# Daily Use and Operation

---

## 1. Power On/Off and Sleep Mode

- Power On: Press and hold the button for 2 seconds to turn on the device. It will enter the last used mode.
- Power Off: Press and hold the button for 3 seconds to turn off the device.
- Auto Power Off: If no operation or button press is detected for 30 minutes, the device will automatically power off to save battery.
- Sleep Mode: The device will enter sleep mode when idle, during which a small amount of power will still be consumed.

## 2. Charging Instructions

- Charging Status: When connected to a charger, the screen will light up automatically, and the battery icon will flash to indicate charging.
- Full Charge Notification: When fully charged, the screen will turn off, and the device will power down automatically.
- Low Battery Notification: When the battery level is below 10%, the battery icon's progress bar will empty, and a low battery alert sound will be emitted. Please charge the device promptly.

# Frequently Asked Questions

---

- Q1: What should I do if the device does not power on?  
Check if the battery is depleted. Connect the charger and try powering it on again. If the issue persists, contact customer service.
- Q2: Is it normal for the screen not to light up while charging?  
The screen should light up automatically during charging. If it does not, check if the charging connection is secure.
- Q3: Can a metronome use both sound and vibration?  
Only vibrations can be provided. You can turn on another sound metronome at the same time and use it in combination for better learning sometimes.
- Q4: What should I do if I feel uncomfortable/skin redness after wearing it for a long time?  
First check if you are allergic to ABS straps. In addition, the strap should not be too tight. Or try changing the wearing point intermittently (e.g. swapping left and right hands).

# Maintenance and Care

---

- 1.Cleaning: Wipe the device surface with a soft, dry cloth. Avoid using chemical cleaners or liquids directly on the device.
- 2.Storage: When not in use for extended periods, power off the device and store it in a dry, cool environment.
- 3.Battery Maintenance: It is recommended to charge the device at least once a month to maintain battery health.