

TDK-Lambda power supply remote control

Our version: Gen 50-30

Remote control via RS232 remote control. Need connector as presented in fig. 7-3 in manual.

Purchased this: https://www.elfa.se/en/adaptor-sub-male-to-rj45-9p-mh-connectors-da9-pmj8/p/30036055?q=db9+connector&filter__Termination=plug-in&filter__categoryCodePathROOT%2Fcat-L2D_379527=cat-DNAV_0301&filter__categoryCodePathROOT=cat-L2D_379527&page=2&origPos=40&origPageSize=25&simi=85.76

Cabled it from this guide: https://www.usconverters.com/downloads/support/db9_rj45_assembling_guide.pdf and the table with colour + the scheme presented in the power supply manual.

TDK Lambda proposes:

- RS232 interface cable. <http://www.conrad.com/ce/en/product/515782/TDK-Lambda-ACC-GENZ-232-9-Z-232-9-RS232-Interface-Cable-For-Z-Genesys-Laboratory-Power>
- USB adapter. <http://www.datatec.de/TDK-Lambda-Digitus-Adapter.htm>

Working config.

The RJ45 - DB9 adapter was connected with the three cables indicated in the TDK Lambda manual. Correct connection was ensured via buzzing. It turned out that the colour scheme vs. pin was inverted (or somehow the cable was flipped). Thus the following was connected:

- Orange to DB9 2
- Blue to DB9 3
- White to DB9 5
- OBS: use the left-bottom most usb-connection, otherwise it won't work!

GUI:

- <https://www.de.tdk-lambda.com/technical-centre/software-tools.aspx>
- Genesys and then download "Genesys™ Drivers - GEN Control"
- For manual - see unzipped folder.

Configuring on Linux

(Drivers are useless as they assume LAN communication: http://www.us.tdk-lambda.com/HP/product_html/Drivers/drivers_8.htm, should be bookmarked)

Useful commands: <https://www.cyberciti.biz/faq/find-out-linux-serial-ports-with-setserial/>

stty use this for: “Open and use the specified DEVICE instead of stdin.”.

1. Devices are: `/dev/ttyS0` and `0 = COM1`, ... For USB-port -> `ttyUSB0`
2. Nice manual for **stty**: <https://www.esrl.noaa.gov/gmd/dv/hats/cats/stations/qnxman/stty.html>

Interesting on how to send data (did not manage to get it work though): <https://unix.stackexchange.com/questions/117037/how-to-send-data-to-a-serial-port-and-see-a>

Setting baud rate: `stty -F /dev/ttyS0 9600`

Might be of interest (GTKTERM): http://elinux.org/Communicate_with_hardware_using_USB_cable_for_Ubuntu

USB-interface TDK-Lambda: https://www.us.tdk-lambda.com/hp/pdfs/Product_manuals/Genesys%20USB%20User%20Manual.pdf

Setting up

Following this: <https://unix.stackexchange.com/questions/117037/how-to-send-data-to-a-serial-port-and-see-any-answer>

1. `dmesg | grep tty` - checks serial port connection. Here you get `ttyUSB2 @ebbe` and seemingly `ttyUSB0 @lundiumberry`.
2. `sudo chmod o+rw /dev/ttyUSB2` - change read and writing permissions.
3. `stty -F /dev/ttyUSB2 9600 cs8 -cstopb` - Setting up TDK-Lambda communication protocol (see below).
4. Open two terminal tabs and read in one and write in the other:
5. *Read:* `cat -v < /dev/ttyUSB2`
6. *Write:* `echo -ne 'ADR 06' > /dev/ttyUSB2`
7. **NO ANSWER nor action:(**

According to manual:

- Baud rate: 9600
- Data bits: 8
- Parity: None

- Stop bits: 1
- Flow control: None

-> **stty command:** `stty -F /dev/ttyUSB2 9600 cs8 -cstopb`. In order: baud rate, data bits and stop bits. Correct? Don't do anything for parity and flow control? The following was also tried: `stty -F /dev/ttyUSB2 9600 cs8 -cstopb -parenb`

Tried:

1. Added `-crtcts -ixon` -> still not working. Tried to disable flow control as some pointed out.

Screen

How to send commands: <http://www.linuxquestions.org/questions/linux-software-2/how-to-send-a-command-to-a-screen-session-625015/> https://pixhawk.ethz.ch/tutorials/serial_terminal Setup was tried with: `screen /dev/ttyUSB2 9600,cs8,-parentb,-cstopb,-parenb`

Minicom: also tried, real sweet for port settings.