

# AVR UART Echo with Increment Program

Your Name

August 5, 2025

## Overview

This document explains a simple UART communication program for an AVR microcontroller (such as ATmega328P on Arduino Uno). The program initializes UART, receives a byte, increments it by 1, and sends it back.

## 1 Program Code

Listing 1: UART Echo with Increment

```
1  #define F_CPU 16000000UL
2  #define BAUD 9600
3  #define UBRR_VALUE ((F_CPU / (16UL * BAUD)) - 1)
4
5  #include <avr/io.h>
6
7  void uart_init() {
8      UBRROH = (uint8_t)(UBRR_VALUE >> 8);
9      UBRROL = (uint8_t)UBRR_VALUE;
10     UCSROB = (1 << RXEN0) | (1 << TXEN0);           // Enable RX
11     // and TX
12     UCSROC = (1 << UCSZ01) | (1 << UCSZ00);           // 8-bit
13     // data, 1 stop bit
14 }
15
16 uint8_t uart_receive() {
17     while (!(UCSR0A & (1 << RXC0))); // Wait for data to be
18     // received
19     return UDR0;                       // Return received byte
20 }
21
22 void uart_send(uint8_t data) {
23     while (!(UCSR0A & (1 << UDRE0))); // Wait for empty
24     // transmit buffer
```

```

21     UDRO = data;                                // Send data
22 }
23
24 int main(void) {
25     uart_init();
26
27     while (1) {
28         uint8_t received = uart_receive();
29         uint8_t incremented = received + 1;
30         uart_send(incremented);
31     }
32 }

```

## 2 Explanation of Components

### ATmega328P Microcontroller

The ATmega328P is the microcontroller used in the Arduino Uno. It features a Universal Synchronous and Asynchronous serial Receiver and Transmitter (USART) module which allows serial communication.

### UART Registers Used

- **UBRR0H and UBRR0L:** USART Baud Rate Registers High and Low byte. Used to set the baud rate.
- **UCSR0A (USART Control and Status Register A):** Contains flags like RXC0 (receive complete) and UDRE0 (data register empty).
- **UCSR0B (USART Control and Status Register B):** Controls enabling/disabling receiver (RXEN0) and transmitter (TXEN0).
- **UCSR0C (USART Control and Status Register C):** Configures frame format (data bits, parity, stop bits).
- **UDR0 (USART Data Register):** Used to read received data or write data to be transmitted.

### UART Pins on Arduino Uno (ATmega328P)

- **RX (Pin 0)** - Receive pin for serial data input.
- **TX (Pin 1)** - Transmit pin for serial data output.

### **3 How it works**

1. The UART is initialized with a baud rate of 9600 bps, 8 data bits, no parity, and 1 stop bit.
2. The program waits for a byte to be received via UART.
3. Once received, it increments the byte value by 1.
4. Then sends the incremented byte back through UART.
5. This process repeats indefinitely.

### **4 References**

- AVR libc User Manual - UART Baud Rate
- ATmega328P Datasheet