

## 02-3 Device Trees

A systematic way to describe hardware

Much taken from:

<http://learn.adafruit.com/introduction-to-the-beaglebone-black-device-tree>

## Device Tree - Overview

- A way to describe hardware in a system
- Example: how the UART interfaces with the system
  - which pins
  - how they should be muxed
  - the device to enable
  - which driver to use

## History

- Under the 3.2 kernel
  - Huge influx of ARM systems in the past few years
  - ARM board files described how each board worked
  - a lot of confusion and conflicts in the Linux kernel surrounding the ARM components
- Under the 3.8 kernel
  - Any new ARM boards use the flattened device tree

## Device Tree and Overlays

- The device tree is a file (or files) that describe at boot time all the hardware
- **Problem:** Embedded systems often add hardware at run time (i.e. capes)
- **Solution:** Device Tree Overlays and cape manager

## gpio Example Overlay

- See Handout
- Example is a tree structure of nodes and properties ([http://devicetree.org/Device\\_Tree\\_Usage](http://devicetree.org/Device_Tree_Usage))
- Start with

```
/*
 * Copyright (C) 2012 Texas Instruments Incorporated - http://www.ti.com/
 *
 * This program is free software: you can redistribute it and/or modify
 * it under the terms of the GNU General Purpose License Version 2 as
 * published by the Free Software Foundation
 *
 * Original from: github.com/jadonk/validation-scripts/blob/master/test-capemgr/
 *
 * Modified by Derek Molloy for the example on www.derekmolloy.ie
 * that maps GPIO pins for the example
 * From: https://github.com/derekmolloy/boneDeviceTree/tree/master/overlay
 */
```

## Walk Through – 1

```
/dts-v1/;
/plugin/;

// Version and plugin
/{
    // Root node
    compatible = "ti,beaglebone", "ti,beaglebone-black";

    // describes which platforms the DT overlay works with
    // most compatible -> least compatible

    // Name all the platforms that you'd like to support, as it will
    // fail to load in any platforms not mentioned.
```

## Walk Through – 2

```
part-number = "DM-GPIO-Test";
version = "00A0";
```

- Part number and version are further guards to ensure that the proper DT overlays are loaded.
- Also used for the name of the .dts file in the form of  
    <part-no>-<rev>.dts
- Also, as far as I can tell, the revision must be 00A0 on the BeagleBone Black.

## Walk Through – 3

### • Not in your example

```
/* state the resources this cape uses */
exclusive-use =
    /* the pin header uses */
    "P9.24", /* uart1_txd */
    "P9.26", /* uart1_rxd */
    /* the hardware ip uses */
    "uart1";
```

- exclusive-use property allows overlays to describe what resources they need, and prevents any other overlays from using those resources.

## Fragments

- Describe which target to overlay
- Use to customize either mux pins or enable devices

```
fragment@0 {
    target = <&am33xx_pinmux>;
    __overlay__ {
        pinctrl_test: DM-GPIO-Test-Pins {
            pinctrl-single,pins = <
                0x078 0x07 /* P9_12 60 OUTPUT MODE7 - The LED Output */
                0x184 0x2f /* P9_24 15 INPUT MODE7 none - The Button Input */
                0x034 0x37 /* P8_11 45 INPUT MODE7 pullup - Yellow Wire */
                0x030 0x27 /* P8_12 44 INPUT MODE7 pulldown - Green Wire */
                0x024 0x2f /* P8_13 23 INPUT MODE7 none - White Wire */
            /* OUTPUT GPIO(mode7) 0x07 pulldown, 0x17 pullup, 0x2f no pullup/down */
            /* INPUT GPIO(mode7) 0x27 pulldown, 0x37 pullup, 0x2f no pullup/down */
            >;
        };
    };
};
```

<https://www.kernel.org/doc/Documentation/devicetree/bindings/pinctrl/pinctrl-single.txt>

## Register values

- Use the Molloy P8/P9 tables to find the register values, or

```
bone$ exercises/gpio/findGPIO.js P9_12
{ name: 'GPIO1_28',
  gpio: 60,
  mux: 'gpmc_ben1',
  eeprom: 36,
  key: 'P9_12',
  muxRegOffset: '0x078',
  options:
    [ 'gpmc_ben1',
      'mii2_col',
      'NA',
      'mmc2_dat3',
      'NA',
      'NA',
      'mcaspo_aclkr',
      'gpio1_28' ] }
```

## Register values

```
• Or
bone$ ./findGPIO.js 7
Looking for gpio 7
{ name: 'GPIO0_7',
  gpio: 7,
  mux: 'ecap0_in_pwm0_out',
  eeprom: 4,
  pwm: { muxmode: 0, path: 'ecap0', name: 'ECAPPWM0' },
  key: 'P9_42',
  muxRegOffset: '0x164',
  options:
    [ 'ecap0_in_pwm0_out',
      'uart3_txd',
      'spi1_cs1',
      'pr1_ecap0_ecap_capin_apwm_o',
      'spi1_sclk',
      'mmc0_sdwp',
      'xdma_event_intr2',
      'gpio0_7' ] }
```

## Register contents

- From the Molloy table

GPIO Settings				
Bit 6	Bit 5	Bit 4	Bit 3	Bit 2,1,0
Slew Control	Receiver Active	Pullup/Pulldown	Enable Pullup/Pulldown	Mux Mode
0 Fast	0 Disable	0 Pulldown select	0 Enabled	000 Mode 0 to
1 Slow	1 Enable	1 Pullup select	1 Disabled	111 Mode 7

e.g. INPUT GPIO(mode7) 0x07 pulldown, 0x17 pullup, 0x2f no pullup/down

e.g. OUTPUT GPIO(mode7) 0x27 pulldown, 0x37 pullup, 0x2f no pullup/down

- Or from the Technical Reference Manual
- Section 9.2.2, page 747 (of 4161!)

Table 9-1. Pad Control Register Field Descriptions

Bit	Field	Value	Description
11:2	Reserved	Reserved	Reserved
6	SLEWCTL	0 1	Signal slew rate control. 0: Fast. 1: Slow.
5	RSACTIVE	0 1	Input enable value for the first bit to 0 for output only. Set to 1 for input or output. 0: Receiver disabled. 1: Receiver enabled.
4	PULLTYPESEL	0 1	First pullup/pulldown type selection. 0: Pullup selected. 1: Pulldown selected.
3	PULLUDEN	0 1	First pullup/pulldown enable. 0: Pullup/pulldown enabled. 1: Pullup/pulldown disabled.
2:0	BRUNMODE	000 001 010 011 100 101 110 111	First function signal mux select.

Some peripherals do not support slew rate. To determine which peripherals support each slew rate, see AM335x ARM Cortex-A8 Microprocessor J74450 Revision number (1700-171).

## Fragments - 2

- Enables gpio

```
fragment@1 {
    target = <&ocp>;
    __overlay__ {
        test_helper: helper {
            compatible = "bone-pinmux-helper";
            pinctrl-names = "default";
            pinctrl-0 = <&pinctrl_test>;
            status = "okay";
        };
    };
};
```

## Firmware

- DT Overlays live in /lib/firmware

```
bone$ ls /lib/firmware
3com                               bone_pwm_P8_46-00A0.dtbo
BB-ADC-00A0.dtbo                  bone_pwm_P8_46-00A0.dts
BB-ADC-00A0.dts                   bone_pwm_P9_14-00A0.dtbo
BB-BONE-AUDI-01-00A0.dtbo         bone_pwm_P9_14-00A0.dts
BB-BONE-AUDI-01-00A0.dts         bone_pwm_P9_16-00A0.dtbo
BB-BONE-BACON-00A0.dtbo          bone_pwm_P9_16-00A0.dts
-
BB-BONE-PRU-01-00A0.dtbo          cape-bone-adafruit-lcd-00A0.dtbo
BB-BONE-PRU-01-00A0.dts          cape-bone-adafruit-lcd-00A0.dts
-
BB-I2C1-00A0.dtbo                 cape-bone-nixie-00A0.dts
BB-I2C1-00A0.dts                 cape-bone-pinmux-test-00A0.dtbo
-
BB-SPI0-00A0.dtbo                 cape-bone-tester-00A0.dts
BB-SPI0-00A0.dts                 cape-bone-weather-00A0.dtbo
BB-SPI1-00A0.dtbo                 cape-bone-weather-00A0.dts
```

compiled

Source

## Listing Overlays

Defined in .bashrc

- bone\$ export SLOTS=/sys/devices/bone\_capemgr.\*/slots
- See what's loaded

```
bone$ cat $SLOTS
0: 54:PF---
1: 55:PF---
2: 56:PF---
3: 57:PF---
4: ff:P-O-L Bone-LT-eMMC-2G,00A0,Texas Instrument,BB-BONE-EMMC-2G
5: ff:P-O-L Bone-Black-HDMI,00A0,Texas Instrument,BB-BONELT-HDMI
```

No Capes

## Compiling and Loading Overlays

- Compile with

```
bone$ dtc -O dtb -o DM-GPIO-Test-00A0.dtbo -b 0 -@ DM-GPIO-Test.dts
```

Compiling the overlay from .dts to .dtbo

- Or

```
bone$ ./build
```

Compiling the overlay from .dts to .dtbo

- Install

```
bone$ cp DM-GPIO-Test-00A0.dtbo /lib/firmware
```

```
bone$ echo DM-GPIO-Test > $SLOTS
```

## Verify Overlay

- Check to be sure it worked

```
bone$ cat $SLOTS
0: 54:PF---
1: 55:PF---
2: 56:PF---
3: 57:PF---
4: ff:P-O-L Bone-LT-eMMC-2G,00A0,Texas Instrument,BB-BONE-EMMC-2G
5: ff:P-O-L Bone-Black-HDMI,00A0,Texas Instrument,BB-BONELT-HDMI
7: ff:P-O-L Override Board Name,00A0,Override Manuf,DM-GPIO-Test
```

- Remove with

```
bone$ echo -7 > $SLOTS
```

## Making it persistent

- You have to run the command...

```
bone$ echo DM-GPIO-Test > $SLOTS
```

- ...everytime you boot

- However you can make it automatically run at boot time with

- Edit the file /boot/uEnv.txt and add

```
cape_enable=capemgr.enable_partno=MAY-gpio-set
```

Not working with this kernel