

## A USER GUIDE FOR DONJON VERSION5

A. HÉBERT, D. SEKKI, AND R. CHAMBON

## Contents

Contents	ii
List of Tables	vi
List of Figures	ix
1 INTRODUCTION	1
2 GENERAL SPECIFICATION OF DONJON	3
2.1 Modules	3
2.2 Data structures	5
2.3 Syntactic rules for input specification	6
2.4 General input structure	6
3 GENERAL CORE-DESCRIPTION MODULES	8
3.1 The RESINI: module	8
3.1.1 Main input data to the RESINI: module	9
3.1.2 Input of global and local parameters	12
3.2 The USPLIT: module	16
3.2.1 Input data to the USPLIT: module	16
3.3 The MACINI: module	18
3.4 The DEVINI: module	19
3.4.1 Input data to the DEVINI: module	19
3.4.2 Description of dev-rod input structure	20
3.4.3 Description of rod-group input structure	22
3.5 The DETINI: module	23
3.5.1 Input data to the DETINI: module	23
3.5.2 Description of the detector data	24
3.6 The LZC: module	26
3.6.1 Input data to the LZC: module	26
3.6.2 Description of dev-lzc input structure	27
3.6.3 Description of lzc-group input structure	29
3.7 The DSET: module	30
3.7.1 Input data to the DSET: module	30
3.8 The MCC: module	32
3.8.1 Main input data to the MCC: module	32
3.9 The MOVDEV: module	34
3.9.1 Input data to the MOVDEV: module	34
3.10 The NEWMAC: module	36
3.11 The FLPOW: module	37
3.11.1 Input data to the FLPOW: module	38
3.12 The TAVG: module	40
3.12.1 Input data to the TAVG: module	40
3.12.2 Time-average calculation using DONJON	41
3.13 The TINST: module	43
3.13.1 Input data to the TINST: module	44
3.14 The SIM: module	46
3.14.1 Input data to the SIM: module	46
3.15 The XENON: module	50
3.15.1 Input data to the XENON: module	50
3.16 The DETECT: module	52
3.16.1 Input data to the DETECT: module	52
3.17 The CVR: module	54
3.17.1 Input data to the CVR: module	54
3.18 The HST: module	57

3.18.1	Example	60
3.19	The <b>ROD:</b> module	64
3.19.1	Main input data to the <b>ROD:</b> module	64
3.20	The <b>IDET:</b> module	67
3.20.1	Input data to the <b>IDET:</b> module	67
4	<b>CROSS-SECTION INTERPOLATION MODULES</b>	69
4.1	The <b>CRE:</b> module	69
4.1.1	Input data for the <b>CRE:</b> module	70
4.2	The <b>NCR:</b> module	73
4.2.1	Interpolation data input for module <b>NCR:</b>	73
4.2.2	Defining local and global parameters	75
4.2.3	Interpolation in the parameter grid	77
4.3	The <b>SCR:</b> module	84
4.3.1	Interpolation data input for module <b>SCR:</b>	84
4.3.2	Defining global parameters	86
4.3.3	Depletion data structure	88
4.3.4	Interpolation in the parameter grid	89
4.4	The <b>ACR:</b> module	94
4.4.1	Interpolation data input for module <b>ACR:</b>	94
4.4.2	Defining global parameters	96
4.4.3	Depletion data structure	98
4.4.4	Interpolation in the parameter grid	99
4.5	The <b>PCR:</b> module	100
4.5.1	Interpolation data input for module <b>PCR:</b>	100
4.5.2	Defining parameters	101
4.5.3	Depletion data structure	103
4.6	The <b>AFM:</b> module	105
4.6.1	Input data to the <b>AFM:</b> module	105
4.7	The <b>T16CP0:</b> module	110
4.7.1	Input data for the <b>T16CP0:</b> module	111
4.8	The <b>D2P:</b> module	114
4.8.1	The <b>PMAXS</b> format	114
4.8.2	General format of the module	117
5	<b>THERMAL-HYDRAULICS MODULES</b>	127
5.1	The <b>THM:</b> module	127
5.1.1	Input data to the <b>THM:</b> module	127
6	<b>POINT KINETICS MODULES</b>	134
6.1	The <b>PKINI:</b> module	134
6.1.1	Input data to the <b>PKINI:</b> module	134
6.2	The <b>PKINS:</b> module	137
6.2.1	Input data to the <b>PKINS:</b> module	137
7	<b>OPTIMIZATION MODULES</b>	139
7.1	The <b>DLEAK:</b> module	139
7.1.1	Data input for module <b>DLEAK:</b>	139
7.2	The <b>DSPH:</b> module	141
7.2.1	Data input for module <b>DSPH:</b>	141
7.3	The <b>DREF:</b> module	143
7.3.1	Minimizing the RMS error of power distribution	143
7.3.2	Minimizing the RMS error associated with <b>SPH</b> factor calculation	143
7.3.3	Calling specifications	147
7.4	The <b>GRAD:</b> module	149
7.4.1	Data input for module <b>GRAD:</b>	149
7.5	The <b>PLQ:</b> module	151

7.5.1	Data input for module PLQ:	151
7.6	The LNSR: module	154
7.6.1	Data input for module LNSR:	155
7.7	The FPSPH: module	157
7.7.1	Data input for module FPSPH:	158
8	PIN-POWER RECONSTRUCTION MODULES	160
8.1	The NAP: module	160
8.1.1	Additional properties calculations	161
8.1.2	Pin power reconstruction	162
8.1.3	Heterogeneous assembly geometry definition	163
9	DONJON DATA STRUCTURES	165
9.1	Contents of /fmap/ data structure	165
9.1.1	The state-vector content	165
9.1.2	The main /fmap/ directory	166
9.1.3	The FUEL sub-directories	170
9.1.4	The {hcycle} sub-directories	170
9.1.5	The PARAM sub-directories	172
9.1.6	The ROD-INFO sub-directory	172
9.1.7	The ASSEMBLY sub-directory	173
9.2	Contents of /matex/ data structure	175
9.2.1	The state-vector content	175
9.2.2	The /matex/ directory	175
9.3	Contents of /device/ data structure	177
9.3.1	The state-vector content	177
9.3.2	The main /device/ directory	177
9.3.3	The DEV-ROD sub-directories	178
9.3.4	The ROD-GROUP sub-directories	179
9.3.5	The DEV-LZC sub-directories	179
9.3.6	The LZC-GROUP sub-directories	180
9.4	Contents of a /detect/ data structure	181
9.4.1	The state-vector content	181
9.4.2	The main /detect/ directory	181
9.4.3	The /name_type/ sub-directories	181
9.4.4	The /name_detect/ sub-directories	182
9.5	Contents of /power/ data structure	183
9.5.1	The state-vector content	183
9.5.2	The /power/ directory	183
9.6	Contents of /history/ data structure	185
9.6.1	The main directory	185
9.6.2	The fuel type sub-directory	186
9.6.3	The cell type sub-directory	187
9.7	Contents of /thm/ data structure	188
9.7.1	The main /thm/ directory	188
9.7.2	The HISTORY-DATA sub-directory	191
9.8	Contents of a /optimize/ data structure	193
9.8.1	The sub-directory /OLD-VALUE/ in /optimize/	196
9.9	Contents of /d2p.info/ data structure	197
9.9.1	The state-vector content	197
9.10	Contents of a /intdetec/ data structure	205
9.10.1	The state-vector content	205
9.10.2	The main /intdetec/ directory	205
10	EXAMPLES	206
10.1	(Example1) – Compo related example	207

10.2	(Example2) – Multicompo related example . . . . .	211
10.3	Procedures . . . . .	214
10.3.1	Input file for geometry . . . . .	214
10.3.2	Input file for devices . . . . .	217
10.3.3	Input file for fuel map . . . . .	226
10.3.4	Input file for exit burnups . . . . .	229
References	. . . . .	232
Index	. . . . .	235

## List of Tables

1	Structure <b>(DONJON)</b>	6
2	Structure RESINI:	8
3	Structure <b>(descresini1)</b>	9
4	Structure <b>(descresini2)</b>	12
5	Structure USPLIT:	16
6	Structure <b>(desclink)</b>	16
7	Structure MACINI:	18
8	Structure DEVINI:	19
9	Structure <b>(descdev)</b>	19
10	Structure <b>(dev-rod)</b>	21
11	Structure <b>(rod-group)</b>	22
12	Structure DETINI:	23
13	Structure <b>(descinidet)</b>	23
14	Structure <b>(descdet)</b>	24
15	Structure LZC:	26
16	Structure <b>(descLzc)</b>	27
17	Structure <b>(dev-lzc)</b>	27
18	Structure <b>(lzc-group)</b>	29
19	Structure DSET:	30
20	Structure <b>(descdset)</b>	30
21	Structure MCC:	32
22	Structure <b>(descmcc1)</b>	32
23	Structure MOVDEV:	34
24	Structure <b>(descmove)</b>	34
25	Structure NEWMAC:	36
26	Structure FLPOW:	37
27	Structure <b>(descflpow)</b>	38
28	Structure TAVG:	40
29	Structure <b>(desctavg)</b>	40
30	Structure TINST:	43
31	Structure <b>(desctinst)</b>	44
32	Structure SIM:	46
33	Structure <b>(descsim)</b>	47
34	Structure XENON:	50
35	Structure <b>(descxenon)</b>	51
36	Structure DETECT:	52
37	Structure <b>(descdetect)</b>	52
38	Structure CVR:	54
39	Structure <b>(descrcvr)</b>	54
40	Updating an HISTORY structure using a MAP structure	57
41	Updating an HISTORY structure using a BURNUP structure	57
42	Updating a BURNUP structure using an HISTORY structure	57
43	Updating an HISTORY structure using a MAP structure	57
44	Structure <b>(hstdim)</b>	58
45	Structure <b>(hstbrn)</b>	59
46	Structure <b>(hstpar)</b>	60
47	Structure ROD:	64
48	Structure <b>(descrod1)</b>	65
49	Structure IDET:	67
50	Structure <b>(descidet)</b>	67

51	Structure CRE:	69
52	Structure (desc cre1)	70
53	Structure (desc cre2)	70
54	Structure (desc data1)	71
55	Structure (desc data2)	71
56	Structure (NCR:)	73
57	Structure (ncr_data)	73
58	Structure (desc intf)	75
59	NCR inputs for instantaneous cases	80
60	NCR inputs for TA cases	81
61	Structure (SCR:)	84
62	Structure (scr_data)	84
63	Structure (desc ints)	86
64	Structure (desc depl)	88
65	SCR inputs for instantaneous cases	92
66	SCR inputs for TA cases	93
67	Structure (ACR:)	94
68	Structure (scr_data)	94
69	Structure (ACR desc ints)	96
70	Structure (desc depl)	98
71	Structure (PCR:)	100
72	Structure (PCR_data)	100
73	Structure (desc intf)	101
74	Structure (desc depl)	103
75	Structure AFM:	105
76	Structure (desc afm)	105
77	AFM options summary	109
78	Structure T16CP0:	110
79	Structure (desc t16cpo)	111
80	Structure D2P:	117
81	Structure (desc phase1)	118
82	Structure THM:	127
83	Structure (desc thm)	127
84	Structure PKINI:	134
85	Structure (desc pkini)	134
86	Structure PKINS:	137
87	Structure (desc pkins)	137
88	Structure (DLEAK:)	139
89	Structure (dleak_data)	139
90	Structure (DSPH:)	141
91	Structure (dsph_data)	141
92	Structure (DREF:)	147
93	Structure GRAD:	149
94	Structure grad_data	149
95	Structure PLQ:	151
96	Structure plq_data	151
97	Structure LNSR:	154
98	Structure lnsr_data	155
99	Structure FPSPH:	158
100	Structure fpsph_data	158
101	Structure (NAP:)	160
102	Structure (desc nap1)	161
103	Structure (desc nap2)	162

104	Structure ( <b>descnap3</b> )	163
105	Records and sub-directories in /fmap/ data structure	166
106	Records in <b>FUEL</b> sub-directories	170
107	Records in {hcycle} sub-directories	170
108	Records in <b>PARAM</b> sub-directories	172
109	Records in <b>ROD-INFO</b> sub-directories	173
110	Assembly type sub-directory	173
111	Records in /matex/ data structure	175
112	Records and sub-directories in /device/ data structure	177
113	Records in <b>DEV-ROD</b> sub-directories	178
114	Records in <b>ROD-GROUP</b> sub-directories	179
115	Records in <b>DEV-LZC</b> sub-directories	180
116	Records in <b>LZC-GROUP</b> sub-directories	180
117	Records and sub-directories in /detect/ data structure	181
118	Records in /name.type/ sub-directories	182
119	Records in /name.detect/ sub-directories	182
120	Records in /power/ data structure	183
121	Main records and sub-directories in /history/	185
122	Fuel type sub-directory	186
123	Cell sub-directory	187
124	Main records and sub-directories in /thm/	188
125	Sub-directories in <b>HISTORY-DATA</b> directory	191
126	Records in <b>TIMESTEP</b> directories	192
127	Records in each <b>CHANNEL</b> directory	192
128	Main records and sub-directories in /optimize/	194
129	Main records and sub-directories in //OLD-VALUE//	196
130	Records and sub-directories in /d2p.info/ data structure	199
131	Records and sub-directories in /SAPHYB_INFO/	199
132	Records in /PKEY_INFO/	200
133	Records and sub-directories in /HELIOS_HEAD/	201
134	Records and sub-directories in /GENPMAXS_INP/	201
135	Records in sub-directory /TH_DATA/	202
136	Records and sub-directories in sub-directory /BRANCH_INFO/	202
137	Sub-directories in /CROSS_SECT/	203
138	Records in the sub-directory /MACROLIB_XS/	203
139	Records in the sub-directory /MICROLIB_XS/	204
140	Records in the sub-directory /DIVERS/	204
141	Records in /intdetec/ data structure	205



## List of Figures

1	Presentation of fully- and partially-inserted 3-part control rods. . . . .	20
2	Presentation of a partially-inserted 2-part control rod. . . . .	64
3	Complete grid, one point case . . . . .	82
4	Complete grid, TA case . . . . .	82
5	Partial grid, complete planes, one point case . . . . .	82
6	Partial grid, complete planes, TA case . . . . .	82
7	Partial grid, complete axis, one point case . . . . .	82
8	Partial grid, complete axis, TA case . . . . .	82
9	Partial grid, complete axis with another configuration, one point case . . . . .	83
10	Partial grid, one complete plane and one complete axis, one point case . . . . .	83
11	Partial grid, one complete plane and one complete axis, TA case . . . . .	83
12	Partial grid, one complete plane and one complete axis with another configuration, one point case . . . . .	83
13	Simplified cluster geometry used for CANDU reactor cases. . . . .	130
14	Line search iterations. . . . .	154
15	Fixed point SPH iterations. . . . .	157
16	Newton SPH iterations. . . . .	157
17	Face View of ACR Benchmark Core Model (292 Channels) . . . . .	206
18	Geometry definition (plane-1) . . . . .	215
19	Top View of ACR Benchmark Core Model . . . . .	218
20	Combustion zones definition . . . . .	229

## 1 INTRODUCTION

DONJON is a full-core modelization code designed around solution techniques of the neutron diffusion or simplified  $P_n$  equation.<sup>[1]</sup> The current DONJON package is an evolution version, released as an attempt to introduce the innovative capabilities for the full-core modeling and simulations of different types of nuclear reactors such as Pressurized Water Reactors (PWRs), legacy CANDU reactors, and Advanced CANDU Reactors (ACRs). The computer code DONJON (Release 4.0) is part of Version4 distribution<sup>[2]</sup>, built around the GAN generalized driver<sup>[3]</sup>. The current DONJON package (DONJON Version5) is a rewrite of the code around the GANLIB5 kernel<sup>[4]</sup>, intended to be 64-bit clean.

DONJON execution depends on other computer codes, components of Version4, namely: GANLIB, UTILIB, DRAGON<sup>[5]</sup>, and TRIVAC<sup>[6]</sup> codes. The DRAGON modules are used with DONJON code to define the reactor geometry, to provide the macroscopic cross-section libraries and to perform micro-depletion calculations. The TRIVAC solver modules are used to perform a spatial discretization of the reactor geometry and to provide the numerical solution according to the user-selected numerical procedure<sup>[7-12]</sup>. The UTILIB library provides the utility and linear algebra libraries. Finally, the GANLIB computer code provides CLE-2000 capabilities to control data flows and to implement *computational schemes*. GANLIB also provide LCM data structures to exchange information between modules.

The DONJON code is divided into several modules, each module is designed to perform some particular tasks. The transfer of information between the modules is achieved by means of well defined data structure. Several design features, data structure and computing algorithms were recovered, revised and adapted from the previous DONJON version<sup>[13,14]</sup>. One of the main concerns of the DONJON developers is to ensure the code reliability and extensibility.

The DONJON modules are first designed for the reactor full-core modeling in 3-D Cartesian geometry. These modules are built around the reactor fuel lattice specification corresponding to the common design features of CANDU reactors. The modules related to the modeling of reactivity mechanisms, which are normally presented in the reactor core, also constitute an important part of code. The DONJON code can perform several full-core calculations and can be used to determine some important core characteristics, such as the power and normalized flux distributions over the reactor core. All full-core calculations using current version of DONJON correspond to the reactor static conditions.

The modeling of the reactor fuel lattice using DONJON is made in considering that the fuel lattice is composed of a well defined number of fuel channels and bundles. All reactor channels contain the same number of fuel bundles and are identified by their specific names. The fuel bundles have a distinct set of properties that are recovered and interpolated according to the specified global and local parameters. The interpolation of fuel properties with respect to burnup distribution can be performed according to the time-average or instantaneous models<sup>[15]</sup>. The time-average calculation is performed in considering the bidirectional refuelling scheme of reactor channels and assuming that all channels have the same bundle-shift.

The modeling of the reactivity mechanisms is based on their specified parameters, which include the devices position, rods insertion level, water filling level, direction of movement, etc. The rod-devices insertion level can be set according to their nominal positions or they can be displaced in and out of core. The devices can also be divided into several groups so that they can be manipulated, displaced or moved simultaneously. The time-dependent behaviour of the moving devices can be modeled and used for the transient simulations or reactor control studies. The reactivity worth of devices can also be studied and predicted using DONJON.

The reactor material properties are essentially recovered from the reactor database, obtained from the lattice calculations using DRAGON code. The two distinct macroscopic cross-section libraries can be constructed using DONJON. The first MACROLIB is constructed only for the material properties which are evolution-independent, such as reflector and devices properties. The second MACROLIB is constructed only for the fuel properties, defined per each fuel bundle over the fuel lattice. The two libraries are next combined and updated, according to the devices insertion level. The produced extended MACROLIB is subsequently used to obtain the numerical solution, using TRIVAC modules.

Finally, it should be noted that the DONJON code development is permanently in progress. The

future updates will provide several extended capabilities for the reactor design and calculations; they will be gradually added to the subsequent DONJON versions.

## 2 GENERAL SPECIFICATION OF DONJON

### 2.1 Modules

Reactor calculations using DONJON are performed by means of sequential execution of several user-selected modules, according to the user-defined computing scheme. Each module is designed to perform some particular tasks. The detailed description of DONJON modules is given in Section 3 to Section 6. In order to perform the reactor calculations, it is also required to use some DRAGON and TRIVAC modules. For more details on DRAGON modules specification, refer to its user guide<sup>[5]</sup>; for more details on TRIVAC modules specification, refer to its user guide<sup>[6]</sup>. Because the code execution is controlled by the GAN generalized driver, it is also possible to use its utility modules<sup>[3, 5]</sup>. A brief description of each module that can be executed using DONJON is given below. A short description of each data structure that can be used in DONJON is given in Section 2.2.

- The following DRAGON modules can be executed using DONJON:

GE0:	module used to create or modify a reactor geometry. The spatial locations of the reactor material mixtures must also be defined using the GE0: module. Only 3-D Cartesian reactor geometries are allowed with DONJON.
MAC:	module used to create or modify a MACROLIB containing the material properties, by directly specifying the group-ordered macroscopic cross-sections for each selected material mixture.

- The following TRIVAC modules can be executed using DONJON:

TRIVAT:	module used to perform a 3-D numerical discretization or “tracking” of the reactor geometry.
TRIVAA:	module used to compute the set of system matrices with respect to the previously obtained “tracking” information.
FLUD:	module used to compute the numerical solution to an eigenvalue problem, corresponding to a previously obtained set of system matrices.

- The following are short descriptions of utility modules that can be executed using DONJON:

UTL:	module used to perform several utility actions on a data structure.
DELETE:	module used to delete one or many data structures.
GREP:	module used to extract a single value from a data structure.
END:	module used to delete all the local linked lists, to close all the remaining local files and to return from a procedure; or to terminate the overall DONJON execution controlled by the GAN generalized driver.

- The following are short descriptions of DONJON modules:

CRE:	module used to create a MACROLIB containing the material properties, by interpolating the nuclear properties from a mono-parameter database, previously generated in the lattice code.
NCR:	module used to create a MICROLIB or a MACROLIB containing the material properties, by interpolating the nuclear properties from a multi-parameter database, previously generated in the lattice code.
AFM:	module used to create a MACROLIB containing the material properties, by interpolating the nuclear properties from a multi-parameter feedback model database, previously generated in the lattice code.
USPLIT:	module used to create an extended reactor material index over the whole mesh-splitted reactor geometry.
RESINI:	module used to define the fuel lattice, to create the fuel-map geometry and to specify the global and local parameters.
MACINI:	module used to create an extended MACROLIB, in which the properties are stored per each material region, over the whole mesh-splitted reactor geometry.
DEVINI:	module used for 3-D modeling of rod-type devices in the reactor core.
DETINI:	module used to read and store detector information.
LZC:	module used for 3-D modeling of liquid zone controllers in the reactor core.
DSET:	module used to set the new devices parameters, that can be used for the reactivity worth studies.
MCC:	module used to modify the fuel map in order to compute a Doppler or general reactivity coefficient.
MOVDEV:	module used to compute the time-dependent positions of the moving rod-type devices.
NEWMAC:	module used to create an extended MACROLIB, that will contain the updated material properties, computed with respect to the actual devices positions.
FLPOW:	module used to compute and print powers and normalized fluxes over the reactor core.
TAVG:	module used to perform burnups calculation according to the time-average model, compute burnups integration limits, core-average exit burnup, axial power-shapes and channel refuelling rates.
TINST:	module used to perform burnups calculation according to the time-linear model and compute instantaneous burnups values. This module is specific to Candu reactor refuelling.
SIM:	module used to perform burnups calculation according to the time-linear model and compute instantaneous burnups values. This module is specific to PWR reactor refuelling.
DETECT:	module used to compute the mean flux at each detector site and the response of each detector according to different types of interpolation.
CVR:	module used for the core-voiding simulations.
HST:	module used to manage a full reactor execution in DONJON using explicit DRAGON calculations for each cell (see Section 3.18). <sup>[19]</sup>
NAP:	pin power reconstruction module. <sup>[48,49]</sup>

## 2.2 Data structures

The transfer of information between the modules is performed by means of well defined data structures, also called objects. The objects can be defined in either create, read-only or modification mode. Each object has its own specific signature that can be easily recognized by a module. A detailed description of DONJON data structures is given in Section 9. For more details on DRAGON and TRIVAC data structures, refer to their guide<sup>[18]</sup>. A brief description of all data structures that can be used in DONJON is given below.

GEOMETRY	data structure containing the geometry information. This object has a signature <code>L_GEOM</code> ; it is created using DRAGON module <code>GE0</code> .
MACROLIB	data structure containing the multigroup macroscopic properties; it has a signature <code>L_MACROLIB</code> . This object can be created in several modules, namely: using DRAGON modules <code>MAC</code> and <code>NCR</code> ; or using DONJON modules <code>CRE</code> , <code>MACINI</code> , and <code>NEWMAC</code> .
COMPO	data structure containing the mono-parameter database, generated by the lattice code. This object has a signature <code>L_COMPO</code> ; it is created using DRAGON module <code>CP0</code> .
MULTICOMPO	data structure containing the multi-parameter database, generated by the lattice code. This object has a signature <code>L_MULTICOMPO</code> ; it is created using DRAGON module <code>COMPO</code> .
SAPHYB	data structure containing the multi-parameter database, generated by the lattice code. This object has a signature <code>L_SAPHYB</code> ; it is created using the APOLLO2 lattice code or the DRAGON module <code>SAP</code> .
FMAP	data structure containing the fuel-lattice specification. This object has a signature <code>L_MAP</code> ; it is created using DONJON module <code>RESINI</code> .
MATEX	data structure containing the extended reactor material index. This object has a signature <code>L_MATEX</code> ; it is created using DONJON module <code>USPLIT</code> .
DEVICE	data structure containing the devices specification. This object has a signature <code>L_DEVICE</code> ; it is created using DONJON module <code>DEVINI</code> .
DETECT	data structure containing detector positions and responses. This object has a signature <code>L_DETECT</code> ; it is created using DONJON module <code>DETINI</code> , and can be modified by the modules <code>DETINI</code> and <code>DETECT</code> .
TRACK	data structure containing a "tracking" information of the reactor geometry. This object has a signature <code>L_TRACK</code> ; it is created using TRIVAC module <code>TRIVAT</code> .
SYSTEM	data structure containing a set of system matrices. This object has a signature <code>L_SYSTEM</code> ; it is created using TRIVAC module <code>TRIVAA</code> .
FLUX	data structure containing the numerical solution to an eigenvalue problem. This object has a signature <code>L_FLUX</code> ; it is created using TRIVAC module <code>FLUD</code> .
POWER	data structure containing the powers and normalized fluxes over the reactor core. This object has a signature <code>L_POWER</code> ; it is created using DONJON module <code>FLPOW</code> .
HISTORY	This data structure contains the information required to ensure a smooth coupling of DRAGON with DONJON when an history based full reactor calculation is to be performed. It is used only by the <code>HST</code> module.

### 2.3 Syntactic rules for input specification

The input data to any module is read in free format using the subroutine REDGET. CLE-2000 variables<sup>[22,23]</sup> are also allowed. The user guide for DONJON is written using the following convention:

- the parameters surrounded by single square brackets '[' ]' denote an optional input;
- the parameters surrounded by double square brackets '[[ ]]' denote an input which may be repeated as many times as needed;
- the parameters in braces separated by vertical bars '{ | }' denote a choice where one and *only* one input is mandatory;
- the parameters in **bold face** and in brackets '( )' denote an input structure;
- the parameters in italics and in brackets with an index '*(data(i) , i = 1, n )*' denote a set of n inputs;
- the words using the typewriter font **KEYWORD** are character constants used as keywords;
- the words in italics denote the user-defined variables: they are lower-case and of integer type (when starting from *i* to *n*), or of real type (when starting from *a* to *h* or from *o* to *z*); or they are upper-case and of character type *CHARACTER*.

### 2.4 General input structure

DONJON is built around the GAN generalized driver<sup>[3,23]</sup>. Accordingly, all the modules that will be used during the current execution must be first identified. It is also necessary to define the format of each object (data structure) that will be processed by these modules. Then, the modules required for the specific DONJON calculation are called successively, information being transferred from one module to the next via the objects. Finally, the execution of DONJON is terminated when it encounters the **END:** module, even if it is followed by additional data records in the input data stream. The general input data structure therefore follows the calling specifications given below:

Table 1: Structure (**DONJON**)

```
[ MODULE [[ MODNAME ]] ; ]
[ LINKED_LIST [[ STRNAME ]] ; ]
[ XSM_FILE [[ STRNAME ]] ; ]
[ SEQ_BINARY [[ STRNAME ]] ; ]
[ SEQ_ASCII [[ STRNAME ]] ; ]
[[ (module) ; ]]
END: ;
```

where

<b>MODULE</b>	keyword used to specify the names of all modules that will be used in the current DONJON execution.
<b>MODNAME</b>	<b>character*12</b> name of a DONJON, or DRAGON, or TRIVAC, or utility module. The list of modules that can be executed using DONJON code is provided in Section 2.1.

LINKED_LIST	keyword used to specify the names of data structure that will be stored as linked lists.
XSM_FILE	keyword used to specify the names of all data structure that will be stored on XSM format files.
SEQ_BINARY	keyword used to specify the names of all data structure that will be stored on sequential binary files.
SEQ_ASCII	keyword used to specify the names of all data structures that will be stored on sequential ASCII files.
STRNAME	<b>character*12</b> name of a data structure. The list of data structure that can be used in DONJON is presented in Section 2.2.
( <b>module</b> )	input specification for a module that will be executed. For DONJON specific modules, these input structures are described in Section 3 to Section 6.
END:	keyword to call the normal end-of-execution utility module.
;	keyword to specify the end of record. This keyword is used to delimit the part of the input data stream associated with each module.

Generally, the user has the choice to declare the most of data structure in the format of a linked list to reduce CPU times or as a XSM file to reduce memory resources. In general, the data structure are stored on the sequential ASCII files only for the backup purposes.

The input data normally ends with a call to the **END:** module. However, the GAN driver will insert automatically the **END:** module, even if it was not provided, upon reaching an end-of-file in the input stream.

Each (**module**) calling specification contains a module execution description and its associated input structure. All these modules, except the **END:** module may be called more than once.



### 3 GENERAL CORE-DESCRIPTION MODULES

#### 3.1 The RESINI: module

The **RESINI:** module is used for modeling of the reactor fuel lattice in *3-D* Cartesian geometry or *3-D* Hexagonal geometry. This modeling is based on the following considerations:

- For *3-D* Cartesian geometry, the reactor fuel lattice is composed of a well defined number of fuel channels. Each channel is composed of a well defined number of *fuel bundles*. In **RESINI:** terminology, a *fuel bundle* can be a CANDU fuel cluster or an axial slice of a PWR or FBR assembly with homogeneous cross sections. Each reactor channel is identified by its specific name which corresponds to its position in the fuel lattice.

In a Candu reactor, the channels are refuelled according to the bidirectional refuelling scheme. The refuelling scheme of a channel corresponds to the number of displaced fuel bundles (bundle-shift) during each channel refuelling. The direction of refuelling corresponds to the direction of coolant flow along the channel.

In a PWR, a basic assembly layout can be projected over the fuel map using a naval-coordinate position system. Assembly refuelling and shuffling will be possible using the ad hoc module **SIM:** (see Section 3.14).

- For *3-D* Hexagonal geometry, the reactor fuel lattice is composed of a well defined number of fuel channels and each channel is composed of a well defined number of fuel bundle. All fuel bundles have the same volume. All channels contain the same number of fuel bundles. Refuelling is not available during the calculation. The lattice indexation is kept to identify the hexagons.
- The fuel regions generally have a different set of global and local parameters. For example, the fuel bundles have a different evolution of the fuel properties according to the given burnup distribution, which is a global parameter. Consequently, the homogenized cell properties will differ from one fuel region to another, i.e., they are not uniform over the fuel lattice. Thus, the realistic modeling of a reactor core requires the fuel properties to be interpolated with respect to global and local parameters, which must be specified in the fuel map.

Note that the above considerations correspond to the typical core modeling of CANDU or PWR reactors. The **RESINI:** module will create a new **FMAP** object that will store the information related to the fuel lattice specification and properties (see Section 9.1).

In PWR cases, each channel correspond to an assembly. Using heterogeneous mixtures in one assembly increases the complexity of the geometry. However, two levels geometries (embedded geometry) are not possible in the DONJON code. The general idea is then to define one channel per mixture for all assemblies. All these channels have then to be regrouped by assembly to impose the same burnup. This process could be done manually, but if the heterogeneity of the cross-section is large (ex. one mixture per pin within a complete core), the geometry definition may be too complex. This task can be performed automatically by the module **NAP:**.

The **RESINI:** module specifications are:

Table 2: Structure **RESINI:**

```
{ FLMAP MATEX := RESINI: MATEX [COMPO] :: (descresini1) |
  FLMAP := RESINI: FLMAP [FLMAP2] :: (descresini2) }
```

where

<i>FLMAP</i>	<b>character*12</b> name of the RESINI object that will contain the fuel-lattice information. If <i>FLMAP</i> appears on both LHS and RHS, it will be updated; otherwise, it is created.
<i>MATEX</i>	<b>character*12</b> name of the MATEX object specified in the modification mode. <i>MATEX</i> is required only when <i>FLMAP</i> is created.
<i>COMPO</i>	<b>character*12</b> name of the MULTICOMPO data structure (L_COMPO signature) where the detailed subregion geometry at assembly level is stored.
<i>FLMAP2</i>	<b>character*12</b> name of the RESINI object that contains the fuel-lattice information to recover from.
(descresini1)	structure describing the main input data to the RESINI: module. Note that this input data is mandatory and must be specified only when <i>FLMAP</i> is created.
(descresini2)	structure describing the input data for global and local parameters. This data is permitted to be modified in the subsequent calls to the RESINI: module.

### 3.1.1 Main input data to the RESINI: module

Note that the input order must be respected.

Table 3: Structure (descresini1)

```
[ EDIT iprint ]
::: [ SPLIT-NAP: ] GEO: (descgeo)
[ ::: NAP: (descnap3) ]
[ ASSEMBLY na nax nay
  A-ZONE { (iza(i) , i = 1, nch) A-NX (nbax(i) , i = 1, nay) A-IBX (ibax(i) , i = 1, nay) | ASBLY }
  AXNAME (XNAMEA(i) , i = 1, nax)
  AYNAME (YNAMEA(i) , i = 1, nay) ]
{ NXNAME (XNAME(i) , i = 1, nx) NYNAME (YNAME(i) , i = 1, ny)
  | NHNAME (HNAME(i) , i = 1, nh) }
[ SIM lx ly (naval(i) , i = 1, nch) ]
[ FOLLOW nis (HISOT(i) , i = 1, nis) ]
NCOMB { ncomb B-ZONE (icz(i) , i = 1, nch) | ALL | ASBLY }
(descresini2)
```

where

EDIT	keyword used to set <i>i</i> print.
<i>i</i> print	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); larger values produce increasing amounts of output.
:::	keyword used to indicate the call to an embedded module.

SPLIT-NAP:	keyword to specify that the embedded geometry will be split by the embedded NAP: module .
GEO:	keyword used to call the GEO: module. The fuel-map geometry differs from the complete reactor geometry in the sense that it must be defined as a coarse geometry, i.e. without mesh-splitting over the fuel bundles. Consequently, the mesh-spacings over the fuel regions must correspond to the bundle dimensions (e.g. $h_x=width$ ; $h_y=height$ ; $h_z=length$ or in 3-D Hexagonal geometry $h_x=side$ ; $h_z=height$ ). Note that the total number of non-virtual regions in the embedded geometry must equal to the number of fuel channels <i>times</i> the number of fuel bundles per channel. This means that only the fuel-type mixture indices are to be provided in the data input to the GEO: module for MIX record. Other material regions (e.g. reflector) must be declared as virtual, i.e. with the mixtures indices set to 0.
(descgeo)	structure describing the input data to the GEO: module (see the DRAGON5 user guide <sup>[5]</sup> ). Only 3-D Cartesian or 3-D Hexagonal fuel-map geometry is allowed.
NAP:	keyword used to call the NAP: module. The heterogeneous assembly geometry definition will be called using the geometry defined previously with the embedded module GEO: and the COMPO data structure. See section 8.1.3 for important note on the coarse geometry requirement.
(descnap3)	structure describing the input data to the NAP: module to automatically define the core geometry with heterogeneous assembly (See Section 8.1.3).
ASSEMBLY	keyword to specify that assembly related information are provided.
na	number of assemblies.
nax	number of assemblies along x-direction.
nay	number of assemblies along y-direction.
A-ZONE	keyword to specify the assembly number <i>iza</i> of each channels.
iza	assembly belonging number.
A-NX	keyword to specify the number of assembly <i>nbax</i> per row.
nbax	number of assembly for each row.
A-IBX	keyword to specify the column for the first assembly <i>ibax</i> on each row.
ibax	column number for the first assembly on each row.
ASBLY	(after A-ZONE) keyword to automatically compute the assembly number of each channel. A call to the embedded module NAP: is required previously.
AXNAME	keyword to specify the assembly position names along x-direction XNAMEA.
XNAMEA	character*2 array of horizontal channel names. A horizontal channel name is identified by the channel column using numerical characters '1', '2', '3', and so on. Note that the total number of X-names must equal to <i>nx</i> .
AYNAME	keyword to specify the assembly position names along y-direction YNAMEA.
YNAMEA	character*2 array of horizontal channel names. A horizontal channel name is identified by the channel column using numerical characters 'A', 'B', 'C', and so on. Note that the total number of Y-names must equal to <i>ny</i> .

<i>NXNAME</i>	keyword used to specify <i>XNAME</i> for 3-D Cartesian geometry case.
<i>XNAME</i>	<b>character*2</b> array of horizontal channel names. A horizontal channel name is identified by the channel column using numerical characters '1', '2', '3', and so on. Note that the total number of X-names must equal to the total number of subdivisions along the X-direction in the fuel-map geometry. All non-fuel regions are to be assigned a single character '-'. This option is not available for 3-D Hexagonal geometry. When assembly are defined and split, several names can be the same.
<i>nx</i>	integer total number of subdivisions along the X-direction in the fuel-map geometry. Not used for 3-D hexagonal geometry.
<i>NYNAME</i>	keyword used to specify <i>YNAME</i> for 3-D Cartesian geometry case.
<i>YNAME</i>	<b>character*2</b> array of vertical channel names. A vertical channel name is identified by the channel row using alphabetical letters 'A' (from the top), 'B', 'C', and so on. The total number of Y-names must equal to the total number of subdivisions along the Y-direction in the fuel-map geometry. All non-fuel regions are to be assigned a single character '-'. This option is not available for 3-D Hexagonal geometry. When assembly are defined and split, several names can be the same.
<i>ny</i>	integer total number of subdivisions along the Y-direction in the fuel-map geometry. Not used for 3-D hexagonal geometry.
<i>NHNAME</i>	keyword used to specify <i>XHAME</i> for 3-D hexagonal geometry case.
<i>HNAME</i>	<p><b>character*8</b> array of horizontal channel names. A radial channel name can be identified by the following scheme: The core is divided into 6 60-degree sectors; the sectors are labeled "A", "B", "C", "D", "E", and "F"</p> <ul style="list-style-type: none"> <li>• Rings of channels are numbered starting at ring 0 for the central channel</li> <li>• Each channel is now identified as a string 'RRSAA', with RR the ring number, S the sector, and AA the assembly number in the ring.</li> </ul> <p>For example:</p> <p><b>Ring 0:</b> C00A01</p> <p><b>Ring 1:</b> C01A01, C01B01, C01C01, C01D01, C01E01, C01F01</p> <p><b>Ring 2:</b> C02A01, C02A02, C02B01, C02B02, C02C01, C02C02, C02D01, C02D02, C02E01, C02E02, C02F01, C02F02.</p> <p>All non-fuel regions are to be assigned a single character '-'. This option is not available for 3-D Cartesian geometry.</p>
<i>nh</i>	integer total number of subdivisions along the hexagonal plane in the fuel-map geometry. Not used for 3-D Cartesian geometry.
<i>NCOMB</i>	keyword used to specify the number of combustion zones.
<i>ncomb</i>	integer total number of combustion zones. This value must be greater than (or equal to) 1 and less than (or equal to) the total number of reactor channels.
<i>B-ZONE</i>	keyword used to specify <i>icz</i> .
<i>icz</i>	integer array of combustion-zone indices, specified for every channel. A reactor channel can belong to only one combustion zone, however a combustion zone can be specified for several channels.

ALL	keyword used to indicate that the total number of combustion zones equals to the number of reactor channels. In this particular case, each channel will have a unique combustion-zone number. Hence, an explicit specification of the combustion-zone indices can be omitted.
<i>nch</i>	$N_{ch}$ : number of fuel channels in the radial plane.
<i>nb</i>	$N_b$ : number of fuel bundles (or assembly slices) in the axial plane.
ASBLY	(after NCOMB) keyword to specify that one combustion zone per assembly is to be defined.
SIM	keyword used to specify a basic assembly layout for the SIM: PWR refuelling module (see Section 3.14).
<i>lx</i>	number of assemblies along the $X$ axis. Typical values are 15 or 17.
<i>ly</i>	number of assemblies along the $Y$ axis.
<i>naval</i>	<b>character*3</b> identification name corresponding to the basic naval-coordinate position of an assembly. <i>naval</i> ( <i>i</i> ) is the concatenation of a letter (generally chosen between A and T) and of an integer (generally chosen between 01 and 17). An assembly may occupies four positions in the fuel map in order to be represented by four radial burnups. In this case, the same naval-coordinate value will appear at four different ( <i>i</i> ) indices.
FOLLOW	keyword used to set the particularized isotopes that will be saved in each fuel cycle information directory.
<i>nis</i>	number of particularized isotopes that will be saved in each fuel cycle information directory.
HISOT	<b>character*8</b> array of particularized isotope names.

### 3.1.2 Input of global and local parameters

The information with respect to the fuel burnup is required for the fuel-map MACROLIB construction, using either the CRE:, NCR: or AFM: module. The fuel-region properties related to other local or global parameters can be interpolated only using the NCR: module.

Table 4: Structure (**descresini2**)

```
[ EDIT iprint ]
[ BTYPE { TIMAV-BURN | INST-BURN } ]
[ TIMAV-BVAL ( bvalue(i) , i = 1, ncomb ) ]
[ INST-BVAL { SAME bvalue | CHAN ( bvalue(i) , i = 1, nch ) | BUND ( bvalue(i) , i = 1, nch·nb ) |
SMOOTH } | ASBLY ( bvalue(i) , i = 1, na ) | OLDMAP ]
[ BUNDLE-POW { SAME pwvalue | CHAN ( pwvalue(i) , i = 1, nch ) | BUND ( pwvalue(i) , i = 1, nch·nb ) } ]
[ REACTOR-POW pwtot AXIAL-PFORM ( fvalue(i) , i = 1, nb ) ]
[ REF-SHIFT { ishift | COMB ( ishift(i) , i = 1, ncomb ) } ]
[[ ADD-PARAM PNAME PNAME PARKEY PARKEY { GLOBAL | LOCAL } ]]
[[ SET-PARAM PNAME { pvalue | OLDMAP | { [ TIMES PNAMEREF ] SAME pvalue |
```

continued on next page

Structure (**descresini2**)

continued from last page

```

    CHAN (pvalue(i) , i = 1, nch ) | BUND (pvalue(i) , i = 1, nch.nb ) |
    LEVEL [ { H+ | H- } ] { SAME lvalue | CHAN (lvalue(i) , i = 1, nch ) } } ] ]
[[ FUEL { WEIGHT | ENRICH | POISON } (fvalue(i) , i = 1, nfuel ) ]]
[ CELL (ialch(i) , i = 1, nch ) ]
;

```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); = 2 to print the channels refuelling schemes (if they are new or modified); = 3 initial burnup limits per each channel are also printed (if the axial power-shape has been reinitialized).
BTYPE	keyword used to specify the type of interpolation with respect to burnup data. This information will be used during the execution of CRE:, NCR: or AFM: module.
TIMAV-BURN	keyword used to indicate the burnups interpolation according to the time-average model. This option is not available in 3-D Hexagonal geometry.
INST-BURN	keyword used to indicate the burnups interpolation according to the instantaneous model.
TIMAV-BVAL	keyword used to indicate the input of average exit burnup values per each combustion zone. Note that the axial power-shape and the first burnup limits will be reinitialized each time the average exit burnups are modified by the user. These data are required for the time-average calculation (see Section 3.12). This option is not available with 3-D Hexagonal geometry.
INST-BVAL	keyword used to specify the instantaneous burnup values for each fuel bundle.
SMOOTH	keyword used to level fuel mixtures burnup. If the burnup is supposed to be the same at each occurrence of every fuel mixture (for symmetry reasons), SMOOTH will make sure they share the exact same value (the first one in the burnup map). Purpose is only to correct calculation noise in historic calculation.
ASBLY	keyword to specify that one burnup value per assembly is to be defined.
OLDMAP	keyword to specify that the burnup value is recovered from <i>FLMAP2</i> . The recovered burnup distribution is either from a previous calculation: <ul style="list-style-type: none"> <li>• with the same geometry but different initialization values. Example: homogeneous calculation followed by a pin power reconstruction where assemblies were not defined in the first place.</li> <li>• with a different geometry. In this case, the assembly geometry of the new <i>FLMAP</i> and the geometry of the <i>FLMAP2</i> must match. Example: homogeneous calculation followed by a heterogeneous calculation or pin power reconstruction</li> </ul>
BUNDLE-POW	keyword used to specify the power values for each fuel bundle. This option is not available in 3-D Hexagonal geometry.
<i>bvalue</i>	real array containing the burnups values, given in <i>MW·day per tonne</i> /MW of initial heavy elements. The fuel burnup is considered as a global parameter.

<i>pwvalue</i>	real array containing the powers values, given in kW.																
REACTOR-POW	keyword used to specify the full reactor power. This information is not required if BUNDLE-POW data is provided.																
<i>pwtot</i>	power value, given in MW.																
AXIAL-PFORM	keyword used to specify the axial form factors. They are assumed identical in all channels.																
<i>fvalue</i>	axial form factor value.																
REF-SHIFT	keyword used to specify <i>ishift</i> . Note that the axial power-shape and the first burnup limits will be reinitialized each time the channel refuelling schemes are modified by the user. This option is not available in 3-D Hexagonal geometry.																
COMB	keyword used to indicate the input of bundle-shift numbers per combustion zone.																
<i>ishift</i>	integer array (or single value) of the bundle-shift numbers. A single <i>ishift</i> value means that the same bundle-shift will be applied for all combustion zones. Note that the bundle-shift value must be positive, it corresponds to the number of displaced fuel bundles during each channel refuelling.																
ADD-PARAM	keyword used to indicate the input of information for a new global or local parameter. For more information about the parameter data organization on FMAP data structure see Section 9.1.5.																
PNAME	keyword used to specify <i>PNAME</i> .																
<i>PNAME</i>	<b>character*12</b> identification name of a given parameter. This name is user-defined so that it is arbitrary, however it must be unique so that it can be used for the search of parameter information and interpolation purpose. Moreover, it is recommended to use the following pre-defined values: <table border="1" data-bbox="441 1180 980 1440"> <tbody> <tr> <td>C-BORE</td><td>Boron concentration</td></tr> <tr> <td>T-FUEL</td><td>Averaged fuel temperature</td></tr> <tr> <td>T-SURF</td><td>Surfacic fuel temperature</td></tr> <tr> <td>T-COOL</td><td>Averaged coolant temperature</td></tr> <tr> <td>D-COOL</td><td>Averaged coolant density</td></tr> <tr> <td colspan="2">CANDU-only parameters:</td></tr> <tr> <td>T-MODE</td><td>Averaged moderator temperature</td></tr> <tr> <td>D-MODE</td><td>Averaged moderator density</td></tr> </tbody> </table>	C-BORE	Boron concentration	T-FUEL	Averaged fuel temperature	T-SURF	Surfacic fuel temperature	T-COOL	Averaged coolant temperature	D-COOL	Averaged coolant density	CANDU-only parameters:		T-MODE	Averaged moderator temperature	D-MODE	Averaged moderator density
C-BORE	Boron concentration																
T-FUEL	Averaged fuel temperature																
T-SURF	Surfacic fuel temperature																
T-COOL	Averaged coolant temperature																
D-COOL	Averaged coolant density																
CANDU-only parameters:																	
T-MODE	Averaged moderator temperature																
D-MODE	Averaged moderator density																
PARKEY	keyword used to specify <i>PARKEY</i> .																
<i>PARKEY</i>	<b>character*12</b> corresponding name of a given parameter as it is recorded in the particular multi-parameter compo file. The <i>PARKEY</i> name of a parameter may not be same as its <i>PNAME</i> and can also differ from one multi-compo file to another.																
GLOBAL	keyword used to indicate that a given parameter is global, which will have a single and constant parameter's value.																
LOCAL	keyword used to indicate that a given parameter is local. In this case, the total number of recorded parameter's values will be set to $N_{ch} \times N_b$ .																
SET-PARAM	keyword used to indicate the input (or modification) of the actual values for a parameter specified using its <i>PNAME</i> .																

<b>SAME</b>	keyword used to indicate that a core-average value of a local parameter will be provided. If the keyword <b>SAME</b> is specified, then this average value will be set for all fuel bundles for every reactor channel.
<b>CHAN</b>	keyword used to indicate that the values of a local parameter will be provided per each reactor channel. If the keyword <b>CHAN</b> is specified, then the channel-averaged parameter's value will be set for all fuel bundles containing in the same reactor channel.
<b>BUND</b>	keyword used to indicate that the values of a local parameter will be specified per each fuel bundle for every channel.
<b>TIMES</b>	keyword used to indicate that the values of the local parameter <i>PNAME</i> is a translation of the local parameter <i>PNAMEREF</i> via a multiplication of the constant indicated by <b>SAME</b> .
<i>PNAMEREF</i>	<b>character*12</b> identification name of a given parameter.
<i>pvalue</i>	real array (or a single value) containing the actual parameter's values. Note that these values will not be checked for consistency by the module. It is the user responsibility to provide the valid parameter's values which should be consistent with those recorded in the multicompo database.
<b>OLDMAP</b>	keyword to specify that the <i>pvalue</i> value(s) is (are) recovered from <i>FLMAP2</i> .
<b>LEVEL</b>	keyword to specify that parameter <i>PNAME</i> (declared as <b>LOCAL</b> ) is a control rod insertion parameter computed as a function of variable <i>lvalue</i> set between 0.0 (rod out of the core) and 1.0 (rod fully inserted). The variable <i>lvalue</i> can be a core-averaged value (with keyword <b>SAME</b> ) or a set of channel-defined values (with keyword <b>CHAN</b> ).
<b>H+</b>	keyword used to specify that a rod will be inserted into reactor core from the highest position (e.g. from the top for vertically moving rod-device). This is the default option.
<b>H-</b>	keyword used to specify that a rod will be inserted into reactor core from the lowest position (e.g. from the bottom for vertically moving rod-device).
<b>FUEL</b>	keyword used to indicate the input of data which will be specified for each fuel type.
<b>WEIGHT</b>	keyword used to indicate the input of initial heavy metal content in a bundle, given in <i>kg</i> .
<b>ENRICH</b>	keyword used to indicate the input of fuel enrichment values, given in <i>wt%</i> .
<b>POISON</b>	keyword used to indicate the input of poison load in a fuel.
<i>fvalue</i>	real value of the fuel-type parameter, specified for each fuel type in the same order as the fuel mixture indices have been recorded in the <b>MATEX</b> object (see Section 3.2.1).
<i>nfuel</i>	integer total number of the fuel types, as been defined in the <b>USPLIT</b> module.
<b>CELL</b>	keyword used to specify that a patterned age distribution will be input and used to compute instantaneous bundle burnup.
<i>ialch</i>	real array containing the refueling sequence numbers. This channel is refueled the <i>ialch(i)</i> th one. The channels are ordering from the top left to the bottom right of the core. The expression of the resulting bundle burnups are given in Ref. 20.



### 3.2 The USPLIT: module

The USPLIT: module is used to create a MATEX object that will provide a link between the reactor geometry and material index. The 3-D Cartesian or 3-D Hexagonal reactor geometry, which is previously produced in the GEO: module, is analyzed and the material mixture indices are recomputed in order to provide a unique mixture number for each material sub-volume. Such renumbering permits a complex reactor core modeling. A MATEX object is also used to store some additional information that will be required and updated by other DONJON modules (see Section 9.2).

The USPLIT: module specification is:

Table 5: Structure USPLIT:

*GEOM MATEX* := USPLIT: { *GEOM* | *GEOMOLD* } :: (desclink)

where

<i>GEOM</i>	<b>character*12</b> name of a GEOMETRY object. This object is defined in creation (appears only on LHS) or modification (appears on both LHS and RHS) mode. An existing geometry previously created in the GEO: module is modified. Only 3-D Cartesian or 3-D Hexagonal reactor geometries are allowed.
<i>MATEX</i>	<b>character*12</b> name of a MATEX object to be created by the module.
<i>GEOMOLD</i>	<b>character*12</b> name of a GEOMETRY object previously created in the GEO: module. This object must be specified in read-only mode (appears only on RHS). It is copied into <i>GEOM</i> at the beginning of USPLIT: module. Only 3-D Cartesian or 3-D Hexagonal reactor geometries are allowed.
(desclink)	structure describing the input data to the USPLIT: module.

#### 3.2.1 Input data to the USPLIT: module

Note that the fuel-type and reflector-type mixture indices are need to be specified explicitly and the input order must be respected.

Table 6: Structure (desclink)

```
[ EDIT iprint ]
NGRP ngrp
MAXR maxreg
NMIX nmixt
[ NREFL nrefl RMIX ( mixr(i) , i = 1, nrefl ) ]
[ NFUEL { nfuel FMIX ( mixf(i) , i = 1, nfuel ) | ASBLY } ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); larger values produce increasing amounts of output.
NGRP	keyword used to specify <i>ngrp</i> .
<i>ngrp</i>	integer total number of energy groups. This value must be greater than 0.
MAXR	keyword used to specify <i>maxreg</i> .
<i>maxreg</i>	integer maximum number of mesh-splitted regions in the reactor geometry. In 3-D Hexagonal geometry, it corresponds to the total number of prismatic blocks $l_h * l_z$ .
NMIX	keyword used to extend number of material mixtures in case new fuels are going to be inserted in the fuel map in upcoming fuel cycles. By default, <i>nmixt</i> is set to the maximum mixture index in RHS geometry <i>GEOM</i> or <i>GEOMOLD</i> .
<i>nmixt</i>	the maximum fuel mixture index in the complete life of the reactor. This number must be greater than the maximum mixture index in RHS geometry <i>GEOM</i> or <i>GEOMOLD</i> .
NREFL	keyword used to specify <i>nrefl</i> .
<i>nrefl</i>	integer total number of reflector types. A reactor should have at least one reflector material.
RMIX	keyword used to specify <i>mixr</i> .
<i>mixr</i>	integer array of the reflector-type mixture indices. Each reflector type is assigned a distinct mixture number as previously defined in the GEOMETRY object.
NFUEL	keyword used to specify <i>nfuel</i> .
<i>nfuel</i>	integer total number of fuel types. A reactor should have at least one fuel type.
FMIX	keyword used to specify <i>mixf</i> .
<i>mixf</i>	integer array of the fuel-type mixture indices. Each fuel type is assigned a distinct mixture number as previously defined in the GEOMETRY object.
ASBLY	keyword used to compute automatically <i>nfuel</i> and <i>mixf</i> (i). This option is only available when the geometry has been split by the NAP: module.

### 3.3 The MACINI: module

The `MACINI:` module is used to construct an extended MACROLIB, in which the properties are stored per each material region over the whole mesh-splitted reactor geometry. This MACROLIB is obtained by combining the material properties which are contained in the two distinct MACROLIB objects:

- The first MACROLIB contains the material properties which are evolution-independent, such as reflector and device properties. It is created using either `MAC:`, `CRE:`, `NCR:` or `AFM:` module.
- The second is a fuel-map MACROLIB created using either `CRE:`, `NCR:` or `AFM:` module. It must contain the interpolated fuel properties per each fuel bundle.

The resulting MACROLIB will contain the properties that are stored for each reactor material and per each mesh-splitted volume. When the devices are not present in the reactor core, then the resulting MACROLIB can be considered as a complete reactor MACROLIB and it can be directly used for the numerical solving. However, when the devices are inserted into the reactor core, the resulting MACROLIB is not yet complete; it must be subsequently updated with respect to the device properties, using the `NEWMAC:` module (see Section 3.10).

The `MACINI:` module specification is:

Table 7: Structure `MACINI:`

```
MACRO2 MATEX := MACINI: MATEX MACRO [ MACFL ] :: [ EDIT iprint ] [ FUEL ] ;
```

where

<code>MACRO2</code>	<code>character*12</code> name of the extended MACROLIB to be created by the module.
<code>MATEX</code>	<code>character*12</code> name of the MATEX object containing an extended material index over the reactor geometry. <code>MATEX</code> must be specified in the modification mode; it will store the recovered h-factors per each fuel region.
<code>MACRO</code>	<code>character*12</code> name of a MACROLIB, created using either <code>MAC:</code> , <code>CRE:</code> , <code>NCR:</code> or <code>AFM:</code> module, for the evolution-independent material properties (see structure <b>(descrcr1)</b> or refer to the user guide <sup>[5]</sup> ).
<code>MACFL</code>	<code>character*12</code> name of a fuel-map MACROLIB, created using either <code>CRE:</code> , <code>NCR:</code> or <code>AFM:</code> module, for the interpolated fuel properties (see structure <b>(descrcr2)</b> or refer to the user guide <sup>[5]</sup> ).
<code>EDIT</code>	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing; larger values produce increasing amounts of output. The default value is <i>iprint</i> = 1.
<code>FUEL</code>	keyword used to indicate that <code>MACRO</code> is a fuel-map MACROLIB in case where only two RHS objects are defined. By default, <code>MACRO</code> contains evolution-independent cross sections.

### 3.4 The DEVINI: module

The DEVINI: module is used for the modeling of reactivity mechanisms, based on the devices specifications which are read from the input data file. The module will create a new DEVICE object that will store the devices specifications and parameters (see Section 9.3). Note that only the rod-type (i.e. solid) devices are considered using the DEVINI: module; the liquid zone controllers can be added subsequently, using the LZC: module (see Section 3.6). A rod-type device is a reactivity controller rod (or plate), such as: a zone control rod (ZCR), a shutoff rod (SOR), etc. Several devices parameters can be modified using the DSET: module (see Section 3.7).

A device specification includes several controller rod parameters, such as: a rod position, rod insertion level, direction of movement, etc. The devices positions can not overlap in the reactor core; they are referred using 3-D-Cartesian coordinates. The insertion level of rods can be set according to their nominal positions or they can be displaced *in* or *out* of core. The rods can also be divided into the several user-defined groups so that they can be manipulated, displaced or moved simultaneously.

The DEVINI: module specification is:

Table 8: Structure DEVINI:

```
DEVICE MATEX := DEVINI: MATEX :: (descdev)
```

where

<i>DEVICE</i>	<b>character*12</b> name of the DEVICE object that will be created by the module; it will contain the devices information.
<i>MATEX</i>	<b>character*12</b> name of the MATEX object that will be updated by the module. The rod-devices material mixtures are appended to the previous material index and the rod-devices indices are also modified, accordingly.
( <b>descdev</b> )	structure describing the input data to the DEVINI: module.

#### 3.4.1 Input data to the DEVINI: module

The DEVINI: module allows the definition of rod-type devices made of one or many (up to 10) parts, as depicted in Fig. 1.

Table 9: Structure (**descdev**)

```
[ EDIT iprint ]
NUM-ROD nrod [ { FADE | MOVE } ]
( (dev-rod), i = 1, nrod )
[ CREATE ROD-GR ngrp ( (rod-group), i = 1, ngrp ) ]
;
```




Figure 1: Presentation of fully- and partially-inserted 3-part control rods.

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); larger values produce increasing amounts of output.
NUM-ROD	keyword used to specify <i>nrod</i> .
<i>nrod</i>	integer total number of the reactor rod-type devices. This number must be greater than 0.
FADE	fading rod keyword. A fraction of the fully inserted rod vanishes (default option).
MOVE	moving rod keyword. The complete rod is moving (DONJON3-type movement).
CREATE	keyword used to create the rod-groups of devices. The creation of groups is optional.
ROD-GR	keyword used to set <i>ngrp</i> .
<i>ngrp</i>	integer total number of the rod groups to be created. This number must be greater than 0.
(dev-rod)	structure describing the input data for each individual rod.
(rod-group)	structure describing the input data for each group of rods.

### 3.4.2 Description of dev-rod input structure

A rod position is referred by its 3-D Cartesian coordinates only. Note that the devices positions can not overlap. The input order of data must be respected.

Table 10: Structure (**dev-rod**)

```

ROD id
  ROD-NAME NAME
  AXIS { X | Y | Z }
  FROM { H+ | H- }
  [ LEVEL value ]
  [ SPEED speed ]
  [ TIME time ]
  [[ MAXPOS (pos(i), i = 1, 6) DMIX mix1 mix2 ]]
ENDROD

```

where

ROD	keyword used to specify the rod <i>id</i> number.
<i>id</i>	integer identification number of the current rod. Each rod-type device must be assigned a unique <i>id</i> number, given in an ascending order ranging from 1 to <i>nrod</i> .
ROD-NAME	keyword used to specify the rod <i>NAME</i> .
<i>NAME</i>	<b>character*12</b> name of the current rod. In general, this name is composed by the rod specific type (e.g. SOR, ZCR, etc.) followed by its sequential number (e.g. 01, 02, etc.).
AXIS	keyword used to specify the rod movement axis. A rod can be displaced along only one of the axis.
X	keyword used to specify that a rod is displaced along X axis.
Y	keyword used to specify that a rod is displaced along Y axis.
Z	keyword used to specify that a rod is displaced along Z axis.
FROM	keyword used to specify the insertion side of geometry. The rod-devices can be inserted into the reactor core from only one side of geometry. For example, some vertically moving devices can be inserted only from the top, whereas other only from the bottom.
H+	keyword used to specify that a rod will be inserted into reactor core from the highest position (e.g. from the top for vertically moving rod-device).
H-	keyword used to specify that a rod will be inserted into reactor core from the lowest position (e.g. from the bottom for vertically moving rod-device).
LEVEL	keyword used to specify the actual rod insertion level <i>value</i> . By default, the rod insertion level is left undefined.
<i>value</i>	real positive value of the rod insertion level. This value is used to compute the actual rod position in the reactor core. The rod insertion level is minimal ( <i>value</i> = 0.0) when the rod is completely withdrawn, and it is maximal ( <i>value</i> = 1.0) when the rod is fully inserted. For the partially inserted rod the insertion level must be: $0.0 < \textit{value} < 1.0$
SPEED	keyword used to specify <i>speed</i> . By default, the speed is left undefined.
<i>speed</i>	real positive value of the rod movement speed, given in cm/s. This value is needed only for the reactor regulating purpose.

TIME	keyword used to specify <i>time</i> . By default, the insertion time is left undefined.
<i>time</i>	real value of time for the rod insertion (or extraction), given in sec. This value is needed only for the reactor regulating purpose.
MAXPOS	keyword used to specify the full-inserted coordinates of a rod part. The sequence of MAXPOS and DMIX data structures is repeated for each part making the rod.
<i>pos</i>	real array containing 3-D Cartesian coordinates of the full-inserted rod. This is the limiting rod position in the reactor core, which may or may not be the same as the actual rod position. These coordinates must be given in the order: X−, X+, Y−, Y+, Z−, and Z+.
DMIX	keyword used to specify <i>mix1</i> and <i>mix2</i> .
<i>mix1</i>	first of two integer rod mixture indices. Index <i>mix1</i> corresponds to the perturbed cross sections.
<i>mix2</i>	second of two integer rod mixture indices. Index <i>mix2</i> corresponds to the reference cross sections. Indices <i>mix1</i> and <i>mix2</i> will be used to compute the incremental cross sections in the NEWMAC: module.
ENDROD	keyword used to end the rod description.

### 3.4.3 Description of rod-group input structure

The partition of devices into groups is very useful when the same action is to be applied to several rods, e.g. setting of new parameters (using the DSET: module) or rods moving (using the MOVDEV: module).

Table 11: Structure (**rod-group**)

GROUP-ID *igrp* { ROD-ID [[ *id* ]] | ALL }

where

GROUP-ID	keyword used to set <i>igrp</i> number.
<i>igrp</i>	integer identification number of a group to be created. Each rods group must be assigned a unique identification number, given in ascending order ranging from 1 to <i>ngrp</i> .
ROD-ID	keyword used to set the rod <i>id</i> numbers.
<i>id</i>	integer identification numbers of rods which belong to the same group <i>igrp</i> . A particular rod (or several rods) may belong to different groups, but it could not be repeated inside the same group. The total number of rods in any group must be between 1 and <i>nrod</i> .
ALL	keyword used to specify that all rods will belong to the same group <i>igrp</i> .

### 3.5 The DETINI: module

The DETINI: module is used to read and store detector information. A detector is represented by a 2-D or 3-D Cartesian/Hexagonal geometry.

The DETINI: module specification is:

Table 12: Structure DETINI:

```
DETECT := DETINI: [ DETECT ] :: (descdet)
```

where

<i>DETECT</i>	<b>character*12</b> name of the DETECT object that will be created by the module; it will contain the detector informations. If DETECT appear on RHS, it is updated, otherwise, it is created.
(descdev)	structure describing the input data to the DETINI: module.

#### 3.5.1 Input data to the DETINI: module

Note that the input order must be respected.

Table 13: Structure (descinidet)

```
[ EDIT iprt ] [ HEXZ ] NGRP ngrp
[[ TYPE NAMTYP
INFO ndetect nrep { SPECTRAL ( spec(i), i=1,ngrp ) | DEFAULT }
[ INVCONST ( tinvt(i), i=1,nrep-2 ) ] [ FRACTION ( fract(i), i=1,nrep-1 ) ]
( (descdet), i=1,ndetect ) ]]
;
```

where

EDIT	keyword used to set <i>iprt</i> .
<i>iprt</i>	index used to control the printing in module INIDET: . =1,2 for no print(default value); =3 for printing the contents of the output DETECT.
HEXZ	keyword to specify that only hexagonal detectors will be defined. If this keyword is absent, Cartesian detectors will be defined.
NGRP	keyword used to set <i>ngrp</i> .
<i>ngrp</i>	number of energy groups in the calculation. It must be equal to the number set in the MACD: module or by the COMPO files.



TYPE	keyword to specify the detector type.
NAMTYP	<p>character*12 name of the detector type. To correspond to the actual detector response model encoded, the type of detector must be in this list:</p> <ul style="list-style-type: none"> <li>• PLATN_REGUL</li> <li>• PLATN_SAU</li> <li>• VANAD_REGUL</li> <li>• CHION_SAU</li> <li>• CHION_REGUL</li> </ul> <p>For other type names, only a fixed normalisation can be performed.</p>
INFO	keyword to specify the information associated with the detector type.
<i>ndetect</i>	number of detectors of the specified type.
<i>nrep</i>	number of detector response components for the specified type. It must be greater or equal to 2, corresponding to a response in fraction and the reference flux value.
SPECTRAL	keyword to specify the energy spectral of a detector type.
<i>spec</i>	array containing the energy spectral of a detector type.
DEFAULT	keyword to specify the energy spectral will be initialized as 1.0 for the highest energy group and 0.0 for other groups.
INVCONST	keyword to specify the inverse time constants of the detector type model. This option is only valid for platinum, ( <i>NAMTYP</i> (1:5) = 'PLATN'), detector type.
<i>tin</i>	array containing the inverse time constants of the detector model.
FRACTION	keyword to specify the fractions corresponding to each delayed or prompt response of the detector type model. This option is only valid for platinum, ( <i>NAMTYP</i> (1:5) = 'PLATN'), detector type.
<i>frac</i>	array containing the detector type model fractions.
( <b>descdet</b> )	structure describing the format used to read detector information.

### 3.5.2 Description of the detector data

Note that the information input order must be respected.

Table 14: Structure (**descdet**)

```

NAME NAMDET
[ NHEX nhex HEX ( ihex(i), i=1,nhex ) ]
POSITION ( pos(i), i=1,6 )
RESP ( rep(i), i=1,nrep )
ENDN

```

where

NAME	keyword to specify the detector name.
NAMDET	<b>character*12</b> name of the detector. The different names in alphabetical order must fit their usual numbering in the core.(Ex: PLATN01, CHION01C)
NHEX	keyword to set the number of hexagons where the detector is placed.
nhex	number of hexagons.
HEX	keyword to set the hexagon numbers corresponding to the detector position.
ihex	array containing the hexagon numbers where the detector is present, as ordered in the geometry definition.
POSITION	keyword to specify the detector coordinates.
pos	array containing the positions of the specified detector. The positions must be read as X- X+ Y- Y+ Z- Z+ . For 2-D geometry, Z coordinates must be 0.0 and a value greater than 1.0. For hexagonal geometry, only Z coordinates are used in 3-D representation.
RESP	keyword to specify the detector initial responses.
rep	array containing the initial responses of the detector. To use the current detector models in DONJON, responses are given as <ul style="list-style-type: none"> <li>• For vanadium detectors: current response, last response.</li> <li>• For platinum detectors: current response, reference flux, last detector slow responses.</li> <li>• For ion chamber detectors: current logarithmic response, current log rate response, reference flux.</li> </ul>
ENDN	keyword to specify the end of the detector informations.

### 3.6 The LZC: module

The LZC: module is used for the modeling of liquid zone controllers, which are normally presented in the CANDU6-type reactor core. The liquid zone controllers specifications are read from the input data file. Note that this modeling can be made after the rod-type devices have been previously defined using the DEVINI: module (see Section 3.4). In this case, the previously created DEVICE object will be updated by the LZC: module; it will store the additional and separate information with respect to the liquid controllers (see Section 9.3).

The liquid zone controller specification includes several device parameters, such as: the whole device position, water filling level, direction of filling, etc. Note that a liquid zone controller is normally composed of two parts: one part is empty and the second part is full-filled. The water level can be adjusted according to the control reactivity requirements. The controllers positions are referred using 3-D-Cartesian coordinates. Several devices parameters can be modified using the DSET: module (see Section 3.7). The liquid controllers can also be divided into the several user-defined groups so that they can be manipulated simultaneously.

The LZC: module specification is:

Table 15: Structure LZC:

*DEVICE MATEX* := LZC: [ *DEVICE* ] *MATEX* :: (desclzc)

where

<i>DEVICE</i>	<b>character*12</b> name of the <i>DEVICE</i> object. Note, if the rod-type devices are not present in the reactor core, then <i>DEVICE</i> object must appear only on the LHS (i.e. in create mode), it will contain the information only with respect to the liquid zone controllers. However, if the rod-type devices are present in the reactor core, then they must be specified first (i.e. before the liquid controllers) using the DEVINI: module (see Section 3.4). In the last case, the <i>DEVICE</i> object must also appear on the RHS (i.e. in modification mode), it will contain the additional and separate information with respect to the liquid zone controllers.
<i>MATEX</i>	<b>character*12</b> name of the <i>MATEX</i> object that will be updated by the module. The lzc-devices material mixtures are appended to the previous material index and the lzc-devices indices are also modified, accordingly.
(desclzc)	structure describing the input data to the LZC: module.

#### 3.6.1 Input data to the LZC: module

Note that the input order must be respected.

Table 16: Structure (**desclzc**)

```
[ EDIT iprint ]
NUM-LZC nlzc
((dev-lzc), i = 1, nlzc)
[ CREATE LZC-GR ngrp (lzc-group), i = 1, ngrp ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); larger values produce increasing amounts of output.
NUM-LZC	keyword used to specify <i>nlzc</i> .
<i>nlzc</i>	integer total number of liquid zone controllers. This number must be greater than 0.
CREATE	keyword used to create the lzc-groups of devices. The creation of groups is optional.
LZC-GR	keyword used to set <i>ngrp</i> .
<i>ngrp</i>	integer total number of the lzc groups to be created. This number must be greater than 0.
<b>(dev-lzc)</b>	structure describing the input data for each individual liquid controller.
<b>(lzc-group)</b>	structure describing the input data for each group of liquid controllers.

### 3.6.2 Description of dev-lzc input structure

Note that the devices positions can not overlap in the reactor core. The input order of data must be respected.

Table 17: Structure (**dev-lzc**)

```
LZC id
MAXPOS ( pos(i) , i = 1, 6 )
MAX-FULL fmax
AXIS { X | Y | Z }
LEVEL value
[ RATE rate ]
[ TIME time ]
EMPTY-MIX ( mixE(n), n = 1, 2 )
FULL-MIX ( mixF(n), n = 1, 2 )
```

where

LZC	keyword used to specify the liquid controller <i>id</i> number.
<i>id</i>	integer identification number of the current liquid controller. Each controller must be assigned a unique <i>id</i> number, given in an ascending order ranging from 1 to <i>nlzc</i> .
MAXPOS	keyword used to specify the entire position of a liquid zone controller, including its empty and full parts.
<i>pos</i>	real array containing 3-D Cartesian coordinates of the liquid zone controller position in the reactor core. These coordinates must be given in the order: X- X+ Y- Y+ Z- Z+
MAX-FULL	keyword used to specify <i>fmax</i> .
<i>fmax</i>	real value of the limiting coordinate along the controller filling axis, which corresponds to the maximum full-filling level for the current liquid controller.
AXIS	keyword used to specify the controller filling axis. A liquid controller can be filled along only one (vertical) axis.
X	keyword used to specify that a liquid controller is filled along X axis.
Y	keyword used to specify that a liquid controller is filled along Y axis.
Z	keyword used to specify that a liquid controller is filled along Z axis.
LEVEL	keyword used to specify the actual filling level.
<i>value</i>	real positive value of the water level. This value is minimal ( <i>value</i> = 0.0) when the controller is empty, and it is maximal ( <i>value</i> = 1.0) when the controller is full-filled. For the partially filled controller the water level must be: $0.0 < \textit{value} < 1.0$
RATE	keyword used to specify <i>rate</i> .
<i>rate</i>	real positive value of the water filling rate, given in m <sup>3</sup> /s. This value is needed only for the reactor regulating purpose.
TIME	keyword used to specify <i>time</i> .
<i>time</i>	real value of the filling time, given in sec. This value is needed only for the reactor regulating purpose.
EMPTY-MIX	keyword used to specify <i>mixE</i> .
<i>mixE</i>	two integer mixture indices, specified for the empty-part of liquid controller. The first and the second mixture indices correspond to the perturbed and the reference cross sections, respectively. These indices will be used to compute the incremental cross sections in the NEWMAC: module.
FULL-MIX	keyword used to specify <i>mixF</i> .
<i>mixF</i>	two integer mixture indices, specified for the full-part of liquid controller. The first and the second mixture indices correspond to the perturbed and the reference cross sections, respectively. These indices will be used to compute the incremental cross sections in the NEWMAC: module.

### 3.6.3 Description of lzc-group input structure

The partition of lzc-devices into groups is similar to that of rod-devices.

Table 18: Structure (**lzc-group**)

GROUP-ID *igrp* { LZC-ID [[ *id* ]] | ALL }

where

GROUP-ID	keyword used to set <i>igrp</i> number.
<i>igrp</i>	integer identification number of a group to be created. Each controllers group must be assigned a unique identification number, given in ascending order ranging from 1 to <i>ngrp</i> .
LZC-ID	keyword used to set the controllers <i>id</i> numbers.
<i>id</i>	integer identification numbers of the liquid controllers which belong to the same group <i>igrp</i> . A particular controller (or several devices) may belong to different groups, but it could not be repeated inside the same group. The total number of liquid controllers in any group must be between 1 and <i>nlzc</i> .
ALL	keyword used to specify that all liquid controllers will belong to the same group <i>igrp</i> .

### 3.7 The DSET: module

The DSET: module is used to set or to update some of the devices parameters. The new parameters can be applied for the rod-type devices and/or for the liquid zone controllers, such as: the new insertion level for the rods or water filling level for the lzc-type devices, etc. It is possible to apply the new parameters to the individual user-selected devices as well as to the user-selected groups of devices. If the device (rod-insertion or lzc-filling) level is selected for the modification, then a new device position is recomputed accordingly. The DSET: module can be used to perform the device reactivity studies and also to predict the reactivity worth of the rod-devices.

The DSET: module specification is:

Table 19: Structure DSET:

*DEVICE* := DSET: *DEVICE* :: (descdset)

where

*DEVICE*            **character\*12** name of the *DEVICE* object that will be updated by the module.  
**(descdset)**        structure describing the input data to the DSET: module.

#### 3.7.1 Input data to the DSET: module

It is possible to set or to modify the parameters for several individual devices and/or for several groups of devices simultaneously.

Table 20: Structure (descdset)

```
EDIT iprint
[[ { ROD irod | ROD-GROUP irgrp | LZC ilzc | LZC-GROUP ilgrp }
  [ LEVEL value ] [ SPEED speed ] [ TIME time ]
END ]]
;
```

where

**EDIT**            keyword used to set *iprint*.  
*iprint*            integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing; larger values produce increasing amounts of output.  
**ROD**            keyword used to specify the rod *irod* number.  
*irod*            integer identification number of a rod to be modified. Each rod-type device has a

	unique <i>irod</i> number, ranging from 1 to <i>nrod</i> , as been defined in the DEVINI: module (see Section 3.4.2).
ROD-GROUP	keyword used to specify the rod-group <i>irgrp</i> number.
<i>irgrp</i>	integer identification number of a rod-group of devices that will be modified with the same parameters. Each rod-group has a unique <i>irgrp</i> number, ranging from 1 to <i>ngrp</i> , as been defined in the DEVINI: module (see Section 3.4.3).
LZC	keyword used to specify the liquid controller <i>ilzc</i> number.
<i>ilzc</i>	integer identification number of a liquid controller to be modified. Each lzc-type device has a unique <i>ilzc</i> number, ranging from 1 to <i>nlzc</i> , as been defined in the LZC: module (see Section 3.6.2).
LZC-GROUP	keyword used to specify the lzc-group <i>ilgrp</i> number.
<i>ilgrp</i>	integer identification number of a lzc-group of devices that will be modified with the same parameters. Each lzc-group has a unique <i>ilgrp</i> number, ranging from 1 to <i>ngrp</i> , as been defined in the LZC: module (see Section 3.6.3).
LEVEL	keyword used to specify a new level <i>value</i> .
<i>value</i>	real positive value of the new device level. For the rod-type devices this <i>value</i> must correspond to the new rod insertion level (see Section 3.4.3). For the lzc-type devices this <i>value</i> must correspond to the new water filling level (see Section 3.6.2). In any case, the new level value must be: $0.0 \leq \text{value} \leq 1.0$
SPEED	keyword used to specify a new value for <i>speed</i> .
<i>speed</i>	real positive value of the device speed. For the rod-type devices this value must correspond to the speed of rod movement (insertion or extraction), given in cm/s. For the lzc-type devices this value must correspond to the water filling rate, given in m <sup>3</sup> /s. The value of <i>speed</i> is required only for the reactor regulating purpose.
TIME	keyword used to specify a new value for <i>time</i> .
<i>time</i>	real value of time either for the rod insertion (or extraction) or for the liquid controller filling, given in sec. The value of <i>time</i> is required only for the reactor regulating purpose.
END	keyword used to indicate the end of input of the new parameters for the current device or group of devices.



### 3.8 The MCC: module

The MCC: module supplies tools to edit selectively one or several parameters of a fuel map object. These parameters are the ones defined when the fuel map is created, according to the calculation grid chosen to compute the macroscopic cross-sections libraries. Their selective edition is useful to study their impact on the core reactivity. For instance, this module enables to increase uniformly the fuel temperature in each cell, without modifying any other parameter such as the moderator temperature. It grants access to the Doppler coefficient, even at hot full power when the fuel temperature is different in every cell of the core.

This module enables the computation of (non-exhaustive list) : the Doppler coefficient, the power Doppler coefficient (Doppler during a power transient), the moderator temperature coefficient, the boron concentration coefficient, the reactivity with the fuel temperature set to the moderator one, etc.

Note that this module does not perform any reactivity calculation (only fuel map edition).

The MCC: module specifications are:

Table 21: Structure MCC:

$[FLMAP1] := MCC: FLMAP1 [FLMAP2] :: (descmcc1)$
--

where

<i>FLMAP1</i>	<b>character*12</b> name of the MAP object that will contain the updated fuel-lattice information. If <i>FLMAP1</i> appears on both LHS and RHS, it will be updated; if it only appears on RHS, it will only be read to display its contents.
<i>FLMAP2</i>	<b>character*12</b> name of the MAP object that contains information to be recovered to update <i>FLMAP1</i> . If <i>FLMAP2</i> exists, data to update <i>FLMAP1</i> will be taken in it. If not, data to update <i>FLMAP1</i> will be taken in <i>FLMAP1</i> .
<b>(descmcc1)</b>	structure describing the main input data to the MCC: module. Note that this input data is mandatory and must be specified either if <i>FLMAP1</i> is updated or only read.

#### 3.8.1 Main input data to the MCC: module

Table 22: Structure (descmcc1)

<pre>[ EDIT iprint ] [[ REC rec1 { UNI value1   ADD value2   { SAME   READ } rec2 } ]] [ TTD pcore ] ;</pre>
--

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); larger values produce increasing amounts of output. A value of 5 or higher will display the contents of <i>FLMAP1</i> object after edition, and a value of 6 or higher will display the contents before edition.
REC	keyword used to indicate that the name of the record to be updated will follow.
<i>rec1</i>	name of the record to be updated. The authorised values are defined in the table 9.1.5, page 172 (P-NAME variable). To be allowed, these values have to be previously defined in the fuel map before calling MCC.
UNI	keyword to specify that an uniform and absolute value is to be set. With this parameter, the <i>rec1</i> of every region will have the same value.
<i>value1</i>	absolute value (in Kelvin if it is a temperature) that will be set for <i>rec1</i> in every region.
ADD	keyword to specify that an uniform variation of <i>rec1</i> value is to be applied. With this parameter, the value of <i>rec1</i> will be altered in every region.
<i>value2</i>	value of <i>rec1</i> variation (in Kelvin if it is a temperature) that will be applied to every region.
SAME	keyword used to indicate that the values to edit <i>rec1</i> are to be recovered from <i>rec2</i> in the same fuel map, <i>FLMAP1</i> . For instance, it enables the user to set the fuel temperature with the moderator temperature.
READ	keyword used to indicate that the values to edit <i>rec1</i> are to be recovered from <i>rec2</i> in an other fuel map, <i>FLMAP2</i> . For instance, it enables the user to set the fuel temperature in <i>FLMAP1</i> with the fuel temperature of <i>FLMAP2</i> .
<i>rec2</i>	name of the record where the data to perform the update of <i>FLMAP1</i> is to be recovered. The authorised values are defined in the table 9.1.5, page 172 (P-NAME variable). To be allowed, these values have to be previously defined in the fuel map before calling MCC.
TTD	keyword used to indicate that the values of the 'D-COOL' record are to be updated. They will be computed from the moderator temperature stored in the 'T-COOL' folder and the core pressure, using the water tables. Note that the position of the TTD keyword matters, the density being calculated when TTD is called and not at the end of MCC: execution.
<i>pcore</i>	core pressure (in Pa).

### 3.9 The MOVDEV: module

The MOVDEV: module can be used for the transient simulations and reactor control studies, which are related to the time-dependent rod-devices displacement in the reactor core. The rods can be inserted into or extracted from the reactor core, at constant or at variable speed of movement. The rod positions are recomputed at every given time step of movement. The new rod positions can be computed in several ways, based on either: current time increment and movement speed; relative change in rod positions; or current rod insertion level. The MOVDEV: module allows the rod-devices to be displaced individually or simultaneously in groups.

The MOVDEV: module specification is:

Table 23: Structure MOVDEV:

*DEVICE* := MOVDEV: *DEVICE* :: (**descmove**)

where

*DEVICE*            **character\*12** name of the *DEVICE* object that will be modified by the module. The rods positions are updated according to the current time step of movement.

(**descmove**)        structure describing the input data to the MOVDEV: module.

#### 3.9.1 Input data to the MOVDEV: module

It is possible to move several individual rods and/or several groups of rods simultaneously. A user must be aware that a particular device will not be displaced more than once during the same time step. Note that the input order of data to the module must be respected.

Table 24: Structure (**descmove**)

```
[ EDIT iprint ]
DELT delt
[[ { ROD id | GROUP igrp }
{ INSR | EXTR }
{ LEVEL value | DELH delh | SPEED speed } ]]
```

where

**EDIT**            keyword used to set *iprint*.

*iprint*            integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); larger values produce increasing amounts of output.

DELT	keyword used to set <i>delt</i> .
<i>delt</i>	real value of the time increment for the current time step, given in sec.
ROD	keyword used to specify the rod <i>id</i> number.
<i>id</i>	integer identification number of a rod-type device to be displaced. Each rod has a unique <i>id</i> number, ranging from 1 to <i>nrod</i> , as been defined in the DEVINI: module (see Section 3.4.2).
GROUP	keyword used to specify a rod-group <i>igrp</i> number.
<i>igrp</i>	integer number of a group of rods that will be displaced simultaneously, with the same parameters of movement. Each group of rod-devices has a unique <i>igrp</i> number, ranging from 1 to <i>ngroup</i> , as been defined in the DEVINI: module (see Section 3.4.3).
INSR	keyword used to specify that a particular rod or a group of rods will be inserted into the reactor core during the period of time <i>delt</i> .
EXTR	keyword used to specify that a particular rod or a group of rods will be extracted from the reactor core during the period of time <i>delt</i> .
LEVEL	keyword used to specify the new level <i>value</i> .
<i>value</i>	real positive value of the rod insertion level at current time step. This value will be used to compute the new rod position in the reactor core. The insertion level is minimal ( <i>value</i> = 0.0) when the rod is completely withdrawn, and it is maximal ( <i>value</i> = 1.0) when the rod is fully inserted. For the partially inserted rod the insertion level must be: $0.0 < \textit{value} < 1.0$
DELH	keyword used to specify the value <i>delh</i> .
<i>delh</i>	real positive (absolute) value of the relative change in the rod position during the period of time <i>delt</i> . This is a time-dependent rod displacement along the rod movement axis, which must be given in cm.
SPEED	keyword used to set the current value of <i>speed</i> .
<i>speed</i>	real positive (absolute) value of the rod movement speed, given in cm/s. The rod speed can be kept constant or it can be modified at any time step <i>delt</i> . The devices could also have the different speeds of movement.

### 3.10 The NEWMAC: module

The NEWMAC: module is used to create a complete MACROLIB with respect to the devices parameters. The resulting MACROLIB will contain the exact properties for every material region, over the whole mesh-splitted reactor geometry. The material properties of each region are recomputed with respect to the actual position of each rod-type and if present lzc-type device. The computing algorithm is based on the determination of the volumic fraction occupied by each device; the incremental cross sections are then adjusted, accordingly. Note that the NEWMAC: module must be executed each time the devices positions are modified from the previously computed ones.

The NEWMAC: module specification is:

Table 25: Structure NEWMAC:

```
MACRO3 MATEX := NEWMAC: MATEX MACRO2 DEVICE :: [ EDIT iprint ] [ XFAC xfac ] ;
```

where

<i>MACRO3</i>	<b>character*12</b> name of the MACROLIB to be created by the module. It will contain the updated properties of each material region with respect to the current position of each device.
<i>MATEX</i>	<b>character*12</b> name of the MATEX object, containing the complete reactor material index including devices. <i>MATEX</i> must be specified in the modification mode; it will store the updated h-factors, computed per each fuel region with respect to the devices positions.
<i>MACRO2</i>	<b>character*12</b> name of the read-only extended MACROLIB, previously created by the MACINI: module.
<i>DEVICE</i>	<b>character*12</b> name of the read-only DEVICE object containing the devices information and parameters.
EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing; larger values produce increasing amounts of output. The default value is <i>iprint</i> = 1.
XFAC	keyword used to specify the number of cells on which incremental cross sections were computed in the supercell code.
<i>xfac</i>	corrective factor for delta sigmas (real number). For DRAGON code, <i>xfac</i> is generally set to 2.0 and, for MULTICELL code, set to 1.0 . The default value is 2.0.

### 3.11 The FLPOW: module

The FLPOW: module is used to compute and print the flux and power distributions over the reactor core. It also computes and prints some additional information, for example: the fluxes ratios with respect to the thermal energy-group fluxes; the mean power density; the power- and flux-form factors; etc. The computed fluxes and powers are printed either on files or on the screen. Note that the calculation using the FLPOW: module can be performed once the numerical solution has been previously established using the FLUD: or KINSOL: module.

According to the user-selected module specification, the average fluxes and powers can be computed per each fuel region over the fuel lattice *and/or* per each material region over the whole reactor geometry. In either case, all fluxes are normalized to the given total reactor power corresponding to the reactor nominal conditions at core equilibrium. If the reactor is perturbed from its initial state, then a new total reactor power can be recomputed and, accordingly, the flux and power distributions will be updated using the previously computed normalization factor.

The FLPOW: module will create a new POWER object that will store the information related to the reactor fluxes and powers (see Section 9.5). In addition, the POWER object will store several parameters that can be used as power and criticality constraints for the optimization and fuel management purposes, namely: the maximum channel and bundle powers; the channel and bundle power-form factors; the effective multiplication factor (recovered from the FLUX or KINET data structure).

The FLPOW: module specifications are:

Table 26: Structure FLPOW:

```
{
  POWER [ NRMFLUX ] [ FMAP ]
    := FLPOW: [ POWOLD ] FMAP { FLUX | KINET } TRACK MATEX [ MACRO ]
    :: (descflpow)
|
  POWER := FLPOW: [ POWOLD ] { FLUX | KINET } TRACK MACRO
    :: (descflpow)
}
```

where

<i>POWER</i>	<b>character*12</b> name of the POWER object that will be created by the module. It will contain the information related to the reactor fluxes and powers.
<i>NRMFLUX</i>	<b>character*12</b> name of the FLUX object, in creation mode. According to the chosen option, this object contains either the fluxes normalized to the given total reactor power or the fluxes per bundle. Is it useful if you want to compute the detectors readings with the DETECT: module.
<i>POWOLD</i>	<b>character*12</b> name of the read-only POWER object. It must contain the previously computed flux normalization factor, which corresponds to the reactor nominal or equilibrium conditions.
<i>FMAP</i>	<b>character*12</b> name of the FMAP object containing the fuel lattice specification. When <i>FMAP</i> is specified on the RHS, the fluxes and powers calculations are performed over

the fuel lattice as well as over the whole reactor geometry. If *FMAP* is specified on the LHS, its records 'BUND-PW' and 'FLUX-AV' will be set according to the information present in *POWER*.

<i>FLUX</i>	<b>character*12</b> name of the <i>FLUX</i> object, previously created by the <i>FLUD</i> : module. The numerical flux solution contained in <i>FLUX</i> is recovered and all flux are normalized to the given total reactor power.
<i>KINET</i>	<b>character*12</b> name of the <i>KINET</i> object, previously created by the <i>KINSOL</i> : module. The numerical flux solution contained in <i>KINET</i> is recovered.
<i>TRACK</i>	<b>character*12</b> name of the <i>TRACK</i> object, created by the <i>TRIVAT</i> : module. The information stored in <i>TRACK</i> is recovered and used for the average flux calculation.
<i>MATEX</i>	<b>character*12</b> name of the <i>MATEX</i> object, containing the reactor material index and the h-factors that will be recovered and used for the power calculation.
<i>MACRO</i>	<b>character*12</b> name of the <i>MACROLIB</i> object, containing the h-factors that will be recovered and used for the power calculation.
( <b>descflpow</b> )	structure describing the input data to the <i>FLPOW</i> : module .

### 3.11.1 Input data to the *FLPOW*: module

Note that the fuel-lattice power distribution can be printed only on the screen.

Table 27: Structure (**descflpow**)

```
[ EDIT iprint ]
[ { PTOT power | P-NEW } ]
[ FSTH fsth ] [ INIT ]
[ { NORM | BUND } ]
[ PRINT { MAP | DISTR [ FLUX ] [ RATIO ] [ POWER ] | ALL } ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum editing (default value); = 2 only channel powers in radial plane are printed; = 3 only bundle powers per each radial plane are printed; = 10 only bundle powers per each channel are printed. Any combination of the values 2, 3 and 10 is possible, for example 5 = 2+3. Note that any other value of <i>iprint</i> behaves as the first lower possible value, for example 7 gives the same output as 5. Moreover channel and bundle powers can be printed only if the <i>FMAP</i> object was provided in the calling specification.
PTOT	keyword used to specify the input of power. By default, a power is recovered from the <i>KINET</i> object.

<i>power</i>	real total reactor power, given in MW. This value must correspond to the reactor nominal conditions.
FSTH	keyword to specify the thermal to fission power ratio.
<i>fsth</i>	thermal to fission power ratio. By default this value is not used, and the total power is the one given after the PTOT keyword.
INIT	keyword used to save the actual power distribution in the BUND-PW-INI record of the fuel map object <i>FMAP</i> . It is used by the AFM: module to apply power feedback during a fast transient using the initial power distribution instead of the actual power.
P-NEW	keyword used to indicate that a new total reactor power is to be recomputed, based on the previously calculated flux normalization factor. The flux and power distributions over the reactor core are updated, accordingly. Note that this option is valid only if a read-only <i>POWOLD</i> object is provided.
PRINT	keyword used to indicate the printing on files. Note that all produced files will have the same extension “.res”.
MAP	keyword used to specify the printing of the average fluxes and flux ratios per fuel bundle. The normalized bundle fluxes are computed and printed for each reactor channel and per each energy group. The flux ratios are computed with respect to the thermal energy-group fluxes; they are printed on the same file.
DISTR	keyword used to indicate the printing of data computed over the whole reactor geometry.
FLUX	keyword used to specify the printing of flux distribution. The normalized fluxes are printed in separated files, one file per energy group; the number of produced files will then equal to the total number of energy groups. The flux values are printed for each mesh-splitted volume, in X, Y and Z planes; the virtual regions will have the fluxes values set to 0.
RATIO	keyword used to specify the printing of flux-ratio distribution. The flux ratios are computed with respect to the thermal energy-group fluxes per each mesh-splitted volume. They are printed in separated files; the number of produced files will equal to the total number of energy groups less one.
POWER	keyword used to specify the printing of power distribution. The power values are printed for each mesh-splitted volume, in X, Y, and Z planes; the non-fuel regions will have the power values set to 0.
ALL	keyword used to indicate the printing of all available information, i.e. without particular selection of data.
NORM	keyword to specify that the output flux object will contain a value per mesh-splitted element, normalized to the given power, as required by the DETECT: module. This is the default option.
BUND	keyword to specify that the output flux object will contain a value per bundle, normalized to the given power.



### 3.12 The TAVG: module

The **TAVG:** module is used to compute the burnup integration limits for each fuel bundle, the axial power-shape over the fuel lattice, the channel refuelling rates and the reactor core-average exit burnup. All calculations using the **TAVG:** module are performed according to the time-average model for the equilibrium-core conditions. The computing algorithm is based on bidirectional refuelling schemes of channels and average exit burnups specified over the fuel lattice, which should be recorded in the fuel map using the **RESINI:** module.

Note that the complete time-average calculation is a complex and iterative procedure, requiring of several full-core calculations (external iterations) to be performed. The main steps of the time-average calculation using **DONJON** are briefly described at the end of this section. The **TAVG:** module can also be used to compute the instantaneous fuel burnups according to the channel patterned-age-model, for the fuel management and optimization purposes.

The **TAVG:** module specification is:

Table 28: Structure **TAVG:**

$FMAP := TAVG: FMAP \text{ } POWER :: (\text{desctavg})$
--

where

<i>FMAP</i>	<b>character*12</b> name of a <b>FMAP</b> object, that will be updated by the <b>TAVG:</b> module. The <i>FMAP</i> object must contain the average exit burnups and refuelling schemes of channels.
<i>POWER</i>	<b>character*12</b> name of a <b>POWER</b> object containing the channel and bundle powers, previously computed by the <b>FLPOW:</b> module. The channel and bundle powers are used by the <b>TAVG:</b> module to compute the normalized axial power-shape over each channel.
<b>(desctavg)</b>	structure describing the input data to the <b>TAVG:</b> module.

#### 3.12.1 Input data to the TAVG: module

Note that the input order must be respected.

Table 29: Structure **(desctavg)**

<pre>[ EDIT <i>iprint</i> ] [ AX-SHAPE [ RELAX <i>relval</i> ] ] [ B-EXIT ] ;</pre>
---

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); = 2 only the burnup limits over each channel are printed; = 3 only the axial power-shape values over each channel are printed; = 4 only the channel refuelling rates are printed; for larger values of <i>iprint</i> everything will be printed.
AX-SHAPE	keyword used to indicate the calculation of the new axial power-shape and corresponding burnups limits over each reactor channel.
RELAX	keyword used to set the relaxation parameter <i>relval</i> .
<i>relval</i>	real value of the relaxation parameter, generally used to control the axial-shape convergence over the external time-average iterations. The optimal value, which corresponds to the minimal total number of such iterations, can be found by performing several runs at different <i>relval</i> . The default value of the relaxation parameter is set to 0.5
B-EXIT	keyword used to indicate the calculation of the core-average exit burnup and the channel refuelling rates.

### 3.12.2 Time-average calculation using DONJON

When the average exit burnups are provided for each channel, the exact burnup integration limits for each fuel bundle are unknown and need to be determined. The burnups integration limits are function of the normalized axial power-shape, which in turn depends on the flux solution over the fuel lattice. Moreover, the flux solution depends on the fuel-map macrolib (i.e. fuel properties), which in turn depends on the burnups integration limits for each fuel bundle. Consequently, the time-average calculation is an iterative procedure that consists to repeat all the steps required for the axial power-shape computation. This repetition is to be made until the relative error between the two (successives) axial power-shape calculations becomes as small as required for the precision.

The axial power-shape computing scheme is composed of several steps, each step is performed using an appropriate DONJON or TRIVAC module:

1. An initial axial power-shape is set as a flat distribution over the fuel lattice and the first burnup integration limits are calculated approximately, using the **RESINI:** module.
2. A time-average integration is performed and a new fuel-map **MACROLIB** is created, using either **NCR:**, **CRE:** or **AFM:** module.
3. An extended **MACROLIB** over the whole reactor geometry is created, using the **MACINI:** module.
4. If the devices are inserted into the reactor core, then the previously created **MACROLIB** is to be updated for the devices properties using the **NEWMAC:** module.
5. The complete **MACROLIB** is subsequently used by the **TRIVAA:** module in order to create a matrix **SYSTEM**.
6. The full-core numerical solution (i.e. fluxes and effective multiplication factor) is computed, using the **FLUD:** module.
7. The channel and bundle powers are next calculated, using the **FLPOW:** module.
8. Finally, the new axial power-shape and burnup limits are computed, using the **TAVG:** module.

Note that the steps from 2 to 8 are to be repeated until the required precision for the axial power-shape convergence is satisfied.

### 3.13 The TINST: module

The TINST: module is used to compute the instantaneous burnup for each fuel bundle. You can also use TINST: to refuel your reactor, according to a refueling-scheme. The scheme can be either specified with RESINI:, or directly in TINST:.

The TINST: module specification is:

Table 30: Structure TINST:

```
{ FMAP := TINST: FMAP [ POWER ] |
  MICLIB3 FMAP := TINST: FMAP MICLIB2 MICLIB }
:: (desctinst)
```

where

<i>FMAP</i>	<b>character*12</b> name of a FMAP object, that will be updated by the TINST: module. The <i>FMAP</i> object must contain the instantaneous burnups for each fuel bundle and the weight of each fuel mixture.
<i>POWER</i>	<b>character*12</b> name of a POWER object containing the channel and bundle powers, previously computed by the FLPOW: module. The channel and bundle powers are used by the TINST: module to compute the new burn-up of each bundle. If bundle-powers are previously specified with the module RESINI:, you can refuel your core without a <i>POWER</i> object.
<i>MICLIB3</i>	<b>character*12</b> name of a LIBRARY object, that will be created by the TINST: module. This MICROLIB contains the fuel properties after refueling when keyword MICRO is used in <b>(desctinst)</b> .
<i>MICLIB2</i>	<b>character*12</b> name of a LIBRARY object, that will be read by the TINST: module. This must be a fuel-map <i>LIBRARY</i> created either created by the NCR: or the EVO: module.
<i>MICLIB</i>	<b>character*12</b> name of a LIBRARY object, that will be read by the TINST: module. This MICROLIB contains the new fuel properties, that should be used for the refueling.
<b>(desctinst)</b>	structure describing the input data to the TINST: module.

3.13.1 Input data to the *TINST*: module

Note that the input order must be respected.

Table 31: Structure (**desctinst**)

```
[ EDIT iprint ]
[ BURN-STEP rburn | TIME rtime { DAY | HOUR | MINUTE | SECOND } ]
[[ REFUEL [ MICRO ] CHAN NAMCHA nsh ]]
[[ NEWFUEL [ MICRO ] CHAN NAMCHA nsh { SOME ( imix(i), i=1,ABS(nsh) ) | ALL imix } ]]
[[ SHUFF CHAN NMCHA1 TO { NMCHA2 | POOL } ]]
[ PICK >> burnup << ]
;
```

where

EDIT	keyword used to set <i>i</i> print.
<i>i</i> print	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); = 2 only the burnup limits over each channel are printed; = 3 only the axial power-shape values over each channel are printed; = 4 only the channel refueling rates are printed; for larger values of <i>i</i> print everything will be printed.
BURN-STEP	keyword used to indicate an increase of core average burn-up.
<i>r</i> burn	keyword used to indicate in MWd/t the average increase of burn-up in the core.
TIME	keyword used to indicate the time of combustion at the power specified in <i>POWER</i> structure.
<i>r</i> time	keyword used to set the time combustion value in DAY or HOUR or MINUTE or SECOND.
DAY	keyword used to specify that <i>r</i> time is a number of days.
HOUR	keyword used to specify that <i>r</i> time is a number of hours.
MINUTE	keyword used to specify that <i>r</i> time is a number of minutes.
SECOND	keyword used to specify that <i>r</i> time is a number of seconds.
REFUEL	key word to specify a channel refueling.
MICRO	keyword used to perform a microscopic refueling. In this case, three libraries have to be provided when <i>TINST</i> : is called.
CHAN	key word to specify the refueled channel information.
<i>NAMCHA</i>	channel name. In Cartesian geometry, <i>NAMCHA</i> is a character*4 variable defined by <i>NXNAME</i> and <i>NYNAME</i> and constructed as <code>WRITE(NAMCHA, ' (A1,A3) ' ) NYNAME(1:1),NXNAME(1:2).</code>

<i>nsh</i>	refueling scheme. The absolute value of <i>nsh</i> is the number of fuel bundles inserted in the channel <i>NAMCHA</i> . The sign of <i>nsh</i> define the refueling direction: positive direction is from the first to the <i>nk</i> -th bundle and negative is from the <i>nk</i> -th to the first bundle.
NEWFUEL	key word to specify that a channel will be refueled with a different type of fuel.
SOME	key word to specify that the <i>nsh</i> values of fuel types can be different.
<i>imix</i> (i)	index number of a fuel type with respect to the values defined in module NCR:, CRE: or AFM:.
ALL	key word to specify that the <i>nsh</i> values of fuel types will be identical to <i>imix</i> .
SHUFF	key word to specify that a specified channel will move into an other one or discharge into the pool.
CHAN	key word to specify the moved channel name.
<i>NMCHA1</i>	channel name as defined by <i>NXNAME</i> and <i>NYNAME</i> . It is constructed as <i>NAMCHA</i> .
TO	key word to specify the bundle destination.
<i>NMCHA2</i>	channel name as defined by <i>NXNAME</i> and <i>NYNAME</i> . It is constructed as <i>NAMCHA</i> .
POOL	key word to specify that the channel referenced by <i>NMCHA1</i> is discharged into the pool.
PICK	keyword used to recover the final burnup value (in MW-day/tonne) in a CLE-2000 variable.
<i>burnup</i>	<b>character*12</b> CLE-2000 variable name in which the extracted burnup value will be placed.

### 3.14 The SIM: module

The **SIM:** module can perform a sequence of operations related to fuel management in PWRs:

- simulate a refuelling and shuffling scheme and update the burnup distribution accordingly. The refuelling scheme is specified directly in **SIM:**.
- increase the burnup using the power available in the *POWER* object and compute the final instantaneous burnup of each assembly subdivision
- modify a local parameter such as the Boron concentration in the coolant.

The **SIM:** module specification is:

Table 32: Structure **SIM:**

```
FMAP [ MLIB ] := SIM: FMAP [ MLIB ] [ POWER ]
:: (descsim)
```

where

<i>FMAP</i>	<b>character*12</b> name of a <i>FMAP</i> object, that will be updated by the <b>SIM:</b> module. The <i>FMAP</i> object must contain the instantaneous burnups for each assembly subdivision, a basic naval-coordinate assembly layout and the weight of each assembly subdivision.
<i>MLIB</i>	<b>character*12</b> name of a MICROLIB (type <b>L_LIBRARY</b> ) containing particularized isotope data. If this object also appears on the RHS, it is open in modification mode and updated. Number densities of isotopes present in list <i>HISOT</i> (see Sect. 3.1.1) are recovered from a fuel cycle information directory of <i>FMAP</i> and saved in <i>MLIB</i> or recovered from <i>MLIB</i> and saved in a fuel cycle information directory of <i>FMAP</i> .
<i>POWER</i>	<b>character*12</b> name of a <i>POWER</i> object containing the channel and powers of the assembly subdivisions, previously computed by the <b>FLPOW:</b> module. The channel and powers of the assembly subdivisions are used by the <b>SIM:</b> module to compute the new burn-up of each assembly subdivision. If the powers of the assembly subdivisions are previously specified with the module <b>RESINI:</b> , you can burn your core without a <i>POWER</i> object.
(descsim)	structure describing the input data to the <b>SIM:</b> module.

#### 3.14.1 Input data to the **SIM:** module

Note that the input order must be respected.

Table 33: Structure (**descsim**)

```

[ EDIT iprint ]
[ CYCLE hcnew [ FROM hcold [ BURN { indcycle | burncycle } ] ]
  [ { MAP (hx(i), i=1, lx )
      (hy(j), (hcase(i,j), i=1, lx ), j=1,ly ) |
      QMAP (hx(i), i=lx/2+1, lx )
      (hy(j), (hcase(i,j), i=lx/2+1, lx ), j=ly/2+1,ly ) } ]
  [ SPEC [[ [asmb1] ]
    { SET AVGB avburn | SET FUEL ifuel | FROM hcold2 AT asmb2 [ BURN { indcycle | burncycle } ] }
    ] ]
  [ DIST-AX [[ [asmb1] ]
    { SET (axn(i), i=1,nb) | FROM hcold2 AT asmb2 [ BURN { indcycle | burncycle } ] }
    ] ]
  [ BURN-STEP rburn | TIME rtime { DAY | HOUR | MINUTE | SECOND } ]
  [ SET-FOLLOW [ BURN { indcycle | burncycle } ] ]
ENDCYCLE ]
[[ COMPARE hc1 [ BURN { indcycle1 | burncycle1 } ] hc2 [ BURN { indcycle2 | burncycle2 } ]
  { DIST-BURN >> epsburn << | DIST-POWR >> epspowr << } ] ]
[[ SET-PARAM PNAME pvalue ] ]
;

```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); for larger values of <i>iprint</i> everything will be printed.
CYCLE	keyword defining operations based on the actual fuel cycle.
<i>hcnew</i>	<b>character*12</b> identification name of the specific fuel cycle.
FROM	keyword defining the previous fuel cycle in case that some information needs to be transmitted to the actual fuel cycle.
<i>hcold</i>	<b>character*12</b> identification name of the previous fuel cycle.
BURN	keyword defining the burnup at which the assembly is recycled in the previous fuel cycle. By default, the last burnup step is used.
<i>indcycle</i>	integer index of the burnup step in the previous fuel cycle.
<i>burncycle</i>	real value of the burnup in the previous fuel cycle.
MAP	keyword defining the assembly layout in naval-coordinate positions in the actual fuel cycle. Here, <i>lx</i> and <i>ly</i> values are those defined in the fuel map (see Section 3.1.2).
QMAP	keyword defining the assembly layout in naval-coordinate positions using quarter-core symmetry conditions. Here, the lower-right quarter is defined. The full map is reconstructed through rotations around the center.
<i>hx</i>	ordered list of available <b>character*1</b> prefixes for the <i>X</i> -oriented naval-coordinate positions. Values are generally chosen between A and T.



<i>hy</i>	ordered list of available <b>character*2</b> suffixes for the <i>Y</i> -oriented naval-coordinate positions. Values are generally chosen between 01 and 17.
<i>hcase</i>	<b>character*4</b> or integer identification value for the (i,j) position. Accepted values are: <ul style="list-style-type: none"> <li>•  , - or - - for a position outside the core,</li> <li>• <b>NEW</b> for a new assembly (at zero burnup) selected according to the fuel map specified in Sect. 3.1,</li> <li>• <b>SPC</b> for an assembly described later in the dataset using a <b>SPEC</b> specification,</li> <li>• or a naval-coordinate position referring to the position of an assembly in cycle <i>hcold</i> that is recycled in the current cycle,</li> <li>• <i>imix</i> for an assembly (at zero burnup) made of fuel mixture <i>imix</i>. The fuel mixture should be selected among integer values defined in the fuel map <b>GEO:/MIX</b> data of Table 3.</li> </ul>
<b>SPEC</b>	keyword defining specifications related to all assemblies previously identified with the <b>SPC</b> keyword. If <b>QMAP</b> keyword has been used with <b>SPC</b> values, the 4 equivalent assemblies must be specified (i.e. not only the lower-right quarter assembly).
<i>asmb1</i>	<b>character*3</b> naval-coordinate position of an assembly identified with a <b>SPC</b> keyword. Up to 30 coordinates can be set aside if many assemblies have the same specification.
<b>SET</b>	keyword indicating that a user-defined value will be assigned to the assembly.
<b>AVGB</b>	keyword indicating that an averaged burnup will be assigned to the assembly.
<i>avburn</i>	real value of the average burnup in MWd/t.
<b>FUEL</b>	keyword indicating that a new fuel assembly will be used.
<i>fuel</i>	integer index of the fuel type corresponding to the new fuel assembly. Fuel type indices are those used in the <b>RESINI: PLANE</b> descriptions of Sect. 3.1.
<b>FROM</b>	keyword indicating that a value recovered from another assembly will be assigned to the current assembly.
<i>hcold2</i>	<b>character*12</b> identification name of a previous fuel cycle.
<b>AT</b>	keyword indicating that the naval-coordinate position of the other assembly will be given.
<i>asmb2</i>	<b>character*3</b> naval-coordinate position of the other assembly in cycle <i>hcold2</i> .
<b>DIST-AX</b>	keyword used to impose an axial burnup distribution to the assembly. The burnup distribution is recovered from an existing assembly or is set to user-supplied values.
<i>axn</i>	real values of the axial burnup distribution.
<b>BURN-STEP</b>	keyword used to indicate an increase of core average burn-up.
<i>rburn</i>	keyword used to indicate in MWd/t the average increase of burn-up in the core.
<b>TIME</b>	keyword used to indicate the time of combustion at the power specified in <b>POWER</b> structure.
<i>rtime</i>	keyword used to set the time combustion value in <b>DAY</b> or <b>HOURL</b> or <b>MINUTE</b> or <b>SECOND</b> .
<b>DAY</b>	keyword used to specify that <i>rtime</i> is a number of days.

HOURL	keyword used to specify that <i>rtime</i> is a number of hours.
MINUTE	keyword used to specify that <i>rtime</i> is a number of minutes.
SECOND	keyword used to specify that <i>rtime</i> is a number of seconds.
SET-FOLLOW	keyword used to reset the number densities of particularized isotopes in the <i>hcnew</i> fuel cycle information directory of the fuel map. The burnup step indicated by BURN structure is used to store the particularized isotopes. By default, the last burnup step is used. The MICROLIB <i>MLIB</i> must be defined in read-only mode in Table 32.
ENDCYCLE	keyword indicating the end of data specific to the actual fuel cycle.
COMPARE	keyword for obtaining a CLE-2000 variable that is a measure of the discrepancy between two cycles.
<i>hc1</i>	<b>character*12</b> identification name of the first fuel cycle to compare.
<i>hc2</i>	<b>character*12</b> identification name of the second fuel cycle to compare.
DIST-BURN	keyword used to recover the discrepancy on burnup distribution in a CLE-2000 variable.
<i>epsburn</i>	<b>character*12</b> CLE-2000 variable name in which the extracted burnup discrepancy (expressed in MW-day/tonne) will be placed.
DIST-POWR	keyword used to recover the relative error on power distribution in a CLE-2000 variable.
<i>epspowr</i>	<b>character*12</b> CLE-2000 variable name in which the extracted power relative error will be placed.
SET-PARAM	keyword used to indicate the input (or modification) of the actual values for a parameter specified using its <i>PNAME</i> .
PNAME	keyword used to specify <i>PNAME</i> .
<i>PNAME</i>	<b>character*12</b> name of a parameter.
<i>pvalue</i>	single real value containing the actual parameter's values. Note that this value will not be checked for consistency by the module. It is the user responsibility to provide the valid parameter's value which should be consistent with those recorded in the multicompo or Saphyb database.

### 3.15 The XENON: module

The **XENON:** module is used to correct the Xenon distribution coming from an interpolation calculation. This module computes the new densities according to the bundle flux, and the equation providing the balance concentration of Xenon-135 :

$$N_{Xe} = \frac{(Y_I + Y_X)\Sigma_f\phi}{\lambda_X + \sigma_X\phi} \quad (3.1)$$

where

- $Y_I$  is the fission yield of I135
- $Y_X$  is the fission yield of Xe135
- $\sigma_X$  is the capture cross section of Xe135
- $\lambda_X$  is the decay constant of Xe135
- $\Sigma_f$  is the total fission cross section
- $\phi$  is the bundle flux

The **XENON:** module specification is:

Table 34: Structure **XENON:**

```
MICROLIB := XENON: MICROLIB [ POWER ]
:: (descxenon)
```

where

<i>MICROLIB</i>	<b>character*12</b> name of a <b>LIBRARY</b> object, that will be updated by the <b>XENON:</b> module. The Xenon should be extracted in this library for the use of this module.
<i>POWER</i>	<b>character*12</b> name of a <b>POWER</b> object containing the bundle fluxes, previously computed by the <b>FLPOW:</b> module. The fluxes should be normalized to the reactor power.
<b>(descxenon)</b>	structure describing the input data to the <b>XENON:</b> module.

#### 3.15.1 Input data to the **XENON:** module

Note that the input order must be respected.

Table 35: Structure (**descxenon**)

```
[ EDIT iprint ]
[ INIT ]
;
```

where

**EDIT**                      keyword used to set *iprint*.

*iprint*                      integer index used to control the printing on screen.

**INIT**                      keyword used to indicate the initialization of the library for a recursive calculation using the **XENON:** module. The Xenon concentration is set to zero for all the bundles.

### 3.16 The DETECT: module

The DETECT: module is used to compute the mean flux at each detector site and the response of each detector.

The DETECT: module specifications are:

Table 36: Structure DETECT:

```
DETEC := DETECT: DETEC FLUX TRACK GEOM :: (descdetect) ;
```

where

<i>DETEC</i>	<b>character*12</b> name of the DETECT containing the detector positions and responses.
<i>FLUX</i>	<b>character*12</b> name of the FLUX containing the flux solution computed by the FLUD: or FLPOW: modules. To obtain a correct result, the best is to use a normalized flux, coming from the FLPOW: module. In this case, the fluxes are normalized to the reactor power.
<i>TRACK</i>	<b>character*12</b> name of the TRACK containing the TRIVAC tracking.
<i>GEOM</i>	<b>character*12</b> name of the GEOMETRY containing the mesh-splitting geometry created by the USPLIT: or GEO: modules.
<b>(descdetect)</b>	structure containing the data to module DETECT:.

#### 3.16.1 Input data to the DETECT: module

Note that the fuel-lattice power distribution can be printed only on the screen.

Table 37: Structure (descdetect)

```
[ EDIT iprt ] TIME dt REF kc
[ NORM vnorm ]
[ SIMEX { SPLINE | PARAB } ]
;
```

where

<b>EDIT</b>	key word used to set <i>iprt</i> .
<i>iprt</i>	index used to control the printing in module DETECT:. =0 for no print; =1 for minimum printing(default value); =4 for printing each detector name; =5 for finite element numbers and total number of finite elements for each detector.

TIME	key word used to set <i>dt</i> .
<i>dt</i>	time step between two calls to the DETECT: module.
REF	key word used to set <i>kc</i> .
<i>kc</i>	index used to control the type of calculation, =0 for reference calculation; =1 normal calculation. The reference responses are used to obtain detector current responses in full power fractions.
NORM	key word used to set <i>vnorm</i> .
<i>vnorm</i>	value used to normalized responses of all the detectors present in DETECT.
SIMEX	key word used to specify that a polynomial interpolation of detector fluxes according to HQSIMEX method. This interpolation will be applied only for vanadium detectors, under <i>NAMTYP</i> of value VANAD_REGUL.
SPLINE	key word to specify that the flux at detector site will be computed with a spline method.
PARAB	key word to specify that the flux at detector site will be computed with a parabolic method.

### 3.17 The CVR: module

The **CVR:** module is used to update the fuel-type index and the coolant densities throughout the reactor core as required for the voiding simulations. A particular core-voiding pattern is either selected from the several pre-defined patterns or directly defined by the user in an arbitrary fashion. In the last case, the user may specify the individual voided channels by indicating their identification names. The **CVR:** module will create a new (perturbed) **FMAP** object, in which the fuel-type mixtures indices are modified according to the specified core-voiding pattern. The information with respect to the relative coolant densities is required only for the subsequent interpolation of fuel properties using the **NCR:** module. These data will also be reordered by the **CVR:** module according to the specified voiding pattern and recorded as local parameter in the perturbed fuel-map object (see Section 3.1.2).

The **CVR:** module specification is:

Table 38: Structure **CVR:**

$FMAPV := CVR: FMAP :: (descrcvr)$
------------------------------------

where

<i>FMAP</i>	<b>character*12</b> name of a read-only <b>FMAP</b> object, created in the <b>RESINI:</b> module. This object must contain the non-perturbed fuel-cell properties.
<i>FMAPV</i>	<b>character*12</b> name of a new <b>FMAP</b> object, that will contain the modified fuel-type indices and reordered coolant densities according to the specified core-voiding pattern.
<b>(descrcvr)</b>	structure describing the input data to the <b>CVR:</b> module.

#### 3.17.1 Input data to the CVR: module

Note that the input order must be respected.

Table 39: Structure **(descrcvr)**

<pre> EDIT <i>iprint</i> ( MIX-FUEL <i>mixF</i>(i) MIX-VOID <i>mixV</i>(i) , i = 1, <i>nfuel</i> ) [ DENS-COOL <i>PNAME</i> SET <i>dcoolV</i> ] VOID-PATTERN { FULL   HALF   QUARTER   CHECKER   CHECKER-1/2   CHECKER-1/4   CHAN-VOID <i>nvoid</i> ( <i>YNAME</i>(i) <i>XNAME</i>(i) , i = 1, <i>nvoid</i> ) } ; </pre>
--

where

<b>EDIT</b>	keyword used to set <i>iprint</i> .
-------------	-------------------------------------

<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing; = 2 modified fuel indices and coolant densities are printed per bundle over each channel; = 3 modified fuel indices are printed per each radial plane; for larger values of <i>iprint</i> everything will be printed.
MIX-FUEL	keyword used to specify <i>mixF</i> .
<i>mixF</i>	integer fuel-type mixture number of the non-perturbed fuel cell. This number must be specified for each fuel type as been recorded in the MATEX object (see Section 3.2.1).
MIX-VOID	keyword used to specify <i>mixV</i> .
<i>mixV</i>	integer new mixture number assigned to the voided fuel cell. Note that this number must be specified for each fuel type and it must be different from any other reactor material mixtures.
DENS-COOL	keyword used to specify <i>PNAME</i> . This information is required only for the interpolation of fuel properties using the NCR: module.
<i>PNAME</i>	<b>character*12</b> user-defined identification name of local parameter associated with the relative coolant density. The recommended name is D-COOL. This parameter name and the unperturbed densities values should be previously recorded in the <i>FMAP</i> object (see Section 3.1.2). The same <i>PNAME</i> will be set for the coolant density in the perturbed <i>FMAPV</i> , but the actual values of coolant densities throughout the core will be reordered by the CVR: module according to the specified voiding pattern.
SET	keyword used to specify the value <i>dcoolV</i> .
<i>dcoolV</i>	real value of the relative coolant density (with respect to the nominal or unperturbed conditions) associated with the voided reactor channels. In general, this value equals to 0.0 for the complete voiding of a channel and to 1.0 for an unperturbed channel. Intermediate values of <i>dcoolV</i> will then correspond to the partially voided channels. It is supposed that all voided channels will have the same <i>dcoolV</i> value.
VOID-PATTERN	keyword used to specify the core voiding pattern, which will be used for a particular voiding simulation.
FULL	keyword used to specify the full-core voiding pattern. According to this pattern, the fuel mixtures will be modified for all reactor channels.
HALF	keyword used to specify the half-core voiding pattern. According to this pattern, the fuel mixtures will be modified only for the upper-half of reactor channels.
QUARTER	keyword used to specify the quarter-core voiding pattern. According to this pattern, the fuel mixtures will be modified only for the upper-left quarter of reactor channels.
CHECKER	keyword used to specify the checkerboard-full voiding pattern. According to this pattern, the fuel mixtures will be modified for all reactor channels in which the direction of coolant flow is positive.
CHECKER-1/2	keyword used to specify the checkerboard-half voiding pattern. According to this pattern, the fuel mixtures will be modified only for the upper-half of reactor channels in which the direction of coolant flow is positive.
CHECKER-1/4	keyword used to specify the checkerboard-quarter voiding pattern. According to this pattern, the fuel mixtures will be modified only for the upper-left quarter of reactor channels in which the direction of coolant flow is positive.



CHAN-VOID	keyword used to specify the user-defined voiding pattern. Each voided channel must be identified by its <i>YNAME</i> name followed by its <i>XNAME</i> .
<i>nvoid</i>	integer total number of the voided channels. This number must be greater than 0 and less than (or equal to) the total number of reactor channels.
<i>YNAME</i>	<b>character*2</b> vertical name of the voided channel. A vertical channel name is identified by the channel row using an alphabetical letter ('A', 'B', 'C', etc). The total number of the specified Y-names must equal to the total number of voided channels <i>nvoid</i> .
<i>XNAME</i>	<b>character*2</b> horizontal name of the voided channel. A horizontal channel name is identified by the channel column using a numerical character ('1', '2', '3', etc.). The total number of the specified X-names must equal to the total number of voided channels <i>nvoid</i> .

### 3.18 The HST: module

The HST: module has been designed to manage a full reactor execution in DONJON using explicit DRAGON calculations for each cell.<sup>[19]</sup> This module saves in an HISTORY data structure the information available in BURNUP data structures generated by DRAGON. It can also read MAP data structure generated by DONJON to prepare the HISTORY data structure for a new series of cell calculations in DRAGON. The HISTORY data structure can also be used to update the MAP data structure. Finally, the module HST: can be used to create an initial BURNUP data structure that can be used to evolve the cell another time step in DRAGON.

The HST: module can be used to create or update an HISTORY data structure. The possible options are:

Table 40: Updating an HISTORY structure using a MAP structure

```
HISTORY := HST: [ HISTORY ] MAP [ :: [ (hstdim) ] [ GET (hstpar) ] ]
```

Table 41: Updating an HISTORY structure using a BURNUP structure

```
HISTORY := HST: [ HISTORY ] [ BURNUP ] [ :: [ (hstdim) ]  
[ GET (hstpar) ] [ CELLID icha ibun [ idfuel ] [ GET (hstpar) ] ] ]
```

It can also be used to create a BURNUP data structure from the information available on an HISTORY data structure:

Table 42: Updating a BURNUP structure using an HISTORY structure

```
BURNUP := HST: HISTORY [ :: [ (hstdim) ]  
[ PUT (hstpar) ]  
CELLID icha ibun  
[ PUT { BREFL (hstbrn) (hstpar) AREFL (hstbrn) (hstpar) | [ AREFL ] (hstbrn) (hstpar)  
} ] ]
```

It can also be used to update a MAP data structure from the information available on an HISTORY data structure:

Table 43: Updating an HISTORY structure using a MAP structure

```
MAP := HST: MAP HISTORY
```

where

HISTORY	<b>character*12</b> name of an HISTORY data structure.
BURNUP	<b>character*12</b> name of a BURNUP data structure.
MAP	<b>character*12</b> name of a MAP data structure.
<b>(hstdim)</b>	structure containing the dimensions for the HISTORY data structure.
CELLID	keyword to identify the cell for which history information is to be processed.
<i>icha</i>	channel number for which history information is to be processed.
<i>ibun</i>	bundle number for which history information is to be processed.
<i>idfuel</i>	fuel type number associated with this cell. One can associate to each fuel cell a different fuel type. By default a single fuel type is defined and it fills every fuel cell. Only the initial properties of each fuel type are saved. These properties are used for refueling.
GET	keyword to specify that the values of the parameters selected in <b>(brnpar)</b> will be read from the input stream or CLE-2000 local variables and stored on the HISTORY data structure.
PUT	keyword to specify that the values of the parameters selected in <b>(brnpar)</b> will be read from the HISTORY data structure and transferred to local CLE-2000 variables.
BREFL	to specify that the information to extract from the HISTORY data structure is related to the properties of the cell before refueling takes place.
AREFL	to specify that the information to extract from the HISTORY data base is related to the properties of the cell after refueling took place.
<b>(hstbrn)</b>	structure containing the burnup options.
<b>(hstpar)</b>	structure containing the local parameters options.

The **(hstdim)** input structure is required for general dimensioning purpose. It is generally used only when creating the HISTORY data structure. However, the number of global and local parameters used in a HISTORY data structure can be increased at all time. The number of channels, bundles and the refueling scheme must be defined at the creation of the HISTORY data structure. This information can be provided manually or extracted from a MAP data structure. The general form of the **(hstdim)** input structure follows:

Table 44: Structure **(hstdim)**

```
[ EDIT iprint ]
[ DIMENSIONS [ GLOBAL nglo ] [ LOCAL nloc ] [ BUNDLES nbun bunl ] [ CHANNELS ncha ] ]
```

where

EDIT	keyword used to modify the print level <i>iprint</i> .
<i>iprint</i>	index used to control the printing in this module. It must be set to 0 if no printing on the output file is required.
DIMENSIONS	keyword used to indicate that the general dimensioning of the HISTORY data structure will be modified.

GLOBAL	keyword used to modify the number of global parameters on the HISTORY data structure.
<i>nglob</i>	the number of global parameters. Note that the history module will use the maximum value between the current <i>nglob</i> and the value, if any, defined on the HISTORY data structure.
LOCAL	keyword used to modify the number of local parameters on the HISTORY data structure.
<i>nloc</i>	the number of local parameters. Note that the history module will use the maximum value between the current <i>nloc</i> and the value, if any, defined on the HISTORY data structure.
BUNBLES	keyword used to specify the number of bundles per channels for the reactor model considered in the HISTORY data structure.
<i>nbun</i>	the number of bundles per channels for the reactor model. Note that if <i>nbun</i> is different from the value already defined on the HISTORY data structure or the MAP data structure, the execution will be aborted.
<i>bunl</i>	bundle length in cm. This information is required to compute initial fuel weight.
CHANNELS	keyword used to specify the number of fuel channels for the reactor model considered in the HISTORY data structure.
<i>ncha</i>	the number of fuel channels for the reactor model. Note that if <i>ncha</i> is different from the value already defined on the HISTORY data structure or the MAP data structure, the execution will be aborted.

The (**hstbrn**) serves a unique purpose, mainly to extract from the HISTORY file the information required to process a burnup evaluation in DRAGON using the **EVO:** module. The information must be stored inside CLE-2000 variables. The general form of this output structure is:

Table 45: Structure (**hstbrn**)

BURN <i>period power</i>
--------------------------

where

BURN	keyword to indicate that burnup information follows.
<i>period</i>	the burnup period (in days) that will be transferred to a real CLE-2000 variable.
<i>power</i>	the power density (in kW/kg) that will be transferred to a real CLE-2000 variable.

The (**hstpar**) serves two purposes. First, it is used to define the names of the local and global parameters that may be used in our calculations as well as the values of these local parameters. In can also be used to extract from a HISTORY data structure the values of these parameters. The general form of this structure is:

Table 46: Structure (**hstpar**)

[[ <i>NAMPAR valpar</i> ]]
----------------------------

where

<i>NAMPAR</i>	name of a local or global parameter to process. The parameters specified before the keyword <i>CELLID</i> is read will be considered global otherwise they will be considered local.
<i>valpar</i>	real value for the local or global parameter to process. In the case where the <b>GET</b> option is activated, the history module will extract this parameter from the input data stream. In the case where the <b>PUT</b> option is activated, the history module will try to transfer this information into a real CLE-2000 variable.

### 3.18.1 Example

The history interface between the codes DRAGON and DONJON has been written as a new module in order to facilitate the access to the GANLIB utilities that manage the required hierarchical data structures. The resulting **HST:** module can be called both by DRAGON and DONJON.

The reactor model we will consider as an example is a 3-D model with an  $x = 3$ ,  $y = 3$  and  $z = 3$  mesh. Here we will assume that the  $x - y$  plane describes fuel channels. The  $z$  plane will be associated with the so-called fuel bundles. This choice is somewhat arbitrary, however it is useful if the refueling takes place in a specific direction as in a CANDU reactor. Here, a 2-bundle shift fueling strategy will be considered. To each fresh fuel cell introduced in the core the **HST:** module will associate a unique cell number between 1 and  $N_c$ , the maximum number of cells in the reactor. Most of the information associated with the fresh fuel cells will be extracted from a DRAGON BURNUP file or defined using variable local parameters. Each fresh fuel cell inserted in the core will also be associated with a specific fuel type. Each fuel type is defined as a unique initial fuel composition. The fuel management for the reactor, including burnup and refueling will be performed by the DONJON code. Here the **HST:** will interact with this code via the MAP data structure. Typically, each cell in the reactor will be burned inside DRAGON using the power provided in the **AX-SHAPE** record and the depletion time provided in the **BURNUP-BEG** record stored in the MAP structure. When refueling takes place some of the fuel cells will be extracted, other will be displaced from one position to another and finally new fresh fuel cells inserted. The fresh fuel cells properties will be extracted from the fuel types properties available on the HISTORY data structure.

In a coupled DRAGON/DONJON execution, the **HST:** module will be called at various points and for various reasons. The first call to **HST:** can be performed using:

```

MODULE HST: ;
*----
* Map data structure for initialization: MAPO
* History data structure : History
*----
SEQ_ASCII MAPO ;
XSM_FILE History ;
XSM_FILE Reseau ;
*----
* Reactor parameters

```

```

* ncha = number of channels = 9
* nbun = number of bundles = 3
* nevo = number of evolution = 3
* nglo = number of global parameters = 1
* nloc = number of local parameters = 2
* bunl = bundle length in cm = 49.53 cm
*----
INTEGER ncha nbun nevo nglo nloc :=
9 3 3 1 2 ;
REAL bunl := 49.53 ;
*----
* Initialize History using MAP0
*----
Reseau := MAP0 ;
History := HST: Reseau ::
DIMENSIONS GLOBAL <<nglo>> LOCAL <<nloc>>
BUNDLES <<nbun>> <<bunl>>
CHANNELS <<ncha>> ;

```

Here, the HISTORY data structure will be stored in the XSM file `History`. One global and two local parameters are considered. No information about the name or the value of the global and local parameters will be available. This initialization procedure stores information only on the main level of the HISTORY data structure if the MAP data structure is not available. In this case the HISTORY is updated using a MAP data structure (in sequential ASCII file `MAP0`). The number of channels and bundles per channel are stored and compared with the same information in the MAP structure. For each bundle in the MAP, cell type and fuel type directories are constructed. The bundle powers and burnups available in MAP are used to generate the power rates in kW/kg and the depletion time in days required to reach the specified burnups. These values are stored in the HISTORY in the `PARAMBURNTAR` record. The fuel mass is mandatory for such calculation, thus the fuel weight is recovered from the MAP. If the HISTORY is in modification mode, the fuel weight is computed using the bundle length and the initial fuel density. Now, let us assume that a DRAGON calculation was performed for the cell located in bundle  $j = 1$  of channel  $i = 1$ . We will also assume that these cells contain a single type of fuel. Here the moderator temperature `TMod` is a global parameter while the fuel (`TComb`) and coolant (`TCalo`) temperatures are considered local parameters. We assume that after the cell flux calculation a BURNUP data structure was generated using the following instructions:

```

*----
* Procedures for cell calculation: CellCalc
*----
PROCEDURE CellCalc ;
*----
* Global parameter: Tmod for moderator temperature
* Local parameters: TComb for fuel temperature
* TCalo for coolant temperature
*----
REAL TMod := 345.66 ;
REAL TComb TCalo := 941.29 560.66 ;
*----
* Initial burnup options for cell calculation
*----
REAL Power DeltaT := 31.9713 5.0 ;
*----
* Local data structures
*----

```

```

LINKED_LIST Burnup Edition ;
*----
* Execution control parameters
* icha = channel number = 1
* ibun = bundle number = 1
*----
INTEGER icha ibun := 1 1 ;
*----
* Perform cell calculation
*----
Burnup Edition := CellCalc Burnup ::
<<TComb>> <<TCalo>> <<TMod>>
<<Power>> <<DeltaT>> ;

```

Then, assuming that the history structure `HistXSM` was created using the options above, we can use

```

*----
* Update history structure
*----
History := HST: History Burnup ::
GET TMod <<TMod>>
CELLID <<icha>> <<ibun>>
GET TComb <<TComb>> TCalo <<TCalo>> ;

```

where no `idfuel` is given (see Table 41), thus we have used the default value for `idfuel`= 1 to store in HISTORY the general information associated with fuel channel 1 and bundle 1. Here, the initial properties associated with fuel type 1 will be generated from the initial isotope densities in the BURNUP. For the CELLID, here `icha`= 1 and `ibun`= 1, the burnup information, isotope densities, depletion parameters and initial fuel density are stored in a `/celldir/` directory. Moreover the power rate 31.9713 kW/kg and the depletion time 5.0 days are kept in the `PARAMBURNTAR` record.

A HISTORY data structure that contains the initial cell information can be updated using a MAP data structure:

```

*----
* Map data structure for refueling: MAP1
*----
SEQ_ASCII MAP1 ;
*----
* Refuel
*----
Reseau := MAP1 ;
History := HST: History Reseau ;

```

Here, new burnup power ratings will be stored in the HISTORY data structure reflecting the power distribution in the DONJON calculation. The refueling information available in the MAP structure will also be used to redistribute the fuel in the HISTORY structure at various cell location.

Finally the last option is to recover this information in DRAGON to perform a new series of cell calculations:

```

*----
* Local parameters
* Initial burnup options for cell calculation
* *A is after refueling
* *B is before refueling
*----

```

```

REAL TCombA TCaloA TCombB TCaloB ;
REAL PowerA DeltaTA PowerB DeltaTB ;
Burnup := HST: History ::
PUT TMod >>TMod<<
CELLID <<icha>> <<ibun>>
PUT BREFL BURN >>DeltaTB<< >>PowerB<<
TComb >>TCombB<< TCalo >>TCaloB<<
AREFL BURN >>DeltaTA<< >>PowerA<<
TComb >>TCombA<< TCalo >>TCaloA<< ;
IF DeltaTB 0.0 > THEN
*----
* Burn before refueling
*----
Burnup Edition := CellCalc Burnup ::
<<TCombB>> <<TCaloB>> <<TMod>>
<<PowerB>> <<DeltaTB>> ;
Edition := DELETE: Edition ;
ENDIF ;
*----
* Burn after refueling
*----
Burnup Edition := CellCalc Burnup ::
<<TCombA>> <<TCaloA>> <<TMod>>
<<PowerA>> <<DeltaTA>> ;
*----
* Update History
*----
History := HST: History Burnup ::
CELLID <<icha>> <<ibun>> ;

```

Note that here, there are two sets of local parameters that can be extracted from the history data structure, namely the before (BREFL) and the after (AREFL) refueling information. In the case of fresh fuel (single fuel description or a refueled bundle) extracting the before information is not required. However, if one uses the general procedure described above to extract the before and after information, one will be able to identify the new fuel bundles as well as the bundle that have not been moved in the core by the fact that  $\Delta t = 0$  for burnup before refueling. For bundles that have been displaced in the core during refueling then  $\Delta t > 0$ .



### 3.19 The ROD: module

The ROD: module used for rod insertion gestion in PWR. This module creates a 3-D field for rod parameter in a fuel map. This local field contains, for each mesh, one coefficient describing the rod insertion for the considered mesh. These coefficients are chosen according to rod coefficients saved in the SAPHYB or MULTICOMPO object.

The ROD: module specifications are:

Table 47: Structure ROD:

*FLMAP* := ROD: *FLMAP* :: (descrod1)

where

*FLMAP*            **character\*12** name of the MAP object that will contain the 3-D rod file. The *FLMAP* has to be modified for the module and must appear on both LHS and RHS.

(descrod1)        structure describing the main input data to the ROD: module. Note that this input data is mandatory and must be specified.

#### 3.19.1 Main input data to the ROD: module

A *rod identification number* (RIN) is a local parameter (type real) assigned to each type of rod in the SAPHYB or MULTICOMPO object. Black bars of 900 MW PWRs in France are made of AICN material (Silver-Indium-Cadmium). Black bars of 1300 MW, N4 and EPR PWRs in France are made of a section of B4C followed by a section of AICN (in yellow), as depicted in Fig. 2.




Figure 2: Presentation of a partially-inserted 2-part control rod.

Recommended values are:

RIN	type of bar
0	AICG (grey bar, generally out at nominal power)
1 (= val1)	rod extracted
2	AICN (black bar, generally out or partly inserted)
3	B4C (black bar, generally out or partly inserted)

The rod identification number is interpolated over each axial mesh of the fuel map. A local parameter name *par1* is defined and their distributed values are computed by the ROD: module as depicted in Fig. 2. Local parameters *par1* are identified as *ROD* in the figure. A local value of *ROD* = 2.5 corresponds to a mesh of the fuel map containing 50% of AICN material and 50% of B4C material.

Table 48: Structure (**descrod1**)

```
[ EDIT iprint ]
[ PARA par1 vall ]
[ LINS insm ]
[ STEP step ]
[ NRFB nrfb ]
[ RGRP
  { ngrp maxmix
    ((hgrp(i) isrt(i) rin(i,1) [[ hmix(i,j) rin(i,j+1) ]]), i=1, ngrp, j=1, lmix-1)
    | nrmv
      ((hgrp(i) isrt(i)), i=1, nrmv) }
  ENDRGRP ]
[ RMAP nass
  ((hrod(i,j)), i=1, lx, j=1,ly )
  ENDRMAP ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); larger values produce increasing amounts of output.
PARA	keyword used to indicate that the name of the record to be contained the rod field will follow.
<i>par1</i>	name of the rod record and local parameter to be created. This name must correspond to the rod name of the SAPHYB or MULTICOMPO object.
<i>vall</i>	real value of the 3-D rod field <i>par1</i> . This value enables to initialise the field to a uniform value, corresponding to a core with no rod inserted.
LINS	keyword used to indicate the maximum number of insertion steps for all rods.
<i>insm</i>	integer value of maximum rod insertion step.
STEP	keyword used to indicate the length of one rod step.
<i>step</i>	real value of rod step length (in cm).
NRFB	keyword used to indicate the number of bottom-reflective meshes in the core.
<i>nrfb</i>	integer value of bottom-reflective meshes in the core.
RGRP	keyword used to define all rod groups present in the core.
<i>ngrp</i>	integer value of the number of rod groups present in the core.

<i>maxmix</i>	integer value of the maximum number of rod zones (for hybrid rods with many materials).
<i>nrmv</i>	integer value of the number of rod groups that rod insertion is modified.
<i>hgrp</i>	<b>character*3</b> identification value for the rod group <i>i</i> .
<i>isrt</i>	integer value for the number of inserted steps for the rod group <i>i</i> .
<i>rin</i>	real value for the rod identification number (RIN) considered from the SAPHYB or MULTICOMPO object.
<i>lmix</i>	real value for the height (in cm) of the RIN considered. If only one RIN is used to define the rod, <i>lmix</i> is not defined. If two or more RIN are used for one rod, the values of the lower rod sections with $1 \leq j < lmix$ should be defined, as depicted in Fig. 2.
<i>lmix</i>	integer value for the number of <i>rin</i> for each rod group.
ENDRGRP	keyword used to indicate the end of rod groups definition.
RMAP	keyword used to define the position of each rod group inside the core.
<i>nass</i>	integer value of number of assemblies inside the core.
<i>hrod</i>	<b>character*3</b> identification value for the (i,j) position. Accepted values are: <ul style="list-style-type: none"> <li>•  , - or - - for an unrodded assembly,</li> <li>• or a <b>character*3</b> identification value referring to the identification value of the rod group.</li> </ul>
ENDRMAP	keyword used to indicate the end of rod group position map.

### 3.20 The IDET: module

The IDET: module can perform an evaluation of fission chamber response in a PWR by integrating the fission rate over the detector positions. This module is limited to Cartesian geometry.

The IDET: module specification is:

Table 49: Structure IDET:

```

IDETEC := IDET: [ IDETEC ] TRKNAM FLUNAM LIBNAM [ FMAP ]
:: (descidet)

```

where

<i>IDETEC</i>	<b>character*12</b> name of a IDETECT data structure, (L_INTDETEC signature) that will be created or updated by the IDET: module.
<i>TRKNAM</i>	<b>character*12</b> name of the read-only TRACKING data structure (L_TRACK signature) containing the finite-element tracking.
<i>FLUNAM</i>	<b>character*12</b> name of the read-only FLUXUNK data structure (L_FLUX signature) containing the finite-element solution.
<i>LIBNAM</i>	<b>character*12</b> name of the read-only MACROLIB data structure (L_LIBRARY signature) that contains the interpolated microscopic cross sections.
<i>FMAP</i>	<b>character*12</b> name of the read-only FMAP data structure (L_MAP signature) containing renumbered mixture indices. This object is optionnal.
<b>(descidet)</b>	structure describing the input data to the IDET: module.

#### 3.20.1 Input data to the IDET: module

Table 50: Structure (descidet)

```

[ EDIT iprint ]
[ DETNAME dname ] [ REANAME rname ]
DETECTOR
  [[ POSITION { valx | INTEG valx1 valx2 } { valy | INTEG valy1 valy2 }
    [ { valz | INTEG valz1 valz2 } ] ]]
ENDD
;

```

where

EDIT                    keyword used to set *iprint*.

<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing (default value); =2 for more printouts.
DETNAME	keyword used to set <i>dname</i> , the alias name of the isotope used as detector. By default, <i>dname</i> =U235 is used.
<i>dname</i>	character*12 alias name of the isotope used as detector.
REANAME	keyword used to set <i>rname</i> , the name of the nuclear reaction used as detector. By default, <i>rname</i> =NFTOT is used.
<i>rname</i>	character*12 name of the nuclear reaction used as detector.
POSITION	keyword defining the position of a single detector.
INTEG	keyword indicating that the detector reading will be averaged between two Cartesian positions.
<i>valx</i>	position (real number) of the detector along <i>X</i> axis.
<i>valx1</i>	starting position (real number) of the detector along <i>X</i> axis.
<i>valx2</i>	ending position (real number) of the detector along <i>X</i> axis. We must have <i>valx1</i> < <i>valx2</i> .
<i>valy</i>	position (real number) of the detector along <i>Y</i> axis.
<i>valy1</i>	starting position (real number) of the detector along <i>Y</i> axis.
<i>valy2</i>	ending position (real number) of the detector along <i>Y</i> axis. We must have <i>valy1</i> < <i>valy2</i> .
<i>valz</i>	position (real number) of the detector along <i>Z</i> axis. Detector position along <i>Z</i> axis is given only for 3D geometries.
<i>valz1</i>	starting position (real number) of the detector along <i>Z</i> axis.
<i>valz2</i>	ending position (real number) of the detector along <i>Z</i> axis. We must have <i>valz1</i> < <i>valz2</i> .

## 4 CROSS-SECTION INTERPOLATION MODULES

### 4.1 The CRE: module

The **CRE:** module is used for the recovering and interpolation of nuclear properties from one or many COMPO objects, originated from the transport calculations using lattice code DRAGON. A resulting MACROLIB will be created (or updated) by the **CRE:** module, it will contain the nuclear properties of some selected reactor materials.

Two types of MACROLIB can be constructed using the **CRE:** module:

- A MACROLIB that will be constructed for the few reactor materials, namely for the devices and/or reflector properties. It can also be created for the few fuel regions defined in the reactor core. This MACROLIB is permitted to be updated for the new properties in the subsequent calls to the **CRE:** module.
- A fuel-map MACROLIB that will be constructed over the fuel lattice only. This MACROLIB will contain a set of interpolated fuel properties with respect to the burnup distribution over the fuel lattice and according to the interpolation option defined in the FMAP object. The total number of mixtures in the resulting MACROLIB will equal to the total number of fuel bundles.

Note that the **CRE:** module can be used only with the mono-parameter COMPO objects and the nuclear properties can be interpolated only with respect to the burnup data. In case of the MACROLIB construction from a multi-parameter database, the **NCR:** module should be used instead. In this case, the interpolation of nuclear properties can be made with respect to global and local parameters, if they were previously specified in the fuel-map (see Section 3.1.2).

The **CRE:** module specifications are:

Table 51: Structure **CRE:**

```
{ MACRO := CRE: [ MACRO ] [[ CPO ]] :: (desccre1) |
  MACFL := CRE: [[ CPO ]] FMAP :: (desccre2) }
```

where

<i>MACRO</i>	<b>character*12</b> name of the MACROLIB object to be created or updated for the few reactor material properties. Note that if <i>MACRO</i> appears on the RHS, the information previously stored in <i>MACRO</i> is kept.
<i>CPO</i>	<b>character*12</b> name of the COMPO object containing the mono-parameter database from transport calculations.
<i>MACFL</i>	<b>character*12</b> name of the fuel-map MACROLIB that will be created only for the fuel properties over the fuel lattice.
<i>FMAP</i>	<b>character*12</b> name of the FMAP object containing the fuel-map specification and burnup informations.
<b>(desccre1)</b>	structure describing the input data to the <b>CRE:</b> module when the FMAP object is not specified.

**(descrc2)** structure describing the input data to the **CRE:** module for the fuel-map MACROLIB construction.

#### 4.1.1 Input data for the **CRE:** module

Table 52: Structure **(descrc1)**

```
[ EDIT iprint ]
[ NMIX nmix ]
READ [[ COMPO CPO (descdata1) ]]
;
```

Table 53: Structure **(descrc2)**

```
[ EDIT iprint ]
READ [[ TABLE CPO (descdata2) ]]
;
```

where

<b>EDIT</b>	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing of information on screen: = 0 for no print; = 1 for minimum printing; larger values will produce increasing amounts of output.
<b>NMIX</b>	keyword used to define the number of material mixtures <i>nmix</i> . This data must be given only if <i>MACRO</i> is created and the <i>FMAP</i> object is not specified.
<i>nmix</i>	integer maximum number of reactor material mixtures, as defined in the reactor geometry.
<b>READ</b>	keyword used to read the MACROLIB specification from the input data file.
<b>COMPO</b>	keyword used to indicate a simple MACROLIB creation, i.e. according to the first calling specification when <i>FMAP</i> object is not specified.
<b>TABLE</b>	keyword used to indicate a fuel-map MACROLIB creation, i.e. according to the second calling specification with <i>FMAP</i> object specified.
<i>CPO</i>	<b>character*12</b> name of the selected <b>COMPO</b> object. This name must appear in the calling specification to the <b>CRE:</b> module.
<b>(descdata1)</b>	structure containing the interpolation specification if <b>COMPO</b> is the selected option.
<b>(descdata2)</b>	structure containing the interpolation specification if <b>TABLE</b> is the selected option.

Table 54: Structure (**descdata1**)

```

[[ MIX mix NAMDIR [ DERIV ] [ UPS ]
  [ { I-BURNUP burn | T-BURNUP burn0 burn1 } ]
  [ MICRO { [[ HISO { conc | * } ]] | ALL } ]
ENDMIX ]]

```

Table 55: Structure (**descdata2**)

```

[[ MIX mix NAMDIR [ DERIV ] [ UPS ]
  [ { TIMAV-BURN | INST-BURN | AVG-EX-BURN ivarty } ]
  [ MICRO { [[ HISO { conc | * } ]] | ALL } ]
ENDMIX ]]

```

where

MIX	keyword used to set the material mixture <i>mix</i> .
<i>mix</i>	integer identifier for the material mixture that will be included in the MACROLIB. The maximum number of identifiers permitted is <i>nmix</i> and the maximum value that <i>mix</i> may have is <i>nmix</i> . Note that if <b>TABLE</b> is the selected option, then <i>mix</i> identifies the fuel type as defined in the reactor geometry.
NAMDIR	<b>character*12</b> directory name in the <i>CPO</i> object from which the nuclear properties for material mixture <i>mix</i> are to be recovered.
DERIV	keyword used to compute the derivative of the MACROLIB information with respect to <i>burn</i> or <i>burn1</i> value. By default, the MACROLIB information is not differentiated.
UPS	keyword used to compute properties with no up-scattering contribution.
TIMAV-BURN	keyword used to compute time-averaged cross-section information. This option is available <i>only if</i> <b>TABLE</b> is the selected option. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the <i>FMAP</i> object.
INST-BURN	keyword used to compute cross-section information at specific bundle burnups. This option is available <i>only if</i> <b>TABLE</b> is the selected option. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the <i>FMAP</i> object.
AVG-EX-BURN	keyword used to compute the derivatives of cross-section information relative to the exit burnup of a single combustion zone. The derivatives are computed using Eq. (3.3) of Ref. 16, written as

$$\frac{\partial \bar{\Sigma}_x}{\partial B_j^e} = \frac{1}{B_j^e (B_{j,k}^{\text{eoc}} - B_{j,k}^{\text{boc}})} \left[ - \int_{B_{j,k}^{\text{boc}}}^{B_{j,k}^{\text{eoc}}} dB \Sigma_x(B) + B_{j,k}^{\text{eoc}} \Sigma_x(B_{j,k}^{\text{eoc}}) - B_{j,k}^{\text{boc}} \Sigma_x(B_{j,k}^{\text{boc}}) \right]$$

where  $B_{j,k}^{\text{boc}}$ ,  $B_{j,k}^{\text{eoc}}$ , and  $B_j^e$  are the beginning of cycle burnup of bundle  $\{j, k\}$ , end of cycle burnup of bundle  $\{j, k\}$  and exit burnup of channel  $j$ . This option is available *only if* **TABLE** is the selected option.



<i>ivarty</i>	index of the combustion zone for differentiation of cross-section information.
I-BURNUP	keyword used to perform a single interpolation and to set the burnup interpolation value <i>burn</i> .
<i>burn</i>	real interpolation value of the burnup, given in MW·day per tonne of initial heavy elements.
T-BURNUP	keyword used to perform a time-average MACROLIB evaluation between the burnup values <i>burn0</i> and <i>burn1</i> .
<i>burn0</i>	real initial value of the burnup, given in MW·day per tonne of initial heavy elements.
<i>burn1</i>	real final value of the burnup, given in MW·day per tonne of initial heavy elements.
MICRO	keyword used to set the number densities of the extracted isotopes present in the COMPO linked list or XSM file. By default, the extracted isotopes are not added to the resulting MACROLIB.
<i>HISO</i>	<b>character*12</b> name of an extracted isotope.
<i>conc</i>	user-defined real number density of the extracted isotope, given in $10^{24}$ particles per $\text{cm}^3$ .
*	keyword used to indicate that the number density for the isotope <i>HISO</i> will be recovered from the COMPO object.
ALL	keyword used to indicate that all the number densities are to be recovered from the COMPO object.
ENDMIX	keyword used to indicate the end of data specification for the material mixture <i>mix</i> .

## 4.2 The NCR: module

This component of DONJON is dedicated to the interpolation of MICROLIB and MACROLIB data from a MULTICOMPO object, the reactor database produced by COMPO:. A set of *global* and/or *local parameters* are defined for each material mixture and used as multi-dimensional interpolation variables.

The calling specifications are:

Table 56: Structure (NCR:)

```
MLIB := NCR: [ { MLIB | MLIB2 } ] CPONAM1 [[ CPONAM2 ]] [ MAPFL ] :: (ncr_data)
```

where

<i>MLIB</i>	<b>character*12</b> name of a MICROLIB (type L_LIBRARY) or MACROLIB (type L_MACROLIB) containing the interpolated data. If this object also appears on the RHS of structure (NCR:), it is open in modification mode and updated.
<i>MLIB2</i>	<b>character*12</b> name of an optional MICROLIB object whose content is copied on <i>MLIB</i> .
<i>CPONAM1</i>	<b>character*12</b> name of the LCM object containing the MULTICOMPO data structure (L_MULTICOMPO signature).
<i>CPONAM2</i>	<b>character*12</b> name of an additional LCM object containing an auxiliary MULTICOMPO data structure (L_MULTICOMPO signature). This object is optional.
<i>MAPFL</i>	<b>character*12</b> name of the MAP object containing fuel regions description, global and local parameter information (burnup, fuel/coolant temperatures, coolant density, etc). Keyword TABLE is expected in (ncr_data).
<i>ncr_data</i>	input data structure containing interpolation information (see Section 4.2.1).

### 4.2.1 Interpolation data input for module NCR:

Table 57: Structure (ncr\_data)

```
[ EDIT iprint ]
[ ALLX nbfuel ] [ RES ] [ PURE ]
[ { MACRO | MICRO } ] [ { LINEAR | CUBIC } ] [ LEAK b2 ]
[ NMIX nmixt ]
{ [[ COMPO CPONAM NAMDIR (descintf) ]]
  | [[ TABLE CPONAM NAMDIR [ namburn ] (descintf) ]] }
;
```

where

EDIT            keyword used to set *iprint*.

<i>iprint</i>	index used to control the printing in module <code>NCR:</code> . =0 for no print; =1 for minimum printing (default value).
<code>ALLX</code>	keyword used to register the region number of each isotope before merging. This option is useful if the same keyword has been specified in <code>EDI:</code> and <code>COMPO:</code> before.
<i>nbfuel</i>	number of fuel rings used for micro-depletion calculations.
<code>RES</code>	keyword indicating that the interpolation is done only for the microscopic cross sections and not for the isotopic densities. In this case, a RHS <code>MICROLIB</code> must be defined and the number densities are recovered from it. This option is useful for micro-depletion applications. <b>Important note:</b> It is possible to force interpolation of some isotopic densities with <code>RES</code> option if these isotopes are explicitly specified with a “*” flag after <code>MICRO</code> keyword in <i>descintf</i> input data structure (see Section 4.5.2).
<code>PURE</code>	keyword indicating that the interpolation is a pure linear combination of <i>terp</i> factors. The fission spectra are <i>not</i> renormalized. By default, non-linear effects are produced by renormalization operations.
<code>MACRO</code>	keyword indicating that <i>MLIB</i> is a <code>MACROLIB</code> .
<code>MICRO</code>	keyword indicating that <i>MLIB</i> is a <code>MICROLIB</code> (default option). Object <i>MLIB</i> contains an embedded <code>MACROLIB</code> , but the CPU time required to obtain it is longer.
<code>LINEAR</code>	keyword indicating that interpolation of the <code>MULTICOMPO</code> uses linear Lagrange polynomials (default option).
<code>CUBIC</code>	keyword indicating that interpolation of the <code>MULTICOMPO</code> uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. 17.
<code>LEAK</code>	keyword used to introduce leakage in the embedded <code>MACROLIB</code> . This option should only be used for non-regression tests.
<i>b2</i>	the imposed buckling corresponding to the leakage.
<code>NMIX</code>	keyword used to define the maximum number of material mixtures. This information is required only if <i>MLIB</i> is created.
<i>nmixt</i>	the maximum number of mixtures (a mixture is characterized by a distinct set of macroscopic cross sections) the <code>MACROLIB</code> may contain. The default value is <i>nmixt</i> = 0 or the value recovered from <i>MLIB</i> if it appears on the RHS of structure ( <code>NCR:</code> ).
<code>COMPO</code>	keyword used to set <i>CPONAM</i> and to define each global and local parameter.
<code>TABLE</code>	keyword used to set <i>CPONAM</i> and to recover some global and local parameter from a <code>MAP</code> object named <i>MAPFL</i> .
<i>CPONAM</i>	<code>character*12</code> name of the LCM object containing the <code>MULTICOMPO</code> data structure where the interpolation is performed. This name must be set in the RHS of structure ( <code>NCR:</code> ).
<i>NAMDIR</i>	access the <code>MULTICOMPO</code> structure of <i>CPONAM</i> from the sub-directory named <i>NAMDIR</i> . This value must be set equal to 'default' if not previously defined by a <code>STEP UP</code> keyword in module <code>COMPO</code> .
<i>namburn</i>	name of the parameter for burnup (or irradiation) in the sub-directory named <i>NAMDIR</i> . This value is defined if option <code>TABLE</code> is set and if burnup (or irradiation) is to be considered as parameter.

*descintf* input data structure containing interpolation information relative to the MULTICOMPO data structure named *CPONAM* (see Section 4.5.2).

#### 4.2.2 Defining local and global parameters

If a MAP object is defined on the RHS of structure (**NCR:**), and if the **TABLE** keyword is set, some information required to set the interpolation points is found in this object. In this case, the **NCR:** operator search the MULTICOMPO object for global or local parameters having an arbitrary name specified in the MAP object or set directly in this module. Note that any parameter's value set directly in this module prevails on a value stored in the *MAPFL* object.

Each instance of *descintf* is a data structure specified as

Table 58: Structure (**descintf**)

```
[[ MIX imix [ { FROM imixold | USE } ]
  [ { TIMAV-BURN | INST-BURN | AVG-EX-BURN ivarty } ]
  [[ { SET | DELTA | ADD } ] [ { LINEAR | CUBIC } ] PARKEY { val1 | MAP } [ { val2 | MAP } ]
    [ REF [[ PARKEY { valref | SAMEASREF } ]] ENDREF ] ]]
  [ MICRO { ALL | ONLY } [[ HISO { conc | * } ]]]
ENDMIX ]]
```

where

MIX	keyword used to set <i>imix</i> . Discontinuity factor information present in the Multicompo is interpolated as mixture 1 values.
<i>imix</i>	index of the mixture that is to be created in the MICROLIB and MACROLIB.
FROM	keyword used to set the index of the mixture in the MULTICOMPO object.
<i>imixold</i>	index of the mixture that is recovered in the MULTICOMPO object. By default, <i>imixold</i> =1.
USE	keyword used to set the index of the mixture in the MULTICOMPO object equal to <i>imix</i> .
TIMAV-BURN	keyword used to compute time-averaged cross-section information. This option is available <i>only if</i> a <i>MAPFL</i> object is set. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the <i>MAPFL</i> object.
INST-BURN	keyword used to compute cross-section information at specific bundle burnups. This option is available <i>only if</i> a <i>MAPFL</i> object is set. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the <i>MAPFL</i> object.
AVG-EX-BURN	keyword used to compute the derivatives of cross-section information relative to the exit burnup of a single combustion zone. The derivatives are computed using Eq. (3.3) of Ref. 16, written as

$$\frac{\partial \bar{\Sigma}_x}{\partial B_j^e} = \frac{1}{B_j^e (B_{j,k}^{\text{eoc}} - B_{j,k}^{\text{boc}})} \left[ - \int_{B_{j,k}^{\text{boc}}}^{B_{j,k}^{\text{eoc}}} dB \Sigma_x(B) + B_{j,k}^{\text{eoc}} \Sigma_x(B_{j,k}^{\text{eoc}}) - B_{j,k}^{\text{boc}} \Sigma_x(B_{j,k}^{\text{boc}}) \right]$$

where  $B_{j,k}^{\text{boc}}$ ,  $B_{j,k}^{\text{eoc}}$ , and  $B_j^e$  are the beginning of cycle burnup of bundle  $\{j,k\}$ , end of cycle burnup of bundle  $\{j,k\}$  and exit burnup of channel  $j$ . This option is available

only if a *MAPFL* object is set. By default, the type of calculation (*TIMAV-BURN* or *INST-BURN*) is recovered from the *MAPFL* object.

<i>ivarty</i>	index of the combustion zone for differentiation of cross-section information.
SET	keyword used to indicate a simple interpolation at <i>val1</i> or an averaging between <i>val1</i> and <i>val2</i> . The result $\sigma_{\text{ref}}$ is also used as the reference value when the <b>ADD</b> is used. Note: see at the ending note of this section for a detailed description and examples.
DELTA	keyword used to indicate a delta-sigma calculation between <i>val2</i> and <i>val1</i> (i.e., $\Delta\sigma_{\text{ref}} = \sigma_{\text{val2}} - \sigma_{\text{val1}}$ is computed). This keyword can be used only once in each mixture data block (initiated with a <b>MIX</b> keyword). Note: see at the ending note of this section for a detailed description and examples.
ADD	keyword used to indicate a delta-sigma calculation between <i>val2</i> and <i>val1</i> is added to the reference value (i.e., $\Delta\sigma = \sigma_{\text{val2}} - \sigma_{\text{val1}}$ is used as contribution, $\sigma_{\text{ref}} + \Delta\sigma$ or $\Delta\sigma_{\text{ref}} + \Delta\sigma$ is returned). Note: see at the ending note of this section for a detailed description and examples.
LINEAR	keyword indicating that interpolation of the <i>MULTICOMPO</i> for parameter <i>PARKEY</i> uses linear Lagrange polynomials. It is possible to set different interpolation modes to different parameters. By default, the interpolation mode is set in Sect. 4.2.1.
CUBIC	keyword indicating that interpolation of the <i>MULTICOMPO</i> for parameter <i>PARKEY</i> uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. 17. By default, the interpolation mode is set in Sect. 4.2.1.
<i>PARKEY</i>	<b>character*12</b> user-defined keyword associated to a global or local parameter to be set.
<i>val1</i>	value of a global or local parameter used to interpolate. <i>val1</i> is the initial value of this parameter in case an average is required. <i>val1</i> can be an integer, real or string value.
<i>val2</i>	value of the final global or local parameter. By default, a simple interpolation is performed, so that <i>val2</i> = <i>val1</i> . <i>val2</i> is always a real value with <i>val2</i> ≥ <i>val1</i> .
MAP	keyword used to indicate that the value of parameter <i>val1</i> or the second value for the $\Delta\sigma$ calculation is recovered from <i>MAPFL</i> , i.e. the <i>MAP</i> object containing fuel regions description.
REF	keyword only available together with the <b>ADD</b> option. It is used to set all the other variable values when a $\Delta$ contribution is performed for one variable.
<i>valref</i>	value of the reference parameter, when it is directly given by the user. Note that there is no default value.
SAMEASREF	keyword used to specify that the reference value will be the same as in the reference case, i.e. for the $\sigma_{\text{ref}}$ computation.
ENDREF	keyword only available together with the <b>ADD</b> option. It is used to specify that all the other variable values which are required are given.
MICRO	keyword used to set the number densities of some isotopes present in the <i>MULTICOMPO</i> object. The data statement “ <i>MICRO ALL</i> ” is used by default.
ALL	keyword to indicate that all the isotopes present in the <i>MULTICOMPO</i> object will be used in the <i>MICROLIB</i> and <i>MACROLIB</i> objects. Concentrations of these isotopes will be recovered from the <i>MULTICOMPO</i> object or set using the “ <i>HISO conc</i> ” data statement.

ONLY	keyword to indicate that only the isotopes set using the “ <i>HISO conc</i> ” data statement will be used in the MICROLIB and MACROLIB objects.
<i>HISO</i>	character*8 name of an isotope.
<i>conc</i>	user-defined value of the number density (in $10^{24}$ particles per $\text{cm}^3$ ) of the isotope.
*	the value of the number density for isotope <i>HISO</i> is recovered from the MULTICOMPO object.
ENDMIX	end of specification keyword for the material mixture.

#### 4.2.3 Interpolation in the parameter grid

The following example corresponds to a delta-sigma computation in mixture 1 corresponding to a perturbation. Note that in this case, the MACROLIB object may content negative cross-section.

```
MACROLIB := NCR: CPO ::
  EDIT 40 NMIX 1 MACRO COMPO CPO default
  MIX 1 !(* delta sigma contribution *)
    SET 'CELL' '3D'
    DELTA 'PITCH' 0.0 1.0
  ENDMIX
;
```

When the number of parameters used for the interpolation is increased, all the lattice computations corresponding to all the combinations of parameters may not be done for computation time reasons. In this case, some approximations may be required. The choice for the SET, DELTA and ADD is then dependent of the structure of the database (i.e. how the database grid of possibilities is filled). When a MAP object containing fuel regions description is used, the problem become even more complex, because values have to be automatically changed for all bundles. In order to clarify all the different possibilities and limitations dependently of the database structure, we will use a 3 parameter case. The paramaters are referenced by 'A', 'B' and 'C'. But before we explain the different cases, we want to remind that the interpolation factors are computed on each axis sepearatly.

The first case corresponds to a complete grid, represented by a gray paralepiped on Fig. 3 and 4. The figure 3 shows that the interpolated value in point  $V$  can be obtained directly without MAP object. For time-average (TA) computation, lets assume that the parameter 'B' represents the burnup (and keep this convention for other database structure also). In this case the figure 4 shows also that the direct interpolation can be done to compute an average value between the points  $V'$  and  $V$ . Note that the TA burnups are stored in the MAP object, and are then recovered automatically.

The second case corresponds to a partial grid where all the lattice computations have been perfomed for several pairs of parameters, which are represented as the gray rectangles on Fig. 5 and 6. If we use the notations of Fig. 5 and 6, the best estimate interpolated values,  $f$ , we can get are given by:

$$f = f(V) \approx f(V_B) + (f(V_{BA}) - f(V_B)) + (f(V_{BC}) - f(V_B)) = f(V_{BC}) + (f(V_{BA}) - f(V_B)) = f(V_{BA}) + (f(V_{BC}) - f(V_B)) \text{ for instataneous}$$

$$f = f(V', V) \approx f(V'_B, V_B) + (f(V'_{BA}, V_{BA}) - f(V'_B, V_B)) + (f(V'_{BC}, V_{BC}) - f(V'_B, V_B)) = f(V'_{BC}, V_{BC}) + (f(V'_{BA}, V_{BA}) - f(V'_B, V_B)) = f(V'_{BA}, V_{BA}) + (f(V'_{BC}, V_{BC}) - f(V'_B, V_B)) \text{ for TA}$$

where  $f(.,.)$  represents the average value between two points.

The third case corresponds to a minimal grid, where the lattice computations have been perfomed only for one parameter variation at a time. In this case, the grid is represented by the thick gray lines on the axis on Fig. 7 and 8. If we use the notations of Fig. 7 and 8, the best estimate interpolated values,  $f$ , we can get are given by:

$$f = f(V) \approx f(V_0) + (f(V_A) - f(V_0)) + (f(V_B) - f(V_0)) + (f(V_C) - f(V_0)) = f(V_B) + (f(V_A) - f(V_0)) +$$

$(f(V_C) - f(V_0))$  for instantaneous

$f = f(V', V) \approx f(V'_B, V_B) + (f(V_A) - f(V_0)) + (f(V_C) - f(V_0))$  for TA

Note that the reference point ( $V_0$  in the example) does not have to be the same for all parameters. Database structures such as represented on Fig 9 can also be used. In this case, we even have two choices for the  $\Delta f$  computation on axis 'A'.

The last case is in fact a mix of cases 2 and 3. The gray rectangle and the gray line on Fig. 10 and 11 represent where all the lattice computations have been performed. With the notations used on those figures, one can write that the best estimate interpolated values,  $f$ , we can get are given by:

$f = f(V) \approx f(V_B) + (f(V_{BC}) - f(V_B)) + (f(V_A) - f(V_0)) = f(V_{BC}) + (f(V_A) - f(V_0))$  for instantaneous

$f = f(V', V) \approx f(V'_B, V_B) + (f(V'_{BC}, V_{BC}) - f(V'_B, V_B)) + (f(V_A) - f(V_0)) = f(V'_{BC}, V_{BC}) + (f(V_A) - f(V_0))$  for TA

Note once again that the reference point ( $V_0$  in the example) does not have to be the same for all parameters. Database structures such as represented on Fig 12 can also be used.

The input files will actually reflect the previous equations. However, they are different if the parameters are stored in a MAP object, *MAPFL*, or provided directly by the user. For the case of one point interpolation (i.e. instantaneous), the input files will be:

case	all parameters explicitly set	all parameters in MAP
GRID (Fig. 3)	<pre> MACROLIB := NCR: CPO ::   NMIX 1 MACRO   COMPO CPO default   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc&gt;&gt;   ENDMIX ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1   ENDMIX ; </pre>
PLANE (Fig. 5)	<pre> MACROLIB := NCR: CPO ::   NMIX 1 MACRO   COMPO CPO default   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb&gt;&gt; ENDREF !or 'B' SAMEASREF ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; MAP     REF 'A' &lt;&lt;va0&gt;&gt;     'B' SAMEASREF ENDREF !or SET 'A' &lt;&lt;va0&gt;&gt; !or ADD 'A' &lt;&lt;va0&gt;&gt; MAP !or REF 'C' &lt;&lt;vc0&gt;&gt; !or 'B' SAMEASREF ENDREF   ENDMIX ; </pre>
AXE (Fig. 7)	<pre> MACROLIB := NCR: CPO ::   NMIX 1 MACRO   COMPO CPO default   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF     ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; MAP     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF     ADD 'C' &lt;&lt;vc0&gt;&gt; MAP     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>

*continued on next page*



case	all parameters explicitly set	all parameters in MAP
PLANE + AXE (Fig. 10)	<pre> MACROLIB := NCR: CPO ::   NMIX 1 MACRO   COMPO CPO default   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; MAP     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>

Table 59: NCR inputs for instantaneous cases

For the TA, the burnup variable has no other choice than to be stored in the MAP object, *MAPFL*. Then the input files will be:

case	only the burnup in MAP	all parameters in MAP
GRID (Fig. 4)	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'C' &lt;&lt;vc&gt;&gt;   ENDMIX ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1   ENDMIX ; </pre>
PLANE (Fig. 6)	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;     REF 'A' &lt;&lt;va0&gt;&gt;     'B' SAMEASREF ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO   TABLE CPO default 'B'   MIX 1     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; MAP     REF 'A' &lt;&lt;va0&gt;&gt;     'B' SAMEASREF ENDREF !or SET 'A' &lt;&lt;va0&gt;&gt; !or ADD 'A' &lt;&lt;va0&gt;&gt; MAP !or REF 'C' &lt;&lt;vc0&gt;&gt; !or 'B' SAMEASREF ENDREF   ENDMIX ; </pre>

continued on next page

case	only the burnup in MAP	all param. in MAP
AXE (Fig. 8)	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO     TABLE CPO default 'B'     MIX 1       SET 'A' &lt;&lt;va0&gt;&gt;       SET 'C' &lt;&lt;vc0&gt;&gt;       ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;       REF 'C' &lt;&lt;vc0&gt;&gt;       'B' &lt;&lt;vb0&gt;&gt; ENDREF       ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;       REF 'A' &lt;&lt;va0&gt;&gt;       'B' &lt;&lt;vb0&gt;&gt; ENDREF     ENDMIX   ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO     TABLE CPO default 'B'     MIX 1       SET 'A' &lt;&lt;va0&gt;&gt;       SET 'C' &lt;&lt;vc0&gt;&gt;       ADD 'A' &lt;&lt;va0&gt;&gt; MAP       REF 'C' &lt;&lt;vc0&gt;&gt;       'B' &lt;&lt;vb0&gt;&gt; ENDREF       ADD 'C' &lt;&lt;vc0&gt;&gt; MAP       REF 'A' &lt;&lt;va0&gt;&gt;       'B' &lt;&lt;vb0&gt;&gt; ENDREF     ENDMIX   ; </pre>
PLANE + AXE (Fig. 11)	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO     TABLE CPO default 'B'     MIX 1       SET 'A' &lt;&lt;va0&gt;&gt;       SET 'C' &lt;&lt;vc&gt;&gt;       ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;       REF 'C' &lt;&lt;vc0&gt;&gt;       'B' &lt;&lt;vb0&gt;&gt; ENDREF     ENDMIX   ; </pre>	<pre> MACROLIB := NCR: CPO FMAP ::   NMIX 1 MACRO     TABLE CPO default 'B'     MIX 1       SET 'A' &lt;&lt;va0&gt;&gt;       ADD 'A' &lt;&lt;va0&gt;&gt; MAP       REF 'C' &lt;&lt;vc0&gt;&gt;       'B' &lt;&lt;vb0&gt;&gt; ENDREF     ENDMIX   ; </pre>

Table 60: NCR inputs for TA cases

The following pictures correspond to the previous different examples:




Figure 3: Complete grid, one point case




Figure 6: Partial grid, complete planes, TA case




Figure 4: Complete grid, TA case




Figure 7: Partial grid, complete axis, one point case




Figure 5: Partial grid, complete planes, one point case




Figure 8: Partial grid, complete axis, TA case




Figure 9: Partial grid, complete axis with another configuration, one point case




Figure 11: Partial grid, one complete plane and one complete axis, TA case




Figure 10: Partial grid, one complete plane and one complete axis, one point case




Figure 12: Partial grid, one complete plane and one complete axis with another configuration, one point case

### 4.3 The SCR: module

This component of DONJON is dedicated to the interpolation of MACROLIB data from a SAPHYB object, the reactor database produced by module SAP: in DRAGON or by module SAPHYB: in APOLLO2.<sup>[25]</sup> A set of *global parameters* are defined for each material mixture and used as multi-dimensional interpolation variables.

The calling specifications are:

Table 61: Structure (SCR:)

```
MLIB := SCR: [ { MLIB | MLIB2 } ] SAPNAM1 [[ SAPNAM2 ]] [ MAPFL ] :: (scr_data)
```

where

<i>MLIB</i>	<b>character*12</b> name of a MICROLIB (type L_LIBRARY) or MACROLIB (type L_MACROLIB) containing the interpolated data. If this object also appears on the RHS of structure (SCR:), it is open in modification mode and updated.
<i>MLIB2</i>	<b>character*12</b> name of an optional MICROLIB object whose content is copied on <i>MLIB</i> .
<i>SAPNAM1</i>	<b>character*12</b> name of the LCM object containing the SAPHYB data structure (L_SAPHYB signature).
<i>SAPNAM2</i>	<b>character*12</b> name of an additional LCM object containing an auxiliary SAPHYB data structure (L_SAPHYB signature). This object is optional.
<i>MAPFL</i>	<b>character*12</b> name of the MAP object containing fuel regions description, global parameter information (burnup, fuel/coolant temperatures, coolant density, etc). Keyword TABLE is expected in (scr_data).
<i>scr_data</i>	input data structure containing interpolation information (see Section 4.3.1).

Note: SAPHYB files generated by APOLLO2 don't have a signature. If such a SAPHYB is given as input to module SCR:, a signature must be included before using it. The following instruction can do the job:

```
Saphyb := UTL: Saphyb :: CREA SIGNATURE 3 = 'L_SA' 'PHYB' ' ' ;
```

#### 4.3.1 Interpolation data input for module SCR:

Table 62: Structure (scr\_data)

```
[ EDIT iprint ]
[ RES ] [ PURE ]
[ { MACRO | MICRO } ] [ { LINEAR | CUBIC } ] [ LEAK b2 ] [ EQUI TEXT4 ] [ MASL TEXT4 ]
[ NMIX nmixt ]
{ [[ SAPHYB SAPNAM (descints) ]] | [[ TABLE SAPNAM [ namburn ] (descints) ]] }
[ (descdepl) ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module SCR: . =0 for no print; =1 for minimum printing (default value).
RES	keyword indicating that the interpolation is done only for the microscopic cross sections and not for the isotopic densities. In this case, a RHS MICROLIB must be defined and the number densities are recovered from it. This option is useful for micro-depletion applications. <b>Important note:</b> It is possible to force interpolation of some isotopic densities with RES option if these isotopes are explicitly specified with a “*” flag after MICRO keyword in <i>descints</i> input data structure (see Section 4.3.2).
PURE	keyword indicating that the interpolation is a pure linear combination of terp factors. The fission spectra are <i>not</i> renormalized. By default, non-linear effects are produced by renormalization operations.
MACRO	keyword indicating that <i>MLIB</i> is a MACROLIB (default option).
MICRO	keyword indicating that <i>MLIB</i> is a MICROLIB. Object <i>MLIB</i> contains an embedded MACROLIB, but the CPU time required to obtain it is longer.
LINEAR	keyword indicating that interpolation of the SAPHYB uses linear Lagrange polynomials (default option).
CUBIC	keyword indicating that interpolation of the SAPHYB uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. 17.
LEAK	keyword used to introduce leakage in the embedded MACROLIB. This option should only be used for non-regression tests.
<i>b2</i>	the imposed buckling corresponding to the leakage.
EQUI	keyword used to select a SPH factor set in the Saphyb. By default, the cross sections and diffusion coefficients are not SPH-corrected.
MASL	keyword used to recover the heavy metal density in the local parameter data of the Saphyb.
<i>TEXT4</i>	character*4 user-defined keyword of the SPH factor set or heavy metal density selected in the Saphyb. These sets are stored as local parameter information in the Saphyb.
NMIX	keyword used to define the maximum number of material mixtures. This information is required only if <i>MLIB</i> is created.
<i>nmixt</i>	the maximum number of mixtures (a mixture is characterized by a distinct set of macroscopic cross sections) the MACROLIB may contain. The default value is <i>nmixt</i> = 0 or the value recovered from <i>MLIB</i> if it appears on the RHS of structure ( <b>scr_data</b> ).
SAPHYB	keyword used to set <i>SAPNAM</i> and to define each global parameter.
TABLE	keyword used to set <i>SAPNAM</i> and to recover some global parameter from a MAP object named <i>MAPFL</i> .
<i>SAPNAM</i>	<b>character*12</b> name of the LCM object containing the SAPHYB data structure where the interpolation is performed. This name must be set in the RHS of structure ( <b>SCR:</b> ).
<i>namburn</i>	name of the parameter for burnup (or irradiation). This value is defined if option TABLE is set <i>and</i> if burnup (or irradiation) is to be considered as parameter.

<i>descints</i>	input data structure containing interpolation information relative to the SAPHYB data structure named <i>SAPNAM</i> (see Section 4.3.2).
( <b>descdepl</b> )	input structure describing the depletion chain (see Section 4.5.3). This input structure requires option <b>MICRO</b> . By default, the depletion chain data is not written in the output <b>MICROLIB</b> .

#### 4.3.2 Defining global parameters

If a **MAP** object is defined on the RHS of structure (**SCR:**), and if the **TABLE** keyword is set, some information required to set the interpolation points is found in this object. In this case, the **SCR:** operator search the SAPHYB object for global parameters having an arbitrary name specified in the **MAP** object or set directly in this module. Note that any parameter's value set directly in this module prevails on a value stored in the *MAPFL* object.

Each instance of *descints* is a data structure specified as

Table 63: Structure (**descints**)

```
[[ MIX imix [ { FROM imixold | USE } ]
  [ { TIMAV-BURN | INST-BURN | AVG-EX-BURN ivarty } ]
  [[ { SET | DELTA | ADD } ] [ { LINEAR | CUBIC } ] PARKEY { val1 | MAP } [ { val2 | MAP } ]
    [ REF [[ PARKEY { valref | SAMEASREF } ]] ENDREF ] ]
  [ MICRO { ALL | ONLY } [[ HISO { conc | * } [ NOEV ] ] ]
ENDMIX ]]
```

where

<b>MIX</b>	keyword used to set <i>imix</i> . Discontinuity factor information present in the Saphyb is interpolated as mixture 1 values.
<i>imix</i>	index of the mixture that is to be created in the <b>MICROLIB</b> and <b>MACROLIB</b> .
<b>FROM</b>	keyword used to set the index of the mixture in the SAPHYB object.
<i>imixold</i>	index of the mixture that is recovered in the SAPHYB object. By default, <i>imixold</i> = 1.
<b>USE</b>	keyword used to set the index of the mixture in the SAPHYB object equal to <i>imix</i> .
<b>TIMAV-BURN</b>	keyword used to compute time-averaged cross-section information. This option is available <i>only if</i> a <i>MAPFL</i> object is set. By default, the type of calculation ( <b>TIMAV-BURN</b> or <b>INST-BURN</b> ) is recovered from the <i>MAPFL</i> object.
<b>INST-BURN</b>	keyword used to compute cross-section information at specific bundle burnups. This option is available <i>only if</i> a <i>MAPFL</i> object is set. By default, the type of calculation ( <b>TIMAV-BURN</b> or <b>INST-BURN</b> ) is recovered from the <i>MAPFL</i> object.
<b>AVG-EX-BURN</b>	keyword used to compute the derivatives of cross-section information relative to the exit burnup of a single combustion zone. The derivatives are computed using Eq. (3.3) of Ref. 16, written as

$$\frac{\partial \bar{\Sigma}_x}{\partial B_j^e} = \frac{1}{B_j^e (B_{j,k}^{\text{eoc}} - B_{j,k}^{\text{boc}})} \left[ - \int_{B_{j,k}^{\text{boc}}}^{B_{j,k}^{\text{eoc}}} dB \Sigma_x(B) + B_{j,k}^{\text{eoc}} \Sigma_x(B_{j,k}^{\text{eoc}}) - B_{j,k}^{\text{boc}} \Sigma_x(B_{j,k}^{\text{boc}}) \right]$$

where  $B_{j,k}^{\text{boc}}$ ,  $B_{j,k}^{\text{eoc}}$ , and  $B_j^{\text{e}}$  are the beginning of cycle burnup of bundle  $\{j, k\}$ , end of cycle burnup of bundle  $\{j, k\}$  and exit burnup of channel  $j$ . This option is available *only if* a *MAPFL* object is set. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the *MAPFL* object.

<i>ivarty</i>	index of the combustion zone for differentiation of cross-section information.
SET	keyword used to indicate a simple interpolation at <i>val1</i> or an averaging between <i>val1</i> and <i>val2</i> . The result $\sigma_{\text{ref}}$ is also used as the reference value when the <b>ADD</b> is used. Note: see at the ending note of this section for a detailed description and examples.
DELTA	keyword used to indicate a delta-sigma calculation between <i>val2</i> and <i>val1</i> (i.e., $\Delta\sigma_{\text{ref}} = \sigma_{\text{val2}} - \sigma_{\text{val1}}$ is computed). This keyword can be used only once in each mixture data block (initiated with a <b>MIX</b> keyword). Note: see at the ending note of this section for a detailed description and examples.
ADD	keyword used to indicate a delta-sigma calculation between <i>val2</i> and <i>val1</i> is added to the reference value (i.e., $\Delta\sigma = \sigma_{\text{val2}} - \sigma_{\text{val1}}$ is used as contribution, $\sigma_{\text{ref}} + \Delta\sigma$ or $\Delta\sigma_{\text{ref}} + \Delta\sigma$ is returned). Note: see at the ending note of this section for a detailed description and examples.
LINEAR	keyword indicating that interpolation of the SAPHYB for parameter <i>PARKEY</i> uses linear Lagrange polynomials. It is possible to set different interpolation modes to different parameters. By default, the interpolation mode is set in Sect. 4.3.1.
CUBIC	keyword indicating that interpolation of the SAPHYB for parameter <i>PARKEY</i> uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. 17. By default, the interpolation mode is set in Sect. 4.3.1.
<i>PARKEY</i>	<b>character*12</b> user-defined keyword associated to a global parameter to be set.
<i>val1</i>	value of a global parameter used to interpolate. <i>val1</i> is the initial value of this parameter in case an average is required. <i>val1</i> can be an integer, real or string value.
<i>val2</i>	value of the final global parameter. By default, a simple interpolation is performed, so that <i>val2</i> = <i>val1</i> . <i>val2</i> is always a real value with <i>val2</i> ≥ <i>val1</i> .
MAP	keyword used to indicate that the value of parameter <i>val1</i> or the second value for the $\Delta\sigma$ calculation is recovered from <i>MAPFL</i> , i.e. the <i>MAP</i> object containing fuel regions description.
REF	keyword only available together with the <b>ADD</b> option. It is used to set all the other variable values when a $\Delta$ contribution is performed for one variable.
<i>valref</i>	value of the reference parameter, when it is directly given by the user. Note that there is no default value.
SAMEASREF	keyword used to specify that the reference value will be the same as in the reference case, i.e. for the $\sigma_{\text{ref}}$ computation.
ENDREF	keyword only available together with the <b>ADD</b> option. It is used to specify that all the other variable values which are required are given.
MICRO	keyword used to set the number densities of some isotopes present in the SAPHYB object. The data statement “MICRO ALL” is used by default.
ALL	keyword to indicate that all the isotopes present in the SAPHYB object will be used in the MICROLIB and MACROLIB objects. Concentrations of these isotopes will be recovered from the SAPHYB object or set using the “ <i>HISO conc</i> ” data statement.



ONLY	keyword to indicate that only the isotopes set using the “ <i>HISO conc</i> ” data statement will be used in the MICROLIB and MACROLIB objects.
<i>HISO</i>	<b>character*8</b> name of an isotope.
<i>conc</i>	user-defined value of the number density (in $10^{24}$ particles per $\text{cm}^3$ ) of the isotope.
*	the value of the number density for isotope <i>HISO</i> is recovered from the SAPHYB object.
NOEV	keyword to force the isotope <i>HISO</i> to be non-depleting.
ENDMIX	end of specification keyword for the material mixture.

#### 4.3.3 Depletion data structure


Part of the depletion data used in the isotopic depletion calculation (the fission yields and the radioactive decay constants) is recovered from the Saphyb file. Remaining depletion data is recovered from the input data structure (**descdepl**). This data describes the heredity of the radioactive decay and the neutron activation chain.

Table 64: Structure (**descdepl**)

```
CHAIN
  [[ NAMDPL [ izaef ]
    [[ reaction [ energy ] ] ]
    [ { STABLE | FROM [[ { DECAY | reaction } [[ yield NAMPAR ] ] ] } ] ] ]
ENDCHAIN
```

with:

CHAIN	keyword to specify the beginning of the depletion chain.				
NAMDPL	<b>character*12</b> name of an isotope (or isomer) of the depletion chain that appears as a particularized isotope of the Saphyb.				
izaef	optional six digit integer representing the isotope. The first two digits represent the atomic number of the isotope; the next three indicate its mass number and the last digit indicates the excitation level of the nucleus (0 for a nucleus in its ground state, 1 for an isomer in its first excited state, etc.). For example, $^{238}\text{U}$ in its ground state will be represented by <i>izaef</i> =922380.				
reaction	<b>character*6</b> identification of a neutron-induced reaction that takes place either for production of this isotope, its depletion, or for producing energy. Example of reactions are following: <table> <tr> <td>NG</td><td>indicates that a radiative capture reaction takes place either for production of this isotope, its depletion or for producing energy.</td></tr> <tr> <td>N2N</td><td>indicates that the following reaction is taking place:</td></tr> </table>	NG	indicates that a radiative capture reaction takes place either for production of this isotope, its depletion or for producing energy.	N2N	indicates that the following reaction is taking place:
NG	indicates that a radiative capture reaction takes place either for production of this isotope, its depletion or for producing energy.				
N2N	indicates that the following reaction is taking place:				



N3N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 3n + {}^{A-2} X_Z$
N4N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 4n + {}^{A-3} X_Z$
NP	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow p + {}^A Y_{Z-1}$
NA	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow {}^4\text{He}_2 + {}^{A-3} X_{Z-2}$
NFTOT	indicates that a fission is taking place.
energy	energy (in MeV) recoverable per neutron-induced reaction of type <i>reaction</i> . If the energy associated to radiative capture is not explicitly given, it should be added to the energy released per fission. By default, <i>energy</i> =0.0 MeV.
STABLE	non depleting isotope. Such an isotope may produces energy by neutron-induced reactions (such as radiative capture).
FROM	indicates that this isotope is produced from decay or neutron-induced reactions.
DECAY	indicates that a decay reaction takes place for its production.
yield	branching ratio or production yield expressed in fraction.
NAMPAR	<b>character*12</b> name of the a parent isotope (or isomer) that appears as a particularized isotope of the Saphyb.
ENDCHAIN	keyword to specify the end of the depletion chain.

#### 4.3.4 Interpolation in the parameter grid

The following example corresponds to a delta-sigma computation in mixture 1 corresponding to a perturbation. Note that in this case, the MACROLIB object may content negative cross-section.

```
MACROLIB := SCR: SAP ::
  EDIT 40 NMIX 1 SAPHYB SAP
  MIX 1 !(* delta sigma contribution *)
        SET 'CELL' '3D'
        DELTA 'PITCH' 0.0 1.0
  ENDMIX
;
```

When the number of parameters used for the interpolation is increased, all the lattice computations corresponding to all the combinations of parameters may not be done for computation time reasons. In this case, some approximations may be required. The choice for the SET, DELTA and ADD is then dependent of the structure of the database (i.e. how the database grid of possibilities is filled). When a MAP object containing fuel regions description is used, the problem become even more complex, because values have to be automatically changed for all bundles. In order to clarify all the different possibilities

and limitations dependently of the database structure, we will use a 3 parameter case. The parameters are referenced by 'A', 'B' and 'C'. But before we explain the different cases, we want to remind that the interpolation factors are computed on each axis separately.

The first case corresponds to a complete grid, represented by a gray parallelepiped on Fig. 3 and 4. The figure 3 shows that the interpolated value in point  $V$  can be obtained directly without MAP object. For time-average (TA) computation, let's assume that the parameter 'B' represents the burnup (and keep this convention for other database structure also). In this case the figure 4 shows also that the direct interpolation can be done to compute an average value between the points  $V'$  and  $V$ . Note that the TA burnups are stored in the MAP object, and are then recovered automatically.

The second case corresponds to a partial grid where all the lattice computations have been performed for several pairs of parameters, which are represented as the gray rectangles on Fig. 5 and 6. If we use the notations of Fig. 5 and 6, the best estimate interpolated values,  $f$ , we can get are given by:

$$\begin{aligned} f &= f(V) \approx f(V_B) + (f(V_{BA}) - f(V_B)) + (f(V_{BC}) - f(V_B)) = f(V_{BC}) + (f(V_{BA}) - f(V_B)) = \\ &= f(V_{BA}) + (f(V_{BC}) - f(V_B)) \text{ for instantaneous} \\ f &= f(V', V) \approx f(V'_B, V_B) + (f(V'_{BA}, V_{BA}) - f(V'_B, V_B)) + (f(V'_{BC}, V_{BC}) - f(V'_B, V_B)) = f(V'_{BC}, V_{BC}) + \\ &+ (f(V'_{BA}, V_{BA}) - f(V'_B, V_B)) = f(V'_{BA}, V_{BA}) + (f(V'_{BC}, V_{BC}) - f(V'_B, V_B)) \text{ for TA} \end{aligned}$$

where  $f(.,.)$  represents the average value between two points.

The third case corresponds to a minimal grid, where the lattice computations have been performed only for one parameter variation at a time. In this case, the grid is represented by the thick gray lines on the axis on Fig. 7 and 8. If we use the notations of Fig. 7 and 8, the best estimate interpolated values,  $f$ , we can get are given by:

$$\begin{aligned} f &= f(V) \approx f(V_0) + (f(V_A) - f(V_0)) + (f(V_B) - f(V_0)) + (f(V_C) - f(V_0)) = f(V_B) + (f(V_A) - \\ &+ f(V_0)) + (f(V_C) - f(V_0)) \text{ for instantaneous} \\ f &= f(V', V) \approx f(V'_B, V_B) + (f(V_A) - f(V_0)) + (f(V_C) - f(V_0)) \text{ for TA} \end{aligned}$$

Note that the reference point ( $V_0$  in the example) does not have to be the same for all parameters. Database structures such as represented on Fig 9 can also be used. In this case, we even have two choices for the  $\Delta f$  computation on axis 'A'.

The last case is in fact a mix of cases 2 and 3. The gray rectangle and the gray line on Fig. 10 and 11 represent where all the lattice computations have been performed. With the notations used on those figures, one can write that the best estimate interpolated values,  $f$ , we can get are given by:

$$\begin{aligned} f &= f(V) \approx f(V_B) + (f(V_{BC}) - f(V_B)) + (f(V_A) - f(V_0)) = f(V_{BC}) + (f(V_A) - f(V_0)) \text{ for instantaneous} \\ f &= f(V', V) \approx f(V'_B, V_B) + (f(V'_{BC}, V_{BC}) - f(V'_B, V_B)) + (f(V_A) - f(V_0)) = f(V'_{BC}, V_{BC}) + (f(V_A) - \\ &+ f(V_0)) \text{ for TA} \end{aligned}$$

Note once again that the reference point ( $V_0$  in the example) does not have to be the same for all parameters. Database structures such as represented on Fig 12 can also be used.

The input files will actually reflect the previous equations. However, they are different if the parameters are stored in a MAP object, *MAPFL*, or provided directly by the user. For the case of one point interpolation (i.e. instantaneous), the input files will be:

case	all parameters explicitly set	all parameters in MAP
GRID (Fig. 3)	<pre>MACROLIB := SCR: SAP ::   NMIX 1   SAPHYB SAP   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc&gt;&gt;   ENDMIX ;</pre>	<pre>MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     ENDMIX ;</pre>
PLANE (Fig. 5)	<pre>MACROLIB := SCR: SAP ::   NMIX 1   SAPHYB SAP   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb&gt;&gt; ENDREF !or     'B' SAMEASREF ENDREF   ENDMIX ;</pre>	<pre>MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; MAP     REF 'A' &lt;&lt;va0&gt;&gt;     'B' SAMEASREF ENDREF !or SET 'A' &lt;&lt;va0&gt;&gt; !or ADD 'A' &lt;&lt;va0&gt;&gt; MAP !or REF 'C' &lt;&lt;vc0&gt;&gt; !or 'B' SAMEASREF ENDREF   ENDMIX ;</pre>
AXE (Fig. 7)	<pre>MACROLIB := SCR: SAP ::   NMIX 1   SAPHYB SAP   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF     ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ;</pre>	<pre>MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; MAP     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF     ADD 'C' &lt;&lt;vc0&gt;&gt; MAP     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ;</pre>

*continued on next page*

case	all parameters explicitly set	all parameters in MAP
PLANE + AXE (Fig. 10)	<pre> MACROLIB := SCR: SAP ::   NMIX   SAPHYB SAP   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'B' &lt;&lt;vb&gt;&gt;     SET 'C' &lt;&lt;vc&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; MAP     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>

Table 65: SCR inputs for instantaneous cases

For the TA, the burnup variable has no other choice than to be stored in the MAP object, *MAPFL*. Then the input files will be:

case	only the burnup in MAP	all parameters in MAP
GRID (Fig. 4)	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'C' &lt;&lt;vc&gt;&gt;   ENDMIX ; </pre>	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1   ENDMIX ; </pre>
PLANE (Fig. 6)	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;     REF 'A' &lt;&lt;va0&gt;&gt;     'B' SAMEASREF ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'C' &lt;&lt;vc0&gt;&gt; MAP     REF 'A' &lt;&lt;va0&gt;&gt;     'B' SAMEASREF ENDREF !or SET 'A' &lt;&lt;va0&gt;&gt; !or ADD 'A' &lt;&lt;va0&gt;&gt; MAP !or REF 'C' &lt;&lt;vc0&gt;&gt; !or 'B' SAMEASREF ENDREF   ENDMIX ; </pre>

continued on next page

case	only the burnup in MAP	all param. in MAP
AXE (Fig. 8)	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF     ADD 'C' &lt;&lt;vc0&gt;&gt; &lt;&lt;vc&gt;&gt;     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'C' &lt;&lt;vc0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; MAP     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF     ADD 'C' &lt;&lt;vc0&gt;&gt; MAP     REF 'A' &lt;&lt;va0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>
PLANE + AXE (Fig. 11)	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     SET 'C' &lt;&lt;vc&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; &lt;&lt;va&gt;&gt;     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>	<pre> MACROLIB := SCR: SAP FMAP ::   NMIX 1   TABLE SAP 'B'   MIX 1     SET 'A' &lt;&lt;va0&gt;&gt;     ADD 'A' &lt;&lt;va0&gt;&gt; MAP     REF 'C' &lt;&lt;vc0&gt;&gt;     'B' &lt;&lt;vb0&gt;&gt; ENDREF   ENDMIX ; </pre>

Table 66: SCR inputs for TA cases

#### 4.4 The ACR: module

The APOLLO2 Portable data EXchange file (APEX) contains the results obtained by a set of APOLLO2 calculation steps as well as restart data.

The APEX file is written in HDF5 format, allowing full portability and hierarchical data organization. It can be edited and modified using the HDFView tool.

This file constitutes a natural boundary between the spectral code and the downstream codes. Particularly, it contains all the data needed by the code in charge of cross-sections (XS) library generation for 3D core simulators. Each elementary calculation is characterized by a set of parameters. Parameterization allows external codes building their own XS representation by defining XS dependencies through appropriate functions or laws. For instance, standard parameters for PWR reactors are burn-up, water temperature, water density, boron concentration, xenon concentration, fuel temperature and history parameters. BWR specific parameters are instant void fraction and void history.

This component of DONJON is dedicated to the interpolation of MACROLIB data from an APEX file, the reactor database produced by APOLLO2-A.<sup>[26]</sup> A set of *global parameters* are defined for each material mixture and used as multi-dimensional interpolation variables.

The calling specifications are:

Table 67: Structure (**ACR:**)

*MLIB* := ACR: [ { *MLIB* | *MLIB2* } ] *APXNAM1* [ [ *APXNAM2* ] ] [ *MAPFL* ] :: (**scr\_data**)

where

<i>MLIB</i>	<b>character*12</b> name of a MICROLIB (type <b>L_LIBRARY</b> ) or MACROLIB (type <b>L_MACROLIB</b> ) containing the interpolated data. If this object also appears on the RHS of structure ( <b>ACR:</b> ), it is open in modification mode and updated.
<i>MLIB2</i>	<b>character*12</b> name of an optional MICROLIB object whose content is copied on <i>MLIB</i> .
<i>APXNAM1</i>	<b>character*12</b> name of the HDF5 file containing the APEX data structure.
<i>APXNAM2</i>	<b>character*12</b> name of an additional HDF5 file containing an auxiliary APEX data structure. This object is optional.
<i>MAPFL</i>	<b>character*12</b> name of the MAP object containing fuel regions description, global parameter information (burnup, fuel/coolant temperatures, coolant density, etc). Keyword <b>TABLE</b> is expected in ( <b>scr_data</b> ).
<i>scr_data</i>	input data structure containing interpolation information (see Section 4.4.1).

##### 4.4.1 Interpolation data input for module ACR:

Table 68: Structure (**scr\_data**)

[ **EDIT** *iprint* ]  
[ **RES** ] [ **PURE** ]

continued on next page

Structure (**scr\_data**)

continued from last page

```
[ { MACRO | MICRO [ TOTAL ] } ] [ { LINEAR | CUBIC } ] [ LEAK b2 ]
[ NMIX nmixt ]
{ [[ APEX APXNAM (ACRdescints) ]] | [[ TABLE APXNAM [ namburn ] (ACRdescints) ]] }
[ (descdepl) ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module ACR:. =0 for no print; =1 for minimum printing (default value).
RES	keyword indicating that the interpolation is done only for the microscopic cross sections and not for the isotopic densities. In this case, a RHS MICROLIB must be defined and the number densities are recovered from it. This option is useful for micro-depletion applications. <b>Important note:</b> It is possible to force interpolation of some isotopic densities with RES option if these isotopes are explicitly specified with a “*” flag after MICRO keyword in <i>ACRdescints</i> input data structure (see Section 4.4.2).
PURE	keyword indicating that the interpolation is a pure linear combination of terp factors. The fission spectra are <i>not</i> renormalized. By default, non-linear effects are produced by renormalization operations.
MACRO	keyword indicating that <i>MLIB</i> is a MACROLIB (default option).
MICRO	keyword indicating that <i>MLIB</i> is a MICROLIB. Object <i>MLIB</i> contains an embedded MACROLIB, but the CPU time required to obtain it is longer.
TOTAL	keyword to force using the total macroscopic set <i>xs/mac/TOTAL</i> of the Apex file. By default, the residual macroscopic set <i>xs/mac/RESIDUAL</i> is used together with microscopic cross-section information available in the <i>xs/mic/</i> group.
LINEAR	keyword indicating that interpolation of the APEX uses linear Lagrange polynomials (default option).
CUBIC	keyword indicating that interpolation of the APEX uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. 17.
LEAK	keyword used to introduce leakage in the embedded MACROLIB. This option should only be used for non-regression tests.
<i>b2</i>	the imposed buckling corresponding to the leakage.
NMIX	keyword used to define the maximum number of material mixtures. This information is required only if <i>MLIB</i> is created.
<i>nmixt</i>	the maximum number of mixtures (a mixture is characterized by a distinct set of macroscopic cross sections) the MACROLIB may contain. The default value is <i>nmixt</i> = 0 or the value recovered from <i>MLIB</i> if it appears on the RHS of structure ( <b>scr_data</b> ).
APEX	keyword used to set <i>APXNAM</i> and to define each global parameter.
TABLE	keyword used to set <i>APXNAM</i> and to recover some global parameter from a MAP object named <i>MAPFL</i> .



<i>APXNAM</i>	<b>character*12</b> name of the LCM object containing the APEX data structure where the interpolation is performed. This name must be set in the RHS of structure ( <b>ACR:</b> ).
<i>namburn</i>	name of the parameter for burnup (or irradiation). This value is defined if option <b>TABLE</b> is set <i>and</i> if burnup (or irradiation) is to be considered as parameter.
<i>ACRdescints</i>	input data structure containing interpolation information relative to the APEX data structure named <i>APXNAM</i> (see Section 4.4.2).
( <b>descdepl</b> )	input structure describing the depletion chain (see Section 4.4.3). This input structure requires option <b>MICRO</b> . By default, the depletion chain data is not written in the output <b>MICROLIB</b> .

#### 4.4.2 Defining global parameters

If a **MAP** object is defined on the RHS of structure (**ACR:**), and if the **TABLE** keyword is set, some information required to set the interpolation points is found in this object. In this case, the **ACR:** operator search the APEX file for global parameters having an arbitrary name specified in the **MAP** object or set directly in this module. Note that any parameter's value set directly in this module prevails on a value stored in the *MAPFL* object.

Each instance of *ACRdescints* is a data structure specified as

Table 69: Structure (**ACRdescints**)

```
[[ MIX imix [ { FROM imixold | USE } ]
  [ { TIMAV-BURN | INST-BURN | AVG-EX-BURN ivarty } ]
  [[ { SET | DELTA | ADD } ] [ { LINEAR | CUBIC } ] PARKEY { val1 | MAP } [ { val2 | MAP } ]
    [ REF [[ PARKEY { valref | SAMEASREF } ]] ENDREF ] ] ]
  [ MICRO { ALL | ONLY } [[ HISO { conc | * } [ NOEV ] ] ] ]
ENDMIX ]]
```

where

<b>MIX</b>	keyword used to set <i>imix</i> .
<i>imix</i>	index of the mixture that is to be created in the <b>MICROLIB</b> and <b>MACROLIB</b> .
<b>FROM</b>	keyword used to set the index of the mixture in the APEX file.
<i>imixold</i>	index of the mixture that is recovered in the APEX file. By default, <i>imixold</i> = 1.
<b>USE</b>	keyword used to set the index of the mixture in the APEX file equal to <i>imix</i> .
<b>TIMAV-BURN</b>	keyword used to compute time-averaged cross-section information. This option is available <i>only if</i> a <i>MAPFL</i> object is set. By default, the type of calculation ( <b>TIMAV-BURN</b> or <b>INST-BURN</b> ) is recovered from the <i>MAPFL</i> object.
<b>INST-BURN</b>	keyword used to compute cross-section information at specific bundle burnups. This option is available <i>only if</i> a <i>MAPFL</i> object is set. By default, the type of calculation ( <b>TIMAV-BURN</b> or <b>INST-BURN</b> ) is recovered from the <i>MAPFL</i> object.

**AVG-EX-BURN** keyword used to compute the derivatives of cross-section information relative to the exit burnup of a single combustion zone. The derivatives are computed using Eq. (3.3) of Ref. 16, written as

$$\frac{\partial \bar{\Sigma}_x}{\partial B_j^e} = \frac{1}{B_j^e (B_{j,k}^{\text{eoc}} - B_{j,k}^{\text{boc}})} \left[ - \int_{B_{j,k}^{\text{boc}}}^{B_{j,k}^{\text{eoc}}} dB \Sigma_x(B) + B_{j,k}^{\text{eoc}} \Sigma_x(B_{j,k}^{\text{eoc}}) - B_{j,k}^{\text{boc}} \Sigma_x(B_{j,k}^{\text{boc}}) \right]$$

where  $B_{j,k}^{\text{boc}}$ ,  $B_{j,k}^{\text{eoc}}$ , and  $B_j^e$  are the beginning of cycle burnup of bundle  $\{j,k\}$ , end of cycle burnup of bundle  $\{j,k\}$  and exit burnup of channel  $j$ . This option is available *only if a MAPFL object is set*. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the MAPFL object.

<b>ivarty</b>	index of the combustion zone for differentiation of cross-section information.
<b>SET</b>	keyword used to indicate a simple interpolation at <i>val1</i> or an averaging between <i>val1</i> and <i>val2</i> . The result $\sigma_{\text{ref}}$ is also used as the reference value when the <b>ADD</b> is used. Note: see at the ending note of this section for a detailed description and examples.
<b>DELTA</b>	keyword used to indicate a delta-sigma calculation between <i>val2</i> and <i>val1</i> (i.e., $\Delta\sigma_{\text{ref}} = \sigma_{\text{val2}} - \sigma_{\text{val1}}$ is computed). This keyword can be used only once in each mixture data block (initiated with a <b>MIX</b> keyword). Note: see at the ending note of this section for a detailed description and examples.
<b>ADD</b>	keyword used to indicate a delta-sigma calculation between <i>val2</i> and <i>val1</i> is added to the reference value (i.e., $\Delta\sigma = \sigma_{\text{val2}} - \sigma_{\text{val1}}$ is used as contribution, $\sigma_{\text{ref}} + \Delta\sigma$ or $\Delta\sigma_{\text{ref}} + \Delta\sigma$ is returned). Note: see at the ending note of this section for a detailed description and examples.
<b>LINEAR</b>	keyword indicating that interpolation of the APEX for parameter <i>PARKEY</i> uses linear Lagrange polynomials. It is possible to set different interpolation modes to different parameters. By default, the interpolation mode is set in Sect. 4.4.1.
<b>CUBIC</b>	keyword indicating that interpolation of the APEX for parameter <i>PARKEY</i> uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. 17. By default, the interpolation mode is set in Sect. 4.4.1.
<b>PARKEY</b>	<b>character*12</b> user-defined keyword associated to a global parameter to be set.
<i>val1</i>	value of a global parameter used to interpolate. <i>val1</i> is the initial value of this parameter in case an average is required. <i>val1</i> can be an integer, real or string value.
<i>val2</i>	value of the final global parameter. By default, a simple interpolation is performed, so that <i>val2</i> = <i>val1</i> . <i>val2</i> is always a real value with <i>val2</i> ≥ <i>val1</i> .
<b>MAP</b>	keyword used to indicate that the value of parameter <i>val1</i> or the second value for the $\Delta\sigma$ calculation is recovered from <i>MAPFL</i> , i.e. the MAP object containing fuel regions description.
<b>REF</b>	keyword only available together with the <b>ADD</b> option. It is used to set all the other variable values when a $\Delta$ contribution is performed for one variable.
<i>valref</i>	value of the reference parameter, when it is directly given by the user. Note that there is no default value.
<b>SAMEASREF</b>	keyword used to specify that the reference value will be the same as in the reference case, i.e. for the $\sigma_{\text{ref}}$ computation.

ENDREF	keyword only available together with the ADD option. It is used to specify that all the other variable values which are required are given.
MICRO	keyword used to set the number densities of some isotopes present in the APEX file. The data statement “MICRO ALL” is used by default.
ALL	keyword to indicate that all the isotopes present in the APEX file will be used in the MICROLIB and MACROLIB objects. Concentrations of these isotopes will be recovered from the APEX file or set using the “ <i>HISO conc</i> ” data statement.
ONLY	keyword to indicate that only the isotopes set using the “ <i>HISO conc</i> ” data statement will be used in the MICROLIB and MACROLIB objects.
<i>HISO</i>	<b>character*8</b> name of an isotope.
<i>conc</i>	user-defined value of the number density (in $10^{24}$ particles per $\text{cm}^3$ ) of the isotope.
*	the value of the number density for isotope <i>HISO</i> is recovered from the APEX file.
NOEV	keyword to force the isotope <i>HISO</i> to be non-depleting.
ENDMIX	end of specification keyword for the material mixture.

#### 4.4.3 Depletion data structure

Part of the depletion data used in the isotopic depletion calculation (the fission yields and the radioactive decay constants) is recovered from the Apex file. Remaining depletion data is recovered from the input data structure (**descdepl**). This data describes the heredity of the radioactive decay and the neutron activation chain.

Table 70: Structure (**descdepl**)

```
CHAIN
  [[ NAMDPL [ izae ]
    [[ reaction [ energy ] ]]
    [ { STABLE | FROM [[ { DECAY | reaction } [[ yield NAMPAR ]] ] ] } ] ] ]
ENDCHAIN
```

with:

CHAIN	keyword to specify the beginning of the depletion chain.
NAMDPL	<b>character*12</b> name of an isotope (or isomer) of the depletion chain that appears as a particularized isotope of the Apex file.
<i>izae</i>	optional six digit integer representing the isotope. The first two digits represent the atomic number of the isotope; the next three indicate its mass number and the last digit indicates the excitation level of the nucleus (0 for a nucleus in its ground state, 1 for an isomer in its first excited state, etc.). For example, $^{238}\text{U}$ in its ground state will be represented by <i>izae</i> =922380.

<i>reaction</i>	<b>character*6</b> identification of a neutron-induced reaction that takes place either for production of this isotope, its depletion, or for producing energy. Example of reactions are following:
NG	indicates that a radiative capture reaction takes place either for production of this isotope, its depletion or for producing energy.
N2N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 2n + {}^{A-1} X_Z$
N3N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 3n + {}^{A-2} X_Z$
N4N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 4n + {}^{A-3} X_Z$
NP	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow p + {}^A Y_{Z-1}$
NA	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow {}^4\text{He}_2 + {}^{A-3} X_{Z-2}$
NFTOT	indicates that a fission is taking place.
<i>energy</i>	energy (in MeV) recoverable per neutron-induced reaction of type <i>reaction</i> . If the energy associated to radiative capture is not explicitly given, it should be added to the energy released per fission. By default, <i>energy</i> =0.0 MeV.
STABLE	non depleting isotope. Such an isotope may produces energy by neutron-induced reactions (such as radiative capture).
FROM	indicates that this isotope is produced from decay or neutron-induced reactions.
DECAY	indicates that a decay reaction takes place for its production.
<i>yield</i>	branching ratio or production yield expressed in fraction.
NAMPAR	<b>character*12</b> name of the a parent isotope (or isomer) that appears as a particularized isotope of the Apex file.
ENDCHAIN	keyword to specify the end of the depletion chain.

#### 4.4.4 Interpolation in the parameter grid

The following example corresponds to a delta-sigma computation in mixture 1 corresponding to a perturbation. Note that in this case, the MACROLIB object may content negative cross-section.

```
MACROLIB := ACR: APEXFILE ::
  EDIT 40 NMIX 1 APEX APEXFILE
  MIX 1 !(* delta sigma contribution *)
        SET 'CELL' '3D'
        DELTA 'PITCH' 0.0 1.0
  ENDMIX
;
```

#### 4.5 The PCR: module

This component of DONJON is dedicated to the interpolation of MICROLIB and MACROLIB data from a PMAXS file, the reactor database produced by the GenPMAXS utility.<sup>[52]</sup> A set of *parameters* are defined for each material mixture and used as multi-dimensional interpolation variables.

The calling specifications are:

Table 71: Structure (**PCR:**)

```
MLIB := PCR: [ { MLIB | MLIB2 } ] PMAX1 [[ PMAX2 ]] [ MAPFL ] :: (PCR_data)
```

where

<i>MLIB</i>	<b>character*12</b> name of a MICROLIB (type <b>L_LIBRARY</b> ) or MACROLIB (type <b>L_MACROLIB</b> ) containing the interpolated data. If this object also appears on the RHS of structure ( <b>PCR:</b> ), it is open in modification mode and updated.
<i>MLIB2</i>	<b>character*12</b> name of an optional MICROLIB object whose content is copied on <i>MLIB</i> .
<i>PMAX1</i>	<b>character*12</b> name of the PMAXS file.
<i>PMAX2</i>	<b>character*12</b> name of an additional PMAXS file. This file is optional.
<i>MAPFL</i>	<b>character*12</b> name of the MAP object containing fuel regions description, parameter information (burnup, fuel/coolant temperatures, coolant density, etc). Keyword <b>TABLE</b> is expected in ( <b>PCR_data</b> ).
<i>PCR_data</i>	input data structure containing interpolation information (see Section 4.5.1).

##### 4.5.1 Interpolation data input for module PCR:

Table 72: Structure (**PCR\_data**)

```
[ EDIT iprint ]
[ { MACRO | MICRO } ] [ { LINEAR | CUBIC } ] [ LEAK b2 ]
[ NMIX nmixt ]
{ [[ PMAXS PMAX (descintf) ]]
  | [[ TABLE PMAX (descintf) ]] }
[ (descdepl) ]
;
```

where

<b>EDIT</b>	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module PCR:. =0 for no print; =1 for minimum

	printing (default value).
MACRO	keyword indicating that <i>MLIB</i> is a MACROLIB (default option).
MICRO	keyword indicating that <i>MLIB</i> is a MICROLIB. Object <i>MLIB</i> contains an embedded MACROLIB, but the CPU time required to obtain it is longer.
LINEAR	keyword indicating that interpolation of the PMAXS file uses linear Lagrange polynomials (default option).
CUBIC	keyword indicating that interpolation of the PMAXS file uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. [17].
LEAK	keyword used to introduce leakage in the embedded MACROLIB. This option should only be used for non-regression tests.
<i>b2</i>	the imposed buckling corresponding to the leakage.
NMIX	keyword used to define the maximum number of material mixtures. This information is required only if <i>MLIB</i> is created.
<i>nmixt</i>	the maximum number of mixtures (a mixture is characterized by a distinct set of macroscopic cross sections) the MACROLIB may contain. The default value is <i>nmixt</i> = 0 or the value recovered from <i>MLIB</i> if it appears on the RHS of structure <b>(PCR:)</b> .
PMAXS	keyword used to set <i>PMAX</i> and to define each parameter.
TABLE	keyword used to set <i>PMAX</i> and to recover some parameter from a MAP object named <i>MAPFL</i> .
<i>PMAX</i>	<b>character*12</b> name of the PMAXS file where the interpolation is performed. This name must be set in the RHS of structure <b>(PCR:)</b> .
<i>descintf</i>	input data structure containing interpolation information relative to the PMAXS file named <i>PMAX</i> (see Section 4.5.2).
<b>(descdepl)</b>	input structure describing the depletion chain (see Section 4.5.3). This input structure requires option MICRO. By default, the depletion chain data is not written in the output MICROLIB.

#### 4.5.2 Defining parameters

If a MAP object is defined on the RHS of structure **(PCR:)**, and if the TABLE keyword is set, some information required to set the interpolation points is found in this object. In this case, the PCR: operator search the PMAXS file for parameters having an arbitrary name specified in the MAP object or set directly in this module. Note that any parameter's value set directly in this module prevails on a value stored in the *MAPFL* object.

Each instance of *descintf* is a data structure specified as

Table 73: Structure **(descintf)**

[[ MIX *imix*

continued on next page

Structure (**descintf**)

continued from last page

```

[ { TIMAV-BURN | INST-BURN | AVG-EX-BURN ivarty } ]
[[ { SET | DELTA | ADD } ] [ { LINEAR | CUBIC } ] PARKEY { val1 | MAP } [ { val2 | MAP } ]
  [ REF [[ PARKEY { valref | SAMEASREF } ]] ENDREF ] ]]
[ MICRO [[ HISO conc ]] ]
ENDMIX ]]

```

where

MIX keyword used to set *imix*.*imix* index of the mixture that is to be created in the MICROLIB and MACROLIB.TIMAV-BURN keyword used to compute time-averaged cross-section information. This option is available *only if* a *MAPFL* object is set. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the *MAPFL* object.INST-BURN keyword used to compute cross-section information at specific bundle burnups. This option is available *only if* a *MAPFL* object is set. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the *MAPFL* object.

AVG-EX-BURN keyword used to compute the derivatives of cross-section information relative to the exit burnup of a single combustion zone. The derivatives are computed using Eq. (3.3) of Ref. [16], written as

$$\frac{\partial \bar{\Sigma}_x}{\partial B_j^e} = \frac{1}{B_j^e (B_{j,k}^{\text{eoc}} - B_{j,k}^{\text{boc}})} \left[ - \int_{B_{j,k}^{\text{boc}}}^{B_{j,k}^{\text{eoc}}} dB \Sigma_x(B) + B_{j,k}^{\text{eoc}} \Sigma_x(B_{j,k}^{\text{eoc}}) - B_{j,k}^{\text{boc}} \Sigma_x(B_{j,k}^{\text{boc}}) \right]$$

where  $B_{j,k}^{\text{boc}}$ ,  $B_{j,k}^{\text{eoc}}$ , and  $B_j^e$  are the beginning of cycle burnup of bundle  $\{j, k\}$ , end of cycle burnup of bundle  $\{j, k\}$  and exit burnup of channel  $j$ . This option is available *only if* a *MAPFL* object is set. By default, the type of calculation (TIMAV-BURN or INST-BURN) is recovered from the *MAPFL* object.

*ivarty* index of the combustion zone for differentiation of cross-section information.SET keyword used to indicate a simple interpolation at *val1* or an averaging between *val1* and *val2*. The result  $\sigma_{\text{ref}}$  is also used as the reference value when the ADD is used. Note: see at the ending note of this section for a detailed description and examples.DELTA keyword used to indicate a delta-sigma calculation between *val2* and *val1* (i.e.,  $\Delta\sigma_{\text{ref}} = \sigma_{\text{val2}} - \sigma_{\text{val1}}$  is computed). This keyword can be used only once in each mixture data block (initiated with a MIX keyword). Note: see at the ending note of this section for a detailed description and examples.ADD keyword used to indicate a delta-sigma calculation between *val2* and *val1* is added to the reference value (i.e.,  $\Delta\sigma = \sigma_{\text{val2}} - \sigma_{\text{val1}}$  is used as contribution,  $\sigma_{\text{ref}} + \Delta\sigma$  or  $\Delta\sigma_{\text{ref}} + \Delta\sigma$  is returned). Note: see at the ending note of this section for a detailed description and examples.LINEAR keyword indicating that interpolation of the PMAXS file for parameter *PARKEY* uses linear Lagrange polynomials. It is possible to set different interpolation modes to different parameters. By default, the interpolation mode is set in Sect. 4.5.1.

CUBIC	keyword indicating that interpolation of the PMAXS file for parameter <i>PARKEY</i> uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. [17]. By default, the interpolation mode is set in Sect. 4.5.1.
<i>PARKEY</i>	<b>character*12</b> user-defined keyword associated to a parameter to be set.
<i>val1</i>	value of a parameter used to interpolate. <i>val1</i> is the initial value of this parameter in case an average is required. <i>val1</i> can be an integer, real or string value.
<i>val2</i>	value of the final parameter. By default, a simple interpolation is performed, so that <i>val2=val1</i> . <i>val2</i> is always a real value with <i>val2</i> $\geq$ <i>val1</i> .
MAP	keyword used to indicate that the value of parameter <i>val1</i> or the second value for the $\Delta\sigma$ calculation is recovered from <i>MAPFL</i> , i.e. the MAP object containing fuel regions description.
REF	keyword only available together with the ADD option. It is used to set all the other variable values when a $\Delta$ contribution is performed for one variable.
<i>valref</i>	value of the reference parameter, when it is directly given by the user. Note that there is no default value.
SAMEASREF	keyword used to specify that the reference value will be the same as in the reference case, i.e. for the $\sigma_{\text{ref}}$ computation.
ENDREF	keyword only available together with the ADD option. It is used to specify that all the other variable values which are required are given.
MICRO	keyword used to set the number densities of some isotopes present in the PMAXS file.
<i>HISO</i>	<b>character*8</b> name of an isotope (namely 'Xe135' or 'Sm149').
<i>conc</i>	user-defined value of the number density (in $10^{24}$ particles per $\text{cm}^3$ ) of the isotope.
ENDMIX	end of specification keyword for the material mixture.

#### 4.5.3 Depletion data structure

Depletion data is recovered from the input data structure (**descdepl**). This data describes the heredity of the radioactive decay and the neutron activation chain.

Table 74: Structure (**descdepl**)

```
CHAIN nel
  [[ NAMDPL [ ize ]
    [[ { DECAY dcr | reaction [ energy ] } ] ]
    [ { STABLE | FROM [[ { DECAY | reaction } [[ yield NAMPAR ] ] ] } ] ] ]
ENDCHAIN
```

with:

CHAIN        keyword to specify the beginning of the depletion chain.



<i>nel</i>	number of depleting isotopes in the chain.
<i>NAMDPL</i>	<b>character*12</b> name of an isotope (or isomer) of the depletion chain that appears as a particularized isotope of the PMAXS file.
<i>izae</i>	optional six digit integer representing the isotope. The first two digits represent the atomic number of the isotope; the next three indicate its mass number and the last digit indicates the excitation level of the nucleus (0 for a nucleus in its ground state, 1 for an isomer in its first excited state, etc.). For example, $^{238}\text{U}$ in its ground state will be represented by <i>izae</i> =922380.
DECAY	indicates that a decay reaction takes place either for production of this isotope or its depletion.
<i>dcr</i>	radioactive decay constant (in $10^{-8} \text{ s}^{-1}$ ) of the isotope. By default, <i>dcr</i> =0.0.
<i>reaction</i>	<b>character*6</b> identification of a neutron-induced reaction that takes place either for production of this isotope, its depletion, or for producing energy. Example of reactions are following:
NG	indicates that a radiative capture reaction takes place either for production of this isotope, its depletion or for producing energy.
N2N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 2n + {}^{A-1} X_Z$
N3N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 3n + {}^{A-2} X_Z$
N4N	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow 4n + {}^{A-3} X_Z$
NP	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow p + {}^A Y_{Z-1}$
NA	indicates that the following reaction is taking place:
	$n + {}^A X_Z \rightarrow {}^4\text{He}_2 + {}^{A-3} X_{Z-2}$
NFTOT	indicates that a fission is taking place.
<i>energy</i>	energy (in MeV) recoverable per neutron-induced reaction of type <i>reaction</i> . If the energy associated to radiative capture is not explicitly given, it should be added to the energy released per fission. By default, <i>energy</i> =0.0 MeV.
STABLE	non depleting isotope. Such an isotope may produces energy by neutron-induced reactions (such as radiative capture).
FROM	indicates that this isotope is produced from decay or neutron-induced reactions.
DECAY	indicates that a decay reaction takes place for its production.
<i>yield</i>	branching ratio or production yield expressed in fraction.
<i>NAMPAR</i>	<b>character*12</b> name of the a parent isotope (or isomer) that appears as a particularized isotope of the PMAXS file.
ENDCHAIN	keyword to specify the end of the depletion chain.

#### 4.6 The AFM: module

The AFM: module is used to create an extended MACROLIB containing set of interpolated nuclear properties from a feedback model database.<sup>[21]</sup> The DATABASE information are obtained by previous DRAGON calculations using module CFC:.<sup>[18]</sup>

There are two possible utilizations:

- Construction of an extended MACROLIB for fuel properties directly from DATABASE information with respect to local parameters contained in the fuel map object or directly input.
- Construction of an extended MACROLIB containing only one set of cross sections derivated from the DATABASE information. Properties can be obtained for fuel or reflector.

The calling specifications are:

Table 75: Structure AFM:

*MACRO* := AFM: [ *MACRO* ] *DBASE* [ *MAPFL* ] :: (**descafm**)

where

<i>MACRO</i>	<b>character*12</b> name of the extended MACROLIB. The MACROLIB can be in modification mode.
<i>DBASE</i>	<b>character*12</b> name of the DATABASE object containing fuel properties with respect to local parameters.
<i>MAPFL</i>	<b>character*12</b> name of the MAP object containing fuel regions description and burnup informations. This file is only required when a <i>MACRO</i> is created for fuel area.
<b>(descafm)</b>	structure containing the data to module AFM:.

##### 4.6.1 Input data to the AFM: module

Table 76: Structure (**descafm**)

```
{ MAP | MCR mmix } INFOR NAMDB
DNAME ntyp ( NAMTYP(i), i=1,ntyp )
REFT ( imix(i) NAMTYP(i), i=1,ntyp )
[ EDIT iprint ]
[ FIXP { INIT | pow } ]
[ { PWF | NPWF } ]
[ TFUEL tfuel ]
[ TCOOL tcool ]
[ TMOD tmod ]
```

continued on next page

Structure (**descaf**m)

continued from last page

```

[ BORON nB ]
[ RDCL dcool ]
[ RDMD dmod ]
[ PUR purity ]
[ BURN bval ]
[ { XENON nXe | XEREF } ]
[ { NEP nNp | NREF } ]
[ SAM nSm ]
[ IMET imet ]
[ BLIN ]
;

```

where

MAP	keyword to specify that a MACROLIB for fuel properties will be computed.
MCR	keyword to specify that a MACROLIB containing only one non-zero mixture will be created.
<i>mmix</i>	maximum number of mixtures in the MACROLIB.
INFOR	keyword to specify the data base name.
NAMDB	<b>character*72</b> title of the database as it has been created.
DNAME	keyword to specify the number of fuel types and their names as stored in the data base.
<i>ntyp</i>	number of fuel types. For MCR option, <i>ntyp</i> must be 1.
NAMTYP(i)	<b>character*12</b> name of the directory where each fuel type information has been stored.
REFT	keyword to specify a number associated with a fuel type name.
<i>imix</i> (i)	fuel type index as specified for the fuel map or a non-zero mixture number for the single-property sc macrolib.
EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module AFM: . =0 for no print(default value); =1 for minimum printing; larger values produce increasing amounts of output.
FIXP	keyword used to set the power used for cross-section interpolation.
INIT	a distributed beginning-of-transient bundle power in kW is used. This power distribution has to be pre-calculated in the FLPOW: module using the INIT keyword.
<i>pow</i>	uniform bundle power in kW. If this data is omitted, the reference value in the data base is used or the bundle powers present in a MAP. The reference value is 615 kW if none were provided at the database computation time.
PWF	keyword used to activate power bundle feedback on fuel properties using powers recovered from 'BUND-PW' record in MAPFL. This is the default option if MAP is selected.
NPWF	keyword used to deactivate PWF feedback. This is the only possible option if MCR is selected.

TFUEL	keyword used to set <i>tfuel</i> .
<i>tfuel</i>	fuel temperature in K. If this data is omitted and the bundle powers present in a MAP, fuel temperatures are computed with respect to powers. If this data is omitted and there is no bundle power, the reference value in the data base is used, where it is 941.29 K if none were provided at the database computation time.
TCOOL	keyword used to set <i>tcool</i> .
<i>tcool</i>	coolant temperature in K. If this data is omitted, the reference value in the data base is used. The reference value is 560.66 K if none were provided at the database computation time.
TMOD	keyword used to set <i>tmod</i> .
<i>tmod</i>	moderator temperature in K. If this data is omitted, the reference value in the data base is used. The reference value is 345.66 K if none were provided at the database computation time.
BORON	keyword used to set <i>nB</i> .
<i>nB</i>	Boron concentration in ppm. If this data is omitted, the reference value in the data base is used. The reference value is 0.0 ppm. See note below for inside equations.
RDCL	keyword used to set <i>dcool</i> .
<i>dcool</i>	coolant density in $g/cm^3$ . If this data is omitted, the reference value in the data base is used. The reference value is $0.81212 g/cm^3$ if none were provided at the database computation time.
RDMD	keyword used to set <i>dmod</i> .
<i>dmod</i>	moderator density in $g/cm^3$ . If this data is omitted, the reference value in the data base is used. The reference value is $1.082885 g/cm^3$ if none were provided at the database computation time.
PUR	keyword used to set <i>purity</i> .
<i>purity</i>	moderator purity in atm%. If this data is omitted, the reference value in the data base is used. The reference value is 99.911 atm% if none were provided at the database computation time.
BURN	keyword used to set <i>bval</i> . This option is valid only when MCR is used and can not be omitted.
<i>bval</i>	fuel burnup in MWd/t. This value must be positive.
XENON	keyword used to set <i>nXe</i> .
<i>nXe</i>	Xenon concentration in $10^{24}at/cm^3$ . This concentration will be applied to every bundle.
XEREF	keyword used to specify that the Xenon concentrations as computed with DRAGON will be taken. If this option is omitted and MAP contains bundle fluxes, new Xenon concentrations will be computed and used.
NEP	keyword used to set <i>nNp</i> .
<i>nNp</i>	Neptunium concentration in $10^{24}at/cm^3$ .

XEREF	keyword used to specify that the Neptunium concentrations as computed with DRAGON will be taken. If this option is omitted and MAP contains bundle fluxes, new Neptunium concentrations will be computed and used.
SAM	keyword used to set $nSm$ .
$nSm$	Samarium concentration in $10^{24}at/cm^3$ . If this data is omitted, bundle concentrations as computed by DRAGON is used.
IMET	keyword used to set $imet$ .
$imet$	interpolation type for time-average calculations. $imet = 1$ : using Lagrange approximations; $imet = 2$ : using spline approximations; $imet = 3$ : using Hermite approximations (default value).
BLIN	keyword used to linear interpolation for burnup instead of the Lagrangian interpolation method.

Note: The concentration of boron is provided in terms of  $10^{24}at/cm^3$  in the database. However, the usual units are  $ppm(wt)$  of Boron. Thus, the input asks for  $ppm$  of Boron ( $n_B$ ), and automatically transform the units into  $10^{24}at/cm^3$  using the following equations:

$$\begin{aligned}
 \rho_B(g/cm^3) &= n_B \cdot \rho_{water}(g/cm^3) \\
 \text{and} \\
 \rho_{water}(at/cm^3) &= 3\rho_{water}(molecule/cm^3) = \frac{3 \cdot N}{M_{water}} \rho_{water}(g/cm^3) \\
 \rho_B(at/cm^3) &= \rho_B(molecule/cm^3) = \frac{N}{M_B} \rho(g/cm^3) \\
 \text{thus} \\
 \rho_B(10^{24}at/cm^3) &= n_B \cdot \frac{M_{water}}{3 \cdot M_B} \rho_{water}(10^{24}at/cm^3)
 \end{aligned}$$

where  $M$  molar mass and  $N$  the Avogadro number.

They are many options on how to use the module AFM: for its different purposes. A compact summary is presented on Tab. 77.

The Rozon correlation for fuel temperature as a function of bundle power is:

$$T_{fuel} = T_{cool} + 0.476 P + 2.267 P^2 \times 10^{-4}$$

where  $P$  is in kW and temperatures are in Kelvin.

Table 77: AFM options summary

Option	Keywords	Parameter values
MCR	REFT REFT + {TFUEL, TCOOL, ...}	Nominal values Nominal values except for specified parameters
TAB	REFT  REFT + {TFUEL, TCOOL, ...}	Nominal values except for TFUEL parameter which is computed according to the Rozon cor- relation using nominal power Same as above except for specified parameters which will have a constant value
MAP with local parameters	REFT  REFT + {TFUEL, TCOOL, ...}	Nominal values except for local parameters in- cluded in MAP Same as above except for specified parameters which will have a constant value
MAP without local parame- ters	REFT  REFT + {TFUEL, TCOOL, ...}	Nominal values except for TFUEL parameter which is computed according to the Rozon cor- relation if power distribution is available Same as above except for specified parameters which will have a constant value

#### 4.7 The T16CP0: module

The WIMS-AECL **Tape16** file is a FORTRAN sequential binary file which is used to transfer the results of a WIMS-AECL calculation to other applications.<sup>[27]</sup> The explicit contents of this file may vary from application to application since the output of most records to this file is controlled by the user who can activate specific keywords in the WIMS-AECL input file.

The standard CPO data structure used by the code DONJON is generally generated by the cell code DRAGON. This data structure can be stored on a FORTRAN direct access binary file in the form of a hierarchical data base. There is also the possibility to keep the contents of this data structure in memory (with the same hierarchical structure) for faster access. The structure of the data base is in the form of a list of material directories which contain burnup sub-directories. Inside each of these burnup sub-directories the isotopic contents of a mixture is described and the multigroup cross sections associated with a specific isotope are stored in individual sub-directories. Note that in this database the macroscopic cross sections associated with a mixture are stored in a default isotopic sub-directory.

The interface between the **Tape16** file and the CPO data structure should be written as a new module of the code DONJON in order to facilitate the access to the GANLIB utilities which manage the hierarchical data structures. This module will be called **T16CP0:**. The transfer of information from a **Tape16** format file to a CPO data structure will require the following DONJON instructions:

The **T16CP0:** module specifications for creating or updating a CPO data structure from a **Tape16** file are:

Table 78: Structure T16CP0:

```
DONCPO := T16CP0: [ DONCPO ] WIMS16 :: (desct16cpo) ;
```

where

DONCPO	name of data structure where the output CPO is stored. This can be a new data structure or an old data structure which will be updated.
(desct16cpo)	input specifications for the execution of the T16CP0: module.
;	end of record keyword. This keyword is used to delimit the part of the input data stream associated the current module.

In the following dataset

```
MODULE T16CP0: ;
SEQ_BINARY WIMS16 ;
LINKED_LIST DONCPO ;

DONCPO := T16CP0: WIMS16 ::
...
;
```

means that that the module will read the sequential binary file WIMS16 file (in readonly mode) and create the CPO data structure DONCPO while the dataset

```
MODULE T16CP0: ;
SEQ_BINARY WIMS16 ;
LINKED_LIST DONCPO ;
```

```

DONCPO := T16CPO: DONCPO WIMS16 ::
...
;

```

means that the data structure DONCPO will be updated. The input instructions (replaced by ... here) should indicate what part of the information located on WIMS16 should be transferred to DONCPO and in what order.

#### 4.7.1 Input data for the T16CPO: module

The input data structure (**desct16cpo**) will take the form:

Table 79: Structure (**desct16cpo**)

```

[ EDIT iprint ]
[ NMIX nmixt ]
[ CONDG ngcond (igc(i) , i=1,ngcond ) ]
[ LIST ]
[ MIX [[ MIXNAM [ { CELLAV | REGION noreg } ]
      [ RC [ nburn ] fstrec ]
      [[ NAMPER valref npert (valper(i), fstrec(i) , i=1,npert ) ]]
      [ MTMD [ valleft valrefd ] npert (valpert(i), valperd(i), fstrec(i) , i=1,npert ) ]
      ]] ]

```

where

EDIT	optional keyword used to modify the print level <i>iprint</i> .
<i>iprint</i>	index used to control the printing in this module. It must be set to 0 if no printing on the output file is required while values <10 will print general information about each record requested on Tape16 as well as other generic information pertinent to the T16CPO: module. Finally for values of <i>iprint</i> ≥ 10, additional information required for debugging will be printed. The default value is <i>iprint</i> =1.
NMIX	optional keyword used to define the number of mixtures created on the CPO data structure.
<i>nmixt</i>	the maximum number of mixtures created. The default value is <i>nmixt</i> =1.
CONDG	optional keyword used to define the group structure for condensation. In the case where the CPO is to be updated, the information following CONDG must yield an energy group structure compatible with that already available on this data structure. If it is absent, the code will first try to use the CPO group structure (if available). Then, it will try to use the editing group structure corresponding to NGREAC on the following Tape16 record:

REACTION<sub>UU</sub>, FLUX<sub>UUUUUU</sub>, NEL

Finally, if everything else fails, it will select the main transport group structure corresponding to NGMTR on the following Tape16 record:



WIMS<sub>UUUUUU</sub>, CONSTANT<sub>UU</sub>, NEL

<i>ngcond</i>	the number of condensed groups required.
<i>ilg</i>	the last group number associated with each condensed group.
LIST	keyword to specify that the complete contents of <b>Tape16</b> must be listed on the output file.
MIX	keyword to specify that the remaining information will be associated with mixture properties definition.
MIXNAM	<b>character*6</b> name of the mixture to create or update on the CPO.
CELLAV	optional keyword to specify that cell averaged data will be taken from <b>Tape16</b> . This is the default option.
REGION	optional keyword to specify that regional data will be taken from <b>Tape16</b> . The default option is <b>CELLAV</b> .
<i>noreg</i>	region number associated with this material in <b>Tape16</b> .
RC	optional keyword to specify that the cross section taken from <b>Tape16</b> are at reference value. This information must be defined at least once for each mixture. It must also precede the definition of perturbation parameters.
<i>nburn</i>	number of consecutive burnup steps associated with mixture. The default value is <i>nburn</i> =1. We will assume that the same number of burnup steps is also available for the nuclear properties associated with the perturbed local parameters.
<i>fstrec</i>	first <b>Tape16</b> record number associated with this mixture.
NAMPER	<b>character*2</b> name of the perturbation. Each perturbation is associated with a single local parameter. The values permitted for <i>NAMPER</i> are the following: <ol style="list-style-type: none"> <li>1. FT for fuel temperature</li> <li>2. MT for moderator temperature</li> <li>3. MD for moderator density</li> <li>4. MP for moderator purity</li> <li>5. MB for moderator boron</li> <li>6. CT for coolant temperature</li> <li>7. CD for coolant density</li> <li>8. CP for coolant purity</li> <li>9. RT for reflector temperature</li> <li>10. RD for reflector density</li> <li>11. RP for reflector purity</li> </ol> <p>Note that these keywords are identical to those used in the Proc16 program.<sup>[28]</sup> Here the moderator, coolant and reflector can be D<sub>2</sub>O, H<sub>2</sub>O or any other mixture since DONJON is not aware of the compositions of these mixtures. In the case where many different <b>Tape16</b> files contains the reference and the individual perturbation effects, one must first define the reference case before updating the CPO using the <b>Tape16</b> files containing the perturbations.</p>
<i>valref</i>	reference value of the associated local parameter.

<i>npert</i>	number of local parameter perturbations.
<i>valper</i>	perturbed values of the local parameter.
MTMD	<b>character*4</b> name of perturbation associated with combine temperature and density changes effects. Note that this keyword is equivalent to the MTS keyword used in the Proc16 program. <sup>[28]</sup> In principle, any combined perturbations effects could be built from the catenation of two individual perturbations given in <i>NAMPER</i> .
<i>valreft</i>	reference temperature. This is required if either the MT or the MD perturbation is not defined.
<i>valrefd</i>	reference density. This is required if either the MT or the MD perturbation is not defined.
<i>npert</i>	number of simultaneous perturbations in moderator temperature and density.
<i>valpert</i>	perturbed values of the moderator temperature.
<i>valperd</i>	perturbed value of the moderator density.

The explicit name of the mixtures MIXDIR that will be stored on the main CPO directory will correspond to a catenation of *MIXNAM* and a perturbation name and an index *i* describing the perturbation order. It is created using the following FORTRAN instructions for the reference mixture:

```
WRITE(MIXDIR, '(A6,A6)') MIXNAM, 'RC_0000'
```

while for the  $i^{th}$  perturbed state associated with *NAMPER*(*J*) we will use:

```
WRITE(MIXDIR, '(A6,A2,A2,I2)') MIXNAM, NAMPER(J), '_00', i
```

Finally, for the  $i^{th}$  perturbed state associated with the MTMD perturbation we will use:

```
WRITE(MIXDIR, '(A6,A4,I2)') MIXNAM, 'MTMD', i
```

Typically if the (**desct16cpo**) structure takes the form:

```
EDIT 0
NMIX 2
MIX
  Candu  RC 15 1
          FT 900.0 2 1100.0 16 1300.0 46
  Maple  RC 70
          RP 1.0 1 0.5 71
```

Then the first 15 cases stored on the **Tape16** file will correspond to a reference CANDU fuel with burnup. The reference fuel temperature is 900.0 K. The next 15 cases are for a fuel temperature of 1100.0 K. Finally cases 46 to 60 are for a fuel temperature of 1300.0 K. The Maple mixture will have no burnup. The reference Maple cross sections correspond to case 70, while case 71 contains the effect on the Maple fuel mixture cross sections of a 50 % reduction in reflector purity . As a result we will end up with a CPO data structure which contains 5 mixtures called respectively

```
Candu_RC_0000
Candu_FT_0001
Candu_FT_0002
Maple_RC_0000
Maple_RP_0001
```

The beginning of a new case on **Tape16** will be identified by the presence of the record:

```
CELLAV_0000,MODERATOR
```

in a **Tape16** file. Accordingly, the keyword CELLAV should be used in the WIMS-AECL run creating this file. In addition, if the **REGION** option is used in the **T16CPO**: input data structure, then it should also be used in the WIMS-AECL run creating this file.

#### 4.8 The D2P: module

The objective of the D2P: module is to produce a file containing the macroscopic cross sections generated by the DRAGON5 lattice code and readable by the GenPMAXS software. This module makes possible the use of DRAGON-integrated XS into the PARCS core code. PARCS (*Purdue Advanced Reactor Core Simulator*) from the U.S. NRC <sup>[51]</sup> is a full 3D core code for the simulation of nuclear reactor steady state and transient behavior, at a specific burnup state.

The main objective of the D2P: module is to produce an output file with which can be accepted by GenPMAXS to produce the PMAXS file. In order to minimize the development in the GenPMAXS code, the choice has been made to reproduce an existing format already accepted by GenPMAXS. The HELIOS output format has been selected.

A Microlib is extracted from a Saphyb (or Multicompo) obtained by DRAGON (or APOLLO) in a previous calculation. The D2P: module extracts cross sections contained in this microlib and creates two files:

- an input file needed by GenPMAXS to produce a PMAXS (extention “.inp”)
- a file containing data cross sections in HELIOS-like format (extention “.dra”)

Note that the D2P: module is compatible with the last version of GenPMAXS (v6.1.3) and PARCS (v32m17 etc.).

##### 4.8.1 The PMAXS format

The depletion capability of the PARCS code is reachable thanks to a specific format of cross section file, named PMAXS (*Purdue Macrosocopic Cross Section File*)<sup>[52]</sup>. This format is generated using the GenPMAXS code, based on output files of several lattice codes such as HELIOS, CASMO, TRITON, WIMS, CONDOR and SERPENT. This module intend to add DRAGON in this list.

The macroscopic cross sections are stored in the PMAXS file using partial derivatives as a function of state variables. Consequently the PMAXS format is a multi-dimentional table including burnup dependance. This format is a flexible way to obtain a more or less accurate meshing of cross sections. In addition of burnup, the list of state variables around which PMAXS is built is the following:

1. CR: control rod fraction
2. DC: density of coolant
3. PC: soluble poison concentration in coolant
4. TF: temperature of fuel
5. TC: temperature of coolant
6. IC: impurity of coolant
7. DM: density of moderator
8. PM: soluble poison concentration in moderator
9. TM: temperature of moderator
10. IM: impurity of moderator
11. DN: density difference between neighbor and current assembly
12. BN: burnup difference between neighbor and current assembly

These variables **should** be specified in this order. With the exception of burnup, each variable is optional. The following equation is used to compute a cross section  $\Sigma$  in the PMAXS formalism (including 4 state variables), with  $r$  the reference state and  $m$  the mid point between the reference state and the current node state ( $CR, DC, \sqrt{TF}, TC$ ):

$$\begin{aligned} \Sigma(CR, DC, \sqrt{TF}, TC) = & \Sigma^r(DC^r, \sqrt{TF}^r, TC^r) + \Delta DC \left. \frac{\partial \Sigma}{\partial DC} \right|_{(CR, DC^m, \sqrt{TF}^r, TC^r)} + \\ & \Delta \sqrt{TF} \left. \frac{\partial \Sigma}{\partial \sqrt{TF}} \right|_{(CR, DC, \sqrt{TF}^m, TC^r)} + \Delta TC \left. \frac{\partial \Sigma}{\partial TC} \right|_{(CR, DC, \sqrt{TF}, TC^m)} \end{aligned}$$

The PMAXS formalism and the procedure branching generation are completely described in the GenPMAXS manual [52].

The PMAXS file contains eight blocks, few of them are optional and others mandatory. A precise description of each block is proposed in the APPENDIX A of GenPMAXS manual [52]. In this section, a short description of blocks is given.

#### Block XS CONTROL information (mandatory)

The first block stores data reflecting the conditions in which cross sections are obtained and what kind of informations is contained in the PMAXS file. It is composed of five integers for the number of energy groups, of delay neutron groups etc. Then, fifteen logical flags indicates if the PMAXS contains the corresponding data such as assembly discontinuity factor (ADF), Xe and Sm microscopic cross sections ... The block is ended by five lines of comments to be filled by the user.

```
GLOBAL_V      1  2  6  1  1  45  17  F  F  F  F  F  F  F  F  F  F  F  F  T
Contents of T/H Invariant Variables(TIV) block and Cross Sections(XS) block
TIV:
XS:tr,ab,nf,kf/sct/
2 Group value of each variable are put together in a line.
Some variables(separated by ",") share a line,"/" means change line
Generated by GenPMAXS-V6.1.1
```

#### Block BRANCHES information (optional)

This blocks identifies the state variables used for the branching and the corresponding states for all branches.

```
STA_VAR      4 CR DC PC TF
BRANCHES     1  2  6  18  54
RE  1      0.00000      0.71100  1000.00000  900.00000
CR  1      1.00000      0.71100  1000.00000  900.00000
CR  2      2.00000      0.71100  1000.00000  900.00000
DC  1      0.00000      0.66100  1000.00000  900.00000
DC  2      0.00000      0.75200  1000.00000  900.00000
DC  3      1.00000      0.66100  1000.00000  900.00000
DC  4      1.00000      0.75200  1000.00000  900.00000
DC  5      2.00000      0.66100  1000.00000  900.00000
DC  6      2.00000      0.75200  1000.00000  900.00000
PC  1      0.00000      0.66100      0.00000  900.00000
...
```

In this example, the PMAXS cross sections depend on 4 state variables: CR, DC, PC and TF. There are 2 branches for control rods, 6 for coolant density, 18 for boron concentration, and 54 for fuel temperature.

#### Block BURNUP information (optional)

It contains the number of burnup sets and burnup points. Each cross sections will be repeated for each burnup points.

```

BURNUPS      1
  1  35 0.00000 0.00900 0.01900 0.07500 0.15000 0.50000 1.00000 2.00000 3.00000
        4.00000 6.00000 8.00000 10.0000 12.0000 14.0000 16.0000 18.0000 20.0000
        24.0000 28.0000 32.0000 36.0000 40.0000 44.0000 48.0000 52.0000 56.0000
        60.0000 64.0000 68.0000 72.0000 76.0000 80.0000 84.0000 86.0000

```

In the above example, one can observe a set of 35 burnup points from 0 to 86 GWd/t.

#### Block XS SET identification (mandatory)

In this block, the geometrical configuration of core reactor is specified and also the number of ADF in each group, the number of rod rows and columns in whole assembly, the rod lattice pitch etc. Some of these parameters have default values

```

XS_SET  00000001  1 1 1 17 17 3 1.44270 0.72135 0.72135 2.78613 0.73659 0.00016
        0.00000   0.00000

```

#### Block HISTORY CASE identification (mandatory)

This block describes the state variables values for all histories contained in the PMAXS file. The first parameter refers to the burnup set.

```

HISTORYC  1      0.00000      0.71100 1000.00000   900.00000

```

#### Block T/H invariant variables (mandatory)

It contains invariant variables, if the corresponding logical flag in block XS CONTROL is set to 'T'. The list of invariant variables, repeated for each burnup points, is:

- Chi spectra
- Yield of I, Xe, and Sm
- Beta of delayed neutron
- Lambda of delayed neutron
- Decay heat data

```

1.00000E+00 0.00000E+00 5.13949E-08 2.17697E-06
8.87406E-14 1.13375E-13 4.25558E-15
2.68628E-04 1.43419E-03 1.39641E-03 3.23740E-03 1.43931E-03 5.99082E-04
1.33535E-02 3.26045E-02 1.21056E-01 3.05531E-01 8.60559E-01 2.89034E+00
...

```

This block contains the necessary information for 1 burnup point and for each energy group Chi,inV/YLD/Bet/Lam/.

#### Block XS data (mandatory)

Cross sections in PMAXS file are listed for each burnup point and for each neutron energy group. Some cross sections are optional (see table below)

XS data block		
STR	<i>Transport cross section</i>	mandatory
SAB	<i>Absorption cross section</i>	mandatory
SNF	<i>Nu-fission cross section</i>	mandatory
SKF	<i>Kappa-fission cross section</i>	mandatory
XENG	<i>Microscopic capture cross section of Xenon</i>	optional
SMNG	<i>Microscopic capture cross section of Samarium</i>	optional
SFI	<i>Fission cross section</i>	optional
DET	<i>Detector response parameter</i>	optional
SCT	<i>Scattering cross section</i>	mandatory
ADF	<i>Assembly discontinuity factor</i>	optional
DED	<i>Direct energy deposition</i>	optional
J1	<i>J1 factors</i>	optional
CDF	<i>Corner discontinuity factor</i>	optional
GFF	<i>Group-Wise form function</i>	optional

#### 4.8.2 General format of the module

The D2P: module can perform a sequence of phases related to the generation of a cross section format readable by GenPMAXS :

- PHASE 1 : recover input data from Saphyb and create output files
  1. recover information from a Saphyb file,
  2. store general information in output file,
  3. generate the GenPMAXS input file
- PHASE 2 : recover cross section from microlib thanks to the SCR: (or NCR:) module and store in memory,
- PHASE 3 : store cross sections in output file.

The general format of the data for the D2P: module is the following:

Table 80: Structure D2P:

```
{ PROC INF :=D2P: INF { SAP | MCO } :: PHASE 1 [ EDIT iprint ] (descphase1)
| GEN HEL INF :=D2P: MIC INF { SAP | MCO } :: PHASE 2 [ EDIT iprint ]
| HEL GEN INF :=D2P: INF GEN HEL :: PHASE 3 [ EDIT iprint ]
}
```

In the DRAGON formalism, the Left-Hand-Side (LHS) is dedicated to the objects created or modified by the module, the Right-Hand-Side (RHS) is used for input objects, all parameters are passed to the module after the "::" delimiter .  
where

**HEL**                      **ascii file** Output file with HELIOS-like format, compulsory if *iphase*= 1 (in creation mode) or if *iphase*=3 (in modification mode).

<i>GEN</i>	<b>ascii file</b> Input file for running GenPMAXS, compulsory if <i>iphase</i> = 1 (in creation mode) or if <i>iphase</i> =2 or 3 (in modification mode)
<i>INF</i>	<b>LCM object</b> Block of data for the dialogue between different sequence of operations.
<i>SAP</i>	Saphyb object with cross sections to be extracted, compulsory if <i>iphase</i> = 1 or 2.
<i>MCO</i>	Multicompo object with cross sections to be extracted, compulsory if <i>iphase</i> = 1 or 2.
<i>MIC</i>	microlib object with cross sections for one burnup point, compulsory if <i>iphase</i> = 2.
<i>PROC</i>	<b>ascii file</b> data set automatically created by :=D2P: and used for execution of PHASE=2 and PHASE=3.
<i>PHASE</i>	keyword used to set <i>iphase</i> .
<i>iph</i>	integer index used to control the current phase of D2P: module
<i>EDIT</i>	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print (default value) ; = 1 for minimum printing ; for larger values of <i>iprint</i> everything will be printed.
( <i>descphase1</i> )	input data structure for PHASE 1 of this module

NB : The complete sequence of execution of the :=D2P: module should be performed in two separate data files. The first execution is dedicated to PHASE=1 and then, at the end of this step, a second data file is automatically generated by the module to run PHASE=2 and PHASE=3.

In the case where the current PHASE of the D2P: module is *iphase*=1, the (*descphase1*) takes the form:

Table 81: Structure (*descphase1*)

```
[ NAMDIR mixdir ] [ MIX imix ]
[ TEMP htemp ]
[ PKEY (refnam(i) sapnam(i), i=1, npkey) ENDPKEY ]
[ OTHER noth (othpk(i) othtyp(i) othval(i), i=1, noth) ]
[ ADF [ MERGE ] { DRA nadf (hadf(i), i=1, nadf) | GET | SEL } ]
[ CDF DRA ncdf (hcdf(i), i=1, ncdf) ]
[ GFF DRA ]
FUEL {
BARR { DEF unrodded aicg aicn | USER unrodded (compo(i), i=1, ncompo) ENDBARR }
[ GRID { SAP | DEF |
USER { GLOBAL (pkey(i), nval(i), i=1, npkey) ENDGLOBAL |
[ NEW ] ADD (pkey(i), nval(i), (val(j), j=1, nval(i)), i=1, npkey) ENDADD } } ]
[ ISOTOPES { [ XE135 xenam ] [ SM149 smnam ] [ I135 inam ] [ PM147 pm47nam ] [ ND147 nd47nam ]
[ PM149 pmnam ] [ PM148 pm48nam ] [ PM148M pm48mnam ] [ PM149 pmam ] } ENDISOTOPES ]
[ DET hdet ]
[ YLD [ COR ] { REF | MAN (refnam(i), val(i), i=1, npkey) ENDMAN | FIX yldi yldxe yldpm } ]
}
| REFLECTOR
HELIOS [
[ FILE_CONT_1 ncols nrows part hm_dens bypass ]
```

continued on next page

Structure (descphase1)

continued from last page

```

[ FILE_CONT_2 (emin(g), g=1,ngroup) ]
[ FILE_CONT_3 vcool vwatr vmodr vcnrd vfuel vclad vchan ]
[ FILE_CONT_4 pitch xbe ybe ]
[ XS_CONT nside ncorner vfc m ] ]
GENPMAXS [
[ JOB_TIT jobtit ]
[ FILE_NAME fname ]
[ DERIVATIVE der ]
[ VERSION vers ]
[ COMMENT comment ]
[ JOB_OPT ladf lxes lded lj1f lchi lchd linv ldet lyld lcdf lgff lbet lamb ldec ]
[ IUPS iups ]
[ SFAC sfac ]
[ BFAC bfac ]
[ XESM xesmopt ] ]
PROC [
[ MEMO ]
[ MASL hmasl ]
[ EQUI hequi ]
[ ISOT { * | isotval } ] ]

```

where

NAMDIR	keyword used to set <i>mixdir</i> .
<i>mixdir</i>	name of sub-directory in Multicompo containing information to be recovered. Default <i>mixdir</i> = 'default'.
MIX	keyword used to set <i>imix</i>
<i>imix</i>	index of the mixture in the <i>SAP</i> object which will be considered by the module. Default <i>imix</i> =1.
TEMP	keyword used to set <i>htemp</i>
<i>htemp</i>	unit for the temperature variables used in the <i>SAP</i> . Two units are possible <i>htemp</i> ='C' or <i>htemp</i> ='K'. Default <i>htemp</i> ='C'.
PKEY	keyword used to associate a name of PKEY in the <i>SAP</i> object to a type of state variable.
<i>refnam</i>	type of state variable. The possible <i>refnam</i> are : BARR for the control rod (-), DMOD for the density of coolant (g/cc), CBOR for the boron concentration (ppm), TCOM for the fuel temperature (C), TMOD for the moderator temperature (C), BURN for the burnup exposure (MWd/T). It is not necessary to specify all state variable names, only state variables with a different name compared to <i>refnam</i> are expected.
<i>sapnam</i>	name of state variable in the <i>SAP</i> object associated to <i>refnam</i> . Default values are <i>sapnam</i> = <i>refnam</i> . NB: If a state variable name is not correctly associated, an error will occur during processing.
OTHER	keyword used to associate a name of variable in the <i>SAP</i> object to a kind of state variable other than the ones defined in PKEY.



<i>noth</i>	number of variable wich are not defined in with PKEY but present in the SAP object ('FLUE' and 'TIME' exepted). No default.
<i>othpk</i>	name of the other variable. No default.
<i>othtyp</i>	type of the other variable (REAL STRING or INTEGER). <i>othtyp</i> =R,S or I. No default.
<i>othval</i>	value of the other variable . This value is fixed for in the rest of the execution. No default.
FUEL	keyword used to indicate that the input SAP object contains cross sections for fuel assembly .
BARR	keyword used to associate an index of control rod in the SAP object to an index composition in PMAXS.
<i>unrodded</i>	index of control rod in the SAP object for the unrodded cross section. No default.
<i>aicg</i>	index of control rod in the SAP object for the aicg cross section. No default.
<i>aicn</i>	index of control rod in the SAP object for the aicn cross section. No default.
<i>compo</i>	index of control rod in the SAP object for the composition i.No default.
ISOTOPES	keyword used to associate a name of isotope in the SAP object to a specific isotope.
XE135	keyword used to indicate that the following record correponds to the name of Xe 135 in the SAP object .
<i>xenam</i>	name of Xe 135 isotope in the SAP (or MCO) object. Default <i>xenam</i> = 'XE135PF'.
SM149	keyword used to indicate that the following record correponds to the name of Sm 149 in the SAP (or MCO) object .
<i>smnam</i>	name of Xe 135 isotope in the SAP (or MCO) object. Default <i>smnam</i> = 'SM149PF'.
I135	keyword used to indicate that the following record correponds to the name of I 135 in the SAP (or MCO) object .
<i>inam</i>	name of Xe 135 isotope in the SAP (or MCO) object. Default <i>inam</i> = 'I135PF'.
PM149	keyword used to indicate that the following record correponds to the name of Pm 149 in the SAP (or MCO) object .
<i>pmnam</i>	name of Pm 149 isotope in the SAP (or MCO) object. Default <i>pmnam</i> = 'PM149PF'.
PM147	keyword used to indicate that the following record correponds to the name of Pm 147 in the SAP (or MCO) object .
<i>pm47nam</i>	name of Pm 147 isotope in the SAP (or MCO) object. Default <i>pm47nam</i> = 'PM147PF'.
ND147	keyword used to indicate that the following record correponds to the name of Nd 147 in the SAP (or MCO) object .
<i>nd47nam</i>	name of Nd 147 isotope in the SAP (or MCO) object. Default <i>nd47nam</i> = 'ND147PF'.
PM148	keyword used to indicate that the following record correponds to the name of Pm 148 in the SAP (or MCO) object .
<i>pm47nam</i>	name of Pm 148 isotope in the SAP (or MCO) object. Default <i>pm48nam</i> = 'PM148PF'.

PM148M	keyword used to indicate that the following record corresponds to the name of Pm 148m in the SAP (or MCO) object .
<i>pm48mnam</i>	name of Pm 148m isotope in the SAP (or MCO) object. Default <i>pm48nam</i> = 'PM148MPF'.
GRID	keyword used to select the grid of state variables used for the branching generation of the PMAXS file.
SAP	keyword used to indicate that the meshing is the one used in the SAP (or MCO) object. Default option.
USER	keyword used to indicate that the meshing is defined by the user.
GLOBAL	keyword used to set a global meshing by defining for each desired state variables a number of points for the branching calculation.
ADD	keyword used to add a set of new points for the branching calculation. The new points are added to the meshing contained in the SAP (or MCO) object.
NEW	keyword used to indicate that the points contained in the SAP (or MCO) object are ignored, consequently only the set of points indicated using ADD will be considered for the branching calculation.
<i>pkey</i>	name of the state variable. If <i>pkey</i> does not correspond to any name in the SAP (or MCO) object, it will be ignored. It is not necessary to set all state variable contained in SAP (or MCO) , if a state variable is missing, the SAP (or MCO) meshing for this state variable will be considered. NB : the BARR parameter cannot be modified by the user.
<i>nval</i>	number of points for the state variable <i>pkey</i> . In the case GLOBAL, the <i>nval</i> points are obtained by splitting the <i>pkey</i> range from the first to the last values contained in the SAP (or MCO) object, otherwise it corresponds to the number of new points to be introduced in the meshing.
<i>val</i>	value to be added in the branching calculation corresponding to the <i>pkey(i)</i> . In the case where <i>pkey(i)</i> is TCOM or TMOD, the temperature must be in Celsius.
DEF	keyword used to call a default meshing : the values for BARR and BURN are extracted from Saphyb, four default values are considered for DMOD,CBOR, TCOM and TMOD (if exists). These values correspond to the first, mid and last values of the initial SAP (or MCO) meshing. This option is used if the number of branches in the Saphyb or defined by the user exceeds 1000.
ADF	keyword used to set the type of Assembly Discontinuity Factor to be recovered from the SAP (or MCO) object. NB : the <i>ladf</i> flag must be set to true.
MERGE	the Assembly Discontinuity Factors are inserted in the cross sections
DRA	Discontinuity factors are generated using the <i>DRAGON V5</i> procedure. Discontinuity factors could be Assembly Discontinuity Factors (ADF), Corner Discontinuity Factors (CDF) or Group-wise Form Function (GFF). Default option. NB: This option is available with Multicompo produced by the <i>DRAGON V5</i> lattice code using a 2-level flux calculation with the Method Of Characteristics.

$$ADF_{g,f} = \frac{\phi_g^{Het}}{\phi_g^{Hom}},$$

where  $g$  is the energy group,  $f$ , the assembly surface and  $\phi_g^{Het}, \phi_g^{Hom}$  are the average surfacic homogeneous and heterogeneous fluxes in assembly.

GET Assembly discontinuity factors are generated using the *Generalized Equivalence Theory*. NB: This option is available with Saphyb produced by the *APOLLO2* lattice code using a 2-level flux calculation with the Method of Characteristics.

$$\text{ADF}_{g,f} = \frac{\phi_g^{Het}}{\left(\frac{\pm J_g^{Net} \times h}{2 \times D_g}\right) + \phi_g^{Hom}},$$

where  $g$  is the energy group,  $f$ , the assembly surface,  $\phi_g^{Het}, \phi_g^{Hom}$  are the homogeneous and heterogeneous fluxes in assembly,  $D_g$ , the diffusion coefficient,  $h$  the mesh dimension and  $J_g^{Net}$  the net average surfacic current.

SEL Assembly discontinuity factors are generated using the *Selengut* normalization. This option is available with Saphyb produced by the *APOLLO2* lattice code using a 2-level flux calculation with the Method of Characteristics.

$$\text{ADF}_{g,f} = \frac{2 \times (J_g^+ + J_g^-)}{\left(\frac{\pm J_g^{Net} \times h}{2 \times D_g}\right) + \phi_g^{Hom}},$$

where  $g$  is the energy group,  $f$ , the assembly surface,  $\phi_g^{Hom}$  is the homogeneous flux in assembly,  $D_g$ , the diffusion coefficient,  $h$  the mesh dimension and  $J_g^+, J_g^-, J_g^{Net}$  the incoming, outgoing, and net average surfacic currents.

*nadf* number of the ADF-type boundary flux edit to be recovered from Multicompo. Allowed values *nadf* = 1 or 4.

*hadf* name of the ADF-type boundary flux edit to be recovered from Multicompo. Default all *hadf* = 'FD\_B'. In case *nadf*=4, the ADF values correspond to the following sides of the assembly: #1 for North, #2 for East, #3 for South and #4 for West. (same order as the SAPHYB)

CDF keyword used to set the type of Assembly Discontinuity Factor to be recovered from the SAP (or MCO) object. NB : the *ladf* flag must be set to true.

*ncdf* number of the CDF-type boundary flux edit to be recovered from Multicompo. Allowed values *nadf* = 1 or 4.

*hcdf* name of the CDF-type boundary flux edit to be recovered from Multicompo. Default all *hacd* = 'FD\_C'. In case *ncdf*=4, the CDF values correspond to the following corner of the assembly: #1 for North-West, #2 for South-West, #3 for South-East and #4 for North-East.

GFF keyword used to set the type of Group Form Factor to be recovered from the MCO object. NB : the *lgff* flag must be set to true. In case of symmetry (*part*≥2), the numbering is different with the PARCS version (numbering as for CASMO starting from v3.2m18).

DET keyword to set the name of the particularised isotope in which detector cross sections are to be recovered.

*hdet* name of the particularised isotopes containing detector information. No default.

YLD keyword used to set the type of fission yields to be recovered from the SAP (or MCO) object. NB : the *lyld* flag must be set to true.

**COR** keyword used to correct the PM149 fission yield. The correction applied include the contribution of PM148 and PM148M in the production of SM149 (normally not taken into account in the PARCS depletion chain). The correction is :

$$\gamma_{PM} \Rightarrow \gamma_{PM} \times \left[ 1 + \left( \frac{\sum_g N^{PM148} \sigma_g^{PM148} \Phi_g + N^{PM148M} \sigma_g^{PM148M} \Phi_g}{\gamma_{PM} \sum_g \Sigma_g^f \Phi_g} \right) \right]$$

This correction is recommended for comparison with other core codes or with experimental data. The Pm148 and Pm148M need to be particularized in the SAP | MCO object (ISOTOPES keyword to set isotopes names).

**REF** keyword used to indicate that fission yields are recovered from the reference branch calculation.

**MAN** keyword used to indicate that fission yields are fixed by the user according to the local conditions specified.

**FIX** keyword used to indicate that fission yields are fixed for all local conditions including burnup.

*yldi* value for the iodine fission yield. Default: *yldi*=0.06386.

*yldxe* value for the xenon fission yield. Default: *yldxe*=0.00228.

*yldpm* value for the promethium fission yield. Default: *yldpm*=0.0113.

**REFLECTOR** keyword used to indicate that the input *SAP* object contains cross sections for reflector.

**HELIOS** keyword used to indicate that the input data for the *HEL* file will be set by the user.

**FILE\_CONT\_1** keyword used to set the **FILE\_CONT\_1** block. See Ref. 52.

*ncols* number of rod columns. Default: *ncols*=17.

*nrows* number of rod rows. Default: *nrows*=17.

*part* index for computed part of assembly (0/1/2/3 : whole/half/quarter/eight). By default, *part*=3.

*hm\_dens* initial heavy metal density ( $g.cm^{-3}$ ). By default, *hm\_dens*=2.78613. The initial heavy metal density can be computed as follow :

$$hm\_dens = \left( \frac{d_{fuel} \times \pi \times r_{pellet} \times n_{pellet}}{(pitch \times nrows)^2} \right) \times \left( \frac{m_{hm}}{m_{fuel}} \right)$$

where  $d_{fuel}$  is the fuel density,  $r_{pellet}$  the radius of fuel pellet,  $n_{pin}$  the number of fuel rods, *pitch* the rod lattice pitch, *nrows* the number of rows in whole assembly,  $m_{hm}$  the mass of heavy metal, and  $m_{fuel}$  the total mass of fuel.

*bypass* the saturated moderator density ( $g.cm^{-3}$ ). By default, *bypass*=0.73659.

**FILE\_CONT\_2** keyword used to set the lower energy limits of neutron groups.

*emin* lower energy limits of neutron groups. Default: *emin*= { 6.2506E-01, 1E-04 }

**FILE\_CONT\_3** keyword used to set the **FILE\_CONT\_3** block (volume of regions). See Ref. 52.

*vcool* volume of coolant. Default: *vcool*=2.4921E+02.

*vwatr* volume of water. By default, *vwatr*=0.0000E+00.

<i>vmodr</i>	volume of moderator. Default: <i>vmodr</i> =2.4921E+02.
<i>vcnrd</i>	volume of control rods. By default, <i>vcnrd</i> =2.3020E+01.
<i>vfuel</i>	volume of fuel. By default, <i>vfuel</i> =1.4407E+02 .
<i>vclad</i>	volume of cladding. By default, <i>vclad</i> =4.5099E+01.
<i>vchan</i>	volume of channel. By default, <i>vchan</i> =4.5099E+01.
FILE_CONT_4	keyword used to set the FILE_CONT_4 block. See Ref. 52.
<i>pitch</i>	rod lattice pitch (cm). Default: <i>pitch</i> =1.44270E+00.
<i>xbe</i>	starting position of first column rods (cm), i.e. water gap thickness. By default, <i>xbe</i> =7.21350E-01.
<i>ybe</i>	starting position of first row rods (cm), i.e. water gap thickness. By default, <i>ybe</i> =7.21350E-01.
XS_CONT	keyword used to set the XS_CONT block. See Ref. 52.
<i>nside</i>	number of sides in assembly. Default: <i>nside</i> =1.
<i>ncorner</i>	number of corners in assembly. By default, <i>ncorner</i> =1.
<i>vfc</i>	value of <i>vfc</i> . By default, <i>vfc</i> =5.32151E-01.
GENPMAXS	keyword used to indicate that the input data for the GEN file will be set by the user.
JOB_TIT	keyword used to set <i>jobtit</i>
<i>jobtit</i>	<b>character*16</b> name of the PMAXS file created by the D2P: module. Default: <i>jobtit</i> ='D2P.PMAX'
FILE_NAME	keyword used to set <i>fname</i> .
<i>fname</i>	<b>character*12</b> name of the HELIOS-like file ( <i>HEL</i> ) created by the D2P: module. Default: <i>fname</i> ='HELIOS.dra'
DERIVATIVE	keyword used to set <i>der</i> .
<i>der</i>	<b>character</b> (T/F) type of data in non-reference branches of output PMAXS file. If <i>der</i> ='T', data are partial derivatives, otherwise it is raw cross sections. Default: <i>der</i> ='T'.
VERSION	keyword used to set <i>vers</i> .
<i>vers</i>	the version of PARCS which will be used. If <i>vers</i> ≥2.705, generate PMAXS for PARCS 2.71 or later versions, otherwise it is for PARCS 2.7 or earlier versions. Default: <i>vers</i> =3.0. The version number is as follows: v3.2m17 <i>vers</i> =3.217
COMMENT	keyword used to set a comment line.
<i>comment</i>	<b>character*40</b> Comment line for the user. Default: <i>comment</i> ='PWR CASE : UOX/MOX CORE FUEL'.
JOB_OPT	keyword use to set logical flags, it indicates write or not write corresponding data into PMAXS file. If the flag is 'F', default values given in Ref. 52, will be used in PARCS. For reflector case, all flags will be forced to 'F', except for <i>ladf</i> and <i>linv</i> .
<i>ladf</i>	<b>character</b> (T/F) assembly discontinuity factor. Default: <i>ladf</i> ='F'.

<i>lxes</i>	<b>character</b> (T/F) microscopic cross section of Xe and Sm. Default: <i>lxes</i> ='F'.
<i>lded</i>	<b>character</b> (T/F) direct energy deposition fraction. Default: <i>lded</i> ='F'.
<i>lj1f</i>	<b>character</b> (T/F) J1 factor for minimal critical power ratio. Default: <i>lj1f</i> ='F'.
<i>lchi</i>	<b>character</b> (T/F) fission spectrum. Default: <i>lchi</i> ='F'.
<i>lchid</i>	<b>character</b> (T/F) delay neutron fission spectrum. Default: <i>lchid</i> ='F'.
<i>linv</i>	<b>character</b> (T/F) inverse neutron velocity. Must be 'T' for transient. Default: <i>linv</i> ='F'.
<i>ldet</i>	<b>character</b> (T/F) Detector response. Default: <i>ldet</i> ='F'.
<i>lyld</i>	<b>character</b> (T/F) yield values of I, Xe, and Pm. Default: <i>lyld</i> ='F'.
<i>lcdf</i>	<b>character</b> (T/F) corner discontinuity factor. Default: <i>lcdf</i> ='F'.
<i>lgff</i>	<b>character</b> (T/F) group wise power form function. Default: <i>lgff</i> ='F'.
<i>lbet</i>	<b>character</b> (T/F) Beta of delayed neutron. Default: <i>lbet</i> ='F'.
<i>lamb</i>	<b>character</b> (T/F) Lambda of delayed neutron. Default: <i>lamb</i> ='F'.
<i>ldec</i>	<b>character</b> (T/F) Decay heat beta and lambda. Default: <i>ldec</i> ='F'.
<b>IUPS</b>	keyword used to set the treatment for up-scattering.
<i>iups</i>	(0/1) 0: keep up scatter XS, 1: remove up scatter XS, modify down scatter XS with infinite medium spectrum. Default: <i>iups</i> =0.

$$\Sigma'_{s,g \leftarrow g'} = \Sigma'_{s,g \leftarrow g'} - \Sigma'_{s,g' \leftarrow g} \times \frac{\phi_g}{\phi_{g'}}$$

for  $g' < g$

where  $\phi_g, \phi_{g'}$  are the spectra flux either provided by DRAGON or infinite spectra computed in GenPMAXS.

<b>SFAC</b>	keyword used to set <i>sfac</i> . See Ref. 52.
<i>sfac</i>	the scattering cross section factor. If <i>sfac</i> is different from 1, then the scattering cross section will be multiplied by <i>sfac</i> . Default: <i>sfac</i> =1.0.
<b>BFAC</b>	keyword used to set <i>bfac</i> . See Ref. 52.
<i>bfac</i>	the multiplier for betas. If <i>bfac</i> is different from 1, then the betas will be multiplied by <i>bfac</i> . Default: <i>bfac</i> =1.0.
<b>XESM</b>	keyword used to set <i>xesmopt</i> . See Ref. 52.
<i>xesmopt</i>	Compare k-inf in genpmaxs using 1:Pm/Sm data, 2: I/Xe data, 3: I/Xe/Pm/Sm data
<b>PROC</b>	keyword used to create automatically the second data set needed to the complete execution of the module.
<b>MEMO</b>	keyword used to store in the <i>SAP</i> object in memory. If the size of the object is important this option is recommended.
<b>EQUI</b>	keyword used to select a SPH factor set in the Saphyb. By default, the cross sections and diffusion coefficients are not SPH-corrected.

<i>hequi</i>	user-defined keyword used in the saphyb for the SPH factor. This set is stored as local parameter information in the Saphyb.
MASL	keyword used to select a heavy metal density in the Saphyb.
<i>hmasl</i>	user-defined keyword used in the saphyb for the heavy metal density. This set is stored as local parameter information in the Saphyb.
ISOT	keyword used to select a heavy metal density in the Saphyb.
*	the value of the number density for all isotopes is recovered from the saphyb object.
<i>isotval</i>	user-defined value of the number density (in $10^{24}$ particles per $cm^{-3}$ ). This value is fixed for all particularised isotopes other than Xenon-135 and Samarium-149.

## 5 THERMAL-HYDRAULICS MODULES

### 5.1 The THM: module

The **THM:** module is a simplified thermal-hydraulics module where the reactor is represented as a collection of independent channels with no cross-flow between them. Each channel is represented using 1D convection equations along the channel and 1D cylindrical equations for a single pin cell. A two-fluid homogeneous model is used. The **THM:** module is built around *freesteam*, an open source implementation of IAPWS-IF97 steam tables for light water.<sup>[30]</sup>

The simplified model used in **THM:** is based on the work of M. F. Fehri for CANDU clusters<sup>[43]</sup> and P. Gallet for PWR assemblies<sup>[44]</sup>. The **THM:** module works both in steady-state and in transient conditions and includes a subcooled flow boiling model based on the *Bowring* correlation<sup>[45]</sup> or on the *Saha-Zuber* correlation<sup>[46]</sup> for computing the temperature subcooling at the onset of fully developed boiling (OFDB).

The 1D thermal-hydraulics equations are solved in each channel as a fonction of two *fixed* inlet conditions for the coolant velocity and temperature and one *fixed* outlet condition for the pressure.

The **THM:** module specification is:

Table 82: Structure **THM:**

$THERMO \ MAPFL := THM: [ THERMO ] \ MAPFL :: (descthm)$
--

where

<i>THERMO</i>	<b>character*12</b> name of the <b>THERMO</b> object that will be created or updated by the <b>THM:</b> module. Object <b>THERMO</b> contains thermal-hydraulics information set or computed by <b>THM:</b> in transient or in permanent conditions such as the distribution of the enthalpy, the pressure, the velocity, the density and the temperatures of the coolant for all the channels in the geometry. It also contains all the values of the fuel temperatures in transient or in permanent conditions according to the discretisation chosen for the fuel rods.
<i>MAPFL</i>	<b>character*12</b> name of the <b>MAP</b> object containing fuel regions description and local parameter informations.
<b>(descthm)</b>	structure describing the input data to the <b>THM:</b> module.

#### 5.1.1 Input data to the **THM:** module

Table 83: Structure **(descthm)**

$\begin{aligned} &[ EDIT \ iprint ] \\ &[ FLUID \{ H2O \mid D2O \} ] \end{aligned}$
---

continued on next page



Structure (**descthm**)

continued from last page

```

[ RELAX relax ]
[ TIME time [ timestep ] ]
[ FPUISS fract ] [ CRITFL cflux ]
INLET poutlet tinlet
{ CWSECT sect flow | INLET-Q sect qfluid | SPEED velocity }
{ ASSMB { nbf | CHAN (nbf(i), i = 1, nch ) } { nbg | CHAN (nbg(i), i = 1, nch ) }
  | CLUSTER pitch { nbf | CHAN (nbf(i), i = 1, nch ) } }
RADIUS r1 r2 r3 r4
[ POROS poros ] [ PUFR { pufr | CHAN (pufr(i), i = 1, nch ) } ]
[ CONDF ncond (kcond(k), k=0, ncond) [ INV inv ref ] unit ]
[ F-RUG epsr ] [ THETA theta ]
[ CONDC ncond (kcond(k), k=0, ncond) unit ]
[ HGAP hgap ] [ HCONV hconv ] [ TEFF wteff ]
[ CONV maxit1 maxit2 maxit3 ermaxt ermaxc ]
[ RODMESH nb1 nb2 ]
[ FORCEAVE ]
[ { MONO | BOWR | SAHA } ]
[ RAD-PROF [[ rprad fprad ]] ]
[ POWER-LAW tpow ntime (t(i) pow(i), i=1, ntime) ]
[[ SET-PARAM PNAME pvalue ]]
[ PICK >> ratio << ]
;

```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing; larger values produce increasing amounts of output.
FLUID	keyword used to set the fluid type. By default, light water (H <sub>2</sub> O) is used.
H2O	use light water (H <sub>2</sub> O).
D2O	use heavy water (D <sub>2</sub> O).
RELAX	keyword used to set the relaxation parameter <i>relax</i> .
<i>relax</i>	relaxation parameter selected in the interval $0 < relax \leq 1$ and used to update the fuel (average and surface) temperature, coolant temperature and coolant density. The updated value is taken equal to $(1 - relax)$ times the previous iteration value plus <i>relax</i> times the actual iteration value. The default value is <i>relax</i> = 1.
TIME	keyword used to specify the type of calculation (steady-state or transient) performed by the THM: module and the temporal parameters. By default, a steady-state calculation is performed.
<i>time</i>	real value of time in second. Equal to the current time in case of steady-state calculation. Equal to the time at beginning-of-step in case of transient calculation. The default value is 0.0.
<i>timestep</i>	real value (in second) set to the time step in case of a transient calculation. A steady-state/transient calculation is assumed depending if this value is not given/is given.

**FPUISS** keyword used to specify the fraction of the power released in fuel. The remaining fraction is assumed to be released in coolant. The default value is 0.974.

*fract* real value set to the fraction ( $f$ ). Power densities released in coolant and fuel are computed as

$$Q_{\text{cool}} = (1 - f) \frac{V_{\text{cool}} + V_{\text{fuel}}}{V_{\text{cool}}} \frac{P_{\text{mesh}}}{V_{\text{mesh}}}$$

$$Q_{\text{fuel}} = f \frac{V_{\text{cool}} + V_{\text{fuel}}}{V_{\text{fuel}}} \frac{P_{\text{mesh}}}{V_{\text{mesh}}}$$

where  $V_{\text{cool}}$  and  $V_{\text{fuel}}$  are coolant and fuel area computed from *sass*, *nbf*, *nbg*, *r3* and *r4*. The mesh power  $P_{\text{mesh}}$  and volume  $V_{\text{mesh}}$  are recovered from *MAPFL* object.

**CRITFL** keyword used to specify the critical heat flux.

*cflux* real value set to the critical heat flux in W/m<sup>2</sup>. The default value is  $2.0 \times 10^6$  W/m<sup>2</sup>.

**INLET** keyword used to specify the outlet pressure and inlet absolute temperature.

*poutlet* real value set to the outlet coolant pressure in Pa. The pressure along each channel is assumed to be constant and equal to *poutlet* in permanent conditions.

*tinlet* real value set to the inlet coolant absolute temperature in K.

**CWSECT** keyword used to specify the core coolant section and the coolant inlet flow.

*sect* real value set to the core coolant section in m<sup>2</sup>.

*flow* real value set to the coolant flow in m<sup>3</sup>/hr. This value doesn't include the by-pass flow. The inlet coolant velocity in m/s is computed as

$$V = \frac{flow}{3600 \text{ sect}}.$$

**INLET-Q** keyword used to specify the core coolant section and the inlet mass flow rate.

*qfluid* real value set to the inlet mass flow rate in kg/s. This value doesn't include the by-pass flow. The inlet coolant velocity in m/s is computed as

$$V = \frac{qfluid}{\rho_{\text{cool}} \text{ sect}}$$

where  $\rho_{\text{cool}}$  is the coolant density as obtained by the steam tables as a function of *poutlet* and *tinlet*.

**SPEED** keyword used to specify the inlet coolant velocity.

*velocity* real value set to the inlet coolant velocity in m/s.

**ASSMB** keyword used to specify the assembly characteristics, used for PWR cases.

*nbf* integer or real value set to the number of active fuel rods in a single assembly or number of active fuel pins in the cluster. This value can be zero (if a fuel channel is not processed in *THM*:), integer or real (if a fuel channel contains a fraction of a rod).

*nbg* integer or real value set to the number of active guide tubes in a single assembly.

**CLUSTER** keyword used to specify the cluster characteristics, used for CANDU reactor cases.




Figure 13: Simplified cluster geometry used for CANDU reactor cases.

<i>pitch</i>	real value set to the side of the hexagon in m for the simplified cluster geometry. This geometry is depicted in Fig. 13.
CHAN	keyword used to specify that a data is channel-dependent.
<i>nch</i>	number of fuel channels in the radial plane.
RADIUS	keyword used to set the pin-cell radii.
<i>r1</i>	real value set to the fuel pellet radius in m.
<i>r2</i>	real value set to the internal clad rod radius in m.
<i>r3</i>	real value set to the external clad rod radius in m.
<i>r4</i>	real value set to the guide tube radius in m.
POROS	keyword used to set the oxide porosity of fuel. Porosity affects some built-in correlations used to represent the heat conduction phenomenon in fuel.
<i>poros</i>	real value set to the oxide porosity. The default value is 0.05.
PUFR	keyword used to set the plutonium mass enrichment of fuel. Plutonium enrichment affects some built-in correlations used to represent the heat conduction phenomenon in fuel.
<i>pufr</i>	real value set to the plutonium mass enrichment. This value can be unique or channel-dependent. The default value is 0.0.
F-RUG	keyword used to set the rugosity of the fuel rod, used in Müller-Steinhagen correlation for coolant friction.
<i>epsr</i>	real value set to the rugosity of the fuel rod in m. The default value is 0.0.
THETA	keyword used to set the angle of the fuel channel, used in Müller-Steinhagen correlation for coolant friction.
<i>theta</i>	real value set to the angle of the fuel channel in radians. The default value is 0.0, corresponding to a vertical channel.
CONDF	keyword used to set the fuel thermal conductivity as a function of local fuel temperature $T_{fuel}$ . Fuel conductivity is computed as

$$\lambda_{fuel} = \sum_{k=0}^{ncond} kcond(k) * (T_{fuel})^k + \frac{inv}{T_{fuel} - ref}$$

with  $\lambda_{fuel}$  in  $W/m/K$  and  $T_{fuel}$  in the selected unit (Kelvin or Celsius).

By default, built-in models are used, taking into account oxide porosity and plutonium mass enrichment. Note that oxide porosity and plutonium mass enrichment are ignored if this keyword is used.

<i>ncond</i>	integer value set to the degree of the conductivity polynomial.
<i>kcond</i>	real value set to the coefficient of the conductivity polynomial. <i>ncond</i> + 1 coefficients are expected.
<i>unit</i>	string value set to the unit of temperature $T$ in the conductivity function. Can be either <i>CELSIUS</i> or <i>KELVIN</i> .
<i>INV</i>	keyword used to add an inverse term in the fuel conductivity function.
<i>inv</i>	real value set to the coefficient in the inverse term of fuel conductivity. The default value is 0.0 (i.e. no inverse term).
<i>ref</i>	real value set to the reference in the inverse term of fuel conductivity.
<i>CONDC</i>	keyword used to set the clad thermal conductivity as a function of local clad temperature $T_{clad}$ . Clad conductivity is computed with the following polynomial

$$\lambda_{clad} = \sum_{k=0}^{ncond} kcond(k) * (T_{clad})^k$$

with  $\lambda_{clad}$  in  $W/m/K$  and  $T_{clad}$  in the selected unit (Kelvin or Celsius).

By default, a built-in model is used.

<i>HGAP</i>	keyword used to set the heat exchange coefficient of the gap as a constant. By default, a built-in model is used.
<i>hgap</i>	real value set to the constant heat exchange coefficient of the gap in $W/m^2/K$ .
<i>HCONV</i>	keyword used to set the heat transfer coefficient between clad and fluid as a constant. By default, this coefficient is computed using a built-in correlation.
<i>hconv</i>	real value set to the constant heat transfer coefficient between clad and fluid in $W/m^2/K$ .
<i>TEFF</i>	keyword used to set the weighting factor in the effective fuel temperature approximation. The effective fuel temperature is used for the cross sections interpolations on fuel temperature.
<i>wteff</i>	real value $W_{teff}$ set to the weighting factor in the effective fuel temperature. The effective fuel temperature is computed as

$$T_{eff}^{fuel} = W_{teff} * T_{surface}^{fuel} + (1 - W_{teff}) * T_{center}^{fuel}$$

where  $0 \leq W_{teff} \leq 1$ ,  $T_{surface}^{fuel}$  is the temperature at the surface of the fuel pellet (K), and  $T_{center}^{fuel}$  is the temperature at the center of the fuel pellet (K).

By default, the Rowlands weighting factor  $W_{teff} = \frac{5}{9}$  is used<sup>[50]</sup>.

CONV	keyword used to set the convergence criteria for solving the conduction and the conservation equation.
<i>maxit1</i>	integer value set to the maximum number of iterations for computing the conduction integral. The default value is 50.
<i>maxit2</i>	integer value set to the maximum number of iterations for computing the center pellet temperature. The default value is 50.
<i>maxit3</i>	integer value set to the maximum number of iterations for computing the coolant parameters (mass flux, pressure, enthalpy and density) in case of a transient calculation. The default value is 50.
<i>ermaxt</i>	real value set to the maximum temperature error in K. The default value is 1 K.
<i>ermaxc</i>	real value set to the maximum relative error for parameters given by the resolution of flow conservation equations (pressure, velocity and enthalpy). The default value is $10^{-3}$ .
RODMESH	keyword used to set the radial discretization of pin-cells.
<i>nb1</i>	integer value set to the number of discretisation points in fuel. The default value is 5.
<i>nb2</i>	integer value set to the number of discretisation points in the whole pin-cell (fuel+cladding). The default value is 8.
FORCEAVE	keyword used to force the use of the average approximation during the fuel conductivity evaluation. By default, a rectangle quadrature approximation is used.
MONO	keyword used to set a one-phase flow model.
BOWR	keyword used to set a subcooling model based on the Bowring correlation <sup>[45]</sup> (default option).
SAHA	keyword used to set a subcooling model based on the Saha-Zuber correlation <sup>[47]</sup> . This option is recommended for BWR and CANDU applications.
RAD-PROF	keyword used to set radial power form factors. By default, these factors are set to 1.0.
<i>rprad</i>	radius corresponding to a form factor with $0 \leq rprad \leq r1$ . This value doesn't need to correspond to a material limit in the fuel rod.
<i>fprad</i>	radial power form factor corresponding to radius <i>rprad</i> .
POWER-LAW	keyword used to define a time-dependent power law in the input. By default, the power is recovered from the fuelmap object <i>MAPFL</i> .
<i>tpow</i>	total power delivered in the reactor in W.
<i>ntime</i>	number of tabulation points for the power law.
<i>t(i)</i>	tabulation abscissa in time (s).
<i>pow(i)</i>	tabulation power factor corresponding to <i>t(i)</i> . The reactor power at time <i>t(i)</i> is given as <i>tpow</i> × <i>pow(i)</i> .
SET-PARAM	keyword used to indicate the input (or modification) of the actual values for a parameter specified using its <i>PNAME</i> .
PNAME	keyword used to specify <i>PNAME</i> .

*PNAME*            **character\*12** name of a parameter.

*pvalue*            single real value containing the actual parameter's values. Note that this value will not be checked for consistency by the module. It is the user responsibility to provide the valid parameter's value which should be consistent with those recorded in the multicompo or Saphyb database.

**PICK**            keyword used to recover the temperature variation parameter  $R$  in a CLE-2000 variable. This parameter describes the variation of averaged fuel and coolant temperatures during a time step using the formula

$$R = \max \left\{ \frac{1}{\Delta T_{\text{fuel}}} |\bar{T}_{\text{fuel}}(n) - \bar{T}_{\text{fuel}}(n-1)|, \frac{1}{\Delta T_{\text{cool}}} |\bar{T}_{\text{cool}}(n) - \bar{T}_{\text{cool}}(n-1)| \right\}$$

where  $\Delta T_{\text{fuel}} = 5$  K and  $\Delta T_{\text{cool}} = 40$  K.

*ratio*            **character\*12** CLE-2000 variable name in which the temperature variation parameter will be placed.

## 6 POINT KINETICS MODULES

### 6.1 The PKINI: module

The PKINI: module is used to initialize the point kinetics parameters, to define the delayed neutron information and to set the global feedback parameters. The point kinetics equations are solved for a *time stage* using module PKINS: (See Sect. 6.2) as a function of a fixed set of global parameters recovered from the MAP object MAPFL. Modules PKINI: and PKINS: are intended to be used with thermal-hydraulics module THM: (See Sect. 5.1) to simulate a single reactor channel.

The PKINI: module specification is:

Table 84: Structure PKINI:

```
MAPFL := PKINI: MAPFL :: (descpkini)
```

where

**MAPFL**                      **character\*12** name of the MAP object containing fuel regions description and global parameter informations.

**(descpkini)**                structure describing the input data to the PKINI: module.

#### 6.1.1 Input data to the PKINI: module

Table 85: Structure (descpkini)

```
[ EDIT iprint ]
POWER power
[ EPSILON epsilon ]
TIME t0 dt
LAMBDA lambda
NGROUP ngroup
BETAI (beta(i),i=1,ngroup) LAMBDAL (dlambda(i),i=1,ngroup)
ALPHA [[ PNAME { DIRECT | DERIV | SQDERIV }
        [ { LINEAR | CUBIC } ] nalpha (x(i) y(i),i=1,nalpha) ]] ENDA
[ PTIME [[ PNAME [ { LINEAR | CUBIC } ] { ntime (t(i) x(i),i=1,ntime) |
        T-DELT [ nxy ] t1 t2 P-VALV gamma p1 p2 tb1 bval1 [ RESET p3 tb2 bval2 ] } ]] ENDP ]
;
```

where

**EDIT**                      keyword used to set *iprint*.

<i>iprint</i>	integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing; larger values produce increasing amounts of output.
POWER	keyword used to set the initial reactor power.
<i>power</i>	reactor power in MW.
EPSILON	keyword used to set the epsilon of the Runge-Kutta solver used to adjust the internal time step. The default value is $\epsilon = 1.0 \times 10^{-2}$ .
<i>epsilon</i>	user-selected epsilon.
TIME	keyword used to set the initial time and stage duration. It is possible to readjust the stage duration in module PKINS:.
<i>t0</i>	initial time (s).
<i>dt</i>	stage duration (s).
LAMBDA	keyword used to set the prompt neutron generation time.
<i>lambda</i>	prompt neutron generation time (s).
NGROUP	keyword used to set the number of delayed precursor groups.
<i>ngroup</i>	number of delayed precursor groups.
BETAI	keyword used to set the delayed neutron fraction vector.
<i>betai</i>	value of the delayed neutron fraction in a delayed precursor group.
LAMBDAL	keyword used to set the delayed neutron time constant vector.
<i>lambdal</i>	value of the delayed neutron time constant (s) in a delayed precursor group.
ALPHA	keyword used to set the feedback parameters.
PNAME	character*12 name of a feedback parameter. A feedback parameter should be a global parameter defined in the fuelmap.
DIRECT	keyword indicating that the reactivity is a direct function of the global parameter.
DERIV	keyword indicating that the reactivity is a function of the variation of the local parameter with respect to its initial value.
SQDERIV	keyword indicating that the reactivity is a function of the variation of the square root of the local parameter with respect to its initial value. This option is generally used to represent the Doppler effect due to the fuel temperature.
LINEAR	keyword indicating that interpolation of the reactivity effect uses linear Lagrange polynomials (default option).
CUBIC	keyword indicating that interpolation of the reactivity effect uses the Ceschino method with cubic Hermite polynomials, as presented in Ref. 17.
<i>nalpha</i>	number of values in the table describing reactivity effects for feedback parameter PNAME.
<i>x</i>	value of the global parameter.
<i>y</i>	corresponding reactivity coefficient.
PTIME	keyword used to set the time laws for some feedback parameters.



<i>ntime</i>	number of values in the time law for feedback parameter <b>PNAME</b> .
<i>t</i>	time (s)
<i>x</i>	corresponding value of the global parameter.
<b>T-DELT</b>	keyword used to set an analytical time law between two times.
<i>nxy</i>	number of points used to construct the discrete time law. The default value is <i>nxy</i> = 1001.
<i>t1</i>	initial time (s) for the analytical time law domain.
<i>t2</i>	final time (s) for the analytical time law domain.
<b>P-VALV</b>	keyword used to define a time law corresponding to the depressurization of a gas reservoir. The time-variation of the pressure $P(t)$ in a reservoir is given by a relation of the form

$$P(t) = \begin{cases} P_{\max} & \text{if } t \leq tb1 \\ \max\left(P_{\min}, \frac{P_{\max}}{(1+Bt)^\alpha}\right) & \text{otherwise} \end{cases} \quad (6.1)$$

where  $P_{\max}$  is the pressure of the reservoir at time  $t \leq tb1$ , before depressurization and  $P_{\min}$  is the final pressure after depressurization.  $B$  ( $s^{-1}$ ) is the time constant of the exhaust pipe and  $\alpha$  is given by relation

$$\alpha = \frac{2\gamma}{\gamma - 1} \quad (6.2)$$

where  $\gamma$  is a constant related to the gas capacitance (= 1.66 for Helium).

<i>gamma</i>	value of $\gamma$ parameter in Eq. (6.2).
<i>p1</i>	value of pressure $P_{\max}$ in Eq. (6.1).
<i>p2</i>	value of pressure $P_{\min}$ in Eq. (6.1).
<i>tb1</i>	time (s) when the exhaust pipe is open with value <i>bval1</i> . We must have $t1 \leq tb1 < t2$ .
<i>bval1</i>	value of $B$ parameter in Eq. (6.1) after time <i>tb1</i> .
<b>RESET</b>	optional keyword used to reset the opening of the exhaust pipe after a fixed period of time.
<i>p3</i>	value of pressure $P_{\min}$ in Eq. (6.1) after reset.
<i>tb2</i>	time (s) when the exhaust pipe is open with value <i>bval2</i> . We must have $tb1 < tb2 < t2$ .
<i>bval2</i>	value of $B$ parameter in Eq. (6.1) after time <i>tb2</i> .

## 6.2 The PKINS: module

The feedback parameters are responsible for the introduction of reactivity in the solution of the point-kinetics equations. Some feedback parameters have their time variation set by *time laws* defined in module PKINI: (See Sect. 6.1). Some other are assumed constant during a *time stage*, corresponding to a single call to module PKINS:. The PKINS: module is used to solve the point-kinetics equations over a single time stage.

The PKINS: module specification is:

Table 86: Structure PKINS:

```
[ MAPFL := ] PKINS: MAPFL :: (descpkins)
```

where

**MAPFL**            **character\*12** name of the MAP object containing fuel regions description and global parameter informations. This object is declared in read-only mode if and only if keyword PICKR is set.

**(descpkins)**        structure describing the input data to the PKINS: module.

### 6.2.1 Input data to the PKINS: module

Table 87: Structure (descpkins)

```
[ EDIT iprint ]
TIME t0 dt
{ [ POWER power | Y-INIT (y(i),i=1,ngroup+1) } ]
[ { PICK >> power_out << | PICKR >> rho << } ]
;
```

where

**EDIT**            keyword used to set *iprint*.

**iprint**            integer index used to control the printing on screen: = 0 for no print; = 1 for minimum printing; larger values produce increasing amounts of output.

**TIME**            keyword used to set the beginning-of-stage and duration times.

**t0**                beginning-of-stage time (s).

**dt**                stage duration (s). *dt* = 0.0 if keyword PICKR is set.

**POWER**           keyword used to set the beginning-of-stage reactor power.

<i>power</i>	beginning-of-stage reactor power in MW.
Y-INIT	keyword used to set the beginning-of-stage solution of the point kinetics equations.
<i>y</i>	beginning-of-stage value of a component of the beginning-of-stage solution. <i>ngroup</i> is the number of delayed precursor groups.
PICK	keyword used to recover the end-of-stage power (in MW) in a CLE-2000 variable.
<i>power_out</i>	<b>character*12</b> CLE-2000 variable name in which the extracted power value will be placed.
PICKR	keyword used to recover the reactivity at time <i>t0</i> in a CLE-2000 variable.
<i>rho</i>	<b>character*12</b> CLE-2000 variable name in which the reactivity value will be placed.

## 7 OPTIMIZATION MODULES

This section is related to optimization capabilities available in Donjon and based on generalized perturbation theory.<sup>[31,32]</sup> General information about the generalized perturbation theory can be found in Sect. 5.3 of Ref. 1.

### 7.1 The DLEAK: module

The DLEAK: module is used to create a delta MACROLIB (type L\_MACROLIB) with respect to leakage information. Derivatives of leakage-related information (recovered from the input MACROLIB) are stored in the STEP heteroneneous list components present in the output MACROLIB. Derivatives can be taken with respect to a leakage parameter itself ( $D_{g,i}$  or  $\Sigma_{1,g,i}$ ) or relative to factor  $\mu$  in  $\mu D_{g,i}$  or  $\mu \Sigma_{1,g,i}$ . Note that factor  $\mu$  is not a SPH factor because it multiplies only leakage-related parameters. One component of the STEP heteroneneous list is created for each value of energy group  $g$  and for each value of mixture  $i$ .

The calling specifications are:

Table 88: Structure (DLEAK:)

*DMACRO OPTIM* := DLEAK: *MACRO* :: (dleak\_data)

where

*DMACRO*    **character\*12** name of a LCM object (type L\_MACROLIB) containing the delta MACROLIB information. *DMACRO* is created by the module. A STEP heteroneneous list is present in *DMACRO*.

*OPTIM*     **character\*12** name of a second LCM object (type L\_OPTIMIZE) created by the module. Leakage-related parameters are saved in the the control variable record 'VAR-VALUE' of *OPTIM* object. Input data defined in Sect. 7.1.1 is also saved in *OPTIM* object.

*MACRO*     **character\*12** name of the LCM object (type L\_MACROLIB) containing the input MACROLIB.

(dleak\_data) structure containing the data to module DLEAK: (see Sect. 7.1.1).

#### 7.1.1 Data input for module DLEAK:

Table 89: Structure (dleak\_data)

```
[ EDIT iprint ]
TYPE { DIFF | NTOT1 }
DELTA { VALUE | FACTOR }
[ MIXMIN ibm1 ] [ MIXMAX ibm2 ]
[ GRPMIN ngr1 ] [ GRPMAX ngr2 ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module DLEAK:.
TYPE	keyword used to set the leakage parameter that is differentiated.
DIFF	differentiation with respect to diffusion coefficients.
NTOT1	differentiation with respect to $P_1$ -weighted macroscopic total cross sections.
DELTA	keyword used to set the type of differentiation.
VALUE	differentiation with respect to the leakage parameter itself.
FACTOR	differentiation with respect to the correction factor $\mu$ .
MIXMIN	keyword used to set the first mixture where leakage parameters are differentiated. By default, the first mixture index is used.
<i>ibm1</i>	minimum mixture index where leakage parameters are differentiated.
MIXMAX	keyword used to set the last mixture where leakage parameters are differentiated. By default, the total number of mixtures in <i>MACRO</i> is used.
<i>ibm2</i>	maximum mixture index where leakage parameters are differentiated.
GRPMIN	keyword used to set the first energy group where leakage parameters are differentiated. By default, the first energy group index is used.
<i>ngr1</i>	minimum energy group index where leakage parameters are differentiated.
GRPMAX	keyword used to set the last energy group where leakage parameters are differentiated. By default, the total number of energy groups in <i>MACRO</i> is used.
<i>ngr2</i>	maximum energy group index where leakage parameters are differentiated.

## 7.2 The DSPH: module

The DSPH: module is used to create a delta MACROLIB (type L\_MACROLIB) with respect to SPH factor variation. Derivatives of diffusion coefficient and cross-section information (recovered from the input MACROLIB) are stored in the STEP heteroneneous list components present in the output MACROLIB. One component of the STEP heteroneneous list is created for each value of energy group  $g$  and for each value of mixture  $i$ .

The calling specifications are:

Table 90: Structure (DSPH:)

$DMACRO\ OPTIM := DSPH: MACRO :: (dsph\_data)$
--

where

**DMACRO**     **character\*12** name of a LCM object (type L\_MACROLIB) containing the delta MACROLIB information. *DMACRO* is created by the module. A STEP heteroneneous list is present in *DMACRO*.

**OPTIM**       **character\*12** name of a second LCM object (type L\_OPTIMIZE) created by the module. SPH factors are saved in the the control variable record 'VAR-VALUE' of *OPTIM* object. Input data defined in Sect. 7.2.1 is also saved in *OPTIM* object.

**MACRO**       **character\*12** name of the LCM object (type L\_MACROLIB) containing the input MACROLIB. (**dsph\_data**) structure containing the data to module DSPH: (see Sect. 7.2.1).

### 7.2.1 Data input for module DSPH:

Table 91: Structure (dsph\_data)

<pre>[ EDIT <i>iprint</i> ] [ SPH { PN   SN   ALBEDO } ] [ GRPMIN <i>ngr1</i> ] [ GRPMAX <i>ngr2</i> ] ;</pre>
--

where

**EDIT**       keyword used to set *iprint*.

*iprint*       index used to control the printing in module DSPH:.

**PN**       keyword to activate the calculation of heterogeneous SPH factors of diffusion, PN or SPN type.

SN	keyword to activate the calculation of heterogeneous SPH factors of PIJ, IC, SN or MOC type. This is the default option.
ALBEDO	keyword to activate the calculation of a unique SPH factor assigned to the albedo function in each energy group.
GRPMIN	keyword used to set the first energy group where SPH correction is applied. By default, the first energy group index is used.
<i>ngr1</i>	minimum energy group index where SPH correction is applied.
GRPMAX	keyword used to set the last energy group where SPH correction is applied. By default, the total number of energy groups in <i>MACRO</i> is used.
<i>ngr2</i>	maximum energy group index where SPH correction is applied.

### 7.3 The DREF: module

This module is used to set fixed sources that can be used in the right hand term of an adjoint fixed source eigenvalue problem. This type of equation appears in generalized perturbation theory (GPT) applications. The fixed sources set in DREF: are corresponding to the gradient of the RMS functional which is a measure of the discrepancy between actual and reference (or target) reaction rate distributions. The actual reaction rate distribution is recovered from a MICRO or MACRO object. The reference reaction rate distribution is recovered from a MICREF or MACREF object.

#### 7.3.1 Minimizing the RMS error of power distribution

The fixed sources are computed for the case where the OPTIMIZE object was initialized in module DLEAK:. This option is used with the OPTEX reflector model.<sup>[33]</sup>

Actual power values are defined as

$$P_i\{\phi(r)\} \equiv \langle H, \phi \rangle_i = \int_0^\infty dE \int_{V_i} d^3r H(\mathbf{r}, E) \phi(\mathbf{r}, E)$$

where the power factors  $H(\mathbf{r}, E)$  and fluxes  $\phi(\mathbf{r}, E)$  are recovered from H-FACTOR and FLUX-INTG records in a MACROLIB object.

The RMS error on power distribution is an homogeneous functional of the flux defined as

$$\mathcal{F}\{\phi(r)\} = \sum_i \left( \frac{\langle H, \phi \rangle_i}{\langle H, \phi \rangle} - \frac{P_i^*}{\sum_j P_j^*} \right)^2$$

where the reference (or target) powers  $P_i^*$  are obtained from the full-core reference transport calculation.

The gradient of functional  $\mathcal{F}\{\phi(r)\}$  is a  $G$ -group function of space defined as

$$\nabla \mathcal{F}\{\phi(\zeta); \mathbf{r}\} = \frac{2}{\langle H, \phi \rangle} \sum_i \left( \frac{\langle H, \phi \rangle_i}{\langle H, \phi \rangle} - \frac{P_i^*}{\sum_j P_j^*} \right) \left( \delta_i(\mathbf{r}) - \frac{\langle H, \phi \rangle_i}{\langle H, \phi \rangle} \right) \begin{bmatrix} H_1(\mathbf{r}) \\ H_2(\mathbf{r}) \\ \vdots \\ H_G(\mathbf{r}) \end{bmatrix}$$

where  $\delta_i(\mathbf{r}) = 1$  if  $\mathbf{r} \in V_i$  and  $= 0$  otherwise.

Each fixed source  $\nabla \mathcal{F}\{\phi(\zeta); \mathbf{r}\}$  is orthogonal to the flux  $\phi(\mathbf{r})$ .

#### 7.3.2 Minimizing the RMS error associated with SPH factor calculation

The fixed sources are computed for the case where the OPTIMIZE object was initialized in module DSPH:. Module DREF is call to compute the gradients required for computing SPH factors using an optimization algorithm (OPTEX in PLQ:, quasi-Newton in LNSR:, Newton in FPSPH:). Module DREF computes the direct gradients and the fixed sources to be used in a fixed-source eigenvalue problem originating from the generalized perturbation theory (GPT).

Fundamental mode conditions are the cases where no neutron is leaking due to the boundary conditions. In the case where the macro-calculation over macro-group  $g$  is done in non-fundamental mode conditions, it is proposed to apply a SPH correction on the *albedo functions* corresponding to boundaries with a non-conservative condition in the reference calculation.<sup>[38]</sup> If the macro calculation is performed in diffusion or  $P_1$  approximation, the albedo function  $\Lambda(\beta_g)$  corresponding to a non-conservative boundary is defined as

$$\Lambda(\beta_g) = \frac{1}{2} \frac{1 - \beta_g}{1 + \beta_g} \quad (7.1)$$



where  $\beta_g$  is the albedo in macro-group  $g$ . The net current  $\mathbf{J}_g(\mathbf{r})$  escaping the domain at point  $\mathbf{r}$  of the boundary is given by the *albedo boundary condition* as

$$-\mathbf{J}_g(\mathbf{r}) \cdot \mathbf{N}(\mathbf{r}) + \Lambda(\beta_g) \phi_g(\mathbf{r}) = 0 \quad \text{if } \mathbf{r} \in \partial V \quad (7.2)$$

where  $\partial V$  is the fraction of the domain where the non-conservative boundary condition is applied and  $\mathbf{N}(\mathbf{r})$  is the outgoing normal unit vector.

The integrated flux are defined over the macro-region  $m$  and macro-group  $g$  as

$$F_{m,g} \equiv \langle \phi \rangle_{m,g} = \int_{V_m} d^3r \phi_g(\mathbf{r}) \quad (7.3)$$

The net leakage  $L_g$  over each macro group due to non conservative boundary conditions is defined as

$$L_g \equiv \langle \Lambda \phi \rangle_g = \int_{\partial V} d^2r \Lambda(\beta_g) \phi_g(\mathbf{r}) = \int_{\partial V} d^2r \mathbf{J}_g(\mathbf{r}) \cdot \mathbf{N}(\mathbf{r}) . \quad (7.4)$$

In order to preserve the neutron balance in macro-group  $g$ , cross section data and albedo functions must all be SPH corrected. The correction specific to albedo functions is written

$$\tilde{\Lambda}_g = \mu_{M+1,g} \Lambda_g^* \quad (7.5)$$

where  $M$  is the total number of macro-regions and  $\Lambda_g^*$  is the albedo function of the reference calculation in macro-group  $g$ . This correction technique is proposed as an alternative to the discontinuity factor correction used by Ref. 39.

In fundamental mode conditions and in cases where Eq. (7.5) is used, an infinity of SPH factor sets can satisfy the reference reaction rates in each macro-group  $g$ . A unique set is selected with the application of an arbitrary normalization condition. The simplest option is to use the *flux-volume normalization condition* which consists to preserve the averaged flux in the lattice. This normalization condition, satisfied in each macro-group  $g$ , is written

$$\sum_{m=1}^M \int_{V_m} d^3r \tilde{\phi}_g(\mathbf{r}) = \sum_{m=1}^M F_{m,g}^* , \quad g \leq G \quad (7.6)$$

where  $F_{m,g}^*$  is the volume-integrated flux in macro-region  $V_m$  and macro-group  $g$  of the reference calculation.

Equation (7.6) can be rewritten as

$$\sum_{m=1}^M \frac{F_{m,g}^*}{\mu_{m,g}} = \sum_{m=1}^M F_{m,g}^* , \quad g \leq G. \quad (7.7)$$

The absorption rates are defined over the macro-region  $m$  and macro-group  $g$  as

$$P_{a,m,g} \equiv \langle \Sigma_a, \phi \rangle_{m,g} = \int_{V_m} d^3r \Sigma_{a,g}(\mathbf{r}) \phi_g(\mathbf{r}) \quad (7.8)$$

where  $i \leq I$  and  $g \leq G$  and where

$$\Sigma_{a,g}(\mathbf{r}) = \Sigma_g(\mathbf{r}) - \Sigma_{s,g}(\mathbf{r}). \quad (7.9)$$

The  $\nu$ -fission rates are defined over the macro-region  $m$  and macro-group  $g$  as

$$P_{f,m,g} \equiv \langle \nu \Sigma_f, \phi \rangle_{m,g} = \int_{V_m} d^3r \nu \Sigma_{f,g}(\mathbf{r}) \phi_g(\mathbf{r}) \quad (7.10)$$

where  $i \leq I$  and  $g \leq G$  and where  $\nu\Sigma_{f,g}(\mathbf{r})$  is the macroscopic fission cross section multiplied by the averaged number of neutrons emitted per fission.

The absorption and  $\nu$ -fission cross sections are corrected according to

$$\Sigma_{a,m,g} = \mu_{m,g} \Sigma_{a,m,g}^* = \mu_{m,g} \frac{P_{a,m,g}^*}{F_{m,g}^*} \quad (7.11)$$

and

$$\nu\Sigma_{f,m,g} = \mu_{m,g} \nu\Sigma_{f,m,g}^* = \mu_{m,g} \frac{P_{f,m,g}^*}{F_{m,g}^*} \quad (7.12)$$

where the reference integrated fluxes  $F_{m,g}^*$  are also obtained from the full-core reference transport calculation. The SPH factors are normalized in each macro energy group according to

$$\sum_{j=1}^M \frac{F_{j,g}^*}{\mu_{j,g}} = \sum_j F_{j,g}^* , \quad g \leq G. \quad (7.13)$$

The RMS error on absorption distribution is an homogeneous functional of the flux defined as

$$\mathcal{F}\{\phi(\mathbf{r})\} = \sum_{m=1}^{M+2} \sum_{g=1}^G (f_{m,g}\{\phi(\mathbf{r})\})^2 \quad (7.14)$$

where the components  $f_{m,g}\{\phi(\mathbf{r})\}$  are the  $M + 2$  conditions to satisfy in each macro-group. They are defined as

$$f_{m,g}\{\phi(\mathbf{r})\} = \begin{cases} \frac{\langle \Sigma_a, \phi \rangle_{m,g}}{\langle \Sigma_a, \phi \rangle} \frac{P_{a,tot}^*}{\Delta_{a,m,g}} - \frac{P_{a,m,g}^*}{\Delta_{a,m,g}} & \text{if } m \leq M \\ \sqrt{M} \left( \frac{\langle \Lambda + \Sigma_a, \phi \rangle_g}{\langle \nu\Sigma_f, \phi \rangle} \frac{P_{f,tot}^*}{\Delta_{L,g}} - \frac{L_g^* + P_{a,g}^*}{\Delta_{L,g}} \right) & \text{if } m = M + 1 \\ \frac{1}{F_g^*} \sum_{j=1}^M \frac{F_{j,g}^*}{\mu_{j,g}} - 1 & \text{if } m = M + 2 \end{cases} \quad (7.15)$$

with

$P_{a,m,g}^*$  = reference (or target) absorption rates obtained from the full-core reference transport calculation

$P_{f,m,g}^*$  = reference (or target)  $\nu$ -fission rates obtained from the full-core reference transport calculation

$\Delta_{a,m,g}$  = low limit absorption rates defined as  $\max(10^{-4}P_{a,tot}^*, P_{a,m,g}^*)$  in order to avoid division by small numbers.

$L_g^*$  = reference leakage in macro-group  $g$

$\Lambda(\mathbf{r})$  = albedo function defined on the non-conservative boundaries  $\partial V$  of the domain

$\Delta_{L,g}$  = low limit leakage defined as  $\max(10^{-4}P_{f,tot}^*, L_g^* + P_{a,g}^*)$  in order to avoid division by small numbers.

and where  $P_{a,g}^* = \sum_m P_{a,m,g}^*$ ,  $P_{a,tot}^* = \sum_g P_{a,g}^*$ ,  $P_{f,tot}^* = \sum_m \sum_g P_{f,m,g}^*$  and  $F_g^* = \sum_m F_{m,g}^*$ .

The condition  $m = M + 1$  in Eq. (7.15) is based on the preservation of the effective multiplication factor of the core. The SPH normalization relations (7.7) are included in the RMS error in order to simplify the optimization process.

The gradient of functional (7.14) with respect to a variation of flux  $\phi$  is a  $G$ -group function of space whose components are defined as

$$\nabla \mathcal{F}_g\{\phi(\zeta); \mathbf{r}\} = \left[ \frac{d}{d\epsilon} \mathcal{F}\{\phi(\zeta) + \epsilon \delta_g(\zeta - \mathbf{r})\} \right]_{\epsilon=0} ; \quad g = 1, G \quad (7.16)$$

where  $\delta_g(\zeta - \mathbf{r})$  is a multidimensional Dirac delta distribution defined as

$$\delta_g(\zeta - \mathbf{r}) = \text{col} [\delta_{g,h} \delta(\zeta - \mathbf{r}), h = 1, G] \quad (7.17)$$

where  $\delta_{g,h}$  is a Kronecker delta function and  $\delta(\zeta - \mathbf{r})$  is the classical Dirac delta distribution.

Next, we evaluate the gradient of each component  $f_{m,g}\{\phi(\mathbf{r})\}$  with respect to the SPH factors and we construct a rectangular matrix  $\mathbb{A}$ , of size  $(M+2)G \times (M+1)G$ , defined as

$$\mathbb{A} = \left\{ \frac{\partial f_{m,g}}{\partial \mu_{n,h}}; m \leq M+2, n \leq M+1, g \leq G, h \leq G \right\}. \quad (7.18)$$

We first evaluate the direct contribution of these derivatives for a variation of the SPH factors assigned to cross sections (i.e., for  $n \leq M$ ). Direct contributions are the chain rule terms not involving a variation in flux. These direct gradients are

$$\left. \frac{\partial f_{m,g}}{\partial \mu_{n,h}} \right|_{\text{direct}} = \frac{\langle \Sigma_a, \phi \rangle_{m,g}}{\mu_{n,h} \langle \Sigma_a, \phi \rangle} \frac{P_{a,\text{tot}}^*}{\Delta_{a,m,g}} \left( \delta_{m,n} \delta_{g,h} - \frac{\langle \Sigma_a, \phi \rangle_{n,h}}{\langle \Sigma_a, \phi \rangle} \right) \quad \text{if } m \leq M \quad (7.19)$$

$$\left. \frac{\partial f_{M+1,g}}{\partial \mu_{n,h}} \right|_{\text{direct}} = \frac{\sqrt{M}}{\mu_{n,h} \langle \nu \Sigma_f, \phi \rangle} \frac{P_{f,\text{tot}}^*}{\Delta_{L,g}} \left( \delta_{g,h} \langle \Sigma_a, \phi \rangle_{n,h} - \langle \Lambda + \Sigma_a, \phi \rangle_g \frac{\langle \nu \Sigma_f, \phi \rangle_{n,h}}{\langle \nu \Sigma_f, \phi \rangle} \right) \quad (7.20)$$

and

$$\left. \frac{\partial f_{M+2,g}}{\partial \mu_{n,h}} \right|_{\text{direct}} = -\delta_{g,h} \frac{F_{n,g}^*}{\mu_{n,g}^2 F_g^*}. \quad (7.21)$$

The SPH factors assigned to the albedo functions are not responsible for any direct contributions to the derivatives of component  $f_{m,g}\{\phi(\mathbf{r})\}$ . Consequently,

$$\left. \frac{\partial f_{m,g}}{\partial \mu_{M+1,h}} \right|_{\text{direct}} = 0. \quad (7.22)$$

The indirect gradient of each component  $f_{m,g}\{\phi(\mathbf{r})\}$  with respect to the SPH factors are an effect of *flux variation* and are obtained using *generalized perturbation theory* (GPT). The gradient of functional  $f_{m,g}\{\phi(\mathbf{r})\}$  with respect to a variation of flux is a  $G$ -group function of space defined as

$$\nabla f_{m,g}\{\phi(\zeta); \mathbf{r}\} = \begin{bmatrix} f_{m,g,1}\{\phi(\zeta); \mathbf{r}\} \\ f_{m,g,2}\{\phi(\zeta); \mathbf{r}\} \\ \vdots \\ f_{m,g,G}\{\phi(\zeta); \mathbf{r}\} \end{bmatrix} \quad (7.23)$$

where the group- $h$  components are

$$\nabla f_{m,g,h}\{\phi(\zeta); \mathbf{r}\} = \frac{\Sigma_{a,h}(\mathbf{r})}{\langle \Sigma_a, \phi \rangle} \frac{P_{a,\text{tot}}^*}{\Delta_{a,m,g}} \left( \delta_m(\mathbf{r}) \delta_{g,h} - \frac{\langle \Sigma_a, \phi \rangle_{m,g}}{\langle \Sigma_a, \phi \rangle} \right) \quad \text{if } m \leq M \quad (7.24)$$

where  $\delta_m(\mathbf{r}) = 1$  if  $\mathbf{r} \in V_m$  and  $= 0$  otherwise,

$$\begin{aligned} \nabla f_{M+1,g,h}\{\phi(\zeta); \mathbf{r}\} &= \frac{\sqrt{M}}{\langle \nu \Sigma_f, \phi \rangle} \frac{P_{f,\text{tot}}^*}{\Delta_{L,g}} \left[ (\Lambda_h(\mathbf{r}) + \Sigma_{a,h}(\mathbf{r})) \delta_{g,h} \right. \\ &\quad \left. - \nu \Sigma_{f,h}(\mathbf{r}) \frac{\langle \Lambda + \Sigma_a, \phi \rangle_g}{\langle \nu \Sigma_f, \phi \rangle} \right] \end{aligned} \quad (7.25)$$

and

$$\nabla f_{M+2,g,h}\{\phi(\zeta); \mathbf{r}\} = 0. \quad (7.26)$$

We first compute the gradient  $\mathbf{g}$  of the RMS error with respect to a variation of the SPH factors. We define three column vectors as

$$\mathbf{f} = \text{col} \{ f_{m,g} \{ \phi(\mathbf{r}) \} ; \quad m \leq M+2, \quad g \leq G \}, \quad (7.27)$$

$$\nabla \mathbf{f} = \text{col} \{ \nabla f_{m,g} \{ \phi(\zeta); \mathbf{r} \} ; \quad m \leq M+2, \quad g \leq G \} \quad (7.28)$$

and

$$\mathbf{g} = \text{col} \left\{ \frac{\partial \mathcal{F} \{ \phi(\mathbf{r}) \}}{\partial \mu_{n,h}} ; \quad n \leq M+1, \quad h \leq G \right\}. \quad (7.29)$$

From Eqs. (7.14) and (7.16), we have

$$\mathcal{F} \{ \phi(\mathbf{r}) \} = \mathbf{f}^\top \mathbf{f} \quad (7.30)$$

and

$$\nabla \mathcal{F} \{ \phi(\zeta); \mathbf{r} \} = 2 \mathbf{f}^\top \nabla \mathbf{f} \quad (7.31)$$

so that

$$\frac{\partial \mathcal{F}}{\partial \mu_{n,h}} = 2 \sum_{m=1}^{M+2} \sum_{g=1}^G f_{m,g} \frac{\partial f_{m,g}}{\partial \mu_{n,h}} \quad (7.32)$$

where the derivatives of  $f_{m,g}$  are computed taking into account both direct and indirect contributions:

$$\frac{\partial f_{m,g}}{\partial \mu_{n,h}} = \left. \frac{\partial f_{m,g}}{\partial \mu_{n,h}} \right|_{\text{direct}} + \left\langle \nabla f_{m,g} \{ \phi(\zeta); \mathbf{r} \}, \frac{\partial}{\partial \mu_{n,h}} \phi(\mathbf{r}) \right\rangle \quad (7.33)$$

and where the bracket stands for a summation over the  $G$  energy groups and an integration over the domain. The flux derivatives  $\partial \phi / \partial \mu_{n,h}$  are  $G$ -group functions obtained using generalized perturbation theory.

Equation (7.32) can be rewritten in matrix form as

$$\mathbf{g} = 2 \mathbb{A}^\top \mathbf{f}. \quad (7.34)$$

The bracket term in Eq. (7.33) is computed by module **GRAD:**, outside module **DREF:**. Module **GRAD:** compute only the *direct contributions* of the gradients:

- By default, the objective function  $\mathcal{F} \{ \phi(\mathbf{r}) \}$  and direct components of vector  $\mathbf{g}$  are computed.
- If keyword **NEWTON** is set, individual components  $f_{m,g} \{ \phi(\mathbf{r}) \}$  and direct components of matrix  $\mathbb{A}$  are computed.

### 7.3.3 Calling specifications

The calling specifications for module **DREF:** are:

Table 92: Structure (**DREF:**)

```
SOURCE OPTIM := DREF: OPTIM FLUX TRACK { MICRO | MACRO }
{ MICREF | MACREF }
[ :: [ EDIT iprint ] [ NODERIV ] [ NEWTON ] [ RMS >>RMS_VAL<< ] ] ;
```

where

<i>SOURCE</i>	<b>character*12</b> name of a FIXED SOURCES (type <b>L_SOURCE</b> ) object open in creation mode. This object contains the adjoint fixed source corresponding to the RMS error on power distribution.
<i>OPTIM</i>	<b>character*12</b> name of the OPTIMIZE object ( <b>L_OPTIMIZE</b> signature) containing the optimization informations. Object <i>OPTIM</i> must appear on both LHS and RHS to be able to update the previous values.
<i>FLUX</i>	<b>character*12</b> name of the actual FLUX (type <b>L_FLUX</b> ) object open in read-only mode.
<i>TRACK</i>	<b>character*12</b> name of the actual TRACKING (type <b>L_TRACK</b> ) object open in read-only mode.
<i>MICRO</i>	<b>character*12</b> name of the actual MICROLIB (type <b>L_LIBRARY</b> ) object open in read-only mode. The information on the embedded macrolib is used.
<i>MACRO</i>	<b>character*12</b> name of the actual MACROLIB (type <b>L_MACROLIB</b> ) object open in read-only mode.
<i>MICREF</i>	<b>character*12</b> name of reference (or target) MICROLIB (type <b>L_LIBRARY</b> ) object open in read-only mode. The information contained in the embedded macrolib is used to compute $P_i^*$ values.
<i>MACREF</i>	<b>character*12</b> name of reference (or target) MACROLIB (type <b>L_MACROLIB</b> ) object open in read-only mode. This information is used to compute $P_i^*$ values.
<i>EDIT</i>	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module <b>DREF</b> :. =0 for no print; =1 for minimum printing (default value).
<i>NODERIV</i>	keyword used to stop processing of <b>DREF</b> : module after calculation of objective function. By default, information related to the gradient of the RMS functional is also computed.
<i>NEWTON</i>	keyword used to enable the detailed calculation of gradient for all components of the objective function, as required by a full Newtonian approach. By default, only the gradient of the objective function is computed.
<i>RMS</i>	keyword used to recover the RMS error on power or absorption distribution in a CLE-2000 variable.
<i>RMS_VAL</i>	<b>character*12</b> CLE-2000 variable name in which the extracted RMS value will be placed. This variable should be declared real or double precision.

#### 7.4 The GRAD: module

The GRAD: module is designed to perform the following tasks:

- compute the gradients of the *system characteristics* (i.e., objective function and constraints) using solutions of direct or adjoint fixed source eigenvalue problems. Here, we assume an optimization problem with *nvar* control variables and with *ncst* constraints. The total number of system characteristics is therefore equal to *ncst*+1.
- define options and parameters related to the optimization problem.

The calling specifications are:

Table 93: Structure GRAD:

*OPTIM* := GRAD: [ *OPTIM* ] *DFLUX* *GPT* :: (grad\_data)

where

<i>OPTIM</i>	<b>character*12</b> name of the OPTIMIZE object (L_OPTIMIZE signature) containing the optimization informations. Object <i>OPTIM</i> must appear on the RHS to be able to updated the previous values.
<i>DFLUX</i>	<b>character*12</b> name of the FLUX object (L_FLUX signature) containing a set of solutions of fixed-source eigenvalue problems.
<i>GPT</i>	<b>character*12</b> name of the SOURCE object (L_SOURCE signature) containing a set of direct or adjoint sources.
(grad_data)	structure containing the data to the module GRAD: (see Sect. 7.4.1).

##### 7.4.1 Data input for module GRAD:

Table 94: Structure grad\_data

```
[ EDIT iprint ]
[ { MAXIMIZE | MINIMIZE } ]
[ OUT-STEP-LIM sr ]
[ VAR-VALUE ( control(i), i=1,nvar ) ] [ VAR-WEIGHT ( weight(i), i=1,nvar ) ]
[ VAR-VAL-MIN { ( vecmin(i), i=1,nvar ) | ALL varmin ]
[ VAR-VAL-MAX { ( vecmax(i), i=1,nvar ) | ALL varmax ]
[ FOBJ-CST-VAL ( funct(i), i=1,ncst+1 ) ]
[ CST-TYPE ( type(i), i=1,ncst ) ] [ CST-OBJ { ( cstval(i), i=1,ncst ) | KEEP } ]
[ CST-WEIGHT ( cstw(i), i=1,ncst ) ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module.
MAXIMIZE	keyword used to specify that the optimization problem will be a maximization.
MINIMIZE	keyword used to specify that the optimization problem will be a minimization (default).
OUT-STEP-LIM	keyword used to set or reset the maximum steplength along the gradient (default value is $sr = 1.0$ or the value recovered from <i>OPTIM</i> ).
<i>sr</i>	maximum steplength value (real).
VAR-VALUE	keyword to specify the values of the control variables. These values can also be set in a previous call to module <b>GRAD</b> : or set in another module.
<i>control</i>	array containing <i>nvar</i> real values.
VAR-WEIGHT	keyword to specify the values of the control variable weights in the quadratic constraint. All weights are set to 1.0 by default.
<i>weight</i>	array containing <i>nvar</i> real values.
VAR-VAL-MIN	keyword to specify the minimum values of the control variables. These values can also be set in a previous call to module <b>GRAD</b> :.
<i>vecmin</i>	array containing <i>nvar</i> real values.
<i>varmin</i>	single real value used for all control variables.
VAR-VAL-MAX	keyword to specify the maximum values of the control variables. These values can also be set in a previous call to module <b>GRAD</b> :.
<i>vecmax</i>	array containing <i>nvar</i> real values.
<i>varmax</i>	single real value used for all control variables.
FOBJ-CST-VAL	keyword to specify the value of the objective function followed by the actual values of the constraints. These values can also be set in a previous call to module <b>GRAD</b> : or set in another module.
<i>funct</i>	array containing <i>ncst</i> +1 real values.
CST-TYPE	keyword to specify the relation types of the constraints. These values can also be set in a previous call to module <b>GRAD</b> :.
<i>type</i>	array containing <i>ncst</i> integer values. These values are: $= -1$ for $\geq$ , $= 0$ for equality and $= 1$ for $\leq$ .
CST-OBJ	keyword to specify the RHS values of the constraints. These values can also be set in a previous call to module <b>GRAD</b> :.
<i>cstval</i>	array containing <i>ncst</i> real values.
KEEP	keyword to specify that the RHS values of the constraints are identical to the values of the previous iteration.
CST-WEIGHT	keyword to specify the weights (or penalties) of the constraints. These weights are not used with Lemke or MAP methods. These values can also be set in a previous call to module <b>GRAD</b> :.
<i>cstw</i>	array containing <i>ncst</i> real values.

### 7.5 The PLQ: module

The PLQ: module is used to solve a general non-linear optimization problem with constraints using the Optex method.<sup>[1,31–33]</sup> The PLQ: module performs a single iteration of the Optex method where a linearized optimization problem is solved with a quadratic constraint. This quadratic constraint is of the form

$$\sum_{i=1}^{nvar} \omega_i \left( \Delta x_i^{(n)} \right)^2 \leq \left( S^{(n)} \right)^2$$

where  $\omega_i$  is a weight defined after keyword CST-WEIGHT in module GRAD: and  $\Delta x_i^{(n)}$  is a displacement for  $i$ -th control variable at iteration  $(n)$ . The initial value of radius  $S^{(1)}$  is defined after keyword OUT-STEP-LIM.

The gradients of the *system characteristics* can be calculated with module GRAD:. The PLQ: module is also used to define options and parameters for the different method to solve the optimization problem and to reduces the radius  $S^{(n)}$  of the quadratic constraint.

The calling specifications are:

Table 95: Structure PLQ:

*OPTIM* := PLQ: *OPTIM* :: (plq\_data)

where

*OPTIM*                      character\*12 name of the OPTIMIZE object (L\_OPTIMIZE signature) containing the optimization informations. Object *OPTIM* must appear on both LHS and RHS to be able to update the previous values.

(plq\_data)                structure containing the data to the module PLQ: (see Sect. 7.5.1).

#### 7.5.1 Data input for module PLQ:

Table 96: Structure plq\_data

```
[ EDIT iprint ]
[ { MAXIMIZE | MINIMIZE } ]
[ METHOD { SIMPLEX | LEMKE | MAP | AUG-LAGRANG | PENAL-METH } ]
[ OUT-STEP-LIM sr ]
[ OUT-STEP-EPS  $\epsilon_{ext}$  ] [ INN-STEP-EPS  $\epsilon_{inn}$  ]
[ CST-QUAD-EPS  $\epsilon_{quad}$  ]
[ STEP-REDUCT { HALF | PARABOLIC } ]
[ WARNING-ONLY ]
CALCUL-DX [ NO-STORE-OLD ]
[ COST-EXTRAP >> ecost << ]
[ OUT-CONV-TST >> lconv << ]
;
```



where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module.
MAXIMIZE	keyword used to specify that the optimization problem will be a maximization.
MINIMIZE	keyword used to specify that the optimization problem will be a minimization (default).
METHOD	keyword used to define the quasi-linear programming method. <b>Note:</b> If the general Lemke method is used, the quadratic constraint must be active. The strategy consists to proceed in two steps: <ul style="list-style-type: none"> <li>• At first step, the linear programming problem (i. e., without the quadratic constraint) is solved and the control-variable displacement is computed. If this displacement is less than the radius of the quadratic constraint, the step one solution is accepted and step two is not performed. If this displacement is greater than the radius of the quadratic constraint, the step one solution is rejected and step two is performed. Step one can be solved with the SIMPLEX method or with the linear LEMKE method.</li> <li>• At step two, the general LEMKE method is used to find the correct solution. The general Lemke method is based on a parametric linear complementarity principle, as explained in Ref. 42.</li> </ul>
SIMPLEX	keyword used to specify that the SIMPLEX method will be used at step one and the general LEMKE method at step two.
LEMKE	keyword used to specify that the linear LEMKE method will be used at step one and the general LEMKE method at step two.
MAP	keyword used to specify that the MAP method will be used. The quadratic constraint is linearized and a converging sequence of SIMPLEX calculations is performed.
AUG-LAGRANG	keyword used to specify that the augmented Lagrangian method will be used.
PENAL-METH	keyword used to specify that the penalty method will be used.
OUT-STEP-LIM	keyword used to set or reset the initial radius of the quadratic constraint (default value is $sr = 1.0$ or the value recovered from <i>OPTIM</i> ).
<i>sr</i>	initial radius of the quadratic constraint (real or double precision).
OUT-STEP-EPS	keyword used to set the tolerance of outer iteration convergence inside module <i>PLQ</i> : (default value is $1.0 \times 10^{-4}$ ).
$\epsilon_{ext}$	tolerance value (real or double precision).
INN-STEP-EPS	keyword used to set the tolerance used within the SIMPLEX or LEMKE method (default value is $1.0 \times 10^{-4}$ ).
$\epsilon_{inn}$	tolerance value (real or double precision).
CST-QUAD-EPS	keyword to set the convergence parameter <i>epsilon4</i> for the radius of the quadratic constraint inside module <i>GRAD</i> :.
$\epsilon_{quad}$	tolerance for convergence of the radius of the quadratic constraint (real).
STEP-REDUCT	keyword used to define the method of the reduction of the outer step.

HALF	keyword used to specify that the step will be reduced by a factor of 2.
PARABOLIC	keyword used to specify that the step will be reduced with the parabolic method.
WARNING-ONLY	keyword used to specify that only a warning will be used when no valid previous decision vectors can be recall in case of error of the mathematical programming.
CALCUL-DX	keyword used to specify that the new step will be calculated.
NO-STORE-OLD	keyword used to specify that the old value of decision variables and gradients will not be stored in the L_OPTIMIZE/'OLD-VALUE' directory.
COST-EXTRAP	keyword used to calculate the extrapolated objective constant <i>ecost</i> .
<i>ecost</i>	extrapolated objective constant.
OUT-CONV-TST	keyword used to calculate if the external convergence has been reached.
$l_{conv}$	= 1 means that external convergence has been reached; = 0 otherwise.

## 7.6 The LNSR: module

The LNSR: module performs a single iteration of the line search algorithm, used as inner iteration of steepest descent, conjugate gradient or quasi-Newton optimization techniques.<sup>[34]</sup> The Armijo line search algorithm is used.<sup>[35]</sup> The LNSR: module is generally used inside an inner loop, as depicted in Fig 14.




Figure 14: Line search iterations.

The calling specifications are:

Table 97: Structure LNSR:

$OPTIM := LNSR: OPTIM :: (lnsr\_data)$
--

where

*OPTIM*      **character\*12** name of the OPTIMIZE object (L\_OPTIMIZE signature) containing the optimization informations. Object *OPTIM* must appear on both LHS and RHS to be able to update the previous values.

(*lnsr\_data*)      structure containing the data to the module LNSR: (see Sect. 7.7.1).

## 7.6.1 Data input for module LNSR:

Table 98: Structure `lnsr_data`

```
[ EDIT iprint ]
[ { MAXIMIZE | MINIMIZE } ]
[ OUT-STEP-LIM sr ]
[ OUT-STEP-EPS  $\epsilon_{ext}$  ] [ INN-STEP-EPS  $\epsilon_{inn}$  ]
OUT-ITER-MAX maxE
[ OUT-RESTART nstart ]
[ { SD | CG | BFGS | LBFGS [ hist_nr ] | NEWT } ]
[ INN-CONV-TST >>  $l_{convI}$  << OUT-CONV-TST >>  $l_{convE}$  << ]
;
```

where

EDIT	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module.
MAXIMIZE	keyword used to specify that the optimization problem will be a maximization.
MINIMIZE	keyword used to specify that the optimization problem will be a minimization (default).
OUT-STEP-LIM	keyword used to set or reset the maximum stepsize for the line search (default value is $sr = 1.0$ or the value recovered from <i>OPTIM</i> ).
<i>sr</i>	initial radius of the stepsize (real or double precision).
OUT-STEP-EPS	keyword used to set the tolerance of outer iteration convergence inside module LNSR: (default value is $1.0 \times 10^{-4}$ ).
$\epsilon_{ext}$	tolerance value (real or double precision).
INN-STEP-EPS	keyword used to set the tolerance used for the line search algorithm (default value is $1.0 \times 10^{-4}$ ).
$\epsilon_{inn}$	tolerance value (real or double precision).
OUT-ITER-MAX	keyword used to set the maximum number of external iterations.
<i>maxE</i>	maximum number of external iterations.
OUT-RESTART	keyword used to set the external iteration restart cycle. A new recursion cycle is restarted from the conjugate gradient method. By default, no restart is performed.
<i>nstart</i>	number of iterations in one external iteration restart cycle.
SD	steepest descent method (default option).
CG	conjugate gradient method.
BFGS	Broyden-Fletcher-Goldfarb-Shanno method. <sup>[34]</sup>

LBFGS	Memory limited Broyden-Fletcher-Goldfarb-Shanno method. <sup>[36]</sup>
<i>hist_nr</i>	number of corrections used in the memory limited Broyden-Fletcher-Goldfarb-Shanno method (default value is 10).
NEWT	Newton method for unconstrained optimization. <sup>[37]</sup>
INN-CONV-TST	keyword used to determine if the line search convergence has been reached.
<i>l_convI</i>	= 1 means that line search convergence has been reached; = 0 otherwise.
OUT-CONV-TST	keyword used to determine if the external convergence has been reached.
<i>l_convI</i>	= 1 means that external convergence has been reached; = 0 otherwise.

### 7.7 The FPSPH: module

The FPSPH: module performs a single fixed-point (aka. Picard) or Newton SPH iteration. This module is intended to be used in a REPEAT UNTIL loop, implemented in CLE-2000 macro-language, where the macro calculation is explicitly called, as depicted in Figs. 15 and 16.




Figure 15: Fixed point SPH iterations.




Figure 16: Newton SPH iterations.

The calling specifications are:

Table 99: Structure FPSPH:

```
OPTIM := FPSPH: [ OPTIM ] MACROLIB MACROREF :: (fpsph_data)
```

where

<i>OPTIM</i>	<b>character*12</b> name of the OPTIMIZE object (L_OPTIMIZE signature) containing the SPH factors. At the first call, object <i>OPTIM</i> must appear on LHS to receive its initial values. On subsequent calls, object <i>OPTIM</i> must appear on both LHS and RHS to be able to update the previous values.
<i>MACROLIB</i>	<b>character*12</b> name of the read-only extended MACROLIB object (L_MACROLIB signature) containing the macroscopic cross sections used by the macro-calculation and fluxes produced by the macro-calculation.
<i>MACROREF</i>	<b>character*12</b> name of the read-only extended MACROLIB object (L_MACROLIB signature) containing the reference macroscopic cross sections and fluxes.
<b>(fpsph_data)</b>	structure containing the data to the module FPSPH: (see Sect. 7.7.1).

#### 7.7.1 Data input for module FPSPH:

Table 100: Structure fpsph\_data

```
[ EDIT iprint ]
[ SPH { PN | SN } ]
[ GRPMIN ngr1 ] [ GRPMAX ngr2 ]
[ OUT-STEP-EPS  $\epsilon_{ext}$  ]
[ VAR-VAL-MIN varmin ] [ VAR-VAL-MAX varmax ]
[ OUT-CONV-TST >>  $l_{conv}$  << ]
;
```

where

<b>EDIT</b>	keyword used to set <i>iprint</i> .
<i>iprint</i>	index used to control the printing in module.
<b>PN</b>	keyword to activate a calculation of heterogeneous SPH factors of diffusion, PN or SPN type.
<b>SN</b>	keyword to activate a calculation of heterogeneous SPH factors of PIJ, IC, SN or MOC type. This is the default option.

GRPMIN	keyword used to set the first energy group where SPH correction is applied. By default, the first energy group index is used.
<i>ngr1</i>	minimum energy group index where SPH correction is applied.
GRPMAX	keyword used to set the last energy group where SPH correction is applied. By default, the total number of energy groups in <i>MACROLIB</i> is used.
<i>ngr2</i>	maximum energy group index where SPH correction is applied.
OUT-STEP-EPS	keyword used to set the tolerance of SPH iteration convergence inside module <b>FPSPH</b> : (default value is $1.0 \times 10^{-4}$ ).
$\epsilon_{ext}$	tolerance value (real or double precision).
VAR-VAL-MIN	keyword to specify the minimum values of the SPH factors. These values can also be set in a previous call to module <b>GRAD</b> :
<i>varmin</i>	single real value used for all SPH factors.
VAR-VAL-MAX	keyword to specify the maximum values of the SPH factors. These values can also be set in a previous call to module <b>GRAD</b> :
<i>varmax</i>	single real value used for all SPH factors.
OUT-CONV-TST	keyword used to determine if the SPH convergence has been reached.
<i>l<sub>conv</sub></i>	= 1 means that SPH convergence has been reached; = 0 otherwise.



## 8 PIN-POWER RECONSTRUCTION MODULES

This section is related to pin-power reconstruction capabilities available in Donjon. The corresponding theory is explained in [48, 49]

### 8.1 The NAP: module

The NAP: module supplies the main transport-diffusion equivalence options to DRAGON and DONJON. It can be used to perform the pin power reconstruction.[48, 49] The calling specifications are:

Table 101: Structure (NAP:)

```
COMPO := NAP: COMPO TRKNAM FLUNAM :: (descnap1)
MAP := NAP: MAP TRKNAM FLUNAM MATEX MACRES :: (descnap2)
GEONEW := NAP: GEOOLD COMPO :: (descnap3)
```

where

<i>COMPO</i>	<b>character*12</b> name of the MULTICOMPO data structure (L_COMPO signature) where the detailed subregion properties will be stored.
<i>TRKNAM</i>	<b>character*12</b> name of the read-only TRACKING data structure (L_TRACK signature) containing the tracking.
<i>FLUNAM</i>	<b>character*12</b> name of the read-only FLUXUNK data structure (L_FLUX signature) containing a transport solution.
<i>MAP</i>	<b>character*12</b> name of the MAP data structure (L_MAP signature) containing fuel regions description, global and local parameter information (burnup, fuel/coolant temperatures, coolant density, etc). A previous call to the FLPOW: module is highly recommended prior to the pin-power reconstruction to normalize the flux and compute the assembly power. If not, the pin-power reconstruction will be normalized using the whole core power instead of a normalization for each assembly. Keyword PPR is expected in (descnap2).
<i>MATEX</i>	<b>character*12</b> name of the read-only MATEX data structure (L_MATEX signature). The object corresponds to the heterogeneously splited geometry. Keyword PPR is expected in (descnap2).
<i>MACRES</i>	<b>character*12</b> name of the read-only MACROLIB data structure (L_MACROLIB signature) containing a cross section for the fuel. The MACROLIB data structure must have been created with a MULTICOMPO data structure with pin level properties (transport flux, H-factor, infinite domain diffusion flux). Keyword PPR is expected in (descnap2).
<i>GEONEW</i>	<b>character*12</b> name of the created GEOMETRY data structure (L_GEOM signature) containing the detailed core geometry definition at heterogeneous assembly level.
<i>GEOOLD</i>	<b>character*12</b> name of the read-only GEOMETRY data structure (L_GEOM signature) containing the core geometry definition with homogeneous assembly (only 1 mesh per assembly mandatory).
(descnap1)	structure containing the input data to this module to compute additional properties for subregions (see Section 8.1.1).

- (**descnap2**) structure containing the input data to this module to perform pin power reconstruction (see Section 8.1.2).
- (**descnap3**) structure containing the input data to this module to automatically define the core geometry with heterogeneous assembly (see Section 8.1.3).

### 8.1.1 Additional properties calculations

Table 102: Structure (**descnap1**)

```
[ EDIT iprint ]
PROJECTION
STEP namedir
[ IFX ifx ]
{ [[ SET pname pvalue ]] }
;
```

where

EDIT	keyword used to modify the print level <i>iprint</i> .
<i>iprint</i>	integer index used to control the printing in module <b>NAP</b> :. =0 for no print; =1 for minimum printing (default value); larger values of <i>iprint</i> will produce increasing amounts of output.
PROJECTION	keyword to specify that additional properties for subregions will be computed and stored in the MULTICOMPO data-structure <i>COMPO</i> .
STEP	keyword to specify <i>namedir</i> .
<i>namedir</i>	name of the directory containing the homogenized cross sections (homogeneous or heterogeneous).
IFX	keyword to specify <i>ifx</i> .
<i>ifx</i>	number used to create the name of the flux record representing $\psi_{m,p}^{d,\infty}$ . This flux represents the results of calculation in an infinite domain computed in diffusion with cross sections homogenized either homogeneously or heterogeneously. One record is associated with each type of homogenization when the MULTICOMPO is created. Thus MULTICOMPO can be "enriched" up to 5 times, each time using a different homogenization of the assembly at the end of the transport calculations. The following format is used for the flux record name ( <b>RECNAME</b> ): WRITE( <b>RECNAME</b> , '5HFINF_', I3.3') IFX Thus, for example for <i>ifx</i> =2, <b>RECNAME</b> would be FINF_002.
SET	keyword to specify assembly calculations at which $\psi_{m,p}^{d,\infty}$ have been calculated. Repeated as many times as there are parameters in the MULTICOMPO.
<i>pname</i>	name of the parameter in the MULTICOMPO.

*pvalue* value of the parameter in the MULTICOMPO.

Note that in the case of heterogeneously homogenized assembly, the pin-wise projected diffusion flux is stored in mixture 1.

### 8.1.2 Pin power reconstruction

Table 103: Structure (**descnap2**)

```
[ EDIT iprint ]
PPR
NZASS nzass
METH GPPR ifx
[ POWER pow ]
;
```

where

EDIT	keyword used to modify the print level <i>iprint</i> .
<i>iprint</i>	index used to control the printing of this module. The <i>iprint</i> parameter is important for adjusting the amount of data that is printed by this calculation step: <ul style="list-style-type: none"> <li>• <i>iprint</i>=0 results in no output;</li> <li>• <i>iprint</i>=1 ...</li> </ul>
PPR	keyword to perform pin power reconstruction and stored results in the MAP data-structure <i>MAP</i> .
NZASS	keyword to specify <i>nzass</i> .
<i>nzass</i>	number of mesh in Z direction along assemblies.
METH	keyword to select the type of methodology used for pin power reconstruction.
GPPR	keyword to select the generalized pin power reconstruction from an heterogeneous assembly definition (several mixtures per assembly). Note that if there is only one mixture (homogeneous assembly) this method is actually the regular pin power reconstruction.
<i>ifx</i>	number used to create the named of the flux record representing $\psi_{m,p}^{d,\infty}$ . See Sect. 8.1.1 for more details.
POWER	keyword used to normalize the flux. If this keyword is not used, the flux directly computed by the FLUD: is used to perform the pin-power reconstruction, then normalization has to be performed either previously by the FLPOW: module or by the user independently.
<i>pow</i>	power used to normalize the flux (MW).

## 8.1.3 Heterogeneous assembly geometry definition

Table 104: Structure (**descnap3**)

```
[ EDIT iprint ]
DIRGEO namedir [ MACGEO ]
MIXASS nmix (imix(i), i=1,nmix)
[ SLPITX-ASS (ispx(i), i=1,nxass) ]
[ SLPITY-ASS (ispy(i), i=1,nyass) ]
[ MAX-MIX-GEO nmixgeo ]
;
```

where

EDIT	keyword used to modify the print level <i>i</i> print.
<i>i</i> print	index used to control the printing of this module. The <i>i</i> print parameter is important for adjusting the amount of data that is printed by this calculation step: <ul style="list-style-type: none"> <li>• <i>i</i>print=0 results in no output;</li> <li>• <i>i</i>print=1 ...</li> </ul>
DIRGEO	keyword to specify <i>namedir</i> .
<i>namedir</i>	name of the directory containing the heterogeneously or homogeneously homogenized cross sections.
MACGEO	keyword to specify that the macro-geometry stored in the <i>GFF</i> record of the macrolib will be used instead of the macro-geometry of the heterogeneously or homogeneously homogenized cross sections. Usually this other macro-geometry of the assembly corresponds to the pin-by-pin geometry. Note that another multicompo with all pin-wise properties is needed to be able to use the automatically generated geometry.
MIXASS	keyword to specify mixtures corresponding to assembly in the coarse geometry.
<i>nmix</i>	number of type of assembly.
<i>imix</i>	mixture number of the assemblies.
SLPITX-ASS	keyword to specify the mesh splitting at assembly level.
<i>ispx</i>	split along x-direction for each mesh of the heterogeneous assembly.
<i>nxass</i>	number of mesh of the heterogeneous assembly along x-direction.
SLPITY-ASS	keyword to specify the mesh splitting at assembly level.
<i>ispy</i>	split along y-direction for each mesh of the heterogeneous assembly.
<i>nyass</i>	number of mesh of the heterogeneous assembly along y-direction.

MAX-MIX-GEO keyword to specify the number of mixtures in the original core geometry (i.e. before the core geometry is split by the `NAP:` module). This keyword is mandatory if there is a reflector in the geometry otherwise the numbers for fuel mixtures will not match between the split core geometry (GEOMETRY) and the split fuel geometry (GEOMETRY embedded in MAP).

*nmxgeo* number of mixtures in the original core geometry.

**Note:** The included geometry in the *COMPO* has to be unfolded, even if the transport calculations are done on a 1/8th assembly. Moreover no split can be defined in the geometry, one mesh **ONLY** per heterogeneous mixture is mandatory.

## 9 DONJON DATA STRUCTURES

A brief description of each DRAGON, DONJON and TRIVAC data structures, which can be used with DONJON code, is given in Section 2.2. In this section, a detailed description of the DONJON data structures is presented.

### 9.1 Contents of /fmap/ data structure

A /fmap/ data structure is used to store fuel assembly (or bundle) map and fuel information such as powers, average fluxes, control zones, burnup or refueling scheme. The fuel bundle location are given in an embedded sub-directory which contains the records as a /geometry/ data structure. This object has a signature L\_MAP; it is created using the RESINI : module.

#### 9.1.1 The state-vector content

The dimensioning parameters  $\mathcal{S}_i$ , which are stored in the state vector for this data structure, represent:

- The number of fuel bundles per channel  $N_b = \mathcal{S}_1$
- The number of fuel channels  $N_{ch} = \mathcal{S}_2$
- The number of combustion zones  $N_{comb} = \mathcal{S}_3$
- The number of energy groups  $N_{gr} = \mathcal{S}_4$
- The type of interpolation with respect to burnup  $I_{btyp} = \mathcal{S}_5$

$$I_{btyp} = \begin{cases} 0 & \text{interpolation type is not provided} \\ 1 & \text{according to the time-average model} \\ 2 & \text{according to the instantaneous model} \end{cases}$$

- The number of bundle shift.  $N_{shf} = \mathcal{S}_6$
- The number of fuel types  $N_{fuel} = \mathcal{S}_7$
- The number of recorded parameters  $N_{parm} = \mathcal{S}_8$
- The total number of fuel bundles  $N_{tot} = \mathcal{S}_9$
- The number of voided reactor channels  $N_{void} = \mathcal{S}_{10}$
- The option with respect to the core-voiding pattern  $I_{void} = \mathcal{S}_{11}$

$$I_{void} = \begin{cases} 0 & \text{voiding pattern not provided} \\ 1 & \text{full-core voiding pattern} \\ 2 & \text{half-core voiding pattern} \\ 3 & \text{quarter-core voiding pattern} \\ 4 & \text{checkerboard-full voiding pattern} \\ 5 & \text{checkerboard-half voiding pattern} \\ 6 & \text{checkerboard-quarter voiding pattern} \\ 7 & \text{user-defined voiding pattern} \end{cases}$$

- The type of the geometry  $F_t = \mathcal{S}_{12}$

$$F_t = \begin{cases} 7 & \text{Cartesian 3-D geometry} \\ 9 & \text{Hexagonal 3-D geometry} \end{cases}$$

- The naval-coordinate layout used by the **SIM**: module  $I_{\text{sim}} = \mathcal{S}_{13}$ .

The number of assemblies along  $X$  and  $Y$  axis are given using

$$L_x = \frac{I_{\text{sim}}}{100} \quad \text{and} \quad L_y = \text{mod}(I_{\text{sim}}, 100)$$

- The total number of assemblies  $N_{\text{ass}} = \mathcal{S}_{14}$
- The number of assemblies along  $X$  direction in Cartesian geometry. The number of assemblies in the radial plane in hexagonal geometry.  $N_{\text{xa}} = \mathcal{S}_{15}$
- The number of assemblies along  $Y$  direction in Cartesian geometry  $N_{\text{ya}} = \mathcal{S}_{16}$
- The number of plane of the mesh along  $Z$  direction where assemblies are located  $N_{z,\text{ass}} = \mathcal{S}_{17}$
- The number of particularized isotopes to store in  $\{\text{hcycle}\}$  sub-directories  $N_{\text{is}} = \mathcal{S}_{18}$
- The number of  $\{\text{hcycle}\}$  sub-directories  $N_{\text{cy}} = \mathcal{S}_{19}$

### 9.1.2 The main /fmap/ directory

The following records and sub-directories will be found on the first level of /fmap/ directory:

Table 105: Records and sub-directories in /fmap/ data structure

Name	Type	Condition	Units	Comment
<b>SIGNATURE</b> <sub>uuu</sub>	C*12			Signature of the /fmap/ data structure ( <b>SIGNA</b> = <b>L_MAP</b> <sub>uuuuuuuu</sub> ).
<b>STATE-VECTOR</b>	I(40)			Vector describing the various parameters associated with this data structure $\mathcal{S}_i$
<b>FLMIX</b> <sub>uuuuuuuu</sub>	I( $N_{\text{ch}}, N_{\text{b}}$ )			Fuel type indices per bundle or assembly subdivisions for each reactor channel.
<b>FLMIX-INI</b> <sub>uuu</sub>	I( $N_{\text{ch}}, N_{\text{b}}$ )	$I_{\text{sim}} \neq 0$		Fuel type indices per bundle or assembly subdivisions for each reactor channel, as defined by user in <b>RESINI</b> : module.
<b>S-ZONE</b> <sub>uuuuuuu</sub>	C( $N_{\text{ch}}$ ) * 4	$I_{\text{sim}} \neq 0$		identification name corresponding to the basic naval-coordinate position of an assembly, as defined by user in <b>RESINI</b> : module..
<b>BMIX</b> <sub>uuuuuuuuuu</sub>	I( $N_x, N_y, N_z$ )			Renumbered mixture indices per each fuel region over the fuel-map geometry; for the non-fuel regions these indices are set to 0.

continued on next page

Records and sub-directories in /fmap/ data structure

continued from last page

Name	Type	Condition	Units	Comment
XNAME <sub>UUUUUUU</sub>	$C(N_x) * 4$	$F_t = 7$		Channel identification names with respect to their horizontal position in Cartesian geometry.
YNAME <sub>UUUUUUU</sub>	$C(N_y) * 4$	$F_t = 7$		Channel identification names with respect to their vertical position in Cartesian geometry.
HNAME <sub>UUUUUUU</sub>	$C(N_x) * 8$	$F_t = 9$		Channel identification names with respect to their radial position in hexagonal geometry.
AXNAME <sub>UUUUUUU</sub>	$C(N_{xa}) * 4$	$F_t = 7$		Name of the assembly on X-direction (4 character name per assembly) in Cartesian geometry
AYNAME <sub>UUUUUUU</sub>	$C(N_{ya}) * 4$	$F_t = 7$		Name of the assembly on Y-direction (4 character name per assembly) in Cartesian geometry
ASSEMBLY <sub>UUUU</sub>	$\text{Dir}(N_{\text{ass}})$			List of <i>assembly</i> directories. Each component of this list follows the specification presented in Section 9.1.7.
B-ZONE <sub>UUUUUUU</sub>	$I(N_{\text{ch}})$	$N_{\text{comb}} \geq 1$		Combustion-zone indices per channel.
BURN-AVG <sub>UUUUU</sub>	$R(N_{\text{comb}})$		MW d t <sup>-1</sup>	Average exit burnups per combustion zone.
BURN-INST <sub>UUU</sub>	$R(N_{\text{ch}}, N_{\text{b}})$	$I_{\text{btyp}} = 2$	MW d t <sup>-1</sup>	Instantaneous burnups per bundle or assembly subdivisions for each channel.
BURN-BEG <sub>UUUUU</sub>	$R(N_{\text{ch}}, N_{\text{b}})$	$I_{\text{btyp}} = 1$	MW d t <sup>-1</sup>	Low burnup integration limits according to the time-average model.
BURN-END <sub>UUUUU</sub>	$R(N_{\text{ch}}, N_{\text{b}})$	$I_{\text{btyp}} = 1$	MW d t <sup>-1</sup>	Upper burnup integration limits according to the time-average model.
BUND-PW <sub>UUUUUU</sub>	$R(N_{\text{ch}}, N_{\text{b}})$	*	kW	Bundle-powers set in RESINI: module or recovered from L_POWER object.
BUND-PW-INI <sub>U</sub>	$R(N_{\text{ch}}, N_{\text{b}})$	*	kW	Beginning-of-transient bundle-powers recovered from L_POWER object.
FLUX-AV <sub>UUUUUU</sub>	$R(N_{\text{ch}}, N_{\text{b}}, N_{\text{gr}})$	*	cm <sup>-2</sup> s <sup>-1</sup>	The normalized average fluxes recorded per each fuel bundle and for each energy group, recovered from L_POWER object.
REACTOR-PW <sub>UU</sub>	$R(1)$	*	MW	Full reactor power set in RESINI: module or recovered from L_POWER object.
AXIAL-FPW <sub>UUU</sub>	$R(N_{\text{b}})$	*	1	Axial power form factor set in RESINI: module.
B-EXIT <sub>UUUUUUU</sub>	$R(1)$		MW d t <sup>-1</sup>	Core-average discharge burnup.
REF-SHIFT <sub>UUU</sub>	$I(N_{\text{comb}})$			Bundle-shifts per combustion zone. A bundle-shift corresponds to the number of displaced fuel bundles during the refueling operation.
REF-VECTOR <sub>UU</sub>	$I(N_{\text{comb}}, N_{\text{b}})$			Refueling pattern vector per combustion zone.
REF-SCHEME <sub>UU</sub>	$I(N_{\text{ch}})$			Refueling scheme of each channel; it corresponds to the positive or negative bundle-shift number according to the flow direction.
REF-RATE <sub>UUUUU</sub>	$R(N_{\text{ch}})$		kg d <sup>-1</sup>	Channel refueling rates.
REF-CHAN <sub>UUUUU</sub>	$R(N_{\text{ch}})$		d	Time values at which channels are refueled inside a refueling time period.

continued on next page



Records and sub-directories in /fmap/ data structure

continued from last page

Name	Type	Condition	Units	Comment
DEPL-TIME <sub>UUU</sub>	R(1)		d	Refueling time period in days.
{ <i>pshift</i> }	R( $N_{ch}, N_b$ )	$N_{sht} \geq 1$	$kW$	The power of the bundles shifted the $i$ -th time.
{ <i>bshift</i> }	R( $N_{ch}, N_b$ )	$N_{sht} \geq 1$	$MWdT^{-1}$	The burnup of the bundles shifted the $i$ -th time.
{ <i>ishift</i> }	I( $N_{ch}, N_b$ )	$N_{sht} \geq 1$		The number of shifts per bundle during refueling.
AX-SHAPE <sub>UUUU</sub>	R( $N_{ch}, N_b$ )	$I_{btyp} = 1$		Normalized axial power-shape values over the fuel bundles. Equal to fuel-bundle powers divided by channel powers.
EPS-AX <sub>UUUUUU</sub>	R(1)	$I_{btyp} = 1$		Convergence factor for the axial power-shape calculation; it is defined as a relative error between the two successive calculations.
FQ <sub>UUUUUUUUUU</sub>	R(1)			Hot spot factor: power of the hottest 3D Cartesian pin spot normalized to the mean power of a 3D Cartesian pin spot.
				$FQ = \frac{P_{x,y,z}^{\max}(x, y, z)}{P_{x,y,z}^{\text{moy}}(x, y, z)}$
				where $P(x,y,z)$ is the power of an axial part of a pin located at the coordinates $(x,y,z)$ .
FXY <sub>UUUUUUUUUU</sub>	R(1)			Radial hot spot factor: power of the hottest pin normalized to the mean power of a pin.
				$Fxy = \frac{P_{x,y}^{\max}(x, y)}{P_{x,y}^{\text{moy}}(x, y)}$
				with
				$P(x, y) = \int_0^{z_{max}} P(x, y, z) dz$
FXYZ <sub>UUUUUUUU</sub>	R( $N_{z,ass}$ )			For each axial mesh, power of the hottest 2D Cartesian pin spot normalized to the mean power of a 3D Cartesian pin spot.
				$Fxy(z) = \frac{P_{x,y}^{\max}(x, y, z)}{P_{x,y,z}^{\text{moy}}(x, y, z)}$

continued on next page

Records and sub-directories in /finap/ data structure

continued from last page

Name	Type	Condition	Units	Comment
FXYASS <sub>UUUUUU</sub>	R( $N_{\text{ass}}$ )			For each assembly, power of the hottest pin normalized to the mean power of a pin. $Fxy(iass) = \frac{P_{\text{max}}(x, y, iass)}{P_{\text{moy}}(x, y)}$ with $P(x, y, iass) = \int_0^{zmax} P(x, y, z, iass) dz$
HFOLLOW <sub>UUUUUU</sub>	C( $N_{\text{is}}$ ) * 8	$N_{\text{is}} > 0$		Name of the particularized isotopes to store in {hcycle} directory.
GEOMAP <sub>UUUUUU</sub>	Dir			Sub-directory containing the embedded 3D-Cartesian /geometry/ of the fuel lattice.
FUEL <sub>UUUUUUUU</sub>	Dir( $N_{\text{fuel}}$ )			List of fuel-type sub-directories. Each component of the list is a directory containing the information relative to a single fuel type.
ROD-INFO <sub>UUUU</sub>	Dir	*		Sub-directory containing the information corresponding to the local rod insertion for PWR. This sub-directory follows the specification presented in Section 9.1.6.
{hcycle}	Dir( $N_{\text{burn}}$ )	$N_{\text{cy}} > 0$		Sub-directory containing information related to a fuel cycle in a PWR. $N_{\text{burn}}$ is the number of burnup steps used during the simulation of the cycle. These burnup steps may not be of increasing values. If module TINST: was used to burn fuel, the name of the hcycle directory is “_TINST”.
CYCLE-NAMES <sub>U</sub>	C( $N_{\text{cy}}$ ) * 12	$N_{\text{cy}} > 0$		Names of fuel cycle sub-directories {hcycle}.
PARAM <sub>UUUUUUUU</sub>	Dir( $N_{\text{parm}}$ )	$N_{\text{parm}} > 0$		List of parameter-type sub-directories corresponding to actual time. Each component of the list is a directory containing the information relative to a single parameter (see Sect. 9.1.5). The total number of sub-directories corresponds to the total number of recorded parameters $N_{\text{parm}}$ (excluding burnups).

The contents of the GEOMAP sub-directory correspond to the typical contents of the /geometry/ data structure. The dimensioning parameters  $N_x$ ,  $N_y$ , and  $N_z$  represent the number of volumes along the corresponding axis in the fuel-map geometry.

The shifting information records {pshift}, {bshift} and {ishift} will be composed using the following FORTRAN instructions, respectively, as

```
WRITE(pshift, '(A6, I2)') 'PSHIFT', ell
```

WRITE(bshift,'(A6,I2)') 'BSHIFT',ell

WRITE(ishift,'(A6,I2)') 'ISHIFT',ell

for  $1 \leq ell \leq N_{\text{sht}}$ .

Each time a bundle is shifted and stay in the reactor, its burnup and power will be saved in the records {bshift} and {pshift}. For example, {bshift i} and {pshift i} will contain all the burnups and powers of bundles that have been shifted  $i$ -th time.

### 9.1.3 The FUEL sub-directories

Each FUEL sub-directory contains the information corresponding to a single fuel type. Inside each sub-directory, the following records will be found:

Table 106: Records in FUEL sub-directories

Name	Type	Condition	Units	Comment
MIX_	I(1)			Fuel-type mixture number.
TOT_	I(1)			Total number of fuel bundles for this fuel type.
MIX-VOID_	I(1)			Voided-cell mixture number for this fuel type.
WEIGHT_	R(1)		kg	Fuel weight in a bundle for this fuel type.
ENRICH_	R(1)		wt%	Fuel enrichment for this fuel type.
POISON_	R(1)			Poison load for this fuel type.

### 9.1.4 The {hcycle} sub-directories

Each {hcycle} sub-directory contains the information corresponding to a single PWR fuel cycle. Inside each sub-directory, the following records will be found:

Table 107: Records in {hcycle} sub-directories

Name	Type	Condition	Units	Comment
ALIAS_	C(*12			Name of the cycle sub-directory.
TIME_	R(1)		d	Depletion time corresponding to instantaneous burnup values.

continued on next page

Records in {hcycle} sub-directories

continued from last page

Name	Type	Condition	Units	Comment
PARAM <sub>UUUUUUUU</sub>	Dir( $N_{\text{parm}}$ )	$N_{\text{parm}} > 0$		List of parameter-type sub-directories corresponding to refuelling time. Each component of the list is a directory containing the information relative to a single parameter (see Sect. 9.1.5). The total number of sub-directories corresponds to the total number of recorded parameters $N_{\text{parm}}$ (excluding burnups).
BURNAV <sub>UUUUUU</sub>	R(1)		MW d t <sup>-1</sup>	Average burnup of the assembly.
NAME <sub>UUUUUUUU</sub>	$C(N_{\text{ch}}) * 12$			Names of each assembly or of each quart-of-assembly during a refuelling cycle. All quart-of-assembly belonging to the same assembly have the same name.
CYCLE <sub>UUUUUUUU</sub>	$C(L_x \times L_y) * 4$			Shuffling matrix for refuelling as provided by the plant operator. The name "I" is reserved for empty locations.
FLMIX <sub>UUUUUUUU</sub>	$I(N_{\text{ch}}, N_{\text{b}})$			Fuel type indices per assembly subdivisions for each reactor channel.
BURN-INST <sub>UUUU</sub>	$R(N_{\text{ch}}, N_{\text{b}})$		MW d t <sup>-1</sup>	Instantaneous burnups per assembly subdivisions for each channel.
POWER-BUND <sub>UU</sub>	$R(N_{\text{ch}}, N_{\text{b}})$		kW	Powers per assembly subdivisions for each channel.
K-EFFECTIVE <sub>U</sub>	R(1)			Effective multiplication factor $k_{\text{eff}}$ .
FOLLOW <sub>UUUUUUUU</sub>	$R(N_{\text{ch}}, N_{\text{b}}, N_{\text{is}})$	$N_{\text{is}} > 0$	(cm b) <sup>-1</sup>	Number densities of the particularized isotopes.

### 9.1.5 The *PARAM* sub-directories

Each *PARAM* sub-directory contains the information corresponding to a single local or global parameter (excluding burnups). Inside a such sub-directory, the following records will be found:

Table 108: Records in *PARAM* sub-directories

Name	Type	Condition	Units	Comment																
P-NAME <sub>UUUUUU</sub>	C*12			Unique identification name of this parameter. This name is user-defined; however, it is recommended to use the following pre-defined values: <table><tr><td>C-BORE</td><td>Boron concentration</td></tr><tr><td>T-FUEL</td><td>Averaged fuel temperature</td></tr><tr><td>T-SURF</td><td>Surfacic fuel temperature</td></tr><tr><td>T-COOL</td><td>Averaged coolant temperature</td></tr><tr><td>D-COOL</td><td>Averaged coolant density</td></tr><tr><td colspan="2">CANDU-only parameters:</td></tr><tr><td>T-MODE</td><td>Averaged moderator temperature</td></tr><tr><td>D-MODE</td><td>Averaged moderator density</td></tr></table>	C-BORE	Boron concentration	T-FUEL	Averaged fuel temperature	T-SURF	Surfacic fuel temperature	T-COOL	Averaged coolant temperature	D-COOL	Averaged coolant density	CANDU-only parameters:		T-MODE	Averaged moderator temperature	D-MODE	Averaged moderator density
C-BORE	Boron concentration																			
T-FUEL	Averaged fuel temperature																			
T-SURF	Surfacic fuel temperature																			
T-COOL	Averaged coolant temperature																			
D-COOL	Averaged coolant density																			
CANDU-only parameters:																				
T-MODE	Averaged moderator temperature																			
D-MODE	Averaged moderator density																			
PARKEY <sub>UUUUUU</sub>	C*12			Corresponding name of this parameter as recorded in a multi-parameter Compo file.																
P-TYPE <sub>UUUUUU</sub>	I(1)			Number associated to the type of recorded parameter: <i>ptype</i> = 1 for global parameter; <i>ptype</i> = 2 for local parameter.																
P-VALUE <sub>UUUUU</sub>	R(1)	<i>ptype</i> = 1		Recorded single value for global parameter. Temperatures are given in K and densities are given in g/cc.																
	R( <i>N</i> <sub>ch</sub> , <i>N</i> <sub>b</sub> )	<i>ptype</i> = 2		Recorded values for local parameter per each fuel bundle for every channel. Temperatures are given in K and densities are given in g/cc.																

### 9.1.6 The *ROD-INFO* sub-directory

The *ROD-INFO* sub-directory contains the information corresponding to the local rod insertion for PWR. This sub-directory is created after the first calling to the *ROD:* module. Inside this sub-directory, the following records will be found:

Table 109: Records in ROD-INFO sub-directories

Name	Type	Condition	Units	Comment
ROD-INIT <sub>UUUU</sub>	R(1)			Default value for the rod field. This value corresponds to no rod inserted.
INS-MAX <sub>UUUUU</sub>	I(1)			Number associated to the maximum of rod insertion steps possible.
STEP-CM <sub>UUUUU</sub>	R(1)			Length of one rod insertion step (in cm).
REFL-BOTTOM <sub>U</sub>	I(1)			Number of bottom reflective axial-planes.
NB-GROUP <sub>UUUU</sub>	I(1)			Number of rod groups.
MAX-MIX <sub>UUUUU</sub>	I(1)			Maximum number of rod zones for all the rods defined.
ROD-NAME <sub>UUUU</sub>	$C(N_{gr}) * 3$			Name of each rod group defined by user in ROD: module.
ROD-INSERT <sub>UU</sub>	$I(N_{gr})$			Insertion of each rod group defined by user in ROD: module.
ROD-RIN <sub>UUUUU</sub>	$R(N_{gr}, N_{mix})$			Rod identification numbers (RIN) for each rod group defined by user in ROD: module.
ROD-NBZONE <sub>UU</sub>	$I(N_{gr})$			Number of RIN zones for each rod group defined by user in ROD: module.
ROD-HEIGHT <sub>UU</sub>	$R(N_{gr}, N_{mix})$			Height between the bottom of the rod and the beginning of the RIN zone for each rod group and each RIN zone defined by user in ROD: module.
ROD-MAP <sub>UUUUU</sub>	$C(N_{ch}) * 3$			Identification name corresponding to the rod map as defined by user in ROD: module.

## 9.1.7 The ASSEMBLY sub-directory

Table 110: Assembly type sub-directory

Name	Type	Condition	Units	Comment
LABEL <sub>UUUUUUU</sub>	C*8			Label of the assembly. It consists a 8 character name composed of the AYNAM and AXNAME
PIN-POWER <sub>UUU</sub>	$R(N_{pin}^2 * N_{z,ass})$			array containing the pin power for each pin on each mesh plane of the assembly.
ASS-POWER <sub>UUU</sub>	R(1)			total assembly power.

continued on next page

Assembly type sub-directory

continued from last page

Name	Type	Condition	Units	Comment
SIG_F*PHI <sub>UUU</sub>	$R(N_{pin}^2 * N_{z,ass})$			array containing the integral of $\Sigma_f$ times the flux for each pin on each mesh plane of the assembly.
FLUX <sub>UUUUUUUU</sub>	$R(N_{pin}^2 * N_{z,ass} * N_g)$			array containing the flux of each group for each pin on each mesh plane of the assembly.

## 9.2 Contents of /matex/ data structure

A /matex/ data structure is used to store several information related to the reactor extended material index and geometry. This object has a signature `L_MATEX`; it is created using the `USPLIT` module. The information contained in this data structure can be used and updated in other `DONJON` modules.

### 9.2.1 The state-vector content

The dimensioning parameters  $\mathcal{S}_i$ , which are stored in the state vector for this data structure, represent:

- The number of energy groups  $N_{gr} = \mathcal{S}_1$
- The maximum number of material mixtures  $N_m = \mathcal{S}_2$  ( $N_m$  equals to the total number of material regions plus the number of device mixtures)
- The number of reflector types  $N_r = \mathcal{S}_3$
- The number of fuel types  $N_f = \mathcal{S}_4$
- The total number of mixtures indices  $N_{tot} = \mathcal{S}_5$  ( $N_{tot}$  equals to the total number of mesh-splitted volumes plus the number of device mixtures)
- The type of reactor geometry  $I_g = \mathcal{S}_6$  (only  $I_g = 7$  for 3D-Cartesian geometry or  $I_g = 9$  for 3D-Hexagonal geometry are allowed)
- The total number of mesh-splitted volumes  $N_{el} = \mathcal{S}_7$
- The number of mesh-splitted volumes along x-axis  $L_x = \mathcal{S}_8$
- The number of mesh-splitted volumes along y-axis  $L_y = \mathcal{S}_9$
- The number of mesh-splitted volumes along z-axis  $L_z = \mathcal{S}_{10}$

### 9.2.2 The /matex/ directory

The following records will be found on the /matex/ directory:

Table 111: Records in /matex/ data structure

Name	Type	Condition	Units	Comment
<code>SIGNATURE_</code>	<code>C*12</code>			Signature of the /matex/ data structure ( <code>SIGNA=L_MATEX_</code> ).
<code>STATE-VECTOR</code>	<code>I(40)</code>			Vector describing the various parameters associated with this data structure $\mathcal{S}_i$
<code>RMIX_</code>	<code>I(<math>N_r</math>)</code>			The reflector-type mixture indices, as defined in the reactor geometry.
<code>RTOT_</code>	<code>I(<math>N_r</math>)</code>			The total number of reflector regions per each reflector type.

continued on next page



Records in /matex/ data structure

continued from last page

Name	Type	Condition	Units	Comment
FMIX <sub>UUUUUUUU</sub>	$I(N_f)$			The fuel-type mixture indices, as defined in the reactor geometry.
FTOT <sub>UUUUUUUU</sub>	$I(N_f)$			The total number of fuel regions per each fuel type.
MAT <sub>UUUUUUUU</sub>	$I(N_{tot})$			The material mixture indices per each region and including the device mixtures. The fuel-type indices are set negative; the device indices are appended at the end of vector; the virtual-region indices are set to 0.
INDEX <sub>UUUUUUU</sub>	$I(N_{el})$			The renumbered mixture indices. A unique number is associated with each mesh-splitted volume. The device indices are not included; the virtual-region indices are set to 0.
MESHX <sub>UUUUUUU</sub>	$R(L_x + 1)$			The mesh-splitted coordinates along x-axis of the reactor geometry.
MESHY <sub>UUUUUUU</sub>	$R(L_y + 1)$			The mesh-splitted coordinates along y-axis of the reactor geometry.
MESHZ <sub>UUUUUUU</sub>	$R(L_z + 1)$			The mesh-splitted coordinates along z-axis of the reactor geometry.
H-FACTOR <sub>UUUUU</sub>	$R(N_m, N_{gr})$			The h-factors per each mixture and per each energy group, as recovered from the extended /macrolib/ data structure.

### 9.3 Contents of /device/ data structure

A /device/ data structure is used to store several information related to the reactor devices. This object has a signature `L_DEVICE`; it is created using the `DEVINI:` module. The information contained in this data structure can be used and updated in other `DONJON` modules which are related to the devices, namely: `LZC:`, `DSET:`, `MOVDEV:` and `NEWMAC:` modules.

#### 9.3.1 The state-vector content

The dimensioning parameters  $\mathcal{S}_i$ , which are stored in the state vector for this data structure, represent:

- The type of reactor geometry  $I_g = \mathcal{S}_1$  (only  $I_g = 7$  for 3D-Cartesian geometry allowed)
- The total number of rod-type devices  $N_{rod} = \mathcal{S}_2$
- The total number of the rod-type groups  $N_{grp} = \mathcal{S}_3$
- The total number of lzc-type devices  $N_{lzc} = \mathcal{S}_4$
- The total number of the lzc-type groups  $N_{lgrp} = \mathcal{S}_5$
- Type of control rod movement  $I_{mov} = \mathcal{S}_6$  where

$$I_{mov} = \begin{cases} 1 & \text{Fading. A fraction of the fully inserted rod vanishes} \\ 2 & \text{Moving. The complete rod is moving (DONJON3-type movement).} \end{cases}$$

#### 9.3.2 The main /device/ directory

The following records and sub-directories will be found on the first level of /device/ directory:

Table 112: Records and sub-directories in /device/ data structure

Name	Type	Condition	Units	Comment
<code>SIGNATURE_</code>	<code>C*12</code>			Signature of the /device/ data structure ( <code>SIGNA=L_DEVICE</code> ).
<code>STATE-VECTOR</code>	<code>I(40)</code>			Vector describing the various parameters associated with this data structure $\mathcal{S}_i$
<code>DEV_ROD_</code>	<code>Dir(<math>N_{rod}</math>)</code>			Sub-directories for each controller rod. A sub-directory is created for each controller rod according to the rod identification number.
<code>ROD_GROUP_</code>	<code>Dir(<math>N_{grp}</math>)</code>			Sub-directories for each group of rod-type devices. A sub-directory is created for each group of rod-type devices according to the rod-group identification number.

continued on next page

Records and sub-directories in /device/ data structure

continued from last page

Name	Type	Condition	Units	Comment
DEV_LZC <sub>UUUUU</sub>	Dir( $N_{lzc}$ )			Sub-directories for each liquid zone controller. A sub-directory is created for each liquid controller according to the liquid controller identification number.
LZC_GROUP <sub>UUU</sub>	Dir( $N_{lgrp}$ )			Sub-directories for each group of lzc-type devices. A sub-directory is created for each group of lzc-type devices according to the lzc-group identification number.

### 9.3.3 The DEV-ROD sub-directories

Inside each DEV-ROD sub-directory, the following records will be found:

Table 113: Records in DEV-ROD sub-directories

Name	Type	Condition	Units	Comment
ROD-ID <sub>UUUUUU</sub>	I(1)			The identification number of the rod.
ROD-NAME <sub>UUUUU</sub>	C*12			The identification name of the rod.
ROD-PARTS <sub>UUU</sub>	I(1)			The number of parts in the rod ( $N_{\text{part}} \geq 1$ ).
AXIS <sub>UUUUUUUU</sub>	I(1)			The number used to identify the rod movement direction: = 1 along x-axis; = 2 along y-axis; =3 along z-axis.
FROM <sub>UUUUUUUUU</sub>	I(1)			The number used to identify the side of geometry, from which the controller rod is inserted into the reactor core along its direction of movement: = 1 if a rod is inserted from the highest position (e.g. from the top); = -1 if a rod is inserted from the lowest position (e.g. from the bottom).
LENGTH <sub>UUUUUU</sub>	R(2)		cm	The initial and final position coordinates of the full-inserted rod along its direction of movement. The rod length is the distance between these two coordinates.
CORE-LIMITS <sub>U</sub>	R(6)		cm	The initial and final position coordinates of the full core along each Cartesian direction.
MAX-POS <sub>UUUUU</sub>	R( $6 \times N_{\text{part}}$ )		cm	The limiting 3D-Cartesian coordinates of the full-inserted rod. This data is given for each part of the rod.

continued on next page

Records in DEV-ROD sub-directories

continued from last page

Name	Type	Condition	Units	Comment
ROD-MIX <sub>UUUUU</sub>	$I(2 \times N_{\text{part}})$			The rod-type mixture indices. The first number corresponds to the inserted rod position and the second to the withdrawn rod position. This data is given for each part of the rod.
LEVEL <sub>UUUUUUU</sub>	$R(1)$	*		The actual insertion level of the controller rod. This value must be between 0.0 for the full-withdrawn rod and 1.0 for the full-inserted rod.
SPEED <sub>UUUUUUU</sub>	$R(1)$	*	$\text{cm s}^{-1}$	The speed of rod movement (insertion or extraction).
TIME <sub>UUUUUUU</sub>	$R(1)$	*	s	The time for the full rod insertion or extraction.
ROD-POS <sub>UUUUU</sub>	$R(6 \times N_{\text{part}})$	*	cm	The actual 3D-Cartesian coordinates of the rod. This data is given for each part of the rod.

### 9.3.4 The ROD-GROUP sub-directories

Inside each ROD-GROUP sub-directory, the following records will be found:

Table 114: Records in ROD-GROUP sub-directories

Name	Type	Condition	Units	Comment
GROUP-ID <sub>UUUU</sub>	$I(1)$			The identification number of the rod-group.
NUM-ROD <sub>UUUUU</sub>	$I(1)$			The total number $N_{rd}$ of rod-devices in the group.
ROD-ID <sub>UUUUUU</sub>	$I(N_{rd})$			An array of identification numbers of rods which belong to the same group.

### 9.3.5 The DEV-LZC sub-directories

Inside each DEV-LZC sub-directory, the following records will be found:

Table 115: Records in DEV-LZC sub-directories

Name	Type	Condition	Units	Comment
LZC-ID <sub>UUUUUU</sub>	I(1)			The identification number of the liquid zone controller.
MAX-POS <sub>UUUUU</sub>	R(6)		cm	The limiting 3D-Cartesian coordinates of the whole liquid controller, including its empty and full parts.
AXIS <sub>UUUUUUUU</sub>	I(1)			The number used to identify the water filling direction: = 1 along x-axis; = 2 along y-axis; =3 along z-axis.
HEIGHT <sub>UUUUUU</sub>	R(1)		cm	The water height of the full-filled controller along its direction of filling.
LEVEL <sub>UUUUUUU</sub>	R(1)			The actual water level of the liquid controller device. This value must be between 0.0 for the empty state and 1.0 for the full-filled state.
EMPTY-POS <sub>UUU</sub>	R(6)		cm	The actual 3D-Cartesian coordinates of the empty-part of liquid controller.
FULL-POS <sub>UUUU</sub>	R(6)		cm	The actual 3D-Cartesian coordinates of the full-part of liquid controller.
EMPTY-MIX <sub>UUU</sub>	I(2)			The empty-part mixture number and the reference mixture number.
FULL-MIX <sub>UUUU</sub>	I(2)			The full-part mixture number and the reference mixture number.
RATE <sub>UUUUUUUU</sub>	R(1)		$m^3 s^{-1}$	The water filling rate.
TIME <sub>UUUUUUUU</sub>	R(1)		s	The water filling time.

### 9.3.6 The LZC-GROUP sub-directories

Inside each LZC-GROUP sub-directory, the following records will be found:

Table 116: Records in LZC-GROUP sub-directories

Name	Type	Condition	Units	Comment
GROUP-ID <sub>UUUU</sub>	I(1)			The identification number of the lzc-group.
NUM-LZC <sub>UUUUU</sub>	I(1)			The total number $N_{ld}$ of lzc-devices in the group.
LZC-ID <sub>UUUUUU</sub>	I( $N_{ld}$ )			An array of identification numbers of liquid controllers which belong to the same group.

#### 9.4 Contents of a /detect/ data structure

The /detect/ data structure is used to store detector positions and responses. This object has a signature `L_DETECT`; it is created using the `DETINI:` module. The information contained in this data structure can be used and updated in other DONJON modules which are related to the detectors, namely: `DETECT:` and `DETINI:` modules.

##### 9.4.1 The state-vector content

The dimensioning parameters  $\mathcal{S}_i$ , which are stored in the state vector for this data structure, represent:

- The number of energy groups.  $N_g = \mathcal{S}_1$
- The total number of detectors  $\sum \mathcal{I}_1 = \mathcal{S}_2$ .
- Flag for hexagonal detector definition  $\mathcal{S}_3 = 1$  for hexagonal detector definition,  $= 0$  otherwise.

The dimensioning parameters for a specific detector type, which are stored in the vector  $\mathcal{I}_i$ , represents:

- The number of detectors of type { name\_type }  $\mathcal{I}_1$ .
- The number of delayed responses  $+ 2, \mathcal{I}_2$ .

##### 9.4.2 The main /detect/ directory

The following records and sub-directories will be found on the first level of /detect/ directory:

Table 117: Records and sub-directories in /detect/ data structure

Name	Type	Condition	Units	Comment
<code>SIGNATURE_</code>	<code>C*12</code>			Signature of the /detect/ data structure ( <code>SIGNA =L_DETECT</code> ).
<code>STATE-VECTOR</code>	<code>I(40)</code>			Vector describing the various parameters associated with this data structure $\mathcal{S}_i$
<code>{/name_type/}</code>	<code>Dir</code>			Detector type sub-directory contains informations for each detector of this type.

##### 9.4.3 The /name\_type/ sub-directories

Inside each /name\_type/ sub-directory, the following records will be found:

Table 118: Records in /name\_type/ sub-directories

Name	Type	Condition	Units	Comment
INFORMATIONS	I(2)			Record containing describing the various parameters associated with a detector type $\mathcal{I}_i$ .
INV-CONST <sub>UUU</sub>	R( $\mathcal{I}_2 - 2$ )		$s^{-1}$	The inverse time constant of the delayed detector responses.
FRACTION <sub>UUUU</sub>	R( $\mathcal{I}_2 - 1$ )			The delayed and prompt fractions of the detector responses.
SPECTRAL <sub>UUUU</sub>	R( $\mathcal{I}_2 - 1$ )			The energy spectrum of the detector.
{/name_detect/}	Dir			Detector information sub-directory

#### 9.4.4 The /name\_detect/ sub-directories

Inside each /name\_detect/ sub-directory, the following records will be found:

Table 119: Records in /name\_detect/ sub-directories

Name	Type	Condition	Units	Comment
NHEX <sub>UUUUUUUU</sub>	I(nhex)	hex = 1		The numbers of affected hexagons in the first X-Y plane.
POSITION <sub>UUUU</sub>	R(6)		cm	The coordinates of the detector.
RESPON <sub>UUUUUU</sub>	R( $\mathcal{I}_2$ )			The responses of the detector.

## 9.5 Contents of /power/ data structure

A /power/ data structure is used to store the information related to the powers and fluxes over the reactor core. This object has a signature L\_POWER; it is created using the FLPOW: module. The reactor fluxes and powers are recorded using several data formats.

### 9.5.1 The state-vector content

The dimensioning parameters  $\mathcal{S}_i$ , which are stored in the state vector for this data structure, represent:

- The number of energy groups  $N_{gr} = \mathcal{S}_1$
- The total number of mesh-splitted volumes  $N_{el} = \mathcal{S}_2$
- The number of mesh-splitted volumes along x-axis  $L_x = \mathcal{S}_3$
- The number of mesh-splitted volumes along y-axis  $L_y = \mathcal{S}_4$
- The number of mesh-splitted volumes along z-axis  $L_z = \mathcal{S}_5$
- The number of reactor channels  $N_{ch} = \mathcal{S}_6$
- The number of bundles per channel  $N_b = \mathcal{S}_7$

### 9.5.2 The /power/ directory

The following records will be found on the /power/ directory:

Table 120: Records in /power/ data structure

Name	Type	Condition	Units	Comment
SIGNATURE <sub>UUU</sub>	C*12			Signature of the /power/ data structure (SIGNA=L_POWER <sub>UUUUUU</sub> ).
STATE-VECTOR	I(40)			Vector describing the various parameters associated with this data structure $\mathcal{S}_i$
PTOT <sub>UUUUUUUU</sub>	D(1)		MW	The total reactor power.
VTOT <sub>UUUUUUUU</sub>	D(1)		cm <sup>3</sup>	The total reactor volume.
NORM <sub>UUUUUUUU</sub>	D(1)			The flux normalization factor.
FLMIX <sub>UUUUUUUU</sub>	I( $N_{ch}, N_b$ )			Fuel mixture indices per fuel bundle.
FLUX <sub>UUUUUUUU</sub>	R( $N_{el}, N_{gr}$ )		cm <sup>-2</sup> s <sup>-1</sup>	The normalized fluxes over the whole reactor geometry, recorded per each mesh-splitted volume and per each energy group. The flux values over the virtual regions are set to 0.
VOLU-BUND <sub>UUU</sub>	R( $N_{ch}, N_b$ )		cm <sup>2</sup>	The volume of each fuel bundle.
FLUX-BUND <sub>UUU</sub>	R( $N_{ch}, N_b, N_{gr}$ )		cm <sup>-2</sup> s <sup>-1</sup>	The normalized average fluxes recorded per each fuel bundle and per each energy group.

continued on next page



Records in /power/ data structure

continued from last page

Name	Type	Condition	Units	Comment
FLUX-DISTR <sub>UU</sub>	$R(L_x, L_y, L_z, N_{gr})$		$\text{cm}^{-2} \text{ s}^{-1}$	The normalized flux distribution over the whole reactor geometry, recorded per each X-Y-Z planes and per each energy group.
FLUX-RATIO <sub>UU</sub>	$R(L_x, L_y, L_z, N_{gr} - 1)$			The fluxes ratios with respect to the thermal energy-group fluxes.
POWER-BUND <sub>UU</sub>	$R(N_{ch}, N_b)$		$kW$	The bundle powers.
POWER-CHAN <sub>UU</sub>	$R(N_{ch})$		$kW$	The channel powers.
POWER-DISTR <sub>U</sub>	$R(L_x, L_y, L_z)$		$W$	The power distribution over the reactor core, recorded per each X-Y-Z planes. The power values over the non-fuel regions are set to 0.
PMAX-CHAN <sub>UUU</sub>	$R(1)$		$kW$	The maximum channel power.
PMAX-BUND <sub>UUU</sub>	$R(1)$		$kW$	The maximum bundle power.
FORM-CHAN <sub>UUU</sub>	$R(1)$			The radial power-form factor, defined as maximum-to-average channel power in core.
FORM-BUND <sub>UUU</sub>	$R(1)$			The overall power-form factor, defined as maximum-to-average bundle power in core.
K-EFFECTIVE <sub>U</sub>	$R(1)$			The effective multiplication factor, recovered from the /flux/ data structure.

All stored fluxes are normalized either to the given total reactor power or using the previously recorded normalization factor. The recorded values of the maximum channel and bundle powers, the channel and bundle power-form factors, and the effective multiplication factor, can be used as power and criticality constraints for the optimization and fuel management purposes.

## 9.6 Contents of /history/ data structure

This data structure contains the information required to ensure a smooth coupling of DRAGON with DONJON when a history based full reactor calculation is to be performed.

### 9.6.1 The main directory

The following records and sub-directories will be found in the first level of a /history/ directory:

Table 121: Main records and sub-directories in /history/

Name	Type	Condition	Units	Comment
SIGNATURE <sub>UUU</sub>	C*12			parameter <b>SIGNA</b> containing the signature of the data structure
STATE-VECTOR	I(40)			array $\mathcal{S}_i^h$ containing various parameters that are required to describe this data structure
BUNDLELENGTH	R(1)		cm	parameter $L_z$ containing the fuel bundle length
NAMEGLOBAL <sub>UU</sub>	C( $\mathcal{S}_1^h$ )*12			array $\mathcal{G}_j$ containing the names of the global parameters
PARAMGLOBAL <sub>U</sub>	R( $\mathcal{S}_1^h$ )			array $G_j$ containing the value of the global parameters
NAMELOCAL <sub>UUUU</sub>	C( $\mathcal{S}_2^h$ )*12			array $\mathcal{L}_j$ containing the names of the local parameters
CELLID <sub>UUUUUU</sub>	I( $\mathcal{S}_3^h, \mathcal{S}_4^h$ )			array $C_{i,j}$ containing an identification number associated with bundle $i$ and channel $j$
FUELID <sub>UUUUUU</sub>	I( $\mathcal{S}_3^h, \mathcal{S}_4^h$ )			array $F_{i,j}$ containing the fuel type associated with bundle $i$ and channel $j$
{/FUELDIR/}	Dir			list of sub-directories <b>FUEL</b> <sub><math>i,j</math></sub> that contain the properties associated with the fuel type $F_{i,j}$
{/CELLDIR/}	Dir			list of sub-directories <b>CELL</b> <sub><math>i,j</math></sub> that contain the properties associated with the cell $C_{i,j}$

The signature for this data structure is **SIGNA=L\_HISTORY<sub>UUU</sub>**. The array  $\mathcal{S}_i^h$  contains the following information:

- $\mathcal{S}_1^h = N_g$  contains the number of global parameters.
- $\mathcal{S}_2^h = N_l$  contains the number of local parameters.
- $\mathcal{S}_3^h = N_b$  contains the number of bundles per channel.
- $\mathcal{S}_4^h = N_c$  contains the number of channels in the core.
- $\mathcal{S}_5^h = N_s$  contains the number of bundle shift.
- $\mathcal{S}_6^h = T_s$  contains the type of depletion solution used.
- $\mathcal{S}_7^h = T_b$  contains the type of burnup considered.

- $\mathcal{S}_8^h = N_I$  contains the number of isotopes.
- $\mathcal{S}_9^h = G$  contains the number of transport groups.
- $\mathcal{S}_{10}^h = N_r$  contains the number of regions.
- $\mathcal{S}_{11}^h = N_F$  contains the number of fuel types.

The fuel directory name  $\text{FUEL}_{i,j}$  associated with fuel type  $F_{i,j}$  is composed using the following FORTRAN instruction:

```
WRITE(FUEL, '(A4,I8.8)') 'FUEL', F_{i,j}
```

This directory will contain the initial isotopic content of this fuel type. The cell directory name  $\text{CELL}_{i,j}$  associated with  $C_{i,j}$  is composed using the following FORTRAN instruction:

```
WRITE(CELL, '(A4,I8.8)') 'CELL', C_{i,j}
```

This directory will contain the value of the local parameters associated with cell  $C_{i,j}$  as well as the current isotopic content of this cell.

The identification number  $C_{i,j}$  associated with channel  $j$  and bundle  $i$  can be seen as the serial number of the bundle located at a position in space identified by  $(i, j)$ . It is automatically managed by the `HST:` module.<sup>[?]</sup> For a fresh core  $C_{i,j} = n$  where  $n$  represents the cell order definition in the input file. Upon refueling, some bundles in channel  $k$  of the core are displaced from region  $(l, k)$  to  $(m, k)$ , new bundles are introduced at location  $(l, k)$  and old bundles removed from location  $(m, k)$ . If one assumes that  $C^{\text{NEW}}$  and  $C^{\text{OLD}}$  represents the value of  $C$  after and before refueling then we will have:

$$\begin{aligned} C_{m,k}^{\text{NEW}} &= C_{l,k}^{\text{OLD}} \\ C_{l,k}^{\text{NEW}} &= C_{m,k}^{\text{FRESH}} \end{aligned}$$

where  $C_{m,k}^{\text{FRESH}}$  represent a fresh fuel cell. The local parameters and burnup power density of the fuel cell previously located at  $(m, k)$  are preserved and the fresh fuel isotopic densities is that provided in  $F_{m,k}$ , the fuel type associated with  $C_{m,k}^{\text{FRESH}}$ .

### 9.6.2 The fuel type sub-directory

Each fuel sub-directory  $\text{FUEL}_{i,j}$  contains the following information

Table 122: Fuel type sub-directory

Name	Type	Condition	Units	Comment
FUELDEN-INIT	R(2)			array containing the initial density of heavy element in the fuel $\rho_f$ in g/cm <sup>3</sup> and the initial linear density of heavy element in the fuel $m_f$ in g/cm.
ISOTOPEUSED	C( $N_I$ )*12			array containing the name of isotopes used in this fuel type
ISOTOPESMIX <sub>⊥</sub>	I( $N_I$ )			array containing the mixture associated with each isotopes in this fuel type
ISOTOPESDENS	R( $N_I$ )		(cm b) <sup>-1</sup>	array $\rho_i$ containing the density of each isotopes

### 9.6.3 The cell type sub-directory

Each cell isotopic sub-directory  $\text{CELL}_{i,j}$  contains the following information

Table 123: Cell sub-directory

Name	Type	Condition	Units	Comment
FUEL-DEN-INIT	R(2)			array containing the initial density of heavy element in the fuel $\rho_f$ in $\text{g/cm}^3$ and the initial linear density of heavy element in the fuel $m_f$ in $\text{g/cm}$ .
PARAMLOCALBR	R( $N_l$ )			array $V_l^B$ containing the value of the local parameters before refueling
PARAMLOCALAR	R( $N_l$ )			array $V_l^A$ containing the value of the local parameters after refueling
PARAMBURNTBR	R(2)			array containing the depletion time $T^B$ in days and the burnup power rate $P^B$ in $\text{kW/kg}$ before refueling
PARAMBURNTAR	R(2)			array containing the depletion time $T^A$ in days and the burnup power rate $P^A$ in $\text{kW/kg}$ after refueling
DEPL-PARAM <sub>LU</sub>	R(3)			array containing the time step $T$ in days, the burnup $B$ in $\text{kWd/kg}$ and the irradiation $w$ in $\text{n/kb}$ currently reached by the fuel in this cell
ISOTOPESDENS	R( $N_I$ )		$(\text{cm b})^{-1}$	array $\rho_i$ containing the density of each isotopes

## 9.7 Contents of /thm/ data structure

This data structure contains the thermal-hydraulics information required in a multi-physics calculation

### 9.7.1 The main /thm/ directory

The following records and sub-directories will be found in the first level of a /thm/ directory:

Table 124: Main records and sub-directories in /thm/

Name	Type	Condition	Units	Comment
SIGNATURE <sub>UUU</sub>	C*12			parameter SIGNA containing the signature of the data structure
STATE-VECTOR	I(40)			array $S_i^{th}$ containing various integer parameters that are required to describe this data structure
REAL-PARAM <sub>UU</sub>	R(40)			array $R_i^{th}$ containing various floating-point parameters that are required to describe this data structure
MESHZ <sub>UUUUUUU</sub>	$R(S_1^{th})$		m	initial axial meshes as recovered from the fuelmap
REF-RAD <sub>UUUUU</sub>	$R((S_7^{th} - 1) \times S_1^{th})$		m	initial radial meshes as recovered from the first call to THM: module
NB-FUEL <sub>UUUUU</sub>	$R(S_2^{th})$			number of active fuel rods in a single assembly or number of active fuel pins in the cluster
NB-TUBE <sub>UUUUU</sub>	$R(S_2^{th})$			number of active guide tubes in a single assembly
FRACT-PU <sub>UUUU</sub>	$R(S_2^{th})$			plutonium mass enrichment
KCONDF <sub>UUUUUU</sub>	$R(S_{16}^{th} + 3)$	$S_{12}^{th} \neq 0$		coefficients of the user-defined correlation for the fuel thermal conductivity
UCONDF <sub>UUUUUU</sub>	C12	$S_{12}^{th} \neq 0$		string variable set to KELVIN or to CELSIUS
KCONDC <sub>UUUUUU</sub>	$R(S_{17}^{th} + 3)$	$S_{13}^{th} \neq 0$		coefficients of the user-defined correlation for the clad thermal conductivity
UCONDC <sub>UUUUUU</sub>	C12	$S_{13}^{th} \neq 0$		string variable set to KELVIN or to CELSIUS
ERROR-T-FUEL	R(1)		K	absolute error in fuel temperature
ERROR-D-COOL	R(1)		g/cc	absolute error in coolant density
ERROR-T-COOL	R(1)		K	absolute error in coolant temperature
MIN-T-FUEL <sub>UU</sub>	R(1)		K	minimum fuel temperature
MIN-D-COOL <sub>UU</sub>	R(1)		g/cc	minimum coolant density
MIN-T-COOL <sub>UU</sub>	R(1)		K	minimum coolant temperature
MAX-T-FUEL <sub>UU</sub>	R(1)		K	maximum fuel temperature
MAX-D-COOL <sub>UU</sub>	R(1)		g/cc	maximum coolant density
MAX-T-COOL <sub>UU</sub>	R(1)		K	maximum coolant temperature
HISTORY-DATA	Dir			sub-directory containing the historical values taken by the thermal-hydraulics parameters (mass flux, density, pressure, enthalpy, temperature) in the coolant and in the fuel rod for the whole geometry
RAD-PROF_R <sub>UU</sub>	$R(S_{18}^{th})$	$S_{18}^{th} \neq 0$	m	abscissas of the user-defined radial form factor table
RAD-PROF_F <sub>UU</sub>	$R(S_{18}^{th})$	$S_{18}^{th} \neq 0$		form-factor values of the user-defined radial form factor table
TIME-SR1 <sub>UU</sub>	$R(S_{19}^{th})$	$S_{19}^{th} \neq 0$	s	tabulation abscissa in time

continued on next page

Main records and sub-directories in /thm/

continued from last page

Name	Type	Condition	Units	Comment
POWER-SR1 <sub>LU</sub>	R( $\mathcal{S}_{19}^{th}$ )	$\mathcal{S}_{19}^{th} \neq 0$		tabulation power factor corresponding to each tabulation abscissa in time

The signature for this data structure is **SIGNA=L\_THM**. The array  $\mathcal{S}_i^h$  contains the following information:

- $\mathcal{S}_1^{th}$  contains the number of axial meshes  $N_z$ .
- $\mathcal{S}_2^{th}$  contains the number of channels in the radial plane  $N_{ch}$ .
- $\mathcal{S}_3^{th}$  contains the maximum number of iterations for computing the conduction integral.
- $\mathcal{S}_4^{th}$  contains the maximum number of iterations for computing the center pellet temperature.
- $\mathcal{S}_5^{th}$  contains the maximum number of iterations for computing the coolant parameters (velocity, pressure, enthalpy, density) in case of a transient calculation.
- $\mathcal{S}_6^{th}$  contains the number of discretisation points in fuel.
- $\mathcal{S}_7^{th}$  contains the number of total discretisation points in the whole fuel rod (fuel+cladding)  $N_{dtot}$ .
- $\mathcal{S}_8^{th}$  contains the type of calculation performed by the **THM**: module:

$$\mathcal{S}_8^{th} = \begin{cases} 0 & \text{steady-state calculation} \\ 1 & \text{transient calculation.} \end{cases}$$

- $\mathcal{S}_9^{th}$  contains the current time index.
- $\mathcal{S}_{10}^{th}$  flag to set the gap correlation:

$$\mathcal{S}_{10}^{th} = \begin{cases} 0 & \text{built-in correlation is used} \\ 1 & \text{set the heat exchange coefficient of the gap as a user-defined constant.} \end{cases}$$

- $\mathcal{S}_{11}^{th}$  flag to set the heat transfer coefficient between the clad and fluid:

$$\mathcal{S}_{11}^{th} = \begin{cases} 0 & \text{built-in correlation is used} \\ 1 & \text{set the heat exchange coefficient between the clad and fluid as a user-defined constant.} \end{cases}$$

- $\mathcal{S}_{12}^{th}$  flag to set the fuel thermal conductivity:

$$\mathcal{S}_{12}^{th} = \begin{cases} 0 & \text{built-in correlation is used} \\ 1 & \text{set the fuel thermal conductivity as a function of a simple user-defined correlation.} \end{cases}$$

- $\mathcal{S}_{13}^{th}$  flag to set the clad thermal conductivity:

$$\mathcal{S}_{13}^{th} = \begin{cases} 0 & \text{built-in correlation is used} \\ 1 & \text{set the clad thermal conductivity as a function of a simple user-defined correlation.} \end{cases}$$

- $\mathcal{S}_{14}^{th}$  type of approximation used during the fuel conductivity evaluation:

$$\mathcal{S}_{14}^{th} = \begin{cases} 0 & \text{use a rectangle quadrature approximation} \\ 1 & \text{use an average approximation.} \end{cases}$$

- $\mathcal{S}_{15}^{th}$  type of subcooling model:

$$\mathcal{S}_{15}^{th} = \begin{cases} 0 & \text{use the Bowring correlation} \\ 1 & \text{use the Saha-Zuber correlation.} \end{cases}$$

- $\mathcal{S}_{16}^{th}$  contains the number of terms in the user-defined correlation for the fuel thermal conductivity (if  $\mathcal{S}_{12}^{th} = 1$ ).
- $\mathcal{S}_{17}^{th}$  contains the number of terms in the user-defined correlation for the clad thermal conductivity (if  $\mathcal{S}_{13}^{th} = 1$ ).
- $\mathcal{S}_{18}^{th}$  type of radial form factor for the power:

$$\mathcal{S}_{18}^{th} = \begin{cases} 0 & \text{flat radial form factor} \\ N_{\text{rad}} & \text{number of point in the radial form factor table.} \end{cases}$$

- $\mathcal{S}_{19}^{th}$  number of points in the user-defined time-power table.
- $\mathcal{S}_{20}^{th}$  type of fluid:

$$\mathcal{S}_{20}^{th} = \begin{cases} 0 & \text{light water (H}_2\text{O)} \\ 1 & \text{heavy water (D}_2\text{O)}. \end{cases}$$

The array  $\mathcal{R}_i^{th}$  contains the following information:

- $\mathcal{R}_1^{th}$  contains the current time step in s.
- $\mathcal{R}_2^{th}$  contains the fraction of reactor power released in fuel.
- $\mathcal{R}_3^{th}$  contains the critical heat flux in W/m<sup>2</sup>.
- $\mathcal{R}_4^{th}$  contains the inlet coolant velocity in m/s.
- $\mathcal{R}_5^{th}$  contains the outlet coolant pressure in Pa.
- $\mathcal{R}_6^{th}$  contains the inlet coolant temperature in K.
- $\mathcal{R}_7^{th}$  contains the fuel porosity.
- $\mathcal{R}_8^{th}$  contains the fuel pellet radius
- $\mathcal{R}_9^{th}$  contains the internal clad rod radius in m.
- $\mathcal{R}_{10}^{th}$  contains the external clad rod radius in m.
- $\mathcal{R}_{11}^{th}$  contains the guide tube radius in m.
- $\mathcal{R}_{12}^{th}$  contains the hexagonal side in m. Used only for cluster geometries.
- $\mathcal{R}_{13}^{th}$  contains the temperature maximum absolute error (in K) allowed in the solution of the conduction equations.
- $\mathcal{R}_{14}^{th}$  contains the maximum relative error allowed in the matrix resolution of the conservation equations of the coolant.

- $\mathcal{R}_{15}^{th}$  contains the relaxation parameter for the multiphysics parameters (temperature of fuel and coolant and density of coolant).
- $\mathcal{R}_{16}^{th}$  contains the time in s.
- $\mathcal{R}_{17}^{th}$  contains the heat transfer coefficient of the gap (if  $\mathcal{S}_{10}^{th} = 1$ ).
- $\mathcal{R}_{18}^{th}$  contains the heat transfer coefficient between the clad and fluid (if  $\mathcal{S}_{11}^{th} = 1$ ).
- $\mathcal{R}_{19}^{th}$  contains the surface temperature weighting factor of effective fuel temperature for the Rowlands approximation.
- $\mathcal{R}_{20}^{th}$  reactor power, as defined after the **POWER-LAW** keyword.
- $\mathcal{R}_{21}^{th}$  maximum of variable variations in local parameters (used for time step adjustment strategy).
- $\mathcal{R}_{22}^{th}$  contains the rugosity of the fuel rod in m, used in Müller-Steinhagen correlation for coolant friction.
- $\mathcal{R}_{23}^{th}$  contains the angle in radians of the fuel channel with respect of the vertical axis.

### 9.7.2 The *HISTORY-DATA* sub-directory

In the **HISTORY-DATA** directory, the following sub-directories will be found:

Table 125: Sub-directories in **HISTORY-DATA** directory

Name	Type	Condition	Units	Comment
<b>TIMESTEP0000</b>	Dir			sub-directory containing all the values of the thermal-hydraulics parameters computed by the <b>THM</b> : module <i>in steady-state conditions</i> .
<b>TIMESTEP<math>numt</math></b>	Dir			sub-directories containing all the values of the thermal-hydraulics parameters computed by the <b>THM</b> : module in transient conditions at a given time index <i>numt</i> . <i>numt</i> can take values between 1 and 9999 in I4.4 format.

In the **TIMESTEP0000** and in each of the **TIMESTEP $numt$**  sub-directories, the following records will be found:



Table 126: Records in **TIMESTEP** directories

Name	Type	Condition	Units	Comment
<b>TIME</b> <sub>UUUUUUUU</sub>	R(1)		<i>s</i>	time
<b>CHANNEL</b> <sub>UUUUUU</sub>	Dir( $N_{\text{ch}}$ )			list of $N_{\text{ch}}$ sub-directories containing all the values of the thermal-hydraulics parameters computed by the <b>THM:</b> module and sorted channel by channel.

In each of the **CHANNEL** sub-directories, the following records will be found:

Table 127: Records in each **CHANNEL** directory

Name	Type	Condition	Units	Comment
<b>VINLET</b> <sub>UUUUUU</sub>	R(1)		$m.s^{-1}$	inlet velocity
<b>TINLET</b> <sub>UUUUUU</sub>	R(1)		<i>K</i>	inlet temperature
<b>PINLET</b> <sub>UUUUUU</sub>	R(1)		<i>Pa</i>	inlet pressure
<b>VELOCITIES</b> <sub>UU</sub>	R( $N_z$ )		$m.s^{-1}$	velocity in each of the $N_z$ bundles of the channel numbered <i>numc</i>
<b>PRESSURE</b> <sub>UUUU</sub>	R( $N_z$ )		<i>Pa</i>	pressure in each bundle of the channel
<b>ENTHALPY</b> <sub>UUUU</sub>	R( $N_z$ )		$J.kg^{-1}$	enthalpy in each bundle of the channel
<b>DENSITY</b> <sub>UUUUU</sub>	R( $N_z$ )		$kg.m^{-3}$	density in each bundle of the channel
<b>LIQUID-DENS</b> <sub>U</sub>	R( $N_z$ )		$kg.m^{-3}$	density of liquid phase in each bundle of the channel
<b>TEMPERATURES</b>	R( $N_z, N_{\text{dtot}}$ )		<i>K</i>	distribution of the temperature in the fuel-pin for each bundle of the channel
<b>CENTER-TEMPS</b>	R( $N_z$ )		<i>K</i>	center fuel pellet temperature in each bundle of the channel
<b>RADII</b>	R( $N_z, N_{\text{dtot}} - 1$ )		<i>m</i>	fuel and clad radii

### 9.8 Contents of a /optimize/ data structure

The /optimize/ specification is used to store the optimization variables and functions values and definitions, limits and options.

In any case, the signature variable for this data structure must be **SIGNA=L\_OPTIMIZE<sub>LU</sub>**. The dimensioning parameters for this data structure, which are stored in the state vector  $\mathcal{S}_i^o$ , represents:

- The number of decision variables  $N_{var} = \mathcal{S}_1^o$ .
- The number of constraints  $N_{cst} = \mathcal{S}_2^o$ .
- The type of optimization  $\mathcal{S}_3^o$ , where

$$\mathcal{S}_3^o = \begin{cases} 1 & \text{minimization} \\ -1 & \text{maximization} \end{cases}$$

- The result of a test for external convergence of the optimization problem  $\mathcal{S}_4^o$ , where

$$\mathcal{S}_4^o = \begin{cases} 0 & \text{not converged} \\ 1 & \text{converged} \end{cases}$$

- The index of external iteration ( $\mathcal{S}_5^o$ ). If module **PLQ:** is used, this is the iteration index relative to the solution of a new linear optimization problem with a quadratic constraint. If module **LNSR:** is used, this is the number of times the line search algorithm is called.
- The type of reduction for the radius if the quadratic constraint ( $\mathcal{S}_6^o$ ) used in module **PLQ:**, where

$$\mathcal{S}_6^o = \begin{cases} 1 & \text{half} \\ 2 & \text{parabolic} \end{cases}$$

- The type of gradient search  $\mathcal{S}_7^o$ , where

$$\mathcal{S}_7^o = \begin{cases} 0 & \text{steepest descent} \\ 1 & \text{conjugate gradient} \\ 2 & \text{Broyden-Fletcher-Goldfarb-Shanno (BFGS)} \\ 3 & \text{memory limited Broyden-Fletcher-Goldfarb-Shanno (LBFGS)} \\ 4 & \text{Newton method for unconstrained optimization} \end{cases}$$

- The type of optimization method  $\mathcal{S}_8^o$ , where

$$\mathcal{S}_8^o = \begin{cases} 0 & \text{not set} \\ 1 & \text{OPTEX method with module PLQ:} \\ 2 & \text{line search algorithm with module LNSR:} \\ 3 & \text{fixed point SPH algorithm with module FPSPH:} \\ 4 & \text{Newtonian SPH algorithm with module FPSPH:} \end{cases}$$

- The resolution's method for the linear problem with quadratic constraint used in module **PLQ:** ( $\mathcal{S}_9^o$ ), where

$$\mathcal{S}_9^o = \begin{cases} 1 & \text{SIMPLEX/LEMKE} \\ 2 & \text{LEMKE/LEMKE} \\ 3 & \text{MAP} \\ 4 & \text{Augmented Lagragian} \\ 5 & \text{Penalty Method} \end{cases}$$

- The index of line search iteration in module **LNSR**: ( $S_{10}^o$ ). The maximum number of line search iterations is fixed to 50 in module **LNSR**:.
- The result of a test for the convergence of the line search iterations  $S_{11}^o$  in module **LNSR**:, where

$$S_{11}^o = \begin{cases} 0 & \text{not converged} \\ 1 & \text{converged} \\ 2 & \text{maximum line search iteration reached} \end{cases}$$

- The maximum number of external iterations in module **LNSR**: ( $S_{12}^o$ ).
- The external iteration restart cycle in module **LNSR**: ( $S_{13}^o$ ).
- A flag for unsuccessful resolution in module **PLQ**:  $S_{14}^o$ , where

$$S_{14}^o = \begin{cases} 0 & \text{successful at last iteration} \\ \geq 1 & \text{number of iteration with unsuccessful resolution.} \end{cases}$$

Table 128: Main records and sub-directories in /optimize/

Name	Type	Condition	Units	Comment
<b>SIGNATURE</b> <sub>UUU</sub>	C*12			Signature of the data structure ( <b>SIGNA</b> )
<b>STATE-VECTOR</b>	I(40)			Vector describing the various parameters associated with data structure $S_i^o$ .
<b>DEL-STATE</b> <sub>UUU</sub>	I(40)	*		Vector describing the various parameters associated with data structure $S_i^g$ . This array is available if the <b>OPTIMIZE</b> object has been created using module <b>DLEAK</b> : or <b>DSPH</b> :.
<b>VAR-VALUE</b> <sub>UUU</sub>	D( $N_{var}$ )			The values of the decision variables
<b>VAR-VAL-MAX</b> <sub>U</sub>	D( $N_{var}$ )			The maximum values of the decision variables can be.
<b>VAR-VAL-MIN</b> <sub>U</sub>	D( $N_{var}$ )			The minimum values of the decision variables can be.
<b>VAR-WEIGHT</b> <sub>UU</sub>	D( $N_{var}$ )			The weight of the decision variables $w_i$ in the quadratic constraint.
<b>CST-OBJ</b> <sub>UUUUU</sub>	D( $N_{cst}$ )			The limit value of the constraints. The units depends with the type of the constraint type.
<b>CST-TYPE</b> <sub>UUUUU</sub>	I( $N_{cst}$ )			The type of the constraints: =-1 for $\geq$ ; =0 for $=$ ; =1 for $\leq$ .
<b>CST-WEIGHT</b> <sub>UU</sub>	D( $N_{cst}$ )			The weight of the constraint $\eta_j$ and $\gamma_j$ for the duals and meta-heuristic methods.
<b>FOBJ-CST-VAL</b>	D( $N_{cst} + 1$ )			The actual values of the objective function (first value) and the constraints (the following values). The number of the constraints are assigned in the order they have been defined.
<b>OPT-PARAM-R</b> <sub>U</sub>	D(40)			The different limits and values for the iterative calculations of the optimization problem.

continued on next page

Main records and sub-directories in /optimize/

continued from last page

Name	Type	Condition	Units	Comment
GRADIENT <sub>UUUU</sub>	$D(N_{var}, N_{cst} + 1)$			The gradients of the objective function and the constraints. The gradients of the objective for all the decision variables are in first position, then follow the gradients of the constraints.
GRADIENT-DIR	$D(N_{var}, N_{cst} + 1)$	*		The direct component (without the flux effect) for the gradients of the objective function and the constraints.
DIRECTION <sub>UUU</sub>	$D(N_{var})$	$\mathcal{S}_8^o = 2$		Direction of the line search.
HESSIAN <sub>UUUUU</sub>	$D(N_{var}, N_{var})$	$\mathcal{S}_7^o = 2$		The hessian matrix containing second derivatives of the objective function with respect to the decision variables.
LNSR-INFO <sub>UUU</sub>	$D(9)$	$\mathcal{S}_8^o = 2$		Double precision values used by module LNSR:.
OLD-VALUE <sub>UUU</sub>	Dir			Directory containing different informations of the previous iterations. the values of the decision variables, the objective function, the constraints and the gradients of these functions for the previous external iteration. This repository will be created by the module PLQ: (unless it is specified to not do) or by module LNSR:.

The array OPT-PARAM-R contains double precision values related with the different limits and values for the iterative calculations of the optimization problem:

1st	$S$	initial radius of the quadratic constraint in module PLQ: or maximum stepsize for the line search in module LNSR: (default: 1.0).
2nd	$\delta$	initial size of the hypercube for MAP method. (default: 0.1).
3rd	$\varepsilon_{\text{ext}}$	limit for external convergence (default: $10^{-4}$ ).
4th	$\varepsilon_{\text{int}}$	limit for internal convergence (default: $10^{-4}$ ).
5th	$\varepsilon_{\text{quad}}$	limit for convergence of the quadratic constraint in module PLQ: (default: $10^{-4}$ ).

The other value of the record are not used and set to 0.0.

The optional array DEL-STATE contains integer values related to the definition of mixture and group indices in module DLEAK:.

- The number of energy groups in macrolib  $\mathcal{S}_1^g$ .
- The number of mixtures in macrolib  $\mathcal{S}_2^g$ .
- The type of leakage parameters  $\mathcal{S}_3^g$ , where

$$\mathcal{S}_3^g = \begin{cases} 1 & \text{use diffusion coefficients} \\ 2 & \text{use } P_1\text{-weighted macroscopic total cross sections.} \end{cases}$$

- The type of control variables  $\mathcal{S}_4^g$ , where

$$\mathcal{S}_4^g = \begin{cases} 1 & \text{use leakage parameters} \\ 2 & \text{use correction factors on leakage parameters} \\ 3 & \text{use SPH factors compatible with diffusion theory, } P_n \text{ and } SP_n \text{ equations} \\ 4 & \text{use SPH factors compatible with other types of transport-theory macro-} \\ & \text{calculations} \\ 5 & \text{use one SPH factor assigned to the albedo function in each macro-group.} \end{cases}$$

- The minimum group index  $\mathcal{S}_5^g$ , with  $1 \leq \mathcal{S}_5^g \leq \mathcal{S}_1^g$ .
- The maximum group index  $\mathcal{S}_6^g$ , with  $\mathcal{S}_5^g \leq \mathcal{S}_6^g \leq \mathcal{S}_2^g$ .
- The minimum mixture index  $\mathcal{S}_7^g$ , with  $1 \leq \mathcal{S}_7^g \leq \mathcal{S}_2^g$ .
- The maximum mixture index  $\mathcal{S}_8^g$ , with  $\mathcal{S}_7^g \leq \mathcal{S}_8^g \leq \mathcal{S}_2^g$ .
- The number of physical albedos  $\mathcal{S}_9^g$ .

#### 9.8.1 The sub-directory /OLD-VALUE/ in /optimize/

Table 129: Main records and sub-directories in //OLD-VALUE//

Name	Type	Condition	Units	Comment
VAR-VALUE <sub>UUU</sub>	D( $N_{var}$ )			The values of the decision variables of the last valid iteration.
FOBJ-CST-VAL	D( $N_{cst} + 1$ )			The values of the objective function and the constraints of the last valid iteration.
GRADIENT <sub>UUUU</sub>	D( $N_{var}, N_{cst} + 1$ )			The gradients of the objective function and the constraints of the last valid iteration.
VAR-VALUE2 <sub>UU</sub>	D( $N_{var}$ )	$\mathcal{S}_8^o = 1$		The values of the decision variables of the second-last valid iteration.
BEST-VAR <sub>UUUU</sub>	D( $N_{var}$ )	$\mathcal{S}_8^o = 1$		The values of the decision variables corresponding to the best valid solution ever found.
BEST-FCT <sub>UUUU</sub>	D(1)	$\mathcal{S}_8^o = 1$		The value of the objective function corresponding to the best valid solution ever found.

## 9.9 Contents of /d2p\_info/ data structure

A /d2p\_info/ data structure is used to store cross sections and Saphyb information such as keff, kinf, assembly discontinuity factors. This object has a signature L\_INFO; it is created using the D2P: module.

### 9.9.1 The state-vector content

The dimensioning parameters  $\mathcal{S}_i$ , which are stored in the state vector for this data structure, represent:

- The number of energy groups  $N_{\text{gr}} = \mathcal{S}_1$
- The number of pkey for the generation of the PMAXS file  $N_{\text{pk}} = \mathcal{S}_2$
- The number of cross sections recovered using the SCR: module  $N_{\text{xs}} = \mathcal{S}_3$
- The number of points with respect to burnup  $N_{\text{bu}} = \mathcal{S}_4$
- The type of branching calculation requested for the generation of PMAXS tree  $I_{\text{grid}} = \mathcal{S}_5$

$$I_{\text{grid}} = \begin{cases} 0 & \text{default meshing} \\ 1 & \text{according to the saphyb content} \\ 2 & \text{user defined with global otpion} \\ 3 & \text{user defined with add otpion} \\ 4 & \text{user defined with add new otpion} \end{cases}$$

- The number of control rod composition  $N_{\text{comp}} = \mathcal{S}_6$
- The number of delay neutron groups  $N_{\text{del}} = \mathcal{S}_7$
- The number of columns in assembly  $N_{\text{cols}} = \mathcal{S}_8$
- The number of rows in assembly  $N_{\text{rows}} = \mathcal{S}_9$
- The computed part of assembly assembly  $I_{\text{part}} = \mathcal{S}_{10}$

$$I_{\text{part}} = \begin{cases} 0 & \text{whole} \\ 1 & \text{half} \\ 2 & \text{quarter} \\ 3 & \text{eighth} \end{cases}$$

- The number of sides in assembly.  $N_{\text{surf}} = \mathcal{S}_{11}$
- The number of corners in assembly  $N_{\text{corn}} = \mathcal{S}_{12}$
- The number of assembly discontinuity factors per energy groups  $N_{\text{adf}} = \mathcal{S}_{13}$
- The number of ADF-type boundary flux edits.  $N_{\text{type}} = \mathcal{S}_{14}$
- The number of corner discontinuity factors per energy groups.  $N_{\text{cdf}} = \mathcal{S}_{15}$
- The number of group-wise form functions per energy groups in compued part of assembly.  $N_{\text{gff}} = \mathcal{S}_{16}$
- The number of pin on each side of the assembly.  $N_{\text{pin}} = \mathcal{S}_{17}$
- The type of cross section library containing the cross sections.  $I_{\text{typ}} = \mathcal{S}_{18}$

$$I_{\text{typ}} = \begin{cases} 0 & \text{saphyb} \\ 1 & \text{multicompo} \end{cases}$$

- The temperature unit for moderator and fuel.  $I_{\text{temp}} = \mathcal{S}_{19}$

$$I_{\text{temp}} = \begin{cases} 0 & \text{celsius} \\ 1 & \text{kelvin} \end{cases}$$

- The number of additional parameters contained in the saphyb (other than state variables).  $N_{\text{oth}} = \mathcal{S}_{20}$
- The treatment of Assembly Discontinuity Factors.  $I_{\text{merge}} = \mathcal{S}_{21}$

$$I_{\text{merge}} = \begin{cases} 0 & \text{ADF are explicitly stored in the PMAXS} \\ 1 & \text{ADF are inserted in the cross sections} \end{cases}$$

- The correction on Pm 147 fission yield.  $I_{\text{cor}} = \mathcal{S}_{22}$

$$I_{\text{cor}} = \begin{cases} 0 & \text{No correction of Pm 147 fission yield} \\ 1 & \text{Correction of Pm 147 fission yield} \end{cases}$$

The following records and sub-directories will be found on the first level of /d2p\_info/ directory:

Table 130: Records and sub-directories in /d2p\_info/ data structure

Name	Type	Condition	Units	Comment
SIGNATURE <sub>UUU</sub>	C*12			Signature of the /d2p_info/ data structure (SIGNA=L_INFO <sub>UUUUUU</sub> ).
STATE-VECTOR	I(40)			Vector describing the various parameters associated with this data structure
BARR_INFO <sub>UUU</sub>	I( $N_{comp}$ )			Meaning of control rod in the saphyb object. $N_{comp}$ is the number of composition for control rods (including the unrodded case)
SAPHYB_INFO <sub>U</sub>	Dir	$iph \geq 1$		Information related to the saphyb content.
HELIOS_HEAD <sub>U</sub>	Dir	$iph \geq 1$		Information related to the header of output .DRA file
GENPMAXS_INP	Dir	$iph \geq 2$		Information related to the GenPMAXS input file.
BRANCH_INFO <sub>U</sub>	Dir	$iph \geq 3$		Information related to the current branch calculation.
TH_DATA <sub>UUUUU</sub>	Dir( $N_{bu}$ )	$iph \geq 2$		Information related to the invariant T/H data block. Each component of the list is a directory containing TH data for a single burnup point.

Table 131: Records and sub-directories in /SAPHYB\_INFO/

Name	Type	Condition	Units	Comment
PKEY_INFO <sub>UUU</sub>	Dir(6)			Each component of the list is a directory containing information for all possible state variables.
OTHPK <sub>UUUUUUU</sub>	$C(N_{oth}) * 12$			Name of other parameters .
OTHTYP <sub>UUUUUU</sub>	$I((N_{oth}))$			Type of other parameters (Integer=1, Real=2, String=3.
OTHVAC <sub>UUUUUU</sub>	$C(N_{oth}) * 12$			Value of other parameters of type characater.
OTHVAR <sub>UUUUUU</sub>	$R((N_{oth}))$			Value of other parameters of type real.
NTOT <sub>UUUUUU</sub>	I(1)			Total number of parameters in the SAP (or MCO) object. Exept 'FLUE' and 'TIME'
STATE_VAR <sub>UUU</sub>	$C(N_{pk}) * 12$			Name of state variables (PKEY).

continued on next page



Records and sub-directories in /SAPHYB\_INFO/

continued from last page

Name	Type	Condition	Units	Comment
ISOTOPES <sub>UUUUU</sub>	C(8) * 12			Reference name of isotopes in the saphyb object for depletion chain, recovery of fission yield and number densities. 1) Xe135 2) I135 3) Sm 149 4) Pm149 5)Pm148 6) Pm148m 7) Nd147 8)Pm147 .
/suname/	R( $N_k$ )			Values for each state variable specified by PKEY <sub>k</sub> , $N_k$ is the number of value taken for the $k^{th}$ PKEY.
PKIDX <sub>UUUUUUUU</sub>	I( $N_{pk}$ )			Correspondance of indices between SAP/MCO and GenPMAXS state variables
ADF_TYPE <sub>UUUUU</sub>	C*3	ladf		Type of ADF recovered (DRA, GET or SEL).
HADF <sub>UUUUUUUUU</sub>	C( $N_{adf}$ ) * 8	ladf		Name of the ADF-type boundary flux edit to be recovered from Multicompo
CDF_TYPE <sub>UUUUU</sub>	C*3	lcdf		Type of CDF recovered (only DRA).
HCDF <sub>UUUUUUUUU</sub>	C( $N_{adf}$ ) * 8	lcdf		Name of the CDF-type boundary flux edit to be recovered from Multicompo.
GFF_TYPE <sub>UUUUU</sub>	C*3	lgff		Type of GFF recovered (only DRA).
YLD_OPT <sub>UUUUU</sub>	C*3	lyld		Type of fission yield to be recovered (FIX,MAN or DEF).
YLD_FIX <sub>UUUUU</sub>	R(3)	lyld		User defined values for fission yields (1:I, 2:XE, 3:PM)
YLD_LOC <sub>UUUUU</sub>	R(6)	lyld		Values for state parameter on which fission yields are calculated.

Each component of the list PKEY\_INFO is a directory containing for all possible state variables ( 1=BARR, 2=DMOD, 3=CBOR, 4=TCOM, 5=TMOD, 6=BURN). Inside each groupwise directory, the following records will be found:

Table 132: Records in /PKEY\_INFO/

Name	Type	Condition	Units	Comment
LFLAG <sub>UUUUUUUU</sub>	I(1)			Indicates if the corresponding state variable can be found in the SAP (or MCO) object.
NAME <sub>UUUUUUUUU</sub>	C*12	lflag		Name of the state parameter in the SAP (or MCO) object. For BARR and BURN state variables, this record exists even if LFLAG is <i>false</i> .

Table 133: Records and sub-directories in /HELIOS\_HEAD/

Name	Type	Condition	Units	Comment
FILE_CONT_1_	R(2)			Set of data for FILE_CONT_1 block in DRA file : Heavy metal Density(HM.Dens), Bypass Density(ByPass).
FILE_CONT_2_	R(8)			Set of data for FILE_CONT_2 block in DRA file : Lower Energy Limits of Neutron Groups.
FILE_CONT_3_	R(7)			Set of data for FILE_CONT_3 block in DRA file : Volume of coolant (VCool), moderator (VModr), control rods (VCnRd), fuel(VFuel), cladding (VClad), channels (VChan), water (VWatR).
FILE_CONT_4_	R(3)			Set of data for FILE_CONT_4 block in DRA file : Cell Pitch and X,Y Position of First Cell.
XS_CONT_	R(1)			Set of data for XS_CONT block in DRA file : (VFCM).

Table 134: Records and sub-directories in /GENPMAXS\_INP/

Name	Type	Condition	Units	Comment
FLAG_	I(1)			Indicates the end of a branch calculation.
JOB_TIT_	C*16			Name of final PMAXS file.
FILE_NAME_	C*12			Name of output DRA file
DERIVATIVE_	C*4			Set of data for FILE_CONT_3 block in DRA file : Volume of coolant (VCool), moderator (VModr), control rods (VCnRd), fuel(VFuel), cladding (VClad), channels (VChan), water (VWatR).
VERSION_	R(1)			Version of PARCS used.
COMMENT_	C*40			Free comment.
JOB_OPT_	C(14) * 1			Options for GenPMAXS running (see [52]).
DAT_SRC_	R(5)			Data source information (see [52]).

Each component of the list TH\_DATA is a directory containing TH data for a single burnup point. Inside each groupwise directory, the following records associated will be found:

Table 135: Records in sub-directory /TH\_DATA/

Name	Type	Condition	Units	Comment
CHI_	$R(N_{gr})$	$lchi$		The steady-state energy spectrum of the neutron emitted by fission $\chi$ .
OVERV_	$R(N_{gr})$	$linv$	$\text{s.cm}^{-1}$	The average of the inverse neutron velocity.
LAMBDA_	$R(N_{del})$	$lamb$	$\text{s}^{-1}$	Decay constant of delayed neutron.
BETA_	$R(N_{del})$	$lbet$		Effective delayed neutron fraction.
YLDPM_	$R(1)$	$lyld$		Effective yield value of Pm-149
YLDXe_	$R(1)$	$lyld$		Effective yield value of Xe-135
YLDI_	$R(1)$	$lyld$		Effective yield value of I-135

Table 136: Records and sub-directories in sub-directory /BRANCH\_INFO/

Name	Type	Condition	Units	Comment
BRANCH_IT_	$I(1)$			Index of the current branch type calculation.
BRANCH_	$C*4$			Current BRANCH type calculation.
BRANCH_NB_	$I(1)$			Number of branches to be created in PMAXS files.
REF_STATE_	$R(N_{pk} - 1)$			Values of state variables for reference state, burnup excepted.
HST_STATE_	$R(N_{pk} - 1)$			Values of state variables for history state, burnup excepted.
STATE_INDEX_	$I(N_{pk})$			Current index value for each state variables.
BRANCH_INDEX	$I(N_{pk})$			Index of current branch calculation.
STATE_	$R(N_{pk})$			State variable values for the current branch calculation.
REWIND_	$I(1)$			Indicates the end of a branch calculation (REWIND=1).
STOP_	$I(1)$			Indicates the end of calculation (STOP=1).
CROSS_SECT_	$\text{Dir}(N_{bu})$			Each component of the list is a directory containing cross sections for all burnup point of a specific branch(cross sections are overwritten after each branch calculation).
DIVERS_	$\text{Dir}(N_{bu})$	$I_{grid} \leq 1$		Each component of the list is a directory containing the DIVERS data block recovered from the saphyb object(informations are overwritten after each branch calculation).

Each component of the list **CROSS\_SECT** is a directory containing cross sections for all burnup point of a specific branch. Cross sections for a single burnup points are filled sequentially during the branching calculation. Inside each groupwise directory, the following sub-directories will be found:

Table 137: Sub-directories in /CROSS\_SECT/

Name	Type	Condition	Units	Comment
MACROLIB_XS_	Dir			Directory for macroscopic cross sections for a given calculated branch (cross sections are overwritten after each branch calculation).
MICROLIB_XS_	Dir()	<i>lxs</i>		Directory for microscopic cross sections for a given calculated branch (cross sections are overwritten after each branch calculation).

Table 138: Records in the sub-directory /MACROLIB\_XS/

Name	Type	Condition	Units	Comment
XTR_	$R(N_{gr})$		$cm^{-1}$	The transport cross section $\Sigma_f^g$ : $\Sigma_t^g = 1/(3 \cdot D_g)$ .
ABSORPTION_	$R(N_{gr})$		$cm^{-1}$	The absorption cross section $\Sigma_a^g$ : $\Sigma_a^g = \Sigma_{tot}^g - \sum_{g'} \Sigma_s^{g \rightarrow g'}$ .
KAPPA_FI_	$R(N_{gr})$		$cm^{-1}$	The product of $\Sigma_f^g$ , the fission cross section with the energy emitted by this reaction $\kappa$ : $\kappa \Sigma_f^g$ .
X_NU_FI_	$R(N_{gr})$		$cm^{-1}$	The product of $\Sigma_f^g$ , the fission cross section with the averaged number of fission-emitted delayed neutron $\nu$ : $\nu \Sigma_f^g$ .
SCAT_	$R(N_{gr} * N_{gr})$		$cm^{-1}$	Scattering cross section elements from group $g$ to $g'$ : $\Sigma_s^{g \rightarrow g'}$ .
DET_	$R(N_{gr})$	<i>ldet</i>		The detector response parameter, it is product of cross section and local flux ratio.
SFI_	$R(N_{gr})$	<i>lxs</i>	$cm^{-1}$	The fission cross section: $\Sigma_f^g$ .
ADF_	$R(N_{adf}, N_{gr})$	<i>ladf</i>		Assembly Discontinuity Factors.
CDF_	$R(N_{cdf}, N_{gr})$	<i>lcdf</i>		Corner Discontinuity Factors.
GFF_	$R(N_{pin} * N_{pin}, N_{gr})$	<i>lgff</i>		Group-wise Form Function.

Table 139: Records in the sub-directory /MICROLIB\_XS/

Name	Type	Condition	Units	Comment
XENG_	$R(N_{gr})$		$\text{cm}^{-2}$	The microscopic absorption cross section of Xenon: $\sigma_{a,Xe}^g = \sigma_{tot,Xe}^g - \sum_{g'} \Sigma_{s,Xe}^{g \rightarrow g'}$ .
SMNG_	$R(N_{gr})$		$\text{cm}^{-2}$	The microscopic absorption cross section of Samarium: $\sigma_{a,Sm}^g = \sigma_{tot,Sm}^g - \sum_{g'} \Sigma_{s,Sm}^{g \rightarrow g'}$ .
XEND_	$R(N_{gr})$		$(\text{b.cm})^{-1}$	The Xenon number density: $n_{Xe}$ .
SMND_	$R(N_{gr})$		$(\text{b.cm})^{-1}$	The Samarium number density: $n_{Sm}$ .

Each component of the list **DIVERS** is a directory containing informations for all burnup points of a specific branch recovered from the **DIVERS** block of the saphy object. Inside each groupwise directory, the following records will be found:

Table 140: Records in the sub-directory /DIVERS/

Name	Type	Condition	Units	Comment
B2_	$R(1)$		$\text{cm}^{-2}$	Critical buckling.
KEFF_	$R(1)$			Effective multiplication factor.
KINF_	$R(1)$			Infinite multiplication factor.

### 9.10 Contents of a /intdetec/ data structure

The /intdetec/ data structure is used to store integrated detector positions and responses in a PWR. This object has a signature L\_INTDETEC; it is created using the IDET: module.

#### 9.10.1 The state-vector content

The dimensioning parameters  $\mathcal{S}_i$ , which are stored in the state vector for this data structure, represent:

- The first dimension of matrices COORD1, COORD2 and COORD3, representing the maximum number of interpolation points for a single detector.  $N_{\max} = \mathcal{S}_1$ .
- The total number of detectors.  $N_{\det} = \mathcal{S}_2$ .

#### 9.10.2 The main /intdetec/ directory

The following records will be found on the first level of /intdetec/ directory:

Table 141: Records in /intdetec/ data structure

Name	Type	Condition	Units	Comment
SIGNATURE <sub>UUU</sub>	C*12			Signature of the /intdetec/ data structure (SIGNA =L_INTDETEC <sub>UU</sub> ).
STATE-VECTOR	I(40)			Vector describing the various parameters associated with this data structure $\mathcal{S}_i$
NINX <sub>UUUUUUUU</sub>	I( $\mathcal{S}_2$ )			Number of interpolation point for the detector reading along $X$ axis.
NINY <sub>UUUUUUUU</sub>	I( $\mathcal{S}_2$ )			Number of interpolation point for the detector reading along $Y$ axis.
NINZ <sub>UUUUUUUU</sub>	I( $\mathcal{S}_2$ )			Number of interpolation point for the detector reading along $Z$ axis.
COORD1 <sub>UUUUUU</sub>	R( $\mathcal{S}_1, \mathcal{S}_2$ )		cm	Values of the interpolation coordinates along $X$ axis.
COORD2 <sub>UUUUUU</sub>	R( $\mathcal{S}_1, \mathcal{S}_2$ )		cm	Values of the interpolation coordinates along $Y$ axis.
COORD3 <sub>UUUUUU</sub>	R( $\mathcal{S}_1, \mathcal{S}_2$ )		cm	Values of the interpolation coordinates along $Z$ axis.
DETNAM <sub>UUUUUU</sub>	C*12			Alias name of the isotope used as detector.
REANAM <sub>UUUUUU</sub>	C*12			Name of the nuclear reaction used as detector.
RESPON <sub>UUUUUU</sub>	R( $\mathcal{S}_2$ )			The integrated responses of the detectors.

## 10 EXAMPLES

The following examples of input files represent a typical core modeling using DONJON. The main characteristics of a simplified design for the ACR-700 benchmark core model are given below.




Figure 17: Face View of ACR Benchmark Core Model (292 Channels)

- Number of reactor channels 292
- Number of fuel bundles per channel 12
- Core radius 260 cm
- Core length 594.36 cm
- Lattice pitch 22 cm
- Reactor thermal power 1800 MW(th)

## 10.1 (Example1) – Compo related example

Input data for test case: **Example1.x2m**

```

*****
*
* Input file :   Example1.x2m
* Purpose    :   Test for non-regression using DONJON-4
* Author(s)  :   D. Sekki (2007/11)
*
*****
PROCEDURE    assertS Pgeom Pfmap Pburn Pdevc ;
MODULE       DELETE: GREP: END: CRE: MACINI: FLUD: USPLIT:
              DSET: TAVG: FLPOW: TRIVAT: TRIVAA: NEWMAC: ;
LINKED_LIST  GEOM TRACK MATEX FMAP FLUX POWER MACFL
              DEVICE MACRO1 MACRO2 MACRO SYSTEM ;
LINKED_LIST  LREFL1 LREFL2 LFUEL1 LFUEL2
              LZCRin LZCRot LSORin LSORot ;

*--
* variables:
*--
INTEGER      nbMix   := 8 ;
INTEGER      nbRefl  nbFuel := 2 2 ;
INTEGER      mFuel1  mFuel2 := 1 2 ;
INTEGER      mRefl1  mRefl2 := 3 4 ;
INTEGER      mZCRin  mZCRot := 5 6 ;
INTEGER      mSORin  mSORot := 7 8 ;
INTEGER      MaxReg  := 100000 ;
STRING       Method  := "MCFD" ;
INTEGER      degree  quadr := 1 1 ;
INTEGER      iter    iEdit := 0 5 ;
REAL         Power   := 1800. ;
REAL         epsil   := 1.E-5 ;
REAL         Precf   := 1.E-5 ;
REAL         Eps     Keff Bexit ;

*--
* compo files:
*--
SEQ_ASCII    SFUEL1  :: FILE 'CpoFuel1' ;
SEQ_ASCII    SFUEL2  :: FILE 'CpoFuel2' ;
SEQ_ASCII    SREFL1  :: FILE 'CpoMode1' ;
SEQ_ASCII    SREFL2  :: FILE 'CpoMode2' ;
SEQ_ASCII    SZCRin  :: FILE 'CpoZCRin' ;
SEQ_ASCII    SZCRot  :: FILE 'CpoZCRot' ;
SEQ_ASCII    SSORin  :: FILE 'CpoSORin' ;
SEQ_ASCII    SSORot  :: FILE 'CpoSORot' ;

*--
* compo directories:
*--
STRING       NamFuel1 := "FUEL1      1" ;
STRING       NamFuel2 := "FUEL2      1" ;
STRING       NamRefl1 := "MODE1     1" ;
STRING       NamRefl2 := "MODE2     1" ;

```



```

STRING   NamZCRin := "ZCRIN       1" ;
STRING   NamZCRot := "ZCROT       1" ;
STRING   NamSORin := "SORIN       1" ;
STRING   NamSORot := "SOROT       1" ;

*-----
*
*               FULL-CORE  CALCULATION
*               =====
*--
* geometry construction:
*--
GEOM := Pgeom ;
*--
* reactor material index:
*--
GEOM MATEX := USPLIT: GEOM :: EDIT 0 NGRP 2 MAXR <<MaxReg>>
              NREFL <<nbRefl>>  RMIX <<mRefl1>> <<mRefl2>>
              NFUEL <<nbFuel>>  FMIX <<mFuel1>> <<mFuel2>> ;
*--
* numerical discretization:
*--
IF Method "MCFD" = THEN
  TRACK := TRIVAT: GEOM :: EDIT 1
          MAXR <<MaxReg>> MCFD <<degree>> ;
ELSEIF Method "PRIM" = THEN
  TRACK := TRIVAT: GEOM :: EDIT 1
          MAXR <<MaxReg>> PRIM <<degree>> ;
ELSEIF Method "DUAL" = THEN
  TRACK := TRIVAT: GEOM :: EDIT 1
          MAXR <<MaxReg>> DUAL <<degree>> <<quadr>> ;
ENDIF ;
*--
* macrolib for reflector:
*--
LREFL1 := SREFL1 ;
LREFL2 := SREFL2 ;
MACRO1 := CRE: LREFL1 LREFL2 :: EDIT 1 NMIX <<nbMix>> READ
          COMPO LREFL1  MIX <<mRefl1>> <<NamRefl1>> ENDMIX
          COMPO LREFL2  MIX <<mRefl2>> <<NamRefl2>> ENDMIX ;
*--
* device specification:
*--
DEVICE MATEX := Pdevc MATEX ::
          <<mZCRin>> <<mZCRot>> <<mSORin>> <<mSORot>> ;
*--
* full insertion of ZCR-devices:
*--
DEVICE := DSET: DEVICE :: EDIT 1
          ROD-GROUP 1 LEVEL 1.0 END
          ROD-GROUP 2 LEVEL 1.0 END
          ROD-GROUP 3 LEVEL 1.0 END ;
*--
* update macrolib for devices:

```

```

*--
LZCRin := SZCRin ;
LZCRot := SZCRot ;
LSORin := SSORin ;
LSORot := SSORot ;
MACRO1 := CRE: MACRO1 LZCRin LZCRot LSORin LSORot :: EDIT 1
      READ
      COMPO LZCRin  MIX <<mZCRin>> <<NamZCRin>> ENDMIX
      COMPO LZCRot  MIX <<mZCRot>> <<NamZCRot>> ENDMIX
      COMPO LSORin  MIX <<mSORin>> <<NamSORin>> ENDMIX
      COMPO LSORot  MIX <<mSORot>> <<NamSORot>> ENDMIX ;

*--
* fuel-map specification:
*--
FMAP MATEX := Pfmap MATEX ;
*--
* average exit burnups:
*--
FMAP := Pburn FMAP ;
*--
* initialization:
*--
LFUEL1 := SFUEL1 ;
LFUEL2 := SFUEL2 ;
EVALUATE Eps := epsil 1. + ;
*-----
*               TIME-AVERAGE CALCULATION
*-----
WHILE Eps epsil > iter 20 < * DO

      EVALUATE iter := iter 1 + ;
*--
* fuel-map macrolib:
*--
      MACFL := CRE: LFUEL1 LFUEL2 FMAP :: EDIT 0 READ
      TABLE LFUEL1
      MIX <<mFuel1>> <<NamFuel1>> ENDMIX
      TABLE LFUEL2
      MIX <<mFuel2>> <<NamFuel2>> ENDMIX ;
*--
* extended macrolib:
*--
      MACRO2 MATEX := MACINI: MATEX MACRO1 MACFL :: EDIT 0 ;
      MACFL := DELETE: MACFL ;
*--
* complete macrolib:
*--
      MACRO MATEX := NEWMAC: MATEX MACRO2 DEVICE :: EDIT 0 ;
      MACRO2 := DELETE: MACRO2 ;
*--
* numerical solution:
*--
      SYSTEM := TRIVAA: MACRO TRACK :: EDIT 0 ;

```

```

MACRO := DELETE: MACRO ;
IF iter 1 = THEN
    FLUX := FLUD: SYSTEM TRACK :: EDIT 0
        ACCE 3 3 ADI 4 EXTE 1000 <<Precf>>
        THER 1000 ;
ELSE
    FLUX := FLUD: FLUX SYSTEM TRACK :: EDIT 0
        ACCE 3 3 ADI 4 EXTE 1000 <<Precf>>
        THER 1000 ;
ENDIF ;
SYSTEM := DELETE: SYSTEM ;
*--
* flux and power:
*--
POWER := FLPOW: FMAP FLUX TRACK MATEX ::
    EDIT 0 PTOT <<Power>> ;
*--
* burnups integration limits:
*--
FMAP := TAVG: FMAP POWER :: EDIT 0
    AX-SHAPE RELAX 0.5 B-EXIT ;
POWER := DELETE: POWER ;
*--
* current parameters:
*--
GREP: FLUX :: GETVAL 'K-EFFECTIVE' 1 >>Keff<< ;
GREP: FMAP :: GETVAL EPS-AX 1 >>Eps<< ;
ECHO "Iteration No. " iter ;
ECHO "AXIAL-SHAPE ERROR : " Eps ;
ECHO "RESULTING K-EFF : " Keff ;

ENDWHILE ;
*-----
*--
* edit resulting fluxes and powers:
*--
POWER := FLPOW: FMAP FLUX TRACK MATEX ::
    EDIT <<iEdit>> PTOT <<Power>> ;
*--
* last parameters:
*--
GREP: FLUX :: GETVAL 'K-EFFECTIVE' 1 >>Keff<< ;
GREP: FMAP :: GETVAL EPS-AX 1 >>Eps<< ;
GREP: FMAP :: GETVAL B-EXIT 1 >>Bexit<< ;
ECHO "Number of Iterations " iter ;
ECHO "AXIAL-SHAPE ERROR : " Eps ;
ECHO "CORE-AVERAGE EXIT BURNUP : " Bexit ;
ECHO "RESULTING K-EFFECTIVE : " Keff ;
assertS FLUX :: 'K-EFFECTIVE' 1 1.050128 ;
END: ;
QUIT .

```

## 10.2 (Example2) – Multicompo related example

Input data for test case: **Example2.x2m**

```

*****
*
* Input file :   Example2.x2m
* Purpose    :   Test for non-regression using DONJON-4
* Author(s)  :   D. Sekki (2007/11)
*
*****
PROCEDURE    assertS Pgeom Pfmap Pburn Pdevc ;
MODULE       DELETE: GREP: END: NCR: MACINI: FLUD: USPLIT:
              DSET: TAVG: FLPOW: TRIVAT: TRIVAA: NEWMAC: ;
LINKED_LIST  GEOM TRACK MATEX FMAP FLUX POWER MACFL
              DEVICE MACRO1 MACRO2 MACRO SYSTEM LCPO ;

*--
* variables:
*--
INTEGER      nbMix   := 8 ;
INTEGER      nbRefl  nbFuel := 2 2 ;
INTEGER      mFuel1  mFuel2 := 1 2 ;
INTEGER      mRefl1  mRefl2 := 3 4 ;
INTEGER      mZCRin  mZCRot := 5 6 ;
INTEGER      mSORin  mSORot := 7 8 ;
INTEGER      MaxReg   := 100000 ;
STRING       Method   := "MCFD" ;
INTEGER      degree  quadr := 1 1 ;
INTEGER      iter  iEdit := 0 5 ;
REAL         Power    := 1800. ;
REAL         epsil    := 1.E-5 ;
REAL         Precf    := 1.E-5 ;
REAL         Eps      Keff Bexit ;
*--
* multi-compo file:
*--
SEQ_ASCII    SCPO :: FILE 'MultiCompo' ;
*-----
*
*              FULL-CORE  CALCULATION
*              =====
*--
* geometry construction:
*--
GEOM := Pgeom ;
*--
* reactor material index:
*--
GEOM MATEX := USPLIT: GEOM :: EDIT 1 NGRP 2 MAXR <<MaxReg>>
              NREFL <<nbRefl>>  RMIX <<mRefl1>> <<mRefl2>>
              NFUEL <<nbFuel>>  FMIX <<mFuel1>> <<mFuel2>> ;
*--
* numerical discretization:

```

```

*--
IF Method "MCFD" = THEN
  TRACK := TRIVAT: GEOM :: EDIT 1
    MAXR <<MaxReg>> MCFD <<degree>> ;
ELSEIF Method "PRIM" = THEN
  TRACK := TRIVAT: GEOM :: EDIT 1
    MAXR <<MaxReg>> PRIM <<degree>> ;
ELSEIF Method "DUAL" = THEN
  TRACK := TRIVAT: GEOM :: EDIT 1
    MAXR <<MaxReg>> DUAL <<degree>> <<quadr>> ;
ENDIF ;
*--
* macrolib for reflector and devices:
*--
LCPO := SCPO ;
*
MACRO01 := NCR: LCPO :: EDIT 1 MACRO NMIX <<nbMix>>
  COMPO LCPO MODE
  MIX <<mRef1>> SET MTYPE CELL20 ENDMIX
  MIX <<mRef12>> SET MTYPE CELL18 ENDMIX
  COMPO LCPO FUEL
  MIX <<mZCRin>>
    SET FTYPE ZCU SET RDTPOS 1. SET RDDPOS 1.
  ENDMIX
  MIX <<mZCRot>>
    SET FTYPE ZCU SET RDTPOS 1. SET RDDPOS 0.
  ENDMIX
  MIX <<mSORin>>
    SET FTYPE SOR SET RDTPOS 1. SET RDDPOS 1.
  ENDMIX
  MIX <<mSORot>>
    SET FTYPE SOR SET RDTPOS 1. SET RDDPOS 0.
  ENDMIX ;
*--
* device specification:
*--
DEVICE MATEX := Pdevc MATEX ::
  <<mZCRin>> <<mZCRot>> <<mSORin>> <<mSORot>> ;
*--
* full insertion of ZCR-devices:
*--
DEVICE := DSET: DEVICE :: EDIT 1
  ROD-GROUP 1 LEVEL 1.0 END
  ROD-GROUP 2 LEVEL 1.0 END
  ROD-GROUP 3 LEVEL 1.0 END ;
*--
* fuel-map specification:
*--
FMAP MATEX := Pfmap MATEX ;
*--
* average exit burnups:
*--
FMAP := Pburn FMAP ;

```

```

EVALUATE Eps := epsil 1. + ;
*-----
*               TIME-AVERAGE CALCULATION
*-----
WHILE Eps epsil > iter 10 < * DO

    EVALUATE iter := iter 1 + ;
*--
* fuel-map macrolib:
*--
    MACFL := NCR: LCPO FMAP :: EDIT 0 MACRO
            TABLE LCPO FUEL BURN
            MIX <<mFuel1>> SET FTYPE CELL20 ENDMIX
            TABLE LCPO FUEL BURN
            MIX <<mFuel2>> SET FTYPE CELL18 ENDMIX ;
*--
* extended macrolib:
*--
    MACRO2 MATEX := MACINI: MATEX MACRO1 MACFL :: EDIT 0 ;
    MACFL := DELETE: MACFL ;
*--
* complete macrolib:
*--
    MACRO MATEX := NEWMAC: MATEX MACRO2 DEVICE :: EDIT 0 ;
    MACRO2 := DELETE: MACRO2 ;
*--
* numerical solution:
*--
    SYSTEM := TRIVAA: MACRO TRACK :: EDIT 0 ;
    MACRO := DELETE: MACRO ;
    IF iter 1 = THEN
        FLUX := FLUD: SYSTEM TRACK :: EDIT 0
                ACCE 3 3 ADI 4 EXTE 1000 <<Precf>>
                THER 1000 ;
    ELSE
        FLUX := FLUD: FLUX SYSTEM TRACK :: EDIT 0
                ACCE 3 3 ADI 4 EXTE 1000 <<Precf>>
                THER 1000 ;
    ENDIF ;
    SYSTEM := DELETE: SYSTEM ;
*--
* flux and power:
*--
    POWER := FLPOW: FMAP FLUX TRACK MATEX ::
            EDIT 0 PTOT <<Power>> ;
*--
* burnups integration limits:
*--
    FMAP := TAVG: FMAP POWER :: EDIT 0
            AX-SHAPE RELAX 0.5 B-EXIT ;
    POWER := DELETE: POWER ;
*--
* current parameters:

```

```

*--
  GREP: FLUX :: GETVAL 'K-EFFECTIVE' 1 >>Keff<< ;
  GREP: FMAP :: GETVAL EPS-AX 1 >>Eps<< ;
  ECHO "Iteration No. " iter ;
  ECHO "AXIAL-SHAPE ERROR : " Eps ;
  ECHO "RESULTING K-EFF   : " Keff ;

ENDWHILE ;
*-----
*--
* edit resulting fluxes and powers:
*--
POWER := FLPOW: FMAP FLUX TRACK MATEX ::
        EDIT <<iEdit>> PTOT <<Power>> ;
*--
* last parameters:
*--
  GREP: FLUX :: GETVAL 'K-EFFECTIVE' 1 >>Keff<< ;
  GREP: FMAP :: GETVAL EPS-AX 1 >>Eps<< ;
  GREP: FMAP :: GETVAL B-EXIT 1 >>Bexit<< ;
  ECHO "Number of Iterations " iter ;
  ECHO "AXIAL-SHAPE ERROR      : " Eps ;
  ECHO "CORE-AVERAGE EXIT BURNUP : " Bexit ;
  ECHO "RESULTING K-EFFECTIVE    : " Keff ;
  assertS FLUX :: 'K-EFFECTIVE' 1 1.050102 ;
  END: ;
  QUIT .

```

### 10.3 Procedures

#### 10.3.1 Input file for geometry

Input data for test case: **Pgeom.c2m**

```

*****
*
* Procedure : Pgeom.c2m
* Purpose   : Reactor geometry definition
* Author(s) : D. Sekki (2007/06)
*
* CALL      : GEOM := Pgeom ;
*
*****

PARAMETER  GEOM :: :: LINKED_LIST GEOM ; ;
MODULE     END: GEO: ;

      GEOM := GEO: :: CAR3D 24 24 12

```





```

3 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 3 ! J

3 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 3 ! K
3 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 3 ! L
3 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 3 ! M
3 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 3 ! N
0 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 0 ! O
0 3 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 0 ! P
0 0 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 3 3 0 0 ! Q
0 0 0 3 3 1 1 1 1 1 1 1 1 1 1 1 1 3 3 0 0 0 ! R
0 0 0 3 3 3 3 1 1 1 1 1 1 1 1 1 1 3 3 3 0 0 0 ! S
0 0 0 0 0 3 3 3 3 3 3 3 3 3 3 3 3 0 0 0 0 0 0 ! -
0 0 0 0 0 0 3 3 3 3 3 3 3 3 3 3 3 0 0 0 0 0 0 ! -
0 0 0 0 0 0 0 0 3 3 3 3 3 3 3 3 3 0 0 0 0 0 0 ! -

```

```

PLANE 2 SAME 1
PLANE 3 SAME 1
PLANE 4 SAME 1

```

```

PLANE 5

```

```

* - - - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 - - -

0 0 0 0 0 0 0 0 4 4 4 4 4 4 4 4 4 0 0 0 0 0 0 0 0 0 ! -
0 0 0 0 0 0 0 4 4 4 4 4 4 4 4 4 4 4 0 0 0 0 0 0 0 ! -
0 0 0 0 0 0 4 4 4 4 4 4 4 4 4 4 4 4 4 0 0 0 0 0 0 ! -
0 0 0 4 4 4 4 4 2 2 2 2 2 2 2 2 2 2 2 4 4 4 0 0 0 ! A
0 0 0 4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 0 0 ! B
0 0 4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 0 ! C
0 4 4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 0 ! D
0 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 ! E
4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! F
4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! G
4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! H
4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! J

4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! K
4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! L
4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! M
4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 4 ! N
0 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 ! O
0 4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 ! P
0 0 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 0 ! Q
0 0 0 4 4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 0 0 ! R
0 0 0 4 4 4 4 2 2 2 2 2 2 2 2 2 2 2 2 4 4 0 0 0 ! S
0 0 0 0 0 4 4 4 4 4 4 4 4 4 4 4 4 4 0 0 0 0 0 0 ! -
0 0 0 0 0 0 4 4 4 4 4 4 4 4 4 4 4 4 0 0 0 0 0 0 ! -
0 0 0 0 0 0 0 0 4 4 4 4 4 4 4 4 4 4 0 0 0 0 0 0 ! -

```

```

PLANE 6 SAME 5
PLANE 7 SAME 5
PLANE 8 SAME 5

```

```

PLANE  9  SAME 1
PLANE 10  SAME 1
PLANE 11  SAME 1
PLANE 12  SAME 1

MESHX  0.0  20.  40.  62.  84. 106. 128. 150. 172.
        194. 216. 238. 260. 282. 304. 326. 348. 370.
        392. 414. 436. 458. 480. 500. 520.

MESHY  0.0  20.  40.  62.  84. 106. 128. 150. 172.
        194. 216. 238. 260. 282. 304. 326. 348. 370.
        392. 414. 436. 458. 480. 500. 520.

MESHZ  0.0 49.53 99.06 148.59 198.12 247.65 297.18
        346.71 396.24 445.77 495.30 544.83 594.36

SPLITX 2 2 2 2 2 2 2 2 2 2 2 2
        2 2 2 2 2 2 2 2 2 2 2 2

SPLITY 2 2 2 2 2 2 2 2 2 2 2 2
        2 2 2 2 2 2 2 2 2 2 2 2

SPLITZ 2 2 2 2 2 2 2 2 2 2 2 2 ;

END: ;
QUIT .

```

### 10.3.2 Input file for devices

Input data for test case: **Pdevc.c2m**

```

*****
*                                                                 *
* Procedure :  Pdevc.c2m                                         *
* Purpose   :  Reactor rod-devices specification               *
* Author(s) :  D. Sekki (2007/06)                               *
*                                                                 *
* CALL      :  DEVICE MATEX := Pdevc MATEX ::                  *
*            <<mZCRin>> <<mZCRout>> <<mSORin>> <<mSORout>> ;      *
*                                                                 *
*****

PARAMETER  DEVICE MATEX ::
                                ::: LINKED_LIST DEVICE MATEX ; ;
MODULE     END: DEVINI: ;
INTEGER    mZCRin mZCRout mSORin mSORout ;
*--
* Read arguments:
*--
:: >>mZCRin<< >>mZCRout<< >>mSORin<< >>mSORout<< ;

```




Figure 19: Top View of ACR Benchmark Core Model

```
DEVICE MATEX := DEVINI: MATEX :: EDIT 1 NUM-ROD 56 FADE
```

```
*--
```

```
* ZCR:
```

```
*--
```

```
ROD 1
```

```
ROD-NAME ZCR01A
```

```
LEVEL 0.0 AXIS Y FROM H-
```

```
MAXPOS 161.0 183.0 0.0 260.0 123.825 173.355
```

```
DMIX <<mZCRin>> <<mZCRout>>
```

```
ENDROD
```

```
*
```

```
ROD 2
```

```

        ROD-NAME ZCRO1B
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 161.0 183.0  260.0 520.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>
    ENDROD
*
    ROD 3
        ROD-NAME ZCRO2A
        LEVEL 0.0  AXIS Y  FROM H-
        MAXPOS 205.0 227.0  0.0 260.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>
    ENDROD
*
    ROD 4
        ROD-NAME ZCRO2B
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 205.0 227.0  260.0 520.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>
    ENDROD
*
    ROD 5
        ROD-NAME ZCRO3A
        LEVEL 0.0  AXIS Y  FROM H-
        MAXPOS 249.0 271.0  0.0 260.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>
    ENDROD
*
    ROD 6
        ROD-NAME ZCRO3B
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 249.0 271.0  260.0 520.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>
    ENDROD
*
    ROD 7
        ROD-NAME ZCRO4A
        LEVEL 0.0  AXIS Y  FROM H-
        MAXPOS 293.0 315.0  0.0 260.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>
    ENDROD
*
    ROD 8
        ROD-NAME ZCRO4B
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 293.0 315.0  260.0 520.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>
    ENDROD
*
    ROD 9
        ROD-NAME ZCRO5A
        LEVEL 0.0  AXIS Y  FROM H-
        MAXPOS 337.0 359.0  0.0 260.0  123.825 173.355
        DMIX <<mZCRin>> <<mZCRout>>

```

```

ENDROD
*
ROD 10
  ROD-NAME ZCR05B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 337.0 359.0  260.0 520.0  123.825 173.355
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 11
  ROD-NAME ZCR06A
  LEVEL 0.0  AXIS Y  FROM H-
  MAXPOS 161.0 183.0  0.0 260.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 12
  ROD-NAME ZCR06B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 161.0 183.0  260.0 520.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 13
  ROD-NAME ZCR07A
  LEVEL 0.0  AXIS Y  FROM H-
  MAXPOS 205.0 227.0  0.0 260.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 14
  ROD-NAME ZCR07B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 205.0 227.0  260.0 520.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 15
  ROD-NAME ZCR08A
  LEVEL 0.0  AXIS Y  FROM H-
  MAXPOS 249.0 271.0  0.0 260.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 16
  ROD-NAME ZCR08B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 249.0 271.0  260.0 520.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 17
  ROD-NAME ZCR09A

```

```

        LEVEL 0.0  AXIS Y  FROM H-
        MAXPOS 293.0 315.0  0.0 260.0  272.415 321.945
        DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 18
  ROD-NAME ZCR09B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 293.0 315.0  260.0 520.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 19
  ROD-NAME ZCR10A
  LEVEL 0.0  AXIS Y  FROM H-
  MAXPOS 337.0 359.0  0.0 260.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 20
  ROD-NAME ZCR10B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 337.0 359.0  260.0 520.0  272.415 321.945
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 21
  ROD-NAME ZCR11A
  LEVEL 0.0  AXIS Y  FROM H-
  MAXPOS 161.0 183.0  0.0 260.0  421.005 470.535
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 22
  ROD-NAME ZCR11B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 161.0 183.0  260.0 520.0  421.005 470.535
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 23
  ROD-NAME ZCR12A
  LEVEL 0.0  AXIS Y  FROM H-
  MAXPOS 205.0 227.0  0.0 260.0  421.005 470.535
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD
*
ROD 24
  ROD-NAME ZCR12B
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 205.0 227.0  260.0 520.0  421.005 470.535
  DMIX <<mZCRin>> <<mZCRout>>
ENDROD

```

```

*
  ROD 25
    ROD-NAME ZCR13A
    LEVEL 0.0  AXIS Y  FROM H-
    MAXPOS 249.0 271.0  0.0 260.0  421.005 470.535
    DMIX <<mZCRin>> <<mZCRout>>
  ENDROD
*
  ROD 26
    ROD-NAME ZCR13B
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 249.0 271.0  260.0 520.0  421.005 470.535
    DMIX <<mZCRin>> <<mZCRout>>
  ENDROD
*
  ROD 27
    ROD-NAME ZCR14A
    LEVEL 0.0  AXIS Y  FROM H-
    MAXPOS 293.0 315.0  0.0 260.0  421.005 470.535
    DMIX <<mZCRin>> <<mZCRout>>
  ENDROD
*
  ROD 28
    ROD-NAME ZCR14B
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 293.0 315.0  260.0 520.0  421.005 470.535
    DMIX <<mZCRin>> <<mZCRout>>
  ENDROD
*
  ROD 29
    ROD-NAME ZCR15A
    LEVEL 0.0  AXIS Y  FROM H-
    MAXPOS 337.0 359.0  0.0 260.0  421.005 470.535
    DMIX <<mZCRin>> <<mZCRout>>
  ENDROD
*
  ROD 30
    ROD-NAME ZCR15B
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 337.0 359.0  260.0 520.0  421.005 470.535
    DMIX <<mZCRin>> <<mZCRout>>
  ENDROD

*--
* SOR:
*--
  ROD 31
    ROD-NAME SOR01
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 117.0 139.0  53.75 466.25  49.53 99.06
    DMIX <<mSORin>> <<mSORout>>
  ENDROD
*
```

```

ROD 32
  ROD-NAME SOR02
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 183.0 205.0  24.5 495.5  49.53 99.06
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 33
  ROD-NAME SOR03
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 227.0 249.0  24.5 495.5  49.53 99.06
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 34
  ROD-NAME SOR04
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 271.0 293.0  24.5 495.5  49.53 99.06
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 35
  ROD-NAME SOR05
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 315.0 337.0  24.5 495.5  49.53 99.06
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 36
  ROD-NAME SOR06
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 381.0 403.0  53.75 466.25  49.53 99.06
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 37
  ROD-NAME SOR07
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 117.0 139.0  53.75 466.25  123.825 173.355
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 38
  ROD-NAME SOR08
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 381.0 403.0  53.75 466.25  123.825 173.355
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 39
  ROD-NAME SOR09
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 117.0 139.0  53.75 466.25  222.885 272.415

```



```

        DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 40
    ROD-NAME SOR10
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 227.0 249.0  24.5 495.5  198.12 247.65
    DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 41
    ROD-NAME SOR11
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 271.0 293.0  24.5 495.5  198.12 247.65
    DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 42
    ROD-NAME SOR12
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 381.0 403.0  53.75 466.25  222.885 272.415
    DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 43
    ROD-NAME SOR13
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 117.0 139.0  53.75 466.25  272.415 321.945
    DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 44
    ROD-NAME SOR14
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 381.0 403.0  53.75 466.25  272.415 321.945
    DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 45
    ROD-NAME SOR15
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 117.0 139.0  53.75 466.25  321.945 371.475
    DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 46
    ROD-NAME SOR16
    LEVEL 0.0  AXIS Y  FROM H+
    MAXPOS 227.0 249.0  24.5 495.5  346.71 396.24
    DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 47

```

```

        ROD-NAME SOR17
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 271.0 293.0  24.5 495.5  346.71 396.24
        DMIX <<mSORin>> <<mSORout>>
    ENDROD
*
    ROD 48
        ROD-NAME SOR18
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 381.0 403.0  53.75 466.25  321.945 371.475
        DMIX <<mSORin>> <<mSORout>>
    ENDROD
*
    ROD 49
        ROD-NAME SOR19
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 117.0 139.0  53.75 466.25  421.005 470.535
        DMIX <<mSORin>> <<mSORout>>
    ENDROD
*
    ROD 50
        ROD-NAME SOR20
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 381.0 403.0  53.75 466.25  421.005 470.535
        DMIX <<mSORin>> <<mSORout>>
    ENDROD
*
    ROD 51
        ROD-NAME SOR21
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 117.0 139.0  53.75 466.25  495.3 544.83
        DMIX <<mSORin>> <<mSORout>>
    ENDROD
*
    ROD 52
        ROD-NAME SOR22
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 183.0 205.0  24.5 495.5  495.3 544.83
        DMIX <<mSORin>> <<mSORout>>
    ENDROD
*
    ROD 53
        ROD-NAME SOR23
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 227.0 249.0  24.5 495.5  495.3 544.83
        DMIX <<mSORin>> <<mSORout>>
    ENDROD
*
    ROD 54
        ROD-NAME SOR24
        LEVEL 0.0  AXIS Y  FROM H+
        MAXPOS 271.0 293.0  24.5 495.5  495.3 544.83
        DMIX <<mSORin>> <<mSORout>>

```

```

ENDROD
*
ROD 55
  ROD-NAME SOR25
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 315.0 337.0  24.5 495.5  495.3 544.83
  DMIX <<mSORin>> <<mSORout>>
ENDROD
*
ROD 56
  ROD-NAME SOR26
  LEVEL 0.0  AXIS Y  FROM H+
  MAXPOS 381.0 403.0  53.75 466.25  495.3 544.83
  DMIX <<mSORin>> <<mSORout>>
ENDROD

*--
* create rod-devices groups:
*--
  CREATE ROD-GR 5

  GROUP-ID 1
  ROD-ID 1 2 15 16 19 20 23 24 27 28

  GROUP-ID 2
  ROD-ID 3 4 7 8 9 10 13 14

  GROUP-ID 3
  ROD-ID 5 6 11 12 17 18 21 22 25 26 29 30

  GROUP-ID 4
  ROD-ID 31 36 37 38 39 42 43 44 45 48 49 50 51 52 53 54 55

  GROUP-ID 5
  ROD-ID 32 33 34 35 40 41 46 47 53 56 ;

END: ;
QUIT .

```

### 10.3.3 Input file for fuel map

Input data for test case: **Pfmap.c2m**

```

*****
*
* Procedure :  Pfmap.c2m
* Purpose   :  Reactor fuel-map specification
* Author(s) :  D. Sekki (2007/11)
*
* CALL      :  FMAP MATEX := Pfmap MATEX ;
*
*****

```

```
*****
PARAMETER  FMAP MATEX :: :: LINKED_LIST FMAP MATEX ; ;
MODULE     END: RESINI ;
```

```
FMAP MATEX := RESINI: MATEX :: EDIT 0
```

```

::: GEO: CAR3D 20 20 12

```

```

EDIT 0
X- VOID  X+ VOID
Y- VOID  Y+ VOID
Z- VOID  Z+ VOID

```

MIX

PLANE 1

[illegible]

PLANE 2	SAME 1
PLANE 3	SAME 1
PLANE 4	SAME 1

PLANE 5

[illegible]

```

0 0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 0 ! D
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! E
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! F
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! G
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! H
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! J

```

```

0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! K
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! L
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! M
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! N
0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! O
0 0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! P
0 0 2 2 2 2 2 2 2 2 2 2 2 2 2 2 0 ! Q
0 0 0 2 2 2 2 2 2 2 2 2 2 2 2 0 0 ! R
0 0 0 0 0 2 2 2 2 2 2 2 2 2 0 0 0 ! S
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 ! -

```

```

PLANE 6 SAME 5
PLANE 7 SAME 5
PLANE 8 SAME 5

```

```

PLANE 9 SAME 1
PLANE 10 SAME 1
PLANE 11 SAME 1
PLANE 12 SAME 1

```

```

MESHX 0.0 62. 84. 106. 128. 150. 172.
194. 216. 238. 260. 282. 304. 326.
348. 370. 392. 414. 436. 458. 520.

```

```

MESHY 0.0 62. 84. 106. 128. 150. 172.
194. 216. 238. 260. 282. 304. 326.
348. 370. 392. 414. 436. 458. 520.

```

```

MESHZ 0.0 49.53 99.06 148.59 198.12 247.65
297.18 346.71 396.24 445.77 495.30 544.83 594.36

```

```

;
```

```

NXNAME '- '1' '2' '3' '4' '5' '6' '7' '8' '9' '10'
'11' '12' '13' '14' '15' '16' '17' '18' '- '

```

```

NYNAME '- 'A' 'B' 'C' 'D' 'E' 'F' 'G' 'H' 'J'
'K' 'L' 'M' 'N' 'O' 'P' 'Q' 'R' 'S' '- '

```

```

NCOMB 73 B-ZONE

```

```

1 2 3 4 5 5 4 3 2 1 6 7 8 9
10 11 12 12 11 10 9 8 7 6 13 14 15 16
17 18 19 20 20 19 18 17 16 15 14 13 21 22
23 24 25 26 27 28 28 27 26 25 24 23 22 21
29 30 31 32 33 34 35 36 37 37 36 35 34 33
32 31 30 29 38 39 40 41 42 43 44 45 46 46

```

```

45 44 43 42 41 40 39 38 47 48 49 50 51 52
53 54 55 55 54 53 52 51 50 49 48 47 56 57
58 59 60 61 62 63 64 64 63 62 61 60 59 58
57 56 65 66 67 68 69 70 71 72 73 73 72 71
70 69 68 67 66 65 65 66 67 68 69 70 71 72
73 73 72 71 70 69 68 67 66 65 56 57 58 59
60 61 62 63 64 64 63 62 61 60 59 58 57 56
47 48 49 50 51 52 53 54 55 55 54 53 52 51
50 49 48 47 38 39 40 41 42 43 44 45 46 46
45 44 43 42 41 40 39 38 29 30 31 32 33 34
35 36 37 37 36 35 34 33 32 31 30 29 21 22
23 24 25 26 27 28 28 27 26 25 24 23 22 21
13 14 15 16 17 18 19 20 20 19 18 17 16 15
14 13 6 7 8 9 10 11 12 12 11 10 9 8
7 6 1 2 3 4 5 5 4 3 2 1

```

;

END: ;

QUIT .

#### 10.3.4 Input file for exit burnups

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A					1	2	3	4	5	5	4	3	2	1				
B			6	7	8	9	10	11	12	12	11	10	9	8	7	6		
C		13	14	15	16	17	18	19	20	20	19	18	17	16	15	14	13	
D		21	22	23	24	25	26	27	28	28	27	26	25	24	23	22	21	
E	29	30	31	32	33	34	35	36	37	37	36	35	34	33	32	31	30	29
F	38	39	40	41	42	43	44	45	46	46	45	44	43	42	41	40	39	38
G	47	48	49	50	51	52	53	54	55	55	54	53	52	51	50	49	48	47
H	56	57	58	59	60	61	62	63	64	64	63	62	61	60	59	58	57	56
J	65	66	67	68	69	70	71	72	73	73	72	71	70	69	68	67	66	65
K	65	66	67	68	69	70	71	72	73	73	72	71	70	69	68	67	66	65
L	56	57	58	59	60	61	62	63	64	64	63	62	61	60	59	58	57	56
M	47	48	49	50	51	52	53	54	55	55	54	53	52	51	50	49	48	47
N	38	39	40	41	42	43	44	45	46	46	45	44	43	42	41	40	39	38
O	29	30	31	32	33	34	35	36	37	37	36	35	34	33	32	31	30	29
P		21	22	23	24	25	26	27	28	28	27	26	25	24	23	22	21	
Q		13	14	15	16	17	18	19	20	20	19	18	17	16	15	14	13	
R			6	7	8	9	10	11	12	12	11	10	9	8	7	6		
S					1	2	3	4	5	5	4	3	2	1				

Figure 20: Combustion zones definition

Input data for test case: **Pburn.c2m**

```

*****
*
* Procedure :   Pburn.c2m
* Purpose   :   Provide average exit burnups
* Author(s) :   D. Sekki (2007/11)
*
* CALL      :   FMAP := Pburn FMAP ;
*
*****
PARAMETER FMAP :: :: LINKED_LIST FMAP ; ;
MODULE     END: RESINI: ;

      FMAP := RESINI: FMAP :: EDIT 2  REF-SHIFT 8

      BTYPE TIMAV-BURN
      TIMAV-BVAL

*A
  1008.98  1057.69  1071.61  1095.41  1137.92

*B
  1365.60  1586.43  1643.79  1656.34  1756.62
  2014.25  2364.85

*C
  1806.72  2019.33  2425.27  2556.62  2822.28
  3250.93  3391.85  3761.47

*D
  2279.49  2267.03  2563.72  2898.28  3261.49
  3409.15  3715.98  4136.73

*E
  2258.14  2345.30  3173.47  3111.80  3212.21
  3456.56  3705.48  3801.69  3953.67

*F
  2678.92  3263.24  3614.41  3764.97  3813.93
  3857.62  3925.74  4046.12  4119.31

*G
  2792.21  3087.13  3705.48  3960.65  4030.43
  4025.20  3978.10  3990.31  4037.40

*H
  1693.96  2811.67  3666.96  4115.83  4241.15
  4134.99  4025.20  3910.02  3915.26

*J
  2268.81  3065.97  3826.17  4232.46  4380.19
  4121.05  3995.54  3889.07  3890.81
;

```

END: ;  
QUIT .



## References

- [1] A. Hébert, Applied Reactor Physics, Second Edition, Presses Internationales Polytechnique, ISBN 978-2-553-01698-1, 396 p., Montréal, 2016.
- [2] A. Hébert, "Development Procedures for Version4 of Reactor Physics Codes," Report IGE-287, École Polytechnique de Montréal, Institut de Génie Nucléaire (2006).
- [3] A. Hébert and R. Roy, "The GAN Generalized Driver," École Polytechnique de Montréal, Institut de Génie Nucléaire (2000).
- [4] A. Hébert and R. Roy, "The Ganlib5 kernel guide (64-bit clean version)," Report IGE-332, École Polytechnique de Montréal, January 2013.
- [5] G. Marleau, A. Hébert and R. Roy, "A User Guide for DRAGON Version5," Report IGE-335, École Polytechnique de Montréal, Institut de Génie Nucléaire (2014).
- [6] A. Hébert, "A User Guide for TRIVAC Version4," Report IGE-293, École Polytechnique de Montréal, Institut de Génie Nucléaire (2007).
- [7] A. Hébert, "TRIVAC, A Modular Diffusion Code for Fuel Management and Design Applications," *Nucl. J. of Canada*, Vol. 1, No. 4, 325 (1987).
- [8] A. Hébert, "Application of the Hermite Method for Finite Element Reactor Calculations," *Nucl. Sci. Eng.*, **91**, 34 (1985).
- [9] A. Hébert, "Variational Principles and Convergence Acceleration Strategies for the Neutron Diffusion Equation," *Nucl. Sci. Eng.*, **91**, 414 (1985).
- [10] A. Hébert, "Preconditioning the Power Method for Reactor Calculations," *Nucl. Sci. Eng.*, **94**, 1 (1986).
- [11] A. Hébert, "Development of the Nodal Collocation Method for Solving the Neutron Diffusion Equation," *Ann. Nucl. Energy*, **14**, 527 (1987).
- [12] A. Hébert, "Application of a Dual Variational Formulation to Finite Element Reactor Calculations," *Ann. nucl. Energy*, **20**, 823 (1993).
- [13] E. Varin, A. Hébert, J. Koclas and R. Roy, "A User Guide for DONJON," Report IGE-208, , École Polytechnique de Montréal, Institut de Génie Nucléaire (2005).
- [14] E. Varin, A. Hébert, "Data Structures for DONJON," Report IGE-226, École Polytechnique de Montréal, Institut de Génie Nucléaire (2003).
- [15] D. Rozon, "Gestion du combustible nucléaire. Notes de cours Ene6109," Report IGE-298, École Polytechnique de Montréal, Institut de Génie Nucléaire (2007).
- [16] R. Chambon, *Optimisation de la gestion du combustible dans les réacteurs CANDU refroidis à l'eau légère*, Ph. D. Thesis, École Polytechnique de Montréal (2006).
- [17] A. Hébert, *Revisiting the Ceschino Interpolation Method*, in *MATLAB – A Ubiquitous Tool for the Practical Engineer*, Clara M. Ionescu (Ed.), InTech Open Access Publisher, ISBN 978-953-307-907-3, Croatia, 2011.
- [18] A. Hébert, G. Marleau and R. Roy, "A description of the DRAGON Data Structures," Report IGE-295, École Polytechnique de Montréal, Institut de Génie Nucléaire (2007).
- [19] E. Varin and G. Marleau, "CANDU reactor core simulations using fully coupled DRAGON and DONJON calculations," *Ann. Nucl. Energy*, **33**, 682 (2006).

- [20] J. Tajmouati, “Optimisation de la gestion du combustible enrichi d’un réacteur CANDU avec prise en compte des paramètres locaux,” Ph. D. thesis, École Polytechnique de Montréal (1993).
- [21] M. T. Sissaoui, G. Marleau and D. Rozon, “CANDU Reactor Simulations Using the Feedback Model with Actinide Burnup History,” *Nucl. Technology*, **125**, 197 (1999).
- [22] R. Roy, “The CLE-2000 Tool-box,” Report IGE-163, École Polytechnique de Montréal, Institut de Génie Nucléaire (1999).
- [23] A. Hébert and R. Roy, “A Programmer’s Guide for the GAN Generalized Driver – FORTRAN-77 version,” Report IGE-158, École Polytechnique de Montréal, Institut de Génie Nucléaire (1994).
- [24] “Argonne Code Center: Benchmark Problem Book,” ANL-7416, Supp. 2, ID11-A2, Argonne National Laboratory (1977).
- [25] S. Loubière, R. Sanchez, M. Coste, **A. Hébert**, Z. Stankovski, C. Van Der Gucht and I. Zmi-jarevic, “APOLLO2, Twelve Years Later,” paper presented at the *Int. Conf. on Mathematics and Computation, Reactor Physics and Environmental Analysis in Nuclear Applications*, Madrid, Spain, September 27–30, 1999.
- [26] A. Janet, “APOLLO2-A User’s Manual Version 1.26.0,” Report D02-DTIPD-F-17-0503, CONV17\_0026, Framatome (2018).
- [27] J. Griffiths, *WIMS-AECL Users Manual*, Report RC-1176, Atomic Energy of Canada Limited, Chalk River, Ontario (1994).
- [28] J.V. Donnelly, *Post-Processing WIMS-AECL Results with Proc16*, Report FCC-RCP-001, Atomic Energy of Canada Limited, Chalk River, Ontario (1997).
- [29] J.V. Donnelly, *Wrfsp: Post-Processing Data from WIMS-AECL to RFSP*, Report FCC-RCP-006, Atomic Energy of Canada Limited, Chalk River, Ontario (1997).
- [30] See the home page at <http://freesteam.sourceforge.net/>.
- [31] D. Rozon, A. Hébert and D. McNabb, “The application of generalized perturbation theory and mathematical programming to equilibrium refueling studies of a CANDU reactor,” *Nucl.Sci. Eng.*, **78**, 211 (1981).
- [32] R. Chambon, E. Varin and D. Rozon, “CANDU fuel management optimization using alternative gradient methods,” *Ann. Nucl. Energy*, **34**, 1002 (2007).
- [33] A. Hébert and H. Leroyer, “A Presentation of the OPTEX Reflector Model,” *Nucl. Sci. Eng.*, **176**, 312–324 (2014).
- [34] W. H. Press, B. P. Flannery, S. A. Teukolsky and W. T. Vetterling, *Numerical Recipes in FORTRAN, Second Edition*, Cambridge University Press, Cambridge (1992).
- [35] L. Armijo, “Minimization of functions having Lipschitz continuous first partial derivatives,” *Pacific journal of mathematics*, Vol. 16, **1**, 1–3, 1966.
- [36] J. Nocedal, “Updating Quasi-Newton Matrices With Limited Storage,” *Math. of Computation*, Vol. 35, **151**, 773–782 (1980).
- [37] A. Hébert, “Développement de la méthode SPH: Homogénéisation de cellules dans un réseau non uniforme et calcul des paramètres de réflecteur,” Ph. D. thesis, CEA-N-2209 (1981).
- [38] A. Hébert, “A general presentation of the SPH equivalence technique in non-fundamental mode cases,” Submitted to *Annals of Nucl. Energy* (2019).

- [39] V. Labouré, Y. Wang, J. Ortensi, S. Schunert, F. Gleicher, M. DeHart and R. Martineau, “Hybrid super homogenization and discontinuity factor method for continuous finite element diffusion,” *Ann. nucl. Energy*, **128**, 443–454 (2019).
- [40] A. Hébert, “Application of a Dual Variational Formulation to Finite Element Reactor Calculations”, *Ann. nucl. Energy*, **20**, 823 - 845 (1993).
- [41] A. Hébert, “Mixed-dual implementations of the of the simplified  $P_n$  method,” *Ann. nucl. Energy*, **37**, 498–511 (2010).
- [42] J. A. Ferland, “A linear programming problem with an additional quadratic constraint solved by parametric linear complementarity,” Publication number 497, Département d’informatique et de recherche opérationnelle, Université de Montréal, January 1984.
- [43] M. F. Fehri, “Développement d’un code de thermohydraulique pour le couplage neutro-nique/thermohydraulique,” M. Sc. A. Thesis, École Polytechnique de Montréal (2008).
- [44] P. Gallet, “Développement d’un module de thermohydraulique simplifiée dans le code DONJON4 pour l’étude multiphysique des réacteurs à eau pressurisée,” Ph. D. Thesis, École Polytechnique de Montréal (2014).
- [45] R. W. Bowring, “Physical Model, Based on Bubble Detachment, and Calculation of Steam Voidage in the Subcooled Region of a Heated Channel,” OECD Report HPR-10, 1962.
- [46] P. Saha and N. Zuber, “Point Of Net Vapor Generation and Vapor Void Fraction in Subcooled Boiling,” *Int. heat transfer conference*, Tokyo, Japan, 3 Sep 1974.
- [47] R. T. Lahey and F. J. Moody, *The Thermal-Hydraulics of a Boiling Water Nuclear Reactor*, American Nuclear Society Publications, U.S.A. (1977).
- [48] R. Chambon, “Specifications and User Guide for NAP: module in DRAGON/DONJON VERSION5 (Pin Power Reconstruction module),” Report IGE-345, École Polytechnique de Montréal, Institut de Génie Nucléaire (2014).
- [49] M. Fliscounakis, E. Girardi and T. Courau, “A Generalized Pin-Power Reconstruction Method for Arbitrary Heterogeneous Geometries,” M&C 2011, Rio de Janeiro, Brasil, May 8–12 2011.
- [50] G. Rowlands, “Resonance Absorption and Non-Uniform Temperature Distributions,” *Journal of Nuclear Energy Parts A/B*, 16, pp 235-236 (1962).
- [51] T. Downar, Y. Xu and V. Seker, “PARCS v3.0, U.S. NRC Core Neutronics Simulator, User Manual,” Department of Nuclear Engineering and Radiological Science, University of Michigan, Ann Arbor, MI (2012).
- [52] A. Ward, Y. Xu and T. Downar, “GenPMAXS-v6.1.1, Code for Generating the PARCS Cross Section Interface File PMAXS,” University of Michigan, 2013.

## Index

- 'FD-B', 122
- 'FD-C', 122
- $\epsilon_{ext}$ , 151, 152, 155, 158, 159
- $\epsilon_{inn}$ , 151, 152, 155
- $\epsilon_{quad}$ , 151, 152
- $l_{convE}$ , 155
- $l_{convI}$ , 155, 156
- $l_{conv}$ , 151, 153, 158, 159
- 'BUND-PW', 38
- 'C', 119
- 'FLUE', 120, 199
- 'FLUX-AV', 38
- 'I135PF', 120
- 'K', 119
- 'ND147PF', 120
- 'PM147PF', 120
- 'PM148MPF', 121
- 'PM148PF', 120
- 'PM149PF', 120
- 'SM149PF', 120
- 'TIME', 120, 199
- 'XE135PF', 120
- 'default', 119
- (, 207, 211
- (descphase1), 117, 118
- (compo(i), i=1, ncompo), 118
- (emin(g), g=1, ngroup), 119
- (hadf(i), i=1, nadf), 118
- (hcdf(i), i=1, ncdf), 118
- (pkey(i), nval(i), i=1, npkey), 118
- (pkey(i), nval(i), (val(j), j=1, nval(i)), i=1, npkey), 118
- (refnam(i), val(i), i=1, npkey) ENDMAN, 118
- \*, 119, 126
- \*, 71, 72, 74, 75, 77, 85, 86, 88, 95, 96, 98
- , 48, 66
- .DRA, 199
- .dra, 114
- .inp, 114
- .res, 39
- //OLD-VALUE//, 196
- ::, 8, 16, 18, 19, 23, 26, 30, 32, 34, 36, 37, 40, 43, 46, 50, 52, 54, 57, 64, 67, 69, 73, 84, 94, 100, 105, 110, 117, 127, 134, 137, 139, 141, 147, 149, 151, 154, 158, 160
- :::, 9
- ::=, 8, 16, 18, 19, 23, 26, 30, 32, 34, 36, 37, 40, 43, 46, 50, 52, 54, 57, 64, 67, 69, 73, 84, 94, 100, 105, 110, 127, 134, 137, 139, 141, 147, 149, 151, 154, 158, 160
- : =D2P:, 117, 118
- ;, 6, 7, 32, 52, 65, 110
- BURNUP, 57, 58
- HISTORY, 57, 58
- MAP, 57, 58
- D2P:, 117
- descphase1, 118, 119
- 3-D, 1, 3, 4, 8, 10, 11, 13, 14, 16, 17, 19, 20, 26, 166
- 3D, 169, 175, 177-180
- 1, 117
- 2, 117
- 3, 117
- DETECT:, 52
- INIDET:, 23
- A-IBX, 9, 10
- A-NX, 9, 10
- A-ZONE, 9, 10
- (ACR:), 94, 96
- ACR:, 94
- (ACRdescints), 95, 96
- ACRdescints, 95, 96
- ADD, 32, 33, 75-77, 86, 87, 89, 96-98, 102, 103, 118, 121
- ADD-PARAM, 12, 14
- ADF, 118, 121
- AFM:, 4, 12, 13, 18, 39, 41, 45, 105
- aicg, 118, 120
- aicn, 118, 120
- ALBEDO, 141, 142
- ALL, 9, 12, 22, 29, 38, 39, 44, 45, 71, 72, 75, 76, 86, 87, 96, 98, 149
- ALLX, 73, 74
- ALPHA, 134, 135
- and/or, 37
- APEX, 95
- APXNAM, 95, 96
- APXNAM1, 94
- APXNAM2, 94
- AREFL, 57, 58, 63
- ASBLY, 9, 10, 12, 13, 16, 17
- asmb1, 47, 48
- asmb2, 47, 48
- ASSEMBLY, 9, 10
- ASSMB, 128, 129
- AT, 47, 48
- AUG-LAGRANG, 151, 152
- avburn, 47, 48
- AVG-EX-BURN, 71, 75, 86, 96, 97, 102
- AVGB, 47, 48

AX-SHAPE, 40, 41, 60  
 AXIAL-PFORM, 12, 14  
 AXIS, 21, 27, 28  
*axn*, 47, 48  
 AXNAME, 9, 10  
 AYNAME, 9, 10  
  
 B-EXIT, 40, 41  
 B-ZONE, 9, 11  
*b2*, 73, 74, 84, 85, 95, 100, 101  
 BARR, 118–121, 200  
*beta*, 134  
 BETAI, 134, 135  
*betai*, 135  
 BFAC, 119, 125  
*bfac*, 119, 125  
 BFGS, 155  
 BLIN, 106, 108  
 BORON, 106, 107  
 BOWR, 128, 132  
 /BRANCH\_INFO/, 202  
 BRANCHES information (optional), 115  
 BREFL, 57, 58, 63  
 (*brnpar*), 58  
 BTYPE, 12, 13  
 BUNBLES, 59  
 BUND, 12, 13, 15, 38, 39  
 BUNDLE-POW, 12–14  
 BUNDLES, 58  
*bunl*, 58, 59  
 BURN, 47, 49, 59, 106, 107, 119, 121, 200  
*burn*, 71, 72  
 BURN-STEP, 44, 47, 48  
*burn0*, 71, 72  
*burn1*, 71, 72  
*burncycle*, 47  
*burncycle1*, 47  
*burncycle2*, 47  
 BURNUP, 57, 58, 60–62  
*burnup*, 44, 45  
 BURNUP information (optional), 115  
 BURNUP-BEG, 60  
*bval*, 106, 107  
*bval1*, 134, 136  
*bval2*, 134, 136  
*bvalue*, 12, 13  
 ByPass, 201  
*bypass*, 123  
  
 CALCUL-DX, 151, 153  
 CBOR, 119, 121, 200  
 CD, 112  
 CDF, 118, 122  
 CELL, 13, 15  
 CELLAV, 111–113  
 {/CELLDIR/}, 185  
 /celldir/, 62  
 CELLID, 60  
 CELLID, 57, 58, 62  
 CELSIUS, 131  
 CFC:, 105  
*cflux*, 128, 129  
 CG, 155  
 CHAIN, 88, 98, 103  
 CHAN, 12, 13, 15, 44, 45, 128, 130  
 CHAN-VOID, 54, 56  
 CHANNEL, 192  
 CHANNELS, 58, 59  
 CHECKER, 54, 55  
 CHECKER-1/2, 54, 55  
 CHECKER-1/4, 54, 55  
 Chi, inV/YLD/Bet/Lam/, 116  
 CLUSTER, 128, 129  
 COMB, 12, 14  
 COMMENT, 119, 124  
*comment*, 119, 124  
 COMPARE, 47, 49  
 COMPO, 8–10, 160, 161, 164  
 COMPO, 70, 73, 74  
 COMPO, 5, 23, 69, 70, 72  
*compo*, 120  
 COMPO:, 5, 74  
*conc*, 71, 72, 75–77, 86–88, 96, 98, 102, 103  
 CONDC, 128, 131  
 CONDF, 128, 130  
 CONDG, 111  
*control*, 149, 150  
 CONV, 128, 132  
 COR, 118, 123  
 COST-EXTRAP, 151, 153  
 CP, 112  
 CPO, 69–71  
 CPO, 110–113  
 CPO:, 5  
 CPONAM, 73–75  
 CPONAM1, 73  
 CPONAM2, 73  
 CRE:, 4, 5, 12, 13, 18, 41, 45, 69, 70  
 CREATE, 19, 20, 27  
 CRITFL, 128, 129  
 CROSS\_SECT, 203  
 /CROSS\_SECT/, 203  
 CST-OBJ, 149, 150  
 CST-QUAD-EPS, 151, 152  
 CST-TYPE, 149, 150  
 CST-WEIGHT, 149–151  
*cstval*, 149, 150

*cstw*, 149, 150  
 CT, 112  
 CUBIC, 73–76, 84–87, 95–97, 100–103, 134, 135  
 CVR:, 4, 54, 55  
 CWSECT, 128, 129  
 CYCLE, 47  
  
 D20, 127, 128  
 D2P.PMAX, 124  
 D2P:, 114, 117, 118, 124, 197  
 /d2p\_info/, 197, 199  
 DATABASE, 105  
 DAY, 44, 47, 48  
 DBASE, 105  
*dcool*, 106, 107  
*dcoolV*, 54, 55  
*dcr*, 103, 104  
 DECAY, 88, 89, 98, 99, 103, 104  
 DEF, 118, 121, 200  
 DEFAULT, 23, 24  
 DELETE:, 3  
 DELH, 34, 35  
*delh*, 34, 35  
 DELT, 34, 35  
*delt*, 34, 35  
 DELTA, 75–77, 86, 87, 89, 96, 97, 102, 139, 140  
 DENS-COOL, 54, 55  
*der*, 119, 124  
 DERIV, 71, 134, 135  
 DERIVATIVE, 119, 124  
 (descfm), 105, 106  
 (descrcr1), 18, 69, 70  
 (descrcr2), 18, 69, 70  
 (descdata1), 70, 71  
 (descdata2), 70, 71  
 (descdepl), 84, 86, 88, 95, 96, 98, 100, 101, 103  
 (descdet), 23, 24  
 (descdetect), 52  
 (descdev), 19, 23  
 (descdset), 30  
 (descflpow), 37, 38  
 (descgeo), 9, 10  
 (descidet), 67  
 (descinidet), 23  
 (descintf), 73, 75, 100–102  
*descintf*, 74, 75, 101  
 (descints), 84, 86  
*descints*, 85, 86  
 (desclink), 16  
 (desclzc), 26, 27  
 (descmcc1), 32  
 (descmove), 34  
 (descnap1), 160, 161  
 (descnap2), 160–162  
 (descnap3), 9, 10, 160, 161, 163  
 (descpkini), 134  
 (descpkins), 137  
 (descrcvr), 54  
 (descresini1), 8, 9  
 (descresini2), 8, 9, 12, 13  
 (descrod1), 64, 65  
 (descsim), 46, 47  
 (desct16cpo), 110, 111, 113  
 (desctavg), 40  
 (descthm), 127, 128  
 (desctinst), 43, 44  
 (descxenon), 50, 51  
 DET, 118, 122  
 DETEC, 52  
 DETECT, 23  
 /detect/, 181  
 DETECT, 5, 23, 52, 53  
 DETECT:, 4, 5, 37, 39, 52, 53, 181  
 DETECTOR, 67  
 DETINI:, 4, 5, 23, 181  
 DETNAME, 67, 68  
 DEV-LZC, 179, 180  
 (dev-lzc), 27  
 DEV-ROD, 178, 179  
 (dev-rod), 19–21  
 DEVICE, 19, 26, 30, 34, 36  
 /device/, 177, 178  
 DEVICE, 5, 19, 26, 30, 34, 36  
 DEVINI:, 4, 5, 19, 26, 31, 35, 177  
 DFLUX, 149  
 DIFF, 139, 140  
 DIMENSIONS, 58  
 DIRECT, 134, 135  
 DIRGEO, 163  
 DIST-AX, 47, 48  
 DIST-BURN, 47, 49  
 DIST-POWR, 47, 49  
 DISTR, 38, 39  
 /DIVERS/, 204  
 DIVERS, 202, 204  
*dlambda*, 134  
 (DLEAK:), 139  
 DLEAK:, 139  
 (dleak\_data), 139  
 DMACRO, 139, 141  
 DMIX, 21, 22  
 DMOD, 119, 121, 200  
*dmod*, 106, 107  
 DNAME, 105, 106  
*dname*, 67, 68  
 DONCPO, 110, 111

(DONJON), 6  
 DRA, 118, 121, 200, 201  
 (DREF:), 147  
 DREF:, 147  
 DSET:, 4, 19, 22, 26, 30, 177  
 (DSPH:), 141  
 DSPH:, 141  
 (dsph\_data), 141  
 dt, 52, 53, 134, 135, 137  
  
 ecost, 151, 153  
 EDI:, 74  
 EDIT, 9, 12, 13, 16–20, 23, 27, 30, 32–34, 36, 38,  
 40, 41, 44, 47, 51, 52, 54, 58, 65, 67, 70,  
 73, 84, 85, 94, 95, 100, 105, 106, 111,  
 117, 118, 127, 128, 134, 137, 139–141,  
 147–152, 155, 158, 161–163  
 emin, 123  
 EMPTY-MIX, 27, 28  
 END, 30, 31  
 END:, 3, 6, 7  
 ENDA, 134  
 ENDADD, 118  
 ENDBARR, 118  
 ENDCHAIN, 88, 89, 98, 99, 103, 104  
 ENDCYCLE, 47, 49  
 ENDD, 67  
 ENDGLOBAL, 118  
 ENDISOTOPES, 118  
 ENDMAN, 118  
 ENDMIX, 71, 72, 75, 77, 86, 88, 96, 98, 102, 103  
 ENDN, 24, 25  
 ENDP, 134  
 ENDPKEY, 118  
 ENDREF, 75, 76, 86, 87, 96, 98, 102, 103  
 ENDRGRP, 65, 66  
 ENDRMAP, 65, 66  
 ENDROD, 21, 22  
 energy, 88, 89, 98, 99, 103, 104  
 ENRICH, 13, 15  
 epsburn, 47, 49  
 EPSILON, 134, 135  
 epsilon, 134, 135  
 epsilon4, 152  
 epspowr, 47, 49  
 epsr, 128, 130  
 EQUI, 84, 85, 119, 125  
 ermaxc, 128, 132  
 ermaxt, 128, 132  
 EVO:, 43, 59  
 EXTR, 34, 35  
  
 F, 124, 125  
 F-RUG, 128, 130  
 FACTOR, 139, 140  
 FADE, 19, 20  
 FILE\_CONT\_1, 118, 123, 201  
 FILE\_CONT\_2, 119, 123, 201  
 FILE\_CONT\_3, 119, 123, 201  
 FILE\_CONT\_4, 119, 124, 201  
 FILE\_NAME, 119, 124  
 FIX, 118, 123, 200  
 FIXP, 105, 106  
 FLMAP, 8, 9, 13, 64  
 FLMAP1, 32, 33  
 FLMAP2, 8, 9, 13, 15, 32, 33  
 flow, 128, 129  
 FLPOW:, 4, 5, 37, 38, 40, 41, 43, 46, 50, 52, 106,  
 160, 162, 183  
 FLUD:, 3, 5, 37, 38, 41, 52, 162  
 FLUID, 127, 128  
 FLUNAM, 67, 160  
 FLUX, 37, 38, 52, 147, 148  
 FLUX, 38, 39  
 /flux/, 184  
 FLUX, 5, 37, 38, 52, 149  
 FLUXUNK, 67, 160  
 FMAP, 37–40, 43, 46, 54, 55, 67, 69, 71  
 FMAP, 8, 14  
 /fmap/, 165–169  
 FMAP, 5, 37, 40, 43, 46, 54, 67, 69, 70  
 FMAPV, 54, 55  
 fmax, 27, 28  
 FMIX, 16, 17  
 fname, 119, 124  
 FOBJ-CST-VAL, 149, 150  
 FOLLOW, 9, 12  
 FORCEAVE, 128, 132  
 fprad, 128, 132  
 FPSPH:, 158  
 (fpsph\_data), 158  
 fpsph\_data, 158  
 FPUISS, 128, 129  
 frac, 24  
 fract, 23, 128, 129  
 FRACTION, 23, 24  
 FROM, 21, 47, 48, 75, 86, 88, 89, 96, 98, 99, 103,  
 104  
 firstrec, 111, 112  
 FSTH, 38, 39  
 fsth, 38, 39  
 FT, 112  
 FUEL, 13, 15, 18, 47, 48, 118, 120, 170  
 fuel, 48  
 {/FUELDIR/}, 185  
 FULL, 54, 55  
 FULL-MIX, 27, 28

- funct*, 149, 150
- fvalue*, 12–15
- gamma*, 134, 136
- GEN*, 117, 118, 124
- GENPMAXS*, 119, 124
- /GENPMAXS.INP/*, 201
- GEO:*, 3, 5, 9, 10, 16, 52
- GEOM*, 16, 17, 52
- GEOMAP*, 169
- /geometry/*, 165, 169
- GEOMETRY*, 5, 16, 17, 52, 160, 164
- GEOMOLD*, 16, 17
- GEONEW*, 160
- GEOOLD*, 160
- GET*, 57, 58, 60, 118, 122, 200
- GFF*, 163
- GFF*, 118, 122
- GLOBAL*, 12, 14, 58, 59, 118, 121
- GPPR*, 162
- GPT*, 149
- GRAD:*, 149
- (grad\_data)*, 149
- grad\_data*, 149
- GREP:*, 3
- GRID*, 118, 121
- GROUP*, 34, 35
- GROUP-ID*, 22, 29
- GRPMAX*, 139–142, 158, 159
- GRPMIN*, 139–142, 158, 159
- H+*, 13, 15, 21
- H-*, 13, 15, 21
- H2O*, 127, 128
- hadf*, 122
- HALF*, 54, 55, 151, 153
- hc1*, 47, 49
- hc2*, 47, 49
- hcase*, 47, 48
- hcdf*, 122
- hcnew*, 47, 49
- hcold*, 47, 48
- hcold2*, 47, 48
- HCONV*, 128, 131
- hconv*, 128, 131
- hcycle*, 169
- hdet*, 122
- hdet*, 118
- height*, 10
- HEL*, 117, 123, 124
- HELIOS*, 118, 123
- HELIOS.dra*, 124
- /HELIOS-HEAD/*, 201
- hequi*, 119, 126
- HEX*, 24, 25
- HEXZ*, 23
- HGAP*, 128, 131
- hgap*, 128, 131
- hgrp*, 65, 66
- HISO*, 71, 72, 75–77, 86–88, 96, 98, 102, 103
- HISOT*, 9, 12, 46
- hist\_nr*, 156
- hist\_nr*, 155
- History*, 61
- /history/*, 185
- HISTORY*, 5, 57–62
- HISTORY CASE identification (mandatory)*, 116
- HISTORY-DATA*, 191
- HistXSM*, 62
- HM\_Dens*, 201
- hm\_dens*, 123
- hmasl*, 119, 126
- hmix*, 65, 66
- HNAME*, 9, 11
- HOURL*, 44, 47–49
- hrod*, 65, 66
- HST:*, 4, 5, 57, 60, 186
- (hstbrn)*, 57–59
- (hstdim)*, 57, 58
- (hstpar)*, 57–60
- htemp*, 118, 119
- hx*, 47
- hy*, 47, 48
- I-BURNUP*, 71, 72
- I135*, 118, 120
- ialch*, 13, 15
- ialch(i)*, 15
- ibax*, 9, 10
- ibm1*, 139, 140
- ibm2*, 139, 140
- ibun*, 57, 58
- ibun*, 62
- icha*, 57, 58
- icha*, 62
- icz*, 9, 11
- id*, 21, 22, 27–29, 34, 35
- IDET:*, 67, 205
- IDETEC*, 67
- IDETECT*, 67
- idfuel*, 57, 58
- idfuel*, 62
- ifuel*, 47
- IFX*, 161
- ifx*, 161, 162
- igc*, 111
- igrp*, 22, 29, 34, 35



- ihex*, 24, 25
- ilg*, 112
- ilgrp*, 30, 31
- ilzc*, 30, 31
- IMET*, 106, 108
- imet*, 106, 108
- imix*, 44, 45, 48, 75, 86, 96, 101, 102, 105, 106, 118, 119, 163
- imixold*, 75, 86, 96
- in*, 19
- inam*, 118, 120
- indcycle*, 47
- indcycle1*, 47
- indcycle2*, 47
- INF*, 117, 118
- INFO*, 23, 24
- INFOR*, 105, 106
- INIT*, 38, 39, 51, 105, 106
- INLET*, 128, 129
- INLET-Q*, 128, 129
- INN-CONV-TST*, 155, 156
- INN-STEP-EPS*, 151, 152, 155
- insm*, 65
- INSR*, 34, 35
- INST-BURN*, 12, 13, 71, 75, 76, 86, 87, 96, 97, 102
- INST-BVAL*, 12, 13
- /intdetec/*, 205
- INTEG*, 67, 68
- INV*, 128, 131
- inv*, 128, 131
- INVCONST*, 23, 24
- iph*, 118
- iphase*, 117, 118
- iphase=1*, 118
- iprint*, 9, 12, 13, 16–20, 27, 30, 32–34, 36, 38, 40, 41, 44, 47, 51, 54, 55, 58, 65, 67, 68, 70, 73, 74, 84, 85, 94, 95, 100, 105, 106, 111, 117, 118, 127, 128, 134, 135, 137, 139–141, 147–152, 155, 158, 161–163
- iprt*, 23, 52
- irgrp*, 30, 31
- irod*, 30, 31
- ishift*, 12, 14
- ISOT*, 119, 126
- ISOTOPES*, 118, 120, 123
- isotval*, 119, 126
- ispx*, 163
- ispy*, 163
- isrt*, 66
- isrt(i)*, 65
- IUPS*, 119, 125
- iups*, 119, 125
- ivarty*, 71, 72, 75, 76, 86, 87, 96, 97, 102
- iza*, 9, 10
- izae*, 88, 98, 103, 104
- JOB\_OPT*, 119, 124
- JOB\_TIT*, 119, 124
- jobtit*, 119, 124
- kc*, 52, 53
- kcond*, 128, 131
- KEEP*, 149, 150
- KELVIN*, 131
- kg*, 15
- KINET*, 37, 38
- KINET*, 37, 38
- KINSOL:*, 37, 38
- L*, 195
- L\_POWER*, 167
- ladf*, 121, 122, 124
- ladf lxes lded lj1f lchi lchd linv ldet lyld lcdf lgff lbet lamb ldec*, 119
- lamb*, 125
- LAMBDA*, 134, 135
- lambda*, 134, 135
- LAMBDAL*, 134, 135
- lambdai*, 135
- lbet*, 125
- LBFGS*, 155, 156
- lcdf*, 125
- lchi*, 125
- lchid*, 125
- ldec*, 125
- lded*, 125
- ldet*, 125
- LEAK*, 73, 74, 84, 85, 95, 100, 101
- LEMKE*, 151, 152
- length*, 10
- LEVEL*, 13, 15, 21, 27, 28, 30, 31, 34, 35
- LFLAG*, 200
- lgff*, 122, 125
- LIBNAM*, 67
- LIBRARY*, 43
- LIBRARY*, 43, 50
- LINEAR*, 73–76, 84–87, 95–97, 100–102, 134, 135
- LINKED\_LIST*, 6, 7
- LINS*, 65
- linv*, 124, 125
- LIST*, 111, 112
- lj1f*, 125
- lmix*, 65, 66
- LNSR:*, 154, 195
- (lnsr\_data)*, 154
- lnsr\_data*, 155
- LOCAL*, 12, 14, 15, 58, 59

- lvalue*, 13, 15
- lx*, 9, 12, 47, 65
- lxes*, 125
- ly*, 9, 12, 47
- lyld*, 122, 125
- LZC*, 27, 28, 30, 31
- LZC-GR*, 27
- LZC-GROUP*, 30, 31, 180
- (lzc-group)**, 27, 29
- LZC-ID*, 29
- LZC:*, 4, 19, 26, 31, 177
- 
- MAC:*, 3, 5, 18
- MACD:*, 23
- MACFL*, 18, 69
- MACGEO*, 163
- MACINI:*, 4, 5, 18, 36, 41
- MACREF*, 143, 147, 148
- MACRES*, 160
- MACRO*, 105
- MACRO*, 18, 37, 38, 69, 70, 105, 139–143, 147, 148
- MACRO*, 73, 74, 84, 85, 95, 100, 101
- MACRO2*, 18, 36
- MACRO3*, 36
- MACROLIB*, 158, 159
- MACROLIB*, 77, 89, 99
- /macrolib/*, 176
- MACROLIB*, 1, 3–5, 12, 18, 36, 38, 41, 67, 69–72, 105, 106, 158, 160
- /MACROLIB\_XS/*, 203
- MACROREF*, 158
- MAN*, 118, 123, 200
- MAP*, 32, 64
- MAP*, 160, 162
- MAP*, 38, 39, 47, 75, 76, 86, 87, 96, 97, 102, 103, 105, 106, 151, 152
- MAP*, 57–62, 105–108, 127, 134, 137, 160, 162, 164
- MAPO*, 61
- MAPFL*, 73–76, 79, 80, 84–87, 91, 92, 94–97, 100–103, 105, 106, 127, 129, 132, 134, 137
- MASL*, 84, 85, 119, 126
- MATEX*, 8, 9, 16, 18, 19, 26, 36–38, 160
- MATEX*, 16
- /matex/*, 175, 176
- MATEX*, 5, 9, 15, 16, 18, 19, 26, 36, 38, 55, 160
- MAX-FULL*, 27, 28
- MAX-MIX-GEO*, 163, 164
- maxE*, 155
- MAXIMIZE*, 149–152, 155
- maxit1*, 128, 132
- 
- maxit2*, 128, 132
- maxit3*, 128, 132
- maxmix*, 65, 66
- MAXPOS*, 21, 22, 27, 28
- MAXR*, 16, 17
- maxreg*, 16, 17
- MB*, 112
- MCC*, 33
- MCC:*, 4, 32, 33
- MCO*, 117, 118
- MCO*, 120–122, 199, 200
- MCR*, 105–107
- MD*, 112, 113
- MEMO*, 119, 125
- MERGE*, 118, 121
- METH*, 162
- METHOD*, 151, 152
- MIC*, 117, 118
- MICLIB*, 43
- MICLIB2*, 43
- MICLIB3*, 43
- MICREF*, 143, 147, 148
- MICRO*, 143, 147, 148
- MICRO*, 44, 71–76, 84–87, 95, 96, 98, 100–103
- MICROLIB*, 43
- MICROLIB*, 50
- MICROLIB*, 4
- /MICROLIB\_XS/*, 204
- MINIMIZE*, 149–152, 155
- MINUTE*, 44, 47–49
- MIX*, 10, 71, 75, 76, 86, 87, 96, 97, 101, 102, 111, 112, 118, 119
- mix*, 71, 72
- MIX-FUEL*, 54, 55
- MIX-VOID*, 54, 55
- mix1*, 21, 22
- mix2*, 21, 22
- MIXASS*, 163
- mixdir*, 118, 119
- mixE*, 27, 28
- mixF*, 27, 28, 54, 55
- mixf*, 16, 17
- MIXMAX*, 139, 140
- MIXMIN*, 139, 140
- MIXNAM*, 111–113
- mixr*, 16, 17
- mixV*, 54, 55
- MLIB*, 46, 49, 73, 74, 84, 85, 94, 95, 100, 101
- MLIB2*, 73, 84, 94, 100
- mmix*, 105, 106
- MODNAME*, 6
- MODULE*, 6
- (module)**, 6, 7

MONO, 128, 132  
 MOVDEV:, 4, 22, 34, 177  
 MOVE, 19, 20  
 MP, 112  
 MT, 112, 113  
 MTMD, 111, 113  
 MTS, 113  
 MULTICOMPO, 5, 9, 160–162  
 MW·day per tonne, 13  
  
 N2N, 88, 99, 104  
 N3N, 89, 99, 104  
 N4N, 89, 99, 104  
 NA, 89, 99, 104  
 na, 9, 10, 12  
 nadf, 118, 122  
 nalpha, 134, 135  
 namburn, 73, 74, 84, 85, 95, 96  
 NAMCHA, 44, 45  
 NAMDB, 105, 106  
 NAMDET, 24, 25  
 NAMDIR, 71, 73, 74  
 NAMDIR, 118, 119  
 NAMDPL, 88, 98, 103, 104  
 NAME, 21  
 NAME, 24, 25  
 /name\_detect/, 182  
 {/name\_detect/}, 182  
 /name\_type/, 181, 182  
 {/name\_type/}, 181  
 namedir, 161, 163  
 NAMPAR, 60, 88, 89, 98, 99, 103, 104  
 NAMPER, 111–113  
 NAMTYP, 23, 24, 53, 105, 106  
 (NAP:), 160  
 NAP:, 4, 9, 10, 17, 160, 164  
 nass, 65, 66  
 naval, 9, 12  
 nax, 9, 10  
 nay, 9, 10  
 nB, 106, 107  
 nb, 12, 13, 47  
 nb1, 128, 132  
 nb2, 128, 132  
 nbax, 9, 10  
 nbf, 128, 129  
 nbfuel, 73, 74  
 nbg, 128, 129  
 nbun, 58, 59  
 nburn, 111, 112  
 Nc, 60  
 ncdf, 118, 122  
 nch, 9, 12, 13, 128, 130  
  
 ncha, 58, 59  
 ncols, 123  
 ncols nrows part hm\_dens bypass, 118  
 NCOMB, 9, 11, 12  
 ncomb, 9, 11, 12  
 ncond, 128, 131  
 ncorner, 124  
 (NCR:), 73–75  
 NCR:, 4, 5, 12, 13, 18, 41, 43, 45, 54, 55, 69, 73, 117  
 (ncr\_data), 73  
 ncr\_data, 73  
 ncst, 149, 150  
 ND147, 118, 120  
 nd47nam, 118, 120  
 ndetect, 23, 24  
 nel, 103, 104  
 NEP, 106, 107  
 NEW, 48, 118, 121  
 NEWFUEL, 44, 45  
 NEWMAC:, 4, 5, 18, 22, 28, 36, 41, 177  
 NEWT, 155, 156  
 NEWTON, 147, 148  
 NFTOT, 89, 99, 104  
 NFUEL, 16, 17  
 nfuel, 13, 15–17, 54  
 NG, 88, 99, 104  
 ngcond, 111, 112  
 nglo, 58, 59  
 nglob, 59  
 NGMTR, 111  
 ngr1, 139–142, 158, 159  
 ngr2, 139–142, 158, 159  
 NGREAC, 111  
 NGROUP, 134, 135  
 ngroup, 134, 135, 138  
 ngroup+1, 137  
 NGRP, 16, 17, 23  
 ngrp, 16, 17, 19, 20, 22, 23, 27, 29, 31, 35, 65  
 nh, 9, 11  
 NHEX, 24, 25  
 nhex, 24, 25  
 NHNAME, 9, 11  
 nis, 9, 12  
 nk, 45  
 nloc, 58, 59  
 nlzc, 27–29, 31  
 NMCHA1, 44, 45  
 NMCHA2, 44, 45  
 NMIX, 16, 17, 70, 73, 74, 84, 85, 95, 100, 101, 111  
 nmix, 70, 71, 163  
 nmixt, 16, 17, 73, 74, 84, 85, 95, 100, 101, 111  
 nmxgeo, 163, 164

*nNp*, 106, 107  
 NO-STORE-OLD, 151, 153  
 NODERIV, 147, 148  
 NOEV, 86, 88, 96, 98  
*noreg*, 111, 112  
 NORM, 38, 39, 52, 53  
*noth*, 118, 120  
 NP, 89, 99, 104  
*npert*, 111, 113  
 NPWF, 105, 106  
 NREF, 106  
 NREFL, 16, 17  
*nrefl*, 16, 17  
*nrep*, 23, 24  
 NRFB, 65  
*nrfb*, 65  
 NRMFLUX, 37  
*nrmv*, 65, 66  
*nrod*, 19–22, 31, 35  
*nrows*, 123  
*nsh*, 44, 45  
*nside*, 124  
*nside ncorner vfc*m, 119  
*nSm*, 106, 108  
*nstart*, 155  
*ntime*, 128, 132, 134, 136  
 NTOT1, 139, 140  
*ntyp*, 105, 106  
 NUM-LZC, 27  
 NUM-ROD, 19, 20  
*nval*, 121  
*nvar*, 149, 150  
*nvoid*, 54, 56  
*nx*, 9, 11  
*nx*a, 10  
*nxass*, 163  
*nXe*, 106, 107  
 NXNAME, 44, 45  
 NXNAME, 9, 11  
*nxy*, 134, 136  
*ny*, 9, 11  
*nya*, 10  
*nyass*, 163  
 NYNAME, 44, 45  
 NYNAME, 9, 11  
 NZASS, 162  
*nzass*, 162  
  
 OLDMAP, 12, 13, 15  
 ONLY, 75, 77, 86, 88, 96, 98  
 OPTIM, 139, 141, 147–152, 154, 155, 158  
 /optimize/, 193–195  
 OPTIMIZE, 143, 148, 149, 151, 154, 158  
  
*or*, 31, 34, 54  
 OTHER, 118, 119  
*othpk*, 120  
*othpk(i) othtyp(i) othval(i)*, 118  
*othtyp*, 120  
*othval*, 120  
*out*, 19  
 OUT-CONV-TST, 151, 153, 155, 156, 158, 159  
 OUT-ITER-MAX, 155  
 OUT-RESTART, 155  
 OUT-STEP-EPS, 151, 152, 155, 158, 159  
 OUT-STEP-LIM, 149–152, 155  
  
 P, 195  
 P-NAME, 33  
 P-NEW, 38, 39  
 P-VALV, 134, 136  
*p1*, 134, 136  
*p2*, 134, 136  
*p3*, 134, 136  
*par1*, 65  
 PARA, 65  
 PARAB, 53  
 PARABOLIC, 151, 153  
 PARAM, 172  
 PARAMBURNTAR, 61, 62  
 PARKEY, 12, 14, 75, 76, 86, 87, 96, 97, 102, 103  
 PARKEY, 12, 14  
*part*, 122, 123  
*pcore*, 32, 33  
 (PCR:), 100, 101  
 PCR:, 100  
 (PCR\_data), 100  
*PCR\_data*, 100  
 PENAL-METH, 151, 152  
*period*, 59  
 PHASE, 117, 118  
 PICK, 44, 45, 128, 133, 137, 138  
 PICKR, 137, 138  
*pitch*, 124, 128, 130  
*pitch xbe ybe*, 119  
 PKEY, 118–120, 199  
*pkey*, 121  
 PKEY\_INFO, 200  
 PKEY<sub>k</sub>, 200  
*pkey(i)*, 121  
 /PKEY\_INFO/, 200  
 PKINI:, 134, 137  
 PKINS:, 134, 135, 137  
 PLQ:, 151, 195  
 (plq\_data), 151  
*plq\_data*, 151  
 PM147, 118, 120

PM148, 118, 120  
 PM148M, 118, 121  
 PM149, 118, 120  
 pm47nam, 118, 120  
 pm48mnam, 118, 121  
 pm48nam, 118, 120, 121  
 pmam, 118  
 PMAX, 100, 101  
 PMAX1, 100  
 PMAX2, 100  
 PMAXS, 100, 101, 121  
 pmnam, 118, 120  
 PN, 141, 158  
 PNAME, 12, 14, 15, 47, 49, 54, 55, 128, 132–134  
 PNAME, 12, 14, 49, 132, 135, 136  
 pname, 161  
 PNAMEREF, 12, 15  
 POISON, 13, 15  
 POOL, 44, 45  
 POROS, 128, 130  
 poros, 128, 130  
 pos, 21, 22, 24, 25, 27, 28  
 POSITION, 24, 25, 67, 68  
 poutlet, 128, 129  
 pow, 105, 106, 128, 162  
 pow(*i*), 132  
 POWER, 37, 38, 40, 43, 44, 46, 48, 50  
 POWER, 37–39, 134, 135, 137, 162  
 /power/, 183, 184  
 POWER, 5, 37, 40, 43, 46, 50  
 power, 38, 39, 59, 134, 135, 137, 138  
 POWER-LAW, 128, 132  
 power\_out, 137, 138  
 POWOLD, 37, 39  
 PPR, 160, 162  
 PRINT, 38, 39  
 PROC, 117, 118  
 PROC, 119, 125  
 PROJECTION, 161  
 PTIME, 134, 135  
 PTOT, 38, 39  
 PUFR, 128, 130  
 pufr, 128, 130  
 PUR, 106, 107  
 PURE, 73, 74, 84, 85, 94, 95  
 purity, 106, 107  
 PUT, 57, 58, 60  
 pvalue, 12, 13, 15, 47, 49, 128, 133, 161, 162  
 PWF, 105, 106  
 PWR CASE : UOX/MOX CORE FUEL, 124  
 pwtot, 12, 14  
 pwvalue, 12, 14  
 qfluid, 128, 129  
 QMAP, 47, 48  
 QUARTER, 54, 55  
 R,S or I, 120  
 r1, 128, 130, 132  
 r2, 128, 130  
 r3, 128–130  
 r4, 128–130  
 RAD-PROF, 128, 132  
 RADIUS, 128, 130  
 RATE, 27, 28  
 rate, 27, 28  
 RATIO, 38, 39  
 ratio, 128, 133  
 rburn, 44, 47, 48  
 RC, 111, 112  
 RD, 112  
 RDCL, 106, 107  
 RDMD, 106, 107  
 reaction, 88, 89, 98, 99, 103, 104  
 REACTOR-POW, 12, 14  
 READ, 32, 33, 70  
 REANAME, 67, 68  
 REC, 32, 33  
 rec1, 32, 33  
 rec2, 32, 33  
 REF, 52, 53, 75, 76, 86, 87, 96, 97, 102, 103, 118, 123  
 ref, 128, 131  
 REF-SHIFT, 12, 14  
 REFLECTOR, 118, 123  
 refnam, 119  
 refnam(*i*), 118  
 REFT, 105, 106  
 REFUEL, 44  
 REGION, 111–113  
 RELAX, 40, 41, 128  
 relax, 128  
 relval, 40, 41  
 rep, 24, 25  
 RES, 73, 74, 84, 85, 94, 95  
 RESET, 134, 136  
 RESINI, 9  
 RESINI:, 4, 5, 8, 9, 40, 41, 43, 46, 54, 165, 167  
 RESP, 24, 25  
 REWIND, 202  
 RGRP, 65  
 rho, 137, 138  
 rin, 66  
 rin(*i*,1), 65  
 rin(*i*,*j*+1), 65  
 RMAP, 65, 66

RMIX, 16, 17  
 RMS, 147, 148  
 RMS\_VAL, 147, 148  
 rname, 67, 68  
 ROD, 21, 30, 34, 35  
 ROD-GR, 19, 20  
 ROD-GROUP, 30, 31, 179  
 (rod-group), 19, 20, 22  
 ROD-ID, 22  
 ROD-INFO, 172, 173  
 ROD-NAME, 21  
 ROD:, 64, 172  
 RODMESH, 128, 132  
 RP, 112  
 rprad, 128, 132  
 RT, 112  
 rtime, 44, 47-49  
  
 SAHA, 128, 132  
 SAM, 106, 108  
 SAME, 12, 13, 15, 32, 33  
 SAMEASREF, 75, 76, 86, 87, 96, 97, 102, 103  
 SAP, 117-120, 123, 125  
 SAP, 118-122, 199, 200  
 SAP:, 5  
 SAPHYB, 84, 85  
 SAPHYB, 5  
 /SAPHYB\_INFO/, 199, 200  
 SAPNAM, 84-86  
 sapnam, 119  
 sapnam(i), 118  
 SAPNAM1, 84  
 SAPNAM2, 84  
 sass, 129  
 (SCR:), 84-86  
 SCR:, 84, 117, 197  
 (scr\_data), 84, 85, 94, 95  
 scr\_data, 84, 94  
 SD, 155  
 SECOND, 44, 47-49  
 sect, 128, 129  
 SEL, 118, 122, 200  
 SEQ\_ASCII, 6, 7  
 SEQ\_BINARY, 6, 7  
 SET, 47, 48, 54, 55, 75-77, 86, 87, 89, 96, 97, 102, 161  
 SET-FOLLOW, 47, 49  
 SET-PARAM, 12, 14, 47, 49, 128, 132  
 SFAC, 119, 125  
 sfac, 119, 125  
 SHUFF, 44, 45  
 side, 10  
 SIM, 9, 12  
 SIM:, 4, 46  
 SIMEX, 53  
 SIMPLEX, 151, 152  
 SLPITX-ASS, 163  
 SLPITY-ASS, 163  
 SM149, 118, 120  
 smnam, 118, 120  
 SMOOTH, 12, 13  
 SN, 141, 142, 158  
 SOME, 44, 45  
 SOURCE, 147, 148  
 SOURCE, 149  
 SPC, 48  
 SPEC, 47, 48  
 spec, 23, 24  
 SPECTRAL, 23, 24  
 SPEED, 21, 30, 31, 34, 35, 128, 129  
 speed, 21, 30, 31, 34, 35  
 SPH, 141, 158  
 SPLINE, 53  
 SPLIT-NAP:, 9, 10  
 SQDERIV, 134, 135  
 sr, 149-152, 155  
 STABLE, 88, 89, 98, 99, 103, 104  
 STEP, 65, 161  
 step, 65  
 STEP-REDUCT, 151, 152  
 STOP, 202  
 STRNAME, 6, 7  
 SYSTEM, 5, 41  
  
 T, 124, 125  
 t, 128, 134, 136  
 t(i), 132  
 T-BURNUP, 71, 72  
 T-DELT, 134, 136  
 T/H invariant variables (mandatory), 116  
 t0, 134, 135, 137, 138  
 t1, 134, 136  
 T16CPO:, 110, 111, 113  
 t2, 134, 136  
 TABLE, 70, 71, 73-75, 84-86, 94-96, 100, 101  
 Tape16, 110-113  
 TAVG:, 4, 40, 41  
 tb1, 134, 136  
 tb2, 134, 136  
 TCalo, 61  
 TCOM, 119, 121, 200  
 TComb, 61  
 TCOOL, 105, 107  
 tcool, 105, 107  
 TEF, 128, 131  
 TEMP, 118, 119

*TEXT4*, 84, 85  
*TFUEL*, 105, 107  
*tfuel*, 105, 107  
*TH\_DATA*, 201  
*/TH\_DATA/*, 202  
*THERMO*, 127  
*THERMO*, 127  
*THETA*, 128, 130  
*theta*, 128, 130  
*/thm/*, 188, 189  
*THM:*, 127, 128, 134, 189, 191, 192  
*TIMAV-BURN*, 12, 13, 71, 75, 76, 86, 87, 96, 97, 102  
*TIMAV-BVAL*, 12, 13  
*TIME*, 21, 22, 27, 28, 30, 31, 44, 47, 48, 52, 53, 128, 134, 135, 137  
*time*, 21, 22, 27, 28, 30, 31, 128  
*TIMES*, 12, 15  
*times*, 10  
*TIMESTEP*, 191, 192  
*timestep*, 128  
*TIMESTEP0000*, 191  
*tinlet*, 128, 129  
*TINST:*, 4, 43, 44  
*tinu*, 23, 24  
*TMOD*, 105, 107, 119, 121, 200  
*TMod*, 61  
*tmod*, 105, 107  
*TO*, 44, 45  
*TOTAL*, 95  
*tpow*, 128, 132  
*TRACK*, 37, 38, 52, 147, 148  
*TRACK*, 5, 38, 52  
*TRACKING*, 67, 160  
*TRIVAA:*, 3, 5, 41  
*TRIVAT:*, 3, 5, 38  
*TRKNAM*, 67, 160  
*TTD*, 32, 33  
*TYPE*, 23, 24, 139, 140  
*type*, 149, 150  
  
*UNI*, 32, 33  
*unit*, 128, 131  
*unrodded*, 118, 120  
*UPS*, 71  
*USE*, 75, 86, 96  
*USER*, 118, 121  
*USPLIT:*, 4, 5, 15, 16, 52, 175  
*UTL:*, 3  
  
*val*, 121  
*val1*, 64, 65, 75, 76, 86, 87, 96, 97, 102, 103  
*val2*, 75, 76, 86, 87, 96, 97, 102, 103  
*valpar*, 60  
  
*valper*, 111, 113  
*valperd*, 111, 113  
*valpert*, 111, 113  
*valref*, 75, 76, 86, 87, 96, 97, 102, 103, 111, 112  
*valrefd*, 111, 113  
*valreft*, 111, 113  
*VALUE*, 139, 140  
*value*, 21, 27, 28, 30, 31, 34, 35  
*value1*, 32, 33  
*value2*, 32, 33  
*valx*, 67, 68  
*valx1*, 67, 68  
*valx2*, 67, 68  
*valy*, 67, 68  
*valy1*, 67, 68  
*valy2*, 67, 68  
*valz*, 67, 68  
*valz1*, 67, 68  
*valz2*, 67, 68  
*VAR-VAL-MAX*, 149, 150, 158, 159  
*VAR-VAL-MIN*, 149, 150, 158, 159  
*VAR-VALUE*, 149, 150  
*VAR-WEIGHT*, 149, 150  
*varmax*, 149, 150, 158, 159  
*varmin*, 149, 150, 158, 159  
*VChan*, 201  
*vchan*, 124  
*VClad*, 201  
*vclad*, 124  
*VCnRd*, 201  
*vcnrd*, 124  
*VCool*, 201  
*vcool*, 123  
*vcool vwatr vmodr vcnrd vfuel vclad vchan*, 119  
*vecmax*, 149, 150  
*vecmin*, 149, 150  
*velocity*, 128, 129  
*vers*, 119, 124  
*VERSION*, 119, 124  
*VFCM*, 201  
*vfcM*, 124  
*VFuel*, 201  
*vfuel*, 124  
*VModr*, 201  
*vmodr*, 124  
*vnorm*, 52, 53  
*VOID-PATTERN*, 54, 55  
*VWatR*, 201  
*vwatr*, 123  
  
*WARNING-ONLY*, 151, 153  
*WEIGHT*, 13, 15  
*weight*, 149, 150

*width*, 10  
WIMS16, 110, 111  
*wt*, 15  
*wteff*, 128, 131

X, 21, 27, 28  
*x*, 134–136  
*xbe*, 124  
XE135, 118, 120  
*xenam*, 118, 120  
XENON, 106, 107  
XENON:, 50, 51  
XEREF, 106–108  
XESM, 119, 125  
*xesmopt*, 119, 125  
XFAC, 36  
*xfac*, 36  
XHAME, 11  
XNAME, 9, 11, 54, 56  
XNAMEA, 9, 10  
XS CONTROL, 116  
XS CONTROL information (mandatory), 115  
XS data (mandatory), 116  
XS SET identification (mandatory), 116  
XS\_CONT, 119, 124, 201  
XSM, 72  
XSM\_FILE, 6, 7

Y, 21, 27, 28  
*y*, 134, 135, 137, 138  
Y-INIT, 137, 138  
*ybe*, 124  
*yield*, 88, 89, 98, 99, 103, 104  
YLD, 118, 122  
*yldi*, 118, 123  
*yldpm*, 118, 123  
*yldxe*, 118, 123  
YNAME, 9, 11, 54, 56  
YNAMEA, 9, 10

Z, 21, 27, 28