

README

Perry Kundert

November 25, 2014

Contents

| | | |
|----------|--|----------|
| 1 | Actuator Position Control via EtherNet/IP | 1 |
| 1.1 | Installing | 1 |
| 1.2 | Positioning | 2 |
| 1.2.1 | Command- or Pipe-line usage | 2 |
| 1.3 | SMC Gateway Simulator | 3 |

1 Actuator Position Control via EtherNet/IP

The `cpppo_positioner` module allows control of the position of a set of actuators, by initiating a communication channel, and issuing new position directives via the actuator state machine. The current state is polled as necessary via EtherNet/IP CIP read commands, and data updates and state changes are performed via EtherNet/IP CIP writes.

1.1 Installing

Clone the repository, and run the `setup.py` installer:

```
$ git clone git@github.com:pjkundert/cpppo_positioner.git
$ cd cpppo_positioner
$ python setup.py install
$ python
Python 2.7.6 (default, Sep  9 2014, 15:04:36)
[GCC 4.2.1 Compatible Apple LLVM 6.0 (clang-600.0.39)] on darwin
Type "help", "copyright", "credits" or "license" for more information.
>>> import cpppo_positioner
```

```
>>>
```

1.2 Positioning

A Python API is provided to implement positioning control.

```
from import cpppo_positioner import smc lec_gen1
gateway = smc lec_gen1()
gateway.position( actuator=0, timeout=10.0, position=12345, speed=100, ... )
```

1.2.1 Command- or Pipe-line usage

An executable module entry point (`python -m cpppo_positioner`), and a convenience executable script (`cpppo_positioner`) are supplied.

If your application generates a stream of actuator position data, or if you have some manual positions you wish to move to, you can use the command-line interface. You may supply one or more actuator positions in blobs of JSON data (an actual position would have more entries, such as `acceleration`, `deceleration`, `timeout`, ...):

```
$ position='{ "actuator": 0, "position": 12345, "speed": 100 }'
```

These positions may be supplied either as single parameters on the command line, or as separate lines of input (if standard input is selected, by supplying a `-` option):

```
$ python -m cpppo_positioner --address gateway -v "$position"
$ echo "$position" | cpppo_positioner --address gateway -v -
```

- Quoting double-quotes on Windows Powershell

Note that on Windows Cmd or Powershell, it is very difficult to quote double-quote characters in strings. In Powershell, you need to use the bash-slash + back-tick before each double-quote. Unexpectedly, using a single-quoted string does **not** allow you to contain double-quotes.

You can get double quotes into a string:

```
PS > $position = '{ "actuator": 0, "position": 12345, "speed": 100 }'
PS > $position
'{ "actuator": 0, "position": 12345, "speed": 100 }'
```

However, when you try to use them, they are re-interpreted on inclusion in a command:

```
PS > python -m cpppo_positioner --address gateway -v "$position"
PS > python -m cpppo_positioner -v "$position"
... Invalid position data: { actuator: 0, position: 12345, speed: 100 };
    Expecting property name: line 1 column 3 (char 2)
```

So, the only way to do this is to use the strange back-slash + back-tick double-escape, directly as a command-line argument:

```
PS > python -m cpppo_positioner --address gateway -v '{ \'"actuator\':"': 0, .
```

Recommendation: use Linux or Mac, or install Cygwin and use bash on Windows. Trust me; this is just the tip of the iceberg...

1.3 SMC Gateway Simulator

To simulate a number of SMC positioning actuators behind an SMC LEC-GEN1 gateway, run:

```
$ python -m cpppo_positioner.simulator 3
```