

**Mathematica Framework for Communication with other  
Platforms for Robotic Applications**

**Anthony and Thomas Huang**

## Table of Contents

1 MATHEMATICA FRAMEWORK.....	1
1.1 Data Packets.....	1
1.2 Usage.....	2
1.3 Functions and Variables.....	2
2 MBED CLASS.....	4
2.1 Structure.....	4
2.1 Functions and Variables.....	4
2.3 Usage.....	6
Appendix A - mbed Serial_Communication Class Example Usage.....	7

# 1 MATHEMATICA FRAMEWORK

The following is a documentation of the Mathematica framework for serial communication with other platforms.

## 1.1 Data Packets

The framework uses instruction packets in the form: [Start][ID][Length][Instruction][Parameter 1]...[Parameter N][Checksum]. The packets include command data that other platforms should read to know what to do. The packets sent across the serial connection must follow this form, or else other platforms would not respond to the messages. The packet includes the following parts (in order):

1. [Start] : The start byte is one byte and notifies the beginning of the packet. The start byte for our framework is the integer 124 or the hex number 0x7C.
2. [ID] : The ID byte is a unique integer value required for serial communication between Mathematica and multiple platforms or boards. Each connected device is assigned a different unique integer value.
3. [Length] : The length byte is the length of the packet. It is calculated as the number of parameters + 2.
4. [Instruction] : Instruction should be either 0 or 1. If instruction is 1, the command would be a read request. This will be a request for information that will be sent back from mbed. If function is 0, the command would be a write request. This will be a request to change some information in the connected device.
5. [Parameters] : Parameters depend on the function. If instruction is 1, or a read request, the parameters will determine what information is read from mbed. For example, using “gyro” as an parameter will return some information from the gyroscope. For a read request, the length of parameters is usually 1. If instruction is 0, or a write request, the parameters will specify what to change and the value to change it to. The first parameter indicates what to change and the following parameters indicate what to change it to. In the case of controlling a snake bot, angles must be passed into servos. Thus, the parameters for a write request are in the form: [ChangeAngle][Angle1][Angle2]...[AngleN].
6. [Checksum] : The checksum is used to check if the packet is damaged during communication. It is calculated by summing up all the bytes except the checksum itself. If this sum value is greater than the integer value 255 (8 bytes), subtract it by 256. If the checksum calculated does not equal the checksum sent, the packet is destroyed.

## 1.2 Usage

The general procedure of sending a request through serial from Mathematica with our framework will now be discussed.

First, the user has to connect to the device with the `ConnectDevice` function. The argument to this function is the address of the connection to the device. After the connection is made, the user would be able to send “write” messages with `WriteMessage`. The arguments of the message is passed as an argument to the function. The function will convert the argument into a message form that is acceptable by the framework. `ReadMessage` works in the same way, except it returns the information that is read from the connected device.

## 1.3 Functions and Variables

The comprehensive list of functions and variables will now be discussed.

`ConnectDevice`[ *DeviceAddress\_*: “”, *BaudRate\_*: 9600 ]

Connects through serial to *DeviceAddress*. Sets the baud rate to *BaudRate*. Returns the connection to the device. This connection can be passed into the `ReadMessage` and `WriteMessage` functions.

*DeviceAddress* depends on the operating system of the computer the device is connected to:

Windows: “COM#”

MacOS or Linux: “/dev/ttyXX” or “/dev/tty.usbserialXX” or something similar

Default value of *DeviceAddress*: “” - connects to nothing.

Default value of *BaudRate*: 9600 - default baud rate supported by most boards.

Examples:

`ConnectDevice[/dev/cu.usbmodem1413]` // for Mac or Linux users

`ConnectDevice[COM4]` // for Windows users

`ReadMessage`[ *Device\_*: “”, *BoardID\_*: 1, *ReadMessageArg\_*: 0 ]

Send a read request to the connection *Device* to the board with ID *BoardID* with the argument as *ReadMessageArg*.

`ReadMessage` writes an instruction packet with the form [Start][ID][Length][Instruction][ReadMessageArg][Checksum]. *Device* is the connection to a device. *BoardID* is an integer which indicates the board to receive information from. *ReadMessageArg* is an integer which is parsed in the connected device. Depending on the integer, mbed can return different information through serial. `ReadMessage` returns values received from serial after the read request is sent.

Default value of *DeviceAddress*: “” - reads from nothing.

Default value of *BoardID*: 1 - reads from board with ID 1.

Default value of *ReadMessageArg*: 0 - reads information from the board with argument as 0. 0 is usually used to return all information.

Returns a string.

Examples:

```
dev = ConnectDevice["/dev/cu.usbmodem1413"] // first connect to device and set a variable to save the connection
```

```
ReadMessage[dev,1] // read from board with ID 1 through connection dev with argument as default, 0.
```

```
ReadMessage[dev,1, 2] // same as above except the argument is 2.
```

```
WriteMessage[ Device_: "", BoardID_: 1, WriteMessageArg_: 0, WriteMessage_: "" ]
```

Send a write request to the connection *Device* to the board with ID *BoardID* with the arguments as

*WriteMessageArg* and *WriteMessage*. *WriteMessage* writes an instruction packet with the form [Start][ID]

[Length][Instruction][WriteMessageArg][Parameter 1]...[Parameter N][Checksum]. *Device* is the connection to a device. *BoardID* is an integer which indicates the board to receive information from. *WriteMessageArg* indicates what to change and *WriteMessage* indicate what to change it to.

*WriteMessageArg* is an integer.

*WriteMessage* is an array of integers or floats.

Default value of *DeviceAddress*: "" - reads from nothing.

Default value of *BoardID*: 1 - reads from board with ID 1.

Default value of *WriteMessageArg*: 0 - writes information to the board with argument as 0.

Default value of *WriteMessage*: "" - writes nothing. This could unintentionally erase important data, so be careful.

Examples:

```
dev = ConnectDevice["/dev/cu.usbmodem1413"] // first connect to device and set a variable to save the connection
```

```
WriteMessage[dev,1] // write "" to board with ID 1 through connection dev with default argument 0.
```

```
WriteMessage[dev,1,2] // same as above except the argument is 2.
```

```
WriteMessage[dev,1,1,{40}] // write {40} with argument as 1.
```

```
WriteMessage[dev,1,3,{45,45,45}] // write {45,45,45} with argument as 3.
```

```
DisconnectDevice[ ]
```

Disconnects *Device*.

Default value of *Device*: "" - does nothing.

Example:

```
dev = ConnectDevice["/dev/cu.usbmodem1413"]
```

```
DisconnectionDevice[dev] // disconnects the connection dev
```

## 2 MBED CLASS

A mbed class for serial communication with Mathematica was created as an example to show how it works. Following is the documentation of the class.

### 2.1 Structure

Serial\_Communication Class:

Public Functions:

```
Serial_Communication(PinName tx, PinName rx, int baud_rate);
bool read_packet();
void packet_destroy();
```

Public Variables:

```
int packet_data[256];
int packet_size;
int packet_id
Int packet_instruc;
```

Private Functions:

```
bool validate_checksum();
```

Private Variables:

```
int packet_header
Int packet_length
Int packet_checksum;
int packet_mode;
bool read_mode;
```

### 2.1 Functions and Variables

Public Functions:

```
Serial_Communication(PinName tx, PinName rx, int baud_rate);
```

Creates a Serial\_Communication object. Creates a serial connection with the pins tx and rx. Sets the baud rate of the connection to baud\_rate. Initializes the values for all public and private variables.

Parameters:

tx is the pin for the TX line

rx is the pin for the RX line

baud\_rate is baud rate for the serial communication. Must be the same as in Mathematica. Default value is 9600.

Example:

```
Serial_Communication sc(USBTX, USBRX, 115200);
```

// Creates a Serial\_Communication object called sc, creates a serial connection with the pins USBTX and USBRX, and sets the baud rate of the connection to 115200.

bool read\_packet(int *timeout*);

Reads a packet sent from Mathematica. Function runs until a packet is read, or until function timeouts. Returns true if the packet is read successfully and returns false if packet is broken (checksum mismatch). Also returns false if function timeouts. Destroys the packet before returning false. Sets the public and private variables to values in the packet.

Parameters:

timeout is time in ms till function timeouts and quits. Default value is 100 ms.

Example:

```
state = sc.read_packet(); // reads a packet and returns whether success or fail to state
    // using default timeout time 100 ms
if(state) { // if success
    // do something with data
}
```

void packet\_destroy();

Destroys the current packet. Does so by setting all the public and private variables back to their initial values. Function must be called before reading another packet.

Example:

```
sc.read_packet();
// code to do something with data
sc.packet_destroy();
```

Private Functions:

bool validate\_checksum();

Validates the checksum. Calculated in the same way as in Mathematica (summing up all the bytes except the checksum itself). Returns true if checksum is the same as in the packet and returns false otherwise.

Public Variables:

int packet\_data[256];

Contains the arguments in the packet. The first index corresponds to the read/write type.

int packet\_size;

Contains the length of the arguments in the packet. Used to traverse the packet\_data array.

int packet\_id;

Contains the ID in the packet.

int packet\_instruc;

Contains the instruction in the packet. Determines whether request is read or write.

Serial pc;

Contains the serial connection. Can be used to output things through serial.

Private Variables:

int packet\_header;

Contains the header in the packet. Must be equal to 124 to be recognized as a packet.

Int packet\_length;

Contains the length of the packet. Calculated as the number of parameters + 2.

Int packet\_checksum;

Contains the checksum of the packet. Calculated in the same way as in Mathematica (summing up all the bytes except the checksum itself).

int packet\_mode;

Contains the current mode of the packet, which determines what is read next.

0 - ID

1 - Length

2 - Instruction

3 - Args

4 - Checksum

5 - Read complete

bool read\_mode;

Stores true if header is detected. False otherwise.

## 2.3 Usage

The general procedure for receiving a packet and using the data will now be discussed.

First, the user has to create an object of the Serial\_Communication class:

```
Serial_Communication sc(USBTX, USBRX, 115200);
```

Then, inside the while loop in the main function, the user has to call the read\_packet() function to receive a packet:

```
state = sc.read_packet();
```

The read\_packet() function will return true when read is successful:

```
if(state) { // do something with data }
```

How to read and interpret the data is up to the user. An example is shown in Appendix A.

After doing something to the data, always destroy the packet. This must be done before reading another packet:

```
sc.packet_destroy();
```



## Appendix A - mbed Serial\_Communication Class Example Usage

Serial\_Communication sc(USBTX, USBRX, 115200); // created Serial\_Communication object

```
int main() { // main function
    while(1) { // main while loop
        state = sc.read_packet(); // read packet with default timeout time 100 ms
        if(state) { // if read successful
            switch(sc.packet_instruc) {
                case 0: // instruction 0. Write
                    switch(sc.packet_data[0]) {
                        case 0: // 0. Default
                            sc.pc.printf("Please input an argument to the Write function.");
                            break;
                        case 1: // 1. Servo angles
                            for (int counter = 0; counter < sc.packet_size; ++counter) {
                                servos_list[counter].position((float)(sc.packet_data[counter + 1] - 90));
                            }
                            break;
                    }
                    break;
                case 1: // instruction 1. Read
                    switch(sc.packet_data[0]) {
                        case 1: // 1. Servo angles
                            sc.pc.printf("Nothing to see here.");
                            break;
                        case 2: // 2. Gyro
                            filt_compute(true);
                            sc.pc.printf("%f %f %f", gx, gy, gz);
                            break;
                        case 3: // 3. Accelerometer
                            filt_compute(true);
                            sc.pc.printf("%d %d %d", a[0], a[1], a[2]);
                            break;
                        case 4: // 4. Magnetometer
                            filt_compute(true);
                            sc.pc.printf("%d %d %d", m[0], m[1], m[2]);
                            break;
                    }
                    break;
            }
        }
        sc.packet_destroy();
    }
}
```