


Choosing an Engine

black queen

a6	Stockfish 7	<input type="checkbox"/> DEFAULT
b6	Texel 1.06	
c6	Arasan 20.0	
d6	Rodent II 0.9.66	
e6	Zurichess graubuenden	
f6	Floyd x7da0e241	
g6	Cinnamon 2.0-20160502	
h6	Galjoen v0.36	




Example: Arasan 20.0

Choosing a Level

black queen

a5	Level 0 (= weakest)	
b5	Level 3	
c5	Level 6	
d5	Level 9	
e5	Level 12	
f5	Level 15	
g5	Level 18	
h5	Level 20 (= strongest)	<input type="checkbox"/> DEFAULT




Example: Level 9

Choosing an Opening Book

black queen

a3	No book	
b3	ECO A: flank openings	
c3	ECO B: semiopen games	
d3	ECO C: open games + French	
e3	ECO D: closed games	
f3	ECO E: Indian games	
g3	Fun	
h3	Varied	<input type="checkbox"/> DEFAULT
a4	GM 1950	
b4	Performance	
c4	Stockfish	
d4	Anand	
e4	Korchnoi	
f4	Larsen	
g4	Pro	
h4	GM 2001	




Example: Opening Book 'Fun'


Choosing a Time Control

white queen

a6	Fixed: 1 s / move	
b6	3 s / move	
c6	5 s / move	
d6	10 s / move	
e6	15 s / move	
f6	30 s / move	
g6	60 s / move	
h6	90 s / move	
a4	Blitz: 1 min / game	
b4	3 min / game	
c4	5 min / game	DEFAULT
d4	10 min / game	
e4	15 min / game	
f4	30 min / game	
g4	60 min / game	
h4	90 min / game	
a3	Fischer: 1 min + 1 s / move	
b3	3 min + 2 s / move	
c3	4 min + 2 s / move	
d3	5 min + 3 s / move	
e3	10 min + 5 s / move	
f3	15 min + 10 s / move	
g3	30 min + 15 s / move	
h3	60 min + 30 s / move	



Example: Blitz 15 min / game




Example: Fischer 1 min + 1 s / move

Choosing a Play Mode

white queen

a5	Play against computer	DEFAULT
b5	Analysis mode	
c5	Kibitz mode	
d5	Observe mode	
e5	Remote mode	
f5	Ponder mode	




Example: Play against computer

Shut Down the Computer

white queen

In starting position,
replace the white king
with the spare white queen
to power off the computer.

Also works with empty board
and both white queens on
d1 and e1.




Example: Shut down computer

Reboot the Computer

black queen

In starting position,
replace the black king
with the spare black queen
to reboot the computer.

Also works with empty board
and both black queens on
d8 and e8.



Example: Reboot computer