


SWAT Data Viewer - User's Guide



Overview


The SWAT Data Viewer was developed to act as a virtual and open access data store for stakeholders and decision-makers to view and download SWAT model inputs and outputs for their area of interest. The app features various spatial and temporal data visualization interfaces (mainly in the form of maps and time-series plot). Unlike many of the SWAT related web applications, this application is completely modular meaning that it can be duplicated, customized and served from any server running the Tethys platform and can display the data from any valid SWAT model.

This tutorial will outline the various steps required to set up the app on your own server/computer.


User Instructions


1 Select a watershed/SWAT model to view

In the left navigation pane select a watershed from the “Select Watershed” dropdown menu

A screenshot of a web interface element titled "Select Watershed" in bold black text. Below the title is a dropdown menu with a white background and a thin grey border. The text "Lower Mekong" is visible inside the dropdown, and a small downward-pointing triangle is on the right side of the box.


After selecting a watershed, the map will automatically update to show the streams and subbasin layers for the selected watershed. You can then use the “Toggle Layers” buttons in the left navigation pane to show/hide different layers (depending on availability of those layers)

A screenshot of a web interface element titled "Toggle Layers" in bold black text. Below the title, there are three sections. The first section is "Basins" with a green toggle switch labeled "On". The second section is "Stations" with a green toggle switch labeled "On". The third section is "Supplementary Layers" with three buttons: "Land Use/Land Cover", "Soil", and "None". The "Land Use/Land Cover" button is highlighted in blue.






2 Select a stream or subbasin

- In the main map view, zoom to the stream or subbasin you are interested in and click on the feature




- Clicking on a map feature will automatically open a new window that can be used for data querying at the selected stream/subbasin



- i. You can zoom to a specific event by adjusting the time slider bar



that is located below the time series plot




4 Saving data queries to the Data Cart

- a. If you want to download the time series as a csv file, click the [Add Data to Cart](#) button to write the file to your “cart”.
 - i. When you are finished querying data, navigate to the “Data Cart” tab to download all the data you have added to the cart.



5 Compute land use/land cover and soil coverage percentages in the “{LULC/Soil} Data” tabs

- a. Clip the lulc/soil raster of the entire watershed to the upstream boundary of the selected stream/subbasin by clicking [Clip LULC Raster](#) / [Clip Soil Raster](#)





- b. Click the [Compute LULC Statistics](#) / [Compute Soil Statistics](#) button to compute the coverage percentages for each unique lulc/soil class within the upstream subbasin boundary.
 - i. Note: The lulc data is separated into classes and subclasses. The initial pie chart shows only the high level classes (i.e. agriculture, forest, etc.). You can “drill down” to see the subclass coverage percentages by clicking on the pie chart section of any of the classes. The first two images below show the class and subclass pie charts highlighting the different agricultural lulc types.



Land Cover Distribution



Land Cover Distribution



Soil Coverages



6 Run nasaaccess functions on subsetted watershed boundary

For more information on nasaaccess and the nasaaccess web application, see the “nasaaccess - User’s Guide” tutorial.

The SWAT Data Viewer provides a simple interface for calling the nasaaccess process for the selected upstream subbasin extent.

- a. Select a date range

Select Date Range

Start Date	to	End Date
------------	----	----------

- b. Select the nasaaccess functions that you want to run

Select NASAaccess Functions

Function	Information
<input type="checkbox"/> GLDAS Poly Centroid	Generate air temperature input files as well as air temperature stations file from NASA GLDAS remote sensing products.
<input type="checkbox"/> GLDAS SWAT	Generate SWAT air temperature input files as well as air temperature stations file from NASA GLDAS remote sensing products.
<input type="checkbox"/> GPM Poly Centroid	Generate rainfall input files as well as rain station file from NASA GPM remote sensing products.
<input type="checkbox"/> GPM SWAT	Generate SWAT rainfall input files as well as rain stations file from NASA GPM remote sensing products.

- c. Click [Run nasaaccess](#)
- d. Submit your email address
- Depending on the size of the boundary, date range, and the number of functions you select, the nasaaccess process may take some time. Your email will be used to notify you when your data is ready to download.
- e. Follow the link in the email and download your data from the nasaaccess web application

7 Download spatial and time-series data for further analysis

All of the spatial data that you’ve created during your session (upstream stream reaches, upstream subbasins, upstream lulc, and upstream soil files) and any of the time series queries that you elected to add to your cart were saved to your “Data Cart”.

a. Navigate to the “Data Cart” tab

[RCH Model Outputs](#) [Sub Model Outputs](#) [LULC Data](#) [Soil Data](#) [nasaaccess](#) **Data Cart**

Timeseries data available for download

Data Type	Parameters	Time Step	Start Date	End Date	Stream/Basin ID
rch	FLOW_OUTcms	Daily	01012001	12312015	183
sub	PETmm	Daily	01012009	07312010	183

Spatial data available for download

Data Type	File Type	Outlet Stream ID
reach_upstream	JSON	183
basin_upstream	JSON	183
lulc	TIFF	183
soil	TIFF	183

Download

CancelOK

b. Verify that all the data you want to download is listed there

c. Click

Download