

# Superboard II Quick Reference

## For the Briel Computers Superboard ///

Jeff Tranter <[tranter@pobox.com](mailto:tranter@pobox.com)>

29-Jan-2015

General Specifications	
<b>CPU</b>	65C02
<b>Clock Speed</b>	1 MHz
<b>RAM</b>	32 KB
<b>ROM</b>	10 KB
<b>Keyboard</b>	Integral 53-key
<b>Video</b>	Composite
<b>Power Input</b>	USB 5V host or power supply 1000mA or more
<b>Serial Port Settings</b>	9600 bps 8N1, no handshaking, no flow control

## Memory Map

Address Range	Comments
\$0000 - \$00FF	Zero page RAM.
\$0100 - \$01FF	Stack RAM.
\$0000 - \$7FFF	RAM (32K Superboard ///).
\$A000 - \$BFFF	ROM (BASIC).
\$D085 - \$D39D	Video memory (25x25 mode).
\$D080 - \$D3FF	Video memory (32x28 mode).
\$DF00	Keyboard (write row, read column). Decimal 57088.
\$F000	6850 ACIA status/control register. Decimal 61440.
\$F001	6850 ACIA data register. Decimal 61441.
\$F800-\$FFFF	ROM (OSI routines and monitor).

## ROM Monitor Commands

Display: AAAA DD

In address mode, enter 4 character hex address. In data mode, enter 2 character hex data.

"/" enters data mode.

"." enters address mode.

<Return> (in data mode) advances to next address.

"L" (in address mode) loads from cassette tape/serial port.

"G" (in address mode) starts execution from current address mode.

## Useful Routines

Address	Description
\$0006,\$0007	Address to call get argument of USR() function. Value is returned in \$00AE,F.
\$000D	Number of NULLs to send as per BASIC NULL command.
\$000F	BASIC terminal width.
\$0064	BASIC <Control>O flag.
\$00FB	ROM monitor load flag(non-zero=load mode).
\$00FC	ROM monitor contents of current address.
\$00FE,\$00FF	ROM monitor current address.
\$0100	NMI address.
\$01C0	IRQ address.
\$0200	Cursor position for BASIC output is \$D300 +(\$0200). Default (bottom left) is \$65.
\$0203	LOAD flag (\$80=load from tape).
\$0205	SAVE flag (0=not in save mode).
\$0212	BASIC <Control>C flag (non-zero=ignore <Control>C). Reset by RUN.
\$023E,\$023F	Address of BASIC USR() function.
\$A274	BASIC warm start.
\$BD11	BASIC cold start.
\$BF2D	Send character in A to terminal screen. Handles CR, LF, etc.
\$FCB1	Send character in A to ACIA.
\$FD00	Get key from keyboard and return in A.
\$FE00	ROM monitor entry point.
\$FE80	Get character from ACIA and return in A.
\$FF00	Reset address.
\$FFFA,\$FFFC	NMI vector.
\$FFFC,\$FFFD	Reset vector.
\$FFFE,\$FFFF	IRQ vector.

## Microsoft BASIC

Commands: CONT, LIST, NEW, NULL, RUN

Statements: CLEAR, DATA, DEF, DIM, END, FN, FOR, GOSUB, GOTO, IF, INPUT, LET, LOAD, NEXT, NOT, NULL, ON, OR, POKE, PRINT, READ, REM, RESTORE, RETURN, SAVE, STEP, STOP, THEN, TO, WAIT, ?

Functions: ABS(), ASC(), ATN(), CHR\$(), COS(), EXP(), FRE(), INT(), LEFT\$(), LEN(), LOG(), MID\$(), PEEK(), POS(), RIGHT\$(), RND(), SGN(), SIN(), SPC(), SQR(), STR\$, TAB(), TAN(), USR(), VAL()

Operators: +, -, \*, /, ^, NOT, AND, OR, =, <, >, <>, >=, <=

Editing:

<Shift>+O	Erase last character	<Shift>+P	Erase current line
<Control>+C	Interrupt running program or LIST command.	<Control>+O	Suspend output until ano

## Boot prompt:

```
D/C/W/M ?_  
| | | |  
| | | +--> ROM Monitor  
| | +-----> Warm start (does not clear any BASIC program)  
| +-----> Cold start (clears any BASIC program)  
+-----> Disk boot (requires disk controller)
```

Default video is 25 chars x 25 lines. Power on with BREAK key down to get 32 chars x 28 lines.

Serial Port protocol: 9600 bps, 8N1, no flow control or hardware handshaking. For BASIC, use 50ms char delay, 200ms line delay.