

PICLas Documentation

Institute for Aerodynamics and Gas Dynamics (IAG)
Institute for Space Systems (IRS)
University of Stuttgart, Germany

February 14, 2019

Contents

| | | |
|----------|---|-----------|
| 1 | Introduction | 4 |
| 1.1 | How this documentation is organized | 4 |
| 2 | Installation | 5 |
| 2.1 | Prerequisites | 5 |
| 2.2 | Obtaining the source | 6 |
| 2.3 | Compiling the code | 7 |
| 2.3.1 | Directory paths | 7 |
| 3 | Workflow | 8 |
| 3.1 | Mesh generation with HOPR | 8 |
| 3.2 | Compiler options | 8 |
| 3.3 | Solver settings | 9 |
| 3.4 | Setup of parameter file(s) | 10 |
| 3.5 | Simulation | 10 |
| 3.5.1 | Parallel execution | 11 |
| 3.6 | Post-processing | 11 |
| 4 | Features & Models | 12 |
| 4.1 | Particle Tracking | 12 |
| 4.1.1 | Linear | 12 |
| 4.1.2 | Curved | 12 |
| 4.2 | Boundary Conditions | 12 |
| 4.2.1 | Field | 12 |
| 4.2.2 | Particle | 12 |
| 4.3 | Particle Emission | 12 |
| 4.3.1 | Surface Flux | 12 |
| 4.4 | Particle in Cell | 13 |
| 4.5 | Direct Simulation Monte Carlo | 13 |
| 4.5.1 | Species Definition | 13 |
| 4.5.2 | Relaxation | 13 |
| 4.5.3 | Chemistry & Ionization | 13 |
| 4.5.4 | Surface Chemistry | 13 |
| 5 | Tools Overview | 14 |
| 5.1 | Visualization | 14 |
| 5.1.1 | h5piclas2vtk | 14 |

| | |
|---|-----------|
| 5.1.2 Paraview plugin | 15 |
| 6 Tutorials | 16 |
| 7 Installation guidelines | 17 |
| 7.1 Cloning and compiling at the HLRS | 17 |
| 7.1.1 HTTPS | 17 |
| 8 Parameter file options | 19 |
| References | 84 |

1 Introduction

PICLas is a three-dimensional simulation framework for Particle-in-Cell, Direct Simulation Monte Carlo and other particle methods that can be coupled for the simulation of collisional plasma flows. It features a high-order discontinuous Galerkin (DG) simulation module for the solution of the time-dependent Maxwell equations on unstructured hexahedral elements in three space dimensions. The code was specifically designed for very high order accurate simulations on massively parallel systems. It is licensed under GPLv3, written in Fortran and parallelized with MPI. Implemented features are

- Coupled Particle-in-Cell with Direct Simulation Monte Carlo methods
- Arbitrary order nodal polynomial tensor product basis using Gauss or Gauss Lobatto collocation points for electrostatic and electromagnetic solvers
- Matching high order curved mesh generation from external mesh formats (CGNS, GMSH) or simple analytic blocks via the open source preprocessor **HOPR**
- Non-conforming interfaces based on the mortar approach (electromagnetic solver)
- Non-reflecting boundary conditions via CFS-PMLs (electromagnetic solver)
- Automatic domain decomposition for parallel simulations based on a space filling curve
- High order low-storage explicit Runge-Kutta time integration
- I/O using the HDF5 library optimized for massively parallel jobs

1.1 How this documentation is organized

This user guide is organized to both guide the first steps as well as provide a complete overview of the simulation code's features from a user and a developer point of view.

- Chapter ?? contains step by step instructions from obtaining the source code up to running a first simulation and visualizing the simulation results. In addition, it provides an overview of the whole simulation framework and the currently implemented features.
- Chapter 3 outlines the workflow starting with mesh generation and concluding with the visualization of results produced with **PICLas**.
- Chapter 4 shall serve as a reference for the models and features implemented in **PICLas**.
- Chapter 5 lists tools within the **PICLas** repository, including the post-processing tools.
- Simulation tutorials are contained in Chapter 6.
- Additional installation guidelines for specific systems are given in Chapter 7.
- A complete list of all parameters is given in Chapter 8.

2 Installation

2.1 Prerequisites

PICLas has been tested for various Linux distributions. This includes Ubuntu 14.04 LTS, 16.04 LTS and 18.04 LTS, OpenSUSE 42.1 and CentOS 7. The suggested packages in this section can of course be replaced by self compiled versions.

The required packages for the Ubuntu Linux distributions are listed in table 2.1. Under Ubuntu, they can be obtained using the apt environment:

```
sudo apt-get install git
```

Table 2.1: Debian/Ubuntu packages. x: required, o: optional, -: not available

| Package | Ubuntu 14.04 | Ubuntu 16.04 | Ubuntu 18.04 |
|------------------|--------------|--------------|--------------|
| git | x | x | x |
| cmake | x | x | x |
| cmake-curses-gui | o | o | o |
| liblapack3 | x | x | x |
| liblapack-dev | x | x | x |
| gfortran | x | x | x |
| g++ | x | x | x |
| mpi-default-dev | x | x | x |
| zlib1g-dev | - | x | x |
| exuberant-ctags | o | o | o |

The required packages for OpenSUSE and CentOS are listed in table 2.2.

Under OpenSUSE, packages are installed by the following command.

```
sudo zypper install git
```

The PATH variable must be extended by the openmpi path

```
export PATH=$PATH:/usr/lib64/mpi/gcc/openmpi/bin
```

Under CentOS, packages are installed by the following command.

```
sudo yum install git
```

Additionally, the `PATH` variable must be extended by the `openmpi` path

```
export PATH=$PATH:/usr/lib64/openmpi/bin
```

Table 2.2: OpenSUSE/CentOS packages. x: required, o: optional, -: not available

| Package | OpenSUSE 42.1 | CentOS 7 |
|---------------|---------------|----------|
| git | x | x |
| cmake | x | x |
| lapack-devel | x | x |
| openmpi | x | x |
| openmpi-devel | x | x |
| zlib-devel | x | x |
| gcc-fortran | x | x |
| gcc | x | - |
| gcc-c++ | x | x |
| ctags-etags | - | o |

On some systems it may be necessary to increase the size of the stack (part of the memory used to store information about active subroutines) in order to execute **PICLas** correctly. This is done using the command

```
ulimit -s unlimited
```

from the command line. For convenience, you can add this line to your `.bashrc`.

2.2 Obtaining the source

The **PICLas** repository is available at GitHub. To obtain the most recent version you have two possibilities:

- Clone the **PICLas** repository from Github

```
git clone https://github.com/piclas-framework/piclas.git
```

- Download **PICLas** from Github:

```
wget https://github.com/piclas-framework/piclas/archive/
master.tar.gz
tar xzf master.tar.gz
```

Note that cloning **PICLas** from GitHub may not be possible on some machines, as e.g. the HLRS at the University of Stuttgart restricts internet access. Please refer to section 7.1 of

this user guide.

2.3 Compiling the code

- Open a terminal
- Change into the **PICLas** directory
- Create a new subdirectory and use CMake to configure and compile the code

```
mkdir build; cd build
cmake ../
make
```

For a list of all compiler options see Section 3.2. The executables **PICLas** and **h5piclas2vtk** are contained in your **PICLas** directory in `build/bin/`.

2.3.1 Directory paths

In the following, we write `$PICLASROOT` as a substitute for the path to the **PICLas** repository. Please replace `$PICLASROOT` in all following commands with the path to your **PICLas** repository or add an environment variable `$PICLASROOT`.

Furthermore, the path to executables is omitted in the following, so for example, we write `piclas` instead of `$PICLASROOT/build/bin/piclas`.

Here is some explanation for Linux beginners:

In order to execute a file, you have to enter the full path to it in the terminal. There are two different ways to enable typing `piclas` instead of the whole path (do not use both at the same time!)

1. You can add an alias for the path to your executable. Add a command of the form

```
alias piclas='$PICLASROOT/build/bin/piclas '
```

to the bottom of the file `~/.bashrc`. Source your `~/.bashrc` afterwards with

```
. ~/.bashrc
```

2. You can add the **PICLas** binary directory to your `$PATH` environment variable by adding

```
export PATH=$PATH:$PICLASROOT/build/bin
```

to the bottom of the file `~/.bashrc` and sourcing your `~/.bashrc` afterwards.

Now you are ready for the utilization of **PICLas**.

3 Workflow

In this chapter, the complete process of setting up a simulation in **PICLas** is detailed.

3.1 Mesh generation with HOPR

PICLas obtains its computational meshes solely from the high order preprocessor **HOPR** (available under GPLv3 at <https://www.hopr-project.org>) in HDF5 format. The design philosophy is that all tasks related to mesh organization, different input formats and the construction of high order geometrical mappings are separated from the *parallel* simulation code. These tasks are implemented most efficiently in a *serial* environment. The employed mesh format is designed to make the parallel read-in process as simple and fast as possible. For details concerning the mesh format please refer to the [HOPR HDF5 Curved Mesh Format Documentation](#). Installation instructions can be found [here](#).

Using **HOPR**, simple, structured meshes can be directly created using an [in-built mesh generator](#). A number of strategies to create curved boundaries are also included in HOPR. More complex geometries can be treated by importing meshes generated by external mesh generators in CGNS or GMSH format ([Example parameter file](#)).

The basic command for either mesh generation or conversion of an external mesh is

```
hopr hopr.ini
```

Note that the path to the **HOPR** executable is omitted in the command (see [2.3.1](#)).

3.2 Compiler options

This section describes the main configuration options which can be set when building **PICLas** using CMake. Some options are dependent on others being enabled (or disabled), so the available ones may change.

The first set of options describe general CMake behaviour:

- **CMAKE_BUILD_TYPE**: This statically specifies what build type (configuration) will be built in this build tree. Possible values are
 - Release: “Normal” execution.

- Profile: Performance profiling using gprof.
- Debug: Debug compiler for detailed error messages during code development.
- SANI: Sanitizer compiler for even more detailed error messages during code development.
- CMAKE_HOSTNAME: This will display the host name of the machine you are compiling on.
- CMAKE_INSTALL_PREFIX: If “make install” is invoked or INSTALL is built, this directory is prepended onto all install directories. This variable defaults to /usr/local on UNIX.

For some external libraries and programs that **PICLas** uses, the following options apply:

- CTAGS_PATH: This variable specifies the Ctags install directory, an optional program used to jump between tags in the source file.
- PICLAS_BUILD_HDF5: This will be set to ON if no prebuilt HDF5 installation was found on your machine. In this case a HDF5 version will be build and used instead.
- HDF5_DIR: If you want to use a prebuilt HDF5 library that has been build using the CMake system, this directory should contain the CMake configuration file for HDF5 (optional).

3.3 Solver settings

Before setting up a simulation, the code must be compiled with the desired parameters. The most important compiler options to be set are:

- PICLAS_TIMEDISCMETHOD: Module selection
 - DSMC: Direct Simulation Monte Carlo
 - RK4: Time integration method Runge-Kutta
- PICLAS_EQNSYSNAME: Equation system to be solved
 - maxwell:
 - poisson:
- PICLAS_POLYNOMIAL_DEGREE: Defines the polynomial degree of the solution. The order of convergence follows as $N + 1$. Each grid cell contains $(N + 1)^3$ collocation points to represent the solution.
- PICLAS_NODETYPE: The nodal collocation points used during the simulation
 - GAUSS:
 - GAUSS-LOBATTO:
- PICLAS_INTKIND8: Enables simulations with particle numbers above 2 147 483 647

The options EQNSYSNAME, POLYNOMIAL_DEGREE and NODETYPE can be ignored for a DSMC simulation. For parallel computation the following flags should be configured:

- PICLAS_MPI: Enabling parallel computation
- PICLAS_LOADBALANCE: Enable load-balancing

All other options are set in the parameter file.

3.4 Setup of parameter file(s)

The settings of the simulation are controlled through parameter files, which are given as arguments to the binary. In the case of PIC simulations the input of a single parameter file (e.g. *parameter.ini*) is sufficient, while the DSMC method requires the input of a species parameter file (e.g. *DSMCSpecies.ini*). The most recent list of parameters can be found by invoking the help in the console:

```
piclas --help
```

General parameters such the name of project (used for filenames) and the mesh file (as produced by HOPR) are:

```
ProjectName=TestCase  
MeshFile=test_mesh.h5
```

An overview of the parameters is also given in Chapter 8. The options and underlying models are discussed in Chapter 4. Due to the sheer number of parameters available, it is advisable to build upon an existing parameter file.

3.5 Simulation

After the mesh generation, compilation of the binary and setup of the parameter files, the code can be executed by

```
piclas parameter.ini [DSMCSpecies.ini]
```

The simulation may be restarted from an existing state file

```
piclas parameter.ini [DSMCSpecies.ini] [restart_file.h5]
```

Note: When restarting from an earlier time (or zero), all later state files possibly contained in your directory are deleted!

After a successful simulation, state files will be written out in the HDF5 format preceded by the project name, file type (e.g. State, DSMCState, DSMCSurfState) and the time stamp:

```
TestCase_State_001.5000000000000000.h5  
TestCase_DSMCState_001.5000000000000000.h5
```

3.5.1 Parallel execution

The simulation code is specifically designed for (massively) parallel execution using the MPI library. For parallel runs, the code must be compiled with `PICLAS_MPI=ON`. Parallel execution is then controlled using `mpirun`

```
mpirun -np [no. processors] piclas parameter.ini [DSMCSpecies.ini]  
[restart_file.h5]
```

The grid elements are organized along a space-filling curve, which gives a unique one-dimensional element list. In a parallel run, the mesh is simply divided into parts along the space filling curve. Thus, domain decomposition is done *fully automatic* and is not limited by e.g. an integer factor between the number of cores and elements. The only limitation is that the number of cores may not exceed the number of elements.

3.6 Post-processing

PICLas comes with a tool for visualization. The `h5piclas2vtk` tool converts the HDF5 files generated by **PICLas** to the binary VTK format, readable by many visualization tools like ParaView and VisIt. The tool is executed by

```
h5piclas2vtk [posti.ini] output.h5
```

Multiple HDF5 files can be passed to the `h5piclas2vtk` tool at once. The (optional) runtime parameters to be set in `posti.ini` are given in Section [5.1.1](#).

4 Features & Models

4.1 Particle Tracking

4.1.1 Linear

4.1.2 Curved

4.2 Boundary Conditions

4.2.1 Field

4.2.1.1 Dielectric

4.2.2 Particle

4.2.2.1 Specular/Reflective Wall

4.2.2.2 Porous Wall

The porous boundary condition uses a removal probability to determine whether a particle is deleted or reflected at the boundary.

4.3 Particle Emission

4.3.1 Surface Flux

4.3.1.1 Adaptive Boundaries

Multiple adaptive particle emission conditions can be defined.

4.4 Particle in Cell

4.5 Direct Simulation Monte Carlo

4.5.1 Species Definition

4.5.2 Relaxation

4.5.3 Chemistry & Ionization

4.5.4 Surface Chemistry

5 Tools Overview

This section gives an overview over the tools and scripts contained in the **PICLas** repository. It also provides references to the tutorials where their usage is explained.

5.1 Visualization

5.1.1 h5piclas2vtk

The h5piclas2vtk tool converts the HDF5 files generated by **PICLas** to the binary VTK format, readable by many visualization tools like ParaView and VisIt. The tool is executed by

```
h5piclas2vtk [posti.ini] output.h5
```

Multiple HDF5 files can be passed to the h5piclas2vtk tool at once. The (optional) runtime parameters to be set in posti.ini are given below:

| Option | Default | Description |
|------------------|---------|--|
| NVisu | 1 | Number of points at which solution is sampled for visualization |
| VisuParticles | OFF | Converts the particle data (positions, velocity, species, internal energies) |
| NodeTypeVisu | VISU | Node type of the visualization basis: VISU,GAUSS,GAUSS-LOBATTO,CHEBYSHEV-GAUSS-LOBATTO |
| CalcDiffError | F | Use first state file as reference state for L2 error calculation with the following state files |
| AllowChangedMesh | F | Neglect changes mesh, use inits of first mesh (ElemID must match!). |
| CalcDiffSigma | F | Use last state file as state for L2 sigma calculation. |
| CalcAverage | F | Calculate and write arithmetic mean of all StateFile. |
| VisuSource | F | Use DG_Source instead of DG_Solution. |
| NAnalyze | 2*N | Polynomial degree at which analysis is performed (e.g. for L2 errors, required for CalcDiffError). |

5.1.2 Paraview plugin

A ParaView reader based on `posti_visu` to load **PICLas** state files in ParaView. Provides the interface to adjust `posti_visu` parameters in the ParaView GUI. For this purpose the `libVisuReader.so` has to be loaded as a Plugin in ParaView.

6 Tutorials

This chapter will give a detailed overview of simulations with **PICLas**. It assumes that you are familiar with how to set the compiler options and how to compile the code. The paths to the executables are omitted. It is assumed that you either added aliases for **piclas**, **hopr** and **h5piclas2vtk**, or that you added the binary directories to your `$PATH` variable as described in [2.3.1](#).

Each tutorial is equipped with .ini files *parameter_hopr.ini*, *parameter_piclas.ini*, *parameter_posti.ini* (possibly *DSMCSpecies.ini*) as well as the mesh file **_mesh.h5* in the HDF5 format (created with **HOPR**).

```
parameter_hopr.ini
parameter_piclas.ini
DSMCSpecies.ini
parameter_posti.ini
mesh.h5
```

We suggest to copy each folder to a new directory, where you can run and modify the parameter files.

Available tutorials:

- Work in progress...

7 Installation guidelines

This chapter contains guidelines to install the code from Github on specific systems.

7.1 Cloning and compiling at the HLRS

Unfortunately, the GitHub server is not available on machines at the HLRS, such as the Hazelhen, due to restricted internet access. The workaround is to use ssh tunnels to access the GitHub repositories. Note that the reomte repositories hosted at teh GitLab at the Institute of Aerodynamics and Gasdynamics (IAG), no ssh tunnel is required and cloning works straight forwardly.

The following instructions to access the GitHub repositories on HLRS machines is taken from the HLRS wickie page, see https://wickie.hlrs.de/platforms/index.php/Secure_Shell_ssh#Git.

7.1.1 HTTPS

Unfortunately, just using a SSH tunnel as with the SSH and git protocols is not sufficient in this case. Instead, one has to connect via an additional SOCKS proxy on a machine that has unlimited access to the internet, e.g. your local machine.

In order to do so, establish a proxy by using a special feature of OpenSSH:

```
ssh -N -D 1080 localhost
```

This will establish some kind of a “loopback” SSH connection from your local machine to itself which will not execute any command (-N) but act as an SOCKS proxy on port 1080 (-D 1080).

On a second shell, now login to the desired HWW-system and forward a port on the remote machine (e.g. 7777) to the port on your local machine where the newly established SOCKS proxy is listening on (1080):

```
ssh -R 7777:localhost:1080 <system-name>.hww.de
```

By doing so, you have a SOCKS proxy listening on port 7777 of the HWW-system. Hence you can use this proxy for accessing remote git repositories. Unfortunately, the default versions of

git installed on the HWW-systems are not capable of doing this. You hence have to load an appropriate version first:

```
module load tools/git
```

In order to use the proxy, you can now add “-c https.proxy='socks5://localhost:7777' ” to your git commands, e.g.:

```
git -c https.proxy='socks5://localhost:7777' clone https://  
github.com/piclas-framework/piclas.git
```

In order to avoid typing this in every git call, you can also set the respective port to be used whenever git talks to a remote repository via HTTPS by

```
git config --global https.proxy 'socks5://localhost:7777'
```

Unfortunately, to connect with GitHub for pulling or pushing, the connection to Hazelhen has to be done via the ssh tunnel.

8 Parameter file options

A `parameter.ini` file is needed to control the code. An overview of all options in the parameter file can be generated by following command in the terminal:

```
piclas --help
```

Generally following types are used:

```
INTEGER = 1
REAL    = 1.23456
LOGICAL = T           ! True
LOGICAL =              ! False
STRING  = PICLAS
VECTOR  = (/1.0,2.0,3.0/)
```

The concept of the parameter file is described as followed:

- each single line is saved and examined for specific variable names
- the examination is case-insensitive
- comments can be set with symbol “!” in front of the text

```
! commented text
```

- numbers can also be set by using “pi”

```
vector = (/1,2Pi,3Pi/)
```

- the order of defined variables is with one exception generally indifferent, but it is preferable to group similar variables
- the order becomes important only by modifying boundary conditions, if you want to modify a specific boundary by addressing its name, the related boundary type has to be defined

```
BoundaryName=inflow           ! BC_Name defined in mesh file
BoundaryType=(/2,0,0,0/)
BoundaryName=outflow          ! BC_Name defined in mesh file
BoundaryType=(/2,0,0,0/)
```

The following tables describe the main configuration options which can be used in the parameter file.

MPI

| Variable | Default | Description |
|-----------|---------|--|
| GroupSize | 0 | Define size of MPI subgroups, used to e.g. perform grouped IO, where group master collects and outputs data. |

IO_HDF5

| Variable | Default | Description |
|---------------|---------|--|
| gatheredWrite | F | Set true to activate gathered HDF5 IO for parallel computations. Only local group masters will write data after gathering from local slaves. |

LoadBalance

| Variable | Default | Description |
|-------------------------|---------|--|
| DoLoadBalance | F | Set flag for doing dynamic LoadBalance. |
| LoadBalanceSample | 1 | Define number of iterations (before analyze_dt) that are used for calculation of elemtime information |
| PartWeightLoadBalance | F | Set flag for doing LoadBalance with partMPIWeight instead of elemtimes. Elemtime array in state file is filled with nParts*PartMPIWeight for each Elem. If Flag [TRUE] LoadBalanceSample is set to 0 and vice versa. |
| Load-DeviationThreshold | 0.10 | Define threshold for dynamic load-balancing. Restart performed if $(\text{Maxweight} - \text{Targetweight}) / \text{Targetweight} > \text{defined value}$. |

LoadBalance

| | | |
|--------------------------|------|--|
| Particles-MPIWeight | 0.02 | Define weight of particles for elem loads. (only used if ElemTime does not exist or DoLoadBalance=F). |
| WeightDistributionMethod | | Method for distributing the elem to procs. DEFAULT: 1 if Elemtime exists else -1 -1: elements are equally distributed 0: distribute to procs using elemloads 1: distribute to procs using elemloads, last proc receives least 2: NOT WORKING 3: TODO DEFINE 4: TODO DEFINE 5/6: iterative smoothing of loads towards last proc |

Interpolation

| Variable | Default | Description |
|----------|---------|---|
| N | | Polynomial degree of computation to represent to solution |

Restart

| Variable | Default | Description |
|----------------------|---------|---|
| DoInitialAutoRestart | F | Set Flag for doing automatic initial restart with loadbalancing routines after first 'InitialAutoRestartSample'- number of iterations. Restart is done if Imbalance > 'Load-DeviationThreshold'. |

Restart

| | | |
|--|---|--|
| InitialAutoRestartSample | | Define number of iterations at simulation start used for elemtime sampling before performing automatic initial restart. IF 0 than one iteration is sampled and statefile written has zero timeflag. DEFAULT: LoadBalanceSample. |
| InitialAutoRestart-PartWeightLoadBalance | F | Set flag for doing initial auto restart with partMPIWeight instead of elemtimes. Elemtime array in state file is filled with nParts*PartMPIWeight for each Elem. If Flag [TRUE] InitialAutoRestartSample is set to 0 and vice versa. |
| RestartNullifySolution | F | Set the DG solution to zero (ignore the DG solution in the state file) |

Output

| Variable | Default | Description |
|-------------------|---------|--|
| ProjectName | | Name of the current simulation (mandatory). |
| Logging | F | Write log files containing debug output. |
| WriteErrorFiles | T | Write error files containing error output. |
| OutputFormat | None | File format for visualization: None, Tecplot, TecplotASCII, ParaView. Note: Tecplot output is currently unavailable due to licensing issues. |
| ASCIIOutputFormat | CSV | File format for ASCII files, e.g. body forces: CSV, Tecplot. |
| doPrintStatusLine | F | Print: percentage of time, ... |

Output

| | | |
|-----------------|---|---|
| WriteStateFiles | T | Write HDF5 state files. Disable this only for debugging issues. NO SOLUTION WILL BE WRITTEN! |
|-----------------|---|---|

Piclas Initialization

| Variable | Default | Description |
|----------|---------|------------------------------------|
| UseDSMC | F | Flag for using DSMC in Calculation |
| UseLD | F | Flag for using LD in Calculation |

TimeDisc

| Variable | Default | Description |
|------------------|---------|---|
| TEnd | | End time of the simulation (mandatory). |
| CFLScale | | Scaling factor for the theoretical CFL number, typical range 0.1..1.0 (mandatory) |
| maxIter | -1 | Stop simulation when specified number of timesteps has been performed. |
| NCalcTimeStepMax | 1 | Compute dt at least after every Nth timestep. |
| IterDisplayStep | 1 | Step size of iteration that are displayed. |

Mesh

| Variable | Default | Description |
|-----------------|---------|--|
| DoSwapMesh | F | TODO-DEFINE-PARAMETER Flag to swap mesh for calculation. |
| SwapMeshExePath | | (relative) path to swap-meshfile (mandatory). |

| Mesh | | |
|-------------------------|-----|---|
| SwapMeshLevel | 0 | TODO-DEFINE-PARAMETER 0: initial grid 1: first swap mesh 2: second swap mesh |
| MeshFile | | (relative) path to meshfile (mandatory) (HALOWIKI:) usually located in directory of project.ini |
| useCurveds | T | Controls usage of high-order information in mesh. Turn off to discard high-order data and treat curved meshes as linear meshes. |
| DoWriteStateToHDF5 | T | Write state of calculation to hdf5-file. TODO-DEFINE-PARAMETER |
| interpolateFromTree | T | For non-conforming meshes, built by refinement from a tree structure, the metrics can be built from the tree geometry if it is contained in the mesh. Can improve free-stream preservation. |
| meshScale | 1.0 | Scale the mesh by this factor (shrink/enlarge). |
| meshdeform | F | Apply simple sine-shaped deformation on cartesian mesh (for testing). |
| CalcPoyntingVecIntegral | F | TODO-DEFINE-PARAMETER Calculate pointing vector integral only perpendicular to z axis |
| crossProductMetrics | F | Compute mesh metrics using cross product form. Caution: in this case free-stream preservation is only guaranteed for $N=3*N_{Geo}$. |

Mesh

| | | |
|--------------------|---|--|
| BoundaryName | | Names of boundary conditions to be set (must be present in the mesh!). For each BoundaryName a BoundaryType needs to be specified. |
| BoundaryType | | Type of boundary conditions to be set. Format: (BC_TYPE,BC_STATE) |
| writePartitionInfo | F | Write information about MPI partitions into a file. |

Equation

| Variable | Default | Description |
|---------------|---------------------|---|
| c0 | 1.0 | TODO-DEFINE-PARAMETER Velocity of light (in vacuum) |
| eps | 1.0 | TODO-DEFINE-PARAMETER Electric constant (vacuum permittivity) |
| mu | 1.0 | TODO-DEFINE-PARAMETER Magnetic constant (vacuum permeability = $4\pi E-7H/m$) |
| IniExactFunc | | TODO-DEFINE-PARAMETER Define exact function necessary for linear scalar advection |
| IniWavenumber | (/ 1.0, 1.0, 1.0 /) | TODO-DEFINE-PARAMETER |
| IniCenter | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| IniAmplitude | 0.1 | TODO-DEFINE-PARAMETER |
| IniHalfwidth | 0.1 | TODO-DEFINE-PARAMETER |
| ACfrequency | 0.0 | TODO-DEFINE-PARAMETER |
| ACamplitude | 0.0 | TODO-DEFINE-PARAMETER |

| Equation | | |
|-------------------|------|--|
| chitensWhichField | -1 | TODO-DEFINE-PARAMETER |
| chitensValue | -1.0 | TODO-DEFINE-PARAMETER |
| chitensRadius | -1.0 | TODO-DEFINE-PARAMETER |
| AlphaShape | 2 | TODO-DEFINE-PARAMETER |
| r_cutoff | 1.0 | TODO-DEFINE-PARAMETER Modified for curved and shape-function influence (<i>cdtSafetyFactor</i> + <i>r_cutoff</i>) |

| HDG | | |
|-------------------------|----------------|-----------------------|
| Variable | Default | Description |
| NonLinSolver | 1 | TODO-DEFINE-PARAMETER |
| NewtonExactSourceDeriv | F | TODO-DEFINE-PARAMETER |
| AdaptIterNewton | 0 | TODO-DEFINE-PARAMETER |
| NewtonAdaptStartValue | F | TODO-DEFINE-PARAMETER |
| AdaptIterNewtonToLinear | 100 | TODO-DEFINE-PARAMETER |
| RelaxFacNonlinear | 0.5 | TODO-DEFINE-PARAMETER |
| AdaptIterFixPoint | 10 | TODO-DEFINE-PARAMETER |
| MaxIterFixPoint | 10000 | TODO-DEFINE-PARAMETER |
| NormNonlinearDevLimit | 99999.0 | TODO-DEFINE-PARAMETER |
| EpsNonLinear | 0.10E-05 | TODO-DEFINE-PARAMETER |
| PrecondType | 2 | TODO-DEFINE-PARAMETER |
| epsCG | 0.10E-05 | TODO-DEFINE-PARAMETER |

HDG

| | | |
|-------------------------|-----|------------------------------------|
| useRelativeAbortCrit | F | TODO-DEFINE-PARAMETER |
| maxIterCG | 500 | TODO-DEFINE-PARAMETER |
| OnlyPostProc | F | TODO-DEFINE-PARAMETER |
| ExactLambda | F | TODO-DEFINE-PARAMETER |
| HDG_N | | TODO-DEFINE-PARAMETER Default: 2*N |
| HDG_MassOverintegration | F | TODO-DEFINE-PARAMETER |

Dielectric Region

| Variable | Default | Description |
|-----------------------------|------------------------------------|--|
| DoDielectric | F | Use dielectric regions with EpsR and MuR |
| DielectricFluxNonConserving | F | Use non-conservative fluxes at dielectric interfaces between adielectric region and vacuum |
| DielectricEpsR | 1.0 | Relative permittivity |
| DielectricMuR | 1.0 | Relative permeability |
| DielectricTestCase | default | Test cases, e.g., "FishEyeLens" or "FH_lens" |
| DielectricRmax | 1.0 | Radius parameter for functions |
| DielectricCheckRadius | F | Use additional parameter "DielectricRadiusValue" for checking if a DOF is within a dielectric region |
| DielectricRadiusValue | -1.0 | Additional parameter radius for checking if a DOF is within a dielectric region |
| xyzPhysicalMinMaxDielectric | (/ 0.0, 0.0, 0.0, 0.0, 0.0, 0.0 /) | [xmin, xmax, ymin, ymax, zmin, zmax] vector for defining a dielectric region by giving the bounding box coordinates of the PHYSICAL region |

Dielectric Region

| | | |
|---------------------|------------------------------------|--|
| xyzDielectricMinMax | (/ 0.0, 0.0, 0.0, 0.0, 0.0, 0.0 /) | [xmin, xmax, ymin, ymax, zmin, zmax] vector for defining a dielectric region by giving the bounding box coordinates of the DIELECTRIC region |
| Dielectric_E_0 | 1.0 | Electric field strength parameter for functions |

Filter

| Variable | Default | Description |
|-----------------|-----------------------|-----------------------|
| FilterType | 0 | TODO-DEFINE-PARAMETER |
| HestFilterParam | (/ 36.0, 12.0, 1.0 /) | TODO-DEFINE-PARAMETER |

Analyze

| Variable | Default | Description |
|------------------|---------|--|
| DoCalcErrorNorms | F | Set true to compute L2 and LInf error norms at analyze step. |
| Analyze_dt | 0.0 | Specifies time intervall at which analysis routines are called. |
| NAnalyze | | Polynomial degree at which analysis is performed (e.g. for L2 errors). Default: 2*N. |
| OutputTimeFixed | -1.0 | fixed time for writing state to .h5 |
| nSkipAnalyze | | (Skip Analyze-Dt) |
| CalcTimeAverage | | Flag if time averaging should be performed |
| VarNameAvg | | Count of time average variables |
| VarNameFluc | | Count of fluctuation variables |
| nSkipAvg | | Iter every which CalcTimeAverage is performed |

Analyze

| | | |
|-------------------------|---|---|
| Field-AnalyzeStep | 1 | Analyze is performed each Nth time step |
| CalcPotentialEnergy | F | Calculate Potential Energy. Output file is Database.csv |
| CalcPointsPerWavelength | F | Flag to compute the points per wavelength in each cell |

Analyzefield

| Variable | Default | Description |
|-----------------------|---------|--|
| PoyntingVecInt-Planes | 0 | Total number of Poynting vector integral planes for measuring the directed power flow (energy flux density: Density and direction of an electromagnetic field. |
| Plane-Tolerance | 0.1E-04 | Absolute tolerance for checking the Poynting vector integral plane coordinates and normal vectors of the corresponding sides for selecting relevant sides |
| Plane-[\$]-x-coord | 0.0 | TODO-DEFINE-PARAMETER |
| Plane-[\$]-y-coord | 0.0 | TODO-DEFINE-PARAMETER |
| Plane-[\$]-z-coord | 0.0 | TODO-DEFINE-PARAMETER |
| Plane-[\$]-factor | 1.0 | TODO-DEFINE-PARAMETER |
| PoyntingMainDir | | Direction in which the Poynting vector integral is to be measured. 1: x 2: y 3: z (default) |

RecordPoints

| Variable | Default | Description |
|----------|---------|--|
| RP_inUse | F | Set true to compute solution history at points defined in recordpoints file. |

RecordPoints

| | | |
|--------------|-------|---|
| RP_DefFile | | File containing element-local parametric recordpoint coordinates and structure. |
| RP_MaxMemory | 100.0 | Maximum memory in MiB to be used for storing recordpoint state history. If memory is exceeded before regular IO level states are written to file. |

Particle

| Variable | Default | Description |
|------------------------------|---------|---|
| Particles-ManualTimeStep | 0.0 | Manual timestep [sec] |
| Part-AdaptiveWeightingFactor | 0.001 | Weighting factor theta for weighting of average instantaneous values with those of previous iterations. |
| Particles-SurfaceModel | 0 | Define Model used for particle surface interaction. If >0 then look in section SurfaceModel. 0: Maxwell scattering 1: Kisliuk / Polanyi Wigner (currently not working) 2: Recombination model 3: adsorption/desorption + chemical interaction (SMCR with UBI-QEP, TST and TCE) 4: TODO 5: SEE-E and SEE-I (secondary e- emission due to e- or i+ bombardment) by Levko2015 for copper electrondes 6: SEE-E (secondary e- emission due to e- bombardment) by Pagonakis2016 for molybdenum (originally from Harrower1956) |
| Part-nSpecies | 1 | Number of species used in calculation |

| Particle | | |
|--------------------------------|------|---|
| Part-nMacroRestartFiles | 0 | Number of Restart files used for calculation |
| Part-MacroRestartFile[\$] | none | relative path to Restart file [\$] used for calculation |
| Part-DoInitialIonization | F | When restarting from a state, ionize the species to a specific degree |
| InitialIonizationSpecies | | Supply the number of species that are considered for automatic ionization |
| InitialIonizationSpeciesID | | Supply a vector with the species IDs that are used for the initial ionization. |
| InitialIonizationChargeAverage | | Average charge for each atom/molecule in the cell (corresponds to the ionization degree) |
| Part-MaxParticleNumber | 1 | Maximum number of Particles per proc (used for array init) |
| Particles-dt_part_ratio | 3.8 | TODO-DEFINE-PARAMETER Factors for td200/201 overrelaxation/subcycling |
| Particles-overrelax_factor | 1.0 | TODO-DEFINE-PARAMETER Factors for td200/201 overrelaxation/subcycling |
| Part-NumberOfRandomSeeds | 0 | Number of Seeds for Random Number GeneratorChoose nRandomSeeds = -1 Random = 0 Debugging-friendly with hard-coded deterministic numbers > 0 Debugging-friendly with numbers from ini. |
| Particles-RandomSeed[\$] | 1 | Seed [\$] for Random Number Generator |
| Particles-DoPoissonRounding | F | TODO-DEFINE-PARAMETER Flag to perform Poisson sampling instead of random rounding |

| Particle | | |
|-----------------------------|---------------------|--|
| Particles-DoTimeDepInflow | F | TODO-DEFINE-PARAMETER Insertion and SurfaceFlux with simple random rounding. Linearly ramping of inflow-number-of-particles is only possible with PoissonRounding or DoTimeDepInflow |
| Part-nPeriodicVectors | 0 | TODO-DEFINE-PARAMETER Number of the periodic vectors $j=1, \dots, n$. Value has to be the same as defined in preprog.ini |
| Part-PeriodicVector[\$] | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Vector for periodic boundaries.Has to be the same as defined in preproc.ini in their respective order. |
| Part-DelayTime | 0.0 | TODO-DEFINE-PARAMETER During delay time the particles, won't be moved so the EM field can be evolved |
| Particles-OutputVpiWarnings | F | TODO-DEFINE-PARAMETER Flag for warnings for rejected v if $VPI + PartDensity$ |
| Part-SafetyFactor | 1.0 | TODO-DEFINE-PARAMETER Factor to scale the halo region with MPI |
| Particles-HaloEpsVelo | 0.0 | TODO-DEFINE-PARAMETER Halo region radius |
| NbrOfRegions | 0 | TODO-DEFINE-PARAMETER Number of regions to be mapped to Elements |

| Particle | | |
|-----------------------------------|------------------------------------|---|
| RegionBounds[\$] | (/ 0.0, 0.0, 0.0, 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER RegionBounds ((xmin,xmax,ymin,...) 1:NbrOfRegions) |
| Part-RegionElectronRef[\$] | (/ 0.0, 0.0, 1.0 /) | rho_ref, phi_ref, and Te[eV] for Region# |
| Part-RegionElectronRef[\$]-PhiMax | | max. expected phi for Region# (linear approx. above! def.: phi_ref) |
| Part-LorentzType | 3 | TODO-DEFINE-PARAMETER Used Lorentz boost |
| PrintrandomSeeds | F | Flag defining if random seeds are written. |
| Particles-NumberOfRandomVectors | 100000 | Option defining how many random vectors are calculated |
| Part-DoFieldIonization | F | Do Field Ionization. Implemented models are: * Ammosov-Delone-Krainov (ADK) model |

| IMD | | |
|-----------------|----------------|--|
| Variable | Default | Description |
| IMDTimeScale | 0.1018E-13 | Time unit of input file. The default value is ~10.18 fs which comes from the unit system in IMD |
| IMDLengthScale | 0.10E-09 | Length unit scale used by IMD which is 1 angstrom |
| IMDAtomFile | no file found | IMD data file containing the atomic states for PartState(1:6) |
| IMDCutOff | no_cutoff | Atom cut-off parameter for reducing the number of imported IMD particles 1.) no_cutoff 2.) Epot 3.) coordinates 4.) velocity |
| IMDCutOffxValue | -999.9 | Cut-off coordinate for IMDCutOff='cooridantes' |
| IMDnSpecies | 1 | Count of IMD species |

IMD

| | | |
|--------------|---------------|--|
| IMDInputFile | no file found | Laser data file name containing PartState(1:6) |
|--------------|---------------|--|

VMPF

| Variable | Default | Description |
|-------------------------------|---------|---|
| Part-vMPF | F | TODO-DEFINE-PARAMETER Flag to use variable Macro Particle Factor. |
| Part-vMPFPartMerge | F | TODO-DEFINE-PARAMETER Enable Particle Merge routines. |
| Part-vMPFMergePolOrder | 2 | TODO-DEFINE-PARAMETER Polynomial degree for vMPF particle merge. |
| Part-vMPFCellSplitOrder | 15 | TODO-DEFINE-PARAMETER Order for cell splitting of variable MPF |
| Part-vMPFMergeParticleTarget | 0 | TODO-DEFINE-PARAMETER Count of particles wanted after merge. |
| Part-vMPFSplitParticleTarget | 0 | TODO-DEFINE-PARAMETER Number of particles wanted after split. |
| Part-vMPFMergeParticleIter | 100 | TODO-DEFINE-PARAMETER Number of iterations between particle merges. |
| Part-vMPFvelocityDistribution | OVDR | TODO-DEFINE-PARAMETER Velocity distribution for variable MPF. |
| Part-vMPFrelativistic | F | TODO-DEFINE-PARAMETER |

Particle Sampling

| Variable | Default | Description |
|----------|---------|-------------|
|----------|---------|-------------|

Particle Sampling

| | | |
|------------------------------|---|---|
| Part-WriteMacroValues | F | Set [T] to activate ITERATION DEPENDANT h5 output of macroscopic values sampled every [Part-IterationForMacroVal] iterations from particles. Sampling starts from simulation start. Can not be enabled together with Part-TimeFracForSampling. (HALOWIKI:)Write macro values (e.g. rotational Temperature). |
| Part-WriteMacroVolumeValues | F | Similar to Part-WriteMacroValues. Set [T] to activate iteration dependant sampling and h5 output for each element. Is automatically set true if Part-WriteMacroValues is true. Can not be enabled if Part-TimeFracForSampling is set. |
| Part-WriteMacroSurfaceValues | F | Similar to Part-WriteMacroValues. Set [T] to activate iteration dependant sampling and h5 output on surfaces. Is automatically set true if Part-WriteMacroValues is true. Can not be enbaled if Part-TimeFracForSampling is set. |
| Part-IterationForMacroVal | 1 | Set number of iterations used for sampling if Part-WriteMacroValues is set true. |

Particle Sampling

| | | |
|--------------------------------|---------------------|--|
| Part-TimeFracForSampling | 0.0 | Set value greater 0.0 to enable TIME DEPENDANT sampling. The given simulation time fraction will be sampled. Sampling starts after $T_{End} * (1 - \text{Part-TimeFracForSampling})$. Can not be enabled together with Part-WriteMacroValues. |
| Particles-NumberForDSMCOutputs | 0 | Give the number of outputs for time fraction sampling. Default value is 1 if Part-TimeFracForSampling is enabled. |
| Particles-DSMC-CalcSurfaceVal | F | Set [T] to activate sampling, analyze and h5 output for surfaces. Therefore either time fraction or iteration sampling have to be enabled as well. |
| DSMC-HOSampling-Type | cell_mean | TODO-DEFINE-PARAMETER |
| Particles-DSMC-OutputOrder | 1 | TODO-DEFINE-PARAMETER |
| DSMC-HOSampling-NodeType | visu | TODO-DEFINE-PARAMETER |
| DSMCSampVolWe-BGMdeltas | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| DSMCSampVolWe-FactorBGM | (/ 1.0, 1.0, 1.0 /) | TODO-DEFINE-PARAMETER |
| DSMCSampVolWe-VolIntOrd | 50 | TODO-DEFINE-PARAMETER |
| DSMC-nSurfSample | 1 | Define polynomial degree of particle BC sampling. Default: NGeo |

Particle SurfCollis

| Variable | Default | Description |
|----------|---------|-------------|
|----------|---------|-------------|

Particle SurfCollis

| | | |
|---|---|---|
| Particles- CalcSurfCollis_OnlySwaps | F | TODO-DEFINE- PARAMETER Count only wall collisions being SpeciesSwaps |
| Particles- CalcSurfCollis_Only0Swaps | F | TODO-DEFINE- PARAMETER Count only wall collisions being delete-SpeciesSwaps |
| Particles-CalcSurfCollis_Output | F | TODO-DEFINE- PARAMETER Print sums of all counted wall collisions |
| Particles-AnalyzeSurfCollis | F | TODO-DEFINE- PARAMETER Output of collided/swaped particles during Sampling period? |
| Particles-DSMC- maxSurfCollisNumber | 0 | TODO-DEFINE- PARAMETER Max. number of collided/swaped particles during Sampling |
| Particles-DSMC-NumberOfBCs | 1 | TODO-DEFINE- PARAMETER Count of BC to be analyzed |
| Particles-DSMC-SurfCollisBC | | BCs to be analyzed (def.: 0 = all) |
| Particles- CalcSurfCollis_NbrOfSpecies | 0 | TODO-DEFINE- PARAMETER Count of Species for wall collisions (0: all) |
| Particles-CalcSurfCollis_Species | | TODO-DEFINE- PARAMETER Help array for reading surface stuff |
| Part-WriteFieldsToVTK | F | TODO-DEFINE- PARAMETER Not in Code anymore, but read-in has to be deleted in particle_init.f90 |
| Part-ConstPressAddParts | T | TODO-DEFINE- PARAMETER |
| Part-ConstPressRemParts | F | TODO-DEFINE- PARAMETER |

Particle Species

| Variable | Default | Description |
|--------------------------------------|----------------|--|
| Part-Species[\$]-nInits | 0 | Number of different initial particle placements for Species [\$] |
| Part-Species[\$]-Reset | F | Flag for resetting species distribution with init during restart |
| Part-Species[\$]-ChargeIC | 0.0 | [TODO-DEFINE-PARAMETER] Particle Charge (without MPF) of species[\$] dim |
| Part-Species[\$]-MassIC | 0.0 | Particle Mass (without MPF) of species [\$] [kg] |
| Part-Species[\$]-MacroParticleFactor | 1.0 | Number of Microparticle per Macroparticle for species [\$] |
| Part-Species[\$]-IsImplicit | F | TODO-DEFINE-PARAMETER Flag if specific particle is implicit |
| Part-Species[\$]-UseForInit | T | Flag to use species[\$] for initialization. |
| Part-Species[\$]-UseForEmission | T | Use species[\$] for volume emission. (set EmissionType) |
| Part-Species[\$]-SpaceIC | cuboid | Specifying Keyword for particle space condition of species [\$] in case of one init. - point - line_with_equidistant_distribution - line - disc - gyrotron_circle - circle_equidistant - cuboid - cylinder - cuboid_vpi - cylinder_vpi - LD_insert - cell_local - cuboid_equal - cuboid_with_equidistant_distribution - sin_deviation - IMD |

Particle Species

| | | |
|--|---------------------|--|
| Part-Species[\$]-velocityDistribution | constant | Used velocity distribution. constant: all particles have the same defined velocity.(VelolC, VeloVec) maxwell: sampled from maxwell distribution.(for MWTemperatureIC) maxwell_lpn: maxwell with low particle number (better maxwell dist. approx. for lpn). |
| Part-Species[\$]-rotation | 1 | TODO-DEFINE-PARAMETER Direction of rotation, similar to TE-mode |
| Part-Species[\$]-velocityspread | 0.0 | TODO-DEFINE-PARAMETER Velocity spread in percent |
| Part-Species[\$]-velocityspreadmethod | 0 | TODO-DEFINE-PARAMETER Method to compute the velocity spread |
| Part-Species[\$]-InflowRiseTime | 0.0 | TODO-DEFINE-PARAMETER Time to ramp the number of inflow particles,linearly from zero to unity |
| Part-Species[\$]-initialParticleNumber | 0 | TODO-DEFINE-PARAMETER Initial particle number |
| Part-Species[\$]-RadiusIC | 1.0 | TODO-DEFINE-PARAMETER Radius for IC circle |
| Part-Species[\$]-Radius2IC | 0.0 | TODO-DEFINE-PARAMETER Radius for IC cylinder (ring) |
| Part-Species[\$]-RadiusICGyro | 1.0 | TODO-DEFINE-PARAMETER Gyrotron radius |
| Part-Species[\$]-NormalIC | (/ 0.0, 0.0, 1.0 /) | TODO-DEFINE-PARAMETER Normal orientation of circle. |

Particle Species

| | | |
|--------------------------------------|---------------------|--|
| Part-Species[\$]-BasePointIC | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Base point for IC cuboid and IC sphere |
| Part-Species[\$]-BaseVector1IC | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER First base vector for IC cuboid |
| Part-Species[\$]-BaseVector2IC | (/ 0.0, 1.0, 0.0 /) | TODO-DEFINE-PARAMETER Second base vector for IC cuboid |
| Part-Species[\$]-CuboidHeightIC | 1.0 | TODO-DEFINE-PARAMETER Height of cuboid if SpacelC=cuboid |
| Part-Species[\$]-CylinderHeightIC | 1.0 | TODO-DEFINE-PARAMETER Height of cylinder if SpacelC=cylinder |
| Part-Species[\$]-CalcHeightFromDt | F | TODO-DEFINE-PARAMETER Calculated cuboid/cylinder height from v and dt? |
| Part-Species[\$]-VeloIC | 0.0 | Absolute value of initial velocity. (ensemble velocity) |
| Part-Species[\$]-VeloVecIC | (/ 0.0, 0.0, 0.0 /) | Normalized velocity vector for given VeloIC |
| Part-Species[\$]-Amplitude | 0.01 | TODO-DEFINE-PARAMETER Amplitude for sin-deviation |
| Part-Species[\$]-WaveNumber | 2.0 | TODO-DEFINE-PARAMETER Wave number for sin-deviation |
| Part-Species[\$]-maxParticleNumber-x | 0 | TODO-DEFINE-PARAMETER MaximumNumber of all particles in x-direction |
| Part-Species[\$]-maxParticleNumber-y | 0 | TODO-DEFINE-PARAMETER MaximumNumber of all particles in y-direction |
| Part-Species[\$]-maxParticleNumber-z | 0 | TODO-DEFINE-PARAMETER MaximumNumber of all particles in z-direction |

| Particle Species | | |
|--|------|---|
| Part-Species[\$]-Alpha | 0.0 | TODO-DEFINE-PARAMETER Factor for normal speed in gyrotron simulations. |
| Part-Species[\$]-MWTemperatureIC | 0.0 | Initial translational temperature for Maxwell distribution initialization. |
| Part-Species[\$]-ConstantPressure | 0.0 | TODO-DEFINE-PARAMETER Pressure for an area with constant pressure |
| Part-Species[\$]-ConstPressureRelaxFac | 1.0 | TODO-DEFINE-PARAMETER Relaxation Factor for constant pressure sampling. |
| Part-Species[\$]-PartDensity | 0.0 | Define particle density for species [\$]. PartDensity (real particles per m ³). Used for DSMC with (vpi_)cuboid/cylinder and cell_local initial inserting. Also for LD_insert or (vpi_)cub./cyl. / cell_local as alternative to Part.Emis. in Type1 |
| Part-Species[\$]-ParticleEmissionType | 2 | Define Emission Type for particles (volume emission) 1 = emission rate in part/s, 2 = emission rate part/iteration 3 = user def. emission rate 4 = const. cell pressure 5 = cell pres. w. complete part removal 6 = outflow BC (characteristics method) |
| Part-Species[\$]-ParticleEmission | 0.0 | Emission rate in part/s or part/iteration. |
| Part-Species[\$]-NSigma | 10.0 | TODO-DEFINE-PARAMETER Sigma multiple of maxwell for virtual insert length. |

Particle Species

| | | |
|--|-------------------------|---|
| Part-Species[\$]- NumberOfExcludeRegions | 0 | TODO-DEFINE- PARAMETER Number of different regions to be excluded |
| Part-Species[\$]-MJxRatio | 0.0 | TODO-DEFINE- PARAMETER x direction portion of velocity for Maxwell-Juettner |
| Part-Species[\$]-MJyRatio | 0.0 | TODO-DEFINE- PARAMETER y direction portion of velocity for Maxwell-Juettner |
| Part-Species[\$]-MJzRatio | 0.0 | TODO-DEFINE- PARAMETER z direction portion of velocity for Maxwell-Juettner |
| Part-Species[\$]-WeibelVeloPar | 0.0 | TODO-DEFINE- PARAMETER Parallel velocity component for Weibel |
| Part-Species[\$]-WeibelVeloPer | 0.0 | TODO-DEFINE- PARAMETER Perpendicular velocity component for Weibel |
| Part-Species[\$]- OneDTwoStreamVelo | 0.0 | TODO-DEFINE- PARAMETER Stream Velocity for the Two Stream Instability |
| Part-Species[\$]- OneDTwoStreamTransRatio | 0.0 | TODO-DEFINE- PARAMETER Ratio between perpendicular and parallel velocity |
| Part-Species[\$]-vpiDomainType | perpendicular_extrusion | TODO-DEFINE- PARAMETER Specifying Keyword for virtual Pre-Inserting region implemented: - perpendicular_extrusion (default) - freestream - orifice - ... more following... |

Particle Species

| | | |
|--|---|--|
| Part-Species[\$]-vpiBV1BufferNeg | T | TODO-DEFINE-PARAMETER incl. buffer region in -BV1 direction? |
| Part-Species[\$]-vpiBV1BufferPos | T | TODO-DEFINE-PARAMETER incl. buffer region in +BV1 direction? |
| Part-Species[\$]-vpiBV2BufferNeg | T | TODO-DEFINE-PARAMETER incl. buffer region in -BV2 direction? |
| Part-Species[\$]-vpiBV2BufferPos | T | TODO-DEFINE-PARAMETER incl. buffer region in +BV2 direction? |
| Part-Species[\$]-IsIMDSpecies | F | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-MacroRestartFileID | 0 | Define File ID of file used for Elem specific cell_local init of all macroscopic values |
| Part-Species[\$]-ElemTemperatureFileID | | Define File ID of file used for Elem specific cell_local init of translational temperature. (x,y,z are used from State) DEFAULT: MacroRestartFileID |
| Part-Species[\$]-ElemPartDensityFileID | | Define File ID of file used for Elem specific cell_local init of number density. DEFAULT: MacroRestartFileID |
| Part-Species[\$]-ElemVelocityICFileID | | Define File ID of file used for Elem specific cell_local init of drift velocity. (x,y,z are used from State) DEFAULT: MacroRestartFileID |
| Part-Species[\$]-ElemTVibFileID | | Define File ID of file used for Elem specific cell_local init of vibrational temperature. DEFAULT: MacroRestartFileID only used if DSMC + collismode>1 |

Particle Species

| | |
|----------------------------------|---|
| Part-Species[\$]-ElemTRotFileID | Define File ID of file used for Elem specific cell_local init of rotational temperature. DEFAULT: MacroRestartFileID only used if DSMC + collismode>1 |
| Part-Species[\$]-ElemTElecFileID | Define File ID of file used for Elem specific cell_local init of electronic temperature. DEFAULT: MacroRestartFileID only used if DSMC + collismode>1 + electronicmodel |

Particle Species Ninit

| Variable | Default | Description |
|--|----------|---|
| Part-Species[\$]-Init[\$]-UseForInit | T | TODO-DEFINE-PARAMETER Flag to use Init/Emission for init |
| Part-Species[\$]-Init[\$]-UseForEmission | F | TODO-DEFINE-PARAMETER Flag to use Init/Emission for emission |
| Part-Species[\$]-Init[\$]-SpaceIC | cuboid | Specifying Keyword for particle space condition of species [\$] in case of multiple inits |
| Part-Species[\$]-Init[\$]-velocityDistribution | constant | TODO-DEFINE-PARAMETER Specifying keyword for velocity distribution |
| Part-Species[\$]-Init[\$]-rotation | 1 | TODO-DEFINE-PARAMETER Direction of rotation, similar to TE-mode |
| Part-Species[\$]-Init[\$]-velocityspread | 0.0 | TODO-DEFINE-PARAMETER Velocity spread in percent |
| Part-Species[\$]-Init[\$]-velocityspreadmethod | 0 | TODO-DEFINE-PARAMETER Method to compute the velocity spread |

Particle Species Ninit

| | | |
|---|---------------------|---|
| Part-Species[\$]-Init[\$]-InflowRiseTime | 0.0 | TODO-DEFINE-PARAMETER Time to ramp the number of inflow particles linearly from zero to unity |
| Part-Species[\$]-Init[\$]-initialParticleNumber | 0 | TODO-DEFINE-PARAMETER Number of Particles at time 0.0 |
| Part-Species[\$]-Init[\$]-RadiusIC | 1.0 | TODO-DEFINE-PARAMETER Radius for IC circle |
| Part-Species[\$]-Init[\$]-Radius2IC | 0.0 | TODO-DEFINE-PARAMETER Radius2 for IC cylinder (ring) |
| Part-Species[\$]-Init[\$]-RadiusICGyro | 1.0 | TODO-DEFINE-PARAMETER Radius for Gyrotron gyro radius |
| Part-Species[\$]-Init[\$]-NormalIC | (/ 0.0, 0.0, 1.0 /) | TODO-DEFINE-PARAMETER Normal / Orientation of circle |
| Part-Species[\$]-Init[\$]-BasePointIC | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Base point for IC cuboid and IC sphere |
| Part-Species[\$]-Init[\$]-BaseVector1IC | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER First base vector for IC cuboid |
| Part-Species[\$]-Init[\$]-BaseVector2IC | (/ 0.0, 1.0, 0.0 /) | TODO-DEFINE-PARAMETER Second base vector for IC cuboid |
| Part-Species[\$]-Init[\$]-CuboidHeightIC | 1.0 | TODO-DEFINE-PARAMETER Height of cuboid if SpacelC = cuboid. (set 0 for flat rectangle), negative value = opposite direction |
| Part-Species[\$]-Init[\$]-CylinderHeightIC | 1.0 | TODO-DEFINE-PARAMETER Third measure of cylinder (set 0 for flat rectangle), negative value = opposite direction |

Particle Species Ninit

| | | |
|---|---------------------|---|
| Part-Species[\$]-Init[\$]-CalcHeightFromDt | F | TODO-DEFINE-PARAMETER Calculate cuboid/cylinder height from v and dt? |
| Part-Species[\$]-Init[\$]-VeloIC | 0.0 | TODO-DEFINE-PARAMETER Velocity for initial Data |
| Part-Species[\$]-Init[\$]-VeloVecIC | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Normalized velocity vector |
| Part-Species[\$]-Init[\$]-Amplitude | 0.01 | TODO-DEFINE-PARAMETER Amplitude for sin-deviation initiation. |
| Part-Species[\$]-Init[\$]-WaveNumber | 2.0 | TODO-DEFINE-PARAMETER WaveNumber for sin-deviation initiation |
| Part-Species[\$]-Init[\$]-maxParticleNumber-x | 0 | TODO-DEFINE-PARAMETER Maximum Number of all Particles in x direction |
| Part-Species[\$]-Init[\$]-maxParticleNumber-y | 0 | TODO-DEFINE-PARAMETER Maximum Number of all Particles in y direction |
| Part-Species[\$]-Init[\$]-maxParticleNumber-z | 0 | TODO-DEFINE-PARAMETER Maximum Number of all Particles in z direction |
| Part-Species[\$]-Init[\$]-Alpha | 0.0 | TODO-DEFINE-PARAMETER WaveNumber for sin-deviation initiation. |
| Part-Species[\$]-Init[\$]-MWTemperatureIC | 0.0 | TODO-DEFINE-PARAMETER Temperature for Maxwell Distribution |
| Part-Species[\$]-Init[\$]-ConstantPressure | 0.0 | TODO-DEFINE-PARAMETER Pressure for an Area with a Constant Pressure |
| Part-Species[\$]-Init[\$]-ConstPressureRelaxFac | 1.0 | TODO-DEFINE-PARAMETER Relaxation Factor for constant pressure sampling. |

Particle Species Ninit

| | | |
|--|------|---|
| Part-Species[\$]-Init[\$]-PartDensity | 0.0 | TODO-DEFINE- PARAMETER PartDensity (real particles per m ³) for LD_insert or (vpi_)cub./cyl. as alternative to Part.Emis. in Type1 |
| Part-Species[\$]-Init[\$]- ParticleEmissionType | 2 | TODO-DEFINE- PARAMETER Emission Type 1 = emission rate in 1/s, 2 = emission rate 1/iteration 3 = user def. emission rate 4 = const. cell pressure 5 = cell pres. w. complete part removal 6 = outflow BC (characteristics method) |
| Part-Species[\$]-Init[\$]- ParticleEmission | 0.0 | TODO-DEFINE- PARAMETER Emission in [1/s] or [1/Iteration] |
| Part-Species[\$]-Init[\$]-NSigma | 10.0 | TODO-DEFINE- PARAMETER Sigma multiple of maxwell for virtual insert length |
| Part-Species[\$]-Init[\$]- NumberOfExcludeRegions | 0 | TODO-DEFINE- PARAMETER Number of different regions to be excluded |
| Part-Species[\$]-Init[\$]-MJxRatio | 0.0 | TODO-DEFINE- PARAMETER x direction portion of velocity for Maxwell-Juettner |
| Part-Species[\$]-Init[\$]-MJyRatio | 0.0 | TODO-DEFINE- PARAMETER y direction portion of velocity for Maxwell-Juettner |
| Part-Species[\$]-Init[\$]-MJzRatio | 0.0 | TODO-DEFINE- PARAMETER z direction portion of velocity for Maxwell-Juettner |
| Part-Species[\$]-Init[\$]- WeibelVeloPar | 0.0 | TODO-DEFINE- PARAMETER Parallel velocity component for Weibel |

Particle Species Ninit

| | | |
|---|-------------------------|---|
| Part-Species[\$]-Init[\$]- WeibelVeloPer | 0.0 | TODO-DEFINE- PARAMETER Perpendicular velocity component for Weibel |
| Part-Species[\$]-Init[\$]- OneDTwoStreamVelo | 0.0 | TODO-DEFINE- PARAMETER Stream Velocity for the Two Stream Instability |
| Part-Species[\$]-Init[\$]- OneDTwoStreamTransRatio | 0.0 | TODO-DEFINE- PARAMETER Ratio between perpendicular and parallel velocity |
| Part-Species[\$]-Init[\$]- vpiDomainType | perpendicular_extrusion | TODO-DEFINE- PARAMETER Specifying Keyword for virtual Pre-Inserting region implemented: - perpendicular_extrusion (default) - freestream - orifice - ... more following... |
| Part-Species[\$]-Init[\$]- vpiBV1BufferNeg | T | TODO-DEFINE- PARAMETER incl. buffer region in -BV1 direction? |
| Part-Species[\$]-Init[\$]- vpiBV1BufferPos | T | TODO-DEFINE- PARAMETER incl. buffer region in +BV1 direction? |
| Part-Species[\$]-Init[\$]- vpiBV2BufferNeg | T | TODO-DEFINE- PARAMETER incl. buffer region in -BV2 direction? |
| Part-Species[\$]-Init[\$]- vpiBV2BufferPos | T | TODO-DEFINE- PARAMETER incl. buffer region in +BV2 direction? |
| Part-Species[\$]-Init[\$]- MacroRestartFileID | 0 | Define File ID of file used for Elem specific cell_local init of all macroscopic values |
| Part-Species[\$]-Init[\$]- ElemTemperatureFileID | | Define File ID of file used for Elem specific cell_local init of translational temperature. (x,y,z are used from State) DEFAULT: MacroRestartFileID |

Particle Species Ninit

| | |
|---|---|
| Part-Species[\$]-Init[\$]- ElemPartDensityFileID | Define File ID of file used for Elem specific cell_local init of number density. DEFAULT: MacroRestartFileID |
| Part-Species[\$]-Init[\$]- ElemVelocityICFileID | Define File ID of file used for Elem specific cell_local init of drift velocity. (x,y,z are used from State) DEFAULT: MacroRestartFileID |
| Part-Species[\$]-Init[\$]- ElemTVibFileID | Define File ID of file used for Elem specific cell_local init of vibrational temperature. DEFAULT: MacroRestartFileID only used if DSMC + collismode>1 |
| Part-Species[\$]-Init[\$]- ElemTRotFileID | Define File ID of file used for Elem specific cell_local init of rotational temperature. DEFAULT: MacroRestartFileID only used if DSMC + collismode>1 |
| Part-Species[\$]-Init[\$]- ElemTElecFileID | Define File ID of file used for Elem specific cell_local init of electronic temperature. DEFAULT: MacroRestartFileID only used if DSMC + collismode>1 + electronicmodel |

**Particle Species Init
RegionExcludes**

| Variable | Default | Description |
|--|---------|---|
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-SpaceIC | cuboid | TODO-DEFINE- PARAMETER Specified keyword for excluded particle space condition of species[\$] in case of multiple inits |
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-RadiusIC | 1.0 | TODO-DEFINE- PARAMETER Radius for excluded IC circle |

| Particle Species Init RegionExcludes | | |
|--|---------------------|---|
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-Radius2IC | 0.0 | TODO-DEFINE- PARAMETER Radius2 for excluded IC cylinder (ring) |
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-NormalIC | (/ 0.0, 0.0, 1.0 /) | TODO-DEFINE- PARAMETER Normal orientation of excluded circle |
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-BasePointIC | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE- PARAMETER Base point for excluded IC cuboid and IC sphere |
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-BaseVector1IC | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE- PARAMETER First base vector for excluded IC cuboid |
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-BaseVector2IC | (/ 0.0, 1.0, 0.0 /) | TODO-DEFINE- PARAMETER Second base vector for excluded IC cuboid |
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]-CuboidHeightIC | 1.0 | TODO-DEFINE- PARAMETER Height of excluded cuboid, if Part-Species[\$]-Init[\$]- ExcludeRegion[\$]- SpaceIC=cuboid (set 0 for flat rectangle), negative value = opposite direction |
| Part-Species[\$]-Init[\$]- ExcludeRegion[\$]- CylinderHeightIC | 1.0 | TODO-DEFINE- PARAMETER Height of excluded cylinder, if Part-Species[\$]-Init[\$]- ExcludeRegion[\$]- SpaceIC=cylinder (set 0 for flat circle), negative value = opposite direction |

Particle Boundaries

| Variable | Default | Description |
|-----------------|----------------|---|
| Part-nBounds | 1 | TODO-DEFINE- PARAMETER Number of particle boundaries. |

| Particle Boundaries | | |
|---------------------------------------|------|---|
| Part-Boundary[\$]-NbrOfSpeciesSwaps | 0 | TODO-DEFINE-PARAMETER Number of Species to be changed at wall. |
| Part-Boundary[\$]-Condition | open | <p>TODO-DEFINE-PARAMETER Used boundary condition for boundary[\$]. - open - reflective - periodic - simple_anode - simple_cathode. If condition=open, the following parameters are used: (Part-Boundary[\$]=PB) PB-Ambient, PB-AmbientTemp, PB-AmbientMeanPartMass, PB-AmbientVelo, PB-AmbientDens, PB-AmbientDynamicVisc, PB-AmbientThermalCond, PB-Voltage</p> <p>If condition=reflective: PB-MomentumACC, PB-WallTemp, PB-TransACC, PB-VibACC, PB-RotACC, PB-WallVelo, Voltage, SpeciesSwaps.</p> <p>If condition=periodic: Part-nPeriodicVectors, Part-PeriodicVector[\$]</p> |
| Part-Boundary[\$]-AmbientCondition | F | TODO-DEFINE-PARAMETER Use ambient condition (condition "behind" boundary). |
| Part-Boundary[\$]-AmbientConditionFix | T | TODO-DEFINE-PARAMETER |
| Part-Boundary[\$]-AmbientTemp | 0.0 | TODO-DEFINE-PARAMETER Ambient temperature |
| Part-Boundary[\$]-AmbientMeanPartMass | 0.0 | TODO-DEFINE-PARAMETER Ambient mean particle mass |

Particle Boundaries

| | | |
|--|-----------------------|---|
| Part-Boundary[\$]-AmbientVelo | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETERAmbient velocity |
| Part-Boundary[\$]-AmbientDens | 0.0 | TODO-DEFINE-PARAMETERAmbient density |
| Part-Boundary[\$]-AmbientDynamicVisc | 0.172326582572253E-04 | TODO-DEFINE-PARAMETERAmbient dynamic viscosity |
| Part-Boundary[\$]-AmbientThermalCond | 0.242948500556027E-01 | TODO-DEFINE-PARAMETERAmbient thermal conductivity |
| Part-Boundary[\$]-Adaptive | F | Define if particle boundary [\$] is adaptive [.TRUE.] or not [.FALSE.] |
| Part-Boundary[\$]-AdaptiveType | 2 | Define type of adaptive boundary [\$] [1] (STREAM INLET) with define temperature and pressure and pressurefraction [2] (STREAM OUTLET) with defined pressure and pressurefraction |
| Part-Boundary[\$]-AdaptiveMacroRestartFileID | 0 | Define FileID of adaptive boundary [\$] macro restart if macro restart is used |
| Part-Boundary[\$]-AdaptiveTemp | 0.0 | Define temperature for adaptive particle boundary [\$] (in [K]) |
| Part-Boundary[\$]-AdaptivePressure | 0.0 | Define pressure for adaptive particle boundary [\$] (in [Pa]) |
| Part-Boundary[\$]-Species[\$]-Pressurefraction | 0.0 | If particle boundary [\$] adaptive, define pressurefractions for each species, so sum of all species for this adaptiveis 1.0. Results in abort if not set right. |
| Part-Boundary[\$]-Voltage | 0.0 | TODO-DEFINE-PARAMETERVoltage on boundary [\$] |

| Particle Boundaries | | |
|-------------------------------------|---------------------|---|
| Part-Boundary[\$]-WallTemp | 0.0 | Wall temperature (in [K]) of reflective particle boundary [\$]. |
| Part-Boundary[\$]-MomentumACC | 0.0 | Momentum accommodation coefficient of reflective particle boundary [\$]. |
| Part-Boundary[\$]-TransACC | 0.0 | Translation accommodation coefficient of reflective particle boundary [\$]. |
| Part-Boundary[\$]-VibACC | 0.0 | Vibrational accommodation coefficient of reflective particle boundary [\$]. |
| Part-Boundary[\$]-RotACC | 0.0 | Rotational accommodation coefficient of reflective particle boundary [\$]. |
| Part-Boundary[\$]-ElecACC | 0.0 | Electronic accommodation coefficient of reflective particle boundary [\$]. |
| Part-Boundary[\$]-Resample | F | TODO-DEFINE-PARAMETERResample Equilibrium Distribution with reflection |
| Part-Boundary[\$]-WallVelo | (/ 0.0, 0.0, 0.0 /) | Velocity (global x,y,z in [m/s]) of reflective particle boundary [\$]. |
| Part-Boundary[\$]-SolidState | T | Flag defining if reflective BC is solid [TRUE] or liquid [FALSE]. |
| Part-Boundary[\$]-SolidReactive | F | Flag for defining solid surface to be treated catalytically (for surfacemodel>0). |
| Part-Boundary[\$]-SolidSpec | 0 | Set Species of Solid Boundary. (currently not used) |
| Part-Boundary[\$]-SolidPartDens | 0.10E+20 | If particle boundary defined as solid set surface atom density (in [part/m ²]). |
| Part-Boundary[\$]-SolidMassIC | 0.32395E-24 | Set mass of solid surface particles (in [kg]). |
| Part-Boundary[\$]-SolidAreaIncrease | 1.0 | TODO-DEFINE-PARAMETER |
| Part-Boundary[\$]-SolidCrystallIndx | 4 | Set number of interaction for hollow sites. |

Particle Boundaries

| | | |
|--------------------------------------|---------------------|--|
| Part-Boundary[\$]-LiquidSpec | 0 | Set used species of Liquid Boundary |
| Part-Boundary[\$]-ParamAntoine | (/ 0.0, 0.0, 0.0 /) | Parameters for Antoine Eq (vapor pressure) |
| Part-Boundary[\$]-ProbOfSpeciesSwaps | 1.0 | TODO-DEFINE-PARAMETERProbability of SpeciesSwaps at wall |
| Part-Boundary[\$]-SpeciesSwaps[\$] | (/ 0, 0 /) | TODO-DEFINE-PARAMETERSpecies to be changed at wall (out=: delete) |
| Part-Boundary[\$]-SourceName | | TODO-DEFINE-PARAMETERNo Default. Source Name of Boundary[i]. Has to be selected for allnBounds. Has to be same name as defined in preproc tool |
| Part-Boundary[\$]-UseForQCrit | T | TODO-DEFINE-PARAMETERFlag to use Boundary for Q-Criterion |
| Part-nAuxBCs | 0 | TODO-DEFINE-PARAMETERNumber of auxillary BCs that are checked during tracing |
| Part-AuxBC[\$]-NbrOfSpeciesSwaps | 0 | TODO-DEFINE-PARAMETERNumber of Species to be changed at wall. |
| Part-AuxBC[\$]-Condition | open | TODO-DEFINE-PARAMETERUsed auxillary boundary condition for boundary[\$].- open- reflective- periodic)-> more details see also |
| Part-AuxBC[\$]-MomentumACC | 0.0 | Part-Boundary[\$]-Condition TODO-DEFINE-PARAMETERMomentum accommodation |
| Part-AuxBC[\$]-WallTemp | 0.0 | TODO-DEFINE-PARAMETERWall temperature of boundary[\$] |

| Particle Boundaries | | |
|-----------------------------------|---------------------|--|
| Part-AuxBC[\$]-TransACC | 0.0 | TODO-DEFINE-PARAMETERTranslation accommodation on boundary [\$] |
| Part-AuxBC[\$]-VibACC | 0.0 | TODO-DEFINE-PARAMETERVibrational accommodation on boundary [\$] |
| Part-AuxBC[\$]-RotACC | 0.0 | TODO-DEFINE-PARAMETERRotational accommodation on boundary [\$] |
| Part-AuxBC[\$]-ElecACC | 0.0 | TODO-DEFINE-PAMETERElectronic accommodation on boundary [\$] |
| Part-AuxBC[\$]-Resample | F | TODO-DEFINE-PARAMETERResample Equilibrium Distribution with reflection |
| Part-AuxBC[\$]-WallVelo | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PAMETEREmitted velocity on boundary [\$] |
| Part-AuxBC[\$]-ProbOfSpeciesSwaps | 1.0 | TODO-DEFINE-PAMETERProbability of SpeciesSwaps at wall |
| Part-AuxBC[\$]-SpeciesSwaps[\$] | (/ 0, 0 /) | TODO-DEFINE-PAMETERSpecies to be changed at wall (out=: delete) |
| Part-AuxBC[\$]-Type | plane | TODO-DEFINE-PAMETERType of BC (plane, ...) |
| Part-AuxBC[\$]-r_vec | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PAMETER |
| Part-AuxBC[\$]-radius | | TODO-DEFINE-PAMETER |
| Part-AuxBC[\$]-n_vec | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PAMETER |
| Part-AuxBC[\$]-axis | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PAMETER |

Particle Boundaries

| | | |
|--------------------------|------|-----------------------|
| Part-AuxBC[\$]-lmin | | TODO-DEFINE-PARAMETER |
| Part-AuxBC[\$]-lmax | | TODO-DEFINE-PARAMETER |
| Part-AuxBC[\$]-inwards | T | TODO-DEFINE-PARAMETER |
| Part-AuxBC[\$]-rmax | 0.0 | TODO-DEFINE-PARAMETER |
| Part-AuxBC[\$]-halfangle | 45.0 | TODO-DEFINE-PARAMETER |
| Part-AuxBC[\$]-zfac | 1.0 | TODO-DEFINE-PARAMETER |

Tracking

| Variable | Default | Description |
|---------------------------------|---------|---|
| DoRefMapping | T | Refmapping [T] or Tracing [F] algorithms are used for tracking of particles. |
| TriaTracking | F | Using Triangle-aproximation [T] or (bi-)linear and bezier (curved) description [F] of sides for tracing algorithms. Currently flag is only used in DSMC timediscs. Requires DoRefMapping=F. |
| Write-Tria-DebugMesh | F | Writes per proc triangulated Surfacemesh used for Triatracking. Requires TriaTracking=T. |
| TriaSurfaceFlux | | Using Triangle-aproximation [T] or (bi-)linear and bezier (curved) description [F] of sides for surfaceflux. Default is set to TriaTracking |
| Write-TriaSurfaceFlux-DebugMesh | F | Writes per proc triangulated Surfacemesh used for TriaSurfaceFlux. Requires TriaSurfaceFlux=T. |

Tracking

| | | |
|--------------------|---------|--|
| CountNbOfLostParts | F | Count number of lost particles during tracking that can not be found with fallbacks. |
| PartOut | 0 | If compiled with CODE_ANALYZE flag: For This particle number every tracking information is written as STDOUT. |
| MPIRankOut | 0 | If compiled with CODE_ANALYZE flag: This MPI-Proc writes the tracking information for the defined PartOut. |
| MeasureTrackTime | F | If .TRUE. then the time how long the tracking routines are called are sampled and written for each MPI-Proc. |
| CartesianPeriodic | F | Simplified treatment for periodic box with Refmapping. Not computation of intersection points at periodic BCs. |
| FastPeriodic | F | Further simplification by directly moving particle into grid. Instead of moving the particle several times the periodic displacements, the particle is mapped directly back into the domain. |
| RefMappingGuess | | Initial guess of the Newton for mapping the particle into reference coordinates. 1 -linear pseudo-Cartesian coordinates 2 - Xi of closest Gauss point 3 - Xi of closest XCL_ngeo point 4 -trival guess (0,0,0)^t |
| RefMappingEps | 0.1E-03 | Tolerance for mapping particle into reference element measured as L2-norm of deltaXi |

Tracking

| | | |
|----------------------------------|---------------------|--|
| BezierEpsilonBilinear | 0.1E-05 | Bi-linear tolerance for the bi-linear - planar decision. |
| BezierElevation | 0 | Use BezierElevation>0 to tighten the bounding box. Typical values>10 |
| BezierSampleN | 0 | TODO-DEFINE-PARAMETER Default value: NGeo equidistant sampling of bezier surface for emission |
| Part-FIBGMdeltas | (/ 1.0, 1.0, 1.0 /) | Define the deltas for the cartesian Fast-Init-Background-Mesh. They should be of the similar size as the smallest cells of the used mesh for simulation. |
| Part-FactorFIBGM | (/ 1.0, 1.0, 1.0 /) | Factor with which the background mesh will be scaled. |
| printMPINeighborWarnings | F | Print warning if the MPI-Halo-region between to procs are not overlapping. Only one proc find the other in halo |
| printBezierControlPointsWarnings | F | Print warning if MIN-VAL(BezierControlPoints3d(iDir,::,newSideID)) and global boundaries are too close |
| BezierNewtonAngle | 1.570796326 | BoundingBox intersection angle for switching between Bezierclipping and BezierNewton. |
| BezierClipTolerance | 0.1E-07 | Tolerance for BezierClipping |
| BezierNewtonTolerance | 0.1E-03 | Tolerance for BezierNewton |
| BezierNewtonGuess | 1 | Initial guess for BezierNewton 1 - linear projected face 2 - closest projected BeziercontrolPoint 4 - (0,0)^t |
| BezierNewtonMaxIter | 100 | TODO-DEFINE-PARAMETER |

Tracking

| | | |
|----------------------------|-----|---|
| BezierSplitLimit | 0.6 | Limit for splitting in BezierClipping. Value allows to detect multiple intersections and speed up computation. Parameter is multiplied by 2 |
| BezierClipMaxIter | 100 | Max iteration of BezierClipping |
| BezierClipLineVectorMethod | 2 | TODO-DEFINE-PARAMETER |
| epsilontol | 0.0 | TODO-DEFINE-PARAMETER |
| BezierClipHit | 0.0 | Tolerance in [-1,1] of BezierFace |
| BezierNewtonHit | 0.0 | Tolerance in [-1,1] of BezierNewton |
| BezierClipMaxIntersec | | Max. number of multiple intersections. Default: $2*(N_{Geo}+1)$ |

Particle Analyze

| Variable | Default | Description |
|----------------------------|---------|--|
| Part-AnalyzeStep | 1 | Analyze is performed each Nth time step |
| CalcTotalEnergy | F | Calculate Total Energy. Output file is Database.csv |
| PIC-VerifyCharge | F | Validate the charge after each deposition and write an output in std.out |
| CalcIonizationDegree | F | Compute the ionization degree in each cell |
| CalcPointsPerShapeFunction | F | Compute the points per shape function in each cell |
| CalcPlasmaParameter | F | Compute the plasma parameter N_D in each cell |
| CalcPointsPerDebyeLength | F | Compute the points per Debye length in each cell |
| CalcDebyeLength | F | Compute the Debye length in each cell |
| CalcPictimeStep | F | Compute the HDG time step in each cell |

Particle Analyze

| | | |
|-------------------------|---|--|
| CalcElectronTemperature | F | Compute the electron temperature in each cell |
| CalcElectronIonDensity | F | Compute the electron density in each cell |
| CalcPlasmaFrequency | F | Compute the electron frequency in each cell |
| CalcCharge | F | TODO-DEFINE-PARAMETER Compute the whole deposited charge, absolute and relative charge error |
| CalcKineticEnergy | F | TODO-DEFINE-PARAMETER Calculate Kinetic Energy. |
| CalcInternalEnergy | F | TODO-DEFINE-PARAMETER Calculate Internal Energy. |
| CalcTemp | F | TODO-DEFINE-PARAMETER Calculate Translational temperature. |
| CalcPartBalance | F | TODO-DEFINE-PARAMETER Calculate the Particle Power Balance- input and outflow energy of all particles |
| CalcVelos | F | TODO-DEFINE-PARAMETER Calculate thermal and flow velocities.if CalcVelos = T VelocityDirections = (/[int],[int],[int],[int]/) Switching dimensions for CalcVelos on (1) or off (0) (/v_x,v_y,v_z, v /) |
| CalcLaserInteraction | F | Compute laser-plasma interaction properties such as maximum particle energy per species. |

Particle Analyze

| | | |
|--------------------------------|------------------------------------|--|
| LaserInteractionEkinMaxRadius | | maximum radius (x- and y-dir) of particle to be considered for Ekin maximum calculation (default is HUGE) OR if LaserInteractionEkinMaxZPosMin is true |
| LaserInteractionEkinMaxZPosMin | | minimum z-position of particle to be considered for Ekin maximum calculation (default is -1.*HUGE) OR if LaserInteractionEkinMaxRadius is true |
| VelocityDirections | (/ 1, 1, 1, 1 /) | TODO-DEFINE-PARAMETER x,y,z,abs -> 0/1 = T/F. (please note: CalcVelos) |
| Part-TrackPosition | F | TODO-DEFINE-PARAMETER Track particle position |
| printDiff | F | TODO-DEFINE-PARAMETER |
| printDiffTime | 12.0 | TODO-DEFINE-PARAMETER |
| printDiffVec | (/ 0.0, 0.0, 0.0, 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| CalcNumSpec | F | TODO-DEFINE-PARAMETER Calculate species count. |
| CalcCollRates | F | TODO-DEFINE-PARAMETER Calculate the collision rates per collision pair |
| CalcReacRates | F | TODO-DEFINE-PARAMETER Calculate the reaction rate per reaction |
| CalcShapeEfficiency | F | TODO-DEFINE-PARAMETER Use efficiency methods for shape functions. |

Particle Analyze

| | | |
|---------------------------|----------|--|
| CalcShapeEfficiencyMethod | AllParts | TODO-DEFINE-PARAMETER Choose between “AllParts” and “SomeParts”, to either use all particles or a certain percentage |
| ShapeEfficiencyNumber | 100 | (ShapeEfficiencyNumber) of the currently used particles TODO-DEFINE-PARAMETER Percentage of currently used particles is used. |
| IsRestart | F | TODO-DEFINE-PARAMETER Flag, if the current calculation is a restart. |

TTM

| Variable | Default | Description |
|----------------------|-------------------|---|
| DoImportTTMFile | F | Read IMD Two-Temperature Model (TTM) data (FD grid data with electron temperature and other field data) |
| TTMLogFile | no file specified | TTM Log file path |
| TTMFile | no file found | TTM Data file path |
| TTMGridFDdim | (/ 0, 0, 0 /) | Number of FD grid cells in each direction (/x,y,z/) |
| TTMElemBaryTolerance | 0.1E-05 | TTM FD bary center tolerance to DG bary center. The tolerance is used for finding the corresponding DG element to which the FD data is saved. |

PIC

| Variable | Default | Description |
|----------|---------|-------------|
|----------|---------|-------------|

PIC

| | | |
|---------------------------|---------------------------------------|--|
| PIC-Interpolation-Type | particle_position | TODO-DEFINE- PARAMETER Type of Interpolation-Method to calculate the EM field's value for the particle |
| PIC-InterpolationElemLoop | T | TODO-DEFINE- PARAMETER Interpolate with outer iElem-loop (notfor many Elems per proc!) |
| PIC-externalField | (/ 0.0, 0.0, 0.0, 0.0, 0.0, 0.0 /) | TODO-DEFINE- PARAMETER External field is added to themaxwell-solver-field |
| PIC-scaleexternalField | 1.0 | TODO-DEFINE- PARAMETER |
| PIC-DoInterpolation | T | TODO-DEFINE- PARAMETER Compute the self field's influence on the Particle |
| PIC-BG-Field | T | TODO-DEFINE- PARAMETER BGField data (1:x,0:NBG,0:NBG,0:NBG,1:PP_nElems) If PIC-BG-Field=T Define: PIC-BGFilename PIC-BGFieldScaling PIC-NBG |
| PIC-BGFileName | none | TODO-DEFINE- PARAMETER File name for background field ([character].h5) |
| PIC-NBG | 1 | TODO-DEFINE- PARAMETER Polynomial degree that shall be used for background field during simulation |
| PIC-BGFieldScaling | 1.0 | TODO-DEFINE- PARAMETER Space scaling of background field |
| PIC-curvedexternalField | none | TODO-DEFINE- PARAMETER File to curved external field data. |

PIC

| | | |
|---|---------------------|--|
| PIC-variableexternalField | none | TODO-DEFINE-PARAMETER File containing the external field CSV table |
| PIC-nCollectChargesBCs | 0 | TODO-DEFINE-PARAMETER |
| PIC-CollectCharges[\$]-BC | 0 | TODO-DEFINE-PARAMETER |
| PIC-CollectCharges[\$]-NumOfRealCharges | 0.0 | TODO-DEFINE-PARAMETER |
| PIC-CollectCharges[\$]-ChargeDist | 0.0 | TODO-DEFINE-PARAMETER |
| PIC-NormVecOfWall | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Normal vector for pushTimeStep |
| PIC-DeltaType | 1 | TODO-DEFINE-PARAMETER Flag |
| PIC-DeltaType-N | 1 | TODO-DEFINE-PARAMETER Polynomial degree of delta distribution |
| PIC-BGMdeltas | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Dimensions of PIC background mesh |
| PIC-FactorBGM | (/ 1.0, 1.0, 1.0 /) | TODO-DEFINE-PARAMETER Denominator of PIC-BGMdeltas |
| PIC-OutputSource | F | TODO-DEFINE-PARAMETER Writes the source to hdf5 |

PIC Deposition

| Variable | Default | Description |
|------------------|---------|--|
| PIC-DoDeposition | T | TODO-DEFINE-PARAMETER Switch deposition on/off |

PIC Deposition

| | | |
|-------------------------------|----------------------|--|
| PIC-Deposition-Type | nearest-blurrycenter | TODO-DEFINE-PARAMETER (HALOWIKI:) If Deposition-Type=shape_function Define: PIC-shapefunction-radius PIC-shapefunction-alpha. If Deposition-Type=(cartmesh_volumeweighting/cartmesh_splines) Define: PIC-BGMdeltas PIC-FactorBGM |
| PIC-TimeAverageFile | none | TODO-DEFINE-PARAMETER |
| PIC-epanechnikov-radius | 1.0 | TODO-DEFINE-PARAMETER |
| PIC-shapefunction-radius | 1.0 | TODO-DEFINE-PARAMETER Radius of shape function |
| PIC-shapefunction-alpha | 2 | TODO-DEFINE-PARAMETER Exponent of shape function |
| PIC-shapefunction-equi | F | TODO-DEFINE-PARAMETER Use equidistant points for shapefunction |
| PIC-shapefunction1d-direction | 1 | TODO-DEFINE-PARAMETER Direction of 1D shape function |
| PIC-shapefunction-radius0 | 1.0 | TODO-DEFINE-PARAMETER Minimal shape function radius |
| PIC-shapefunction-scale | 0.0 | TODO-DEFINE-PARAMETER Scaling factor of shape function radius |
| PIC-NbrOfSFdepoFixes | 0 | TODO-DEFINE-PARAMETER Number of fixes for shape func depo at planar BCs |
| PrintSFDepoWarnings | F | TODO-DEFINE-PARAMETER Print the shapefunction warnings |

PIC Deposition

| | | |
|--------------------------------|---------------------|---|
| PIC-SFdepoFixesEps | 0.0 | TODO-DEFINE-PARAMETER Epsilon for defined planes |
| PIC-SFdepoFixes[\$]-Basepoint | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| PIC-SFdepoFixes[\$]-Normal | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| PIC-SFdepoFixes[\$]-ChargeMult | 1.0 | TODO-DEFINE-PARAMETER Multiplier for mirrored charges (wall: -1.0, sym: 1.0) |
| PIC-SFdepoFixes[\$]-xmin | | TODO-DEFINE-PARAMETER -> SFdepoFixesBounds(;;,;) 1:nFixes;1:2(min,max);1:3(x,y,z)? |
| PIC-SFdepoFixes[\$]-ymin | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoFixes[\$]-zmin | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoFixes[\$]-xmax | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoFixes[\$]-ymax | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoFixes[\$]-zmax | | TODO-DEFINE-PARAMETER |
| PIC-NbrOfSFdepoFixLinks | 0 | TODO-DEFINE-PARAMETER Number of linked SFdepoFixes |
| PIC-SFdepoFixLink[\$] | (/ 1, 2 /) | TODO-DEFINE-PARAMETER (1:nLinks) 1:3 (2 fixes are linked with each other!) ;,3 is fraction of 180 deg |
| PIC-NbrOfSFdepoLayers | 0 | TODO-DEFINE-PARAMETER Number of const. source layer for sf-depo at planar BCs |
| PIC-ConstantSFdepoLayers | F | Do deposition of SFdepoLayers just once |
| PIC-SFdepoLayers[\$]-Basepoint | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |

PIC Deposition

| | | |
|---|---------------------|--|
| PIC-SFdepoLayers[\$]-Normal | (/ 1.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| PIC-SFdepoLayers[\$]-xmin | | TODO-DEFINE-PARAMETER -> SFdepoLayersBounds(:, :, :) 1:nFixes;1:2(min,max);1:3(x,y,z)? |
| PIC-SFdepoLayers[\$]-ymin | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoLayers[\$]-zmin | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoLayers[\$]-xmax | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoLayers[\$]-ymax | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoLayers[\$]-zmax | | TODO-DEFINE-PARAMETER |
| PIC-SFdepoLayers[\$]-UseFixBounds | T | TODO-DEFINE-PARAMETER Use alls planes of SFdepoFixes as additional bounds |
| PIC-SFdepoLayers[\$]-Space | cuboid | TODO-DEFINE-PARAMETER Name of space (cuboid or cylinder) |
| PIC-SFdepoLayers[\$]-BaseVector1 | (/ 0.0, 1.0, 0.0 /) | TODO-DEFINE-PARAMETER Base Vector 1 |
| PIC-SFdepoLayers[\$]-BaseVector2 | (/ 0.0, 0.0, 1.0 /) | TODO-DEFINE-PARAMETER Base Vector 2 |
| PIC-SFdepoLayers[\$]-SFdepoLayersRadius | 1.0 | TODO-DEFINE-PARAMETER Radius for cylinder-space |
| PIC-SFdepoLayers[\$]-Chargedens | 1.0 | TODO-DEFINE-PARAMETER |
| PIC-SFdepoLayers[\$]-Spec | 1 | TODO-DEFINE-PARAMETER Particle species for respective layer |
| PIC-SFdepoLayers[\$]-MPF | | MPF for respective layer (def.: MPF of resp. species) |
| PIC-SFResampleAnalyzeSurfCollis | F | TODO-DEFINE-PARAMETER |

PIC Deposition

| | | |
|-------------------------------------|-------|--|
| PIC-SFResampleSurfCollisBC | | TODO-DEFINE- PARAMETER BCs to be analyzed (def.: 0 = all) |
| PIC-SFResampleReducePartNumber | F | TODO-DEFINE- PARAMETER Reduce PartNumberSamp to PartNumberReduced |
| PIC-PartNumThreshold | 0 | TODO-DEFINE- PARAMETER Threshold for checking inserted parts per deposition (otherwise abort) |
| PIC-SFResampleNumberOfBCs | 1 | TODO-DEFINE- PARAMETER Number of BC to be analyzed |
| PIC-SFResamplePartNumberReduced | 0 | TODO-DEFINE- PARAMETER Max. allowed number of parts to be saved |
| PIC-SFResampleNbrOfSpeciesForDtCalc | 1 | TODO-DEFINE- PARAMETER Number of species used for SFResample-dt |
| PIC-SFResampleSpeciesForDtCalc | | TODO-DEFINE- PARAMETER Species used for SFResample-dt (def.: 0 = all) |
| PIC-SFResampleRestart | F | TODO-DEFINE- PARAMETER Read-in old DSMCSurfCollis-file for restart |
| PIC-SFResampleRestartFile | dummy | TODO-DEFINE- PARAMETER Name of the new DSMCSurfCollis-file to read-in by restart |
| PIC-SFResample-xmin | | TODO-DEFINE- PARAMETER |
| PIC-SFResample-ymin | | TODO-DEFINE- PARAMETER |
| PIC-SFResample-zmin | | TODO-DEFINE- PARAMETER |
| PIC-SFResample-xmax | | TODO-DEFINE- PARAMETER |

PIC Deposition

| | | |
|---------------------------------|---|---|
| PIC-SFResample-y _{max} | | TODO-DEFINE-PARAMETER |
| PIC-SFResample-z _{max} | | TODO-DEFINE-PARAMETER |
| PIC-SFResample-UseFixBounds | T | TODO-DEFINE-PARAMETER Use all planes of SFdepoFixes as additional bounds? |

Particle Emission

| Variable | Default | Description |
|---|---------------------|---|
| Part-Species[\$]-nSurfacefluxBCs | 0 | TODO-DEFINE-PARAMETER Number of SF emissions |
| Part-Species[\$]-Surfaceflux[\$]-BC | 0 | TODO-DEFINE-PARAMETER PartBound to be emitted from |
| Part-Species[\$]-Surfaceflux[\$]-velocityDistribution | constant | TODO-DEFINE-PARAMETER Specifying keyword for velocity distribution |
| Part-Species[\$]-Surfaceflux[\$]-VeloIC | 0.0 | TODO-DEFINE-PARAMETER Velocity for initial Data |
| Part-Species[\$]-Surfaceflux[\$]-VeloIsNormal | F | TODO-DEFINE-PARAMETER VeloIC is in Surf-Normal instead of VeloVecIC |
| Part-Species[\$]-Surfaceflux[\$]-VeloVecIC | (/ 0.0, 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Normalized velocity vector |
| Part-Species[\$]-Surfaceflux[\$]-SimpleRadialVeloFit | F | TODO-DEFINE-PARAMETER Fit of $\text{veloR}/\text{veloTot} = -r(A\exp(B*r)+C)$ |
| Part-Species[\$]-Surfaceflux[\$]-preFac | 0.0 | TODO-DEFINE-PARAMETER A , see SimpleRadialVeloFit |
| Part-Species[\$]-Surfaceflux[\$]-powerFac | 0.0 | TODO-DEFINE-PARAMETER B , see SimpleRadialVeloFit |

Particle Emission

| | | |
|--|----------------|---|
| Part-Species[\$]-Surfaceflux[\$]-shiftFac | 0.0 | TODO-DEFINE-PARAMETER C , see SimpleRadialVeloFit |
| Part-Species[\$]-Surfaceflux[\$]-axialDir | 1 | TODO-DEFINE-PARAMETER Axial direction of coordinates in polar system |
| Part-Species[\$]-Surfaceflux[\$]-origin | (/ 0.0, 0.0 /) | TODO-DEFINE-PARAMETER Origin in orth(ogonal?) coordinates of polar system |
| Part-Species[\$]-Surfaceflux[\$]-rmax | 0.1E+22 | TODO-DEFINE-PARAMETER Max radius of to-be inserted particles |
| Part-Species[\$]-Surfaceflux[\$]-rmin | 0.0 | TODO-DEFINE-PARAMETER Min radius of to-be inserted particles |
| Part-Species[\$]-Surfaceflux[\$]-MWTemperatureIC | 0.0 | TODO-DEFINE-PARAMETER Temperature for Maxwell Distribution |
| Part-Species[\$]-Surfaceflux[\$]-PartDensity | 0.0 | TODO-DEFINE-PARAMETER PartDensity (real particles per m ³) for LD_insert or (vpi_)cub./cyl. as alternative to Part.Emis. in Type1 |
| Part-Species[\$]-Surfaceflux[\$]-ReduceNoise | F | TODO-DEFINE-PARAMETER Reduce stat. noise by global calc. of PartIns |
| Part-Species[\$]-Surfaceflux[\$]-AcceptReject | T | TODO-DEFINE-PARAMETER Perform ARM for skewness of RefMap-positioning |
| Part-Species[\$]-Surfaceflux[\$]-ARM_DmaxSampleN | 1 | TODO-DEFINE-PARAMETER Number of sample intervals in xi/eta for Dmax-calc. |
| DoForceFreeSurfaceFlux | F | TODO-DEFINE-PARAMETER Flag if the stage reconstruction uses a force |

Particle Emission

| | | |
|-------------------------|---|---|
| OutputSurfaceFluxLinked | F | Flag to print the SurfaceFlux-linked Info |
|-------------------------|---|---|

DSMC

| Variable | Default | Description |
|-----------------------------------|---------|--|
| Particles-DSMC-OutputMeshInit | F | not working currently Writeoutput mesh for constant pressure BC at initialization. |
| Particles-DSMC-OutputMeshSamp | F | not working currently Write output mesh for constant pressure BC with samplingvalues at t_analyze. |
| Particles-DSMC-CollisMode | 1 | Define mode of collision handling in DSMC. 0: No Collisions (=free molecular flow with DSMC-Sampling-Routines). 1: Elastic Collision 2: Relaxation + Elastic Collision 3: Mode 2 + Chemical Reactions. |
| Particles-DSMC-SelectionProcedure | 1 | Mode of Selection Procedure 1: Laux 2: Gimelsheim. |
| Particles-DSMC-RotRelaxProb | 0.2 | Define the rotational relaxation probability upon collision of molecules (HALOWIKI:)Choice of the vibrational relaxation probability calculation 0-1: constant 2: variable, Boyd) |
| Particles-DSMC-VibRelaxProb | 0.02 | Define the vibrational relaxation probability upon collision of molecules |
| Particles-DSMC-ElecRelaxProb | 0.01 | Define the electronic relaxation probability upon collision of molecules |
| Particles-DSMC-GammaQuant | 0.5 | Set the GammaQuant for zero point energy in Evib (perhaps also Erot) should be 0.5 or 0. |

DSMC

| | | |
|-------------------------------------|---------|--|
| Particles-DSMC-BackwardReacRate | F | Set [TRUE] to enable the automatic calculation of the backward reaction rate coefficient using the equilibrium constant calculated by partition functions [FALSE] if they are defined as separate reactions. |
| Particles-DSMC-PartitionMaxTemp | 20000.0 | Define temperature limit for pre-stored partition function that are used for calculation of backwards rates |
| Particles-DSMC-PartitionInterval | 10.0 | Define temperature interval for pre-stored partition functions that are used for calculation of backwards rates |
| Particles-DSMC-veloMinColl-Spec[\$] | 0.0 | min velo magn. for spec allowed to perform collision |
| Particles-DSMC-CalcQualityFactors | F | Enables [TRUE] / disables [FALSE] the calculation and output of flow-field variable. Maximal collision probability Time-averaged mean collision probability Mean collision separation distance over mean free path |
| Particles-DSMCReservoirSim | F | Only TD=Reservoir (42). Set [TRUE] to disable particle movement. Use for reservoir simulations. |
| Particles-DSMCReservoirSimRate | F | Only TD=Reservoir (42). Set [TRUE] to disable particle reactions. Only probabilities (rates) are calculated. |
| Particles-DSMCReservoirStatistic | F | Only TD=Reservoir (42). Probabilities (rates) are calculated [TRUE] counting reacting particles. [FALSE] summing reaction probabilities. |

DSMC

| | | |
|--|---------|---|
| Particles- DSMCReservoirSurfaceRate | F | Only TD=Reservoir (42). Set [TRUE] to disable particle adsorption and desorption and keep surface coverage constant. Only probabilities (rates) are calculated. |
| Particles-ModelForVibrationEnergy | 0 | Define model used for vibrational degrees of freedom. 0: SHO 1:TSHO. |
| Particles-DSMC-TEVR-Relaxation | F | Flag for T-V-E-R [TRUE] or more simple T-V-R T-E-R [FALSE] relaxation. |
| Particles-DSMC-ElectronicModel | F | Set [TRUE] to model electronic states of atoms and molecules. |
| Particles- DSMCElectronicDatabase | none | If electronic model is used give (relative) path to (h5) Name of Electronic State Database |
| EpsMergeElectronicState | 0.1E-03 | Percentage parameter of electronic energy level merging. |
| Particles-DSMC-UseQCrit | F | Set [TRUE] to enable steady state detection and sampling start using Q-criterion (Burt/Boyd). |
| Particles-DSMC-UseSSD | F | Set [TRUE] to enable steady state detection and sampling start using 3SD routines. |
| Particles-DSMCBackgroundGas | 0 | Define Species number that is used as background gas species |
| Particles- DSMCBackgroundGasDensity | 0.0 | Define Species number density for background gas |

DSMC

| | | |
|------------------------------------|----|---|
| Particles-DSMC-PolyRelaxSingleMode | F | Set [TRUE] for separate relaxation of each vibrational mode of a polyatomic in a loop over all vibrational modes. Every mode has its own corrected relaxation probability, comparison with the same random number while the previous probability is added to the next |
| Particles-DSMC-CompareLandauTeller | F | Only TD=Reservoir (42). |
| Particles-DSMC-UseOctree | F | Use octree method for dynamic grid resolution |
| Particles-OctreePartNumNode | 80 | Resolve grid until the maximum number of particles in a subcell equals OctreePartNumNode. |
| Particles-OctreePartNumNodeMin | 50 | Allow grid division until the minimum number of particles in a subcell is above OctreePartNumNodeMin. |

DSMC Species

| Variable | Default | Description |
|-----------------------------------|----------------|--|
| Part-Species[\$]-SpeciesName | none | Species name of Species[\$] |
| Part-Species[\$]-InteractionID | 0 | ID for identification of particles 1: Atom 2: Molecule 4: Electron 10: Atomic Ion 20: Molecular Ion 40: Excited Atom 100: Excited Atomic Ion 200: Excited Molecule 400: Excited Molecular Ion) |
| Part-Species[\$]-VHSReferenceTemp | 0.0 | Reference temperature for variable hard sphere model. |
| Part-Species[\$]-VHSReferenceDiam | 1.0 | Reference diameter for variable hard sphere model. |
| Part-Species[\$]-omegaVHS | 0.0 | Reference value for exponent omega for variable hard sphere model. |

| DSMC Species | | |
|---|-----|---|
| Part-Species[\$]-CharaTempVib | 0.0 | Characteristic vibrational temperature. |
| Part-Species[\$]-CharaTempRot | 0.0 | Characteristic rotational temperature |
| Part-Species[\$]-Ediss_eV | 0.0 | Energy of Dissoziation in [eV]. |
| Part-Species[\$]-VFDPhi3 | 0.0 | Factor of Phi3 in VFD Method: Phi3 = 0 => VFD |
| Part-Species[\$]-CollNumRotInf | 0.0 | Factor of Phi3 in VFD Method: Phi3 = 0 => VFD -> TCE, ini_2 |
| Part-Species[\$]-TempRefRot | 0.0 | Referece temperature for rotational relaxation according to Parker orZhang, ini_2 -> model dependent! |
| Part-Species[\$]-CollNumVib | 0.0 | Vibrational collision number according to Boyd, ini_2 |
| Part-Species[\$]-TempVib | 0.0 | Vibrational temperature. |
| Part-Species[\$]-TempRot | 0.0 | Rotational temperature. |
| Part-Species[\$]-TempElec | 0.0 | Electronic temperature. |
| Part-Species[\$]-Init[\$]-TempVib | 0.0 | Vibrational temperature. |
| Part-Species[\$]-Init[\$]-TempRot | 0.0 | Rotational temperature. |
| Part-Species[\$]-Init[\$]-TempElec | 0.0 | Electronic temperature. |
| Part-Species[\$]-Surfaceflux[\$]-TempVib | 0.0 | Vibrational temperature. |
| Part-Species[\$]-Surfaceflux[\$]-TempRot | 0.0 | Rotational temperature. |
| Part-Species[\$]-Surfaceflux[\$]-TempElec | 0.0 | Electronic temperature. |
| Part-Species[\$]-HeatOfFormation_K | | Heat of formation of the respective species [Kelvin] |
| Part-Species[\$]-PreviousState | 0 | Species number of the previous state (e.g. N for Nlon) |
| Part-Species[\$]-NextIonizationSpecies | 0 | SpeciesID of the next higher ionization level (required for field ionization) |
| Part-Species[\$]-NumElectronicLevels | 0 | Max elec quantum number + 1 |
| Part-Species[\$]-ElectronicDegeneracy-Level[\$] | 0 | Electronic degeneracy level of respective species |

DSMC Species

| | | |
|--|-----|--|
| Part-Species[\$]-ElectronicEnergyLevel-Level[\$] | 0.0 | Electronic energy level of respective species |
| Part-Species[\$]-SymmetryFactor | 0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-IonizationEn_eV | 0.0 | Energy of Ionization in [eV]. |
| Part-Species[\$]-RelPolarizability | 0.0 | Relative Polarizability |
| Part-Species[\$]-NumEquivElecOutShell | 0 | Number of equivalent electrons in outer shells |
| Part-Species[\$]-NumOfProtons | 0 | Number of protons for respective species. |

DSMC Species Polyatomic

| Variable | Default | Description |
|-----------------------------------|---------|---|
| Part-Species[\$]-PolyatomicMol | F | Allow usage of polyatomic molecules? |
| Part-Species[\$]-LinearMolec | F | Flag if it is a linear molecule |
| Part-Species[\$]-NumOfAtoms | 0 | Number of Atoms in Molecule |
| Part-Species[\$]-CharaTempVib[\$] | 0.0 | Characteristic vibrational temperature. |
| Part-Species[\$]-CharaTempRot[\$] | 0.0 | Characteristic rotational temperature |

DSMC Chemistry

| Variable | Default | Description |
|--|---------|--|
| DSMC-NumOfReactions | 0 | Number of reactions. |
| DSMC-Reaction[\$]-NumberOfNonReactives | 0 | TODO-DEFINE-PARAMETER |
| DSMC-Reaction[\$]-NonReactiveSpecies | | Array with the non-reactive collision partners for dissociation |
| DSMC-Reaction[\$]-ReactionType | none | Used reaction type I: electron impact ionization R: molecular recombination D: molecular dissociation E: molecular exchange reaction X: simple charge exchange reaction) |

| DSMC Chemistry | | |
|---|---------------|---|
| DSMC-Reaction[\$]-QKProcedure | F | Flag to use quantum-kinetic model |
| DSMC-Reaction[\$]-QK-Method | 0 | Recombination Method for Q-K model 1: by Bird 2: by Gallis) If using bird, define the variables: DSMC-Reaction[\$]-QK-Coeff1 DSMC-Reaction[\$]-QK-Coeff2 |
| DSMC-Reaction[\$]-QK-Coeff1 | 0.0 | First Q-K coefficient for Birds method. |
| DSMC-Reaction[\$]-QK-Coeff2 | 0.0 | Second Q-K coefficient for Birds method. |
| DSMC-Reaction[\$]-Reactants | (/ 0, 0, 0 /) | Reactants of Reaction[\$] (SpecNumOfReactant1, SpecNumOfReactant2, SpecNumOfReactant3) |
| DSMC-Reaction[\$]-Products | (/ 0, 0, 0 /) | Products of Reaction[j] (Product1, Product2, Product3) |
| DSMC-Reaction[\$]-Arrhenius-Prefactor | 0.0 | TODO-DEFINE-PARAMETER |
| DSMC-Reaction[\$]-Arrhenius-Powerfactor | 0.0 | TODO-DEFINE-PARAMETER |
| DSMC-Reaction[\$]-Activation-Energy_K | 0.0 | Activation energy (relativ to k_Boltzmann) for Reaction[\$]. |
| DSMC-Reaction[\$]-CEXa | -27.2 | CEX log-factor (g-dep. cross section in Angstrom, def.: value for Xe+) |
| DSMC-Reaction[\$]-CEXb | 175.269 | CEX const. factor (g-dep. cross section in Angstrom, def.: value for Xe+) |
| DSMC-Reaction[\$]-DoScat | F | Perform scattering-based charge-exchange instead of isotropic (model of Samuel Araki by lookup table) |
| DSMC-Reaction[\$]-ELa | -26.8 | with DoScat=T: EL log-factor (g&cut-off-angle-dep. cs in Angstrom, def.: value for Xe+) |

| DSMC Chemistry | | |
|--------------------------------|---------|--|
| DSMC-Reaction[\$]-ELb | 148.975 | with DoScat=T: EL const. factor (g&cut-off-angle-dep. cs in Angstrom, def.: value for Xe+) |
| DSMC-Reaction[\$]-MEXa | -27.2 | with DoScat=F: MEX log-factor (g-dep. cross section in Angstrom, def.: value for Xe+) |
| DSMC-Reaction[\$]-MEXb | 175.269 | with DoScat=F: MEX const. factor (g-dep. cross section in Angstrom, def.: value for Xe+) |
| DSMC-Reaction[\$]-TLU_FileName | 0 | with DoScat=F: No TLU-File needed (def.:) |

| LD | | |
|-------------------------|----------------|---|
| Variable | Default | Description |
| LD-ModelForMultiTemp | 0 | TODO-DEFINE-PARAMETER Modell choice for MultiTemperature (see Paper) 0 = no MultiTemperature Modeling 1 = LD1 2 = LD2 3 = LD3 |
| LD-InitialGuess | 10.0 | TODO-DEFINE-PARAMETER 2nd guess, plus user defined value[m/s], (default 10 m/s) |
| LD-MaxIterNumForLagVelo | 100 | TODO-DEFINE-PARAMETER Max. number of iterations for LAGRANGIAN vell calculation |
| LD-AccuracyForLagVelo | 0.001 | TODO-DEFINE-PARAMETER Accuracy for LAGRANGIAN velocity calculation |
| LD-RepositionsFaktor | 0.0 | TODO-DEFINE-PARAMETER |
| LD-RelaxationsFaktor | 0.0 | TODO-DEFINE-PARAMETER |

LD

| | | |
|-------------------------------------|-----|-----------------------|
| LD-DSMC-RelaxationsFaktorForBufferA | 0.0 | TODO-DEFINE-PARAMETER |
| LD_CalcResidual | F | TODO-DEFINE-PARAMETER |

SurfaceModel

| Variable | Default | Description |
|--------------------------------------|---------|--|
| Part-Species[\$]-MaximumCoverage | 0.0 | Maximum coverage of surfaces with species [\$] (used for surfacemodel=1) |
| Part-Species[\$]-InitialStick | 0.0 | Initial sticking coefficient (S_0) of species [\$] for surfaces (used for Kisliuk model, surfacemodel=1) |
| Part-Species[\$]-PrefactorStick | 0.0 | Prefactor of sticking coefficient of species [\$] for surfaces (used for Kisliuk model, surfacemodel=1) |
| Part-Species[\$]-Adsorbexp | 1 | Adsorption exponent of species [\$] for surfaces (used for Kisliuk model, surfacemodel=1) |
| Part-Species[\$]-Nu-a | 0.0 | TODO-DEFINE-PARAMETER Nu exponent a for surface n |
| Part-Species[\$]-Nu-b | 0.0 | TODO-DEFINE-PARAMETER Nu exponent b for surface n |
| Part-Species[\$]-Desorption-Energy-K | 1.0 | TODO-DEFINE-PARAMETER Desorption energy (K) for surface n |
| Part-Species[\$]-Intensification-K | 0.0 | TODO-DEFINE-PARAMETER Intensification energy (K) for surface n |
| Part-Species[\$]-Recomb-PartnerSpec | -1 | TODO-DEFINE-PARAMETER Partner recombination species (nSpecies) |

| SurfaceModel | | |
|---|-----|---|
| Part-Species[\$]-Recomb-ResultSpec | -1 | TODO-DEFINE-PARAMETER Resulting recombination species (nSpecies) |
| Part-Species[\$]-PartBound[\$]-RecombinationCoeff | 0.0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-PartBound[\$]-RecombinationEnergy | 0.0 | TODO-DEFINE-PARAMETER Energy transformed by reaction (nPartBound,nSpecies) |
| Part-Species[\$]-PartBound[\$]-RecombinationAccommodation | 1.0 | Define energy accomodation coefficient. Describes the percentage of reaction enthalpy of surface reaction transmitted to surface. |
| Part-Species[\$]-PartBound[\$]-Coordination | 0 | Coordination at which particle of species [\$] is bound on surface of boundary [\$]. 1=hollow 2=bridge 3=on-top[surfacemodel=3] |
| Part-Species[\$]-PartBound[\$]-DiCoordination | 0 | If particles of species [\$] are di-, polyatomic and bind with additional coordination at Boundary [\$]. 0: no DiCoordination 1: bound via bridge bonding 2: chelating binding [surfacemodel=3] |
| Part-Species[\$]-PartBound[\$]-HeatOfAdsorption-K | 0.0 | Define heat of adsorption [K] on clear surface for binding atom of species [\$] on boundary [\$]. [Assumption of on-top side bind, surfacemodel=3] |

| SurfaceModel | | |
|--|------|--|
| Particles-SurfCoverageFile | none | Give relative path to Surface-state-file ([Project-name]_DSMCSurfState***.h5) used for coverage init. File must be of same format as calculation (same mesh, same amount of species, cells and surfacemodel). If no file specified: Define Part-Species[\$]-PartBound[\$]-InitialCoverage for initial coverage different than 0. |
| Part-Species[\$]-PartBound[\$]-InitialCoverage | 0.0 | Initial coverage used for species [\$] and surfaces of boundary [\$] in case of no surface-state-file init |
| Particles-Surface-MacroParticleFactor | | Weighting factor used for particles adsorbed on surface in case of reconstruction [surfacemodel=3]. If one surface contains less then 10 surface atoms program abort is called. Default: Species(1)%MPF: Uses macro particle factor of species1. |
| Surface-MaxDissNum | 0 | TODO-DEFINE-PARAMETER |
| Surface-Nbr-DissocReactions | 0 | TODO-DEFINE-PARAMETER Resulting species for given dissoc (2,MaxDissNum,nSpecies) |
| Surface-Nbr-ExchangeReactions | 0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-Adsorption-Powerfactor | 0.0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-Adsorption-Prefactor | 0.0 | TODO-DEFINE-PARAMETER |

| SurfaceModel | | |
|--|----------------|--|
| Part-Species[\$]-Adsorption-EDissBond | 0.0 | TODO-DEFINE-PARAMETER Bond dissociation energy (K) for diss into resultingspecies (ReactNum,nspecies)? |
| Part-Species[\$]-Adsorption-EDissBondPoly1 | 0.0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-Adsorption-EDissBondPoly2 | 0.0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-SurfDiss[\$]-Products | (/ 0, 0 /) | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-SurfDiss[\$]-Powerfactor | 0.0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-SurfDiss[\$]-Prefactor | 0.0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-SurfDiss[\$]-EDissBond | 0.0 | TODO-DEFINE-PARAMETER Bond dissociation energy (K) for diss into resultingspecies (ReactNum,nspecies)? |
| Part-Species[\$]-Surf-ER[\$]-Powerfactor | 0.0 | TODO-DEFINE-PARAMETER |
| Part-Species[\$]-Surf-ER[\$]-Prefactor | 0.0 | TODO-DEFINE-PARAMETER |
| Surface-ExchReact[\$]-Reactants | (/ 0, 0 /) | TODO-DEFINE-PARAMETER |
| Surface-ExchReact[\$]-Products | (/ 0, 0 /) | TODO-DEFINE-PARAMETER |
| Surface-ExchReact[\$]-DissBond_K-Reactants | (/ 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| Surface-ExchReact[\$]-DissBond_K-Products | (/ 0.0, 0.0 /) | TODO-DEFINE-PARAMETER |
| Surface-Adsorption-CalcTST | 0 | TODO-DEFINE-PARAMETER |
| Surface-AdsorptionTST-PartitionMaxTemp | 10000.0 | TODO-DEFINE-PARAMETER Temperature limit for pre-stored partition function (DEF: 20 000K) |

| SurfaceModel | | |
|---|----------------|---|
| Surface-AdsorptionTST-PartitionInterval | 20.0 | TODO-DEFINE-PARAMETER Temperature interval for pre-stored partition function (DEF: 10K) |
| Surface Analyze | | |
| Variable | Default | Description |
| Surface-AnalyzeStep | 1 | Analyze is performed each Nth time step for surfaces |
| Surf-CalcNumSpec | F | TODO-DEFINE-PARAMETER Calculate the number of simulated particles per species on surfaces |
| Surf-CalcCoverage | F | TODO-DEFINE-PARAMETER Calculate the surface coverages for each species |
| Surf-CalcAccommodation | F | TODO-DEFINE-PARAMETER Calculate the surface accommodation coefficient |
| Surf-CalcEvaporation | F | TODO-DEFINE-PARAMETER Calculate rate of evaporation [kg/s] |
| Surf-CalcAdsorbRates | F | TODO-DEFINE-PARAMETER Calculate the adsorption probabilities of species |
| Surf-CalcSurfRates | F | TODO-DEFINE-PARAMETER Calculate the surface reaction rate per reaction (k_r) |

References