



## **Cisco Nexus 3000 Series NX-OS Layer 2 Switching Command Reference**

First Published: April 2011

Last Modified: August 2015

### **Cisco Systems, Inc.**

[www.cisco.com](http://www.cisco.com)

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

*Cisco Nexus 3000 Series NX-OS Layer 2 Switching Command Reference*  
© 2015 Cisco Systems, Inc. All rights reserved.



## **Preface 1**

Audience 1

Document Conventions 1

Related Documentation 2

Documentation Feedback 3

Obtaining Documentation and Submitting a Service Request 3

## **New and Changed Information 11**

### **Layer 2 Commands 1**

cdp 2

clear mac address-table dynamic 4

clear spanning-tree counters 6

clear spanning-tree detected-protocol 7

clear vtp counters 8

errdisable detect cause 9

errdisable recovery cause 10

errdisable recovery interval 12

feature private-vlan 13

feature vtp 14

instance vlan 15

ip igmp snooping (EXEC) 17

ip igmp snooping (VLAN) 18

link debounce 20

lldp 22

lldp tlv-set 25

mac address-table aging-time 27

mac address-table loop-detect port-down 29

mac address-table notification 30

mac address-table static 31

mac-learn 33

name (VLAN configuration)	35
name (MST configuration)	37
negotiate auto	38
private-vlan	40
private-vlan association	42
private-vlan synchronize	44
revision	45
show consistency-checker l2	46
show consistency-checker membership vlan	47
show consistency-checker stp-state vlan	48
show ip igmp snooping	49
show lldp	51
show mac-address-table	53
show mac address-table aging-time	55
show mac address-table count	56
show mac address-table notification	57
show mac address-table	58
show running-config spanning-tree	61
show running-config vlan	63
show running-config vtp	64
show spanning-tree	65
show spanning-tree active	68
show spanning-tree bridge	70
show spanning-tree brief	73
show spanning-tree detail	74
show spanning-tree interface	75
show spanning-tree mst	77
show spanning-tree root	79
show spanning-tree summary	81
show spanning-tree vlan	82
show udld	85
show vlan	87
show vlan dot1Q tag native	90
show vlan id	91
show vlan private-vlan	92

show vtp counters	94
show vtp interface	95
show vtp password	96
show vtp status	97
shutdown (VLAN configuration)	98
spanning-tree bpdupfilter	100
spanning-tree bpduguard	102
spanning-tree bridge	104
spanning-tree cost	105
spanning-tree guard	107
spanning-tree link-type	108
spanning-tree loopguard default	109
spanning-tree mode	110
spanning-tree mst configuration	111
spanning-tree mst cost	113
spanning-tree mst forward-time	115
spanning-tree mst hello-time	116
spanning-tree mst max-age	117
spanning-tree mst max-hops	118
spanning-tree mst port-priority	119
spanning-tree mst priority	120
spanning-tree mst root	121
spanning-tree mst simulate pvst	123
spanning-tree mst simulate pvst global	125
spanning-tree pathcost method	127
spanning-tree port type edge	128
spanning-tree port type edge bpdupfilter default	130
spanning-tree port type edge bpduguard default	132
spanning-tree port type edge default	134
spanning-tree port type network	136
spanning-tree port type network default	138
spanning-tree port-priority	140
spanning-tree vlan	142
state	144
storm-control	146

svi enable	148
switchport access vlan	149
switchport mode private-vlan host	150
switchport mode private-vlan promiscuous	152
switchport monitor rate-limit	153
switchport private-vlan host-association	154
switchport private-vlan mapping	156
vlan	158
vlan dot1Q tag native	160
vtp (interface)	162
vtp domain	163
vtp file	164
vtp mode	166
vtp password	167
vtp version	168



## Preface

---

This preface describes the audience, organization, and conventions of the *Cisco Nexus 3000 Series NX-OS Layer 2 Switching Command Reference*. It also provides information on how to obtain related documentation.

This preface includes the following sections:

- [Audience, page 1](#)
- [Document Conventions, page 1](#)
- [Related Documentation, page 2](#)
- [Obtaining Documentation and Submitting a Service Request, page 3](#)

## Audience

This publication is for experienced network administrators who configure and maintain Cisco Nexus Series switches.

## Document Conventions

Command descriptions use these conventions:

Convention	Description
boldface font	Commands and keywords are in boldface.
italic font	Arguments for which you supply values are in italics.
[ ]	Elements in square brackets are optional.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information that the switch displays are in screen font.
<b>boldface screen font</b>	Information that you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



#### Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



#### Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

Documentation for the Cisco Nexus 3000 Series Switch is available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps11541/tsd_products_support_series_home.html)

The documentation set is divided into the following categories:

### Release Notes

The release notes are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_release\\_notes\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_release_notes_list.html)

### Installation and Upgrade Guides

The installation and upgrade guides are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_installation\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_installation_guides_list.html)

### Command References

The command references are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_command_reference_list.html)

### Technical References

The technical references are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_technical\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_technical_reference_list.html)



**Configuration Guides**

The configuration guides are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps11541/products_installation_and_configuration_guides_list.html)

**Error and System Messages**

The system message reference guide is available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/products\\_system\\_message\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps11541/products_system_message_guides_list.html)

## Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to [nexus3k-docfeedback@cisco.com](mailto:nexus3k-docfeedback@cisco.com). We appreciate your feedback.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *[What's New in Cisco Product Documentation](#)*.

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the *[What's New in Cisco Product Documentation RSS feed](#)*. The RSS feeds are a free service.





## New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 3000 Series NX-OS Layer 2 Switching Command Reference*. The latest version of this document is available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps11541/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps11541/tsd_products_support_series_home.html)

To check for additional information about this Cisco NX-OS Release, see the *Cisco Nexus 3000 Series Switch Release Notes* available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps11541/prod\\_release\\_notes\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_release_notes_list.html)

**Table 1** summarizes the new and changed features, and tells you where they are documented.

**Table 1** *New and Changed Information*

Feature	Description	Changed in Release	Where Documented
Auto-negotiation	This feature cannot be configured when the speed is set as <b>speed auto</b> .	7.0(3)I2(1)	<ul style="list-style-type: none"> <li><a href="#">negotiate auto</a></li> </ul>
Discard Counters	This command can only be executed after running <b>attach module</b> .	7.0(3)I2(1)	<ul style="list-style-type: none"> <li><a href="#">show ip igmp snooping</a></li> </ul>
LLDP	Added new options for the <b>lldp tlv-select</b> and <b>lldp tlv-set</b> commands.	6.0(2)U4(1)	<ul style="list-style-type: none"> <li><a href="#">lldp</a></li> <li><a href="#">lldp tlv-set</a></li> </ul>
Storm Control Enhancements	Added shutdown and trap options as actions for storm control.	6.0(2)U3(1)	<ul style="list-style-type: none"> <li><a href="#">storm-control</a></li> </ul>
MAC Move Detection Action	Introduced this feature	6.0(2)U3(1)	<ul style="list-style-type: none"> <li><a href="#">mac address-table loop-detect port-down</a></li> <li><a href="#">show mac-address-table</a></li> </ul>
LLDP Management TLV IP Address	Commands to specify the IP address in the management TLV.	6.0(2)U3(1)	<a href="#">lldp tlv-set</a>
Consistency checkers	Commands to trigger consistency checkers on MAC addresses, stp states of interfaces in a VLAN, and members of a VLAN added.	6.0(2)U2(1)	<ul style="list-style-type: none"> <li><a href="#">show consistency-checker l2</a></li> <li><a href="#">show consistency-checker membership vlan</a></li> <li><a href="#">show consistency-checker stp-state vlan</a></li> </ul>
Speed non-negotiation	This feature was introduced to enable or disable auto-negotiation on 1 Gigabit ports.	5.0(3)U2(1)	<a href="#">negotiate auto</a>

**Table 1**      ***New and Changed Information (continued)***

<b>Feature</b>	<b>Description</b>	<b>Changed in Release</b>	<b>Where Documented</b>
Support for Granular Input Packet Discards Information	This feature was introduced.	5.0(3)U2(1)	<a href="#">show consistency-checker l2</a>
Layer 2 interfaces	This feature was introduced. You can configure Layer 2 Ethernet interfaces, loopback interfaces, and EtherChannel interfaces.	5.0(3)U1(1)	<a href="#">Layer 2 Commands</a>
VLAN Trunking Protocol (VTP)	This feature was introduced. You can configure the VTP device mode as transparent. You can also configure the VTP database file, set the password for the VTP administrative domain, or enable VTP on an interface.	5.0(3)U1(1)	<a href="#">feature vtp</a> <a href="#">vtp (interface)</a> <a href="#">vtp domain</a> <a href="#">vtp file</a> <a href="#">vtp mode</a> <a href="#">vtp password</a> <a href="#">vtp version</a> <a href="#">show vtp counters</a> <a href="#">show vtp interface</a> <a href="#">show vtp password</a> <a href="#">show vtp status</a>



## Layer 2 Commands

---

This chapter describes the Cisco NX-OS Layer 2 commands available on Cisco Nexus 3000 Series switches.

# cdp

To enable the Cisco Discovery Protocol (CDP) and configure CDP attributes, use the **cdp** command. To disable CDP or reset CDP attributes, use the **no** form of this command.

**cdp** {**advertise** {**v1** | **v2**} | **enable** | **format device-id** {**mac-address** | **serial-number** | **system-name**} | **holdtime** *seconds* | **timer** *seconds*}

**no cdp** {**advertise** | **enable** | **format device-id** {**mac-address** | **serial-number** | **system-name**} | **holdtime** *seconds* | **timer** *seconds*}

## Syntax Description

<b>advertise</b> { <b>v1</b>   <b>v2</b> }	Configures the version to use to send CDP advertisements. Version-2 is the default state.
<b>enable</b>	Enables CDP for all Ethernet interfaces.
<b>format device-id</b>	Configures the format of the CDP device ID.
<b>mac-address</b>	Uses the MAC address as the CDP device ID.
<b>serial-number</b>	Uses the serial number as the CDP device ID.
<b>system-name</b>	Uses the system name, which can be expressed as a fully qualified domain name, as the CDP device ID. This is the default.
<b>holdtime</b> <i>seconds</i>	Specifies the amount of time a receiver should hold CDP information before discarding it. The range is from 10 to 255 seconds; the default is 180 seconds.
<b>timer</b> <i>seconds</i>	Sets the transmission frequency of CDP updates in seconds. The range is from 5 to 254; the default is 60 seconds.

## Command Default

None

## Command Modes

Global configuration mode  
Switch profile configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Examples

This example shows how to configure CDP advertisements on a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# cdp advertise v1
switch(config-sync-sp)#
```

This example shows how to configure the MAC address as the CDP device ID in a switch profile:

```
switch# configure sync
```

```
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# cdp format device-id mac-address
switch(config-sync-sp)#
```

This example shows how to enable CDP on all Ethernet interfaces:

```
switch# configure terminal
switch(config)# cdp enable
switch(config)#
```

This example shows how to configure the MAC address as the CDP device ID:

```
switch# configure terminal
switch(config)# cdp format device-id mac-address
switch(config)#
```

This example shows how to disable CDP on all Ethernet interfaces:

```
switch# configure terminal
switch(config)# no cdp enable
switch(config)#
```

#### Related Commands

Command	Description
<b>show cdp</b>	Displays Cisco Discovery Protocol (CDP) information.
<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
<b>switch-profile</b>	Creates or configures a switch profile.

# clear mac address-table dynamic

To clear the dynamic address entries from the MAC address table, use the **clear mac address-table dynamic** command.

```
clear mac address-table dynamic [[address mac-addr] | [interface {ethernet slot/port |  
port-channel number}] ] [vlan vlan-id]
```

<b>Syntax Description</b>	<b>address</b> <i>mac-addr</i>	(Optional) Specifies the MAC address to remove from the table. Use the format EEEE.EEEE.EEEE.
	<b>interface</b>	(Optional) Specifies the interface for which MAC addresses should be removed from the table. The type can be either Ethernet or EtherChannel.
	<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel for which MAC addresses should be removed from the table. Use the EtherChannel number. The <i>number</i> range is from 1 to 4096.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN from which MAC addresses should be removed from the table. The VLAN ID range is from 1 to 4092.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode Global configuration mode Switch profile configuration mode
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
	5.0(3)U2(1)	Support for this command was introduced in switch profiles.

<b>Usage Guidelines</b>	Use the <b>clear mac address-table dynamic</b> command with no arguments to remove all dynamic entries from the table.
-------------------------	--

To clear static MAC addresses from the table, use the **no mac address-table static** command.

If the **clear mac address-table dynamic** command is entered with no options, all dynamic addresses are removed. If you specify an address but do not specify an interface, the address is deleted from all interfaces. If you specify an interface but do not specify an address, the switch removes all addresses on the specified interfaces.

This command does not require a license.



## Examples

This example shows how to clear all the dynamic entries from the MAC address table:

```
switch# clear mac address-table dynamic
switch#
```

This example shows how to clear all the dynamic entries from the MAC address table for VLAN 2:

```
switch# clear mac address-table dynamic vlan 2
switch#
```

This example shows how to clear all the dynamic entries from the MAC address table in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# mac-learn disable
switch(config-sync-sp)# clear mac address-table dynamic
switch(config-sync-sp)#
```

## Related Commands

Command	Description
<b>show mac address-table</b>	Displays the information about the MAC address table.
<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
<b>switch-profile</b>	Creates or configures a switch profile.

# clear spanning-tree counters

To clear the counters for the Spanning Tree Protocol (STP), use the **clear spanning-tree counters** command.

**clear spanning-tree counters** [**interface** {**ethernet** *interface* | **port-channel** *channel*}] [**vlan** *vlan-id*]

<b>Syntax Description</b>	<b>interface</b>	(Optional) Specifies the interface type.
	<b>ethernet</b> <i>interface</i>	Specifies the slot and port number.
	<b>port-channel</b> <i>channel</i>	Specifies the EtherChannel number.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN. The range is from 1 to 4094.

**Command Default** None

**Command Modes** EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** You can clear all the STP counters on the entire switch, per VLAN, or per interface. This command does not require a license.

**Examples** This example shows how to clear the STP counters for VLAN 5:

```
switch# clear spanning-tree counters vlan 5
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree</b>	Displays information about the spanning tree state.

# clear spanning-tree detected-protocol

To restart the protocol migration, use the **clear spanning-tree detected-protocol** command. With no arguments, the command is applied to every port of the switch.

**clear spanning-tree detected-protocol** [**interface** {**ethernet** *interface* | **port-channel** *channel*}]

## Syntax Description

<b>interface</b>	(Optional) Specifies the interface type.
<b>ethernet</b> <i>interface</i>	Specifies the slot and port number.
<b>port-channel</b> <i>channel</i>	Specifies the EtherChannel number.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Rapid per VLAN Spanning Tree Plus (Rapid PVST+) and Multiple Spanning Tree (MST) have built-in compatibility mechanisms that allow them to interact properly with other versions of IEEE spanning tree or other regions. For example, a switch running Rapid PVST+ can send 802.1D bridge protocol data units (BPDUs) on one of its ports when it is connected to a legacy device. An MST switch can detect that a port is at the boundary of a region when it receives a legacy BPDU or an MST BPDU that is associated with a different region.

These mechanisms are not always able to revert to the most efficient mode. For example, a Rapid PVST+ switch that is designated for a legacy 802.1D bridge stays in 802.1D mode even after the legacy bridge has been removed from the link. Similarly, an MST port assumes that it is a boundary port when the bridges to which it is connected have joined the same region.

To force a port to renegotiate with its neighbors, enter the **clear spanning-tree detected-protocol** command.

This command does not require a license.

## Examples

This example shows how to restart the protocol migration on a specific interface:

```
switch# clear spanning-tree detected-protocol interface ethernet 1/4
switch#
```

## Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning tree state.

# clear vtp counters

To clear VLAN Trunking Protocol (VTP) counters, use the **clear vtp counters** command.

**clear vtp counters**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>Use this command to clear the VTP statistics, such as the VTP requests, VTP advertisements, and configuration revisions.</p> <p>This command does not require a license.</p>
-------------------------	---

<b>Examples</b>	<p>This example shows how to clear the VTP counters:</p> <pre>switch# clear vtp counters switch#</pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show vtp counters</b>	Displays VTP counters.
	<b>show vtp status</b>	Displays VTP information.

# errdisable detect cause

To enable error-disable (err-disabled) detection in an application, use the **errdisable detect cause** command. To disable error disable detection, use the **no** form of this command.

**errdisable detect cause {all | link-flap | loopback}**

**no errdisable detect cause {all | link-flap | loopback}**

## Syntax Description

<b>all</b>	Enables error detection on all cases.
<b>link-flap</b>	Enables error disable detection on linkstate-flapping.
<b>loopback</b>	Enables error disable detection on loopback.

## Command Default

Enabled

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

When error disable detection is enabled and a cause is detected on an interface, the interface is placed in an err-disabled state, which is an operational state that is similar to the link-down state.

This command does not require a license.

## Examples

This example shows how to enable the err-disabled detection on linkstate-flapping:

```
switch# configure terminal
switch(config)# errdisable detect cause link-flap
switch(config)#
```

## Related Commands

Command	Description
<b>errdisable recovery</b>	Configures recovery from the err-disabled state.
<b>show interface status err-disabled</b>	Displays the interface error disabled state.

# errdisable recovery cause

To configure the application to bring the interface out of the error-disabled (err-disabled) state and retry coming up, use the **errdisable recovery cause** command. To revert to the defaults, use the **no** form of this command.

**errdisable recovery cause** {all | bpduguard | failed-port-state | link-flap-recovery | pause-rate-limit | storm-control | udld}

**no errdisable recovery cause** {all | bpduguard | failed-port-state | link-flap-recovery | pause-rate-limit | storm-control | udld}

## Syntax Description

<b>all</b>	Enables the timer to recover from all causes.
<b>bpduguard</b>	Enables the timer to recover from the bridge protocol data unit (BPDU) Guard error-disabled state.
<b>failed-port-state</b>	Enables the timer to recover from a stp set port state failure.
<b>link-flap</b>	Enables the timer to recover from linkstate flapping.
<b>loopback</b>	Enables the timer to recover from the loopback error disabled state.
<b>pause-rate-limit</b>	Enables the timer to recover from the pause rate limit error-disabled state.
<b>storm-control</b>	Enables the timer to recover from the storm control error-disabled state.
<b>udld</b>	Enables the timer to recover from the Unidirectional Link Detection (UDLD) error-disabled state.

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
6.0(2)U3(1)	The <b>storm-control</b> option was added.
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

When an error-disables recovery is enabled, the interface automatically recovers from the error-disabled state, and the device retries bringing the interface up.

This command does not require a license.

## Examples

This example shows how to enable an error-disabled recovery from linkstate flapping:

```
switch# configure terminal
switch(config)# errdisable recovery cause link-flap
switch(config)#
```

This example shows how to enable an error-disabled recovery from storm control error disabled state:

```
switch# configure terminal
switch(config)# errdisable recovery cause storm-control
switch(config)#
```

**Related Commands**

Command	Description
<b>errdisable detect cause</b>	Enables the error-disabled (err-disabled) detection.
<b>show interface status err-disabled</b>	Displays the interface error-disabled state.

# errdisable recovery interval

To configure the recovery time interval to bring the interface out of the error-disabled (err-disabled) state, use the **errdisable recovery interval** command. To revert to the defaults, use the **no** form of this command.

**errdisable recovery interval** *time*

**no errdisable recovery interval**

<b>Syntax Description</b>	<i>time</i> Error disable recovery time interval. The range is from 30 to 65535 seconds.	
<b>Command Default</b>	Disabled	
<b>Command Modes</b>	Global configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	<p>When error disable recovery is enabled, the interface automatically recovers from the err-disabled state, and the device retries bringing the interface up.</p> <p>The device waits 300 seconds to retry.</p> <p>This command does not require a license.</p>	
<b>Examples</b>	<p>This example shows how to enable error disable recovery time interval to 100 seconds:</p> <pre>switch# configure terminal switch(config)# errdisable recovery interval 100 switch(config)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>errdisable recovery cause</b>	Enables an error-disabled recovery on an interface.
	<b>show interface status err-disabled</b>	Displays the interface error-disabled state.



# feature private-vlan

To enable private VLANs, use the **feature private-vlan** command. To return to the default settings, use the **no** form of this command.

**feature private-vlan**

**no feature private-vlan**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Private VLANs are disabled.

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The private VLAN commands are not available until you enable the private VLAN feature. You cannot disable the private VLANs if there are operational ports on the switch that are in private VLAN mode.



**Note**

A private VLAN-isolated port on a Cisco Nexus 3000 Series switch running the current release of Cisco NX-OS does not support IEEE 802.1Q encapsulation and cannot be used as a trunk port.

This command does not require a license.

**Examples** This example shows how to enable private VLAN functionality on the switch:

```
switch# configure terminal
switch(config)# feature private-vlan
switch(config)#
```

Related Commands	Command	Description
	<b>private-vlan</b>	Configures a VLAN as either a community, isolated, or primary private VLAN.
	<b>show vlan private-vlan</b>	Displays information on private VLANs. If the feature is not enabled, this command is not available.
	<b>show feature</b>	Displays whether or not private VLAN is enabled on the switch.

# feature vtp

To enable VLAN Trunking Protocol (VTP), use the **feature vtp** command. To disable VTP, use the **no** form of this command.

**feature vtp**

**no feature vtp**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Examples</b>	This example shows how to enable VTP on the switch:
-----------------	---

```
switch# configure terminal
switch(config)# feature vtp
switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show vtp status</b>	Displays the VTP information.
	<b>vtp</b>	Configures VTP.

# instance vlan

To map a VLAN or a set of VLANs to a Multiple Spanning Tree instance (MSTI), use the **instance vlan** command. To delete the instance and return the VLANs to the default instance (Common and Internal Spanning Tree [CIST]), use the **no** form of this command.

**instance** *instance-id* **vlan** *vlan-id*

**no instance** *instance-id* [**vlan** *vlan-id*]

## Syntax Description

<i>instance-id</i>	Instances to which the specified VLANs are mapped. The range is from 0 to 4094.
<b>vlan</b> <i>vlan-id</i>	Specifies the number of the VLANs that you are mapping to the specified MSTI. The VLAN ID range is from 1 to 4094.

## Command Default

No VLANs are mapped to any MST instance (all VLANs are mapped to the CIST instance).

## Command Modes

MST configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The VLAN identifier is entered as a single value or a range.

The mapping is incremental, not absolute. When you enter a range of VLANs, this range is added to or removed from the existing instances.

Any unmapped VLAN is mapped to the CIST instance.



### Caution

When you change the VLAN-to-MSTI mapping, the system restarts MST.

This command does not require a license.

## Examples

This example shows how to map a range of VLANs to MSTI 4:

```
switch# configure terminal
switch(config)# spanning-tree mst configuration
switch(config-mst)# instance 4 vlan 100-200
switch(config-mst)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst configuration</b>	Displays information about the MST protocol.
	<b>spanning-tree mst configuration</b>	Enters MST configuration mode.

# ip igmp snooping (EXEC)

To enable Internet Group Management Protocol (IGMP), use the **ip igmp snooping** command. To disable IGMP snooping, use the **no** form of this command.

**ip igmp snooping**

**no ip igmp snooping**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	IGMP snooping is enabled.
------------------------	---------------------------

**Note**

If the global setting is disabled, then all VLANs are treated as disabled, whether they are enabled or not.

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Examples</b>	This example shows how to enable IGMP snooping:
-----------------	---

```
switch# ip igmp snooping
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip igmp snooping</b>	Displays IGMP snooping information and configuration.

# ip igmp snooping (VLAN)

To configure Internet Group Management Protocol (IGMP) on a VLAN, use the **ip igmp snooping** command. To negate the command or return to the default settings, use the **no** form of this command

**ip igmp snooping** *parameter*

**no ip igmp snooping** *parameter*

## Syntax Description

<i>parameter</i>	Parameter to configure. See the “Usage Guidelines” section for additional information.
------------------	--

## Command Default

The default settings are as follows:

- **explicit-tracking**—enabled
- **fast-leave**—disabled for all VLANs
- **last-member-query-interval** *seconds*—1
- **querier** *IP-address*—disabled
- **report-suppression**—enabled

## Command Modes

VLAN configuration mode  
Switch profile VLAN configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.
5.0(3)U2(1)	Support was added for the following IGMP parameters in a switch profile: <ul style="list-style-type: none"> <li>• link-local-groups-suppression</li> <li>• optimised-multicast-flood</li> <li>• v3-report-suppression</li> </ul>

## Usage Guidelines

[Table 1](#) lists the valid values for *parameter*.

**Table 1 IGMP Snooping Parameters**

Keyword and Argument	Description
<b>explicit-tracking</b>	Enables tracking IGMPv3 membership reports for each port on a per-VLAN basis. The default is enabled on all VLANs.
<b>fast-leave</b>	Enables IGMPv3 snooping fast-leave processing. The default is disabled for all VLANs.
<b>last-member-query-interval</b> <i>seconds</i>	Removes the group if no hosts respond to an IGMP query message. The valid value is from 1 to 25 seconds. The default is 1 second.

**Table 1** IGMP Snooping Parameters (continued)

Keyword and Argument	Description
<b>link-local-groups-suppression</b>	Enables suppression of IGMP reports from link-local groups.
<b>mrouter interface</b> <i>interface</i>	Configures a static connection to a multicast router. The specified interface is Ethernet or EtherChannel.
<b>optimised-multicast-flood</b>	Configures Optimized Multicast Flood (OMF) on all VLANs.
<b>querier</b> <i>IP-address</i>	Configures a snooping querier. The IP address is used as the source in messages. The default is disabled.
<b>report-suppression</b>	Limits the membership report traffic sent to multicast-capable routers. When you disable report suppression, all IGMP reports are sent as is to multicast-capable routers. The default is enabled.
<b>static-group</b> <i>group-ip-addr</i> [ <b>source</b> <i>source-ip-addr</i> ] <b>interface</b> <i>interface</i>	Configures an interface belonging to a VLAN as a static member of a multicast group. The specified interface is Ethernet or EtherChannel.
<b>v3-report-suppression</b>	Configures IGMPv3 report suppression and proxy reporting for VLANs.

This command does not require a license.

### Examples

This example shows how to configure IGMP snooping parameters for VLAN 5:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# ip igmp snooping last-member-query-interval 3
switch(config-vlan)# ip igmp snooping querier 192.168.2.106
switch(config-vlan)# ip igmp snooping explicit-tracking
switch(config-vlan)# ip igmp snooping fast-leave
switch(config-vlan)# ip igmp snooping report-suppression
switch(config-vlan)# ip igmp snooping mrouter interface ethernet 1/10
switch(config-vlan)# ip igmp snooping static-group 192.168.1.1 interface ethernet 1/10
switch(config-vlan)#
```

### Related Commands

Command	Description
<b>show ip igmp snooping</b>	Displays the IGMP snooping information and configuration.

# link debounce

To enable the debounce timer on an interface, use the **link debounce** command. To disable the timer, use the **no** form of this command.

**link debounce** [*time milliseconds*]

**no link debounce**

<b>Syntax Description</b>	<b>time milliseconds</b> (Optional) Specifies the extended debounce timer. The range is from 0 to 5000 milliseconds. A value of 0 milliseconds disables the debounce time.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	The port debounce time is the amount of time that an interface waits to notify the supervisor of a link going down. During this time, the interface waits to see if the link comes back up. The wait period is a time when traffic is stopped.
-------------------------	--

**Caution**

When you enable the debounce timer, link up and link down detections are delayed, resulting in a loss of traffic during the debounce period. This situation might affect the convergence of some protocols.

This command does not require a license.

<b>Examples</b>	This example shows how to enable the debounce timer and set the debounce time to 1000 milliseconds for an Ethernet interface:
-----------------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# link debounce time 1000
switch(config-if)#
```

This example shows how to disable the debounce timer for an Ethernet interface:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# no link debounce
switch(config-if)#
```



Related Commands	Command	Description
	<b>show interface ethernet</b>	Displays the interface configuration information.
	<b>show interface debounce</b>	Displays the debounce time information for all interfaces.

# lldp

To configure the Link Layer Discovery Protocol (LLDP) global options, use the **lldp** command. To remove the LLDP settings, use the **no** form of this command.

**lldp** { **holdtime** *seconds* | **reinit** *seconds* | **timer** *seconds* | **tlv-select** { **dcbxp** | **management-address** [**v4** | **v6**] | **port-description** | **port-vlan** | **system-capabilities** | **system-description** | **system-name** } }

**no lldp** { **holdtime** | **reinit** | **timer** | **tlv-select** { **dcbxp** | **management-address** | **port-description** | **port-vlan** | **system-capabilities** | **system-description** | **system-name** } }

## Syntax Description

<b>holdtime</b> <i>seconds</i>	Specifies the hold time (in seconds) to set the length of time that a device should save LLDP information received before discarding it. The range is from 10 to 255, and the default is 120 seconds.
<b>reinit</b> <i>seconds</i>	Specifies the length of time (in seconds) to wait before performing LLDP initialization on any interface. The range is from 1 to 10 seconds, and the default is 2 seconds.
<b>timer</b> <i>seconds</i>	Specifies the rate (in seconds) at which LLDP packets are sent. The range is from 5 to 254 seconds, and the default is 30 seconds.
<b>tlv-select</b>	Specifies the Type Length Value (TLV) message.
<b>dcbxp</b>	Specifies the Data Center Ethernet Parameter Exchange (DCBXP) TLV messages.
<b>management-address</b>	Specifies the management address TLV messages.
<b>management-address v4</b>	Specifies the IPv4 management address TLV messages.
<b>management-address v6</b>	Specifies the IPv6 management address TLV messages.
<b>port-description</b>	Specifies the port description TLV messages.
<b>port-vlan</b>	Specifies the port VLAN ID TLV messages.
<b>system-capabilities</b>	Specifies the system capabilities TLV messages.
<b>system-description</b>	Specifies the system description TLV messages.
<b>system-name</b>	Specifies the system name TLV messages.

## Command Default

Holdtime (before discarding): 120 seconds.  
Reinitialization delay: 2 seconds.  
Timer (packet update frequency): 30 seconds.  
TLV-select: Enabled to send and receive all TLVs.

## Command Modes

Global configuration mode  
Switch profile configuration mode

**Command History**

Release	Modification
6.0(2)U4(1)	the <b>v4</b> and <b>v6</b> command options were introduced for the management-address keyword.
5.0(3)U2(1)	Support was added to configure LLDP options in switch profiles.
5.0(3)U1(1)	This command was introduced.

**Usage Guidelines****Note**

LLDP, which is a neighbor discovery protocol that is used for network devices to advertise information about themselves to other devices on the network, is enabled on the switch by default.

The LLDP settings include the length of time before discarding LLDP information received from peers, the length of time to wait before performing LLDP initialization on any interface, and the rate at which LLDP packets are sent.

LLDP supports a set of attributes that it uses to discover neighbor devices. These attributes contain type, length, and value descriptions and are referred to as TLVs. LLDP supported devices can use TLVs to receive and send information to their neighbors. Details such as configuration information, device capabilities, and device identity can be advertised using this protocol.

The switch supports these basic management TLVs. These are mandatory LLDP TLVs.

- Data Center Ethernet Parameter Exchange (DCBXP) TLV
- Management address TLV
- Port description TLV
- Port VLAN ID TLV (IEEE 802.1 organizationally specific TLVs)
- System capabilities TLV
- System description TLV
- System name TLV

The Data Center Bridging Exchange Protocol (DCBXP) is an extension of LLDP. It is used to announce, exchange, and negotiate node parameters between peers. DCBXP parameters are packaged into a specific DCBXP TLV. This TLV is designed to provide an acknowledgement to the received LLDP packet.

DCBXP is enabled by default, provided LLDP is enabled. When LLDP is enabled, DCBXP can be enabled or disabled using the **[no] lldp tlv-select dcbxp** command. DCBXP is disabled on ports where LLDP transmit or receive is disabled.

This command does not require a license.

**Examples**

This example shows how to configure the global LLDP holdtime to 200 seconds:

```
switch# configure terminal
switch(config)# lldp holdtime 200
switch(config)#
```

This example shows how to enable LLDP to send or receive the management address TLVs:

```
switch# configure terminal
switch(config)# lldp tlv-select management-address
```

```
switch(config)#
```

This example shows how to enable LLDP to send or receive IPv4 management address TLVs:

```
switch# configure terminal
switch(config)# lldp tlv-select management-address v4
switch(config)#
```

This example shows how to enable LLDP to send or receive IPv6 management address TLVs:

```
switch# configure terminal
switch(config)# lldp tlv-select management-address v6
switch(config)#
```

This example shows how to disable LLDP to send or receive the DCBXP TLVs:

```
switch# configure terminal
switch(config)# no lldp tlv-select dcbxp
switch(config)#
```

This example shows how to configure the LLDP packet rate to 60 seconds in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# lldp timer 60
switch(config-sync-sp)#
```

## Related Commands

Command	Description
<b>lldp (Interface)</b>	Configures the LLDP feature on an interface.
<b>show lldp</b>	Displays the LLDP configuration information.
<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
<b>switch-profile</b>	Creates or configures a switch profile.

# lldp tlv-set

To specify the management IP address to be sent in the LLDP management TLV, use the **lldp tlv-set** command. To remove the specified management IP address from the LLDP management TLV, use the **no** form of this command.

**lldp tlv-set** { **management-address** *ip-address* [**ipv6**] | **vlan** [*vlan-id*] }

**no lldp tlv-set** { **management-address** *ip-address* [**ipv6**] | **vlan** [*vlan-id*] }

## Syntax Description

<b>management-address</b> <i>ip-address</i>	Specifies the IPv4 address of a port to be sent in the LLDP management TLV.
<b>management-address</b> <i>ip-address</i> <b>ipv6</b>	Specifies the IPv6 address of a port to be sent in the LLDP management TLV.
<b>vlan</b> <i>vlan-id</i>	Specifies the SVI IP address of the VLAN to be sent in the LLDP management TLV.

## Command Default

IP address of the management port mgmt0.

## Command Modes

Global configuration mode

## Command History

Release	Modification
6.0(2)U4(1)	The <b>ipv6</b> option was introduced.
6.0(2)U3(1)	This command was introduced.

## Usage Guidelines

Before configuring the LLDP management TLV IP address, ensure that the LLDP management TLV option is configured.

## Examples

This example shows how to specify the management IPv4 address in the management TLV:

```
switch# configure terminal
switch(config)# interface ethernet 1/8
switch(config-if)# lldp tlv-set management-address 1.1.1.20
```

This example shows how to specify the management IPv6 address in the management TLV:

```
switch# configure terminal
switch(config)# interface ethernet 1/8
switch(config-if)# lldp tlv-set management-address 0dc3:0dc3:0000:0000:0218:baff:fed8:239d
ipv6
```

This example shows how to specify the VLAN ID in the management TLV:

```
switch# configure terminal
switch(config)# lldp tlv-set vlan 10
switch(config)#
```

Related Commands	Command	Description
	<b>lldp</b>	Configures the LLDP global options.
	<b>show lldp</b>	Displays the LLDP configuration information.

# mac address-table aging-time

To configure the aging time for entries in the MAC address table, use the **mac address-table aging-time** command. To return to the default settings, use the **no** form of this command.

**mac address-table aging-time** *seconds* [**vlan** *vlan-id*]

**no mac address-table aging-time** [**vlan** *vlan-id*]

<b>Syntax Description</b>	<i>seconds</i>	Aging time for MAC address table entries. The range is from 0 to 1000000 seconds. The default is 300 seconds. Entering 0 disables MAC address aging.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN to which the changed aging time should be applied. The range is from 1 to 3967 and 4048 to 4093.

<b>Command Default</b>	300 seconds
------------------------	-------------

<b>Command Modes</b>	Global configuration mode Switch profile configuration mode
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
	5.0(3)U2(1)	Support to configure MAC address table aging time was added to switch profiles.

<b>Usage Guidelines</b>	Enter 0 seconds to disable the aging process.
	The age value may be rounded off to the nearest multiple of 5 seconds. If the system rounds the value to a different value from that specified by the user (from the rounding process), the system returns an informational message.
	When you use this command, the age values of all VLANs for which a configuration has not been specified are modified and those VLANs with specifically modified aging times are not modified. When you use the <b>no</b> form of this command without the VLAN parameter, only those VLANs that have not been specifically configured for the aging time reset to the default value. Those VLANs with specifically modified aging times are not modified.
	When you use this command and specify a VLAN, the aging time for only the specified VLAN is modified. When you use the <b>no</b> form of this command and specify a VLAN, the aging time for the VLAN is returned to the current global configuration for the aging time, which may or may not be the default value of 300 seconds depending if the global configuration of the switch for the aging time has been changed.



## Note

In Cisco NX-OS Release 5.0(3)U1(1), you can configure the MAC aging timer on a global basis but not on a per VLAN basis.

The aging time is counted from the last time that the switch detected the MAC address.

This command does not require a license.

## Examples

This example shows how to change the length of time an entry remains in the MAC address table to 500 seconds for the entire switch:

```
switch# configure terminal
switch(config)# mac address-table aging-time 500
switch(config)#
```

This example shows how to change the length of time an entry remains in the MAC address table to 300 seconds for a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# mac address-table aging-time 300
switch(config-sync-sp)#
```

## Related Commands

Command	Description
<b>show mac address-table</b>	Displays information about the MAC address table.
<b>show mac address-table aging-time</b>	Displays information about the MAC address aging time.
<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
<b>switch-profile</b>	Creates or configures a switch profile.



# mac address-table loop-detect port-down

To configure the action of bringing down the port with the lower interface index when a MAC address move loop is detected between two ports, use the **mac address-table loop-detect port-down** command. To revert to the default action of disabling MAC learning, use the **no** form of this command.

**mac address-table loop-detect port-down**

**no mac address-table loop-detect port-down**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)U3(1)	This command was introduced.

**Usage Guidelines** When the number of MAC address moves between two ports exceeds a threshold, it forms a loop. Until Cisco NX-OS Release 6.0(2)U3(1), when a loop was detected between two ports, MAC learning was disabled for 180 seconds. You can now configure the action of bringing down the port with the lower interface index when such a loop is detected by using the **mac address-table loop-detect port-down** command.

**Examples** This example shows how to configure port-down as the action for MAC move loop detection:

```
switch# configure terminal
switch(config)# mac address-table loop-detect port-down
switch(config)# show mac address-table loop-detect
Port Down Action Mac Loop Detect : enabled
```

Related Commands	Command	Description
	<b>show mac address-table loop-detect</b>	Displays the currently configured action for loop detection in the MAC address table.

# mac address-table notification

To configure a log message notification of MAC address table events, use the **mac address-table notification** command. To disable log message notifications, use the **no** form of this command.

**mac address-table notification** { **mac-move** | **threshold** [**limit** *percentage* **interval** *seconds*] }

**no mac address-table notification** { **mac-move** | **threshold** }

## Syntax Description

<b>mac-move</b>	Sends a notification message if the MAC address is moved.
<b>threshold</b>	Sends a notification message if the MAC address table threshold is exceeded.
<b>limit</b> <i>percentage</i>	(Optional) Specifies the percentage limit (1 to 100) beyond which threshold notifications are enabled.
<b>interval</b> <i>seconds</i>	(Optional) Specifies the minimum time in seconds (10 to 10000) between two notifications.

## Command Default

MAC move threshold triggers: 0  
Threshold limit: 50  
Threshold interval: 120

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Examples

This example shows how to configure a log message notification when the threshold exceeds 45 percent, restricting the update interval to once every 1024 seconds:

```
switch# configure terminal
switch(config)# mac address-table notification threshold limit 45 interval 1024
switch(config)#
```

## Related Commands

Command	Description
<b>show mac address-table</b>	Displays information about the MAC address table.

# mac address-table static

To configure a static entry for the MAC address table, use the **mac address-table static** command. To delete the static entry, use the **no** form of this command.

**mac address-table static** *mac-address* **vlan** *vlan-id* { **drop** | **interface** { **ethernet** *slot/port* | **port-channel** *number* } } [ **auto-learn** ]

**no mac address-table static** *mac-address* { **vlan** *vlan-id* }

## Syntax Description

<i>mac-address</i>	MAC address to add to the table. Use the format EEEE.EEEE.EEEE.
<b>vlan</b> <i>vlan-id</i>	Specifies the VLAN to apply the static MAC address. The VLAN ID range is from 1 to 3967 and 4048 to 4093.
<b>drop</b>	Drops all traffic that is received from and going to the configured MAC address in the specified VLAN.
<b>interface</b>	Specifies the interface. The type can be either Ethernet or EtherChannel.
<b>ethernet</b> <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<b>auto-learn</b>	(Optional) Allows the switch to automatically update this MAC address.

## Command Default

None

## Command Modes

Global configuration mode  
Switch profile configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.
5.0(3)U2(1)	Support was added to configure static MAC address table entries in switch profiles.

## Usage Guidelines

You cannot apply the **mac address-table static** *mac-address* **vlan** *vlan-id* **drop** command to a multicast MAC address.

When you install a static MAC address, it is associated with a port. If the same MAC address is seen on a different port, the entry is updated with the new port if you enter the **auto-learn** keyword.

This command does not require a license.

## Examples

This example shows how to add a static entry to the MAC address table:

```
switch# configure terminal
```

```
switch(config)# mac address-table static 0050.3e8d.6400 vlan 3 interface ethernet 1/4
switch(config)#
```

This example shows how to add a static entry to the MAC address table in a switch profile:

```
switch# config sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# mac address-table static 0050.3e8d.6400 vlan 3 interface ethernet
1/2
switch(config-sync-sp)#
```

#### Related Commands

Command	Description
<b>show mac address-table</b>	Displays information about the MAC address table.
<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
<b>switch-profile</b>	Creates or configures a switch profile.

# mac-learn

To control the learning of MAC addresses per interface, use the **mac-learn** command. To delete the list, use the **no** form of this command.

**mac-learn disable**

**no mac-learn disable**

Syntax Description	disable	Disables MAC learning on the specified interface.
--------------------	---------	---

Command Default	Enabled
-----------------	---------

Command Modes	Global configuration mode Switch profile configuration mode
---------------	--

Command History	Release	Modification
	5.0(3)U2(1)	This command was introduced.

Usage Guidelines	<p>By default, each interface automatically learns the MAC addresses of entering traffic.</p> <p>After you disable MAC learning, enter the <b>clear mac address-table dynamic</b> command to clear the dynamic address entries from the MAC address table.</p> <p>The <b>no</b> form of this command reenables MAC address learning.</p> <p>This command does not require a license.</p>
------------------	--

Examples	<p>This example shows how to disable MAC address learning on the switch and then clear the the dynamic address entries from the MAC address table:</p>
----------	--

```
switch# configure terminal
switch(config)# mac-learn disable
switch(config)# clear mac address-table dynamic
switch(config)#
```

This example shows how to disable MAC address learning on a switch profile, and then clear the the dynamic address entries from the MAC address table:

```
switch# config sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# mac-learn disable
switch(config-sync-sp)# clear mac address-table dynamic
switch(config-sync-sp)#
```

Related Commands	Command	Description
	<b>clear mac address-table dynamic</b>	Clears the dynamic address entries from the MAC address table.
	<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
	<b>switch-profile</b>	Creates or configures a switch profile.

## name (VLAN configuration)

To set the name for a VLAN, use the **name** command. To remove the user-configured name from a VLAN, use the **no** form of this command.

**name** *vlan-name*

**no name**

<b>Syntax Description</b>	<i>vlan-name</i>	Name of the VLAN; you can use up to 32 alphanumeric, case-sensitive characters. The default name is VLANxxxx where xxxx represents four numeric digits (including leading zeroes) equal to the VLAN ID number (for example, VLAN0002).
---------------------------	------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	VLAN configuration mode Switch profile VLAN configuration mode
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
	5.0(3)U2(1)	Support for this command was introduced in switch profiles.

<b>Usage Guidelines</b>	You cannot change the name for the default VLAN, VLAN 1, or for the internally allocated VLANs. This command does not require a license.
-------------------------	---

<b>Examples</b>	This example shows how to name VLAN 2:
-----------------	--

```
switch# configure terminal
switch(config)# vlan 2
switch(config-vlan)# name accounting
switch(config-vlan)#
```

This example shows how to name VLAN 3 in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# vlan 3
switch(config-sync-sp-vlan)# name Sales
switch(config-sync-sp-vlan)#
```

Related Commands	Command	Description
	show switch profile	Displays the switch profile configuration.
	show vlan	Displays VLAN information.



# name (MST configuration)

To set the name of a Multiple Spanning Tree (MST) region, use the **name** command. To return to the default name, use the **no** form of this command.

**name** *name*

**no name** *name*

## Syntax Description

<i>name</i>	Name to assign to the MST region. It can be any string with a maximum length of 32 alphanumeric characters.
-------------	---

## Command Default

None

## Command Modes

MST configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Two or more switches with the same VLAN mapping and configuration version number are considered to be in different MST regions if the region names are different.



### Caution

Be careful when using the **name** command to set the name of an MST region. If you make a mistake, you can put the switch in a different region. The configuration name is a case-sensitive parameter.

This command does not require a license.

## Examples

This example shows how to name a region:

```
switch# configure terminal
switch(config)# spanning-tree mst configuration
switch(config-mst)# name accounting
switch(config-mst)#
```

## Related Commands

Command	Description
<b>show spanning-tree mst configuration</b>	Displays information about the MST protocol.
<b>spanning-tree mst configuration</b>	Enters MST configuration mode.

# negotiate auto

To enable autonegotiation on a specified 1-Gigabit Ethernet port, use the **negotiate auto** command. To disable autonegotiation, use the **no** form of this command.

**negotiate auto**

**no negotiate auto**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Enabled
------------------------	---------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	7.0(3)I2(1)	A note was added about configuring <b>no negotiate auto</b> .
	5.0(3)U3(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>You can use this command only on Ethernet and EtherChannel interfaces.</p> <p>Use the negotiate auto command with the speed command.</p> <p>Use the <b>no negotiate auto</b> command to disable autonegotiation on 1-Gigabit ports when the connected peer does not support autonegotiation. By default, autonegotiation is enabled on 1-Gigabit ports and disabled on 10-Gigabit ports.</p>
-------------------------	---



<b>Note</b>	Beginning in 7.0(3)I2(1), <b>no negotiate auto</b> cannot be configured when the speed is set as <b>speed auto</b> . To configure <b>no negotiate auto</b> , change the speed to a fixed speed.
-------------	---

**Caution**

We do not recommend that you enable autonegotiation on 10-Gigabit ports. Enabling autonegotiation on 10-Gigabit ports brings the link down.
---

This command does not require a license.

<b>Examples</b>	This example shows how to enable link negotiation on a specified Ethernet interface:
-----------------	--

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# negotiate auto
switch(config-if)#
```

This example shows how to enable link negotiation on a specified Ethernet interface and advertise that the interface is capable of only 1000 megabyte speed.

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config)# speed 1000
switch(config-if)# negotiate auto
switch(config-if)#
```

This example shows how to enable link negotiation on a specified Ethernet interface and configure the interface to negotiate to all capable speeds. On an RJ45 jack, the interface can autonegotiate to 10, 100, or 1000 megabytes. (Autonegotiation is not possible on 10 or 40 Gigabyte interfaces.)

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config)# speed auto
switch(config-if)# negotiate auto
switch(config-if)#
```

#### Related Commands

Command	Description
<b>show interface brief</b>	Displays information about the interfaces.
<b>show running-config interface</b>	Displays the running configuration information for configured interfaces.

# private-vlan

To configure private VLANs, use the **private-vlan** command. To return the specified VLANs to normal VLAN mode, use the **no** form of this command.

**private-vlan** { **isolated** | **community** | **primary** }

**no private-vlan** { **isolated** | **community** | **primary** }

## Syntax Description

<b>isolated</b>	Designates the VLAN as an isolated secondary VLAN.
<b>community</b>	Designates the VLAN as a community secondary VLAN.
<b>primary</b>	Designates the VLAN as the primary VLAN.

## Command Default

None

## Command Modes

VLAN configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You must enable private VLANs by using the **feature private-vlan** command before you can configure private VLANs. The commands for configuring private VLANs are not visible until you enable private VLANs.

If you delete either the primary or secondary VLAN, the ports that are associated with the VLAN become inactive. When you enter the **no private-vlan** command, the VLAN returns to the normal VLAN mode. All primary and secondary associations on that VLAN are suspended, but the interfaces remain in private VLAN mode. When you reconvert the specified VLAN to private VLAN mode, the original associations are reinstated.

If you enter the **no vlan** command for the primary VLAN, all private VLAN associations with that VLAN are lost. If you enter the **no vlan** command for a secondary VLAN, the private VLAN associations with that VLAN are suspended and are reenabled when you recreate the specified VLAN and configure it as the previous secondary VLAN.

You cannot configure VLAN1 or the internally allocated VLANs as private VLANs.

A private VLAN is a set of private ports that are characterized by using a common set of VLAN number pairs. Each pair is made up of at least two special unidirectional VLANs and is used by isolated ports and/or by a community of ports to communicate with routers.

An isolated VLAN is a VLAN that is used by isolated ports to communicate with promiscuous ports. An isolated VLAN's traffic is blocked on all other private ports in the same VLAN. Its traffic can only be received by standard trunking ports and promiscuous ports that are assigned to the corresponding primary VLAN.

A promiscuous port is defined as a private port that is assigned to a primary VLAN.

A community VLAN is defined as the VLAN that carries the traffic among community ports and from community ports to the promiscuous ports on the corresponding primary VLAN.

A primary VLAN is defined as the VLAN that is used to convey the traffic from the routers to customer end stations on private ports.

Multiple community and isolated VLANs are allowed. If you enter a range of primary VLANs, the system uses the first number in the range for the association.

**Note**

A private VLAN-isolated port on a Cisco Nexus 3000 Series switch running the current release of Cisco NX-OS does not support IEEE 802.1Q encapsulation and cannot be used as a trunk port.

If VLAN Trunking Protocol (VTP) is enabled on a switch, you can configure private VLANs only on a device configured in Transparent mode.

This command does not require a license.

**Examples**

This example shows how to assign VLAN 5 to a private VLAN as the primary VLAN:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# private-vlan primary
```

This example shows how to assign VLAN 100 to a private VLAN as a community VLAN:

```
switch# configure terminal
switch(config)# vlan 100
switch(config-vlan)# private-vlan community
switch(config-vlan)#
```

This example shows how to assign VLAN 109 to a private VLAN as an isolated VLAN:

```
switch# configure terminal
switch(config)# vlan 109
switch(config-vlan)# private-vlan isolated
switch(config-vlan)#
```

**Related Commands**

Command	Description
<b>feature private-vlan</b>	Enables private VLANs.
<b>show vlan</b>	Displays information about VLANs.
<b>show vlan private-vlan</b>	Displays information about private VLANs.

# private-vlan association

To configure the association between a primary VLAN and a secondary VLAN on a private VLAN, use the **private-vlan association** command. To remove the association, use the **no** form of this command.

**private-vlan association** {[**add**] *secondary-vlan-list* | **remove** *secondary-vlan-list*}

**no private-vlan association**

## Syntax Description

<b>add</b>	(Optional) Associates a secondary VLAN to a primary VLAN.
<i>secondary-vlan-list</i>	Number of the secondary VLAN.
<b>remove</b>	Clears the association between a secondary VLAN and a primary VLAN.

## Command Default

None

## Command Modes

VLAN configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You must enable private VLANs by using the **feature private-vlan** command before you can configure private VLANs. The commands for configuring private VLANs are not visible until you enable private VLANs.

If you delete either the primary or secondary VLAN, the ports that are associated with the VLAN become inactive. When you enter the **no private-vlan** command, the VLAN returns to the normal VLAN mode. All primary and secondary associations on that VLAN are suspended, but the interfaces remain in private VLAN mode. However, when you reconvert the specified VLAN to private VLAN mode, the original associations are reinstated.

If you enter the **no vlan** command for the primary VLAN, all private VLAN associations with that VLAN are lost. However, if you enter the **no vlan** command for a secondary VLAN, the private VLAN associations with that VLAN are suspended and return when you recreate the specified VLAN and configure it as the previous secondary VLAN.

The *secondary-vlan-list* argument cannot contain spaces. It can contain multiple comma-separated items. Each item can be a single secondary VLAN ID or a hyphenated range of secondary VLAN IDs. The *secondary-vlan-list* parameter can contain multiple secondary VLAN IDs.

A private VLAN is a set of private ports that are characterized by using a common set of VLAN number pairs. Each pair is made up of at least two special unidirectional VLANs and is used by isolated ports and/or by a community of ports to communicate with routers.

Multiple community and isolated VLANs are allowed. If you enter a range of primary VLANs, the system uses the first number in the range for the association.

Isolated and community VLANs can only be associated with one primary VLAN. You cannot configure a VLAN that is already associated to a primary VLAN as a primary VLAN.

**Note**

A private VLAN-isolated port on a Cisco Nexus 3000 Series switch running the current release of Cisco NX-OS does not support IEEE 802.1Q encapsulation and cannot be used as a trunk port.

This command does not require a license.

**Examples**

This example shows how to create a private VLAN relationship between the primary VLAN 14, the isolated VLAN 19, and the community VLANs 20 and 21:

```
switch# configure terminal
switch(config)# vlan 19
switch(config-vlan)# private-vlan isolated
switch(config)# vlan 20
switch(config-vlan)# private-vlan community
switch(config)# vlan 21
switch(config-vlan)# private-vlan community
switch(config)# vlan 14
switch(config-vlan)# private-vlan primary
switch(config-vlan)# private-vlan association 19-21
switch(config-vlan)#
```

This example shows how to remove isolated VLAN 18 and community VLAN 20 from the private VLAN association:

```
switch# configure terminal
switch(config)# vlan 14
switch(config-vlan)# private-vlan association remove 18,20
switch(config-vlan)#
```

**Related Commands**

Command	Description
<b>feature private-vlan</b>	Enables private VLANs.
<b>show vlan</b>	Displays information about VLANs.
<b>show vlan private-vlan</b>	Displays information about private VLANs.

# private-vlan synchronize

To map the secondary VLANs to the same Multiple Spanning Tree (MST) instance as the primary VLAN, use the **private-vlan synchronize** command.

## private-vlan synchronize

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** MST configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** If you do not map secondary VLANs to the same MST instance as the associated primary VLAN when you exit the MST configuration mode, the device displays a warning message that lists the secondary VLANs that are not mapped to the same instance as the associated VLAN. The **private-vlan synchronize** command automatically maps all secondary VLANs to the same instance as the associated primary VLANs.

This command does not require a license.

**Examples** This example shows how to initialize private VLAN synchronization:

```
switch# configure terminal
switch(config)# spanning-tree mst configuration
switch(config-mst)# private-vlan synchronize
switch(config-mst)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst configuration</b>	Displays information about the MST protocol.
	<b>spanning-tree mst configuration</b>	Enters MST configuration mode.



# revision

To set the revision number for the Multiple Spanning Tree (MST) region configuration, use the **revision** command. To return to the default settings, use the **no** form of this command.

**revision** *version*

**no revision** *version*

Syntax Description	<i>version</i>	Revision number for the MST region configuration. The range is from 0 to 65535.
--------------------	----------------	---

Command Default	Revision 0
-----------------	------------

Command Modes	MST configuration mode
---------------	------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	Two or more switches with the same VLAN mapping and name are considered to be in different MST regions if the configuration revision numbers are different.
------------------	---



## Caution

Be careful when using the **revision** command to set the revision number of the MST region configuration because a mistake can put the switch in a different region.

This command does not require a license.

Examples	This example shows how to set the revision number of the MST region configuration:
----------	--

```
switch(config)# spanning-tree mst configuration
switch(config-mst)# revision 5
switch(config-mst)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays information about the MST protocol.

# show consistency-checker l2

To trigger the Layer 2 Interface consistency checker for MAC addresses and display the results, use the **show consistency-checker l2** command.

**show consistency-checker l2**

**Syntax Description** This command has no arguments or keywords.

**Command Default** *None*

**Command Modes** Any command mode

Command History	Release	Modification
	6.0(2)U2(1)	This command was introduced.

**Usage Guidelines** This command performs a consistency check on MAC addresses.

**Examples** This example shows how to trigger the Layer 2 consistency checker for a module and display the results:

```
switch# show consistency-checker l2
```

Related Commands	Command	Description
	<b>show consistency-checker stp-state vlan</b>	Triggers the consistency checker on the spanning tree state of all interfaces in a VLAN and displays the results.
	<b>show consistency-checker membership vlan</b>	Triggers the consistency checker on all members of a vlan and displays the results.

# show consistency-checker membership vlan

To trigger the VLAN membership consistency checker for members of a VLAN and display the results, use the **show consistency-checker membership vlan** command.

**show consistency-checker membership vlan** *vlan id*

<b>Syntax Description</b>	<i>vlan id</i>	Specifies a VLAN.
---------------------------	----------------	-------------------

<b>Command Default</b>	<i>None</i>
------------------------	-------------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.0(2)U2(1)	This command was introduced.

<b>Examples</b>	This example shows how to trigger the VLAN membership consistency checker and display the results:  switch# <b>show consistency-checker membership vlan 2</b>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show consistency-checker l2</b>	Triggers the consistency checker on MAC addresses and displays the results.
	<b>show consistency-checker stp-state vlan</b>	Triggers the consistency checker on the spanning tree state of all interfaces in a VLAN and displays the results.

# show consistency-checker stp-state vlan

To trigger the consistency checker for the spanning tree state of all interfaces in a VLAN and display the results, use the **show consistency-checker stp-state vlan** command.

**show consistency-checker stp-state vlan** *vlan id*

## Syntax Description

<i>vlan id</i>	Specifies a VLAN.
----------------	-------------------

## Command Default

*None*

## Command Modes

Any command mode

## Command History

Release	Modification
6.0(2)U2(1)	This command was introduced.

## Examples

This example shows how to trigger the Layer 3 Interface consistency checker for a module and display the results:

```
switch# show consistency-checker stp-state vlan 250
```

## Related Commands

Command	Description
<b>show consistency-checker l2</b>	Triggers the consistency checker on MAC addresses and displays the results.
<b>show consistency-checker membership vlan</b>	Triggers the consistency checker on all members of a vlan and displays the results.

# show ip igmp snooping

To display the Internet Group Management Protocol (IGMP) snooping configuration of the switch, use the **show ip igmp snooping** command.

**show ip igmp snooping** [**explicit-tracking** *vlan* *vlan-id* | **groups** [**detail** | *vlan* *vlan-id*] | **mrouter** [*vlan* *vlan-id*] | **querier** [*vlan* *vlan-id*] | *vlan* *vlan-id*]

Syntax Description		
<b>explicit-tracking</b>	(Optional)	Displays information about the explicit host-tracking status for IGMPv3 hosts. If you provide this keyword, you must specify a VLAN.
<b>vlan</b> <i>vlan-id</i>	(Optional)	Specifies a VLAN. The VLAN ID range is from 1 to 4094.
<b>groups</b>	(Optional)	Displays information for the IGMP group address.
<b>detail</b>	(Optional)	Displays detailed information for the group.
<b>mrouter</b>	(Optional)	Displays information about dynamically detected multicast routers.
<b>querier</b>	(Optional)	Displays information about the snooping querier if defined.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Examples</b>	This example shows how to display the IGMP snooping configuration of the switch:
-----------------	--

```
switch# show ip igmp snooping
Global IGMP Snooping Information:
  IGMP Snooping enabled
  Optimised Multicast Flood (OMF) disabled
  IGMPv1/v2 Report Suppression enabled
  IGMPv3 Report Suppression disabled
  Link Local Groups Suppression enabled
  VPC Multicast optimization disabled

IGMP Snooping information for vlan 1
  IGMP snooping enabled
  Optimised Multicast Flood (OMF) disabled
  IGMP querier none
  Switch-querier disabled
  IGMPv3 Explicit tracking enabled
  IGMPv2 Fast leave disabled
  IGMPv1/v2 Report suppression enabled
  IGMPv3 Report suppression disabled
  Link Local Groups suppression enabled
  Router port detection using PIM Hellos, IGMP Queries
  Number of router-ports: 0
```

## ■ show ip igmp snooping

```

Number of groups: 0
Active ports:
  Eth1/1      Eth1/2  Eth1/48
switch#

```

This example shows how to display the IGMP snooping configuration for VLAN 1:

```

switch# show ip igmp snooping vlan 1
IGMP Snooping information for vlan 1
  IGMP snooping enabled
  Optimised Multicast Flood (OMF) disabled
  IGMP querier none
  Switch-querier disabled
  IGMPv3 Explicit tracking enabled
  IGMPv2 Fast leave disabled
  IGMPv1/v2 Report suppression enabled
  IGMPv3 Report suppression disabled
  Link Local Groups suppression enabled
  Router port detection using PIM Hellos, IGMP Queries
  Number of router-ports: 0
  Number of groups: 0
  Active ports:
    Eth1/1      Eth1/2  Eth1/48
switch#

```

## Related Commands

Command	Description
<b>ip igmp snooping (EXEC)</b>	Globally enables IGMP snooping. IGMP snooping must be globally enabled in order to be enabled on a VLAN.
<b>ip igmp snooping (VLAN)</b>	Enables IGMP snooping on the VLAN interface.

# show lldp

To display information about the Link Layer Discovery Protocol (LLDP) configuration on the switch, use the **show lldp** command.

```
show lldp {interface {ethernet slot/port | mgmt intf-no} | neighbors [detail | interface] | timers | tlv-select | traffic [interface {ethernet slot/port | mgmt intf-no}]}
```

Syntax Description		
<b>interface</b>		Displays LLDP interface information, or LLDP neighbor information on an interface.
<b>ethernet</b> <i>slot/port</i>		Displays the configuration information of the Ethernet IEEE 802.3z interface. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>mgmt</b> <i>intf-no</i>		Displays the configuration information of the management interface. The management interface number is 0.
<b>neighbors</b>		Displays information about LLDP neighbors.
<b>detail</b>		(Optional) Displays the detailed information about LLDP neighbors.
<b>timers</b>		Displays information about LLDP timers.
<b>tlv-select</b>		Displays information about the TLVs.
<b>traffic</b>		Displays the LLDP counters configured on the switch.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

## Usage Guidelines



### Note

LLDP, which is a neighbor discovery protocol that is used for network devices to advertise information about themselves to other devices on the network, is enabled on the switch by default.

## Examples

This example shows how to display LLDP interface information:

```
switch# show lldp traffic interface ethernet 1/1
LLDP interface traffic statistics:
```

```
Total frames transmitted: 7490
Total entries aged: 0
Total frames received: 7458
Total frames received in error: 0
```

```

    Total frames discarded: 0
    Total unrecognized TLVs: 0
switch#

```

This example shows how to display LLDP management interface information:

```
switch# show lldp traffic interface mgmt 0
```

This example shows how to display LLDP timers configured on the switch:

```

switch# show lldp timers
LLDP Timers:

    Holdtime in seconds: 120
    Reinit-time in seconds: 2
    Transmit interval in seconds: 30
switch#

```

This example shows how to display LLDP neighbor information:

```

switch# show lldp neighbors detail

switch#

```

This example shows how to display LLDP information for a specified interface:

```
switch# show lldp interface ethernet 1/1
```

This example shows how to display the TLV information:

```

switch# show lldp tlv-select
management-address
port-description
port-vlan
system-capabilities
system-description
system-name
dcbxp
switch#

```

This example shows how to display LLDP traffic information:

```

switch# show lldp traffic
LLDP traffic statistics:

    Total frames transmitted: 7571
    Total entries aged: 0
    Total frames received: 5694
    Total frames received in error: 0
    Total frames discarded: 0
    Total unrecognized TLVs: 0
switch#

```

## Related Commands

Command	Description
<b>lldp</b>	Configures the global LLDP options on the switch.
<b>lldp (Interface)</b>	Configures the LLDP feature on an interface.



# show mac-address-table

To display the contents of the MAC address table, use the **show mac-address-table** command.

```
show mac-address-table [address mac-address] [aging-time] [loop-detect][dynamic | multicast | static] [interface {ethernet slot / port | port-channel number}] [vlan vlan-id]
```

## Syntax Description

<b>address</b> <i>mac-address</i>	(Optional) Displays information about a specific MAC address..
<b>aging-time</b>	(Optional) Displays the MAC address aging time for all VLANs defined in the switch.
<b>loop-detect</b>	(Optional) Displays the MAC address aging time for all VLANs defined in the switch.
<b>dynamic</b>	(Optional) Displays information about the dynamic MAC address table entries only.
<b>interface</b>	(Optional) Specifies the interface. The interface can be either Ethernet or EtherChannel.
<b>ethernet</b> <i>slot / port</i>	(Optional) Specifies the Ethernet interface slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface. The EtherChannel number is from 1 to 4096.
<b>multicast</b>	(Optional) Displays information about the multicast MAC address table entries only.
<b>static</b>	(Optional) Displays information about the static MAC address table entries only.
<b>vlan</b> <i>vlan-id</i>	(Optional) Displays information for a specific VLAN. The VLAN ID range is from 1 to 4094.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
6.0(2)U3(1)	This command was introduced.

## Usage Guidelines

IGMP snooping learnt MAC addresses are not displayed.

## Examples

This example shows how to display the MAC addresses table:

```
switch# show mac-address-table
VLAN      MAC Address      Type      Age      Port
-----+-----+-----+-----+-----
1         0018.b967.3cd0   dynamic   10       Eth1/3
```

## show mac-address-table

```
1          001c.b05a.5380    dynamic 200      Eth1/3
Total MAC Addresses: 2
```

This example shows how to display the current aging time:

```
switch# show mac-address-table aging-time
```

```
Vlan  Aging Time
-----
1      1800
13     1800
42     1800
```

This example shows how to display information about the dynamic entries for the MAC address table:

```
switch# show mac-address-table dynamic
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
  age - seconds since last seen, + - primary entry using vPC Peer-Link
  VLAN      MAC Address      Type      age      Secure NTFY  Ports/SWID.SSID.LID
-----+-----+-----+-----+-----+-----
* 4044      84b8.02a8.6922    dynamic   0          F      F      Eth1/1/33
* 4044      aa9d.21e0.1fe2    dynamic   0          F      F      Eth1/1/33
* 4042      84b8.02a8.6923    dynamic   0          F      F      Br-Eth1/9/1
* 4042      84b8.02a8.692b    dynamic   0          F      F      Br-Eth1/9/1
```



**Note** On platforms where aging is not supported, the aging value will always be displayed as 0

This example shows how to display the currently configured action:

```
switch# configure terminal
switch(config)# show mac address-table loop-detect
Port Down Action Mac Loop Detect : enabled
```

```
switch# configure terminal
switch(config)# no mac address-table loop-detect port-down
switch(config)# show mac address-table loop-detect
Port Down Action Mac Loop Detect : disabled
```

## Related Commands

Command	Description
<b>mac address-table</b>	Configures the action of bringing down the port with the lower interface index when a MAC address move loop is detected between two ports.
<b>loop-detect port-down</b>	

# show mac address-table aging-time

To display information about the time-out values for the MAC address table, use the **show mac address-table aging-time** command.

**show mac address-table aging-time**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Examples</b>	This example shows how to display MAC address aging times:
-----------------	--

```
switch# show mac address-table aging-time
Vlan Aging Time
-----
4040 300
1     300
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>mac address-table aging-time</b>	Configures the aging time for entries in the MAC address table.
	<b>show mac address-table</b>	Displays information about the MAC address table.

# show mac address-table count

To display the number of entries currently in the MAC address table, use the **show mac address-table count** command.

**show mac address-table count** [**address** *EEEE.EEEE.EEEE*] [**dynamic** | **static**] [**interface** {**ethernet** *slot/port* | **port-channel** *number*}] [**vlan** *vlan-id*]

<b>Syntax Description</b>	<b>address</b> <i>EEEE.EEEE.EEEE</i>	(Optional) Displays a count of the MAC address table entries for a specific address.
	<b>dynamic</b>	(Optional) Displays a count of the dynamic MAC addresses.
	<b>static</b>	(Optional) Displays a count of the static MAC addresses.
	<b>interface</b>	(Optional) Specifies the interface. The interface can be Ethernet or EtherChannel.
	<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
	<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface. The EtherChannel number is from 1 to 4096.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Displays information for a specific VLAN. The range is from 1 to 4094.

**Command Default** None

**Command Modes** EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display the number of dynamic entries currently in the MAC address table:

```
switch# show mac address-table count dynamic
MAC Entries for all vlans:
Total MAC Addresses in Use: 1
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show mac address-table</b>	Displays information about the MAC address table.

# show mac address-table notification

To display notifications about the MAC address table, use the **show mac address-table notification** command.

**show mac address-table notification { mac-move | threshold }**

<b>Syntax Description</b>	<b>mac-move</b>	Displays notification messages about MAC addresses that were moved.
	<b>threshold</b>	Displays notification messages sent when the MAC address table threshold was exceeded.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display MAC address move notifications:

```
switch# show mac address-table notification mac-move
MAC Move Notify Triggers: 0
  Number of MAC Addresses added: 6
  Number of MAC Addresses moved: 0
  Number of MAC Addresses removed: 3
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>mac address-table notification mac-move</b>	Configures a log message notification when the MAC address is moved.
	<b>show mac address-table</b>	Displays information about the MAC address table.

# show mac address-table

To display the information about the MAC address table, use the **show mac address-table** command.

```
show mac address-table [address mac-address] [dynamic | multicast | static] [interface
{ ethernet slot/port | port-channel number}] [vlan vlan-id]
```

Syntax Description	
<b>address</b> <i>mac-address</i>	(Optional) Displays information about a specific MAC address.
<b>dynamic</b>	(Optional) Displays information about the dynamic MAC address table entries only.
<b>interface</b>	(Optional) Specifies the interface. The interface can be either Ethernet or EtherChannel.
<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface. The EtherChannel number is from 1 to 4096.
<b>multicast</b>	(Optional) Displays information about the multicast MAC address table entries only.
<b>static</b>	(Optional) Displays information about the static MAC address table entries only.
<b>vlan</b> <i>vlan-id</i>	(Optional) Displays information for a specific VLAN. The VLAN ID range is from 1 to 4094.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The switch maintains static MAC address entries that are saved in its startup configuration across reboots and flushes the dynamic entries.

**Examples** This example shows how to display information about the entries for the MAC address table:

```
switch# show mac address-table
Legend:
      * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
      age - seconds since first seen, + - primary entry using vPC Peer-Link
      VLAN    MAC Address      Type      age      Secure NTFY      Ports
-----+-----+-----+-----+-----+-----+-----
* 1          0011.2233.4455      static    0          F      F      Eth1/1
* 1          0015.0015.0041      dynamic   360        F      F      Eth1/48
```

```
* 1          0055.4433.2211    static    0          F    F    Eth1/2
switch#
```

This example shows how to display information about the entries for the MAC address table for a specific MAC address:

```
switch# show mac address-table address 0015.0015.0041
```

Legend:

```
      * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
      age - seconds since first seen,+ - primary entry using vPC Peer-Link
      VLAN      MAC Address      Type      age      Secure NTFY      Ports
-----+-----+-----+-----+-----+-----
* 1          0015.0015.0041    dynamic    550          F    F    Eth1/48
switch#
```

This example shows how to display information about the dynamic entries for the MAC address table:

```
switch# show mac address-table dynamic
```

Legend:

```
      * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
      age - seconds since first seen,+ - primary entry using vPC Peer-Link
      VLAN      MAC Address      Type      age      Secure NTFY      Ports
-----+-----+-----+-----+-----+-----
* 1          0015.0015.0041    dynamic    410          F    F    Eth1/48
switch#
```

This example shows how to display information about the MAC address table for a specific interface:

```
switch# show mac address-table interface ethernet 1/2
```

Legend:

```
      * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
      age - seconds since first seen,+ - primary entry using vPC Peer-Link
      VLAN      MAC Address      Type      age      Secure NTFY      Ports
-----+-----+-----+-----+-----+-----
* 1          0055.4433.2211    static     0          F    F    Eth1/2
switch#
```

This example shows how to display static entries in the MAC address table:

```
switch# show mac address-table static
```

Legend:

```
      * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
      age - seconds since first seen,+ - primary entry using vPC Peer-Link
      VLAN      MAC Address      Type      age      Secure NTFY      Ports
-----+-----+-----+-----+-----+-----
* 1          0011.2233.4455    static     0          F    F    Eth1/1
* 1          0055.4433.2211    static     0          F    F    Eth1/2
switch#
```

This example shows how to display entries in the MAC address table for a specific VLAN:

```
switch# show mac address-table vlan 1
```

Legend:

```
      * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
      age - seconds since first seen,+ - primary entry using vPC Peer-Link
      VLAN      MAC Address      Type      age      Secure NTFY      Ports
-----+-----+-----+-----+-----+-----
* 1          0011.2233.4455    static     0          F    F    Eth1/1
* 1          0015.0015.0041    dynamic   510          F    F    Eth1/48
* 1          0055.4433.2211    static     0          F    F    Eth1/2
switch#
```

Related Commands	Command	Description
	<b>mac address-table static</b>	Adds static entries to the MAC address table or configures a static MAC address with IGMP snooping disabled for that address.
	<b>show mac address-table aging-time</b>	Displays information about the time-out values for the MAC address table.
	<b>show mac address-table count</b>	Displays the number of entries currently in the MAC address table.
	<b>show mac address-table notifications</b>	Displays information about notifications for the MAC address table.



# show running-config spanning-tree

To display the running configuration for the Spanning Tree Protocol (STP), use the **show running-config spanning-tree** command.

```
show running-config spanning-tree [all | interface {ethernet slot/port | port-channel
channel-num}]
```

<b>Syntax Description</b>	<b>all</b>	(Optional) Displays current STP operating information including default settings.
	<b>interface</b>	(Optional) Displays the STP information for a specific interface.
	<b>ethernet</b> <i>slot/port</i>	(Optional) Displays the STP information for an Ethernet interface. The slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>port-channel</b> <i>channel-num</i>	(Optional) Displays the STP information for an EtherChannel interface. The EtherChannel number is from 1 to 4096.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display information on the running STP configuration:

```
switch# show running-config spanning-tree
spanning-tree mode mst
switch#
```

This example shows how to display detailed information on the running STP configuration:

```
switch# show running-config spanning-tree all
spanning-tree mode mst
no spanning-tree port type edge default
no spanning-tree port type network default
spanning-tree bridge assurance
no spanning-tree loopguard default
spanning-tree mst simulate pvst global
no snmp-server enable traps bridge topologychange
no snmp-server enable traps bridge newroot
no snmp-server enable traps stpx inconsistency
no snmp-server enable traps stpx loop-inconsistency
no snmp-server enable traps stpx root-inconsistency
spanning-tree mst hello-time 2
spanning-tree mst forward-time 15
spanning-tree mst max-age 20
spanning-tree mst max-hops 20
spanning-tree mst 0 priority 32768
```

## show running-config spanning-tree

```
spanning-tree mst configuration
  name
  revision 0
  instance 0 vlan 1-4094
interface Ethernet1/1
  spanning-tree port-priority 128
  spanning-tree cost auto
  spanning-tree link-type auto
  spanning-tree port type network
  no spanning-tree bpduguard
  no spanning-tree bpdufilter
switch#
```



### Note

Display output differs slightly depending on whether you are running Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST).

### Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about STP.

# show running-config vlan

To display the running configuration for a specified VLAN, use the **show running-config vlan** command.

**show running-config vlan** *vlan-id*

Syntax Description	<i>vlan-id</i>	Number of VLAN or range of VLANs. Valid numbers are from 1 to 4096.
--------------------	----------------	---

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command provides information on the specified VLAN, including private VLANs.
	The display varies with your configuration. If you have configured the VLAN name, shutdown status, or suspended status, these are also displayed.

Examples	This example shows how to display the running configuration for VLAN 5:
----------	---

```
switch# show running-config vlan 5

!Command: show running-config vlan 5
!Time: Fri May 28 10:41:28 2010

version 5.0(3)U1(1)
vlan 5

switch#
```

Related Commands	Command	Description
	<b>show vlan</b>	Displays information about all the VLANs on the switch.

# show running-config vtp

To display the VLAN Trunking Protocol (VTP) running configuration, use the **show running-config vtp** command.

**show running-config vtp**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display the VTP running configuration on the switch:

```
switch# show running-config vtp
```

Related Commands	Command	Description
	<b>copy running-config startup-config</b>	Copies the running configuration to the startup configuration file.
	<b>feature vtp</b>	Enables VTP on the switch.
	<b>vtp domain</b>	Configures the VTP administrative domain.
	<b>vtp file</b>	Stores the VTP configuration in a file.
	<b>vtp mode</b>	Configures a VTP device mode.

# show spanning-tree

To display information about the Spanning Tree Protocol (STP), use the **show spanning-tree** command.

**show spanning-tree** [**blockedports** | **inconsistentports** | **pathcost method**]

<b>Syntax Description</b>	<b>blockedports</b>	(Optional) Displays the alternate ports blocked by STP.
	<b>inconsistentports</b>	(Optional) Displays the ports that are in an inconsistent STP state.
	<b>pathcost method</b>	(Optional) Displays whether short or long path cost method is used. The method differs for Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) (configurable, default is short) and Multiple Spanning Tree (MST) (nonconfigurable, operational value is always long).

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The STP port type displays only when you have configured the port as either an STP edge port or an STP network port. If you have not configured the STP port type, no port type displays.

[Table 2](#) describes the fields that are displayed in the output of **show spanning-tree** commands.

**Table 2** *show spanning-tree Command Output Fields*

Field	Definition
Role	Current port STP role. Valid values are as follows: <ul style="list-style-type: none"> <li>Desg (designated)</li> <li>Root</li> <li>Altn (alternate)</li> <li>Back (backup)</li> </ul>

**Table 2** *show spanning-tree Command Output Fields (continued)*

Field	Definition
Sts	Current port STP state. Valid values are as follows: <ul style="list-style-type: none"> <li>• BLK (blocking)</li> <li>• DIS (disabled)</li> <li>• LRN (learning)</li> <li>• FWD (forwarding)</li> </ul>
Type	Status information. Valid values are as follows: <ul style="list-style-type: none"> <li>• P2p/Shr—The interface is considered as a point-to-point (shared) interface by the spanning tree.</li> <li>• Edge—The port is configured as an STP edge port (either globally using the <b>default</b> command or directly on the interface) and no BPDU has been received.</li> <li>• Network—The port is configured as an STP network port (either globally using the <b>default</b> command or directly on the interface).</li> <li>• *ROOT_Inc, *LOOP_Inc, *PVID_Inc, *BA_Inc, and *TYPE_Inc—The port is in a broken state (BKN*) for an inconsistency. The broken states are Root inconsistent, Loopguard inconsistent, PVID inconsistent, Bridge Assurance inconsistent, or Type inconsistent.</li> </ul>

**Note**

Display output differs slightly depending on whether you are running Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST).

**Examples**

This example shows how to display spanning tree information:

```
switch# show spanning-tree

VLAN0001
  Spanning tree enabled protocol rstp
  Root ID    Priority    32769
             Address     0005.0505.053c
             This bridge is the root
             Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

  Bridge ID  Priority    32769 (priority 32768 sys-id-ext 1)
             Address     0005.0505.053c
             Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

Interface      Role Sts Cost          Prio.Nbr Type
-----
Eth1/1         Desg FWD 2             128.129 P2p
Eth1/2         Desg FWD 2             128.130 P2p
Eth1/39        Desg FWD 2             128.167 P2p
Eth1/41        Desg FWD 2             128.169 P2p
Eth1/48        Desg FWD 2             128.176 P2p

switch#
```

This example shows how to display the blocked ports in spanning tree:

```
switch# show spanning-tree blockedports
```

This example shows how to determine if any ports are in any STP-inconsistent state:

```
switch# show spanning-tree inconsistentports
```

This example shows how to display the path cost method:

```
switch# show spanning-tree pathcost method
Spanning tree default pathcost method used is short
switch#
```

Related Commands	Command	Description
	<b>show spanning-tree active</b>	Displays information about STP active interfaces only.
	<b>show spanning-tree bridge</b>	Displays the bridge ID, timers, and protocol for the local bridge on the switch.
	<b>show spanning-tree brief</b>	Displays a brief summary about STP.
	<b>show spanning-tree detail</b>	Displays detailed information about STP.
	<b>show spanning-tree interface</b>	Displays the STP interface status and configuration of specified interfaces.
	<b>show spanning-tree mst</b>	Displays information about Multiple Spanning Tree (MST) STP.
	<b>show spanning-tree root</b>	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
	<b>show spanning-tree summary</b>	Displays summary information about STP.
	<b>show spanning-tree vlan</b>	Displays STP information for specified VLANs.

# show spanning-tree active

To display Spanning Tree Protocol (STP) information on STP-active interfaces only, use the **show spanning-tree active** command.

**show spanning-tree active** [**brief** | **detail**]

<b>Syntax Description</b>	<b>brief</b>	(Optional) Displays a brief summary of STP interface information.
	<b>detail</b>	(Optional) Displays a detailed summary of STP interface information.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display STP information on the STP-active interfaces:

```
switch# show spanning-tree active

VLAN0001
  Spanning tree enabled protocol rstp
  Root ID    Priority    32769
             Address     0005.0505.053c
             This bridge is the root
             Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

  Bridge ID  Priority    32769 (priority 32768 sys-id-ext 1)
             Address     0005.0505.053c
             Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interface      Role Sts Cost      Prio.Nbr Type
-----
Eth1/1         Desg FWD 2         128.129 P2p
Eth1/2         Desg FWD 2         128.130 P2p
Eth1/39        Desg FWD 2         128.167 P2p
Eth1/41        Desg FWD 2         128.169 P2p
Eth1/48        Desg FWD 2         128.176 P2p

switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree</b>	Displays information about STP.
	<b>show spanning-tree bridge</b>	Displays the bridge ID, timers, and protocol for the local bridge on the switch.



Command	Description
<b>show spanning-tree brief</b>	Displays a brief summary about STP.
<b>show spanning-tree detail</b>	Displays detailed information about STP.
<b>show spanning-tree interface</b>	Displays the STP interface status and configuration of specified interfaces.
<b>show spanning-tree mst</b>	Displays information about Multiple Spanning Tree (MST) STP.
<b>show spanning-tree root</b>	Displays the status and configuration of the root bridge for the STP instance to which this switch belongs.
<b>show spanning-tree summary</b>	Displays summary information about STP.
<b>show spanning-tree vlan</b>	Displays STP information for specified VLANs.

# show spanning-tree bridge

To display the status and configuration of the local Spanning Tree Protocol (STP) Bridge Assurance, use the **show spanning-tree bridge** command.

**show spanning-tree bridge** [**address** | **brief** | **detail** | **forward-time** | **hello-time** | **id** | **max-age** | **priority** [**system-id**] | **protocol**]

Syntax Description	
<b>address</b>	(Optional) Displays the MAC address for the STP local bridge.
<b>brief</b>	(Optional) Displays a brief summary of the status and configuration for the STP bridge.
<b>detail</b>	(Optional) Displays a detailed summary of the status and configuration for the STP bridge.
<b>forward-time</b>	(Optional) Displays the STP forward delay interval for the bridge.
<b>hello-time</b>	(Optional) Displays the STP hello time for the bridge.
<b>id</b>	(Optional) Displays the STP bridge identifier for the bridge.
<b>max-age</b>	(Optional) Displays the STP maximum-aging time for the bridge.
<b>priority</b>	(Optional) Displays the bridge priority for this bridge.
<b>system-id</b>	(Optional) Displays the bridge priority with the system ID extension for this bridge.
<b>protocol</b>	(Optional) Displays whether the Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST) protocol is active.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display the STP information for the bridge:

```
switch# show spanning-tree bridge
```

```

Vlan                Bridge ID                Hello  Max  Fwd
                  Time      Age  Dly  Protocol
-----
VLAN0001            32769 (32768,1) 0005.73c6.40c1    2    20   15   rstp
VLAN0018            32786 (32768,18) 0005.73c6.40c1    2    20   15   rstp
switch#
```

Table 3 describes the fields shown in the display.

This example shows how to display the STP address information for the bridge:

```
switch# show spanning-tree bridge address

VLAN0001          0005.73c6.40c1
VLAN0018          0005.73c6.40c1
switch#
```

This example shows how to display the detailed STP information for the bridge:

```
switch# show spanning-tree bridge detail

VLAN0001
  Bridge ID  Priority    32769  (priority 32768 sys-id-ext 1)
             Address    0005.73c6.40c1
             Hello Time  2   sec   Max Age 20 sec   Forward Delay 15 sec
VLAN0018
  Bridge ID  Priority    32786  (priority 32768 sys-id-ext 18)
             Address    0005.73c6.40c1
             Hello Time  2   sec   Max Age 20 sec   Forward Delay 15 sec
switch#
```

This example shows how to display the STP forward delay interval for the bridge:

```
switch# show spanning-tree bridge forward-time

VLAN0001          15
VLAN0018          15
switch#
```

This example shows how to display the STP hello time for the bridge:

```
switch# show spanning-tree bridge hello-time

VLAN0001          2
VLAN0018          2
switch#
```

This example shows how to display the STP bridge ID for the bridge:

```
switch# show spanning-tree bridge id

VLAN0001          8001.0005.73c6.40c1
VLAN0018          8012.0005.73c6.40c1
switch#
```

This example shows how to display the STP maximum-aging time for the bridge:

```
switch# show spanning-tree bridge max-age

VLAN0001          20
VLAN0018          20
switch#
```

This example shows how to display the bridge priority with the system ID extension for the bridge:

```
switch# show spanning-tree bridge priority system-id

VLAN0001          32769  (32768,1)
VLAN0018          32786  (32768,18)
switch#
```

This example shows how to display the STP protocol information for the bridge:

```
switch# show spanning-tree bridge protocol
```

## ■ show spanning-tree bridge

```

VLAN0001      rstp
VLAN0018      rstp
switch#

```

Table 3 describes the fields shown in the display.

**Table 3** *show spanning-tree bridge Field Descriptions*

Field	Description
Vlan	VLAN for which spanning-tree information is shown.
Bridge ID	Bridge identifier of the bridge.
Hello Time	Amount of time, in seconds, that the bridge sends bridge protocol data units (BPDUs).
Max Age	Amount of time, in seconds, that a BPDU packet should be considered valid.
Fwd Dly	Amount of time, in seconds, that the port spends in listening or learning mode.
Protocol	Type of spanning-tree protocol enabled on the VLAN.

#### Related Commands

Command	Description
<b>show running-config spanning-tree</b>	Displays the running configuration information about the Bridge Assurance.
<b>spanning-tree bridge</b>	Enables STP Bridge Assurance on the switch.

# show spanning-tree brief

To display a brief summary of the Spanning Tree Protocol (STP) status and configuration on the switch, use the **show spanning-tree brief** command.

## show spanning-tree brief

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display a brief summary of STP information:

```
switch(config)# show spanning-tree brief
```

```
VLAN0001
  Spanning tree enabled protocol rstp
  Root ID    Priority    32769
             Address     0005.0505.053c
             This bridge is the root
             Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec

  Bridge ID  Priority    32769 (priority 32768 sys-id-ext 1)
             Address     0005.0505.053c
             Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec
```

Interface	Role	Sts	Cost	Prio.Nbr	Type
Eth1/1	Desg	FWD	2	128.129	P2p
Eth1/2	Desg	FWD	2	128.130	P2p
Eth1/39	Desg	FWD	2	128.167	P2p
Eth1/41	Desg	FWD	2	128.169	P2p
Eth1/48	Desg	FWD	2	128.176	P2p

```
switch(config)#
```

Related Commands	Command	Description
	<b>clear spanning-tree counters</b>	Clears the STP counters.

# show spanning-tree detail

To display detailed information on the Spanning Tree Protocol (STP) status and configuration on the switch, use the **show spanning-tree detail** command.

**show spanning-tree detail [active]**

<b>Syntax Description</b>	<b>active</b> (Optional) Displays information about STP active interfaces only.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display detailed information on the STP configuration:

```
switch# show spanning-tree detail
```

```
VLAN0001 is executing the rstp compatible Spanning Tree protocol
Bridge Identifier has priority 32768, sysid 1, address 0005.0505.053c
Configured hello time 2, max age 20, forward delay 15
We are the root of the spanning tree
Topology change flag not set, detected flag not set
Number of topology changes 25 last change occurred 0:59:03 ago
    from Ethernet1/48
Times: hold 1, topology change 35, notification 2
    hello 2, max age 20, forward delay 15
Timers: hello 0, topology change 0, notification 0
```

```
Port 129 (Ethernet1/1) of VLAN0001 is designated forwarding
Port path cost 2, Port priority 128, Port Identifier 128.129
Designated root has priority 32769, address 0005.0505.053c
Designated bridge has priority 32769, address 0005.0505.053c
```

```
<--Output truncated-->
```

```
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>clear spanning-tree counters</b>	Clears the STP counters.

# show spanning-tree interface

To display information on the Spanning Tree Protocol (STP) interface status and configuration of specified interfaces, use the **show spanning-tree interface** command.

**show spanning-tree interface** {**ethernet** *slot/port* | **port-channel** *number*} [**active** [**brief** | **detail**] | **brief** [**active**] | **cost** | **detail** [**active**] | **edge** | **inconsistency** | **priority** | **rootcost** | **state**]

Syntax Description		
<b>interface</b>		Specifies the interface. The interface can be Ethernet or EtherChannel.
<b>ethernet</b> <i>slot/port</i>		Specifies the Ethernet interface slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
<b>port-channel</b> <i>number</i>		Specifies the EtherChannel interface and number. The EtherChannel number is from 1 to 4096.
<b>active</b>		(Optional) Displays information about STP active interfaces only on the specified interfaces.
<b>brief</b>		(Optional) Displays brief summary of STP information on the specified interfaces.
<b>cost</b>		(Optional) Displays the STP path cost for the specified interfaces.
<b>detail</b>		(Optional) Displays detailed STP information about the specified interfaces.
<b>edge</b>		(Optional) Displays the STP-type edge port information for the specified interfaces.
<b>inconsistency</b>		(Optional) Displays the port STP inconsistency state for the specified interfaces.
<b>priority</b>		(Optional) Displays the STP port priority for the specified interfaces.
<b>rootcost</b>		(Optional) Displays the path cost to the root for specified interfaces.
<b>state</b>		(Optional) Displays the current port STP state.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines**

The STP port type displays only when you have configured the port as either an STP edge port or an STP network port. If you have not configured the STP port type, no port type displays.

If you specify an interface that is not running STP, the switch returns an error message.

When you are running Multiple Spanning Tree (MST), this command displays the Per VLAN Spanning Tree (PVST) simulation setting.

**Note**

If you are running Multiple Spanning Tree (MST), use the **show spanning-tree mst** command to show more detail on the specified interfaces.

**Examples**

This example shows how to display STP information on a specified interface:

```
switch(config)# show spanning-tree interface ethernet 1/1
```

Vlan	Role	Sts	Cost	Prio.Nbr	Type
VLAN0001	Desg	FWD	2	128.129	P2p

```
switch(config)#
```

This example shows how to display detailed STP information on a specified interface:

```
switch(config)# show spanning-tree interface ethernet 1/1 detail
```

```
Port 129 (Ethernet1/1) of VLAN0001 is designated forwarding
  Port path cost 2, Port priority 128, Port Identifier 128.129
  Designated root has priority 32769, address 0005.0505.053c
  Designated bridge has priority 32769, address 0005.0505.053c
  Designated port id is 128.129, designated path cost 0
  Timers: message age 0, forward delay 0, hold 0
  Number of transitions to forwarding state: 1
  Link type is point-to-point by default
  BPDU: sent 18697, received 0
```

```
switch(config)#
```

This example shows how to display STP port inconsistency state information for a specified interface:

```
switch(config)# show spanning-tree interface ethernet 1/1 inconsistency
```

```
VLAN0001      none
switch(config)#
```

This example shows how to display STP port priority information for a specified interface:

```
switch(config)# show spanning-tree interface ethernet 1/1 priority
```

```
VLAN0001      128
switch(config)#
```

**Related Commands**

Command	Description
<b>clear spanning-tree counters</b>	Clears the STP counters.



# show spanning-tree mst

To display information on Multiple Spanning Tree (MST) status and configuration, use the **show spanning-tree mst** command.

```
show spanning-tree mst [instance-id [detail | interface {ethernet slot/port | port-channel
number} [detail]]
```

```
show spanning-tree mst [configuration [digest]]
```

```
show spanning-tree mst [detail | interface {ethernet slot/port | port-channel number} [detail]]
```

## Syntax Description

<i>instance-id</i>	(Optional) Multiple Spanning Tree (MST) instance range that you want to display. For example, 0 to 3, 5, 7 to 9.
<b>detail</b>	(Optional) Displays detailed Multiple Spanning Tree (MST) information.
<b>interface</b>	(Optional) Specifies the interface. The interface can be Ethernet or EtherChannel.
<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface and its slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface and number. The EtherChannel number is from 1 to 4096.
<b>configuration</b>	(Optional) Displays current Multiple Spanning Tree (MST) regional information including the VLAN-to-instance mapping of all VLANs.
<b>digest</b>	(Optional) Displays information about the MD5 digest.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

If the switch is not running in STP Multiple Spanning Tree (MST) mode when you enter this command, it returns the following message:

```
ERROR: Switch is not in mst mode
```

## Examples

This example shows how to display STP information about Multiple Spanning Tree (MST) instance information for the VLAN ports that are currently active:

```
switch# show spanning-tree mst
```

This example shows how to display STP information about a specific Multiple Spanning Tree (MST) instance:

```
switch)# show spanning-tree mst 0
```

This example shows how to display detailed STP information about the Multiple Spanning Tree (MST) protocol:

```
switch)# show spanning-tree mst detail
```

This example shows how to display STP information about specified Multiple Spanning Tree (MST) interfaces:

```
switch)# show spanning-tree mst interface ethernet 8/2
```

This example shows how to display information about the Multiple Spanning Tree (MST) configuration:

```
switch)# show spanning-tree mst configuration
```

This example shows how to display the MD5 digest included in the current Multiple Spanning Tree (MST) configuration:

```
switch)# show spanning-tree mst configuration digest
```

#### Related Commands

Command	Description
<b>clear spanning-tree counters</b>	Clears the STP counters.

# show spanning-tree root

To display the status and configuration of the Spanning Tree Protocol (STP) root bridge, use the **show spanning-tree root** command.

**show spanning-tree root** [**address** | **brief** | **cost** | **detail** | **forward-time** | **hello-time** | **id** | **max-age** | **port** | **priority** [**system-id**]]

Syntax Description	
<b>address</b>	(Optional) Displays the MAC address for the STP root bridge.
<b>brief</b>	(Optional) Displays a brief summary of the status and configuration for the root bridge.
<b>cost</b>	(Optional) Displays the path cost from the root to this bridge.
<b>detail</b>	(Optional) Displays detailed information on the status and configuration for the root bridge.
<b>forward-time</b>	(Optional) Displays the STP forward delay interval for the root bridge.
<b>hello-time</b>	(Optional) Displays the STP hello time for the root bridge.
<b>id</b>	(Optional) Displays the STP bridge identifier for the root bridge.
<b>max-age</b>	(Optional) Displays the STP maximum-aging time for the root bridge.
<b>port</b>	(Optional) Displays which port is the root port.
<b>priority</b>	(Optional) Displays the bridge priority for the root bridge.
<b>system-id</b>	(Optional) Displays the bridge identifier with the system ID extension for the root bridge.

**Command Default** None


**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Examples** This example shows how to display the detailed information for the root bridge:

```
switch(config)# show spanning-tree root detail

VLAN0001
  Root ID      Priority    32769
                Address      0005.0505.053c
                This bridge is the root
                Hello Time 2 sec   Max Age 20 sec   Forward Delay 15 sec
switch(config)#
```

 show spanning-tree root

Related Commands	Command	Description
	clear spanning-tree counters	Clears the STP counters.

# show spanning-tree summary

To display summary Spanning Tree Protocol (STP) information on the switch, use the **show spanning-tree summary** command.

**show spanning-tree summary [totals]**

Syntax Description	<b>totals</b>	(Optional) Displays totals only of STP information.
--------------------	---------------	---

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	The display output for this command differs when you are running Rapid Per VLAN Spanning Tree Plus (Rapid PVST+) or Multiple Spanning Tree (MST).
------------------	---

Examples	This example shows how to display a summary of STP information on the switch:
----------	---

```
switch# show spanning-tree summary
Switch is in rapid-pvst mode
Root bridge for: VLAN0001
Port Type Default          is disable
Edge Port [PortFast] BPDU Guard Default is disabled
Edge Port [PortFast] BPDU Filter Default is disabled
Bridge Assurance            is enabled
Loopguard Default          is disabled
Pathcost method used       is short
```

Name	Blocking	Listening	Learning	Forwarding	STP Active
VLAN0001	0	0	0	5	5
1 vlan	0	0	0	5	5

```
switch#
```

Related Commands	Command	Description
	<b>clear spanning-tree counters</b>	Clears the STP counters.

# show spanning-tree vlan

To display Spanning Tree Protocol (STP) information for specified VLANs, use the **show spanning-tree vlan** command.

```
show spanning-tree vlan {vlan-id} [active [brief | detail]]
```

```
show spanning-tree vlan {vlan-id} [blockedports]
```

```
show spanning-tree vlan {vlan-id} [bridge [address] | brief | detail | forward-time | hello-time |  
id | max-age | priority [system-id] | protocol]
```

```
show spanning-tree vlan {vlan-id} [brief [active]]
```

```
show spanning-tree vlan {vlan-id} [detail [active]]
```

```
show spanning-tree vlan {vlan-id} [inconsistentports]
```

```
show spanning-tree vlan {vlan-id} [interface {ethernet slot/port | port-channel number} [active  
[brief | detail]] | brief [active] | cost | detail [active] | edge | inconsistency | priority | rootcost  
| state]]
```

```
show spanning-tree vlan {vlan-id} [root [address | brief | cost | detail | forward-time | hello-time  
| id | max-age | port | priority [system-id]]]
```

```
show spanning-tree vlan {vlan-id} [summary]
```

## Syntax Description

<i>vlan-id</i>	VLAN or range of VLANs that you want to display.
<b>active</b>	(Optional) Displays information about STP VLANs and active ports.
<b>brief</b>	(Optional) Displays a brief summary of STP information for the specified VLANs.
<b>detail</b>	(Optional) Displays detailed STP information for the specified VLANs.
<b>blockedports</b>	(Optional) Displays the STP alternate ports in the blocked state for the specified VLANs.
<b>bridge</b>	(Optional) Displays the status and configuration of the bridge for the specified VLANs.
<b>address</b>	(Optional) Displays the MAC address for the specified STP bridge for the specified VLANs.
<b>forward-time</b>	(Optional) Displays the STP forward delay interval for the bridge for the specified VLANs.
<b>hello-time</b>	(Optional) Displays the STP hello time for the bridge for the specified VLANs.
<b>id</b>	(Optional) Displays the STP bridge identifier for the specified VLANs.
<b>max-age</b>	(Optional) Displays the STP maximum-aging time for the specified VLANs.
<b>priority</b>	(Optional) Displays the STP priority for the specified VLANs.
<b>system-id</b>	(Optional) Displays the bridge identification with the system ID added for the specified VLANs.
<b>protocol</b>	(Optional) Displays which STP protocol is active on the switch.

<b>inconsistentports</b>	(Optional) Displays the ports that are in an inconsistent STP state for specified VLANs.
<b>interface</b>	(Optional) Specifies the interface. The interface can be Ethernet or EtherChannel.
<b>ethernet <i>slot/port</i></b>	(Optional) Specifies the Ethernet interface and its slot number and port number. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
<b>port-channel <i>number</i></b>	(Optional) Specifies the EtherChannel interface and number. The EtherChannel number is from 1 to 4096.
<b>cost</b>	(Optional) Displays the STP path cost for the specified VLANs.
<b>edge</b>	(Optional) Displays the STP-type edge port information for the specified interface for the specified VLANs.
<b>inconsistency</b>	(Optional) Displays the STP port inconsistency state for the specified interface for the specified VLANs.
<b>priority</b>	(Optional) Displays the STP priority for the specified VLANs.
<b>rootcost</b>	(Optional) Displays the path cost to the root for specified interfaces for the specified VLANs.
<b>state</b>	(Optional) Displays the current port STP state. Valid values are blocking, disabled, learning, and forwarding.
<b>port</b>	(Optional) Displays information about the root port for the specified VLANs.
<b>summary</b>	(Optional) Displays summary STP information on the specified VLANs.

**Command Default**

None

**Command Modes**

EXEC mode

**Command History**

Release	Modification
5.0(3)U1(1)	This command was introduced.

**Examples**

This example shows how to display STP information on VLAN 1:

```
switch# show spanning-tree vlan 1
```

```
VLAN0001
  Spanning tree enabled protocol rstp
  Root ID    Priority    32769
             Address     0005.0505.053c
             This bridge is the root
             Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec

  Bridge ID  Priority    32769 (priority 32768 sys-id-ext 1)
             Address     0005.0505.053c
             Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec

Interface                Role Sts Cost          Prio.Nbr Type
```

## show spanning-tree vlan

```

-----
Eth1/1          Desg FWD 2          128.129 P2p
Eth1/2          Desg FWD 2          128.130 P2p
Eth1/39         Desg FWD 2          128.167 P2p
Eth1/41         Desg FWD 2          128.169 P2p
Eth1/48         Desg FWD 2          128.176 P2p

switch#

```

### Related Commands

Command	Description
<b>clear spanning-tree counters</b>	Clears the STP counters.
<b>show spanning-tree summary</b>	Displays summary information about STP.



# show udld

To display the Unidirectional Link Detection (UDLD) information for a switch, use the **show udld** command.

**show udld** [**ethernet** *slot/port* | **global** | **neighbors**]

<b>Syntax Description</b>	<b>ethernet</b> <i>slot/port</i>	Displays UDLD information for an Ethernet IEEE 802.3z interface. The <i>slot</i> number is from 1 to 255, and the <i>port</i> number is from 1 to 128.
	<b>global</b>	Displays the UDLD global status and configuration information on all interfaces.
	<b>neighbors</b>	Displays information about UDLD neighbor interfaces.

**Command Default** None

**Command Modes** EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

## Examples

This example shows how to display UDLD information for all interfaces:

```
switch# show udld

Interface Ethernet1/1
-----
Port enable administrative configuration setting: device-default
Port enable operational state: enabled
Current bidirectional state: unknown
Current operational state: link-up - Multiple neighbor not detected
Message interval: 7
Timeout interval: 5
    Last pkt send on: 751414, May 28 11:08:40 2010
        Probe pkt send on: 751414, May 28 11:08:40 2010
        Echo pkt send on: None.
        Flush pkt send on: None.

    Last pkt rcv on: None.
        Probe pkt rcv on: None.
        Echo pkt rcv on: None.
        Flush pkt rcv on: None.

    Deep pkt inspections done: None.
    Mismatched if index found: None.
    Deep pkt inspection drops: None.

<--Output truncated-->
switch#
```

This example shows how to display the UDLD information for a specified interface:

```
switch# show udd ethernet 1/1

Interface Ethernet1/1
-----
Port enable administrative configuration setting: device-default
Port enable operational state: enabled
Current bidirectional state: unknown
Current operational state: advertisement - Multiple neighbor not detected
Message interval: 7
Timeout interval: 5
    Last pkt send on: 781338, May 28 11:09:48 2010
        Probe pkt send on: 781338, May 28 11:09:48 2010
        Echo pkt send on: None.
        Flush pkt send on: None.

    Last pkt rcv on: None.
        Probe pkt rcv on: None.
        Echo pkt rcv on: None.
        Flush pkt rcv on: None.

    Deep pkt inspections done: None.
    Mismatched if index found: None.
    Deep pkt inspection drops: None.
switch#
```

This example shows how to display the UDLD global status and configuration on all interfaces:

```
switch# show udd global

UDLD global configuration mode: enabled
UDLD global message interval: 15
switch#
```

This example shows how to display the UDLD neighbor interfaces:

```
switch# show udd neighbors
```

## Related Commands

Command	Description
<b>udd (configuration mode)</b>	Configures the UDLD protocol on the switch.
<b>udd (Ethernet)</b>	Configures the UDLD protocol on an Ethernet interface.

# show vlan

To display VLAN information, use the **show vlan** command.

**show vlan** [**brief** | **name** {*name*} | **summary**]

<b>Syntax Description</b>	<b>brief</b>	(Optional) Displays only a single line for each VLAN, naming the VLAN, status, and ports.
	<b>name</b> <i>name</i>	(Optional) Displays information about a single VLAN that is identified by the VLAN name.
	<b>summary</b>	(Optional) Displays the number of existing VLANs on the switch.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command displays information for all VLANs, including private VLANs, on the switch. Each access port can belong to only one VLAN. Trunk ports can be on multiple VLANs.



**Note**

Although a port can be associated with a VLAN as an access VLAN, a native VLAN, or one of the trunk allowed ports, only access VLANs are shown under Ports in the display.

If you shut down a VLAN using the **state suspend** or the **state active** command, these values appear in the Status field:

- suspended—VLAN is suspended.
- active—VLAN is active.

If you shut down a VLAN using the **shutdown** command, these values appear in the Status field:

- act/lshut—VLAN status is active but shut down locally.
- sus/lshut—VLAN status is suspended but shut down locally.

If a VLAN is shut down internally, these values appear in the Status field:

- act/ishut—VLAN status is active but shut down internally.
- sus/ishut—VLAN status is suspended but shut down internally.

If a VLAN is shut down locally and internally, the value that is displayed in the Status field is act/ishut or sus/ishut. If a VLAN is shut down locally only, the value that is displayed in the Status field is act/lshut or sus/lshut.

**Examples**

This example shows how to display information for all VLANs on the switch:

```
switch# show vlan
```

VLAN	Name	Status	Ports
1	default	active	Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/6, Eth1/7, Eth1/8, Eth1/9 Eth1/10, Eth1/11, Eth1/12 Eth1/13, Eth1/14, Eth1/15 Eth1/16, Eth1/17, Eth1/18 Eth1/19, Eth1/20, Eth1/21 Eth1/22, Eth1/23, Eth1/24 Eth1/25, Eth1/26, Eth1/27 Eth1/28, Eth1/29, Eth1/30 Eth1/31, Eth1/32, Eth1/33 Eth1/34, Eth1/35, Eth1/36 Eth1/37, Eth1/38, Eth1/39 Eth1/40, Eth1/41, Eth1/42 Eth1/43, Eth1/44, Eth1/45 Eth1/46, Eth1/47, Eth1/48 Eth1/49, Eth1/50, Eth1/51 Eth1/52, Eth1/53, Eth1/54 Eth1/55, Eth1/56, Eth1/57 Eth1/58, Eth1/59, Eth1/60 Eth1/61, Eth1/62, Eth1/63 Eth1/64
5	VLAN0005	active	

```
Remote SPAN VLANs
```

Primary	Secondary	Type	Ports
5		primary	

```
switch#
```

This example shows how to display the VLAN name, status, and associated ports only:

```
switch# show vlan brief
```

VLAN	Name	Status	Ports
1	default	active	Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/6, Eth1/7, Eth1/8, Eth1/9 Eth1/10, Eth1/11, Eth1/12 Eth1/13, Eth1/14, Eth1/15 Eth1/16, Eth1/17, Eth1/18 Eth1/19, Eth1/20, Eth1/21 Eth1/22, Eth1/23, Eth1/24 Eth1/25, Eth1/26, Eth1/27 Eth1/28, Eth1/29, Eth1/30

```
<--Output truncated-->
```

```
switch#
```

This example shows how to display the VLAN information for a specific VLAN by name:

```
switch# show vlan name VLAN0005
```

VLAN	Name	Status	Ports
5	VLAN0005	active	

```
Remote SPAN VLAN
```

```
-----
```

```
Disabled
```

```
Primary Secondary Type Ports
```

```
-----
```

```
switch#
```

This example shows how to display information about the number of VLANs configured on the switch:

```
switch# show vlan summary
```

```
Number of existing VLANs           : 2
```

```
Number of existing user VLANs      : 2
```

```
Number of existing extended VLANs : 0
```

```
switch#
```

#### Related Commands

Command	Description
<b>show interface switchport</b>	Displays information about the ports, including those in private VLANs.
<b>show vlan private-vlan</b>	Displays private VLAN information.

# show vlan dot1Q tag native

To display the status of tagging on the native VLANs, use the **show vlan dot1Q tag native** command.

**show vlan dot1Q tag native**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Examples</b>	This example shows how to display the status of 802.1Q tagging on the native VLANs:
-----------------	---

```
switch# show vlan dot1Q tag native
vlan dot1q native tag is enabled
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>vlan dot1q tag native</b>	Enables dot1q (IEEE 802.1Q) tagging for all native VLANs on all trunked ports on the switch.

# show vlan id

To display information and statistics for an individual VLAN or a range of VLANs, use the **show vlan id** command.

**show vlan id** {*vlan-id*}

## Syntax Description

*vlan-id* VLAN or range of VLANs that you want to display.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Use this command to display information and statistics on an individual VLAN or a range of VLANs, including private VLANs.



### Note

You can also display information about individual VLANs using the **show vlan name** command.

## Examples

This example shows how to display information for the individual VLAN 5:

```
switch# show vlan id 5
```

VLAN	Name	Status	Ports
5	VLAN0005	active	

Remote SPAN VLAN

-----  
Disabled

Primary	Secondary	Type	Ports
5		primary	

```
switch#
```

## Related Commands

Command	Description
<b>show vlan</b>	Displays information about VLANs on the switch.

# show vlan private-vlan

To display private VLAN information, use the **show vlan private-vlan** command.

**show vlan** [**id** {*vlan-id*}] **private-vlan** [**type**]

<b>Syntax Description</b>	<b>id</b> <i>vlan-id</i>	(Optional) Displays private VLAN information for the specified VLAN.
	<b>type</b>	(Optional) Displays the private VLAN type (primary, isolated, or community).

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

## Examples

This example shows how to display information on all private VLANs on the switch:

```
switch(config)# show vlan private-vlan
Primary Secondary Type Ports
-----
5          primary
switch(config)#
```

This example shows how to display information for a specific private VLAN:

```
switch(config)# show vlan id 42 private-vlan
```

This example shows how to display information on the types of all private VLANs on the switch:

```
switch(config)# show vlan private-vlan type
Vlan Type
-----
5      primary
switch(config)#
```

This example shows how to display information on the type for the specified private VLAN:

```
switch(config)# show vlan id 42 private-vlan type
```



Related Commands	Command	Description
	<b>show interface private-vlan mapping</b>	Displays information about the private VLAN mapping between the primary and secondary VLANs so that both VLANs share the same primary VLAN interface.
	<b>show interface switchport</b>	Displays information about the ports, including those in private VLANs.
	<b>show vlan</b>	Displays information about all the VLANs on the switch.

# show vtp counters

To display the VLAN Trunking Protocol (VTP) statistics, use the **show vtp counters** command.

**show vtp counters**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** Before you use this command, you must enable VTP on the switch by using the **feature vtp** command.



**Note** VTP pruning is not supported in Cisco NX-OS Release 5.0(3)U1(1).

**Examples** This example shows how to display the VTP counters:

```
switch# show vtp counters
```

Related Commands	Command	Description
	<b>feature vtp</b>	Enables VTP on the switch.
	<b>vtp</b>	Enables VTP on an interface.
	<b>vtp mode</b>	Configures the VTP device mode.

# show vtp interface

To display the VLAN Trunking Protocol (VTP) interface status and configuration information, use the **show vtp interface** command.

**show vtp interface** [**ethernet** *slot/port* | **port-channel** *channel-no*]

## Syntax Description

<b>ethernet</b> <i>slot/port</i>	(Optional) Displays the VTP configuration on Ethernet interfaces. The slot number is from 1 to 255, and the port number can be from 1 to 128.
<b>port-channel</b> <i>channel-no</i>	(Optional) Displays the VTP configuration on EtherChannel interfaces. The EtherChannel number can be from 1 to 4096.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Before you use this command, you must enable VTP on the switch by using the **feature vtp** command.

## Examples

This example shows how to display the VTP configuration information on all interfaces:

```
switch# show vtp interface
```

This example shows how to display the VTP configuration information for an Ethernet interface:

```
switch# show vtp interface ethernet 1/12
```

This example shows how to display the VTP configuration information for an EtherChannel interface:

```
switch# show vtp interface port-channel 23
```

## Related Commands

Command	Description
<b>feature vtp</b>	Enables VTP on the switch.
<b>show interface ethernet</b>	Displays the Ethernet interfaces configured on the switch.
<b>show interface port-channel</b>	Displays the EtherChannels configured on the switch.
<b>show vtp status</b>	Displays the VTP configuration status.
<b>vtp</b>	Enables VTP on an interface.

# show vtp password

To display the VLAN Trunking Protocol (VTP) administrative password, use the **show vtp password** command.

**show vtp password** [**domain** *domain-id*]

## Syntax Description

<b>domain</b>	(Optional) Specifies the VTP administrative domain.
<i>domain-id</i>	VTP domain ID. The ID can be from 0 to 4294967295.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Before you use this command, you must enable VTP on the switch by using the **feature vtp** command.

## Examples

This example shows how to display the VTP password configured for administrative domain 1:

```
switch# show vtp password domain 1
```

## Related Commands

Command	Description
<b>feature vtp</b>	Enables VTP on the switch.
<b>vtp domain</b>	Configures the VTP domain.
<b>vtp password</b>	Configures the VTP administrative password.

# show vtp status

To display the VLAN Trunking Protocol (VTP) domain status information, use the **show vtp status** command.

## show vtp status

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** Before you use this command, you must enable VTP on the switch by using the **feature vtp** command.

**Examples** This example shows how to display the VTP domain status:

```
switch# show vtp status
VTP Status Information
-----
VTP Version                : 2 (capable)
Configuration Revision      : 0
Maximum VLANs supported locally : 1005
Number of existing VLANs    : 1
VTP Operating Mode         : Transparent
VTP Domain Name            : Accounting
VTP Pruning Mode           : Disabled (Operationally Disabled)
VTP V2 Mode                : Disabled
VTP Traps Generation       : Disabled
MD5 Digest                 : 0xDF 0x75 0x14 0x0C 0x3E 0xE0 0xA1 0x7E
Configuration last modified by 0.0.0.0 at 0-0-00 00:00:00
VTP version running        : 1

switch#
```

Related Commands	Command	Description
	<b>feature vtp</b>	Enables VTP on the switch.
	<b>vtp domain</b>	Configures the VTP domain.
	<b>vtp mode</b>	Configures the VTP device mode.
	<b>vtp version</b>	Configures the VTP version.

# shutdown (VLAN configuration)

To shut down the local traffic on a VLAN, use the **shutdown** command. To return a VLAN to its default operational state, use the **no** form of this command.

**shutdown**  
  
**no shutdown**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Not shut down

**Command Modes** VLAN configuration mode  
Switch profile VLAN configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
	5.0(3)U2(1)	Support for this command was introduced in switch profiles.

**Usage Guidelines** You cannot shut down, or disable, VLAN 1 or VLANs 1006 to 4094.

After you shut down a VLAN, the traffic ceases to flow on that VLAN. Access ports on that VLAN are also brought down; trunk ports continue to carry traffic for the other VLANs allowed on that port. However, the interface associations for the specified VLAN remain, and when you reenables, or recreates, that specified VLAN, the switch automatically reinstates all the original ports to that VLAN.

To find out if a VLAN has been shut down internally, check the Status field in the **show vlan** command output. If a VLAN is shut down internally, one of these values appears in the Status field:

- act/lshut—VLAN status is active and shut down internally.
- sus/lshut—VLAN status is suspended and shut down internally.

  
**Note**

If the VLAN is suspended and shut down, you use both the **no shutdown** and **state active** commands to return the VLAN to the active state.

This command does not require a license.

**Examples** This example shows how to restore local traffic on VLAN 2 after you have shut down, or disabled, the VLAN:

```
switch(config)# vlan 2
switch(config-vlan)# no shutdown
switch(config-vlan)#
```

This example shows how to shut down local traffic on VLAN 3 in a switch profile:

```
switch# configure sync  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config-sync)# switch-profile s5010  
Switch-Profile started, Profile ID is 1  
switch(config-sync-sp)# vlan 3  
switch(config-sync-sp-vlan)# shutdown  
switch(config-sync-sp-vlan)#
```

#### Related Commands

Command	Description
<b>show vlan</b>	Displays VLAN information.

# spanning-tree bpdupfilter

To enable bridge protocol data unit (BPDU) Filtering on the interface, use the **spanning-tree bpdupfilter** command. To return to the default settings, use the **no** form of this command.

**spanning-tree bpdupfilter {enable | disable}**

**no spanning-tree bpdupfilter**

Syntax Description

<b>enable</b>	Enables BPDU Filtering on this interface.
<b>disable</b>	Disables BPDU Filtering on this interface.

Command Default

The setting that is already configured when you enter the **spanning-tree port type edge bpdupfilter default** command.

Command Modes

Interface configuration mode

Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

Usage Guidelines

Entering the **spanning-tree bpdupfilter enable** command to enable BPDU Filtering overrides the spanning tree edge port configuration. That port then returns to the normal spanning tree port type and moves through the normal spanning tree transitions.



Be careful when you enter the **spanning-tree bpdupfilter enable** command on specified interfaces. Explicitly configuring BPDU Filtering on a port this is not connected to a host can cause a bridging loop because the port will ignore any BPDU that it receives, and the port moves to the STP forwarding state.

Use the **spanning-tree port type edge bpdupfilter default** command to enable BPDU Filtering on all spanning tree edge ports.

This command does not require a license.

Examples

This example shows how to explicitly enable BPDU Filtering on the Ethernet spanning tree edge port 1/4:

```
switch (config)# interface ethernet 1/4
switch(config-if)# spanning-tree bpdupfilter enable
switch(config-if)#
```



Related Commands	Command	Description
	show spanning-tree summary	Displays information about the spanning tree state.

# spanning-tree bpduguard

To enable bridge protocol data unit (BPDU) Guard on an interface, use the **spanning-tree bpduguard** command. To return to the default settings, use the **no** form of this command.

```
spanning-tree bpduguard {enable | disable}

no spanning-tree bpduguard
```

Syntax Description

enable	Enables BPDU Guard on this interface.
disable	Disables BPDU Guard on this interface.

Command Default

The setting that is already configured when you enter the **spanning-tree port type edge bpduguard default** command.

Command Modes

Interface configuration mode

Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

Usage Guidelines

BPDU Guard prevents a port from receiving BPDUs. If the port still receives a BPDU, it is put in the error-disabled state as a protective measure.



Be careful when using this command. You should use this command only with interfaces that connect to end stations; otherwise, an accidental topology loop could cause a data-packet loop and disrupt the switch and network operation.

When you enable this BPDU Guard command globally, the command applies only to spanning tree edge ports. See the **spanning-tree port type edge bpduguard default** command for more information on the global command for BPDU Guard. However, when you enable this feature on an interface, it applies to that interface regardless of the spanning tree port type.

This command has three states:

- **spanning-tree bpduguard enable**—Unconditionally enables BPDU Guard on the interface.
- **spanning-tree bpduguard disable**—Unconditionally disables BPDU Guard on the interface.
- **no spanning-tree bpduguard**—Enables BPDU Guard on the interface if it is an operational spanning tree edge port and if the **spanning-tree port type edge bpduguard default** command is configured.

Typically, this feature is used in a service-provider environment where the network administrator wants to prevent an access port from participating in the spanning tree.

This command does not require a license.

---

**Examples**

This example shows how to enable BPDU Guard on this interface:

```
switch(config-if)# spanning-tree bpduguard enable  
switch(config-if)#
```

---

**Related Commands**

Command	Description
<b>show spanning-tree summary</b>	Displays information about the spanning tree state.

---

# spanning-tree bridge

To enable Bridge Assurance on the switch, use the **spanning-tree bridge** command. To disable Bridge Assurance, use the **no** form of this command.

**spanning-tree bridge assurance**

**no spanning-tree bridge assurance**

<b>Syntax Description</b>	<b>assurance</b>	Enables bridge assurance on all network ports.
---------------------------	------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode Switch profile configuration mode
----------------------	--

<b>Command History</b>	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.0(3)U2(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.0(3)U2(1)	This command was introduced.
Release	Modification				
5.0(3)U2(1)	This command was introduced.				

<b>Usage Guidelines</b>	You can use Bridge Assurance to protect against certain problems that can cause bridging loops in the network. Bridge Assurance is enabled only on spanning tree network ports that are point-to-point links. This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to enable Bridge Assurance on all network ports on the switch:
-----------------	---

```
switch(config)# spanning-tree bridge assurance
switch(config)#
```

This example shows how to enable Bridge Assurance in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# spanning-tree bridge assurance
switch(config-sync-sp)#
```

<b>Related Commands</b>	<table><tr><th>Command</th><th>Description</th></tr><tr><td><b>show spanning-tree bridge</b></td><td>Displays information about the spanning tree bridge.</td></tr><tr><td><b>show running-config spanning-tree</b></td><td>Displays the running configuration information about spanning trees.</td></tr></table>	Command	Description	<b>show spanning-tree bridge</b>	Displays information about the spanning tree bridge.	<b>show running-config spanning-tree</b>	Displays the running configuration information about spanning trees.
Command	Description						
<b>show spanning-tree bridge</b>	Displays information about the spanning tree bridge.						
<b>show running-config spanning-tree</b>	Displays the running configuration information about spanning trees.						

# spanning-tree cost

To set the path cost of the interface for Spanning Tree Protocol (STP) calculations, use the **spanning-tree cost** command. To return to the default settings, use the **no** form of this command.

**spanning-tree** [**vlan** *vlan-id*] **cost** {*value* | **auto**}

**no spanning-tree** [**vlan** *vlan-id*] **cost**

Syntax Description		
<b>vlan</b> <i>vlan-id</i>	(Optional) Lists the VLANs on this trunk interface for which you want to assign the path cost. You do not use this parameter on access ports. The range is from 1 to 4094.	
<i>value</i>	Value of the port cost. The available cost range depends on the path-cost calculation method as follows:	
	<ul style="list-style-type: none"> <li>short—The range is from 1 to 65536.</li> <li>long—The range is from 1 to 200,000,000.</li> </ul>	
<b>auto</b>	Sets the value of the port cost by the media speed of the interface (see <a href="#">Table 4</a> for the values).	

<b>Command Default</b>	Port cost is set by the media speed.
------------------------	--------------------------------------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	The STP port path cost default value is determined from the media speed and path cost calculation method of a LAN interface (see <a href="#">Table 4</a> ). See the <b>spanning-tree pathcost method</b> command for information on setting the path cost calculation method for Rapid per VLAN Spanning Tree Plus (Rapid PVST+).
-------------------------	---

**Table 4**      **Default Port Cost**

Bandwidth	Short Path Cost Method Port Cost	Long Path Cost Method Port Cost
10 Mbps	100	2,000,000
100 Mbps	19	200,000
1-Gigabit Ethernet	4	20,000
10-Gigabit Ethernet	2	2,000

When you configure the *value*, higher values will indicate higher costs.

On access ports, assign the port cost by port. On trunk ports, assign the port cost by VLAN; you can configure all the VLANs on a trunk port as the same port cost.

The EtherChannel bundle is considered as a single port. The port cost is the aggregation of all the configured port costs assigned to that channel.

**Note**

Use this command to set the port cost for Rapid PVST+. Use the **spanning-tree mst cost** command to set the port cost for MST.

This command does not require a license.

**Examples**

This example shows how to access an interface and set a path cost value of 250 for the spanning tree VLAN that is associated with that interface:

```
switch# configure terminal
switch(config)# interface ethernet 1/4
switch(config-if)# spanning-tree cost 250
switch(config-if)#
```

**Related Commands**

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning tree configuration.

# spanning-tree guard

To enable or disable Loop Guard or Root Guard, use the **spanning-tree guard** command. To return to the default settings, use the **no** form of this command.

**spanning-tree guard {loop | none | root}**

**no spanning-tree guard**

Syntax Description	<b>loop</b>	Enables Loop Guard on the interface.
	<b>none</b>	Sets the guard mode to none.
	<b>root</b>	Enables Root Guard on the interface.

Command Default	Disabled
-----------------	----------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	You cannot enable Loop Guard if Root Guard is enabled, although the switch accepts the command to enable Loop Guard on <b>spanning tree edge ports</b> .
	This command does not require a license.

Examples	This example shows how to enable Root Guard:
	switch# <b>configure terminal</b>
	switch(config)# <b>interface ethernet 1/1</b>
	switch(config-if)# <b>spanning-tree guard root</b>
	switch(config-if)#

Related Commands	Command	Description
	<b>show spanning-tree summary</b>	Displays information about the spanning tree state.

# spanning-tree link-type

To configure a link type for a port, use the **spanning-tree link-type** command. To return to the default settings, use the **no** form of this command.

**spanning-tree link-type { auto | point-to-point | shared }**

**no spanning-tree link-type**

## Syntax Description

<b>auto</b>	Sets the link type based on the duplex setting of the interface.
<b>point-to-point</b>	Specifies that the interface is a point-to-point link.
<b>shared</b>	Specifies that the interface is a shared medium.

## Command Default

Link type set automatically based on the duplex setting.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Fast transition (specified in IEEE 802.1w) functions only on point-to-point links between two bridges.

By default, the switch derives the link type of a port from the duplex mode. A full-duplex port is considered as a point-to-point link while a half-duplex configuration is assumed to be on a shared link.



### Note

On a Cisco Nexus 3000 Series switch, port duplex is not configurable.

This command does not require a license.

## Examples

This example shows how to configure the port as a shared link:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# spanning-tree link-type shared
switch(config-if)#
```

## Related Commands

Command	Description
<b>show spanning-tree interface</b>	Displays information about the spanning tree state.



# spanning-tree loopguard default

To enable Loop Guard as a default on all spanning tree normal and network ports, use the **spanning-tree loopguard default** command. To disable Loop Guard, use the **no** form of this command.

**spanning-tree loopguard default**

**no spanning-tree loopguard default**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>Loop Guard provides additional security in the bridge network. Loop Guard prevents alternate or root ports from becoming the designated port because of a failure that could lead to a unidirectional link.</p> <p>Loop Guard operates only on ports that are considered point-to-point links by the spanning tree, and it does not run on spanning tree edge ports.</p> <p>Entering the <b>spanning-tree guard loop</b> command for the specified interface overrides this global Loop Guard command.</p> <p>This command does not require a license.</p>
-------------------------	---

<b>Examples</b>	<p>This example shows how to enable Loop Guard:</p> <pre>switch# configure terminal switch(config)# spanning-tree loopguard default switch(config)#</pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree summary</b>	Displays information about the spanning tree state.

# spanning-tree mode

To switch between Rapid per VLAN Spanning Tree Plus (Rapid PVST+) and Multiple Spanning Tree (MST) Spanning Tree Protocol (STP) modes, use the **spanning-tree mode** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mode {rapid-pvst | mst}**

**no spanning-tree mode**

<b>Syntax Description</b>	<b>rapid-pvst</b>	Sets the STP mode to Rapid PVST+.
	<b>mst</b>	Sets the STP mode to MST.

**Command Default** Rapid PVST+

**Command Modes** Global configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** You cannot simultaneously run MST and Rapid PVST+ on the switch.



## Caution

Be careful when using the **spanning-tree mode** command to switch between Rapid PVST+ and MST modes. When you enter the command, all STP instances are stopped for the previous mode and are restarted in the new mode. Using this command may cause the user traffic to be disrupted.

This command does not require a license.

**Examples** This example shows how to switch to MST mode:

```
switch# configure terminal
switch(config)# spanning-tree mode mst
switch(config-mst)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree summary</b>	Displays the information about the spanning tree configuration.

# spanning-tree mst configuration

To enter the Multiple Spanning Tree (MST) configuration mode, use the **spanning-tree mst configuration** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst configuration**

**no spanning-tree mst configuration**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The default value for the MST configuration is the default value for all its parameters:

- No VLANs are mapped to any MST instance. All VLANs are mapped to the Common and Internal Spanning Tree (CIST) instance.
- The region name is an empty string.
- The revision number is 0.

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The MST configuration consists of three main parameters:

- Instance VLAN mapping—See the **instance vlan** command.
- Region name—See the **name (MST configuration)** command.
- Configuration revision number—See the **revision** command.

The **abort** and **exit** commands allow you to exit MST configuration mode. The difference between the two commands depends on whether you want to save your changes or not:

- The **exit** command commits all the changes before leaving MST configuration mode.
- The **abort** command leaves MST configuration mode without committing any changes.

If you do not map secondary VLANs to the same instance as the associated primary VLAN, when you exit MST configuration mode, the following warning message is displayed:

```
These secondary vlans are not mapped to the same instance as their primary:
-> 3
```

See the **switchport mode private-vlan host** command to fix this problem.

Changing an MST configuration mode parameter can cause connectivity loss. To reduce service disruptions, when you enter MST configuration mode, make changes to a copy of the current MST configuration. When you are done editing the configuration, you can apply all the changes at once by using the **exit** keyword.

In the unlikely event that two administrators commit a new configuration at exactly the same time, this warning message is displayed:

```
% MST CFG:Configuration change lost because of concurrent access
```

This command does not require a license.

### Examples

This example shows how to enter MST-configuration mode:

```
switch# configure terminal  
switch(config)# spanning-tree mst configuration  
switch(config-mst)#
```

This example shows how to reset the MST configuration (name, instance mapping, and revision number) to the default settings:

```
switch# configure terminal  
switch(config)# no spanning-tree mst configuration  
switch(config)#
```

### Related Commands

Command	Description
<b>instance vlan</b>	Maps a VLAN or a set of VLANs to an MST instance.
<b>name (MST configuration)</b>	Sets the name of an MST region.
<b>revision</b>	Sets the revision number for the MST configuration.
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst cost

To set the path-cost parameter for any Multiple Spanning Tree (MST) instance (including the Common and Internal Spanning Tree [CIST] with instance ID 0), use the **spanning-tree mst cost** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst** *instance-id* **cost** {*cost* | **auto**}

**no spanning-tree mst** *instance-id* **cost**

## Syntax Description

<i>instance-id</i>	Instance ID number. The range is from 0 to 4094.
<i>cost</i>	Port cost for an instance. The range is from 1 to 200,000,000.
<b>auto</b>	Sets the value of the port cost by the media speed of the interface.

## Command Default

Automatically set port cost values:

- 10 Mbps—2,000,000
- 100 Mbps—200,000
- 1-Gigabit Ethernet—20,000
- 10-Gigabit Ethernet—2,000

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The port cost depends on the port speed; the faster interface speeds indicate smaller costs. MST always uses long path costs.

Higher cost values indicate higher costs. When entering the cost, do not include a comma in the entry; for example, enter 1000, not 1,000.

The EtherChannel bundle is considered as a single port. The port cost is the aggregation of all the configured port costs assigned to that channel.

This command does not require a license.

## Examples

This example shows how to set the interface path cost:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# spanning-tree mst 0 cost 17031970
switch(config-if)#
```

Related Commands	Command	Description
	<code>show spanning-tree mst</code>	Displays the information about the MST protocol.

# spanning-tree mst forward-time

To set the forward-delay timer for all the instances on the switch, use the **spanning-tree mst forward-time** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst forward-time** *seconds*

**no spanning-tree mst forward-time**

Syntax Description	<i>seconds</i>	Number of seconds to set the forward-delay timer for all the instances on the switch. The range is from 4 to 30 seconds.
--------------------	----------------	--

Command Default	15 seconds
-----------------	------------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Examples	<p>This example shows how to set the forward-delay timer:</p> <pre>switch# configure terminal switch(config)# spanning-tree mst forward-time 20 switch(config)#</pre>
----------	---

Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst hello-time

To set the hello-time delay timer for all the instances on the switch, use the **spanning-tree mst hello-time** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst hello-time** *seconds*

**no spanning-tree mst hello-time**

Syntax Description	<i>seconds</i> Number of seconds to set the hello-time delay timer for all the instances on the switch. The range is from 1 to 10 seconds.	
Command Default	2 seconds	
Command Modes	Global configuration mode	
Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
Usage Guidelines	If you do not specify the <i>hello-time</i> value, the value is calculated from the network diameter. This command does not require a license.	
Examples	This example shows how to set the hello-time delay timer:  switch# <b>configure terminal</b> switch(config)# <b>spanning-tree mst hello-time 3</b> switch(config)#	
Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.



# spanning-tree mst max-age

To set the max-age timer for all the instances on the switch, use the **spanning-tree mst max-age** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst max-age** *seconds*

**no spanning-tree mst max-age**

<b>Syntax Description</b>	<i>seconds</i>	Number of seconds to set the max-age timer for all the instances on the switch. The range is from 6 to 40 seconds.
<b>Command Default</b>	20 seconds	
<b>Command Modes</b>	Global configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	<p>This parameter is used only by Instance 0 or the IST.</p> <p>This command does not require a license.</p>	
<b>Examples</b>	<p>This example shows how to set the max-age timer:</p> <pre>switch# <b>configure terminal</b> switch(config)# <b>spanning-tree mst max-age 40</b> switch(config)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst max-hops

To specify the number of possible hops in the region before a bridge protocol data unit (BPDU) is discarded, use the **spanning-tree mst max-hops** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst max-hops** *hop-count*

**no spanning-tree mst max-hops**

Syntax Description	<i>hop-count</i>	Number of possible hops in the region before a BPDU is discarded. The range is from 1 to 255 hops.
--------------------	------------------	--

Command Default	20 hops
-----------------	---------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Examples

This example shows how to set the number of possible hops:

```
switch# configure terminal
switch(config)# spanning-tree mst max-hops 25
switch(config)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst port-priority

To set the port-priority parameters for any Multiple Spanning Tree (MST) instance, including the Common and Internal Spanning Tree (CIST) with instance ID 0, use the **spanning-tree mst port-priority** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst** *instance-id* **port-priority** *priority*

**no spanning-tree mst** *instance-id* **port-priority**

## Syntax Description

<i>instance-id</i>	Instance ID number. The range is from 0 to 4094.
<i>priority</i>	Port priority for an instance. The range is from 0 to 224 in increments of 32.

## Command Default

Port priority value is 128.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Higher **port-priority** *priority* values indicate smaller priorities.

The priority values are 0, 32, 64, 96, 128, 160, 192, and 224. All other values are rejected.

This command does not require a license.

## Examples

This example shows how to set the interface priority:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# spanning-tree mst 0 port-priority 64
switch(config-if)#
```

## Related Commands

Command	Description
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.
<b>spanning-tree port-priority</b>	Configures the port priority for the default STP, which is Rapid PVST+.

# spanning-tree mst priority

To set the bridge priority, use the **spanning-tree mst priority** command. To return to the default setting, use the **no** form of this command.

**spanning-tree mst** *instance-id* **priority** *priority-value*

**no spanning-tree mst** *instance-id* **priority**

<b>Syntax Description</b>	<i>instance-id</i>	Instance identification number. The range is from 0 to 4094.
	<i>priority-value</i>	Bridge priority. See the “Usage Guidelines” section for valid values and additional information.

**Command Default** Bridge priority default is 32768.

**Command Modes** Global configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** You can set the bridge priority in increments of 4096 only. When you set the priority, valid values are 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, and 61440.

You can set the *priority-value* argument to 0 to make the switch root.

You can enter the *instance-id* argument as a single instance or a range of instances, for example, 0-3,5,7-9.

This command does not require a license.

**Examples** This example shows how to set the bridge priority:

```
switch# configure terminal
switch(config)# spanning-tree mst 0 priority 4096
switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst root

To designate the primary and secondary root and set the timer value for an instance, use the **spanning-tree mst root** command. To return to the default settings, use the **no** form of this command.

**spanning-tree mst** *instance-id* **root** { **primary** | **secondary** } [**diameter** *dia* [**hello-time** *hello-time*]]

**no spanning-tree mst** *instance-id* **root**

Syntax Description		
<i>instance-id</i>		Instance identification number. The range is from 0 to 4094.
<b>primary</b>		Specifies the high priority (low value) that is high enough to make the bridge root of the spanning-tree instance.
<b>secondary</b>		Specifies the switch as a secondary root, if the primary root fails.
<b>diameter</b> <i>dia</i>		(Optional) Specifies the timer values for the bridge that are based on the network diameter.
<b>hello-time</b> <i>hello-time</i>		(Optional) Specifies the duration between the generation of configuration messages by the root switch. The range is from 1 to 10 seconds; the default is 2 seconds.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines**

You can enter the *instance-id* argument as a single instance or a range of instances, for example, 0-3,5,7-9.

If you do not specify the *hello-time* argument, the argument is calculated from the network diameter. You must first specify the **diameter** *dia* keyword and argument before you can specify the **hello-time** *hello-time* keyword and argument.

This command does not require a license.

**Examples** This example shows how to designate the primary root:

```
switch# configure terminal
switch(config)# spanning-tree mst 0 root primary
switch(config)#
```

This example shows how to set the priority and timer values for the bridge:

```
switch# configure terminal
switch(config)# spanning-tree mst 0 root primary diameter 7 hello-time 2
```

```
switch(config)#
```

**Related Commands**

Command	Description
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst simulate pvst

To reenable specific interfaces to automatically interoperate between Multiple Spanning Tree (MST) and Rapid per VLAN Spanning Tree Plus (Rapid PVST+), use the **spanning-tree mst simulate pvst** command. To prevent specific MST interfaces from automatically interoperating with a connecting device running Rapid PVST+, use the **spanning-tree mst simulate pvst disable** command. To return specific interfaces to the default settings that are set globally for the switch, use the **no** form of this command.

**spanning-tree mst simulate pvst**

**spanning-tree mst simulate pvst disable**

**no spanning-tree mst simulate pvst**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Enabled. By default, all interfaces on the switch interoperate seamlessly between MST and Rapid PVST+. See the **spanning-tree mst simulate pvst global** command to change this setting globally.

**Command Modes** Interface configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** MST interoperates with Rapid PVST+ with no need for user configuration. The PVST+ simulation feature enables this seamless interoperability. However, you may want to control the connection between MST and Rapid PVST+ to protect against accidentally connecting an MST-enabled port to a Rapid PVST+-enabled port.

When you use the **spanning-tree mst simulate pvst disable** command, specified MST interfaces that receive a Rapid PVST+ (SSTP) bridge protocol data unit (BPDU) move into the STP blocking state. Those interfaces remain in the inconsistent state until the port stops receiving Rapid PVST+ BPDUs, and then the port resumes the normal STP transition process.



**Note**

To block automatic MST and Rapid PVST+ interoperability for the entire switch, use **no spanning-tree mst simulate pvst global** command.

This command is useful when you want to prevent accidental connection with a device running Rapid PVST+.

To reenable seamless operation between MST and Rapid PVST+ on specific interfaces, use the **spanning-tree mst simulate pvst** command.

This command does not require a license.

---

**Examples**

This example shows how to prevent specified ports from automatically interoperating with a connected device running Rapid PVST+:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# spanning-tree mst simulate pvst disable
switch(config-if)#
```

---

**Related Commands**

Command	Description
<b>spanning-tree mst simulate pvst global</b>	Enables global seamless interoperation between MST and Rapid PVST+.



# spanning-tree mst simulate pvst global

To prevent the Multiple Spanning Tree (MST) switch from automatically interoperating with a connecting device running Rapid per VLAN Spanning Tree Plus (Rapid PVST+), use the **spanning-tree mst simulate pvst global** command. To return to the default settings, which is a seamless operation between MST and Rapid PVST+ on the switch, use the **no spanning-tree mst simulate pvst global** command.

**spanning-tree mst simulate pvst global**

**no spanning-tree mst simulate pvst global**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Enabled. By default, the switch interoperates seamlessly between MST and Rapid PVST+.
------------------------	---

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>MST does not require user configuration to interoperate with Rapid PVST+. The PVST+ simulation feature enables this seamless interoperability. However, you may want to control the connection between MST and Rapid PVST+ to protect against accidentally connecting an MST-enabled port to a Rapid PVST+-enabled port.</p>
-------------------------	---

When you use the **no spanning-tree mst simulate pvst global** command, the switch running in MST mode moves all interfaces that receive a Rapid PVST+ (SSTP) bridge protocol data unit (BPDU) into the Spanning Tree Protocol (STP) blocking state. Those interfaces remain in the inconsistent state until the port stops receiving Rapid PVST+ BPDUs, and then the port resumes the normal STP transition process.

You can also use this command from the interface mode, and the configuration applies to the entire switch.



<b>Note</b>	To block automatic MST and Rapid PVST+ interoperability for specific interfaces, see the <b>spanning-tree mst simulate pvst</b> command.
-------------	--

This command is useful when you want to prevent accidental connection with a device not running MST.

To return the switch to seamless operation between MST and Rapid PVST+, use the **spanning-tree mst simulate pvst global** command.

This command does not require a license.

---

**Examples**

This example shows how to prevent all ports on the switch from automatically interoperating with a connected device running Rapid PVST+:

```
switch# configure terminal
switch(config)# no spanning-tree mst simulate pvst global
switch(config)#
```

---

**Related Commands**


Command	Description
<b>spanning-tree mst simulate pvst</b>	Enables seamless interoperation between MST and Rapid PVST+ by the interface.

# spanning-tree pathcost method

To set the default path-cost calculation method, use the **spanning-tree pathcost method** command. To return to the default settings, use the **no** form of this command.

**spanning-tree pathcost method {long | short}**

**no spanning-tree pathcost method**

<b>Syntax Description</b>	<table> <tr> <td><b>long</b></td><td>Specifies the 32-bit based values for port path costs.</td></tr> <tr> <td><b>short</b></td><td>Specifies the 16-bit based values for port path costs.</td></tr> </table>	<b>long</b>	Specifies the 32-bit based values for port path costs.	<b>short</b>	Specifies the 16-bit based values for port path costs.
<b>long</b>	Specifies the 32-bit based values for port path costs.				
<b>short</b>	Specifies the 16-bit based values for port path costs.				
<b>Command Default</b>	Short				
<b>Command Modes</b>	Global configuration mode				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	<p>The <b>long</b> path-cost calculation method uses all 32 bits for path-cost calculations and yields values in the range of 2 through 2,00,000,000.</p> <p>The <b>short</b> path-cost calculation method (16 bits) yields values in the range of 1 through 65535.</p>				
 <b>Note</b>	<p>This command applies only to the Rapid per VLAN Spanning Tree Plus (Rapid PVST+) spanning tree mode, which is the default mode. When you are using Multiple Spanning Tree (MST) spanning tree mode, the switch uses only the long method for calculating path cost; this is not user-configurable for MST.</p> <p>This command does not require a license.</p>				
<b>Examples</b>	<p>This example shows how to set the default pathcost method to long:</p> <pre>switch# configure terminal switch(config)# spanning-tree pathcost method long switch(config)#</pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>show spanning-tree summary</b></td><td>Displays information about the spanning tree state.</td></tr> </table>	Command	Description	<b>show spanning-tree summary</b>	Displays information about the spanning tree state.
Command	Description				
<b>show spanning-tree summary</b>	Displays information about the spanning tree state.				

# spanning-tree port type edge

To configure an interface connected to a host as an edge port, which automatically transitions the port to the spanning tree forwarding state without passing through the blocking or learning states, use the **spanning-tree port type edge** command. To return the port to a normal spanning tree port, use the **no spanning-tree port type** command.

```
spanning-tree port type edge [trunk]

no spanning-tree port type
```


Syntax Description	trunk (Optional) Configures the trunk port as a spanning tree edge port.
--------------------	--

Command Default	The default is the global setting for the default port type edge that is configured when you entered the <b>spanning-tree port type edge default</b> command. If you did not configure a global setting, the default spanning tree port type is normal.
-----------------	---

Command Modes	Interface configuration mode
---------------	------------------------------


Command History	ReleaseModification
	5.0(3)U1(1) This command was introduced.

Usage Guidelines	You can also use this command to configure a port in trunk mode as a spanning tree edge port.
------------------	---

  
Caution

You should use this command only with interfaces that connect to end stations; otherwise, an accidental topology loop could cause a data-packet loop and disrupt the switch and network operation.

When a linkup occurs, spanning tree edge ports are moved directly to the spanning tree forwarding state without waiting for the standard forward-time delay.

  
Note

This is the same functionality that was previously provided by the Cisco-proprietary PortFast feature.

When you use this command, the system returns a message similar to the following:

```
Warning: portfast should only be enabled on ports connected to a single
host. Connecting hubs, concentrators, switches, bridges, etc... to this
interface when portfast is enabled, can cause temporary bridging loops.
Use with CAUTION
```

When you use this command without the **trunk** keyword, the system returns an additional message similar to the following:

```
%Portfast has been configured on Ethernet1/40 but will only
have effect when the interface is in a non-trunking mode.
```

To configure trunk interfaces as spanning tree edge ports, use the **spanning-tree port type trunk** command. To remove the spanning tree edge port type setting, use the **no spanning-tree port type** command.

The default spanning tree port type is normal.

This command does not require a license.

### Examples

This example shows how to configure an interface connected to a host as an edge port, which automatically transitions that interface to the forwarding state on a linkup:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# spanning-tree port type edge
switch(config-if)#
```

### Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning tree state.

# spanning-tree port type edge bpdupfilter default

To enable bridge protocol data unit (BPDU) Filtering by default on all spanning tree edge ports, use the **spanning-tree port type edge bpdupfilter default** command. To disable BPDU Filtering by default on all edge ports, use the **no** form of this command.

**spanning-tree port type edge bpdupfilter default**

**no spanning-tree port type edge bpdupfilter default**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Disabled

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

To enable BPDU Filtering by default, you must do the following:

- Configure the interface as a spanning tree edge port, using the **spanning-tree port type edge** or the **spanning-tree port type edge default** command.
- Enable BPDU Filtering.

Use this command to enable BPDU Filtering globally on all spanning tree edge ports. BPDU Filtering prevents a port from sending or receiving any BPDUs.



### Caution

Be cautious when using this command; incorrect usage can cause bridging loops.



### Note

The BPDU Filtering feature's functionality is different when you enable it on a per-port basis or globally. When enabled globally, BPDU Filtering is applied only on ports that are operational spanning tree edge ports. Ports send a few BPDUs at a linkup before they effectively filter outbound BPDUs. If a BPDU is received on an edge port, that port immediately becomes a normal spanning tree port with all the normal transitions and BPDU Filtering is disabled. When enabled locally on a port, BPDU Filtering prevents the switch from receiving or sending BPDUs on this port.

This command does not require a license.

**Examples**

This example shows how to enable BPDU Filtering globally on all spanning tree edge operational ports by default:

```
switch# configure terminal
switch(config)# spanning-tree port type edge bpdudfilter default
switch(config)#
```

**Related Commands**

Command	Description
<b>show spanning-tree summary</b>	Displays the information about the spanning tree configuration.
<b>spanning-tree bpdudfilter</b>	Enables BPDU Filtering on the interface.
<b>spanning-tree port type edge</b>	Configures an interface as a spanning tree edge port.

# spanning-tree port type edge bpduguard default

To enable bridge protocol data unit (BPDU) Guard by default on all spanning tree edge ports, use the **spanning-tree port type edge bpduguard default** command. To disable BPDU Guard on all edge ports by default, use the **no** form of this command.

**spanning-tree port type edge bpduguard default**

**no spanning-tree port type edge bpduguard default**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Disabled

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

To enable BPDU Guard by default, you must do the following:

- Configure the interface as spanning tree edge ports by entering the **spanning-tree port type edge** or the **spanning-tree port type edge default** command.
- Enable BPDU Guard.

Use this command to enable BPDU Guard globally on all spanning tree edge ports. BPDU Guard disables a port if it receives a BPDU.

Global BPDU Guard is applied only on spanning tree edge ports.

You can also enable BPDU Guard per interface; see the **spanning-tree bpduguard** command for more information.



### Note

We recommend that you enable BPDU Guard on all spanning tree edge ports.

This command does not require a license.

## Examples

This example shows how to enable BPDU Guard by default on all spanning tree edge ports:

```
switch# configure terminal
switch(config)# spanning-tree port type edge bpduguard default
switch(config)#
```



Related Commands	Command	Description
	<b>show spanning-tree summary</b>	Displays the information about the spanning tree configuration.
	<b>spanning-tree bpduguard</b>	Enables BPDU guard on the interface.
	<b>spanning-tree port type edge</b>	Configures an interface as a spanning tree edge port.

# spanning-tree port type edge default

To configure all access ports that are connected to hosts as edge ports by default, use the **spanning-tree port type edge default** command. To restore all ports connected to hosts as normal spanning tree ports by default, use the **no** form of this command.

**spanning-tree port type edge default**

**no spanning-tree port type edge default**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Disabled

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Use this command to automatically configure all interfaces as spanning tree edge ports by default. This command will not work on trunk ports.



### Caution

Be careful when using this command. You should use this command only with interfaces that connect to end stations; otherwise, an accidental topology loop could cause a data-packet loop and disrupt the switch and network operation.

When a linkup occurs, an interface configured as an edge port automatically moves the interface directly to the spanning tree forwarding state without waiting for the standard forward-time delay. (This transition was previously configured as the Cisco-proprietary PortFast feature.)

When you use this command, the system returns a message similar to the following:

```
Warning: this command enables portfast by default on all interfaces. You
should now disable portfast explicitly on switched ports leading to hubs,
switches and bridges as they may create temporary bridging loops.
```

You can configure individual interfaces as edge ports using the **spanning-tree port type edge** command.

The default spanning tree port type is normal.

This command does not require a license.

## Examples

This example shows how to globally configure all ports connected to hosts as spanning tree edge ports:

```
switch# configure terminal
switch(config)# spanning-tree port type edge default
```

```
switch(config)#
```

**Related Commands**

Command	Description
<b>show spanning-tree summary</b>	Displays information about the spanning tree configuration.
<b>spanning-tree port type edge</b>	Configures an interface as a spanning tree edge port.

# spanning-tree port type network

To configure the interface that connects to a switch as a network spanning tree port, regardless of the global configuration, use the **spanning-tree port type network** command. To return the port to a normal spanning tree port, use the use the **no** form of this command.

**spanning-tree port type network**

**no spanning-tree port type**

Syntax Description

This command has no arguments or keywords.

Command Default

The default is the global setting for the default port type network that is configured when you entered the **spanning-tree port type network default** command. If you did not configure a global setting, the default spanning tree port type is normal.

Command Modes

Interface configuration mode

Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

Usage Guidelines

Use this command to configure an interface that connects to a switch as a spanning tree network port. Bridge Assurance runs only on Spanning Tree Protocol (STP) network ports.

  
**Note**

If you mistakenly configure ports connected to hosts as STP network ports and enable Bridge Assurance, those ports will automatically move into the blocking state.

  
**Note**

Bridge Assurance is enabled by default, and all interfaces configured as spanning tree network ports have Bridge Assurance enabled.

To configure a port as a spanning tree network port, use the **spanning-tree port type network** command. To remove this configuration, use the **no spanning-tree port type** command. When you use the **no spanning-tree port type** command, the software returns the port to the global default setting for network port types.

You can configure all ports that are connected to switches as spanning tree network ports by default by entering the **spanning-tree port type network default** command.

The default spanning tree port type is normal.

This command does not require a license.

---

**Examples**

This example shows how to configure an interface connected to a switch or bridge as a spanning tree network port:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# spanning-tree port type network
switch(config-if)#
```

---

**Related Commands**

Command	Description
<b>show spanning-tree interface</b>	Displays information about the spanning tree configuration per specified interface.

# spanning-tree port type network default

To configure all ports as spanning tree network ports by default, use the **spanning-tree port type network default** command. To restore all ports to normal spanning tree ports by default, use the **no** form of this command.

**spanning-tree port type network default**

**no spanning-tree port type network default**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Disabled

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Use this command to automatically configure all interfaces that are connected to switches as spanning tree network ports by default. You can then use the **spanning-tree port type edge** command to configure specified ports that are connected to hosts as spanning-tree edge ports.



### Note

If you mistakenly configure ports connected to hosts as Spanning Tree Protocol (STP) network ports and Bridge Assurance is enabled, those ports will automatically move into the blocking state.

Configure only the ports that connect to other switches as network ports because the Bridge Assurance feature causes network ports that are connected to hosts to move into the spanning tree blocking state.

You can identify individual interfaces as network ports by using the **spanning-tree port type network** command.

The default spanning tree port type is normal.

This command does not require a license.

## Examples

This example shows how to globally configure all ports connected to switches as spanning tree network ports:

```
switch# configure terminal
switch(config)# spanning-tree port type network default
switch(config)#
```

Related Commands	Command	Description
	show spanning-tree summary	Displays information about the spanning tree configuration.

# spanning-tree port-priority

To set an interface priority when two bridges compete for position as the root bridge, use the **spanning-tree port-priority** command. The priority you set breaks the tie. To return to the default settings, use the **no** form of this command.

**spanning-tree** [vlan *vlan-id*] **port-priority** *value*

**no spanning-tree** [vlan *vlan-id*] **port-priority**

Syntax Description	vlan <i>vlan-id</i>	(Optional) Specifies the VLAN identification number. The range is from 0 to 4094.
	value	Port priority. The range is from 1 to 224, in increments of 32.

Command Default	Port priority default value is 128.
-----------------	-------------------------------------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	<p>Do not use the <b>vlan</b> <i>vlan-id</i> parameter on access ports. The software uses the port priority value for access ports and the VLAN port priority values for trunk ports.</p> <p>The priority values are 0, 32, 64, 96, 128, 160, 192, and 224. All other values are rejected.</p>
------------------	--



Note

Use this command to configure the port priority for Rapid per VLAN Spanning Tree Plus (Rapid PVST+) spanning tree mode, which is the default STP mode. To configure the port priority for Multiple Spanning Tree (MST) spanning tree mode, use the **spacing-tree mst port-priority** command.

This command does not require a license.

Examples	<p>This example shows how to increase the probability that the spanning tree instance on access port interface 2/0 is chosen as the root bridge by changing the port priority to 32:</p> <pre>switch# configure terminal switch(config)# interface ethernet 1/1 switch(config-if)# spanning-tree port-priority 32 switch(config-if)#</pre>
----------	--



Related Commands	Command	Description
	show spanning-tree	Displays information about the spanning tree state.
	spanning-tree interface priority	Displays information on the spanning tree port priority for the interface.

# spanning-tree vlan

To configure Spanning Tree Protocol (STP) parameters on a per-VLAN basis, use the **spanning-tree vlan** command. To return to the default settings, use the **no** form of this command.

**spanning-tree vlan** *vlan-id* [**forward-time** *value* | **hello-time** *value* | **max-age** *value* | **priority** *value* | [**root** {**primary** | **secondary**} [**diameter** *dia* [**hello-time** *value*]]]]

**no spanning-tree vlan** *vlan-id* [**forward-time** | **hello-time** | **max-age** | **priority** | **root**]

## Syntax Description

<i>vlan-id</i>	VLAN identification number. The VLAN ID range is from 0 to 4094.
<b>forward-time</b> <i>value</i>	(Optional) Specifies the STP forward-delay time. The range is from 4 to 30 seconds.
<b>hello-time</b> <i>value</i>	(Optional) Specifies the number of seconds between the generation of configuration messages by the root switch. The range is from 1 to 10 seconds.
<b>max-age</b> <i>value</i>	(Optional) Specifies the maximum number of seconds that the information in a bridge protocol data unit (BPDU) is valid. The range is from 6 to 40 seconds.
<b>priority</b> <i>value</i>	(Optional) Specifies the STP-bridge priority; the valid values are 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, or 61440. All other values are rejected.
<b>root primary</b>	(Optional) Forces this switch to be the root bridge.
<b>root secondary</b>	(Optional) Forces this switch to be the root switch if the primary root fails.
<b>diameter</b> <i>dia</i>	(Optional) Specifies the maximum number of bridges between any two points of attachment between end stations.

## Command Default

The defaults are as follows:

- **forward-time**—15 seconds
- **hello-time**—2 seconds
- **max-age**—20 seconds
- **priority**—32768

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines



### Caution

When disabling spanning tree on a VLAN using the **no spanning-tree vlan *vlan-id*** command, ensure that all switches and bridges in the VLAN have spanning tree disabled. You cannot disable spanning tree on some switches and bridges in a VLAN and leave it enabled on other switches and bridges in the same VLAN because switches and bridges with spanning tree enabled have incomplete information about the physical topology of the network.



### Caution

We do not recommend disabling spanning tree even in a topology that is free of physical loops. Spanning tree is a safeguard against misconfigurations and cabling errors. Do not disable spanning tree in a VLAN without ensuring that there are no physical loops present in the VLAN.

When setting the **max-age *seconds***, if a bridge does not see BPDUs from the root bridge within the specified interval, it assumes that the network has changed and recomputes the spanning-tree topology.

The **spanning-tree root primary** alters this switch's bridge priority to 24576. If you enter the **spanning-tree root primary** command and the switch does not become the root, then the bridge priority is changed to 4096 less than the bridge priority of the current bridge. The command fails if the value required to be the root bridge is less than 1. If the switch does not become the root, an error results.

If the network devices are set for the default bridge priority of 32768 and you enter the **spanning-tree root secondary** command, the software alters this switch's bridge priority to 28762. If the root switch fails, this switch becomes the next root switch.

Use the **spanning-tree root** commands on the backbone switches only.

This command does not require a license.

## Examples

This example shows how to enable spanning tree on VLAN 200:

```
switch# configure terminal
switch(config)# spanning-tree vlan 200
switch(config)#
```

This example shows how to configure the switch as the root switch for VLAN 10 with a network diameter of 4:

```
switch# configure terminal
switch(config)# spanning-tree vlan 10 root primary diameter 4
switch(config)#
```

This example shows how to configure the switch as the secondary root switch for VLAN 10 with a network diameter of 4:

```
switch# configure terminal
switch(config)# spanning-tree vlan 10 root secondary diameter 4
switch(config)#
```

## Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning tree state.

# state

To set the operational state for a VLAN, use the **state** command. To return a VLAN to its default operational state, use the **no** form of this command.

```
state { active | suspend }

no state
```

Syntax Description	active	Specifies that the VLAN is actively passing traffic.
	suspend	Specifies that the VLAN is not passing any packets.

Command Default The VLAN is actively passing traffic.

Command Modes VLAN configuration mode  
Switch profile VLAN configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
	5.0(3)U2(1)	Support for this command was introduced in a switch profile.

Usage Guidelines You cannot suspend the state for VLAN 1 or VLANs 1006 to 4094.  
VLANs in the suspended state do not pass packets.  
This command does not require a license.

Examples This example shows how to suspend VLAN 2:

```
switch# configure terminal
switch(config)# vlan 2
switch(config-vlan)# state suspend
switch(config-vlan)#
```

This example shows how to suspend VLAN 5 in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# vlan 5
switch(config-sync-sp-vlan)# state suspend
switch(config-sync-sp-vlan)#
```

**Related Commands**

Command	Description
show vlan	Displays VLAN information.

# storm-control

To configure traffic storm control for traffic on an interface, use the **storm-control** command. To disable traffic storm control on an interface, use the **no** form of this command.

**storm-control** [**broadcast** | **multicast** | **unicast**] **level** *percentage* [*.fraction*] | [**action** {[**no**] **shutdown** | **trap**}]

**no storm-control** [**broadcast** | **multicast** | **unicast**] **level** *percentage* [*.fraction*] | [**action** {[**no**] **shutdown** | **trap**}]

<b>Syntax Description</b>	<b>broadcast</b>	Configures traffic storm control for broadcast traffic.
	<b>multicast</b>	Configures traffic storm control for multicast traffic.
	<b>unicast</b>	Configures traffic storm control for unicast traffic.
	<b>level</b> <i>percentage</i> . <i>fraction</i>	Specifies the percentage of total available interface bandwidth that the controlled traffic can use. <ul style="list-style-type: none"> <li>The level can range from 0 to 100.</li> <li>The optional fraction of a level can range from 0 to 99.</li> <li>100 percent means no traffic storm control.</li> <li>0.0 percent suppresses all traffic.</li> </ul>
	<b>action shutdown</b>	Configures the port to shut down when incoming traffic exceeds the threshold.
	<b>action trap</b>	Configures the port to generate an SNMP trap when incoming traffic exceeds the threshold.

**Command Default** Traffic storm control is disabled by default.

**Command Modes** Interface configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.0(2)U3(1)	Configurable actions, <b>shutdown</b> and <b>trap</b> , were introduced.

**Usage Guidelines**

- You can configure traffic storm control on a port-channel interface.
- Because of hardware limitations and the method by which packets of different sizes are counted, the level percentage is an approximation. Depending on the sizes of the frames that make up the incoming traffic, the actual enforced level might differ from the configured level by several percentage points.
- Due to a hardware limitation, the output for the **show interface counters storm-control** command does not show ARP suppressions when storm control is configured and the interface is actually suppressing some traffic. Packet drops due to storm control are counted in the input discard counter.

- Due to a hardware limitation, the packet drop counter cannot distinguish between packet drops caused by a traffic storm and other discarded input frames. This can lead to the configured action being triggered even in the absence of a traffic storm.
- Storm control is only for ingress traffic, specifically for unknown unicast, unknown multicast, and broadcast traffic.
- Storm-control is applied on each member of a port channel individually and not on the port channel as a whole.

### Examples

This example shows how to configure traffic storm control for port channels 122 and 123:

```
switch# configure terminal
switch(config)# interface port-channel 122, port-channel 123
switch(config-if-range)# storm-control unicast level 66.75
switch(config-if-range)# storm-control multicast level 66.75
switch(config-if-range)# storm-control broadcast level 66.75
switch(config-if-range)#
```

This example shows how to configure the port to shut down during a traffic storm:

```
switch# configure terminal
switch(config)# interface port-channel 122
switch(config-if)# storm-control action shutdown
```

This example shows how to configure the port to generate an SNMP trap during a traffic storm:

```
switch# configure terminal
switch(config)# interface port-channel 123
switch(config-if)# storm-control action trap
```

### Related Commands

Command	Description
<b>show running-config interface</b>	Displays the running configuration information for configured interfaces.

# svi enable

To enable the creation of VLAN interfaces, use the **svi enable** command. To disable the VLAN interface feature, use the **no** form of this command.

**svi enable**

**no svi enable**

**Syntax Description** This command has no arguments or keywords.

**Command Default** VLAN interfaces are disabled.

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** You must use the **feature interface-vlan** command before you can create VLAN interfaces. This command does not require a license.

**Examples** This example shows how to enable the interface VLAN feature on the switch:

```
switch# configure terminal
switch(config)# svi enable
switch(config)#
```

Related Commands	Command	Description
	<b>interface vlan</b>	Creates a VLAN interface.



# switchport access vlan

To set the access VLAN when the interface is in access mode, use the **switchport access vlan** command. To reset the access-mode VLAN to the appropriate default VLAN for the switch, use the **no** form of this command.

**switchport access vlan** *vlan-id*

**no switchport access vlan**

<b>Syntax Description</b>	<i>vlan-id</i>	VLAN to set when the interface is in access mode. The range is from 1 to 4094, except for the VLANs reserved for internal use.
---------------------------	----------------	--

<b>Command Default</b>	VLAN 1
------------------------	--------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>Use the <b>no</b> form of the <b>switchport access vlan</b> command to reset the access-mode VLAN to the appropriate default VLAN for the switch. This action may generate messages on the device to which the port is connected.</p> <p>This command does not require a license.</p>
-------------------------	--

<b>Examples</b>	This example shows how to configure an Ethernet interface to join VLAN 2:
-----------------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/7
switch(config-if)# switchport access vlan 2
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show interface switchport</b>	Displays the administrative and operational status of a port.

# switchport mode private-vlan host

To set the interface type to be a host port for a private VLAN, use the **switchport mode private-vlan host** command.

**switchport mode private-vlan host**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Interface configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** When you configure a port as a host private VLAN port and one of the following applies, the port becomes inactive:

- The port does not have a valid private VLAN association configured.
- The port is a Switched Port Analyzer (SPAN) destination.
- The private VLAN association is suspended.

If you delete a private VLAN port association, or if you configure a private port as a SPAN destination, the deleted private VLAN port association or the private port that is configured as a SPAN destination becomes inactive.



**Note** We recommend that you enable spanning tree BPDU Guard on all private VLAN host ports.

This command does not require a license.

**Examples** This example shows how to set a port to host mode for private VLANs:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# switchport mode private-vlan host
switch(config-if)#
```

**Related Commands**

Command	Description
<b>show interface switchport</b>	Displays information on all interfaces configured as switch ports.
<b>show vlan private-vlan</b>	Displays the status of the private VLAN.

# switchport mode private-vlan promiscuous

To set the interface type to be a promiscuous port for a private VLAN, use the **switchport mode private-vlan promiscuous** command.

**switchport mode private-vlan promiscuous**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	When you configure a port as a promiscuous private VLAN port and one of the following applies, the port becomes inactive:
	<ul style="list-style-type: none"><li>• The port does not have a valid private VLAN mapping configured.</li><li>• The port is a Switched Port Analyzer (SPAN) destination.</li></ul>

If you delete a private VLAN port mapping or if you configure a private port as a SPAN destination, the deleted private VLAN port mapping or the private port that is configured as a SPAN destination becomes inactive.

See the **private-vlan** command for more information on promiscuous ports.

This command does not require a license.

<b>Examples</b>	This example shows how to set a port to promiscuous mode for private VLANs:
-----------------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# switchport mode private-vlan promiscuous
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show interface switchport</b>	Displays information on all interfaces configured as switch ports.
	<b>show vlan private-vlan</b>	Displays the status of the private VLAN.

# switchport monitor rate-limit

To configure a rate limit to monitor traffic on an interface, use the **switchport monitor rate-limit** command. To remove a rate limit, use the **no** form of this command.

**switchport monitor rate-limit 1G**

**no switchport monitor rate-limit [1G]**

<b>Syntax Description</b>	<b>1G</b> (Optional) Specifies that the rate limit is 1 GB.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Interface configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command does not require a license.	
<b>Examples</b>	This example shows how to limit the bandwidth on Ethernet interface 1/2 to 1 GB:  switch# <b>configure terminal</b> switch(config)# <b>interface ethernet 1/2</b> switch(config-if)# <b>switchport monitor rate-limit 1G</b> switch(config-if)#	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show interface switchport</b>	Displays information on all interfaces configured as switch ports.

# switchport private-vlan host-association

To define a private VLAN association for an isolated or community port, use the **switchport private-vlan host-association** command. To remove the private VLAN association from the port, use the **no** form of this command.

**switchport private-vlan host-association** {*primary-vlan-id*} {*secondary-vlan-id*}

**no switchport private-vlan host-association**

## Syntax Description

<i>primary-vlan-id</i>	Number of the primary VLAN of the private VLAN relationship.
<i>secondary-vlan-id</i>	Number of the secondary VLAN of the private VLAN relationship.

## Command Default

None

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

There is no run-time effect on the port unless it is in private VLAN-host mode. If the port is in private VLAN-host mode but neither of the VLANs exist, the command is allowed but the port is made inactive. The port also may be inactive when the association between the private VLANs is suspended.

The secondary VLAN may be an isolated or community VLAN.

See the **private-vlan** command for more information on primary VLANs, secondary VLANs, and isolated or community ports.



### Note

A private VLAN-isolated port on a Cisco Nexus 3000 Series switch running the current release of Cisco NX-OS does not support IEEE 802.1Q encapsulation and cannot be used as a trunk port.

This command does not require a license.

## Examples

This example shows how to configure a Layer 2 host private VLAN port with a primary VLAN (VLAN 18) and a secondary VLAN (VLAN 20):

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# switchport private-vlan host-association 18 20
switch(config-if)#
```

This example shows how to remove the private VLAN association from the port:

```
switch# configure terminal
```

```
switch(config)# interface ethernet 1/1
switch(config-if)# no switchport private-vlan host-association
switch(config-if)#
```

**Related Commands**

Command	Description
<b>show vlan private-vlan</b>	Displays information on private VLANs.

# switchport private-vlan mapping

To define the private VLAN association for a promiscuous port, use the **switchport private-vlan mapping** command. To clear all mapping from the primary VLAN, use the **no** form of this command.

```
switchport private-vlan mapping {primary-vlan-id} {[add] secondary-vlan-id | remove secondary-vlan-id}
```

```
no switchport private-vlan mapping
```

## Syntax Description

<i>primary-vlan-id</i>	Number of the primary VLAN of the private VLAN relationship.
<b>add</b>	(Optional) Associates the secondary VLANs to the primary VLAN.
<i>secondary-vlan-id</i>	Number of the secondary VLAN of the private VLAN relationship.
<b>remove</b>	Clears the association between the secondary VLANs and the primary VLAN.

## Command Default

None

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

There is no run-time effect on the port unless it is in private VLAN-promiscuous mode. If the port is in private VLAN-promiscuous mode but the primary VLAN does not exist, the command is allowed but the port is made inactive.

The secondary VLAN may be an isolated or community VLAN.

See the **private-vlan** command for more information on primary VLANs, secondary VLANs, and isolated or community ports.



### Note

A private VLAN-isolated port on a Cisco Nexus 3000 Series switch running the current release of Cisco NX-OS does not support IEEE 802.1Q encapsulation and cannot be used as a trunk port.

This command does not require a license.

## Examples

This example shows how to configure the associated primary VLAN 18 to secondary isolated VLAN 20 on a private VLAN promiscuous port:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# switchport private-vlan mapping 18 20
switch(config-if)#
```



This example shows how to add a VLAN to the association on the promiscuous port:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# switchport private-vlan mapping 18 add 21
switch(config-if)#
```

This example shows how to remove all private VLAN associations from the port:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# no switchport private-vlan mapping
switch(config-if)#
```

#### Related Commands

Command	Description
<b>show interface switchport</b>	Displays information on all interfaces configured as switch ports.
<b>show interface private-vlan mapping</b>	Displays the information about the private VLAN mapping for VLAN interfaces or switch virtual interfaces (SVIs).

# vlan

To add a VLAN or to enter the VLAN configuration mode, use the **vlan** command. To delete the VLAN and exit the VLAN configuration mode, use the **no** form of this command.

**vlan** {*vlan-id* | *vlan-range*}

**no vlan** {*vlan-id* | *vlan-range*}

## Syntax Description

<i>vlan-id</i>	Number of the VLAN. The range is from 1 to 4094.
	<b>Note</b> You cannot create, delete, or modify VLAN 1 or any of the internally allocated VLANs.
<i>vlan-range</i>	Range of configured VLANs; see the “Usage Guidelines” section for a list of valid values.

## Command Default

None

## Command Modes

Global configuration mode  
Switch profile configuration mode



### Note

You can also create and delete VLANs in the VLAN configuration mode using these same commands.

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.
5.0(3)U2(1)	Support for this command was introduced in switch profiles.

## Usage Guidelines

When you enter the **vlan** *vlan-id* command, a new VLAN is created with all default parameters and causes the CLI to enter VLAN configuration mode. If the *vlan-id* argument that you entered matches an existing VLAN, nothing happens except that you enter VLAN configuration mode.

You can enter the *vlan-range* using a comma (,), a dash (-), and the number.

VLAN 1 parameters are factory configured and cannot be changed; you cannot create or delete this VLAN. Additionally, you cannot create or delete VLAN 4095 or any of the internally allocated VLANs.

When you delete a VLAN, all the access ports in that VLAN are shut down and no traffic flows. On trunk ports, the traffic continues to flow for the other VLANs allowed on that port, but the packets for the deleted VLAN are dropped. However, the system retains all the VLAN-to-port mapping for that VLAN, and when you reenables, or recreates, that specified VLAN, the switch automatically reinstates all the original ports to that VLAN.

In Cisco NX-OS 5.0(3)U1(1), you can configure VLANs on a device configured as a VLAN Trunking Protocol (VTP) server or transparent device. If the VTP device is configured as a client, you cannot add a VLAN or enter the VLAN configuration mode.

This command does not require a license.

### Examples

This example shows how to add a new VLAN and enter VLAN configuration mode:

```
switch# configure terminal
switch(config)# vlan 2
switch(config-vlan)#
```

This example shows how to add a range of new VLANs and enter VLAN configuration mode:

```
switch# configure terminal
switch(config)# vlan 2,5,10-12,20,25,4000
switch(config-vlan)#
```

This example shows how to add a new VLAN and enter VLAN configuration mode in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# vlan 3
switch(config-sync-sp-vlan)#
```

This example shows how to delete a VLAN:

```
switch# configure terminal
switch(config)# no vlan 2
switch(config)#
```

### Related Commands

Command	Description
<b>ip igmp snooping (VLAN)</b>	Configures the Internet Group Management Protocol (IGMP) on a VLAN.
<b>name (VLAN configuration)</b>	Sets the name for a VLAN.
<b>show vlan</b>	Displays VLAN information.
<b>shutdown (VLAN configuration)</b>	Shuts down the local traffic on a VLAN.
<b>state</b>	Sets the operational state for a VLAN.

# vlan dot1Q tag native

To enable dot1q (IEEE 802.1Q) tagging for all native VLANs on all trunked ports on the switch, use the **vlan dot1Q tag native** command. To disable dot1q (IEEE 802.1Q) tagging for all native VLANs on all trunked ports on the switch, use the **no** form of this command.

```
vlan dot1Q tag native

no vlan dot1Q tag native
```

**Syntax Description** This command has no arguments or keywords.

**Command Default** Disabled


**Command Modes** Global configuration mode  
Switch profile configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
	5.0(3)U2(1)	Support for this command was introduced in switch profiles.

**Usage Guidelines** Typically, you configure 802.1Q trunks with a native VLAN ID, which strips tagging from all packets on that VLAN.

To maintain the tagging on the native VLAN and drop untagged traffic, use the **vlan dot1q tag native** command. The switch will tag the traffic received on the native VLAN and admit only 802.1Q-tagged frames, dropping any untagged traffic, including untagged traffic in the native VLAN.

Control traffic continues to be accepted as untagged on the native VLAN on a trunked port, even when the **vlan dot1q tag native** command is enabled.

**Note**

The **vlan dot1q tag native** command is enabled on global basis.

This command does not require a license.

**Examples** This example shows how to enable 802.1Q tagging on the switch:

```
switch# configure terminal
switch(config)# vlan dot1q tag native
switch(config)#
```

This example shows how to disable 802.1Q tagging on the switch:

```
switch# configure terminal
switch(config)# no vlan dot1q tag native
```

Turning off vlan dot1q tag native may impact the functioning of existing dot1q tunnel ports

```
switch(config)#
```

This example shows how to enable 802.1Q tagging in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# vlan dot1q tag native
switch(config-sync-sp)#
```

**Related Commands**

Command	Description
<b>show vlan dot1q tag native</b>	Displays the status of tagging on the native VLAN.

# vtp (interface)

To enable VLAN Trunking Protocol (VTP) on an interface, use the **vtp** command. To disable VTP on an interface, use the **no** form of this command.

**vtp**

**no vtp**

**Syntax Description** This command has no arguments or keywords.

**Command Default** VTP is enabled on a trunk interface

**Command Modes** Interface configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines**

Before you use this command, you must enable VTP on the switch by using the **feature vtp** command.

VLAN Trunking Protocol (VTP) is a Cisco Proprietary Layer 2 messaging protocol used to distribute the VLAN configuration information across multiple devices within a VTP domain.

This command does not require a license.

**Examples** This example shows how to enable VTP on an interface:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# vtp
switch(config-if)#
```

Related Commands	Command	Description
	<b>copy running-config startup-config</b>	Copies the running configuration to the startup configuration.
	<b>feature vtp</b>	Enables VTP on the switch.
	<b>show running-config vtp</b>	Displays the running VTP configuration.
	<b>show vtp status</b>	Displays VTP information.
	<b>snmp-server enable traps vtp</b>	Enables Simple Network Management Protocol (SNMP) notifications.

# vtp domain

To configure the name of the VLAN Trunking Protocol (VTP) administrative domain, use the **vtp domain** command. To remove the domain name, use the **no** form of this command.

**vtp domain** *name*

**no vtp domain**

<b>Syntax Description</b>	<i>name</i> VTP domain name. The name can be a maximum of 32 ASCII characters.
---------------------------	--

<b>Command Default</b>	Blank (NULL)
------------------------	--------------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	Before you use this command, you must enable VTP on the switch by using the <b>feature vtp</b> command.
	VLAN Trunking Protocol (VTP) is a Cisco Proprietary Layer 2 messaging protocol used to distribute the VLAN configuration information across multiple devices within a VTP domain. Without VTP, you must configure VLANs in each device in the network. Using VTP, you configure VLANs on a VTP server and then distribute the configuration to other VTP devices in the VTP domain.
	This command does not require a license.

<b>Examples</b>	This example shows how to create a VTP domain named accounting:
-----------------	---

```
switch# configure terminal
switch(config)# vtp domain accounting
switch(config)#
```

<b>Related Commands</b>	Command	Description
	<b>feature vtp</b>	Enables VTP on the switch.
	<b>show running-config vtp</b>	Displays the running VTP configuration.
	<b>show vtp status</b>	Displays VTP information.

# vtp file

To store the VLAN Trunking Protocol (VTP) configuration information in a file, use the **vtp file** command. To stop storing the configuration in a file, use the **no** form of this command.

**vtp file bootflash:***server*[*directory/*]*filename*

**no vtp file**

## Syntax Description

<b>bootflash:</b>	Specifies that the VTP configuration file is to be stored in the bootflash memory of the NVRAM. The colon character (:) is required after the file system name.
<i>server</i>	Name of the server. Valid values are <i>///</i> , <i>//module-1/</i> , <i>//sup-1/</i> , <i>//sup-active/</i> , or <i>//sup-local/</i> . The double slash (//) is required.
<i>directory/</i>	(Optional) Name of the destination directory. The directory name is case sensitive.
<i>filename</i>	Name of the VTP configuration file.



### Note

There can be no spaces in the **bootflash://server/directory/filename** string. Individual elements of this string are separated by colons (:) and slashes (/).

## Command Default

VTP database file, vlan.dat

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Before you use this command, you must enable VTP on the switch by using the **feature vtp** command. The default configuration file is stored in the VTP database, vlan.dat, in NVRAM. VTP configuration information is also stored in the startup configuration file.



### Note

Do not delete the vlan.dat file.

When a switch in a VTP domain reloads, the switch updates the VTP domain and VLAN configuration information from the information contained in the VTP database file (vlan.dat) or the startup configuration file.

If both the VTP database and the startup configuration file show the VTP mode as transparent and the VTP domain names match, the VTP database is ignored. The VTP and VLAN configurations in the startup configuration file are used to restore the configuration in this VTP device.



If the VTP domain information in the startup configuration file does not match with that in the VTP database file, then the configuration in the VTP database file is used to restore the configuration in the transparent VTP device.

This command does not require a license.

### Examples

This example shows how to store the VTP configuration to a file named myvtp.txt in the local writable storage file system, bootflash:

```
switch# configure terminal  
switch(config)# vtp file bootflash:///myvtp.txt  
switch(config)#
```

### Related Commands

Command	Description
<b>feature vtp</b>	Enables VTP on the switch.
<b>show running-config vtp</b>	Displays the running VTP configuration.
<b>show vtp status</b>	Displays VTP information.

# vtp mode

To configure the VLAN Trunking Protocol (VTP) device mode, use the **vtp mode** command. To revert to the default server mode, use the **no** form of this command.

**vtp mode transparent**

**no vtp mode**

<b>Syntax Description</b>	<b>transparent</b>	Specifies the device mode as transparent.
---------------------------	--------------------	---

<b>Command Default</b>	Server
------------------------	--------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines**

VLAN Trunking Protocol (VTP) is a Cisco Proprietary Layer 2 messaging protocol used to distribute the VLAN configuration information across multiple devices within a VTP domain. Without VTP, you must configure VLANs in each device in the network. Using VTP, you configure VLANs on a VTP server and then distribute the configuration to other VTP devices in the VTP domain.

In VTP transparent mode, you can configure VLANs (add, delete, or modify) and private VLANs. VTP transparent switches do not participate in VTP. A VTP transparent switch does not advertise its VLAN configuration and does not synchronize its VLAN configuration based on received advertisements. The VTP configuration revision number is always set to zero (0). Transparent switches do forward VTP advertisements that they receive out their trunk ports in VTP Version 2.

This command does not require a license.

**Examples**

This example shows how to configure a VTP device in transparent mode and add VLANs 2, 3, and 4:

```
switch# configure terminal
switch(config)# vtp mode transparent
switch(config)# vlan 2-4
switch(config-vlan)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>feature vtp</b>	Enables VTP on the switch.
	<b>show vtp status</b>	Displays VTP information.
	<b>vlan</b>	Configures VLANs.

# vtp password

To set the password for the VTP administrative domain, use the **vtp password** command. To remove the administrative password, use the **no** form of this command.

**vtp password** *password*

**no vtp password**

<b>Syntax Description</b>	<i>password</i>	VTP domain password. The password is in ASCII text and can be a maximum of 64 characters.
---------------------------	-----------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>If you configure a password for VTP, you must configure the password on all switches in the VTP domain. The password must be the same password on all those switches. The VTP password that you configure is translated by an algorithm into a 16-byte word (MD5 value) that is carried in all summary-advertisement VTP packets.</p> <p>This command does not require a license.</p>
-------------------------	--

<b>Examples</b>	<p>This example shows how to configure a password for the VTP administrative domain named accounting:</p> <pre>switch# <b>configure terminal</b> switch(config)# <b>vtp domain accounting</b> switch(config)# <b>vtp password cisco</b> switch(config)#</pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show vtp password</b>	Displays the VTP domain password.
	<b>show vtp status</b>	Displays VTP information.

# vtp version

To configure the administrative domain to a VLAN Trunking Protocol (VTP) version, use the **vtp version** command. To revert to the default version, use the **no** form of this command.

**vtp version** *version*

**no vtp version**

Syntax Description	<i>version</i> VTP version. The range is from 1 to 2.	
Command Default	Version 1 enabled Version 2 disabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
Usage Guidelines	<p>Before you use this command, you must enable VTP on the switch by using the <b>feature vtp</b> command.</p> <p>If you enable VTP, you must configure either version 1 or version 2. If you are using VTP in a Token Ring environment, you must use version 2.</p> <p>This command does not require a license.</p>	
Examples	<p>This example shows how to enable VTP version 2 for Token Ring VLANs:</p> <pre>switch# <b>configure terminal</b> switch(config)# <b>vtp version 2</b> switch(config)#</pre>	
Related Commands	Command	Description
	<b>feature vtp</b>	Enables VTP on the switch.
	<b>show vtp status</b>	Displays VTP information.