

# Users's Manual for Device Interfaces

Brent Seidel  
Phoenix, AZ

September 5, 2024

This document is ©2024, Brent Seidel. All rights reserved.

Note that this is a draft version and not the final version for publication.

# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	About the Project . . . . .	1
1.2	License . . . . .	1
<b>2</b>	<b>How to Obtain</b>	<b>2</b>
2.1	Dependencies . . . . .	2
2.1.1	bbs_embed_common . . . . .	2
2.1.2	bbs_embed_linux . . . . .	3
2.1.3	bbs_embed_due . . . . .	3
<b>3</b>	<b>Usage Instructions</b>	<b>5</b>
3.1	Linux Based Raspberry Pi and BeagleBone Black . . . . .	5
3.2	Arduino Due . . . . .	5
<b>4</b>	<b>Common API Description</b>	<b>6</b>
4.1	Basic Devices . . . . .	6
4.1.1	Analog Inputs . . . . .	7
4.1.2	General-Purpose Input/Output (GPIO) . . . . .	7
4.1.3	I2C Bus . . . . .	7
4.1.4	Logging . . . . .	10
4.1.5	SPI Bus . . . . .	10
4.2	Higher-Level Device Drivers . . . . .	11
4.2.1	BBS.embed.gpio.tb6612 . . . . .	11
4.2.2	BBS.embed.I2C.ADS1015 . . . . .	12
4.2.3	BBS.embed.i2c.BME280 . . . . .	16
4.2.4	BBS.embed.i2c.BMP180 . . . . .	18
4.2.5	BBS.embed.i2c.L3GD20H . . . . .	20
4.2.6	BBS.embed.i2c.LSM303DLHC . . . . .	24
4.2.7	BBS.embed.i2c.MCP4725 . . . . .	29
4.2.8	BBS.embed.i2c.MCP23008 . . . . .	30
4.2.9	BBS.embed.i2c.MCP23017 . . . . .	31
4.2.10	BBS.embed.i2c.PCA9685 . . . . .	34
4.2.11	BBS.embed.SPI.RA8875 . . . . .	36

---

<b>5</b>	<b>Linux API Description</b>	<b>54</b>
5.1	Common . . . . .	54
5.2	Raspberry Pi . . . . .	54
5.3	BeagleBone Black . . . . .	54
<b>6</b>	<b>Arduino Due API Description</b>	<b>55</b>
<b>7</b>	<b>Other Stuff</b>	<b>56</b>
	<b>Bibliography</b>	<b>57</b>

# List of Tables

4.1	Constants for ADS1015 Mux Mode Configuration . . . . .	12
4.2	Constants for ADS1015 Programmable Gain Amplifier Configuration . . . . .	12
4.3	Constants for ADS1015 Data Rate Configuration . . . . .	13
4.4	Constants for ADS1015 Comparator Queue Configuration . . . . .	13
4.5	Constants for ADS1015 Miscellaneous Configuration . . . . .	13
4.6	Constants for BMP180 Conversion Kinds . . . . .	18
4.7	Constants for L3GD20H Full-Scale Deflection . . . . .	20
4.8	Constants for L3GD20H Status . . . . .	21
4.9	Constants for LSM303DLHC Full-Scale Accelerometer . . . . .	24
4.10	Constants for LSM303DLHC Accelerometer Status . . . . .	24
4.11	Constants for LSM303DLHC Full-Scale Magnetometer . . . . .	24
4.12	Constants for LSM303DLHC Magnetometer Status . . . . .	24
4.13	Constants for MCP4725 Commands . . . . .	29
4.14	Constants for MCP4725 Power-Down Modes . . . . .	30
4.15	Measured Values for PCA9685 Controlling Servos . . . . .	34



# Chapter 1

## Introduction

### 1.1 About the Project

This project provides an interface to hardware available on some Linux based systems and the Arduino Due. It consists of two main components: First an abstract set of classes for certain generic hardware items, and second specific classes to interface with the hardware on specific devices. This separation is done to ease porting of software between different devices. The two Linux based devices that are currently supported are the Raspberry Pi and the BeagleBone Black. Other devices may be added by creating a set of specific classes for the device.

### 1.2 License

This project is licensed using the GNU General Public License V3.0. Should you wish other licensing terms, contact the author.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

# Chapter 2

## How to Obtain

This collection is currently available on GitHub at <https://github.com/BrentSeidel/BBS-BBB-Ada>. Parts are available through alire via “`alr get bbs_embed_common`” and “`alr get bbs_embed_linux`”

### 2.1 Dependencies

#### 2.1.1 bbs\_embed\_common

##### Ada Libraries

The following Ada packages are used:

- `Ada.Integer_Text_IO`
- `Ada.Numerics.Generic_Elementary_Functions` (used only by `lsm303dlhc`)
- `Ada.Real_Time`
- `Ada.Text_IO`
- `Ada.Unchecked_Conversion`

##### Other Libraries

This library depends on the root package BBS available at <https://github.com/BrentSeidel/BBS-Ada> and through alire via “`alr get bbs`”. Packages external to this library are marked with an asterisk.

- `BBS.embed.GPIO`
- `BBS.embed.i2c`
- `BBS.embed.log`
- `BBS.embed.SPI`
- `BBS.units*`



### 2.1.2 bbs\_embed\_linux

#### Ada Libraries

The following Ada packages are used:

- Ada.Direct\_IO
- Ada.IO\_Exceptions
- Ada.Long\_Integer\_Text\_IO
- Ada.Strings.Fixed
- Ada.Text\_IO
- Interfaces.C

#### Other Libraries

This library depends on the root package BBS available at <https://github.com/BrentSeidel/BBS-Ada> and through alire via “`alr get bbs`”. Packages external to this library are marked with an asterisk.

- BBS.embed\*
- BBS.embed.BBB\*
- BBS.embed.GPIO\*
- BBS.embed.log\*
- BBS.embed.SPI\*
- BBS.units\*

### 2.1.3 bbs\_embed\_due

The Arduino Due requires an appropriate run-time system and cross-compiler.

#### Ada Libraries

The following Ada packages are used:

- Ada.Interrupts
- Ada.Interrupts.Names
- Ada.Real\_Time
- Ada.Synchronous\_Task\_Control
- Interfaces
- System
- System.Sam3x8

### **SAM3x8e Stuff**

The following SAM3x8e hardware definition packages are used:

- SAM3x8e
- SAM3x8e.ADC
- SAM3x8e.PIO
- SAM3x8e.PMC
- SAM3x8e.TWI
- SAM3x8e.UART

### **Other Libraries**

This library depends on the root package BBS available at <https://github.com/BrentSeidel/BBS-Ada> and through alire via “`alr get bbs`”. Packages external to this library are marked with an asterisk.

- BBS\*
- BBS.embed\*
- BBS.embed.due.dev
- BBS.embed.due.serial.int
- BBS.embed.due.serial.polled
- BBS.embed.GPIO.Due
- BBS.embed.log\*
- BBS.embed.SPI\*

## Chapter 3

# Usage Instructions

This chapter contains high-level instructions on using this library in your project. First, all projects will need to include the `bbs_embed_common` packages to gain access to the base classes and some device drivers that build on these base classes. The second step is platform specific, as described below.

### 3.1 Linux Based Raspberry Pi and BeagleBone Black

You will need to include the `bbs_embed_linux` packages in your project. The `BBS.embed.rpi` package contains constants for various device names available on the Raspberry Pi. The `BBS.embed.BBB` package contains constants for various devices names on the BeagleBone Black. There is a script, `init-bbb.sh` for the BeagleBone Black or `init-rpi.sh` for the Raspberry Pi that needs to be run to activate some of the devices and set protections on the device files. The script will need to be run as superuser, using the `sudo` command. Among other things, it sets protection on the device files so that your software does not need to run as superuser.

### 3.2 Arduino Due

This has not been worked on for a while. To use this, you will need an ARM ELF Ada compiler and a board support package for the Arduino Due. It did work with a board support package that I'd cobbled together a few generations of gnat ago. Consider this to be experimental, but it should provide a good start to accessing hardware on the Arduino Due.

## Chapter 4

# Common API Description

Dealing with hardware can be complex, especially if you want your software to be portable. The various different boards have different devices (or different numbers of devices) available. Sometimes options are available on one board that are not available on another.

The common library (`bbs_embed_common` in `alire`) contains base classes for hardware devices and higher-level drivers for devices that attach to the basic hardware, for example devices that connect via an I2C bus.

### 4.1 Basic Devices

The package `BBS.embed` defines the following types and functions:

```
type addr7 is mod 2**7
  with size => 7;
type int12 is range -(2**11) .. 2**11 - 1
  with size => 12;
type uint12 is mod 2**12
  with size => 12;
```

The `addr7` is used for addressing devices on an I2C bus. the `int12` and `uint12` are used for the return values from typical analog to digital converters and anywhere else a 12 bit number is needed.

```
function uint12_to_int12 is
  new Ada.Unchecked_Conversion(source => uint12, target => int12);
```

This is used to convert from unsigned to signed 12 bit integers. Should the reverse conversion be needed, it would be easy enough to add it here.

```
function highByte(x : uint16) return uint8 is
  (uint8(x / 2**8));
function lowByte(x : uint16) return uint8 is
  (uint8(x and 16#FF#));
```

These are used to extract the MSB and LST from `uint16` values.

### 4.1.1 Analog Inputs

Analog inputs have one common routine to read the value. Everything else is implementation dependent.

```
function get(self : AIN_record) return uint12 is abstract;
```

Read the value of the specified analog to digital converter.

- *self* - The object for the analog input device.
- Returns the 12-bit value from the analog to digital converter.

### 4.1.2 General-Purpose Input/Output (GPIO)

A GPIO is a device capable of reading or writing a single bit. The physical characteristics are hardware dependent. Some device specific routines may be needed to convert between input and output.

```
procedure set(self : GPIO_record; value : bit) is abstract;
```

Sets the output value of a GPIO device. The effect if the device is set to input is device specific.

- *self* - The object for the GPIO device.
- *value* - The value to write to the GPIO device.

```
function get(self : GPIO_record) return bit is abstract;
```

Reads the value of a GPIO device. The value returned if the device is set to output is device specific.

- *self* - The object for the GPIO device.
- Returns the value read from the GPIO device.

### 4.1.3 I2C Bus

An I2C bus can interface with a number of devices on the bus. It operates with the CPU being the master and the addressed device responding. The basic I2C bus uses 7 bit addressing for devices and operates at 100kHz. Any other options (10 bit addressing or higher speeds would be device specific, if supported).

The `BBS.embed.i2c` defines some datatypes. The ones for external use are:

- `err_code` is an enumeration of error statuses that can be returned. The possible values are `none`, `nack`, `ovre`, `invalid_addr`, and `failed`. In most cases you'll just want to compare the returned error to `none`.
- `buff_index` is an `Integer` index into a buffer with a range of 0 .. 127.
- `buffer` is an array of `uint8` and bounds of `buff_index`. It is used for buffering data for I2C bus transfers.

The following routines are used for communicating with devices on the I2C bus. Note that there is no standard about whether multibyte data should be transferred LSB first or MSB first (I've even seen devices that use both depending on which data you're getting). Routines are provided for MSB first (m1 routines) or MSB second (m2 routines) for 16 bit transfers. For longer transfers, use the block transfer routines and decode the data yourself. The 8 and 16 bit routines cover most of the cases.

```
function read(self : in out i2c_interface_record; addr : addr7; reg : uint8;
              error : out err_code) return uint8 is (0);
```

Read a single byte of data from the specified register in the specified device.

- *self* - The I2C interface device to use for communication.
- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *error* - The error code from the transaction.
- Returns the register contents.

```
function readm1(self : in out i2c_interface_record; addr : addr7; reg : uint8;
                error : out err_code) return uint16 is (0);
```

Read two bytes of data with MSB transferred first from the specified register in the specified device.

- *self* - The I2C interface device to use for communication.
- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *error* - The error code from the transaction.
- Returns the register contents.

```
function readm2(self : in out i2c_interface_record; addr : addr7; reg : uint8;
                error : out err_code) return uint16 is (0);
```

Read two bytes of data with MSB transferred second from the specified register in the specified device.

- *self* - The I2C interface device to use for communication.
- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *error* - The error code from the transaction.
- Returns the register contents.

```
procedure read(self : in out i2c_interface_record; addr : addr7; reg : uint8;
               size : buff_index; error : out err_code) is null;
```

Reads a block of data into the interface record's buffer. The user's code will need to extract the data from that buffer and process it as needed.

- *self* - The I2C interface device to use for communication.
- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *size* - The number of bytes to transfer.
- *error* - The error code from the transaction.

```
procedure write(self : in out i2c_interface_record; addr : addr7; reg : uint8;
                data : uint8; error : out err_code) is null;
```

Write a single byte of data to the specified register in the specified device.

- *self* - The I2C interface device to use for communication.
- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *data* - The data to write.
- *error* - The error code from the transaction.

```
procedure writem1(self : in out i2c_interface_record; addr : addr7; reg : uint8;
                  data : uint16; error : out err_code) is null;
```

Writes two bytes of data with the MSB transferred first to the specified register in the specified device.

- *self* - The I2C interface device to use for communication.
- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *data* - The data to write.
- *error* - The error code from the transaction.

```
procedure writem2(self : in out i2c_interface_record; addr : addr7; reg : uint8;
                  data : uint16; error : out err_code) is null;
```

Writes two bytes of data with the MSB transferred second to the specified register in the specified device.

- *self* - The I2C interface device to use for communication.

- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *data* - The data to write.
- *error* - The error code from the transaction.

```
procedure write(self : in out i2c_interface_record; addr : addr7; reg : uint8;  
               size : buff_index; error : out err_code) is null;
```

Send the specified number of bytes in the interface record's buffer to the specified device and register.

- *self* - The I2C interface device to use for communication.
- *addr7* - The 7 bit address of the device to communicate with.
- *reg* - The register address in the device.
- *size* - The number of bytes to transfer.
- *error* - The error code from the transaction.

In most cases these routines should only be used when writing a driver for an I2C device.

#### 4.1.4 Logging

This is only for debugging purposes. Should say something here briefly.

#### 4.1.5 SPI Bus

The exposed interface for the SPI bus is much simpler than for the I2C bus. If needed, more routines may be added here, but this hasn't been developed as much as the I2C bus interface.

```
procedure set(self : SPI_record; value : uint8) is abstract;
```

Writes a byte to the SPI bus.

- *self* - The SPI interface device to use for communication.
- *data* - The data to write.

```
function get(self : SPI_record) return uint8 is abstract;
```

Reads a byte from the SPI bus.

- *self* - The SPI interface device to use for communication.
- Returns the byte read from the bus.



## 4.2 Higher-Level Device Drivers

These higher-level device drivers build on the lower-level devices. Typically these are devices that attach to a databus.

### 4.2.1 BBS.embed.gpio.tb6612

This is a driver for the Toshiba TB6612 dual DC motor controller [11]. The device driver is designed to sequence the output to drive a stepper motor, or it can control two DC motors separately. It requires four GPIO output pins.

```
procedure init(self : in out TB6612_record; pin_a : BBS.embed.GPIO.GPIO;  
               pin_b : BBS.embed.GPIO.GPIO; pin_c : BBS.embed.GPIO.GPIO;  
               pin_d : BBS.embed.GPIO.GPIO);
```

Initialize the TB6612 driver with the 4 GPIO devices.

- *self* - The TB6612 device to initialize.
- *pin\_a* - The first GPIO pin.
- *pin\_b* - The second GPIO pin.
- *pin\_c* - The third GPIO pin.
- *pin\_d* - The fourth GPIO pin.

```
procedure set_delay(self : in out TB6612_record; wait_time : Natural);
```

Set a time delay between steps to use when stepping the motor a number of steps. If not needed, it can be set to zero.

- *self* - The TB6612 device to modify.
- *wait\_time* - The time delay between steps in mS.

```
procedure step(self : in out TB6612_record; steps : Integer);
```

Move the stepper motor a specified number of steps. A negative number will move in the opposite direction as a positive number. Zero steps will do nothing. If no delay has been specified, a default of 5mS between steps will be used.

- *self* - The TB6612 device to modify.
- *steps* - The number of steps to move the motor.

```
procedure stepper_off(self : in out TB6612_record);
```

De-energize the coils for a stepper motor (or both DC motors).

- *self* - The TB6612 device to modify.

```
procedure set_bridge_a(self : in out TB6612_record; value : Integer);
procedure set_bridge_b(self : in out TB6612_record; value : Integer);
```

Each of the two H-bridges can be controlled separately. This would allow two DC motors to be driven.

- *self* - The TB6612 device to modify.
- *value* - A value of zero sets the bridge off. A positive value sets the polarity in one direction. A negative value sets the polarity in the opposite direction.

Note that polarities are not specified as they depend on how the hardware is wired.

#### 4.2.2 BBS.embed.I2C.ADS1015

This is a driver for the Texas Instruments ADS1015 4 channel analog to digital convertor that attaches to an I2C bus [3]. This converter has a wide variety of configuration options. Refer to the datasheet for details. A number of constants have been defined to support the various configuration options (see Tables 4.1, 4.2, 4.3, and 4.4).

Constant	Mux Mode Configuration
<i>mux_a0_a1</i>	Difference between AIN0 and AIN1 (default)
<i>mux_a0_a3</i>	Difference between AIN0 and AIN3
<i>mux_a1_a3</i>	Difference between AIN1 and AIN3
<i>mux_a2_a3</i>	Difference between AIN2 and AIN3
<i>mux_a0_gnd</i>	Single ended AIN0 value
<i>mux_a1_gnd</i>	Single ended AIN1 value
<i>mux_a2_gnd</i>	Single ended AIN2 value
<i>mux_a3_gnd</i>	Single ended AIN3 value

Table 4.1: Constants for ADS1015 Mux Mode Configuration

Constant	PGA Configuration
<i>pga_6_144</i>	Full scale voltage is 6.144V
<i>pga_4_096</i>	Full scale voltage is 4.096V
<i>pga_2_048</i>	Full scale voltage is 2.048V (default)
<i>pga_1_024</i>	Full scale voltage is 1.024V
<i>pga_0_512</i>	Full scale voltage is 0.512V
<i>pga_0_256</i>	Full scale voltage is 0.256V

Table 4.2: Constants for ADS1015 Programmable Gain Amplifier Configuration

There are some additional configuration parameters that don't have constants defined. These just have values of 0 or 1. See Table 4.5.

The datatype `ADS1015_config` is defined as a record containing the configuration values. It has the following fields:

Constant	Data Rate in Samples per Second (S/S)
<i>dr_0128</i>	Data rate is 128S/S
<i>dr_0250</i>	Data rate is 250S/S
<i>dr_0490</i>	Data rate is 490S/S
<i>dr_0920</i>	Data rate is 920S/S
<i>dr_1600</i>	Data rate is 1600S/S (default)
<i>dr_2400</i>	Data rate is 2400S/S
<i>dr_3300</i>	Data rate is 3300S/S

Table 4.3: Constants for ADS1015 Data Rate Configuration

Constant	Comparator Queue Configuration
<i>comp_que_1</i>	Assert after one conversion
<i>comp_que_2</i>	Assert after two conversions
<i>comp_que_3</i>	Assert after three conversion
<i>comp_que_d</i>	Disable comparator (default)

Table 4.4: Constants for ADS1015 Comparator Queue Configuration

Value	Conversion Mode
0	Continuous conversion mode
1	Power-down single-shot mode (default)
Value	Comparator Mode
0	Traditional, with hysteresis (default)
1	Window comparator
Value	Comparator Polarity
0	Active low (default)
1	Active high
Value	Comparator Latching
0	Non-latching comparator (default)
1	Latching comparator

Table 4.5: Constants for ADS1015 Miscellaneous Configuration

- **os** - Operational status, used to start a conversion if in single shot mode. Don't use when setting configuration.
- **mux** - The mux mode (see Table 4.1).
- **pga** - The programmable gain type (see Table 4.2).
- **mode** - Conversion mode (see Table 4.5).
- **dr** - The data rate (see Table 4.3).
- **comp\_mode** - The comparator mode (see Table 4.5).

- `comp_pol` - The comparator polarity (see Table 4.5).
- `comp_lat` - The comparator latching (see Table 4.5).
- `comp_que` - The comparator queue configuration (see Table 4.4).

```
procedure configure(self : in out ADS1015_record; port : i2c_interface;  
                  addr : addr7; error : out err_code);
```

Initializes the device to the default configuration.

- *self* - The device to initialize.
- *port* - The I2C interface that the device is connected to.
- *addr* - The I2C address of the device.
- *error* - The I2C error code.

```
procedure configure(self : in out ADS1015_record; port : i2c_interface;  
                  addr : addr7; config : ADS1015_config; error : out err_code);
```

Initialize the device using the specified configuration.

- *self* - The device to initialize.
- *port* - The I2C interface that the device is connected to.
- *addr* - The I2C address of the device.
- *config* - A configuration record containing the desired configuration
- *error* - The I2C error code.

```
procedure change_config(self : in out ADS1015_record;  
                      config : ADS1015_config; error : out err_code);
```

Changes the device configuration to new values

- *self* - The device to modify.
- *config* - A configuration record containing the desired configuration
- *error* - The I2C error code.

```
procedure set_mux(self : in out ADS1015_record;  
                 mux : mux_mode_type; error : out err_code);
```

Changes only the mux mode configuration.

- *self* - The device to modify.
- *mux* - The new mux mode configuration value.

- *error* - The I2C error code.

```
procedure set_gain(self : in out ADS1015_record;  
                  gain : pga_type; error : out err_code);
```

Changes only the converter gain value.

- *self* - The device to modify.
- *gain* - The new gain value.
- *error* - The I2C error code.

```
procedure set_continuous(self : in out ADS1015_record; error : out err_code);
```

Sets the converter to operate in continuous mode.

- *self* - The device to modify.
- *error* - The I2C error code.

```
procedure set_1shot(self : in out ADS1015_record; error : out err_code);
```

Sets the converter to operate in single shot mode.

- *self* - The device to modify.
- *error* - The I2C error code.

```
procedure start_conversion(self : in out ADS1015_record; error : out err_code);
```

Start a conversion when in single shot mode. No effect in continuous mode.

- *self* - The device to modify.
- *error* - The I2C error code.

```
function conversion_done(self : in out ADS1015_record; error : out err_code)  
    return Boolean;
```

Checks if conversion is in progress. Will always return *False* (conversion in progress) while in continuous mode. Returns *True* when no conversion is in progress.

- *self* - The device to initialize.
- *error* - The I2C error code.
- Returns a conversion in progress flag.

```
function get_result(self : in out ADS1015_record; error : out err_code)  
    return uint12;
```

Returns the conversion value.

- *self* - The device to initialize.
- *error* - The I2C error code.
- Returns the conversion value

### 4.2.3 BBS.embed.i2c.BME280

This is a driver for the Bosch BME280 temperature, pressure, and humidity sensor that attaches to an I2C bus [2]. A number of constants are defined, but most of them are intended only for internal use. The constant *addr* is the I2C address of the BME280 sensor and is intended for use in the *configure* call.

```
procedure configure(self : in out BME280_record; port : i2c_interface;  
                  addr : addr7; error : out err_code);
```

Called to configure a BME280 device. This needs to be called before the device can be used.

- *self* - The BME280 device to configure.
- *port* - The I2C bus object that the BME280 is connected to.
- *addr* - The I2C address of the device.
- *error* - The error code from any I2C transactions.

```
procedure start_conversion(self : BME280_record; error : out err_code);
```

Instruct the BME280 to start converting temperature, pressure, and humidity readings. These are converted at the same time.

- *self* - The BME280 device to instruct.
- *error* - The error code from any I2C transactions.

```
function data_ready(self : BME280_record; error : out err_code) return boolean;
```

Checks to see if conversion is complete. The user software should wait until conversion is complete before attempting to read otherwise the results will be undefined.

- *self* - The BME280 device to instruct.
- *error* - The error code from any I2C transactions.
- Returns *True* if the conversion is complete and *False* otherwise.

```
procedure read_data(self : in out BME280_record; error : out err_code);
```

Instructs the BME280 to read the converted temperature, pressure, and humidity values into BME280 object and compute calibrated values. There is less overhead to read all three at once.

- *self* - The BME280 device to instruct.
- *error* - The error code from any I2C transactions.

```
procedure get_raw(self : BME280_record; raw_temp : out uint32;  
                raw_press : out uint32; raw_hum : out uint32);
```

Return the raw, uncompensated values after *read\_data()* has been called. This is primarily for debugging purposes.

- *self* - The BME280 device to instruct.
- *raw\_temp* - The raw temperature value.
- *raw\_press* - The raw pressure value.
- *raw\_hum* - The raw humidity value.

```
function get_t_fine(self : BME280_record) return int32;
```

Returns the `t_fine` value after `read_data()` has been called. This is primarily for debugging purposes.

- *self* - The BME280 device to instruct.
- Returns the `t_fine` value.

```
function get_temp(self : BME280_record) return integer;
```

Returns the calibrated temperature value as an **Integer**. The LSB unit is 0.01°C.

- *self* - The BME280 device to instruct.
- Returns the temperature in units of 0.01°C.

```
function get_temp(self : BME280_record) return BBS.units.temp_c;
```

```
function get_temp(self : BME280_record) return BBS.units.temp_f;
```

```
function get_temp(self : BME280_record) return BBS.units.temp_k;
```

Returns the temperature in units of °C, °F, or K, depending on datatype of the destination.

- *self* - The BME280 device to instruct.
- Returns the temperature in units of °C, °F, or K.

```
function get_press(self : BME280_record) return integer;
```

Returns the calibrated pressure value as an **Integer**. The LSB unit is  $\frac{1}{256}$ Pa.

- *self* - The BME280 device to instruct.
- Returns the pressure in units of  $\frac{1}{256}$ Pa.

```
function get_press(self : BME280_record) return BBS.units.press_p;
```

```
function get_press(self : BME280_record) return BBS.units.press_mb;
```

```
function get_press(self : BME280_record) return BBS.units.press_atm;
```

```
function get_press(self : BME280_record) return BBS.units.press_inHg;
```

Returns that pressure in units of Pa, mB, Atm, or inHg, depending on the datatype of the destination.

- *self* - The BME280 device to instruct.

- Returns the pressure in units of Pa, mB, Atm, or inHg.

```
function get_hum(self : BME280_record) return integer;
```

Returns the calibrated relative humidity as an **Integer**. The LSB unit is  $\frac{1}{1024}\%$  humidity.

- *self* - The BME280 device to instruct.
- Returns the humidity in units of  $\frac{1}{1024}\%$  humidity.

```
function get_hum(self : BME280_record) return float;
```

Returns the relative humidity as a percentage relative humidity.

- *self* - The BME280 device to instruct.
- Returns the humidity as a percentage relative humidity.

#### 4.2.4 BBS.embed.i2c.BMP180

This is a driver for the Bosch BMP180 temperature and pressure sensor that attaches to an I2C bus [1]. It has been discontinued by Bosch and is not recommended for new projects. A number of constants are defined, but most of them are intended only for internal use. The constant *addr* is the I2C address of the BMP180 sensor and is intended for use in the **configure** call.

Constant	Conversion Kind
<i>cvt_temp</i>	Convert Temperature
<i>cvt_press0</i>	Convert pressure with no oversampling
<i>cvt_press1</i>	Convert pressure with oversampling of two
<i>cvt_press2</i>	Convert pressure with oversampling of four
<i>cvt_press3</i>	Convert pressure with oversampling of eight

Table 4.6: Constants for BMP180 Conversion Kinds

```
procedure configure(self : in out BMP180_record; port : i2c_interface;
    addr : addr7; error : out err_code);
```

Called to configure a BMP180 device. This needs to be called before the device can be used.

- *self* - The BMP180 device to configure.
- *port* - The I2C bus object that the BMP180 is connected to.
- *addr* - The I2C address of the device.
- *error* - The error code from any I2C transactions.

```
procedure start_conversion(self : in out BMP180_record;
    kind : uint8; error : out err_code);
```

Instruct the BMP180 to start converting temperature or pressure.



- *self* - The BMP180 device to instruct.
- *kind* - The kind of conversion to start. See Table 4.6 for options.
- *error* - The error code from any I2C transactions.

```
function data_ready(self : BMP180_record; error : out err_code)
    return boolean;
```

Checks to see if conversion is complete. The user software should wait until conversion is complete before attempting to read otherwise the results will be undefined.

- *self* - The BMP180 device to instruct.
- *error* - The error code from any I2C transactions.
- Returns *True* if the conversion is complete and *False* otherwise.

```
function get_temp(self : in out BMP180_record; error : out err_code)
    return float;
```

Returns the calibrated temperature value as a **Float** in °C.

- *self* - The BMP180 device to instruct.
- *error* - The error code from any I2C transactions.
- Returns the temperature as a **Float** in °C.

```
function get_temp(self : in out BMP180_record; error : out err_code)
    return integer;
```

Returns the calibrated temperature value as an **Integer**. The LSB unit is 0.1°C.

- *self* - The BMP180 device to instruct.
- *error* - The error code from any I2C transactions.
- Returns the temperature in units of 0.1°C.

```
function get_temp(self : in out BMP180_record; error : out err_code)
    return BBS.units.temp_c;
function get_temp(self : in out BMP180_record; error : out err_code)
    return BBS.units.temp_f;
function get_temp(self : in out BMP180_record; error : out err_code)
    return BBS.units.temp_k;
```

Returns the temperature in units of °C, °F, or K, depending on datatype of the destination.

- *self* - The BMP180 device to instruct.
- *error* - The error code from any I2C transactions.

- Returns the temperature in units of °C, °F, or K.

```
function get_press(self : BMP180_record; error : out err_code)
    return integer;
```

Returns the calibrated pressure value as an **Integer**. The LSB unit is 1Pa.

- *self* - The BMP180 device to instruct.
- *error* - The error code from any I2C transactions.
- Returns the temperature in units of 0.1°C.

```
function get_press(self : BMP180_record; error : out err_code)
    return BBS.units.press_p;
function get_press(self : BMP180_record; error : out err_code)
    return BBS.units.press_mb;
function get_press(self : BMP180_record; error : out err_code)
    return BBS.units.press_atm;
function get_press(self : BMP180_record; error : out err_code)
    return BBS.units.press_inHg;
```

Returns that pressure in units of Pa, mB, Atm, or inHg, depending on the datatype of the destination.

- *self* - The BMP180 device to instruct.
- *error* - The error code from any I2C transactions.
- Returns the pressure in units of Pa, mB, Atm, or inHg.

#### 4.2.5 BBS.embed.i2c.L3GD20H

This is a driver for the STMicrosystems L3GD20H three-axis digital output gyroscope [9]. This device has a number of operating modes that have not been implemented in this driver. A number of constants are defined, but most of them are intended only for internal use. The constant *addr* is the I2C address of the L3GD20H sensor and is intended for use in the **configure** call.

Constant	Full-Scale Deflection
<i>fs_245dps</i>	Full scale is 245°/S (default)
<i>fs_500dps</i>	Full scale is 500°/S
<i>fs_2000dps</i>	Full scale is 2000°/S

Table 4.7: Constants for L3GD20H Full-Scale Deflection

Two utility datatypes are defined for holding rotations. The first, **rotations** is a record with **x**, **y**, and **z** components all of **Integer** type holding the raw rotation values from the sensor. The second, **rotations\_dps** is similar, but the components are all of type **BBS.units.rot\_d\_s** for rotation in degrees per second.

Constant	Status
<i>zyx_or</i>	X,Y,Z axis data overrun - New data has overwritten previous data before it was read
<i>z_or</i>	Z axis data overrun - New data has overwritten previous data before it was read
<i>y_or</i>	Y axis data overrun - New data has overwritten previous data before it was read
<i>x_or</i>	X axis data overrun - New data has overwritten previous data before it was read
<i>zyxda</i>	X,Y,Z axis new data available
<i>zda</i>	Z axis new data available
<i>yda</i>	Y axis new data available
<i>xda</i>	X axis new data available

Table 4.8: Constants for L3GD20H Status

```
procedure configure(self : in out L3GD20H_record; port : i2c_interface;
                  addr : addr7; error : out err_code);
```

Called to configure the L3GD20H device. This must be done before using the device.

- *self* - The L3GD20H device to configure.
- *port* - The I2C bus object that the L3GD20H is connected to.
- *addr* - The I2C address of the device.
- *error* - The error code from any I2C transactions.

```
procedure configure(self : in out L3GD20H_record; port : i2c_interface;
                  addr : addr7; deflection : uint8; error : out err_code);
```

Called to configure the L3GD20H device. This must be done before using the device.

- *self* - The L3GD20H device to configure.
- *port* - The I2C bus object that the L3GD20H is connected to.
- *addr* - The I2C address of the device.
- *deflection* - Set the full-scale deflection (See constants in Table 4.7).
- *error* - The error code from any I2C transactions.

```
function get_temperature(self : L3GD20H_record; error : out err_code)
  return integer;
```

Return the device temperature in °C.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns an **Integer** representing the temperature in °C.

```
function get_rotation_x(self : L3GD20H_record; error : out err_code)
    return integer;
function get_rotation_y(self : L3GD20H_record; error : out err_code)
    return integer;
function get_rotation_z(self : L3GD20H_record; error : out err_code)
    return integer;
```

Return the rotation around the specified axis, *x*, *y*, or *z* as an **Integer** containing the raw sensor value.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns an **Integer** representing the rotation around the specified axis.

```
function get_rotations(self : L3GD20H_record; error : out err_code)
    return rotations;
```

Return a **rotations** record containing the raw sensor values for the rotations around each of the axis.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns a **rotations** record containing the rotations around all axis.

```
function get_temperature(self : L3GD20H_record; error : out err_code)
    return BBS.units.temp_c;
```

Return the device temperature in °C.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns a **BBS.units.temp\_c** representing the temperature in °C.

```
function get_rotation_x(self : L3GD20H_record; error : out err_code)
    return BBS.units.rot_d_s;
function get_rotation_y(self : L3GD20H_record; error : out err_code)
    return BBS.units.rot_d_s;
function get_rotation_z(self : L3GD20H_record; error : out err_code)
    return BBS.units.rot_d_s;
```

Return the rotation around the specified axis, *x*, *y*, or *z* as a **rotations\_dps** containing the rotation in °/S.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.

- Returns a `rotations_dps` representing the rotation around the specified axis.

```
function get_rotations(self : L3GD20H_record; error : out err_code)
    return rotations_dps;
```

Return a `otations_dps` record containing the rotation in °/S around each of the axis.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns a `rotations_dps` record containing the rotations around all axis.

```
function get_status(self : L3GD20H_record; error : out err_code)
    return uint8;
```

Return the device status. The constants in Table 4.8 can be used to decode the status.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns an `uint8` representing the device status.

```
function data_ready(self : L3GD20H_record; error : out err_code)
    return boolean;
```

Checks if the sensor has data ready.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns *True* if data is ready.

```
function measure_offsets(self : in out L3GD20H_record) return boolean;
```

When stationary, the sensors may not report 0. This function should be called when the sensor is stationary. It reads the rotations several times and averages the results. This is used to calculate offset values. The offset values are used when returning the rotations in `rotations_dps`.

This function returns *True* if the measurement was successful - that is all of the values measured are reasonably close to the mean. If it returns false, the sensor may be moving.

- *self* - The L3GD20H device to read.
- *error* - The error code from any I2C transactions.
- Returns *True* if the offset measurement was successful.

Constant	Full-Scale Deflection
<i>fs_2g</i>	Full scale is 2G (default)
<i>fs_4g</i>	Full scale is 4G
<i>fs_8g</i>	Full scale is 8G
<i>fs_16gs</i>	Full scale is 16G

Table 4.9: Constants for LSM303DLHC Full-Scale Accelerometer

Constant	Status
<i>accel_stat_zyxor</i>	X,Y,Z axis data overrun - New data has overwritten previous data before it was read
<i>accel_stat_zor</i>	Z axis data overrun - New data has overwritten previous data before it was read
<i>accel_stat_yor</i>	Y axis data overrun - New data has overwritten previous data before it was read
<i>accel_stat_xorr</i>	X axis data overrun - New data has overwritten previous data before it was read
<i>accel_stat_zyxda</i>	X,Y,Z axis new data available
<i>accel_stat_zda</i>	Z axis new data available
<i>accel_stat_yda</i>	Y axis new data available
<i>accel_stat_xda</i>	X axis new data available

Table 4.10: Constants for LSM303DLHC Accelerometer Status

Constant	Full-Scale Deflection
<i>fa_1.3_gauss</i>	Full scale is 1.3 gauss
<i>fs_1.9_gauss</i>	Full scale is 1.9 gauss
<i>fs_2.5_gauss</i>	Full scale is 2.5 gauss
<i>fs_4.0_gauss</i>	Full scale is 4.0 gauss
<i>fs_4.7_gauss</i>	Full scale is 4.7 gauss
<i>fs_5.6_gauss</i>	Full scale is 5.6 gauss
<i>fs_8.1_gauss</i>	Full scale is 8.1 gauss

Table 4.11: Constants for LSM303DLHC Full-Scale Magnetometer

Constant	Status
<i>mag_lock</i>	Data output register lock.
<i>mag_drdy</i>	Data ready

Table 4.12: Constants for LSM303DLHC Magnetometer Status

#### 4.2.6 BBS.embed.i2c.LSM303DLHC

This is a driver for the STMicrosystems LSM303DLHC three-axis digital output gyroscope [10]. This device has a number of operating modes that have not been implemented in this driver. A number of constants are defined, but most of them are intended only for internal use. The constant *addr\_accel* is the I2C address of the LSM303DLHC accelerometer sensor; the constant *addr\_mag* is the I2C address of the magnetometer sensor. They are intended for use in the *configure* call.

Two utility datatypes are defined for holding accelerations. The first, **accelerations** is a record with **x**, **y**, and **z** components all of **Integer** type holding the raw acceleration values from the sensor. The second, **accelerations\_g** is similar, but the components are all of type **BBS.units.accel\_g** for acceleration in units on 1 earth gravity.

Two utility datatypes are defined for holding magnetic fields. The first, **magnetism** is a record with **x**, **y**, and **z** components all of **Integer** type holding the raw magnetometer values from the sensor. The second, **magnetism\_gauss** is similar, but the components are all of type **BBS.units.mag\_g** for magnetism in units on 1 gauss.

```
procedure configure(self : in out LSM303DLHC_record; port : i2c_interface;
                   accel : addr7; mag : addr7; error : out err_code);
```

Called to configure the LSM303DLHC device. This must be done before using the device.

- *self* - The LSM303DLHC device to configure.
- *port* - The I2C bus object that the LSM303DLHC is connected to.
- *accel* - The I2C address of the device accelerometer.
- *mag* - The I2C address of the device magnetometer.
- *error* - The error code from any I2C transactions.

```
procedure configure(self : in out LSM303DLHC_record;
                   port : i2c_interface; addr_accel : addr7; addr_mag : addr7;
                   accel_fs : uint8; mag_fs : uint8; error : out err_code);
```

Called to configure the LSM303DLHC device. This must be done before using the device.

- *self* - The LSM303DLHC device to configure.
- *port* - The I2C bus object that the LSM303DLHC is connected to.
- *addr\_accel* - The I2C address of the device accelerometer.
- *addr\_mag* - The I2C address of the device magnetometer.
- *accel\_fs* - The acceleration full scale value. See Table 4.9.
- *mag\_fs* - The acceleration full scale value. See Table 4.11.
- *error* - The error code from any I2C transactions.

```
procedure calibrate_accel(self : in out LSM303DLHC_record);
```

The calibrate accel procedure can be called when the sensor is stationary in a 1G acceleration or gravitational field. It takes multiple measurements of the X, Y, and Z acceleration and computes the average of  $X^2 + Y^2 + Z^2$ . This value should be 1.0. A more sophisticated approach would be to compute a calibration value for each of the axis separately, but that would require the sensor to be precisely positioned three time.

- *self* - The LSM303DLHC device to calibrate.

```
function get_acceleration_x(self : LSM303DLHC_record; error : out err_code)
    return integer;
function get_acceleration_y(self : LSM303DLHC_record; error : out err_code)
    return integer;
function get_acceleration_z(self : LSM303DLHC_record; error : out err_code)
    return integer;
```

Return the acceleration along the specified axis, *x*, *y*, or *z* as an **Integer** containing the raw sensor value.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an **Integer** representing the acceleration along the specified axis.

```
function get_accelerations(self : LSM303DLHC_record; error : out err_code)
    return accelerations;
```

Return the acceleration along all axis, *x*, *y*, or *z* as an **accelerations** containing the raw sensor value.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an **accelerations** record containing the acceleration along the all axis.

```
function get_acceleration_x(self : LSM303DLHC_record; error : out err_code)
    return BBS.units.accel_g;
function get_acceleration_y(self : LSM303DLHC_record; error : out err_code)
    return BBS.units.accel_g;
function get_acceleration_z(self : LSM303DLHC_record; error : out err_code)
    return BBS.units.accel_g;
```

Return the acceleration along the specified axis, *x*, *y*, or *z* as a **BBS.units.accel\_g** containing the acceleration in units of 1 gravity.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns a **BBS.units.accel\_g** representing the acceleration along the specified axis.

```
function get_accelerations(self : LSM303DLHC_record; error : out err_code)
    return accelerations_g;
```

Return the acceleration along all axis, *x*, *y*, or *z* as an **accelerations\_g** containing the acceleration in units of 1 gravity.

- *self* - The LSM303DLHC device to read.



- *error* - The error code from any I2C transactions.
- Returns an `accelerations_g` record containing the acceleration along the all axis.

```
function get_accel_status(self : LSM303DLHC_record; error : out err_code)
    return uint8;
```

Return the accelerometer status. The constants in Table 4.10 can be used to decode the status.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an `uint8` representing the device status.

```
function accel_data_ready(self : LSM303DLHC_record; error : out err_code)
    return boolean;
```

Checks if the sensor has data ready.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns *True* if data is ready.

```
function get_temperature(self : LSM303DLHC_record; error : out err_code)
    return integer;
```

Return the device temperature as an **Integer** in units of  $\frac{1}{8}^{\circ}\text{C}$ .

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an **Integer** representing the temperature in units of  $\frac{1}{8}^{\circ}\text{C}$ .

```
function get_temperature(self : LSM303DLHC_record; error : out err_code)
    return float;
```

Return the device temperature as a **Float** in units of  $1^{\circ}\text{C}$ .

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns a **Float** representing the temperature in  $^{\circ}\text{C}$ .

```
function get_temperature(self : LSM303DLHC_record; error : out err_code)
    return BBS.units.temp_c;
```

Return the device temperature in  $^{\circ}\text{C}$ .

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns a `BBS.units.temp_c` representing the temperature in °C.

```
function get_magnet_x(self : LSM303DLHC_record; error : out err_code)
    return integer;
function get_magnet_y(self : LSM303DLHC_record; error : out err_code)
    return integer;
function get_magnet_z(self : LSM303DLHC_record; error : out err_code)
    return integer;
```

Return the magnetic field along the specified axis, *x*, *y*, or *z* as an **Integer** containing the raw sensor value.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an **Integer** representing the magnetic field along the specified axis.

```
function get_magnetism(self : LSM303DLHC_record; error : out err_code)
    return magnetism;
```

Return the magnetic field along all axis, *x*, *y*, or *z* as an **magnetism** containing the raw sensor value.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an **magnetism** record containing the magnetic field along the all axis.

```
function get_magnet_x(self : LSM303DLHC_record; error : out err_code)
    return BBS.units.mag_g;
function get_magnet_y(self : LSM303DLHC_record; error : out err_code)
    return BBS.units.mag_g;
function get_magnet_z(self : LSM303DLHC_record; error : out err_code)
    return BBS.units.mag_g;
```

Return the magnetic field along the specified axis, *x*, *y*, or *z* as a `BBS.units.mag_g` in units of gauss.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an `BBS.units.mag_g` representing the magnetic field along the specified axis in units of gauss.

```
function get_magnetism(self : LSM303DLHC_record; error : out err_code)
    return magnetism_gauss;
```

Return the magnetic field along all axis,  $x$ ,  $y$ , or  $z$  as an `magnetism_gauss` in units of gauss.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an `magnetism_gauss` record containing the magnetic field along the all axis.

```
function get_mag_status(self : LSM303DLHC_record; error : out err_code)
    return uint8;
```

Return the magnetometer status. The constants in Table 4.12 can be used to decode the status.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns an `uint8` representing the device status.

```
function mag_data_ready(self : LSM303DLHC_record; error : out err_code)
    return boolean;
```

Checks if the sensor has data ready.

- *self* - The LSM303DLHC device to read.
- *error* - The error code from any I2C transactions.
- Returns *True* if data is ready.

#### 4.2.7 BBS.embed.i2c.MCP4725

This is a driver for the Microchip MCP4725 digital to analog convertor that attaches to an I2C bus [5].

Constant	Command
<i>Fast_Write</i>	Fast write.
<i>Write_CMD</i>	Write CMD.
<i>Write_EEPROM</i>	Write EEPROM.

Table 4.13: Constants for MCP4725 Commands

```
procedure configure(self : in out MCP4725_record; port : i2c_interface;
    addr : addr7; error : out err_code);
```

Called to configure the MCP4725 device. This must be done before using the device.

- *self* - The MCP4725 device to configure.
- *port* - The I2C bus object that the MCP4725 is connected to.

Constant	Power-Down Mode
<i>PD_Normal</i>	Normal mode.
<i>PD_1k</i>	1k $\Omega$ to groupd.
<i>PD_100k</i>	100k $\Omega$ to ground.
<i>PD_500k</i>	500k $\Omega$ to ground.

Table 4.14: Constants for MCP4725 Power-Down Modes

- *addr* - The I2C address of the device.
- *error* - The error code from any I2C transactions.

```
procedure set(self : in out MCP4725_record; value : uint12;
             err : out err_code);
```

The DAC is only single channel, so this just sets the value using fast write and PD normal mode.

- *self* - The MCP4725 device to set.
- *value* - The output value to use for the DAC.
- *error* - The error code from any I2C transactions.

```
procedure set(self : in out MCP4725_record; cmd : CMD_type; mode : Mode_type;
             value : uint12; err : out err_code);
```

General set command. Use the defined constants for the command and mode. Other values may cause unexpected behavior.

- *self* - The MCP4725 device to set.
- *cmd* - The command to use. See Table 4.13 for available commands.
- *mode* - The power-down mode to use. See Table 4.14 for available modes.
- *value* - The output value to use for the command and mode.
- *error* - The error code from any I2C transactions.

#### 4.2.8 BBS.embed.i2c.MCP23008

This is a driver for the Microchip MCP23008 8-bit I/O port extender[4]. The driver does not support all of the options that the device has. Should more options be needed, the driver can be extended to support them. The device can be configured to be at one of eight different I2C addresses. Constants are defined for each of the possible addresses. They are *addr\_0* through *addr\_7*. Refer to your hardware documentation to determine which address you need.

```
procedure configure(self : in out MCP23008_record; port : i2c_interface;
                  addr : addr7; error : out err_code);
```

Called to configure the MCP23008 device. This must be done before using the device.

- *self* - The MCP23008 device to configure.
- *port* - The I2C bus object that the MCP23008 is connected to.
- *addr* - The I2C address of the device.
- *error* - The error code from any I2C transactions.

```
procedure set_dir(self : MCB23008_record; dir : uint8;  
                 error : out err_code);
```

Set the direction (read(0)/write(1)) for each of the output bits. The direction bits are packed into a `uint8`.

- *self* - The MCP23008 device to configure.
- *dir* - The `uint8` containing the direction bits.
- *error* - The error code from any I2C transactions.

```
procedure set_data(self : MCB23008_record; data : uint8;  
                 error : out err_code);
```

Sets the output bits. Bits are packed into a `uint8`.

- *self* - The MCP23008 device to set.
- *data* - The `uint8` containing the output bits.
- *error* - The error code from any I2C transactions.

```
function read_data(self : MCB23008_record; error : out err_code)  
  return uint8;
```

Read the port. Bits are packed into a `uint8`.

- *self* - The MCP23008 device to set.
- *error* - The error code from any I2C transactions.
- Returns the status if the bits packed into a `uint8`.

#### 4.2.9 BBS.embed.i2c.MCP23017

This is a driver for the Microchip MCP23017 8-bit I/O port extender[6]. The driver does not support all of the options that the device has. Should more options be needed, the driver can be extended to support them. The device can be configured to be at one of eight different I2C addresses. Constants are defined for each of the possible addresses. They are *addr\_0* through *addr\_7*. Refer to your hardware documentation to determine which address you need.

```
procedure configure(self : in out MCP23017_record; port : i2c_interface;  
                 addr : addr7; error : out err_code);
```

Called to configure the MCP23017 device. This must be done before using the device.

- *self* - The MCP23017 device to configure.
- *port* - The I2C bus object that the MCP23017 is connected to.
- *addr* - The I2C address of the device.
- *error* - The error code from any I2C transactions.

```
procedure set_dir(self : MCP23017_record; dir : uint16;  
                 error : out err_code);
```

Set the direction (read(0)/write(1)) for each of the output bits. The direction bits are packed into a `uint16`.

- *self* - The MCP23017 device to configure.
- *dir* - The `uint16` containing the direction bits.
- *error* - The error code from any I2C transactions.

```
function get_dir(self : MCP23017_record;  
                error : out err_code) return uint16;
```

Read the direction (read(0)/write(1)) for each of the output bits. The direction bits are packed into a `uint16`.

- *self* - The MCP23017 device to read.
- *error* - The error code from any I2C transactions.
- Returns the direction bits packed into a `uint16`.

```
procedure set_polarity(self : MCP23017_record; dir : uint16;  
                     error : out err_code);
```

Set the polarity (normal(0)/inverted(1)) for each of the input bits. The direction bits are packed into a `uint16`.

- *self* - The MCP23017 device to configure.
- *dir* - The `uint16` containing the polarity bits.
- *error* - The error code from any I2C transactions.

```
function get_polarity(self : MCP23017_record;  
                    error : out err_code) return uint16;
```

Read the polarity (normal(0)/inverted(1)) for each of the input bits. The direction bits are packed into a `uint16`.

- *self* - The MCP23017 device to read.

- *error* - The error code from any I2C transactions.
- Returns the polarity bits packed into a `uint16`.

```
procedure set_pullup(self : MCP23017_record; dir : uint16;  
                    error : out err_code);
```

Enable/Disable weak pullup resistors (disable(0)/enable(1)) for each of the output bits. The bits are packed into a `uint16`.

- *self* - The MCP23017 device to configure.
- *dir* - The `uint16` containing the pullup bits.
- *error* - The error code from any I2C transactions.

```
function get_pullup(self : MCP23017_record;  
                   error : out err_code) return uint16;
```

Read weak pullup resistors (disable(0)/enable(1)) for each of the output bits. The bits are packed into a `uint16`.

- *self* - The MCP23017 device to read.
- *error* - The error code from any I2C transactions.
- Returns the pullup bits packed into a `uint16`.

```
procedure set_data(self : MCP23017_record; data : uint16;  
                 error : out err_code);
```

Sets the output bits. Bits are packed into a `uint16`.

- *self* - The MCP23017 device to set.
- *data* - The `uint16` containing the output bits.
- *error* - The error code from any I2C transactions.

```
function get_data(self : MCP23017_record; error : out err_code)  
               return uint16;
```

Read the port. Bits are packed into a `uint16`.

- *self* - The MCP23017 device to read.
- *error* - The error code from any I2C transactions.
- Returns the status if the bits packed into a `uint16`.

#### 4.2.10 BBS.embed.i2c.PCA9685

This is a driver for the NXP Semiconductors PCA9685 16-channel, 12-bit PWM with I2C bus LED controller[8]. The driver does not support all of the options that the device has, but these can be added if needed. The device can be configured to respond to one of four different I2C addresses. The constants `addr_0` through `addr_3` are defined for these addresses.

In addition to controlling LEDs, it can control other PWM devices such as servo motors. Note that LED brightness is controlled by the duty cycle and any duty cycle is valid. Servos are controlled by the pulse width which should range from 1.5 to 2.5 mS. See Table 4.15 for some measured values. Note that all measured numbers are approximate. There are probably a few counts left before hitting full scale movement. It's also entirely possible that these values may vary with time, temperature, or other factors.

Servo	Min-position	Max-position
SG90	500mS	2100mS
SG99	450mS	2050mS
SG5010	500mS	2100mS

Table 4.15: Measured Values for PCA9685 Controlling Servos

There are some things to keep in mind:

1. Test your own servos to determine their appropriate values.
2. If you want any sort of precision, you need some sort of position feed-back to the program.
3. The documentation that says that the pulse width for servos should range from 1.5 to 2.5 mS may not be accurate.

PWM channels are 0 to 15. Channel 16 is the all call channel. For each channel there is a 12 bit counter and two thresholds: the on and the off threshold. When the counter is equal to the on threshold, the output turns on. When the counter is equal to the off threshold, the output turns off. This allows the pulses to be staggered between the channels, if needed.

For driving servo motors, the `servo_range` datatype is defined as a `Float` with a range from -1.0 to 1.0. Once the `set_servo_range` procedure has been called, the `set_servo` procedure can be used to set the servo position using `servo_range` rather than figuring out the settings for the duty cycle. Thus, when changing between servos with different characteristics, all that needs to change is the `set_servo_range` call.

```
procedure configure(self : in out PS9685_record; port : i2c_interface;
                  addr : addr7; error : out err_code);
```

Called to configure the PCA9685 device. This must be done before using the device.

- `self` - The PCA9685 device to configure.
- `port` - The I2C bus object that the PCA9685 is connected to.
- `addr` - The I2C address of the device.



- *error* - The error code from any I2C transactions.

```
procedure set(self : PS9685_record; chan : channel;  
             on  : uint12; off  : uint12; error : out err_code);
```

Set on and off times for a specific channel.

- *self* - The PCA9685 device to configure.
- *chan* - The channel number.
- *on* - The on time for the channel.
- *off* - The off time for the channel.
- *error* - The error code from any I2C transactions.

```
procedure set_full_on(self : PS9685_record; chan : channel;  
                    error : out err_code);
```

Sets the specified channel to full on.

- *self* - The PCA9685 device to configure.
- *chan* - The channel number.
- *error* - The error code from any I2C transactions.

```
procedure set_full_off(self : PS9685_record; chan : channel;  
                     error : out err_code);
```

Sets the specified channel to full off.

- *self* - The PCA9685 device to configure.
- *chan* - The channel number.
- *error* - The error code from any I2C transactions.

```
procedure sleep(self : PS9685_record; state : boolean;  
              error : out err_code);
```

If state is *True*, send the device to sleep, otherwise wake it up.

- *self* - The PCA9685 device to configure.
- *state* - *True* for sleep, *False* for wake.
- *error* - The error code from any I2C transactions.

```
procedure set_servo_range(self : in out PS9685_record; chan : channel;  
                        min  : uint12; max  : uint12);
```

Sets the maximum and minimum duty cycles for a channel. Once these are set, a servo motor can be controlled using the `set_servo` procedure using a servo position in the range on -1.0 to 1.0.

- *self* - The PCA9685 device to configure.
- *chan* - The channel number.
- *min* - The minimum duty cycle for the servo, corresponding to servo position -1.0.
- *max* - The maximum duty cycle for the servo, corresponding to servo position 1.0.

```
procedure set_servo(self : PS9685_record; chan : channel;
                    position : servo_range; error : out err_code);
```

Once the servo range has been set by the `set_servo_range` procedure, the servo can be controlled by this function using a servo position from -1.0 to 1.0 rather than the duty cycle.

- *self* - The PCA9685 device to configure.
- *chan* - The channel number.
- *position* - The servo position in a range from -1.0 to 1.0.
- *error* - The error code from any I2C transactions.

#### 4.2.11 BBS.embed.SPI.RA8875

This is the driver for the RAiO RA8875 LCD controller that attaches to the SPI bus[7]. There are a couple of hardware considerations. First, it appears that the RA8875 does not tri-state its SPI output, which means that it doesn't work well with other devices on the SPI bus. This can be fixed by adding a tri-state buffer. Second, while the RA8875 operates at 3.3V, the LCD I used requires 5V for the backlight. This is not insurmountable, but something to be aware of.

The intention of this driver is to provide an Ada interface to the various text and graphics primitives offered by the RA8875. While it works, it still needs some work and should be considered to be experimental. Use at your own risk, or you can use this as a starting point for writing your own driver.

There are a number of constants defined. I expect that most of these are used internal to the driver and should be moved out of the spec. There are also some types that are used in the API. These are documented below.

```
type RA8875_sizes is (RA8875_480x272 , RA8875_800x480 );
```

The datatype `RA8875_sizes` is an enumeration defined for the screen sizes supported by the RA8875. The sizes supported by the RA8875 are 320x240, 320x480, 480x272, 640x480, and 800x480. Right now I only have an 800x480 panel for testing so nothing is tested for other sizes.

```
type RA8875_LAYER is (LAYER1, LAYER2);
```

The datatype `RA8875_LAYER` is used to select the currently active layer for the display. In some configurations, only one layer is allowed and this option is ignored.

```
type RA8875_MWCR0_MODE is (graphic , text );
```

The datatype `RA8875_MWCR0_MODE` is used to determine if the RA8875 is operating in text mode or graphics mode.

type `RA8875_MWCR0_CURDIR` is (`LRTD`, `RLTD`, `TDLR`, `DTLR`);

The datatype `RA8875_MWCR0_CURDIR` is used to determine the memory write direction for graphics mode. The options are left to right top down (*LRTD*), right to left top down (*RLTD*), top down left to right (*TDLR*), and down to top left to right (*DTLR*).

type `RA8875_MWCR1_GCURS_ENABLE` is (`disable`, `enable`);

The datatype `RA8875_MWCR1_GCURS_ENABLE` is used to determine if the graphics cursor should be enabled or disabled.

type `RA8875_MWCR1_GCURS_SET` is range 0 .. 7;

The datatype `RA8875_MWCR1_GCURS_SET` is used to select which set of graphics cursors to use.

type `RA8875_MWCR1_WRITE_DEST` is (`LAYER`, `CGRAM`, `GCURS`, `PATTERN`);

The datatype `RA8875_MWCR1_WRITE_DEST` is used to select the destination for graphics writing.

```
type R5G6B5_color is record
  R : uint8 range 0 .. 31;
  G : uint8 range 0 .. 63;
  B : uint8 range 0 .. 31;
end record;
```

The datatype `R5G6B5_color` is used to represent colors with five bits for the red, six bits for the green, and five bits for the blue channels. This adds up to sixteen bits.

```
type R3G3B2_color is record
  R : uint8 range 0 .. 7;
  G : uint8 range 0 .. 7;
  B : uint8 range 0 .. 3;
end record
with pack, size => 8;
for R3G3B2_color use
  record
    B at 0 range 0 .. 1;
    G at 0 range 2 .. 4;
    R at 0 range 5 .. 7;
  end record;
```

`\begin{lstlisting}`

The datatype `\datatype{R3G3B2\_color}` is used to represent colors with three bits for red, This adds up to eight bits.

`\begin{lstlisting}`

```
type RA8875_FNCR0_Code_Page is
  (RA8875_FNCR0_ISO8859_1, RA8875_FNCR0_ISO8859_2,
   RA8875_FNCR0_ISO8859_3, RA8875_FNCR0_ISO8859_4);
```

The datatype `RA8875_FNCRO_Code_Page` is used to select which code page to use when translating character codes to glyphs on the display.

```
type RA8875_ELLIPSE_PART is (RA8875_ELLIPSE_LL, RA8875_ELLIPSE_UL,  
                             RA8875_ELLIPSE_UR, RA8875_ELLIPSE_LR);
```

The datatype `RA8875_ELLIPSE_PART` is used to select which part of an ellipse is drawn. The options are lower-left (*RA8875\_ELLIPSE\_LL*), upper-left (*RA8875\_ELLIPSE\_UL*), upper-right (*RA8875\_ELLIPSE\_UR*), and lower-right (*RA8875\_ELLIPSE\_LR*).

```
type RA8875_LTPR0_SCROLL_MODE is (LAYER12_SIMULTANEOUS, LAYER1_ONLY,  
                                  LAYER2_ONLY, BUFFERED);
```

The datatype `RA8875_LTPR0_SCROLL_MODE` is used to identify the mode for scrolling. Both layers can be scrolled simultaneously, either of the two layers can be selected to scroll independently, or layer 2 can be used as a scroll buffer.

```
type RA8875_LTPR0_DISP_MODE is (ONLY_LAYER1, ONLY_LAYER2, LIGHTEN, TRANSPARENT,  
                                BOOLOR, BOOLORAND, FLOATING, RESERVED);
```

The datatype `RA8875_LTPR0_DISP_MODE` is used to identify the way to display the two layers. Each layer can be displayed by itself or in various combinations.

```
type RA8875_GCursor is array (0 .. 31, 0 .. 31) of integer range 0 .. 3  
    with Pack;
```

The datatype `RA8875_GCursor` represents a bitmap for the graphics cursor. The pixel values are:

- 0 - GCC0 color
- 1 - GCC1 color
- 2 - Background color
- 3 - Inverse of background color

Note that the coordinates for `GCursor` are reversed from what one would expect. The Y axis coordinate is the first array index and the X axis coordinate is the second array index. One can think of it as being in row, column order.

The API is documented below.

### Low Level Methods

These are primarily intended for supporting the other, higher level routines.

```
procedure setup(self : in out RA8875_record; CS : GPIO.GPIO; screen : SPI_ptr);
```

Initialize and configure the RA8875 device. Use this is no hardware reset GPIO is connected

- *self* - The RA8875 device to configure.
- *CS* - The GPIO used as the device chip select.
- *screen* - The SPI bus that the RA8875 is connected to.

```
procedure setup(self : in out RA8875_record; CS : GPIO.GPIO;  
               RST : GPIO.GPIO; screen : SPI_ptr);
```

Initialize and configure the RA8875 device. Use this if a GPIO is connected to use as a hardware reset.

- *self* - The RA8875 device to configure.
- *CS* - The GPIO used as the device chip select.
- *RST* - The GPIO used as a hardware reset.
- *screen* - The SPI bus that the RA8875 is connected to.

```
procedure hwReset(self : in out RA8875_record);
```

Send a hardware reset command to the RA8875, if a GPIO has been assigned for hardware reset. Otherwise, it does nothing.

- *self* - The RA8875 device to reset.

```
procedure swReset(self : in out RA8875_record);
```

Send a software reset command to the RA8875. This can be done even if no hardware reset GPIO has been configured.

- *self* - The RA8875 device to reset.

```
procedure writeCmd(self : RA8875_record; value : uint8);
```

Send a command to the RA8875.

- *self* - The RA8875 device to send a command to.
- *value* - The command as a `uint8`.

```
procedure writeData(self : RA8875_record; value : uint8);
```

Send data to the RA8875.

- *self* - The RA8875 device to send data to.
- *value* - The data as a `uint8`.

```
function readStatus(self : RA8875_record) return uint8;
```

Read a status value from the RA8875.

- *self* - The RA8875 device to get status from.
- Returns the status as a `uint8`.

```
function readData(self : RA8875_record) return uint8;
```

Read data from the RA8875.

- *self* - The RA8875 device to get data from.
- Returns the data as a `uint8`.

```
procedure writeReg(self : RA8875_record; reg : uint8; value : uint8);
```

Writes data to a RA8875 register.

- *self* - The RA8875 device containing the register.
- *reg* - The register number as a `uint8`.
- *value* - The data as a `uint8`.

```
function readReg(self : RA8875_record; reg : uint8) return uint8;
```

Reads data from a RA8875 register.

- *self* - The RA8875 device containing the register.
- *reg* - The register number as a `uint8`.
- Returns the data as a `uint8`.

### Configuration Methods

```
procedure configure(self : in out RA8875_record; size : RA8875_sizes);
```

Configures the LCD size for use by the RA8875. Currently only 480x272 and 800x480 are supported and only 800x480 has been tested.

- *self* - The RA8875 device to control.
- *size* - The LCD size as a `RA8875_sizes`.

```
procedure setSleep(self : RA8875_record; state : boolean);
```

Sets the sleep state of the RA8875.

- *self* - The RA8875 device to control.
- *state* - If *True*, puts the RA8875 to sleep and turns the display off. If *False* just turns the display off.

```
procedure setDisplay(self : RA8875_record; state : boolean);
```

Turns the display on or off.

- *self* - The RA8875 device to control.
- *state* - If *True*, turns the display on. If *False* turns the display off.

```
procedure GPIOX(self : RA8875_record; state : boolean);
```

Set the state of the GPIOX pin. This is apparently used in the AdaFruit breakout board, though I'm not sure what it's used for.

- *self* - The RA8875 device to control.
- *state* - Sets the state of the GPIOX pin on or off.

```
procedure PWM1config(self : RA8875_record; state : boolean; clock : uint8);
```

Configures PWM channel 1.

- *self* - The RA8875 device to control.
- *state* - Sets the state of the PWM Channel 1 to disable (*False*) or enable (*True*).
- *clock* - Sets the clock divide ratio.

```
procedure PWM2config(self : RA8875_record; state : boolean; clock : uint8);
```

Configures PWM channel 2.

- *self* - The RA8875 device to control.
- *state* - Sets the state of the PWM Channel 2 to disable (*False*) or enable (*True*).
- *clock* - Sets the clock divide ratio.

```
procedure PWM1out(self : RA8875_record; value : uint8);
```

Sets PWM channel 1 duty cycle.

- *self* - The RA8875 device to control.
- *value* - Sets the duty cycle of PWM Channel 1 in units of  $\frac{1}{256}$ .

```
procedure PWM2out(self : RA8875_record; value : uint8);
```

Sets PWM channel 1 duty cycle.

- *self* - The RA8875 device to control.
- *value* - Sets the duty cycle of PWM Channel 1 in units of  $\frac{1}{256}$ .

```
procedure setDisplayCtrl(self : RA8875_record; layer : uint8; hdir : uint8;  
                        vdir : uint8);
```

Sets some of the RA8875 display control parameters.

- *self* - The RA8875 device to control.
- *layer* - 0 For one layer configuration, 128 for two layer configuration.

- *hdir* - 0 For increasing SEG number, 8 for decreasing SEG number.
- *vdir* - 0 For increasing COM number, 4 for decreasing COM number.

```
procedure setWriteCtrl0(self : RA8875_record; mode : RA8875_MWCR0_MODE;  
    cursorVisible : boolean; cursorBlink : boolean;  
    writeDir : RA8875_MWCR0_CURDIR;  
    WriteCursorIncr : boolean; ReadCursorIncr : boolean);
```

Configures the RA8875 memory write control register 0.

- *self* - The RA8875 device to control.
- *mode* - Text or graphics mode.
- *cursorVisible* - Set to *True* to make the cursor visible.
- *cursorBlink* - Set to *True* to make the cursor blink.
- *writeDir* - The direction to write data in graphics mode.
- *WriteCursorIncr* - Set to *True* to increment the cursor when writing memory.
- *ReadCursorIncr* - Set to *True* to increment the cursor when reading memory.

```
procedure setWriteCtrl1(self : RA8875_record;  
    cursorEnable : RA8875_MWCR1_GCURS_ENABLE;  
    GCursorSelect : RA8875_MWCR1_GCURS_SET;  
    writeDest : RA8875_MWCR1_WRITE_DEST;  
    layer : RA8875_LAYER);
```

Configures the RA8875 memory write control register 1.

- *self* - The RA8875 device to control.
- *cursorEnable* - Selects if the graphics cursor is enabled or not.
- *GCursorSelect* - Selects which graphics cursor to use.
- *writeDest* - Selects the destination for graphics writing.
- *writeDir* - The direction to write data in graphics mode.
- *layer* - Selects the layer for graphics writing (used only if the resolution is  $\leq 480 \times 4000$  or the color depth is 8 bits/pixel).



### Text Methods

```
procedure textMode(self : RA8875_record);
```

Sets the RA8875 to text mode.

- *self* - The RA8875 device to control.

```
procedure textColor(self : RA8875_record; bg : R5G6B5_color; fg : R5G6B5_color);
```

Sets the foreground and background color for text.

- *self* - The RA8875 device to control.
- *bg* - The background color.
- *fg* - The foreground color.

```
procedure textSetCodePage(self : RA8875_record; page : RA8875_FNCR0_Code_Page);
```

Selects the code page to used when translating character codes to glyphs on the screen. The options are: *RA8875\_FNCR0\_ISO8859\_1*, *RA8875\_FNCR0\_ISO8859\_2*, *RA8875\_FNCR0\_ISO8859\_3*, and *RA8875\_FNCR0\_ISO8859\_4*.

- *self* - The RA8875 device to control.
- *page* - The code page to use.

```
procedure textSetAttribute(self : RA8875_record; align : boolean;  
                           transparent : boolean;  
                           rotate : boolean; h_size : uint8; v_size : uint8);
```

Sets the attributes in the font control register for drawing text.

- *self* - The RA8875 device to control.
- *align* - Enables or disables text alignment.
- *transparent* - If *True*, the background is transparent instead of the background color.
- *rotate* - If *True*, rotate text by 90°.
- *h\_size* - Horizontal size scale factor (1 .. 4).
- *v\_size* - Vertical size scale factor (1 .. 4).

```
procedure textSetLineHeight(self : RA8875_record; size : uint8);
```

Set the font line distance setting.

- *self* - The RA8875 device to control.
- *size* - The distance between lines of text in pixels.

```
procedure textSetFontWidth(self : RA8875_record; size : uint8);
```

Set the spacing between characters in pixels.

- *self* - The RA8875 device to control.
- *size* - The distance between characters in pixels.

```
procedure textWrite(self : RA8875_record; str : string);
```

Writes a string of text to the display using the currently selected attributes.

- *self* - The RA8875 device to control.
- *str* - The text to write.

### Graphics Methods

```
procedure graphicsMode(self : RA8875_record);
```

Sets the RA8875 to graphics mode.

- *self* - The RA8875 device to control.

```
procedure drawColor(self : RA8875_record; color : R5G6B5_color);
```

Set the color for drawing graphics. The graphics commands will use this color until it is changed.

- *self* - The RA8875 device to control.
- *color* - The color to draw.

```
procedure drawRect(self : RA8875_record; x1 : uint16; y1 : uint16; x2 : uint16;  
                  y2 : uint16; fill : boolean);
```

Draws a rectangle on the display.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of one corner.
- *y1* - The Y-coordinate of one corner.
- *x2* - The opposite X-coordinate.
- *y2* - The opposite Y-coordinate.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawRndRect(self : RA8875_record; x1 : uint16; y1 : uint16; x2 : uint16;  
                    y2 : uint16; rad : uint16; fill : boolean);
```

Draws a rectangle on the display.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of one corner.
- *y1* - The Y-coordinate of one corner.
- *x2* - The opposite X-coordinate.
- *y2* - The opposite Y-coordinate.
- *rad* - The radius of the corner curves.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawLine(self : RA8875_record; x1 : uint16; y1 : uint16; x2 : uint16;  
                  y2 : uint16);
```

Draw a line between two points.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of one end of the line.
- *y1* - The Y-coordinate of one end of the line.
- *x2* - The X-coordinate of the other end of the line.
- *y2* - The Y-coordinate of the other end of the line.

```
procedure drawCircle(self : RA8875_record; x : uint16; y : uint16; rad : uint16;  
                   fill : boolean);
```

Draw a circle.

- *self* - The RA8875 device to control.
- *x* - The X-coordinate of the center of the circle.
- *y* - The Y-coordinate of the center of the circle.
- *rad* - The radius of the circle.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawTriangle(self : RA8875_record; x1 : uint16; y1 : uint16;  
                    x2 : uint16; y2 : uint16; x3 : uint16; y3 : uint16;  
                    fill : boolean);
```

Draw a triangle.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of the first point.

- *y1* - The Y-coordinate of the first point.
- *x2* - The X-coordinate of the second point.
- *y2* - The Y-coordinate of the second point.
- *x3* - The X-coordinate of the third point.
- *y3* - The Y-coordinate of the third point.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawEllipse(self : RA8875_record; x : uint16; y : uint16;  
                    hRad : uint16; vRad : uint16; fill : boolean);
```

Draw an ellipse oriented either horizontally or vertically.

- *self* - The RA8875 device to control.
- *x* - The X-coordinate of the center of the circle.
- *y* - The Y-coordinate of the center of the circle.
- *hRad* - The radius in the horizontal direction.
- *vRad* - The radius in the vertical direction.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawEllipseSegment(self : RA8875_record; x : uint16; y : uint16;  
                           hRad : uint16; vRad : uint16;  
                           seg : RA8875_ELLIPSE_PART; fill : boolean);
```

Draw a segment of an ellipse oriented either horizontally or vertically.

- *self* - The RA8875 device to control.
- *x* - The X-coordinate of the center of the circle.
- *y* - The Y-coordinate of the center of the circle.
- *hRad* - The radius in the horizontal direction.
- *vRad* - The radius in the vertical direction.
- *seg* - Which segment to draw.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawRect(self : RA8875_record; x1 : uint16; y1 : uint16; x2 : uint16;  
                 y2 : uint16; color : R5G6B5_color; fill : boolean);
```

Draws a rectangle on the display.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of one corner.
- *y1* - The Y-coordinate of one corner.
- *x2* - The opposite X-coordinate.
- *y2* - The opposite Y-coordinate.
- *color* - The color for the rectangle.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawRndRect(self : RA8875_record; x1 : uint16; y1 : uint16; x2 : uint16;  
                    y2 : uint16; rad : uint16; color : R5G6B5_color; fill : boolean);
```

Draws a rectangle on the display.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of one corner.
- *y1* - The Y-coordinate of one corner.
- *x2* - The opposite X-coordinate.
- *y2* - The opposite Y-coordinate.
- *rad* - The radius of the corner curves.
- *color* - The color for the rectangle.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawLine(self : RA8875_record; x1 : uint16; y1 : uint16; x2 : uint16;  
                y2 : uint16; color : R5G6B5_color);
```

Draw a line between two points.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of one end of the line.
- *y1* - The Y-coordinate of one end of the line.
- *x2* - The X-coordinate of the other end of the line.
- *y2* - The Y-coordinate of the other end of the line.
- *color* - The color for the line.

```
procedure drawCircle(self : RA8875_record; x : uint16; y : uint16; rad : uint16;  
                color : R5G6B5_color; fill : boolean);
```

Draw a circle.

- *self* - The RA8875 device to control.
- *x* - The X-coordinate of the center of the circle.
- *y* - The Y-coordinate of the center of the circle.
- *rad* - The radius of the circle.
- *color* - The color for the circle.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawTriangle(self : RA8875_record; x1 : uint16; y1 : uint16;  
                      x2 : uint16; y2 : uint16; x3 : uint16; y3 : uint16;  
                      color : R5G6B5_color; fill : boolean);
```

Draw a triangle.

- *self* - The RA8875 device to control.
- *x1* - The X-coordinate of the first point.
- *y1* - The Y-coordinate of the first point.
- *x2* - The X-coordinate of the second point.
- *y2* - The Y-coordinate of the second point.
- *x3* - The X-coordinate of the third point.
- *y3* - The Y-coordinate of the third point.
- *color* - The color for the triangle.
- *fill* - *True* for fill, *False* for outline.

```
procedure drawEllipse(self : RA8875_record; x : uint16; y : uint16; hRad : uint16;  
                    vRad : uint16; color : R5G6B5_color; fill : boolean);
```

Draw an ellipse oriented either horizontally or vertically.

- *self* - The RA8875 device to control.
- *x* - The X-coordinate of the center of the circle.
- *y* - The Y-coordinate of the center of the circle.
- *hRad* - The radius in the horizontal direction.
- *vRad* - The radius in the vertical direction.
- *color* - The color for the ellipse.

- *fill* - *True* for fill, *False* for outline.

```
procedure drawEllipseSegment(self : RA8875_record; x : uint16; y : uint16;  
                             hRad : uint16; vRad : uint16; seg : RA8875_ELLIPSE_PART;  
                             color : R5G6B5_color; fill : boolean);
```

Draw a segment of an ellipse oriented either horizontally or vertically.

- *self* - The RA8875 device to control.
- *x* - The X-coordinate of the center of the circle.
- *y* - The Y-coordinate of the center of the circle.
- *hRad* - The radius in the horizontal direction.
- *vRad* - The radius in the vertical direction.
- *seg* - Which segment to draw.
- *color* - The color for the ellipse segment.
- *fill* - *True* for fill, *False* for outline.

```
procedure waitPoll(self : RA8875_record; reg : uint8; flag : uint8);
```

Repeatedly reads a register and checks for a bit to be cleared. This is commonly used at the end of drawing routines to ensure that the drawing is complete before proceeding. This is intended primarily for use by other of the RA8875 routines and not by user code.

- *self* - The RA8875 device to check.
- *reg* - The register to check.
- *flag* - The set of bits to check. This value is ANDed with the register value and execution proceeds if the result is zero.

### Touch Methods

```
procedure enableTouch(self : RA8875_record; state : boolean);
```

Enable or disable touch processing.

- *self* - The RA8875 device to configure.
- *state* - *True* to enable touch, *False* to disable it.

```
function checkTouched(self : RA8875_record) return boolean;
```

Checks if the RA8875 has recorded a touch event.

- *self* - The RA8875 device to check.

- Returns *True* if a touch event has occurred.

```
procedure readTouchRaw(self : RA8875_record; x : out uint16; y : out uint16);
```

Reads the raw touch location.

- *self* - The RA8875 device to read.
- *x* - The raw X-coordinate of the touch location
- *y* - The raw Y-coordinate of the touch location.

```
procedure readTouchCal(self : RA8875_record; x : out uint16; y : out uint16);
```

Reads the calibrated touch location.

- *self* - The RA8875 device to read.
- *x* - The calibrated X-coordinate of the touch location
- *y* - The calibrated Y-coordinate of the touch location.

```
procedure touchCalibrate(self : in out RA8875_record);
```

Run a touch calibration process. This requires the user to touch the top, bottom, left, and right edges of the touch screen. Based on this, the limits of the touch sensor are computed and added to the RA8875 object.

- *self* - The RA8875 device to calibrate.

```
procedure setTouchCalibration(self : in out RA8875_record; top : uint16;  
                             bottom : uint16; left : uint16; right : uint16);
```

Set the touch sensor limits for the RA8875. This can be useful if the limits are already known and avoids running through the touch calibration process.

- *self* - The RA8875 device to calibrate.
- *top* - The screen top limit.
- *bottom* - The screen bottom limit.
- *left* - The screen left limit.
- *right* - The screen right limit.

```
procedure getTouchCalibration(self : RA8875_record; top : out uint16;  
                             bottom : out uint16; left : out uint16;  
                             right : out uint16);
```

Read the touch sensor limits from the RA8875. This can be useful to save the limits for use with **setTouchCalibration**.



- *self* - The RA8875 device to read.
- *top* - The screen top limit.
- *bottom* - The screen bottom limit.
- *left* - The screen left limit.
- *right* - The screen right limit.

### Region and Layer Methods

```
procedure scroll(self : RA8875_record; hStart : uint16; vStart : uint16;  
               hEnd : uint16; vEnd : uint16; hOffset : uint16; vOffset : uint16);
```

Scroll a region on the display

- *self* - The RA8875 device to scroll.
- *hStart* - The region starting horizontal coordinate.
- *vStart* - The region starting vertical coordinate.
- *hEnd* - The region ending horizontal coordinate.
- *vEnd* - The region ending vertical coordinate.
- *hOffset* - The horizontal scroll amount.
- *vOffset* - The vertical scroll amount.

```
procedure setActiveWindow(self : RA8875_record; top : uint16; bottom : uint16;  
                        left : uint16; right : uint16);
```

Sets the current active window on the display.

- *self* - The RA8875 device to configure.
- *top* - The top of the new active window.
- *bottom* - The bottom of the new active window.
- *left* - The left side of the new active window.
- *right* - The right side of the new active window.

```
procedure screenActive(self : RA8875_record);
```

Sets the entire display area to be the active window.

- *self* - The RA8875 device to configure.

```
procedure setLayers(self : RA8875_record; layer : RA8875_LAYER);
```

Sets the number of layers available for use. May be one or two. If two layers are selected, the graphics depths is reduced to allow two layers.

- *self* - The RA8875 device to configure.
- *layer* - *LAYER1* for one layer, *LAYER2* for two layers.

```
procedure selectLayer(self : RA8875_record; layer : RA8875_LAYER);
```

Selects which layer to use.

- *self* - The RA8875 device to configure.
- *layer* - The currently active layer.

```
procedure setLayerSetting0(self : RA8875_record;  
                           scroll : RA8875_LTPR0_SCROLL_MODE;  
                           float : boolean; display : RA8875_LTPR0_DISP_MODE);
```

Sets layer transparency register 0 in the RA8875.

- *self* - The RA8875 device to configure.
- *scroll* - Sets the scrolling mode.
- *float* - Enables or disables floating window transparency display.
- *display* - Sets the display mode for mixing layers 1 and 2.

### Cursor Methods

```
procedure setTextCursorPos(self : RA8875_record; x : uint16; y : uint16);
```

Sets the text cursor position.

- *self* - The RA8875 device to configure.
- *x* - The X-coordinate of the cursor.
- *y* - The Y-coordinate of the cursor.

```
procedure setGraphCursorColors(self : RA8875_record; color0 : R3G3B2_color;  
                               color1 : R3G3B2_color);
```

Set the graphics cursor colors.

- *self* - The RA8875 device to configure.
- *color0* - The first color to use.
- *color1* - The second color to use.

```
procedure setGraphCursorPos(self : RA8875_record; x : uint16; y : uint16);
```

Sets the graphics cursor position.

- *self* - The RA8875 device to configure.
- *x* - The X-coordinate of the cursor.
- *y* - The Y-coordinate of the cursor.

```
procedure setGraphCursor( self : RA8875_record; curs : RA8875_MWCR1_GCURS_SET;  
                        data : RA8875_GCursor );
```

Sets the graphics cursor.

- *self* - The RA8875 device to configure.
- *curs* - The graphics cursor set.
- *data* - The bitmap for the graphics cursor.

```
procedure selectGraphCursor( self : RA8875_record; curs : RA8875_MWCR1_GCURS_SET;  
                           enable : RA8875_MWCR1_GCURS_ENABLE );
```

Selects the graphics cursor.

- *self* - The RA8875 device to configure.
- *curs* - The graphics cursor set.
- *enable* - Enables or disables the graphics cursor.

### Miscellaneous Methods

```
procedure fillScreen( self : RA8875_record; color : R5G6B5_color );
```

Fills the display with a solid color.

- *self* - The RA8875 device to configure.
- *color* - The color to use.

## Chapter 5

# Linux API Description

### 5.1 Common

### 5.2 Raspberry Pi

### 5.3 BeagleBone Black

## Chapter 6

# Arduino Due API Description

## Chapter 7

# Other Stuff

If there is anything else that should be added, additional chapters may be added as needed.

# Bibliography

- [1] Bosch. BMP180 digital pressure sensor, April 2013.
- [2] Bosch. BME280 combined humidity and pressure sensor, February 2024.
- [3] Texas Instruments. ADS1015 12-bit, 3.3-kSPS, 4-channel, delta-sigma ADC with PGA, oscillator, VREF, comparator, and I2C, January 2018.
- [4] Microchip. MCP23008 8-bit I/O expander with serial interface, 2007.
- [5] Microchip. MCP4725 12-bit digital-to-analog converter with EEPROM memory, 2009.
- [6] Microchip. MCP23017 16-bit I/O expander with serial interface, 2016.
- [7] RAiO. RA8875 character/graphic TFT LCD controller, March 2013.
- [8] NXP Semiconductors. PCA9685 16-channel, 12-bit PWM fm+I<sup>2</sup>C-bus LED controller, April 2015.
- [9] STMicroelectronics. L3GD20 low power 3-axis gyroscope, I2C/SPI digital output, February 2013.
- [10] STMicrosystems. LSM303DLHC ultra-compact high-performance ecompass module: 3d accelerometer and 3d magnetometer, November 2013.
- [11] Toshiba. TB6612FNG driver IC for dual DC motor, October 2014.