

**InvenSense Inc.**

1745 Technology Dr., San Jose, CA 95110 U.S.A.  
Tel: +1 (408) 988-7339 Fax: +1 (408) 988-8104  
website: [www.invensense.com](http://www.invensense.com)

Doc : SW-MA-AND-REL-5.2.0-K  
Doc Rev : 1.0  
Date : 11/27/2013

# MotionApps v5.2.0-K APIs Specification

A printed copy of this document is  
**NOT UNDER REVISION CONTROL**  
unless it is dated and stamped in red ink as,  
“REVISION CONTROLLED COPY.”

This information furnished by InvenSense is believed to be accurate and reliable. However, no responsibility is assumed by InvenSense for its use, or for any infringements or patents or other rights of third parties that may result from its use. Specifications are subject to change without notice. Certain intellectual property owned by InvenSense and described in this document is patent protected. No license is granted by Implication or otherwise under any patent or patent rights of InvenSense. This is an unpublished work protected under the United States copyright laws. This work contains proprietary and confidential information of InvenSense Inc. Use, disclosure or reproduction without the express written authorization of InvenSense Inc. is prohibited. Trademarks that are registered trademarks are the property of their respective companies.

This publication supersedes and replaces all information previously supplied. InvenSense sensors should not be used or sold for the development, storing, production and utilization of any conventional or mass-destructive weapons or any other weapons or life threatening applications, as well as to be used in any other life critical applications such as medical, transportation, aerospace, nuclear, undersea, power, disaster and crime prevention equipment.

Copyright ©2010 InvenSense Corporation.

CONFIDENTIAL & PROPRIETARY

[www.invensense.com](http://www.invensense.com)



**MA v5.2.0-K  
APIs Specification**

Doc : SW-MA-AND-REL-5.2.0-K  
Doc Rev : 1.0  
Date : 11/27/2013

CONFIDENTIAL

## Chapter 1

# Purpose and Scope

This document is a guide to all of the functions available in the InvenSense MotionApps Platform Library (MPL), and corresponds with MotionApps Release v5.2.0-K.

The MPL contains the code for controlling the InvenSense devices, including activating and managing built in motion processing features. All of the source code is in ANSI C and can be compiled in C or C++ environments.

All functions available in the MPL are described in this document, including all parameters involved in the function calls. The functions are divided into modules as follows:

Module	Name	Description
<a href="#">Data Builder</a>	Builds Sensor Data Structures	Builds the sensor structures and calls functions that need to use them.
<a href="#">HAL Outputs</a>	HAL Outputs	Creates and holds information that a Android HAL layer might want.
<a href="#">Message Layer</a>	Message Layer	Holds Messages
<a href="#">ML Math Func</a>	Math Functions	Support Math Functions.
<a href="#">MPL</a>	MPU Start	Handles init, start, and version properties .
<a href="#">Result_Holder</a>	Result Holder	Holds various output results.
<a href="#">Start_Manager</a>	Start Manager	Sends start events.
<a href="#">Storage_Manager</a>	Store Variables	Stores Internal States.

For more information on how to use these functions in a specific application, refer to InvenSense Application Notes.

## Chapter 2

# About this document

This document is automatically generated from the source files using Doxygen's output format in the  $\text{\LaTeX}$ . Heading, footer, and general document format are customized from the standard header template provided by Doxygen. The document is subdivided in the various sections, each describing the main source [Modules](#) composing the MPL and implementing specific features.

Every section starts with a brief description and an overview of the functions composing the module. Each of those functions is also fully documented in the analogous "Function Documentation" section. Clicking on the function prototype will lead to the portion of text full documentating it.

This **MotionApps Functional Specification** is best viewed in a PDF viewer, as it provides text hyperlinks and bookmarks on the left-hand side for ease of browsing. There is an Alphabetical Index of the modules and their functions available at the bottom of this document.

## Chapter 3

# Module Index

### 3.1 Modules

Here is a list of all modules:

data_builder . . . . .	3
hal_outputs . . . . .	25
ml_math_func . . . . .	33
message_layer . . . . .	42
mpl . . . . .	44
results_holder . . . . .	48
start_manager . . . . .	65
storage_manager . . . . .	67
accel_calibration . . . . .	70
small_motion_compass_cal . . . . .	72
compass_fit . . . . .	74
compass_vector_cal . . . . .	76
fast_no_mot . . . . .	78
nine_axis_fusion . . . . .	82
gyro_tc . . . . .	86
heading_from_gyro . . . . .	88
mag_disturb . . . . .	90
motion_no_motion . . . . .	92
no_gyro_fusion . . . . .	95



CONFIDENTIAL

## Chapter 4

# Module Documentation

### 4.1 data\_builder

Motion Library - Data Builder Constructs and Creates the data for MPL.

#### Files

- file [data\\_builder.c](#)  
*Data Builder.*

#### Functions

- void [inv\\_accel\\_was\\_turned\\_off](#) ()  
*This should be called when the accel has been turned off.*
- void [inv\\_apply\\_calibration](#) (struct inv\_single\_sensor\_t \*sensor, const long \*bias)  
*Takes raw data stored in the sensor, removes bias, and converts it to calibrated data in the body frame.*
- inv\_error\_t [inv\\_build\\_accel](#) (const long \*accel, int status, inv\_time\_t timestamp)  
*Record new accel data for use when [inv\\_execute\\_on\\_data\(\)](#) is called.*
- inv\_error\_t [inv\\_build\\_compass](#) (const long \*compass, int status, inv\_time\_t timestamp)  
*Record new compass data for use when [inv\\_execute\\_on\\_data\(\)](#) is called.*
- inv\_error\_t [inv\\_build\\_gyro](#) (const short \*gyro, inv\_time\_t timestamp)  
*Record new gyro data and calls [inv\\_execute\\_on\\_data\(\)](#) if previous sample has not been processed.*

- `inv_error_t inv_build_quat` (const long \*quat, int status, inv\_time\_t timestamp)  
*quaternion data*
- `inv_error_t inv_build_temp` (const long temp, inv\_time\_t timestamp)  
*Record new temperature data for use when `inv_execute_on_data()` is called.*
- `void inv_compass_was_turned_off` ()  
*This should be called when the compass has been turned off.*
- `void inv_disable_compass_soft_iron_matrix` (void)  
*This subroutine disables the the soft iron transformation process.*
- `void inv_enable_compass_soft_iron_matrix` (void)  
*This subroutine enables the the soft iron transformation process.*
- `inv_error_t inv_execute_on_data` (void)  
*After at least one of `inv_build_gyro()`, `inv_build_accel()`, or `inv_build_compass()` has been called, this function should be called.*
- `int inv_get_6_axis_compass_accel_timestamp` (long sample\_rate\_us, inv\_time\_t \*ts)  
*Gets best timestamp and if there is a new piece of data for a 9-axis sensor combination.*
- `int inv_get_6_axis_gyro_accel_timestamp` (long sample\_rate\_us, inv\_time\_t \*ts)  
*Gets best timestamp and if there is a new piece of data for a 9-axis sensor combination.*
- `int inv_get_9_axis_timestamp` (long sample\_rate\_us, inv\_time\_t \*ts)  
*Gets best timestamp and if there is a new piece of data for a 9-axis sensor combination.*
- `int inv_get_accel_accuracy` (void)  
*Returns accuracy of accel.*
- `void inv_get_accel_bias` (long \*bias)  
*Get accel bias from MPL.*
- `void inv_get_accel_bias_dmp_units` (long \*bias)  
*Accel Bias in the form used by the DMP.*
- `int inv_get_accel_on` ()  
*Helper function stating whether the accelerometer is on or off.*
- `long inv_get_accel_sensitivity` (void)  
*Accel sensitivity.*
- `void inv_get_accel_set` (long \*data, int8\_t \*accuracy, inv\_time\_t \*timestamp)  
*Gets a whole set of accel data including data, accuracy and timestamp.*
- `void inv_get_compass_bias` (long \*bias)  
*Returns the current bias for the compass.*
- `int inv_get_compass_on` ()  
*Helper function stating whether the compass is on or off.*
- `long inv_get_compass_sensitivity` (void)



#### 4.1 data\_builder

5

*Compass sensitivity.*

- void [inv\\_get\\_compass\\_set](#) (long \*data, int8\_t \*accuracy, inv\_time\_t \*timestamp)

*Gets a whole set of compass data including data, accuracy and timestamp.*

- void [inv\\_get\\_compass\\_set\\_raw](#) (long \*data, int8\_t \*accuracy, inv\_time\_t \*timestamp)

*Gets a whole set of compass raw data including data, accuracy and timestamp.*

- void [inv\\_get\\_compass\\_soft\\_iron\\_input\\_data](#) (long \*data)

*This subroutine gets the fixed point Q30 compass data before the soft iron transformation.*

- void [inv\\_get\\_compass\\_soft\\_iron\\_matrix\\_d](#) (long \*matrix)

*Gets the 3x3 compass transform matrix in 32 bit Q30 fixed point format.*

- void [inv\\_get\\_compass\\_soft\\_iron\\_matrix\\_f](#) (float \*matrix)

*Gets the 3x3 compass transform matrix in 32 bit floating point format.*

- void [inv\\_get\\_compass\\_soft\\_iron\\_output\\_data](#) (long \*data)

*This subroutine gets the fixed point Q30 compass data after the soft iron transformation.*

- int [inv\\_get\\_factory\\_accel\\_bias\\_mask](#) ()

*Get factory accel bias mask.*

- void [inv\\_get\\_gyro](#) (long \*gyro)

*Get's latest gyro data.*

- int [inv\\_get\\_gyro\\_accuracy](#) (void)

*Returns accuracy of gyro.*

- void [inv\\_get\\_gyro\\_bias](#) (long \*bias)

*Get the gyro biases and temperature record from MPL.*

- void [inv\\_get\\_gyro\\_bias\\_dmp\\_units](#) (long \*bias)

*Gyro Bias in the form used by the DMP.*

- int [inv\\_get\\_gyro\\_on](#) ()

*Helper function stating whether the gyro is on or off.*

- long [inv\\_get\\_gyro\\_sensitivity](#) (void)

*Gyro sensitivity.*

- void [inv\\_get\\_gyro\\_set](#) (long \*data, int8\_t \*accuracy, inv\_time\_t \*timestamp)

*Gets a whole set of gyro data including data, accuracy and timestamp.*

- void [inv\\_get\\_gyro\\_set\\_raw](#) (long \*data, int8\_t \*accuracy, inv\_time\_t \*timestamp)

*Gets a whole set of gyro raw data including data, accuracy and timestamp.*

- inv\_time\_t [inv\\_get\\_last\\_timestamp](#) ()

*Get last timestamp across all 3 sensors that are on.*

- int [inv\\_get\\_mag\\_accuracy](#) (void)

*Returns accuracy of compass.*

- void [inv\\_get\\_mpl\\_accel\\_bias](#) (long \*bias, long \*temp)  
*Get Accel Bias.*
- void [inv\\_get\\_mpl\\_gyro\\_bias](#) (long \*bias, long \*temp)  
*Get the mpl gyro biases.*
- void [inv\\_get\\_raw\\_compass](#) (short \*raw)  
*Gets last value of raw compass data.*
- void [inv\\_get\\_temp\\_set](#) (long \*data, int \*accuracy, inv\_time\_t \*timestamp)  
*Gets a whole set of temperature data including data, accuracy and timestamp.*
- void [inv\\_gyro\\_was\\_turned\\_off](#) ()  
*This should be called when the gyro has been turned off.*
- inv\_error\_t [inv\\_init\\_data\\_builder](#) (void)  
*Initialize the data builder.*
- void [inv\\_quaternion\\_sensor\\_was\\_turned\\_off](#) (void)  
*This should be called when the quaternion data from the DMP has been turned off.*
- inv\_error\_t [inv\\_register\\_data\\_cb](#) (inv\_error\_t(\*func)(struct inv\_sensor\_cal\_t \*data), int priority, int sensor\_type)  
*Registers to receive a callback when there is new sensor data.*
- void [inv\\_reset\\_compass\\_soft\\_iron\\_matrix](#) (void)  
*This subroutine resets the the soft iron transformation to unity matrix and disable the soft iron transformation process by default.*
- void [inv\\_set\\_accel\\_accuracy](#) (int accuracy)  
*Sets the accel accuracy.*
- void [inv\\_set\\_accel\\_bandwidth](#) (int bandwidth\_hz)  
*Set Accel Bandwidth in Hz.*
- void [inv\\_set\\_accel\\_bias](#) (const long \*bias)  
*Sets the factory accel bias.*
- void [inv\\_set\\_accel\\_bias\\_mask](#) (const long \*bias, int accuracy, int mask)  
*Sets the accel bias with control over which axis.*
- void [inv\\_set\\_accel\\_orientation\\_and\\_scale](#) (int orientation, long sensitivity)  
*Sets the orientation and sensitivity of the gyro data.*
- void [inv\\_set\\_accel\\_sample\\_rate](#) (long sample\_rate\_us)  
*Set Accel Sample rate in micro seconds.*
- void [inv\\_set\\_compass\\_bandwidth](#) (int bandwidth\_hz)  
*Set Compass Bandwidth in Hz.*
- void [inv\\_set\\_compass\\_bias](#) (const long \*bias, int accuracy)  
*Sets the compass bias.*
- void [inv\\_set\\_compass\\_disturbance](#) (int dist)  
*Set the state of a compass disturbance.*
- void [inv\\_set\\_compass\\_orientation\\_and\\_scale](#) (int orientation, long sensitivity)  
*Sets the Orientation and Sensitivity of the gyro data.*

## 4.1 data\_builder

7

- void [inv\\_set\\_compass\\_sample\\_rate](#) (long sample\_rate\_us)  
*Set Compass Sample rate in micro seconds.*
- void [inv\\_set\\_compass\\_soft\\_iron\\_input\\_data](#) (const long \*data)  
*This subroutine sets the compass raw data for the soft iron transformation.*
- void [inv\\_set\\_compass\\_soft\\_iron\\_matrix\\_d](#) (long \*matrix)  
*Sets the 3x3 compass transform matrix in 32 bit Q30 fixed point format.*
- void [inv\\_set\\_compass\\_soft\\_iron\\_matrix\\_f](#) (float \*matrix)  
*Sets the 3x3 compass transform matrix in 32 bit floating point format.*
- void [inv\\_set\\_gyro\\_bandwidth](#) (int bandwidth\_hz)  
*Set Gyro Bandwidth in Hz.*
- void [inv\\_set\\_gyro\\_bias](#) (const long \*bias)  
*Sets the factory gyro bias.*
- void [inv\\_set\\_gyro\\_orientation\\_and\\_scale](#) (int orientation, long sensitivity)  
*Sets the Orientation and Sensitivity of the gyro data.*
- void [inv\\_set\\_gyro\\_sample\\_rate](#) (long sample\_rate\_us)  
*Set Gyro Sample rate in micro seconds.*
- void [inv\\_set\\_mpl\\_gyro\\_bias](#) (const long \*bias, int accuracy)  
*Sets the mpl gyro bias.*
- void [inv\\_set\\_quat\\_sample\\_rate](#) (long sample\_rate\_us)  
*Set Quat Sample rate in micro seconds.*
- void [inv\\_temperature\\_was\\_turned\\_off](#) ()  
*This should be called when the temperature sensor has been turned off.*
- inv\_error\_t [inv\\_unregister\\_data\\_cb](#) (inv\_error\_t(\*func)(struct inv\_sensor\_cal\_t \*data))  
*Unregisters the callback that happens when new sensor data is received.*
- void [set\\_sensor\\_orientation\\_and\\_scale](#) (struct inv\_single\_sensor\_t \*sensor, int orientation, long sensitivity)  
*Sets orientation and sensitivity field for a sensor.*

### 4.1.1 Detailed Description

Motion Library - Data Builder Constructs and Creates the data for MPL.

### 4.1.2 Function Documentation

#### 4.1.2.1 void [inv\\_accel\\_was\\_turned\\_off](#) ( )

This should be called when the accel has been turned off.

This is so that we will know if the data is contiguous.

#### 4.1.2.2 void inv\_apply\_calibration ( struct inv\_single\_sensor\_t \* *sensor*, const long \* *bias* )

Takes raw data stored in the sensor, removes bias, and converts it to calibrated data in the body frame.

Also store raw data for body frame.

##### Parameters

in, out	<i>sensor</i>	structure to modify
in	<i>bias</i>	bias in the mounting frame, in hardware units scaled by $2^{16}$ . Length 3.

#### 4.1.2.3 inv\_error\_t inv\_build\_accel ( const long \* *accel*, int *status*, inv\_time\_t *timestamp* )

Record new accel data for use when [inv\\_execute\\_on\\_data\(\)](#) is called.

##### Parameters

in	<i>accel</i>	accel data, length 3. Calibrated data is in $\text{m/s}^2$ scaled by $2^{16}$ in body frame. Raw data is in device units in chip mounting frame.
in	<i>status</i>	Lower 2 bits are the accuracy, with 0 being inaccurate, and 3 being most accurate. The upper bit INV_CALIBRATED, is set if the data was calibrated outside MPL and it is not set if the data being passed is raw. Raw data should be in device units, typically in a 16-bit range.
in	<i>timestamp</i>	Monotonic time stamp, for Android it's in nanoseconds.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.1.2.4 inv\_error\_t inv\_build\_compass ( const long \* *compass*, int *status*, inv\_time\_t *timestamp* )

Record new compass data for use when [inv\\_execute\\_on\\_data\(\)](#) is called.

##### Parameters

in	<i>compass</i>	Compass data, if it was calibrated outside MPL, the units are $\mu\text{T}$ scaled by $2^{16}$ . Length 3.
----	----------------	--

#### 4.1 data\_builder

9

in	status	Lower 2 bits are the accuracy, with 0 being inaccurate, and 3 being most accurate. The upper bit INV_CALIBRATED, is set if the data was calibrated outside MPL and it is not set if the data being passed is raw. Raw data should be in device units, typically in a 16-bit range.
in	timestamp	Monotonic time stamp, for Android it's in nanoseconds.
out	executed	Set to 1 if data processing was done.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

##### 4.1.2.5 inv\_error\_t inv\_build\_gyro ( const short \* gyro, inv\_time\_t timestamp )

Record new gyro data and calls [inv\\_execute\\_on\\_data\(\)](#) if previous sample has not been processed.

#### Parameters

in	gyro	Data is in device units. Length 3.
in	timestamp	Monotonic time stamp, for Android it's in nanoseconds.
out	executed	Set to 1 if data processing was done.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

##### 4.1.2.6 inv\_error\_t inv\_build\_quat ( const long \* quat, int status, inv\_time\_t timestamp )

quaternion data

#### Parameters

in	quat	Quaternion data. $2^{30} = 1.0$ or $2^{14} = 1$ for 16-bit data. - Real part first. Length 4.
in	status	number of axis, 16-bit or 32-bit set INV_QUAT_3ELEMENT if input quaternion has only 3 elements (no scalar). <a href="#">inv_compute_scalar_part()</a> assumes 32-bit data. If using 16-bit quaternion, shift 16 bits first before calling this function.
in	timestamp	
in	timestamp	Monotonic time stamp; for Android it's in nanoseconds.
out	executed	Set to 1 if data processing was done.

Generated on Wed Nov 27 2013 16:25:55 for MLSDK by Doxygen

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.1.2.7 `inv_error_t inv_build_temp ( const long temp, inv_time_t timestamp )`

Record new temperature data for use when `inv_execute_on_data()` is called.

#### Parameters

in	<i>temp</i>	Temperature data in q16 format.
in	<i>timestamp</i>	Monotonic time stamp; for Android it's in nanoseconds.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.1.2.8 `void inv_compass_was_turned_off ( )`

This should be called when the compass has been turned off.

This is so that we will know if the data is contiguous.

#### 4.1.2.9 `inv_error_t inv_execute_on_data ( void )`

After at least one of `inv_build_gyro()`, `inv_build_accel()`, or `inv_build_compass()` has been called, this function should be called.

It will process the data it has received and update all the internal states and features that have been turned on.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.1.2.10 `int inv_get_6_axis_compass_accel_timestamp ( long sample_rate_us, inv_time_t * ts )`

Gets best timestamp and if there is a new piece of data for a 9-axis sensor combination.

It does this by finding a raw sensor that has the closest sample rate that is at least as often desired. It also returns if that raw sensor has a new piece of data. Priority compass, accel on a tie



#### 4.1 data\_builder

11

##### Returns

Returns 1, if the raw sensor being attached has new data, 0 otherwise.

4.1.2.11 `int inv_get_6_axis_gyro_accel_timestamp ( long sample_rate_us,  
inv_time_t * ts )`

Gets best timestamp and if there is a new piece of data for a 9-axis sensor combination.

It does this by finding a raw sensor that has the closest sample rate that is at least as often desired. It also returns if that raw sensor has a new piece of data. Priority is Quaternion-6axis, Quaternion 3-axis, Gyro, Accel

##### Returns

Returns 1, if the raw sensor being attached has new data, 0 otherwise.

4.1.2.12 `int inv_get_9_axis_timestamp ( long sample_rate_us, inv_time_t * ts )`

Gets best timestamp and if there is a new piece of data for a 9-axis sensor combination.

It does this by finding a raw sensor that has the closest sample rate that is at least as often desired. It also returns if that raw sensor has a new piece of data. Priority is 9-axis quat, 6-axis quat, 3-axis quat, gyro, compass, accel on ties.

##### Returns

Returns 1, if the raw sensor being attached has new data, 0 otherwise.

4.1.2.13 `int inv_get_accel_accuracy ( void )`

Returns accuracy of accel.

##### Returns

Accuracy of accel with 0 being not accurate, and 3 being most accurate.

4.1.2.14 `void inv_get_accel_bias ( long * bias )`

Get accel bias from MPL.

##### Parameters

in	bias	Accel bias in hardware units scaled by $2^{16}$ . In chp mounting frame. Length 3.
----	------	--

Generated on Wed Nov 27 2013 16:25:55 for MLSDK by Doxygen

#### 4.1.2.15 void inv\_get\_accel\_bias\_dmp\_units ( long \* *bias* )

Accel Bias in the form used by the DMP.

##### Parameters

out	<i>bias</i>	Accel Bias in the form used by the DMP. It is scaled appropriately and is in the body frame as needed.
-----	-------------	--

#### 4.1.2.16 int inv\_get\_accel\_on ( )

Helper function stating whether the accelerometer is on or off.

##### Returns

TRUE if accel is on, 0 if accel is off

#### 4.1.2.17 long inv\_get\_accel\_sensitivity ( void )

Accel sensitivity.

##### Returns

A scale factor to convert device units to g's scaled by  $2^{16}$  such that  $g\_s = \text{device\_units} * \text{sensitivity} / 2^{30}$ . Typically it works out to be the maximum accel value in g's \*  $2^{15}$ .

#### 4.1.2.18 void inv\_get\_accel\_set ( long \* *data*, int8\_t \* *accuracy*, inv\_time\_t \* *timestamp* )

Gets a whole set of accel data including data, accuracy and timestamp.

##### Parameters

out	<i>data</i>	Accel Data where $1g = 2^{16}$
out	<i>accuracy</i>	Accuracy 0 being not accurate, and 3 being most accurate.
out	<i>timestamp</i>	The timestamp of the data sample.

#### 4.1.2.19 void inv\_get\_compass\_bias ( long \* *bias* )

Returns the current bias for the compass.



#### 4.1 data\_builder

13

##### Parameters

out	<i>bias</i>	Compass bias in hardware units scaled by $2^{16}$ . In mounting frame. Length 3.
-----	-------------	--

##### 4.1.2.20 int inv\_get\_compass\_on ( )

Helper function stating whether the compass is on or off.

##### Returns

TRUE if compass if on, 0 if compass if off

##### 4.1.2.21 long inv\_get\_compass\_sensitivity ( void )

Compass sensitivity.

##### Returns

A scale factor to convert device units to micro Tesla scaled by  $2^{16}$  such that  $uT = \text{device\_units} * \text{sensitivity} / 2^{30}$ . Typically it works out to be the maximum  $uT * 2^{15}$ .

##### 4.1.2.22 void inv\_get\_compass\_set ( long \* data, int8\_t \* accuracy, inv\_time\_t \* timestamp )

Gets a whole set of compass data including data, accuracy and timestamp.

##### Parameters

out	<i>data</i>	Compass Data where $1 uT = 2^{16}$
out	<i>accuracy</i>	Accuracy 0 being not accurate, and 3 being most accurate.
out	<i>timestamp</i>	The timestamp of the data sample.

##### 4.1.2.23 void inv\_get\_compass\_set\_raw ( long \* data, int8\_t \* accuracy, inv\_time\_t \* timestamp )

Gets a whole set of compass raw data including data, accuracy and timestamp.

**Parameters**

out	<i>data</i>	Compass Data where $1 \text{ uT} = 2^{16}$
out	<i>accuracy</i>	Accuracy 0 being not accurate, and 3 being most accurate.
out	<i>timestamp</i>	The timestamp of the data sample.

**4.1.2.24 void inv\_get\_compass\_soft\_iron\_input\_data ( long \* *data* )**

This subroutine gets the fixed point Q30 compass data before the soft iron transformation.

**Parameters**

out	<i>the</i>	pointer of the 3x1 vector compass data in MPL format
-----	------------	--

**4.1.2.25 void inv\_get\_compass\_soft\_iron\_matrix\_d ( long \* *matrix* )**

Gets the 3x3 compass transform matrix in 32 bit Q30 fixed point format.

**Parameters**

out	<i>the</i>	pointer of the 3x3 matrix in Q30 format
-----	------------	---

**4.1.2.26 void inv\_get\_compass\_soft\_iron\_matrix\_f ( float \* *matrix* )**

Gets the 3x3 compass transform matrix in 32 bit floating point format.

**Parameters**

out	<i>the</i>	pointer of the 3x3 matrix in floating point format
-----	------------	--

**4.1.2.27 void inv\_get\_compass\_soft\_iron\_output\_data ( long \* *data* )**

This subroutine gets the fixed point Q30 compass data after the soft iron transformation.

**Parameters**

out	<i>the</i>	pointer of the 3x1 vector compass data in MPL format
-----	------------	--

#### 4.1 data\_builder

15

##### 4.1.2.28 int inv\_get\_factory\_accel\_bias\_mask ( )

Get factory accel bias mask.

###### Parameters

in	<i>bias</i>	Accel bias mask 1 is set, 0 is not set, Length 3 = x,y,z.
----	-------------	---

##### 4.1.2.29 void inv\_get\_gyro ( long \* gyro )

Get's latest gyro data.

###### Parameters

out	<i>gyro</i>	Gyro Data, Length 3. 1 dps = $2^{16}$ .
-----	-------------	---

##### 4.1.2.30 int inv\_get\_gyro\_accuracy ( void )

Returns accuracy of gyro.

###### Returns

Accuracy of gyro with 0 being not accurate, and 3 being most accurate.

##### 4.1.2.31 void inv\_get\_gyro\_bias ( long \* bias )

Get the gyro biases and temperature record from MPL.

###### Parameters

in	<i>bias</i>	Gyro bias in hardware units scaled by $2^{16}$ . In chip mounting frame. Length 3.
----	-------------	--

##### 4.1.2.32 void inv\_get\_gyro\_bias\_dmp\_units ( long \* bias )

Gyro Bias in the form used by the DMP.

###### Parameters

out	bias	Gyro Bias in the form used by the DMP. It is scaled appropriately and is in the body frame as needed. If this bias is applied in the DMP then any quaternion must have the flag INV_BIAS_APPLIED set if it is a 3-axis quaternion, or INV_QUAT_6AXIS if it is a 6-axis quaternion
-----	------	---

#### 4.1.2.33 int inv\_get\_gyro\_on ( )

Helper function stating whether the gyro is on or off.

##### Returns

TRUE if gyro if on, 0 if gyro if off

#### 4.1.2.34 long inv\_get\_gyro\_sensitivity ( void )

Gyro sensitivity.

##### Returns

A scale factor to convert device units to degrees per second scaled by  $2^{16}$  such that  $\text{degrees\_per\_second} = \text{device\_units} * \text{sensitivity} / 2^{30}$ . Typically it works out to be the maximum rate  $* 2^{15}$ .

#### 4.1.2.35 void inv\_get\_gyro\_set ( long \* data, int8\_t \* accuracy, inv\_time\_t \* timestamp )

Gets a whole set of gyro data including data, accuracy and timestamp.

##### Parameters

out	data	Gyro Data where 1 dps = $2^{16}$
out	accuracy	Accuracy 0 being not accurate, and 3 being most accurate.
out	timestamp	The timestamp of the data sample.

#### 4.1.2.36 void inv\_get\_gyro\_set\_raw ( long \* data, int8\_t \* accuracy, inv\_time\_t \* timestamp )

Gets a whole set of gyro raw data including data, accuracy and timestamp.

#### 4.1 data\_builder

17

##### Parameters

out	<i>data</i>	Gyro Data where 1 dps = $2^{16}$
out	<i>accuracy</i>	Accuracy 0 being not accurate, and 3 being most accurate.
out	<i>timestamp</i>	The timestamp of the data sample.

##### 4.1.2.37 `inv_time_t inv_get_last_timestamp ( )`

Get last timestamp across all 3 sensors that are on.

This find out which timestamp has the largest value for sensors that are on.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

##### 4.1.2.38 `int inv_get_mag_accuracy ( void )`

Returns accuracy of compass.

##### Returns

Accuracy of compass with 0 being not accurate, and 3 being most accurate.

##### 4.1.2.39 `void inv_get_mpl_accel_bias ( long * bias, long * temp )`

Get Accel Bias.

##### Parameters

out	<i>bias</i>	Accel bias
out	<i>temp</i>	Temperature where 1 C = $2^{16}$

##### 4.1.2.40 `void inv_get_mpl_gyro_bias ( long * bias, long * temp )`

Get the mpl gyro biases.

##### Parameters

in	<i>bias</i>	Gyro calibrated bias. Length 3.
----	-------------	---------------------------------

#### 4.1.2.41 void inv\_get\_raw\_compass ( short \* raw )

Gets last value of raw compass data.

##### Parameters

out	raw	Raw compass data in mounting frame in hardware units. Length 3.
-----	-----	---

#### 4.1.2.42 void inv\_get\_temp\_set ( long \* data, int \* accuracy, inv\_time\_t \* timestamp )

Gets a whole set of temperature data including data, accuracy and timestamp.

##### Parameters

out	data	Temperature data where 1 degree C = 2 <sup>16</sup>
out	accuracy	0 to 3, where 3 is most accurate.
out	timestamp	The timestamp of the data sample.

#### 4.1.2.43 void inv\_gyro\_was\_turned\_off ( )

This should be called when the gyro has been turned off.

This is so that we will know if the data is contiguous.

#### 4.1.2.44 void inv\_quaternion\_sensor\_was\_turned\_off ( void )

This should be called when the quaternion data from the DMP has been turned off.

This is so that we will know if the data is contiguous.

#### 4.1.2.45 void inv\_set\_accel\_accuracy ( int accuracy )

Sets the accel accuracy.

##### Parameters

in	accuracy	Accuracy rating from 0 to 3, with 3 being most accurate.
----	----------	--

#### 4.1 data\_builder

19

##### 4.1.2.46 void inv\_set\_accel\_bandwidth ( int *bandwidth\_hz* )

Set Accel Bandwidth in Hz.

###### Parameters

in	<i>bandwidth_hz</i>	Gyro bandwidth in Hz
----	---------------------	----------------------

##### 4.1.2.47 void inv\_set\_accel\_bias ( const long \* *bias* )

Sets the factory accel bias.

###### Parameters

in	<i>bias</i>	Accel bias in hardware units (+/- 2 gee full scale assumed) scaled by 2 <sup>16</sup> . In chip mounting frame. Length of 3.
----	-------------	--

##### 4.1.2.48 void inv\_set\_accel\_bias\_mask ( const long \* *bias*, int *accuracy*, int *mask* )

Sets the accel bias with control over which axis.

###### Parameters

in	<i>bias</i>	Accel bias, length 3. In HW units scaled by 2 <sup>16</sup> in body frame
in	<i>accuracy</i>	Accuracy rating from 0 to 3, with 3 being most accurate.
in	<i>mask</i>	Mask to select axis to apply bias set.

##### 4.1.2.49 void inv\_set\_accel\_orientation\_and\_scale ( int *orientation*, long *sensitivity* )

Sets the orientation and sensitivity of the gyro data.

###### Parameters

in	<i>orientation</i>	A scalar defining the transformation from chip mounting to the body frame. The function <a href="#">inv_orientation_matrix_to_scalar()</a> can convert the transformation matrix to this scalar and describes the scalar in further detail.
in	<i>sensitivity</i>	A scale factor to convert device units to g's such that g's = device_units * sensitivity / 2 <sup>30</sup> . Typically it works out to be the maximum g_value * 2 <sup>15</sup> .

#### 4.1.2.50 void inv\_set\_accel\_sample\_rate ( long *sample\_rate\_us* )

Set Accel Sample rate in micro seconds.

##### Parameters

in	<i>sample_rate_us</i>	Set Accel Sample rate in us
----	-----------------------	-----------------------------

#### 4.1.2.51 void inv\_set\_compass\_bandwidth ( int *bandwidth\_hz* )

Set Compass Bandwidth in Hz.

##### Parameters

in	<i>bandwidth_hz</i>	Gyro bandwidth in Hz
----	---------------------	----------------------

#### 4.1.2.52 void inv\_set\_compass\_bias ( const long \* *bias*, int *accuracy* )

Sets the compass bias.

##### Parameters

in	<i>bias</i>	Length 3, in body frame, in hardware units scaled by $2^{16}$ to allow fractional bit correction.
in	<i>accuracy</i>	Accuracy of compass data, where 3=most accurate, and 0=least accurate.

#### 4.1.2.53 void inv\_set\_compass\_disturbance ( int *dist* )

Set the state of a compass disturbance.

##### Parameters

in	<i>dist</i>	1=disturbance, 0=no disturbance
----	-------------	---------------------------------

#### 4.1.2.54 void inv\_set\_compass\_orientation\_and\_scale ( int *orientation*, long *sensitivity* )

Sets the Orientation and Sensitivity of the gyro data.



## 4.1 data\_builder

21

### Parameters

in	<i>orientation</i>	A scalar defining the transformation from chip mounting to the body frame. The function <a href="#">inv_orientation_matrix_to_scalar()</a> can convert the transformation matrix to this scalar and describes the scalar in further detail.
in	<i>sensitivity</i>	A scale factor to convert device units to uT such that $uT = device\_units * sensitivity / 2^{30}$ . Typically it works out to be the maximum $uT\_value * 2^{15}$ .

### 4.1.2.55 void inv\_set\_compass\_sample\_rate ( long *sample\_rate\_us* )

Set Compass Sample rate in micro seconds.

### Parameters

in	<i>sample_rate_us</i>	Set Gyro Sample rate in micro seconds.
----	-----------------------	--

### 4.1.2.56 void inv\_set\_compass\_soft\_iron\_input\_data ( const long \* *data* )

This subroutine sets the compass raw data for the soft iron transformation.

### Parameters

<i>int*</i>	the pointer of the 3x1 vector compass raw data in MPL format
-------------	--

### 4.1.2.57 void inv\_set\_compass\_soft\_iron\_matrix\_d ( long \* *matrix* )

Sets the 3x3 compass transform matrix in 32 bit Q30 fixed point format.

### Parameters

in	<i>the</i>	pointer of the 3x3 matrix in Q30 format
----	------------	---

### 4.1.2.58 void inv\_set\_compass\_soft\_iron\_matrix\_f ( float \* *matrix* )

Sets the 3x3 compass transform matrix in 32 bit floating point format.

Parameters

in	the	pointer of the 3x3 matrix in floating point format
----	-----	--

4.1.2.59 void inv\_set\_gyro\_bandwidth ( int *bandwidth\_hz* )

Set Gyro Bandwidth in Hz.

Parameters

in	<i>bandwidth_hz</i>	Gyro bandwidth in Hz
----	---------------------	----------------------

4.1.2.60 void inv\_set\_gyro\_bias ( const long \* *bias* )

Sets the factory gyro bias.

Parameters

in	<i>bias</i>	Gyro bias in hardware units (+/- 2000 dps full scale assumed) scaled by $2^{16}$ . In chip mounting frame. Length of 3.
----	-------------	---

4.1.2.61 void inv\_set\_gyro\_orientation\_and\_scale ( int *orientation*, long *sensitivity* )

Sets the Orientation and Sensitivity of the gyro data.

Parameters

in	<i>orientation</i>	A scalar defining the transformation from chip mounting to the body frame. The function <a href="#">inv_orientation_matrix_to_scalar()</a> can convert the transformation matrix to this scalar and describes the scalar in further detail.
in	<i>sensitivity</i>	A scale factor to convert device units to degrees per second scaled by $2^{16}$ such that $\text{degrees\_per\_second} = \text{device\_units} * \text{sensitivity} / 2^{30}$ . Typically it works out to be the maximum rate * $2^{15}$ .

#### 4.1 data\_builder

23

##### 4.1.2.62 void inv\_set\_gyro\_sample\_rate ( long sample\_rate\_us )

Set Gyro Sample rate in micro seconds.

###### Parameters

in	sample_rate_us	Set Gyro Sample rate in us
----	----------------	----------------------------

##### 4.1.2.63 void inv\_set\_mpl\_gyro\_bias ( const long \* bias, int accuracy )

Sets the mpl gyro bias.

###### Parameters

in	bias	Gyro bias in hardware units scaled by $2^{16}$ (+/- 2000 dps full scale assumed). In chip mounting frame. Length 3.
in	accuracy	Accuracy of bias. 0 = least accurate, 3 = most accurate.

##### 4.1.2.64 void inv\_set\_quat\_sample\_rate ( long sample\_rate\_us )

Set Quat Sample rate in micro seconds.

###### Parameters

in	sample_rate_us	Set Quat Sample rate in us
----	----------------	----------------------------

##### 4.1.2.65 void inv\_temperature\_was\_turned\_off ( )

This should be called when the temperature sensor has been turned off.

This is so that we will know if the data is contiguous.

##### 4.1.2.66 void set\_sensor\_orientation\_and\_scale ( struct inv\_single\_sensor\_t \* sensor, int orientation, long sensitivity )

Sets orientation and sensitivity field for a sensor.



Parameters

out	<i>sensor</i>	Structure to apply settings to
in	<i>orientation</i>	Orientation description of how part is mounted.
in	<i>sensitivity</i>	A Scale factor to convert from hardware units to standard units (dps, uT, g).

## 4.2 hal\_outputs

25

## 4.2 hal\_outputs

Motion Library - HAL Outputs Sets up common outputs for HAL.

### Files

- file [hal\\_outputs.c](#)  
*HAL Outputs.*

### Functions

- `inv_error_t inv_disable_hal_outputs` (void)  
*Turns off creation and storage of HAL type results.*
- `inv_error_t inv_enable_hal_outputs` (void)  
*Turns on creation and storage of HAL type results.*
- `inv_error_t inv_generate_hal_outputs` (struct `inv_sensor_cal_t` \*`sensor_cal`)  
*Main callback to generate HAL outputs.*
- `int inv_get_sensor_type_accelerometer` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)  
*Acceleration ( $m/s^2$ ) in body frame.*
- `int inv_get_sensor_type_geomagnetic_rotation_vector` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)  
*This corresponds to Sensor.TYPE\_GEOMAGNETIC\_ROTATION\_VECTOR.*
- `int inv_get_sensor_type_gravity` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)  
*Gravity vector ( $m/s^2$ ) in Body Frame.*
- `int inv_get_sensor_type_gyroscope` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)  
*Gyroscope calibrated data (rad/s) in body frame.*
- `int inv_get_sensor_type_gyroscope_raw` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)  
*Gyroscope raw data (rad/s) in body frame.*
- `int inv_get_sensor_type_linear_acceleration` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)  
*Linear Acceleration ( $m/s^2$ ) in Body Frame.*
- `int inv_get_sensor_type_magnetic_field` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)  
*Compass data ( $\mu T$ ) in body frame.*
- `int inv_get_sensor_type_magnetic_field_raw` (float \*`values`, `int8_t` \*`accuracy`, `inv_time_t` \*`timestamp`)

*Compass raw data (uT) in body frame.*

- int `inv_get_sensor_type_orientation` (float \*values, int8\_t \*accuracy, inv\_time\_t \*timestamp)

*This corresponds to Sensor.TYPE\_ORIENTATION.*

- int `inv_get_sensor_type_rotation_vector` (float \*values, int8\_t \*accuracy, inv\_time\_t \*timestamp)

*This corresponds to Sensor.TYPE\_ROTATION\_VECTOR.*

- inv\_error\_t `inv_init_hal_outputs` (void)

*Initializes hal outputs class.*

- inv\_error\_t `inv_start_hal_outputs` (void)

*Turns on generation of HAL outputs.*

- inv\_error\_t `inv_stop_hal_outputs` (void)

*Turns off generation of HAL outputs.*

#### 4.2.1 Detailed Description

Motion Library - HAL Outputs Sets up common outputs for HAL.

#### 4.2.2 Function Documentation

##### 4.2.2.1 inv\_error\_t inv\_enable\_hal\_outputs ( void )

Turns on creation and storage of HAL type results.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

##### 4.2.2.2 inv\_error\_t inv\_generate\_hal\_outputs ( struct inv\_sensor\_cal\_t \* sensor\_cal )

Main callback to generate HAL outputs.

Typically not called by library users.

##### Parameters

in	<i>sensor_cal</i>	Input variable to take sensor data whenever there is new sensor data.
----	-------------------	---

**4.2 hal\_outputs****27****Returns**

Returns INV\_SUCCESS if successful or an error code if not.

**4.2.2.3** int inv\_get\_sensor\_type\_accelerometer ( float \* *values*, int8\_t \* *accuracy*,  
inv\_time\_t \* *timestamp* )

Acceleration (m/s<sup>2</sup>) in body frame.

**Parameters**

out	<i>values</i>	Acceleration in m/s <sup>2</sup> includes gravity. So while not in motion, it should return a vector of magnitude near 9.81 m/s <sup>2</sup>
out	<i>accuracy</i>	Accuracy of the measurment, 0 is least accurate, while 3 is most accurate.
out	<i>timestamp</i>	The timestamp for this sensor. Derived from the timestamp sent to <a href="#">inv_build_accel()</a> .

**Returns**

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.4** int inv\_get\_sensor\_type\_geomagnetic\_rotation\_vector ( float \* *values*,  
int8\_t \* *accuracy*, inv\_time\_t \* *timestamp* )

This corresponds to Sensor.TYPE\_GEOMAGNETIC\_ROTATION\_VECTOR.

Similar to SENSOR\_TYPE\_ROTATION\_VECTOR, but using a magnetometer instead of using a gyroscope. Fourth element = estimated\_accuracy in radians (heading confidence).

**Parameters**

out	<i>values</i>	Length 4.
out	<i>accuracy</i>	is not defined.
out	<i>timestamp</i>	in (ns) for Android.

**Returns**

Returns 1 if the data was updated, 0 otherwise.

**4.2.2.5** `int inv_get_sensor_type_gravity ( float * values, int8_t * accuracy,  
inv_time_t * timestamp )`

Gravity vector (m/s<sup>2</sup>) in Body Frame.

**Parameters**

out	<i>values</i>	Gravity vector in body frame, length 3, (m/s <sup>2</sup> )
out	<i>accuracy</i>	Accuracy of the measurment, 0 is least accurate, while 3 is most accurate.
out	<i>timestamp</i>	The timestamp for this sensor. Derived from the timestamp sent to <a href="#">inv_build_accel()</a> .

**Returns**

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.6** `int inv_get_sensor_type_gyroscope ( float * values, int8_t * accuracy,  
inv_time_t * timestamp )`

Gyroscope calibrated data (rad/s) in body frame.

**Parameters**

out	<i>values</i>	Rotation Rate in rad/sec.
out	<i>accuracy</i>	Accuracy of the measurment, 0 is least accurate, while 3 is most accurate.
out	<i>timestamp</i>	The timestamp for this sensor. Derived from the timestamp sent to <a href="#">inv_build_gyro()</a> .

**Returns**

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.7** `int inv_get_sensor_type_gyroscope_raw ( float * values, int8_t * accuracy,  
inv_time_t * timestamp )`

Gyroscope raw data (rad/s) in body frame.

**Parameters**

out	<i>values</i>	Rotation Rate in rad/sec.
out	<i>accuracy</i>	Accuracy of the measurment, 0 is least accurate, while 3 is most accurate.



## 4.2 hal\_outputs

29

out	<i>timestamp</i>	The timestamp for this sensor. Derived from the timestamp sent to <a href="#">inv_build_gyro()</a> .
-----	------------------	--

### Returns

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.8** int inv\_get\_sensor\_type\_linear\_acceleration ( float \* *values*, int8\_t \* *accuracy*, inv\_time\_t \* *timestamp* )

Linear Acceleration (m/s<sup>2</sup>) in Body Frame.

### Parameters

out	<i>values</i>	Linear Acceleration in body frame, length 3, (m/s <sup>2</sup> ). May show accel biases while at rest.
out	<i>accuracy</i>	Accuracy of the measurment, 0 is least accurate, while 3 is most accurate.
out	<i>timestamp</i>	The timestamp for this sensor. Derived from the timestamp sent to <a href="#">inv_build_accel()</a> .

### Returns

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.9** int inv\_get\_sensor\_type\_magnetic\_field ( float \* *values*, int8\_t \* *accuracy*, inv\_time\_t \* *timestamp* )

Compass data (uT) in body frame.

### Parameters

out	<i>values</i>	Compass data in (uT), length 3. May be calibrated by having biases removed and sensitivity adjusted
out	<i>accuracy</i>	Accuracy 0 to 3, 3 = most accurate
out	<i>timestamp</i>	Timestamp. In (ns) for Android.

### Returns

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.10** `int inv_get_sensor_type_magnetic_field_raw ( float * values, int8_t * accuracy, inv_time_t * timestamp )`

Compass raw data (uT) in body frame.

**Parameters**

out	<i>values</i>	Compass data in (uT), length 3. May be calibrated by having biases removed and sensitivity adjusted
out	<i>accuracy</i>	Accuracy 0 to 3, 3 = most accurate
out	<i>timestamp</i>	Timestamp. In (ns) for Android.

**Returns**

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.11** `int inv_get_sensor_type_orientation ( float * values, int8_t * accuracy, inv_time_t * timestamp )`

This corresponds to Sensor.TYPE\_ORIENTATION.

All values are angles in degrees.

**Parameters**

out	<i>values</i>	Length 3, Degrees. <ul style="list-style-type: none"><li>• values[0]: Azimuth, angle between the magnetic north direction and the y-axis, around the z-axis (0 to 359). 0=North, 90=East, 180=South, 270=West</li><li>• values[1]: Pitch, rotation around x-axis (-180 to 180), with positive values when the z-axis moves toward the y-axis.</li><li>• values[2]: Roll, rotation around y-axis (-90 to 90), with positive values when the x-axis moves toward the z-axis.</li></ul>
-----	---------------	--

**Note**

This definition is different from yaw, pitch and roll used in aviation where the X axis is along the long side of the plane (tail to nose). Note: This sensor type exists for legacy reasons, please use getRotationMatrix() in conjunction with remapCoordinateSystem() and getOrientation() to compute these values instead. Important note: For historical reasons the roll angle is positive in the clockwise direction

## 4.2 hal\_outputs

31

(mathematically speaking, it should be positive in the counter-clockwise direction).

### Parameters

out	<i>accuracy</i>	Accuracy of the measurment, 0 is least accurate, while 3 is most accurate.
out	<i>timestamp</i>	The timestamp for this sensor.

### Returns

Returns 1 if the data was updated or 0 if it was not updated.

**4.2.2.12** `int inv_get_sensor_type_rotation_vector ( float * values, int8_t * accuracy, inv_time_t * timestamp )`

This corresponds to Sensor.TYPE\_ROTATION\_VECTOR.

The rotation vector represents the orientation of the device as a combination of an angle and an axis, in which the device has rotated through an angle  $\theta$  around an axis {x, y, z}.

The three elements of the rotation vector are { $x \cdot \sin(\theta/2)$ ,  $y \cdot \sin(\theta/2)$ ,  $z \cdot \sin(\theta/2)$ }, such that the magnitude of the rotation vector is equal to  $\sin(\theta/2)$ , and the direction of the rotation vector is equal to the direction of the axis of rotation.

The three elements of the rotation vector are equal to the last three components of a unit quaternion { $x \cdot \sin(\theta/2)$ ,  $y \cdot \sin(\theta/2)$ ,  $z \cdot \sin(\theta/2)$ }. The 4th element is  $\cos(\theta/2)$ .

Elements of the rotation vector are unitless. The x,y and z axis are defined in the same way as the acceleration sensor. The reference coordinate system is defined as a direct orthonormal basis, where:

-X is defined as the vector product Y.Z (It is tangential to the ground at the device's current location and roughly points East). -Y is tangential to the ground at the device's current location and points towards the magnetic North Pole. -Z points towards the sky and is perpendicular to the ground.

### Parameters

out	<i>values</i>	Length 5, 4th element being the w angle of the originating 4 elements quaternion and 5th element being the heading accuracy at 95%.
out	<i>accuracy</i>	Accuracy is not defined
out	<i>timestamp</i>	Timestamp. In (ns) for Android.

#### Returns

Returns 1 if the data was updated or 0 if it was not updated.

#### 4.2.2.13 `inv_error_t inv_init_hal_outputs ( void )`

Initializes hal outputs class.

This is called automatically by the enable function. It may be called any time the feature is enabled, but is typically not needed to be called by outside callers.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.2.2.14 `inv_error_t inv_start_hal_outputs ( void )`

Turns on generation of HAL outputs.

This should be called after [inv\\_stop\\_hal\\_outputs\(\)](#) to turn generation of HAL outputs back on. It is automatically called by [inv\\_enable\\_hal\\_outputs\(\)](#).

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.2.2.15 `inv_error_t inv_stop_hal_outputs ( void )`

Turns off generation of HAL outputs.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.3 ml\_math\_func

33

### 4.3 ml\_math\_func

Motion Library - Math Functions Common math functions the Motion Library.

#### Files

- file [ml\\_math\\_func.c](#)  
*Math Functions.*

#### Functions

- int [get\\_highest\\_bit\\_position](#) (unsigned long \*value)  
*Auxiliary function used by testLimitsAndScale() Find the highest nonzero bit in an unsigned 32 bit integer:*
- float [inv\\_angle\\_diff](#) (float ang1, float ang2)  
*Finds the minimum angle difference ang1-ang2 such that difference is between [-M\_PI, M\_PI].*
- short [inv\\_big8\\_to\\_int16](#) (const unsigned char \*big8)  
*Converts a big endian byte stream into a 16-bit integer (short)*
- long [inv\\_big8\\_to\\_int32](#) (const unsigned char \*big8)  
*Converts a big endian byte stream into a 32-bit long.*
- uint32\_t [inv\\_checksum](#) (const unsigned char \*str, int len)  
*bernstein hash, derived from public domain source*
- void [inv\\_convert\\_to\\_body](#) (unsigned short orientation, const long \*input, long \*output)  
*Uses the scalar orientation value to convert from chip frame to body frame.*
- void [inv\\_convert\\_to\\_body\\_with\\_scale](#) (unsigned short orientation, long sensitivity, const long \*input, long \*output)  
*Uses the scalar orientation value to convert from chip frame to body frame and apply appropriate scaling.*
- void [inv\\_convert\\_to\\_chip](#) (unsigned short orientation, const long \*input, long \*output)  
*Uses the scalar orientation value to convert from body frame to chip frame.*
- long [inv\\_fast\\_sqrt](#) (long x0)  
*Calculates square-root of a fixed-point number (30 bit mantissa, positive) Input must be a positive scaled ( $2^{30}$ ) integer The number is scaled to lie between a range in which a Newton-Raphson iteration works best.*
- unsigned long [inv\\_get\\_gyro\\_sum\\_of\\_sqr](#) (const long \*gyro)  
*The gyro data magnitude squared :  $(1 \text{ degree per second})^2 = 2^6 = 2^6 \text{ GYRO\_MAG\_SQR\_SHIFT}$ .*
- unsigned char \* [inv\\_int16\\_to\\_big8](#) (short x, unsigned char \*big8)

*Converts a 16-bit short to a big endian byte stream.*

- unsigned char \* [inv\\_int32\\_to\\_big8](#) (long x, unsigned char \*big8)

*Converts a 32-bit long to a big endian byte stream.*

- long [inv\\_inverse\\_sqrt](#) (long x0, int \*rempow)

*Calculates 1/square-root of a fixed-point number (30 bit mantissa, positive): Q1.30  
Input must be a positive scaled ( $2^{30}$ ) integer The number is scaled to lie between a range in which a Newton-Raphson iteration works best.*

- short [inv\\_little8\\_to\\_int16](#) (const unsigned char \*little8)

*Converts a little endian byte stream into a 16-bit integer (short)*

- long [inv\\_one\\_over\\_x](#) (long x0, int \*pow)

*Calculates 1/x of a fixed-point number (30 bit mantissa) Input must be a scaled ( $2^{30}$ ) integer (+/-) The number is scaled to lie between a range in which a Newton-Raphson iteration works best.*

- unsigned short [inv\\_orientation\\_matrix\\_to\\_scalar](#) (const signed char \*mtx)

*Converts an orientation matrix made up of 0,+1,and -1 to a scalar representation.*

- long [inv\\_q29\\_mult](#) (long a, long b)

*Performs a multiply and shift by 29.*

- long [inv\\_q30\\_mult](#) (long a, long b)

*Performs a multiply and shift by 30.*

- void [inv\\_q\\_add](#) (long \*q1, long \*q2, long \*qSum)

*Performs a fixed point quaternion addition.*

- void [inv\\_q\\_mult](#) (const long \*q1, const long \*q2, long \*qProd)

*Performs a fixed point quaternion multiply.*

- void [inv\\_q\\_norm4](#) (float \*q)

*Performs a length 4 vector normalization with a square root.*

- void [inv\\_q\\_rotate](#) (const long \*q, const long \*in, long \*out)

*Rotates a 3-element vector by Rotation defined by Q.*

- long [inv\\_q\\_shift\\_mult](#) (long a, long b, int shift)

*Performs a multiply and shift by shift.*

- void [inv\\_quaternion\\_to\\_rotation](#) (const long \*quat, long \*rot)

*Converts a quaternion to a rotation matrix.*

- void [inv\\_quaternion\\_to\\_rotation\\_vector](#) (const long \*quat, long \*rot)

*Converts a quaternion to a rotation vector.*

- double [inv\\_vector\\_norm](#) (const float \*x)

*find a norm for a vector*

- float [inv\\_wrap\\_angle](#) (float ang)

*Wraps angle from (-M\_PI,M\_PI].*

- int [test\\_limits\\_and\\_scale](#) (long \*x0, int \*pow)

*Auxiliary function used by [inv\\_OneOverX\(\)](#), [inv\\_fastSquareRoot\(\)](#), [inv\\_inverseSqrt\(\)](#).*

## 4.3 ml\_math\_func

35

### 4.3.1 Detailed Description

Motion Library - Math Functions Common math functions the Motion Library.

### 4.3.2 Function Documentation

#### 4.3.2.1 int get\_highest\_bit\_position ( unsigned long \* value )

Auxiliary function used by testLimitsAndScale() Find the highest nonzero bit in an unsigned 32 bit integer:

##### Parameters

in	value,length	1.
----	--------------	----

##### Returns

highes bit position.

#### 4.3.2.2 float inv\_angle\_diff( float ang1, float ang2 )

Finds the minimum angle difference ang1-ang2 such that difference is between [-M\_PI,M\_PI].

##### Parameters

in	ang1	
in	ang2	

##### Returns

angle difference ang1-ang2

#### 4.3.2.3 void inv\_convert\_to\_body ( unsigned short orientation, const long \* input, long \* output )

Uses the scalar orientation value to convert from chip frame to body frame.

##### Parameters

in	orientation	A scalar that represent how to go from chip to body frame
in	input	Input vector, length 3
out	output	Output vector, length 3

Generated on Wed Nov 27 2013 16:25:55 for MLSDK by Doxygen

**4.3.2.4 void inv\_convert\_to\_body\_with\_scale ( unsigned short *orientation*, long *sensitivity*, const long \* *input*, long \* *output* )**

Uses the scalar orientation value to convert from chip frame to body frame and apply appropriate scaling.

**Parameters**

in	<i>orientation</i>	A scalar that represent how to go from chip to body frame
in	<i>sensitivity</i>	Sensitivity scale
in	<i>input</i>	Input vector, length 3
out	<i>output</i>	Output vector, length 3

**4.3.2.5 void inv\_convert\_to\_chip ( unsigned short *orientation*, const long \* *input*, long \* *output* )**

Uses the scalar orientation value to convert from body frame to chip frame.

**Parameters**

in	<i>orientation</i>	A scalar that represent how to go from chip to body frame
in	<i>input</i>	Input vector, length 3
out	<i>output</i>	Output vector, length 3

**4.3.2.6 long inv\_fast\_sqrt ( long *x0* )**

Calculates square-root of a fixed-point number (30 bit mantissa, positive) Input must be a positive scaled ( $2^{30}$ ) integer The number is scaled to lie between a range in which a Newton-Raphson iteration works best.

**Parameters**

in	<i>x0,length</i>	1
----	------------------	---

**Returns**

scaledSquareRoot on success or zero.

**4.3.2.7 unsigned long inv\_get\_gyro\_sum\_of\_sqr ( const long \* *gyro* )**

The gyro data magnitude squared :  $(1 \text{ degree per second})^2 = 2^6 = 2^{\text{GYRO\_MA-G\_SQR\_SHIFT}}$ .



**4.3 ml\_math\_func****37****Parameters**

in	<i>gyro</i>	Gyro data scaled with 1 dps = $2^{16}$
----	-------------	--

**Returns**

the computed magnitude squared output of the gyroscope.

**4.3.2.8 long inv\_inverse\_sqrt ( long x0, int \* rempow )**

Calculates 1/square-root of a fixed-point number (30 bit mantissa, positive): Q1.30 - Input must be a positive scaled ( $2^{30}$ ) integer The number is scaled to lie between a range in which a Newton-Raphson iteration works best.

Corresponding square root of the power of two is returned. Caller must scale final result by  $2^{\text{rempow}}$  (while avoiding overflow).

**Parameters**

in	<i>x0,length</i>	1
out	<i>rem-pow,length</i>	1

**Returns**

scaledSquareRoot on success or zero.

**4.3.2.9 long inv\_one\_over\_x ( long x0, int \* pow )**

Calculates 1/x of a fixed-point number (30 bit mantissa) Input must be a scaled ( $2^{30}$ ) integer (+/-) The number is scaled to lie between a range in which a Newton-Raphson iteration works best.

Corresponding multiplier power of two is returned. Caller must scale final result by  $2^{\text{pow}}$  (while avoiding overflow).

**Parameters**

in	<i>x,length</i>	1
out	<i>pow,length</i>	1

**Returns**

scaledOneOverX on success or zero.

#### 4.3.2.10 unsigned short inv\_orientation\_matrix\_to\_scalar ( const signed char \* mtx )

Converts an orientation matrix made up of 0,+1,and -1 to a scalar representation.

##### Parameters

in	mtx	Orientation matrix to convert to a scalar.
----	-----	--

##### Returns

Description of orientation matrix. The lowest 2 bits (0 and 1) represent the column the one is on for the first row, with the bit number 2 being the sign. The next 2 bits (3 and 4) represent the column the one is on for the second row with bit number 5 being the sign. The next 2 bits (6 and 7) represent the column the one is on for the third row with bit number 8 being the sign. In binary the identity matrix would therefor be: 010\_001\_000 or 0x88 in hex.

#### 4.3.2.11 long inv\_q29\_mult ( long a, long b )

Performs a multiply and shift by 29.

These are good functions to write in assembly on with devices with small memory where you want to get rid of the long long which some assemblers don't handle well

##### Parameters

in	a	
in	b	

##### Returns

((long long)a\*b)>>29

#### 4.3.2.12 long inv\_q30\_mult ( long a, long b )

Performs a multiply and shift by 30.

These are good functions to write in assembly on with devices with small memory where you want to get rid of the long long which some assemblers don't handle well

##### Parameters

in	a	
in	b	

#### 4.3 ml\_math\_func

39

##### Returns

((long long)a\*b)>>30

##### 4.3.2.13 void inv\_q\_add ( long \* q1, long \* q2, long \* qSum )

Performs a fixed point quaternion addition.

##### Parameters

in	q1	First Quaternion term, length 4. 1.0 scaled to 2 <sup>30</sup>
in	q2	Second Quaternion term, length 4. 1.0 scaled to 2 <sup>30</sup>
out	qSum	Sum after quaternion summation. Length 4. 1.0 scaled to 2 <sup>30</sup> .

##### 4.3.2.14 void inv\_q\_mult ( const long \* q1, const long \* q2, long \* qProd )

Performs a fixed point quaternion multiply.

##### Parameters

in	q1	First Quaternion Multicand, length 4. 1.0 scaled to 2 <sup>30</sup>
in	q2	Second Quaternion Multicand, length 4. 1.0 scaled to 2 <sup>30</sup>
out	qProd	Product after quaternion multiply. Length 4. 1.0 scaled to 2 <sup>30</sup> .

##### 4.3.2.15 void inv\_q\_norm4 ( float \* q )

Performs a length 4 vector normalization with a square root.

##### Parameters

in, out	q	vector to normalize. Returns [1,0,0,0] if magnitude is zero.
---------	---	--

##### 4.3.2.16 long inv\_q\_shift\_mult ( long a, long b, int shift )

Performs a multiply and shift by shift.

These are good functions to write in assembly on with devices with small memory where you want to get rid of the long long which some assemblers don't handle well

#### Parameters

in	<i>a</i>	First multicand
in	<i>b</i>	Second multicand
in	<i>shift</i>	Shift amount after multiplying

#### Returns

((long long)a\*b)<<shift

#### 4.3.2.17 void inv\_quaternion\_to\_rotation ( const long \* *quat*, long \* *rot* )

Converts a quaternion to a rotation matrix.

#### Parameters

in	<i>quat</i>	4-element quaternion in fixed point. One is $2^{30}$ .
out	<i>rot</i>	Rotation matrix in fixed point. One is $2^{30}$ . The First 3 elements of the rotation matrix, represent the first row of the matrix. Rotation matrix multiplied by a 3 element column vector transform a vector from Body to World.

#### 4.3.2.18 void inv\_quaternion\_to\_rotation\_vector ( const long \* *quat*, long \* *rot* )

Converts a quaternion to a rotation vector.

A rotation vector is a method to represent a 4-element quaternion vector in 3-elements. To get the quaternion from the 3-elements, The last 3-elements of the quaternion will be the given rotation vector. The first element of the quaternion will be the positive value that will be required to make the magnitude of the quaternion 1.0 or  $2^{30}$  in fixed point units.

#### Parameters

in	<i>quat</i>	4-element quaternion in fixed point. One is $2^{30}$ .
out	<i>rot</i>	Rotation vector in fixed point. One is $2^{30}$ .

#### 4.3.2.19 double inv\_vector\_norm ( const float \* *x* )

find a norm for a vector

#### 4.3 ml\_math\_func

41

##### Parameters

in	<i>a</i>	vector [3x1]
out	<i>output</i>	the norm of the input vector

##### 4.3.2.20 float inv\_wrap\_angle ( float *ang* )

Wraps angle from (-M\_PI,M\_PI].

##### Parameters

in	<i>ang</i>	Angle in radians to wrap
----	------------	--------------------------

##### Returns

Wrapped angle from (-M\_PI,M\_PI]

##### 4.3.2.21 int test\_limits\_and\_scale ( long \* *x0*, int \* *pow* )

Auxiliary function used by inv\_OneOverX(), inv\_fastSquareRoot(), inv\_inverseSqrt().

Finds the range of the argument, determines the optimal number of Newton-Raphson iterations and . Corresponding square root of the power of two is returned. Restrictions: Number is represented as Q1.30. Number is between the range  $2 < x \leq 0$

##### Parameters

in	<i>x,length</i>	1
out	<i>pow,length</i>	1

##### Returns

# of NR iterations, *x0* scaled between log(2) and log(4) and  $2^N$  scaling ( $N=pow$ )

## 4.4 message\_layer

Motion Library - Message Layer Holds Low Occurance messages.

### Files

- file [message\\_layer.c](#)  
*Holds Low Occurance Messages.*

### Functions

- long [inv\\_get\\_message\\_level\\_0](#) (int clear)  
*Returns Message Flags for Level 0 Messages.*
- void [inv\\_set\\_message](#) (long set, long clear, int level)  
*Sets a message.*

#### 4.4.1 Detailed Description

Motion Library - Message Layer Holds Low Occurance messages.

#### 4.4.2 Function Documentation

##### 4.4.2.1 long [inv\\_get\\_message\\_level\\_0](#) ( int *clear* )

Returns Message Flags for Level 0 Messages.

Levels are to allow expansion of more messages in the future.

##### Parameters

in	<i>clear</i>	If set, will clear the message. Typically this will be set for one reader, so that you don't get the same message over and over.
----	--------------	--

##### Returns

bit field to corresponding message.

##### 4.4.2.2 void [inv\\_set\\_message](#) ( long *set*, long *clear*, int *level* )

Sets a message.



#### 4.4 message\_layer

43

##### Parameters

in	<i>set</i>	The flags to set.
in	<i>clear</i>	Before setting anything this will clear these messages, which is useful for mutually exclusive messages such a motion or no motion message.
in	<i>level</i>	Level of the messages. It starts at 0, and may increase in the future to allow more messages if the bit storage runs out.

## 4.5 mpl

Motion Library - Start Point Initializes MPL.

### Files

- file [mpl.c](#)  
*MPL start point.*
- file [quaternion\\_supervisor.c](#)  
*Performs the quaternion fusion.*

### Functions

- `inv_error_t inv_disable_quaternion (void)`  
*Disables generating the gyro and accel quaternion.*
- `inv_error_t inv_enable_quaternion ()`  
*Turns on quaternion computation.*
- `inv_error_t inv_get_version (char **version)`  
*used to get the MPL version.*
- `inv_error_t inv_init_mpl (void)`  
*Initializes the MPL.*
- `inv_error_t inv_init_quaternion (void)`  
*Initializes all quaternion data.*
- `void inv_set_quaternion (long *quat)`  
*Set the quaternion to the given value.*
- `inv_error_t inv_start_mpl (void)`  
*Starts the MPL.*
- `inv_error_t inv_start_quaternion (void)`  
*Starts gyro and accel quaternion generation.*
- `inv_error_t inv_stop_quaternion (void)`  
*Stops gyro and accel quaternion generation.*
- `int inv_verify_6x_fusion_data (float *data)`  
*Verify that the 6-axis quaternion data is correctedly encrypted.*

#### 4.5.1 Detailed Description

Motion Library - Start Point Initializes MPL. Motion Library Example Architecture.



## 4.5 mpl

45

### 4.5.2 Function Documentation

#### 4.5.2.1 `inv_error_t inv_enable_quaternion ( )`

Turns on quaternion computation.

This must be called after `inv_init_mpl()` and before `inv_start_mpl()`. It is typically only called once per session. `inv_start_quaternion()` and `inv_stop_quaternion()` are used to start and stop this feature. This feature is started automatically and `inv_start_quaternion()` would only need to be called after turning this feature off with `inv_stop_quaternion()`.

##### Returns

INV\_SUCCESS=0 on success, a non-zero error code otherwise.

#### 4.5.2.2 `inv_error_t inv_get_version ( char ** version )`

used to get the MPL version.

##### Parameters

<i>version</i>	a string where the MPL version gets stored.
----------------	---

##### Returns

INV\_SUCCESS if successful or a non-zero error code otherwise.

#### 4.5.2.3 `inv_error_t inv_init_mpl ( void )`

Initializes the MPL.

Should be called first and once

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.5.2.4 `inv_error_t inv_init_quaternion ( void )`

Initializes all quaternion data.

This is called automatically by the enable function. It may be called any time the feature is enabled, but is typically not needed to be called by outside callers.

#### Returns

INV\_SUCCESS=0 on success, a non-zero error code otherwise.

#### 4.5.2.5 void inv\_set\_quaternion ( long \* quat )

Set the quaternion to the given value.

#### Parameters

in	quat	What to set quaternion to. Fixed point scaled by $2^{30}$ , - Length 4.
----	------	---

#### 4.5.2.6 inv\_error\_t inv\_start\_mpl ( void )

Starts the MPL.

Typically called after [inv\\_init\\_mpl\(\)](#) or after a [inv\\_stop\\_mpl\(\)](#) to start the MPL back up an running.

#### Returns

INV\_SUCCESS if successful or a non-zero error code otherwise.

#### 4.5.2.7 inv\_error\_t inv\_start\_quaternion ( void )

Starts gyro and accel quaternion generation.

Automatically called by [inv\\_enable\\_quaternion\(\)](#) and therefor would only need to be called after [inv\\_stop\\_quaternion\(\)](#).

#### Returns

INV\_SUCCESS=0 on success, a non-zero error code otherwise.

#### 4.5.2.8 inv\_error\_t inv\_stop\_quaternion ( void )

Stops gyro and accel quaternion generation.

Call [inv\\_start\\_quaternion\(\)](#) to turn this back on after the stop command.

#### Returns

INV\_SUCCESS=0 on success, a non-zero error code otherwise.

#### 4.5 mpl

47

##### 4.5.2.9 int inv\_verify\_6x\_fusion\_data ( float \* data )

Verify that the 6-axis quaternion data is correctedly encrypted.

##### Parameters

in	data	Quaternion data to be compared with our version stored internally. If encrypted correctly, return 1. If no DMP is used in the 6-axis quaternion, return 2. If encrypted incorrectly, return 0. If quaternion data is identity, return -1.
----	------	---

## 4.6 results\_holder

Motion Library - Results Holder Holds the data for MPL.

### Files

- file [results\\_holder.c](#)  
*Results Holder for HAL.*

### Functions

- `inv_error_t inv_enable_results_holder ()`  
*Turns on storage of results.*
- `inv_error_t inv_generate_results (struct inv_sensor_cal_t *sensor_cal)`  
*Callback that gets called everytime there is new data.*
- `inv_error_t inv_get_6axis_quaternion (long *data, inv_time_t *timestamp)`  
*Returns a quaternion based only on gyro and accel.*
- `inv_error_t inv_get_6axis_quaternion_float (float *data, inv_time_t *timestamp)`  
*Returns a quaternion based only on gyro and accel.*
- `int inv_get_acc_state ()`  
*Gets the accel state set by [inv\\_set\\_acc\\_state\(\)](#)*
- `inv_error_t inv_get_accel (long *data)`  
*Returns 3-element vector of accelerometer data in body frame.*
- `float inv_get_accel_compass_confidence_interval (void)`  
*Get 6 axis (accel and compass) 95% heading confidence interval for quaternion.*
- `inv_error_t inv_get_accel_float (float *data)`  
*Returns 3-element vector of accelerometer float data.*
- `inv_error_t inv_get_accel_quaternion (long *data)`  
*Returns a quaternion based only on accel.*
- `void inv_get_compass_bias_error (long *bias_error)`  
*Get's compass bias error.*
- `int inv_get_compass_state ()`  
*Get's the compass state.*
- `void inv_get_earth_magnetic_local_field_parameter (struct local_field_t *parameters)`  
*Returns the parameters of earth magnetic field local field.*
- `inv_error_t inv_get_geomagnetic_quaternion (long *data, inv_time_t *timestamp)`  
*Returns a quaternion based only on compass and accel.*

#### 4.6 results\_holder

49

- `inv_error_t inv_get_geomagnetic_quaternion_float` (float \*data, inv\_time\_t \*timestamp)

*Returns a quaternion based only on compass and accel.*

- `inv_error_t inv_get_gravity` (long \*data)

*Gets gravity vector.*

- `inv_error_t inv_get_gyro_float` (float \*data)

*Returns 3-element vector of gyro float data.*

- `float inv_get_heading_confidence_interval` (void)

*Get 9 axis 95% heading confidence interval for quaternion.*

- `int inv_get_large_mag_field` ()

*Returns non-zero if there is a large magnetic field.*

- `inv_error_t inv_get_linear_accel` (long \*data)

*Returns 3-element vector of accelerometer data in body frame with gravity removed.*

- `inv_error_t inv_get_linear_accel_float` (float \*data)

*Returns 3-element vector of linear accel float data.*

- `enum compass_local_field_e inv_get_local_field_status` (void)

*Returns the status of earth magnetic field local field parameters.*

- `void inv_get_mag_scale` (long \*data)

*Gets the compass sensitivity.*

- `int inv_get_motion_state` (unsigned int \*cntr)

*Returns the motion state.*

- `enum compass_local_field_e inv_get_mpl_mag_field_status` (void)

*Returns the status of mpl calibrated magnetic field local field parameters.*

- `void inv_get_mpl_magnetic_local_field_parameter` (struct local\_field\_t \*parameters)

*Returns the parameters of mpl calibrated magnetic field local field.*

- `inv_error_t inv_get_quaternion` (long \*data)

*Returns a quaternion.*

- `inv_error_t inv_get_quaternion_float` (float \*data)

*Returns a quaternion.*

- `void inv_get_quaternion_set` (long \*data, int \*accuracy, inv\_time\_t \*timestamp)

*Returns a quaternion with accuracy and timestamp.*

- `inv_error_t inv_get_quaternion_validity` (int \*value)

*Returns the status of the authenticity of the quaternion data.*

- `inv_error_t inv_get_result_holder_status` (long \*rh\_status)

*Returns the status of the result holder.*

- `int inv_get_accel_bias` ()

*Sets state of if we know the accel bias.*

- `int inv_get_compass_bias` ()

*Sets state of if we know the compass bias.*

- `inv_error_t inv_init_results_holder` (void)

*Initializes results holder.*

- `void inv_set_acc_state` (int state)

*Sets the accel state.*

- `void inv_set_accel_bias_found` (int state)

*Sets whether we know the accel bias.*

- `void inv_set_accel_compass_confidence_interval` (float ci)

*Set 6 axis (accel and compass) 95% heading confidence interval for quaternion.*

- `void inv_set_compass_bias_error` (const long \*bias\_error)

*Set compass bias error.*

- `void inv_set_compass_bias_found` (int state)

*Sets whether we know the compass bias.*

- `void inv_set_compass_state` (int state)

*Sets the compass state.*

- `void inv_set_earth_magnetic_local_field_parameter` (struct local\_field\_t \*parameters)

*Set the parameters of earth magnetic field local field.*

- `void inv_set_heading_confidence_interval` (float ci)

*Set 9 axis 95% heading confidence interval for quaternion.*

- `void inv_set_large_mag_field` (int state)

*Set to non-zero if there as a large magnetic field.*

- `void inv_set_local_field_status` (enum compass\_local\_field\_e status)

*Set the status of earth magnetic field local field parameters.*

- `inv_error_t inv_set_local_magnetic_field` (float intensity, float inclination, float declination)

*Set the magnetic field local field struct object.*

- `void inv_set_mag_scale` (const long \*data)

*Sets the compass sensitivity.*

- `void inv_set_motion_state` (unsigned char state)

*Sets the motion state.*

- `void inv_set_mpl_mag_field_status` (enum compass\_local\_field\_e status)

*Set the status of mpl calibrated magnetic field local field parameters.*

- `inv_error_t inv_set_mpl_magnetic_local_field_parameter` (struct local\_field\_t \*parameters)

*Set the parameters of mpl calibrated magnetic field local field This API is used by mpl only.*

- `inv_error_t inv_set_quaternion_validity` (int value)

*Set the status of the authenticity of the quaternion data.*

- `inv_error_t inv_set_result_holder_status` (long rh\_status)

## 4.6 results\_holder

51

*Set the status of the result holder.*

- `inv_error_t inv_start_results_holder (void)`

*Function to turn on this module.*

### 4.6.1 Detailed Description

Motion Library - Results Holder Holds the data for MPL.

### 4.6.2 Function Documentation

#### 4.6.2.1 `inv_error_t inv_generate_results ( struct inv_sensor_cal_t * sensor_cal )`

Callback that gets called everytime there is new data.

It is registered by `inv_start_results_holder()`.

##### Parameters

in	<i>sensor_cal</i>	New sensor data to process.
----	-------------------	-----------------------------

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.2 `inv_error_t inv_get_6axis_quaternion ( long * data, inv_time_t * timestamp )`

Returns a quaternion based only on gyro and accel.

##### Parameters

out	<i>data</i>	6-axis gyro and accel quaternion scaled such that $1.0 = 2^{30}$ .
-----	-------------	--

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.3 `inv_error_t inv_get_6axis_quaternion_float ( float * data, inv_time_t * timestamp )`

Returns a quaternion based only on gyro and accel.

#### Parameters

out	data	6-axis gyro and accel quaternion.
-----	------	-----------------------------------

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.4 int inv\_get\_acc\_state ( )

Gets the accel state set by [inv\\_set\\_acc\\_state\(\)](#)

#### Returns

accel state.

#### 4.6.2.5 inv\_error\_t inv\_get\_accel ( long \* data )

Returns 3-element vector of accelerometer data in body frame.

#### Parameters

out	data	3-element vector of accelerometer data in body frame
-----	------	--

#### Returns

INV\_SUCCESS if successful INV\_ERROR\_INVALID\_PARAMETER if invalid input pointer

#### 4.6.2.6 float inv\_get\_accel\_compass\_confidence\_interval ( void )

Get 6 axis (accel and compass) 95% heading confidence interval for quaternion.

#### Returns

Confidence interval in radians.

#### 4.6.2.7 inv\_error\_t inv\_get\_accel\_float ( float \* data )

Returns 3-element vector of accelerometer float data.



## 4.6 results\_holder

53

### Parameters

out	<i>data</i>	3-element vector of accelerometer float data
-----	-------------	--

### Returns

INV\_SUCCESS if successful INV\_ERROR\_INVALID\_PARAMETER if invalid input pointer

#### 4.6.2.8 `inv_error_t inv_get_accel_quaternion ( long * data )`

Returns a quaternion based only on accel.

### Parameters

out	<i>data</i>	3-axis accel quaternion scaled such that $1.0 = 2^{30}$ .
-----	-------------	---

### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.9 `void inv_get_compass_bias_error ( long * bias_error )`

Get's compass bias error.

See [inv\\_set\\_compass\\_bias\\_error\(\)](#) for setting.

### Parameters

out	<i>bias_error</i>	Accuracy as to how well the compass bias is known. It is the error squared.
-----	-------------------	---

#### 4.6.2.10 `int inv_get_compass_state ( )`

Get's the compass state.

### Returns

the compass state that was set with [inv\\_set\\_compass\\_state\(\)](#)

4.6.2.11 `void inv_get_earth_magnetic_local_field_parameter ( struct local_field_t * parameters )`

Returns the parameters of earth magnetic field local field.

**Parameters**

out	the	parameters of earth magnetic field local field
-----	-----	--

**Returns**

N/A

4.6.2.12 `inv_error_t inv_get_geomagnetic_quaternion ( long * data, inv_time_t * timestamp )`

Returns a quaternion based only on compass and accel.

**Parameters**

out	data	6-axis compass and accel quaternion scaled such that $1.0 = 2^{30}$ .
-----	------	---

**Returns**

Returns INV\_SUCCESS if successful or an error code if not.

4.6.2.13 `inv_error_t inv_get_geomagnetic_quaternion_float ( float * data, inv_time_t * timestamp )`

Returns a quaternion based only on compass and accel.

**Parameters**

out	data	6-axis compass and accel quaternion.
-----	------	--------------------------------------

**Returns**

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6 results\_holder

55

##### 4.6.2.14 `inv_error_t inv_get_gravity ( long * data )`

Gets gravity vector.

###### Parameters

out	data	gravity vector in body frame scaled such that $1.0 = 2^{30}$ .
-----	------	--

###### Returns

Returns INV\_SUCCESS if successful or an error code if not.

##### 4.6.2.15 `inv_error_t inv_get_gyro_float ( float * data )`

Returns 3-element vector of gyro float data.

###### Parameters

out	data	3-element vector of gyro float data
-----	------	-------------------------------------

###### Returns

INV\_SUCCESS if successful INV\_ERROR\_INVALID\_PARAMETER if invalid input pointer

##### 4.6.2.16 `float inv_get_heading_confidence_interval ( void )`

Get 9 axis 95% heading confidence interval for quaternion.

###### Returns

Confidence interval in radians.

##### 4.6.2.17 `int inv_get_large_mag_field ( )`

Returns non-zero if there is a large magnetic field.

See [inv\\_set\\_large\\_mag\\_field\(\)](#) for setting this variable.

###### Returns

Returns non-zero if there is a large magnetic field.

#### 4.6.2.18 `inv_error_t inv_get_linear_accel ( long * data )`

Returns 3-element vector of accelerometer data in body frame with gravity removed.

##### Parameters

out	data	3-element vector of accelerometer data in body frame with gravity removed
-----	------	---

##### Returns

INV\_SUCCESS if successful INV\_ERROR\_INVALID\_PARAMETER if invalid input pointer

#### 4.6.2.19 `inv_error_t inv_get_linear_accel_float ( float * data )`

Returns 3-element vector of linear accel float data.

##### Parameters

out	data	3-element vector of linear accel float data
-----	------	---

##### Returns

INV\_SUCCESS if successful INV\_ERROR\_INVALID\_PARAMETER if invalid input pointer

#### 4.6.2.20 `enum compass_local_field_e inv_get_local_field_status ( void )`

Returns the status of earth magnetic field local field parameters.

##### Parameters

out	N/A	
-----	-----	--

##### Returns

status of local field, defined in enum compass\_local\_field\_e

#### 4.6.2.21 `void inv_get_mag_scale ( long * data )`

Gets the compass sensitivity.

## 4.6 results\_holder

57

### Parameters

out	data	Length 3, sensitivity for each compass axis scaled such that $1.0 = 2^{30}$ .
-----	------	---

### 4.6.2.22 int inv\_get\_motion\_state ( unsigned int \* *cntr* )

Returns the motion state.

### Parameters

out	<i>cntr</i>	Number of previous times a no motion event has occurred in a row.
-----	-------------	---

### Returns

Returns INV\_SUCCESS if successful or an error code if not.

### 4.6.2.23 enum compass\_local\_field\_e inv\_get\_mpl\_mag\_field\_status ( void )

Returns the status of mpl calibrated magnetic field local field parameters.

### Parameters

out	N/A	
-----	-----	--

### Returns

status of local field, defined in enum compass\_local\_field\_e

### 4.6.2.24 void inv\_get\_mpl\_magnetic\_local\_field\_parameter ( struct local\_field\_t \* *parameters* )

Returns the parameters of mpl calibrated magnetic field local field.

### Parameters

out	<i>the</i>	parameters of earth magnetic field local field
-----	------------	--

### Returns

N/A

**4.6.2.25** `inv_error_t inv_get_quaternion ( long * data )`

Returns a quaternion.

**Parameters**

out	<i>data</i>	9-axis quaternion scaled such that $1.0 = 2^{30}$ .
-----	-------------	---

**Returns**

Returns INV\_SUCCESS if successful or an error code if not.

**4.6.2.26** `inv_error_t inv_get_quaternion_float ( float * data )`

Returns a quaternion.

**Parameters**

out	<i>data</i>	9-axis quaternion.
-----	-------------	--------------------

**Returns**

Returns INV\_SUCCESS if successful or an error code if not.

**4.6.2.27** `void inv_get_quaternion_set ( long * data, int * accuracy, inv_time_t * timestamp )`

Returns a quaternion with accuracy and timestamp.

**Parameters**

out	<i>data</i>	9-axis quaternion scaled such that $1.0 = 2^{30}$ .
out	<i>accuracy</i>	Accuracy of quaternion, 0-3, where 3 is most accurate.
out	<i>timestamp</i>	Timestamp of this quaternion in nanoseconds

**4.6.2.28** `inv_error_t inv_get_quaternion_validity ( int * value )`

Returns the status of the authenticity of the quaternion data.

## 4.6 results\_holder

59

### Parameters

out	value	Authenticity of the quaternion data.
-----	-------	--------------------------------------

### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.29 `inv_error_t inv_get_result_holder_status ( long * rh_status )`

Returns the status of the result holder.

### Parameters

out	rh_status	Result holder status.
-----	-----------	-----------------------

### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.30 `int inv_got_accel_bias ( )`

Sets state of if we know the accel bias.

### Returns

return 1 if we know the accel bias, 0 if not. it is set with [inv\\_set\\_accel\\_bias\\_found\(\)](#)

#### 4.6.2.31 `int inv_got_compass_bias ( )`

Sets state of if we know the compass bias.

### Returns

return 1 if we know the compass bias, 0 if not. it is set with [inv\\_set\\_compass\\_bias\\_found\(\)](#)

#### 4.6.2.32 `inv_error_t inv_init_results_holder ( void )`

Initializes results holder.

This is called automatically by the enable function [inv\\_enable\\_results\\_holder\(\)](#). It may be called any time the feature is enabled, but is typically not needed to be called by outside callers.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.33 void inv\_set\_acc\_state ( int state )

Sets the accel state.

See [inv\\_get\\_acc\\_state\(\)](#) to get the value.

#### Parameters

in	state	value to set accel state to.
----	-------	------------------------------

#### 4.6.2.34 void inv\_set\_accel\_bias\_found ( int state )

Sets whether we know the accel bias.

#### Parameters

in	state	Set to 1 if we know the accel bias. Can be retrieved with <a href="#">inv_get_accel_bias()</a>
----	-------	--

#### 4.6.2.35 void inv\_set\_accel\_compass\_confidence\_interval ( float ci )

Set 6 axis (accel and compass) 95% heading confidence interval for quaternion.

#### Parameters

in	ci	Confidence interval in radians.
----	----	---------------------------------

#### 4.6.2.36 void inv\_set\_compass\_bias\_error ( const long \* bias\_error )

Set compass bias error.

See [inv\\_get\\_compass\\_bias\\_error\(\)](#)



**4.6 results\_holder****61****Parameters**

in	<i>bias_error</i>	Set's how accurate we know the compass bias. It is the error squared.
----	-------------------	---

**4.6.2.37 void inv\_set\_compass\_bias\_found ( int *state* )**

Sets whether we know the compass bias.

**Parameters**

in	<i>state</i>	Set to 1 if we know the compass bias. Can be retrieved with <a href="#">inv_get_compass_bias()</a>
----	--------------	--

**4.6.2.38 void inv\_set\_compass\_state ( int *state* )**

Sets the compass state.

**Parameters**

in	<i>state</i>	Compass state. It can be retrieved with <a href="#">inv_get_compass_state()</a> .
----	--------------	---

**4.6.2.39 void inv\_set\_earth\_magnetic\_local\_field\_parameter ( struct local\_field\_t \* *parameters* )**

Set the parameters of earth magnetic field local field.

**Parameters**

in	<i>the</i>	earth magnetic field local field parameters.
----	------------	--

**4.6.2.40 void inv\_set\_heading\_confidence\_interval ( float *ci* )**

Set 9 axis 95% heading confidence interval for quaternion.

**Parameters**

in	<i>ci</i>	Confidence interval in radians.
----	-----------	---------------------------------

#### 4.6.2.41 void inv\_set\_large\_mag\_field ( int *state* )

Set to non-zero if there as a large magnetic field.

See [inv\\_get\\_large\\_mag\\_field\(\)](#) for getting this variable.

##### Parameters

in	<i>state</i>	value to set for magnetic field strength. Should be non-zero if it is large.
----	--------------	--

#### 4.6.2.42 void inv\_set\_local\_field\_status ( enum compass\_local\_field\_e *status* )

Set the status of earth magnetic field local field parameters.

##### Parameters

in	<i>status</i>	of earth magnetic field local field parameters.
----	---------------	---

#### 4.6.2.43 inv\_error\_t inv\_set\_local\_magnetic\_field ( float *intensity*, float *inclination*, float *declination* )

Set the magnetic field local field struct object.

##### Parameters

in	<i>status</i>	of earth magnetic field local field parameters.
----	---------------	---

#### 4.6.2.44 void inv\_set\_mag\_scale ( const long \* *data* )

Sets the compass sensitivity.

##### Parameters

in	<i>data</i>	Length 3, sensitivity for each compass axis scaled such that $1.0 = 2^{30}$ .
----	-------------	---

#### 4.6.2.45 void inv\_set\_motion\_state ( unsigned char *state* )

Sets the motion state.

#### 4.6 results\_holder

63

##### Parameters

in	state	motion state where INV_NO_MOTION is not moving and INV_MOTION is moving.
----	-------	--

#### 4.6.2.46 void inv\_set\_mpl\_mag\_field\_status ( enum compass\_local\_field\_e status )

Set the status of mpl calibrated magnetic field local field parameters.

##### Parameters

in	status	of earth magnetic field local field parameters.
----	--------	---

#### 4.6.2.47 inv\_error\_t inv\_set\_mpl\_magnetic\_local\_field\_parameter ( struct local\_field\_t \* parameters )

Set the parameters of mpl calibrated magnetic field local field This API is used by mpl only.

##### Parameters

in	the	earth magnetic field local field parameters.
----	-----	--

##### Returns

INV\_SUCCESS if successful INV\_ERROR\_INVALID\_PARAMETER if invalid input pointer

#### 4.6.2.48 inv\_error\_t inv\_set\_quaternion\_validity ( int value )

Set the status of the authenticity of the quaternion data.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.49 inv\_error\_t inv\_set\_result\_holder\_status ( long rh\_status )

Set the status of the result holder.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.6.2.50 `inv_error_t inv_start_results_holder ( void )`

Function to turn on this module.

This is automatically called by [inv\\_enable\\_results\\_holder\(\)](#). Typically not called by users.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

## 4.7 start\_manager

65

### 4.7 start\_manager

Motion Library - Start Manager Start Manager.

#### Files

- file [start\\_manager.c](#)

*This handles all the callbacks when [inv\\_start\\_mpl\(\)](#) is called.*

#### Functions

- `inv_error_t inv\_execute\_mpl\_start\_notification (void)`  
*Callback all the functions that want to be notified when [inv\\_start\\_mpl\(\)](#) was called.*
- `inv_error_t inv\_init\_start\_manager (void)`  
*Initilize the start manager.*
- `inv_error_t inv\_register\_mpl\_start\_notification (inv_error_t(*start_cb)(void))`  
*Register a callback to receive when [inv\\_start\\_mpl\(\)](#) is called.*
- `inv_error_t inv\_unregister\_mpl\_start\_notification (inv_error_t(*start_cb)(void))`  
*Removes a callback from start notification.*

#### 4.7.1 Detailed Description

Motion Library - Start Manager Start Manager.

#### 4.7.2 Function Documentation

##### 4.7.2.1 `inv_error_t inv\_execute\_mpl\_start\_notification ( void )`

Callback all the functions that want to be notified when [inv\\_start\\_mpl\(\)](#) was called.

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

##### 4.7.2.2 `inv_error_t inv\_init\_start\_manager ( void )`

Initilize the start manager.

Typically called by [inv\\_start\\_mpl\(\)](#);

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

4.7.2.3 `inv_error_t inv_register_mpl_start_notification ( inv_error_t(*) (void) start_cb )`

Register a callback to receive when `inv_start_mpl()` is called.

#### Parameters

in	<i>start_cb</i>	Function callback that will be called when <code>inv_start_mpl()</code> is called.
----	-----------------	--

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

4.7.2.4 `inv_error_t inv_unregister_mpl_start_notification ( inv_error_t(*) (void) start_cb )`

Removes a callback from start notification.

#### Parameters

in	<i>start_cb</i>	function to remove from start notification
----	-----------------	--

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

## 4.8 storage\_manager

67

### 4.8 storage\_manager

Motion Library - Stores Data for functions.

#### Files

- file [storage\\_manager.c](#)  
*Load and Store Manager.*

#### Defines

- #define [NUM\\_STORAGE\\_BOXES](#) 20  
*Max number of entites that can be stored.*

#### Functions

- `inv_error_t inv\_get\_mpl\_state\_size (size_t *size)`  
*Returns the memory size needed to perform a store.*
- `void inv\_init\_storage\_manager ()`  
*Should be called once before using any of the storage methods.*
- `inv_error_t inv\_load\_mpl\_states (const unsigned char *data, size_t length)`  
*This function takes a block of data that has been saved in non-volatile memory and pushes to the proper locations.*
- `inv_error_t inv\_register\_load\_store (inv_error_t(*load_func)(const unsigned char *data), inv_error_t(*save_func)(unsigned char *data), size_t size, unsigned int key)`  
*Used to register your mechanism to load and store non-volatile data.*
- `inv_error_t inv\_save\_mpl\_states (unsigned char *data, size_t sz)`  
*This function fills up a block of memory to be stored in non-volatile memory.*

#### 4.8.1 Detailed Description

Motion Library - Stores Data for functions.

#### 4.8.2 Function Documentation

##### 4.8.2.1 `inv_error_t inv\_get\_mpl\_state\_size ( size_t * size )`

Returns the memory size needed to perform a store.

#### Parameters

out	size	Size in bytes of memory needed to store.
-----	------	--

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.8.2.2 void inv\_init\_storage\_manager ( )

Should be called once before using any of the storage methods.

Typically called first by [inv\\_init\\_mpl\(\)](#).

#### 4.8.2.3 inv\_error\_t inv\_load\_mpl\_states ( const unsigned char \* data, size\_t length )

This function takes a block of data that has been saved in non-volatile memory and pushes to the proper locations.

Multiple error checks are performed on the data.

#### Parameters

in	data	Data that was saved to be loaded up by MPL
in	length	Length of data vector in bytes

#### Returns

Returns INV\_SUCCESS if successful or an error code if not.

#### 4.8.2.4 inv\_error\_t inv\_register\_load\_store ( inv\_error\_t\*)(const unsigned char \*data) load\_func, inv\_error\_t\*)(unsigned char \*data) save\_func, size\_t size, unsigned int key )

Used to register your mechanism to load and store non-volatile data.

This should typical be called during the enable function for your feature.

#### Parameters

in	load_func	function pointer you will use to receive data that was stored for you.
in	save_func	function pointer you will use to save any data you want saved to non-volatile memory between runs.



#### 4.8 storage\_manager

69

in	size	The size in bytes of the amount of data you want loaded and saved.
in	key	The key associated with your data type should be unique across MPL. The key should change when your type of data for storage changes.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

##### 4.8.2.5 inv\_error\_t inv\_save\_mpl\_states ( unsigned char \* *data*, size\_t *sz* )

This function fills up a block of memory to be stored in non-volatile memory.

##### Parameters

out	<i>data</i>	Place to store data, size of <i>sz</i> , must be at least size returned by <a href="#">inv_get_mpl_state_size()</a>
in	<i>sz</i>	Size of data.

##### Returns

Returns INV\_SUCCESS if successful or an error code if not.

## 4.9 accel\_calibration

Accel calibration.

### Files

- file [accel\\_auto\\_cal.c](#)  
*Accel calibration.*

### Defines

- #define [INV\\_ACCEL\\_CAL\\_SAVE\\_KEY](#) (8230)  
*Change this key if the definition of the struct `auto_cal_obj_t` changes.*

### Functions

- `inv_error_t` [inv\\_disable\\_in\\_use\\_auto\\_calibration](#) (void)  
*Disables an algorithm to set accel biases.*
- `inv_error_t` [inv\\_enable\\_in\\_use\\_auto\\_calibration](#) (void)  
*Turns on an algorithm to set accel biases.*
- `inv_error_t` [inv\\_init\\_in\\_use\\_auto\\_calibration](#) (void)  
*Init in-use auto calibration.*
- `inv_error_t` [inv\\_start\\_in\\_use\\_auto\\_calibration](#) (void)  
*Start accel bias calibration.*
- `inv_error_t` [inv\\_stop\\_in\\_use\\_auto\\_calibration](#) (void)  
*Turns on an algorithm to set accel biases.*

#### 4.9.1 Detailed Description

Accel calibration.

#### 4.9.2 Define Documentation

##### 4.9.2.1 #define [INV\\_ACCEL\\_CAL\\_SAVE\\_KEY](#) (8230)

Change this key if the definition of the struct `auto_cal_obj_t` changes.

Previous keys: 8227, 8228, 8229

## 4.9 accel\_calibration

71

### 4.9.3 Function Documentation

#### 4.9.3.1 `inv_error_t inv_disable_in_use_auto_calibration ( void )`

Disables an algorithm to set accel biases.

Typically called once per session. See [inv\\_stop\\_in\\_use\\_auto\\_calibration\(\)](#) to stop the algorithm.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.9.3.2 `inv_error_t inv_enable_in_use_auto_calibration ( void )`

Turns on an algorithm to set accel biases.

This may be called after [inv\\_init\\_mpl\(\)](#) and before [inv\\_start\\_mpl\(\)](#). It is typically only called once per session.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.9.3.3 `inv_error_t inv_start_in_use_auto_calibration ( void )`

Start accel bias calibration.

It is automatically called in start mode after an enable. This function only needs to be called to start after a stop command generated by [inv\\_stop\\_in\\_use\\_auto\\_calibration\(\)](#).

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.9.3.4 `inv_error_t inv_stop_in_use_auto_calibration ( void )`

Turns on an algorithm to set accel biases.

This may be called after [inv\\_init\\_mpl\(\)](#) and before [inv\\_start\\_mpl\(\)](#). It is typically only called once per session. It does not return a motion state.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

## 4.10 small\_motion\_compass\_cal

Calibrates a compass quickly using gyro's but is less accurate than other algorithms.

### Files

- file [compass\\_bias\\_w\\_gyro.c](#)

### Functions

- `inv_error_t inv_disable_compass_bias_w_gyro (void)`  
*Turns off a compass bias from from gyro aglorithm.*
- `inv_error_t inv_enable_compass_bias_w_gyro (void)`  
*Turns on a compass bias from from gyro aglorithm.*
- `void inv_init_compass_bias_w_gyro ()`  
*Initializes/Resets this module.*
- `inv_error_t inv_start_compass_bias_w_gyro (void)`  
*Allows the user to start the coarse compass bias algorithm.*
- `inv_error_t inv_stop_compass_bias_w_gyro (void)`  
*Allows the user to stop the coarse compass bias algorithm.*

### 4.10.1 Detailed Description

Calibrates a compass quickly using gyro's but is less accurate than other algorithms.

### 4.10.2 Function Documentation

#### 4.10.2.1 `inv_error_t inv_disable_compass_bias_w_gyro ( void )`

Turns off a compass bias from from gyro aglorithm.

It is typically only called once per session. It does not return a motion state.

### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.10 small\_motion\_compass\_cal

73

##### 4.10.2.2 `inv_error_t inv_enable_compass_bias_w_gyro ( void )`

Turns on a compass bias from from gyro algorithm.

This may be called after `inv_enable_mpl()` and before `inv_start_mpl()`. It is typically only called once per session. It will automatically turn off, when the more precise algorithms determine a compass bias solution.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.10.2.3 `void inv_init_compass_bias_w_gyro ( )`

Initializes/Resets this module.

Called by `inv_enable_compass_from_gyro()`.

##### 4.10.2.4 `inv_error_t inv_start_compass_bias_w_gyro ( void )`

Allows the user to start the coarse compass bias algorithm.

It is automatically called in start mode after an enable. This function only needs to be called to start after a stop command generated by `inv_stop_compass_bias_w_gyro()`.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.10.2.5 `inv_error_t inv_stop_compass_bias_w_gyro ( void )`

Allows the user to stop the coarse compass bias algorithm.

To start the algorithm back up call `inv_start_compass_bias_w_gyro()`

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

## 4.11 compass\_fit

A precise compass bias algorithm.

### Files

- file [compass\\_fit.c](#)

### Functions

- `inv_error_t inv_disable_compass_fit (void)`  
*Disables the compass fit algorithm.*
- `inv_error_t inv_enable_compass_fit (void)`  
*Enables the compass fit algorithm.*
- `void inv_init_compass_fit ()`  
*Initializes/Resets this module.*
- `inv_error_t inv_start_compass_fit (void)`  
*Starts the compass fit algorithm.*
- `inv_error_t inv_stop_compass_fit (void)`  
*Stops the compass fit algorithm.*

#### 4.11.1 Detailed Description

A precise compass bias algorithm.

#### 4.11.2 Function Documentation

##### 4.11.2.1 `inv_error_t inv_disable_compass_fit ( void )`

Disables the compass fit algorithm.

Should only be called once per library load when you wish to remove this functionality. See [inv\\_stop\\_compass\\_fit\(\)](#) if you wish to simply stop the algorithm.

### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.11 compass\_fit

75

##### 4.11.2.2 `inv_error_t inv_enable_compass_fit ( void )`

Enables the compass fit algorithm.

This should only be called once per library load. See [inv\\_start\\_compass\\_fit\(\)](#) and [inv\\_stop\\_compass\\_fit\(\)](#) for starting and stopping. Automatically calls [inv\\_start\\_compass\\_fit\(\)](#) and [inv\\_init\\_compass\\_fit\(\)](#). Mutually exclusive with [inv\\_enable\\_vector\\_compass\\_cal\(\)](#).

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.11.2.3 `void inv_init_compass_fit ( )`

Initializes/Resets this module.

Called by [inv\\_enable\\_compass\\_fit\(\)](#).

##### 4.11.2.4 `inv_error_t inv_start_compass_fit ( void )`

Starts the compass fit algorithm.

This is automatically called by [inv\\_enable\\_compass\\_fit\(\)](#) and only needs to be called after a call to [inv\\_stop\\_compass\\_fit\(\)](#).

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.11.2.5 `inv_error_t inv_stop_compass_fit ( void )`

Stops the compass fit algorithm.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

## 4.12 compass\_vector\_cal

A compass calibration algorithm that is mutually exclusive with compass\_fit.

### Files

- file [compass\\_fit.c](#)

### Functions

- `inv_error_t inv_disable_vector_compass_cal (void)`  
*Disables a precise compass bias algorithm.*
- `inv_error_t inv_enable_vector_compass_cal (void)`  
*Enables a precise compass bias algorithm.*
- `inv_error_t inv_init_vector_compass_cal (void)`  
*Initializes/Resets this module.*
- `inv_error_t inv_start_vector_compass_cal (void)`  
*Allows the user to start a precise compass bias algorithm.*
- `inv_error_t inv_stop_vector_compass_cal (void)`  
*Allows the user to stop a precise compass bias algorithm.*

### 4.12.1 Detailed Description

A compass calibration algorithm that is mutually exclusive with compass\_fit.

### 4.12.2 Function Documentation

#### 4.12.2.1 `inv_error_t inv_disable_vector_compass_cal ( void )`

Disables a precise compass bias algorithm.

Should only be called once per library load when you wish to remove this functionality. See [inv\\_stop\\_vector\\_compass\\_cal\(\)](#) if you wish to simply stop the algorithm.

### Returns

INV\_SUCCESS on success or an error code if call was not successful.



## 4.12 compass\_vector\_cal

77

### 4.12.2.2 `inv_error_t inv_enable_vector_compass_cal ( void )`

Enables a precise compass bias algorithm.

This may be called after `inv_init_mpl()` and before `inv_start_mpl()`. It is typically only called once per session. It does not return a motion state. Mutually exclusive with `inv_enable_compass_fit()`.

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

### 4.12.2.3 `inv_error_t inv_init_vector_compass_cal ( void )`

Initializes/Resets this module.

Called by `inv_enable_vector_compass_cal()`. If you are calling this for testing, you probably also want to call `inv_init_adv_fusion_obj()`

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

### 4.12.2.4 `inv_error_t inv_start_vector_compass_cal ( void )`

Allows the user to start a precise compass bias algorithm.

It is automatically called in start mode after an enable. This function only needs to be called to start after a stop command generated by `inv_stop_vector_compass_cal()`.

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

### 4.12.2.5 `inv_error_t inv_stop_vector_compass_cal ( void )`

Allows the user to stop a precise compass bias algorithm.

To start the algorithm back up call `inv_start_vector_compass_cal()`

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

## 4.13 fast\_no\_mot

Fast no motion algorithm used to set the gyro bias.

### Files

- file [fast\\_no\\_motion.c](#)  
*Fast no motion algorithm.*

### Functions

- void [int\\_set\\_fast\\_nomot\\_gyro\\_threshold](#) (long long thresh)  
*Sets internal threshold for fast no motion.*
- inv\_error\_t [inv\\_disable\\_fast\\_nomot](#) (void)  
*Turns off a faster Motion/No Motion to set gyro biases (see [inv\\_enable\\_fast\\_nomot\(\)](#)).*
- inv\_error\_t [inv\\_enable\\_fast\\_nomot](#) (void)  
*Turns on a faster Motion/No Motion to set gyro biases.*
- void [inv\\_fast\\_nomot\\_set\\_gyro\\_bias](#) (struct inv\_sensor\_cal\_t \*sensor\_cal)  
*Used to set gyro bias when no motion is detected.*
- void [inv\\_get\\_fast\\_nomot\\_accel\\_param](#) (long \*cntr, long long \*param)  
*This is used to help set [inv\\_set\\_fast\\_nomot\\_accel\\_threshold\(\)](#).*
- void [inv\\_get\\_fast\\_nomot\\_compass\\_param](#) (long \*cntr, long long \*param)  
*This is used to help set [inv\\_set\\_fast\\_nomot\\_compass\\_threshold\(\)](#).*
- long long [inv\\_get\\_fnm\\_gyro\\_no\\_motion\\_param](#) (void)  
*Get gyro parameters.*
- inv\_error\_t [inv\\_init\\_fast\\_nomot](#) (void)  
*Initializes the fast no motion algorithm.*
- void [inv\\_set\\_default\\_number\\_of\\_samples](#) (int count)  
*Set default number of samples.*
- void [inv\\_set\\_fast\\_nomot\\_accel\\_threshold](#) (long long thresh)  
*Used to set internal threshold.*
- void [inv\\_set\\_fast\\_nomot\\_compass\\_threshold](#) (long long thresh)  
*Used to set internal threshold.*
- inv\_error\_t [inv\\_start\\_fast\\_nomot](#) (void)  
*Allows the user to start the fast no motion algorithm.*
- inv\_error\_t [inv\\_stop\\_fast\\_nomot](#) (void)  
*Allows the user to stop the fast no motion algorithm.*

#### 4.13 fast\_no\_mot

79

##### 4.13.1 Detailed Description

Fast no motion algorithm used to set the gyro bias.

##### 4.13.2 Function Documentation

###### 4.13.2.1 `inv_error_t inv_disable_fast_nomot ( void )`

Turns off a faster Motion/No Motion to set gyro biases (see [inv\\_enable\\_fast\\_nomot\(\)](#)).

It is typically only called once per session. It does not return a motion state. It is mutually exclusive with [inv\\_enable\\_motion\\_no\\_motion\(\)](#).

###### Returns

INV\_SUCCESS on success or an error code if call was not successful.

###### 4.13.2.2 `inv_error_t inv_enable_fast_nomot ( void )`

Turns on a faster Motion/No Motion to set gyro biases.

This may be called after [inv\\_init\\_mpl\(\)](#) and before [inv\\_start\\_mpl\(\)](#). It is typically only called once per session. It does not return a motion state. It is mutually exclusive with [inv\\_enable\\_motion\\_no\\_motion\(\)](#).

###### Returns

INV\_SUCCESS on success or an error code if call was not successful.

###### 4.13.2.3 `void inv_fast_nomot_set_gyro_bias ( struct inv_sensor_cal_t * sensor_cal )`

Used to set gyro bias when no motion is detected.

###### Parameters

in	<i>sensor_cal</i> ,:	pointer of the sensor data structure
----	----------------------	--------------------------------------

###### 4.13.2.4 `void inv_get_fast_nomot_accel_param ( long * cntr, long long * param )`

This is used to help set [inv\\_set\\_fast\\_nomot\\_accel\\_threshold\(\)](#).

cntr is incremented each time there is a new value of param. 100 new values should be sorted from low to high and the 97th value should be used as the threshold parameter

for [inv\\_set\\_fast\\_nomot\\_accel\\_threshold\(\)](#). The compass must be on.

**Parameters**

out	<i>cntr</i>	Counter for when param changes
out	<i>param</i>	Parameter used to help set threshold

**4.13.2.5** void [inv\\_get\\_fast\\_nomot\\_compass\\_param](#) ( long \* *cntr*, long long \* *param* )

This is used to help set [inv\\_set\\_fast\\_nomot\\_compass\\_threshold\(\)](#).

*cntr* is incremented each time there is a new value of *param*. 100 new values should be sorted from low to high and the 97th value should be used as the threshold in [inv\\_set\\_fast\\_nomot\\_compass\\_threshold\(\)](#). The compass must be on.

**Parameters**

out	<i>cntr</i>	Counter for when param changes
out	<i>param</i>	Parameter used to help set threshold

**4.13.2.6** inv\_error\_t [inv\\_init\\_fast\\_nomot](#) ( void )

Initializes the fast no motion algorithm.

Automatically called by [inv\\_enable\\_fast\\_nomot\(\)](#). Not typically called by the user.

**Returns**

INV\_SUCCESS on success or an error code if call was not successful.

**4.13.2.7** void [inv\\_set\\_default\\_number\\_of\\_samples](#) ( int *count* )

Set default number of samples.

Not typically called by users.

**Parameters**

in	<i>N</i>	Number of samples to use for algorithm
----	----------	--

#### 4.13 fast\_no\_mot

81

##### 4.13.2.8 void inv\_set\_fast\_nomot\_accel\_threshold ( long long thresh )

Used to set internal threshold.

This may need to be set based upon device environment. See [inv\\_get\\_fast\\_nomot\\_accel\\_param\(\)](#) for values a range of values to set this too.

###### Parameters

in	thresh	
----	--------	--

##### 4.13.2.9 void inv\_set\_fast\_nomot\_compass\_threshold ( long long thresh )

Used to set internal threshold.

This may need to be set based upon device environment. See [inv\\_get\\_fast\\_nomot\\_compass\\_param\(\)](#) for values a range of values to set this too.

###### Parameters

in	thresh	
----	--------	--

##### 4.13.2.10 inv\_error\_t inv\_start\_fast\_nomot ( void )

Allows the user to start the fast no motion algorithm.

It is automatically in start mode after an enable. This function only needs to be called to start after a stop command generated by [inv\\_stop\\_fast\\_nomot\(\)](#).

###### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.13.2.11 inv\_error\_t inv\_stop\_fast\_nomot ( void )

Allows the user to stop the fast no motion algorithm.

See [inv\\_start\\_fast\\_nomot\(\)](#) to start the algorithm back up.

###### Returns

INV\_SUCCESS on success or an error code if call was not successful.

## 4.14 nine\_axis\_fusion

Performs nine axis sensor fusion.

### Files

- file [fusion\\_9axis.c](#)  
*Performs nine axis sensor fusion.*

### Functions

- `inv_error_t inv_9x_fusion_enable_jitter_reduction (int en)`  
*This enables the jitter reduction feature.*
- `inv_error_t inv_9x_fusion_set_mag_fb (double fb)`  
*This sets the magnetic feedback.*
- `inv_error_t inv_9x_fusion_use_timestamps (int en)`  
*Use timestamps when evaluating compass correction gain.*
- `inv_error_t inv_disable_9x_sensor_fusion ()`  
*Disables the 9 axis sensor fusion algorithm.*
- `inv_error_t inv_enable_9x_sensor_fusion (void)`  
*Enables the 9 axis sensor fusion algorithm.*
- `void inv_init_9x_fusion (void)`  
*Initializes the algorithm.*
- `inv_error_t inv_start_9x_sensor_fusion (void)`  
*Starts the 9 axis sensor fusion.*
- `inv_error_t inv_stop_9x_sensor_fusion (void)`  
*Stops the 9 axis sensor fusion from running.*
- `int inv_verify_9x_fusion_data (float *data)`  
*Verify that the 9-axis quaternion data is correctedly encrypted.*

#### 4.14.1 Detailed Description

Performs nine axis sensor fusion.

#### 4.14.2 Function Documentation

##### 4.14.2.1 `inv_error_t inv_9x_fusion_enable_jitter_reduction ( int en )`

This enables the jitter reduction feature.

**4.14 nine\_axis\_fusion****83****Parameters**

<i>in</i>	<i>en</i>	Should be non-zero to enable the feature. Initialized to 0, i.e. off
-----------	-----------	--

**Returns**

heading correction angle

**4.14.2.2 inv\_error\_t inv\_9x\_fusion\_set\_mag\_fb ( double *fb* )**

This sets the magnetic feedback.

Increasing it results in faster compass correction in the 9 axis quaternion.

**Parameters**

<i>in</i>	<i>fb</i>	Desired magnetic feedback value. Typical value is 1. Also, initialized to 1 in <code>inv_init_9x_fusion</code> .
-----------	-----------	--

**Returns**

heading correction angle

**4.14.2.3 inv\_error\_t inv\_9x\_fusion\_use\_timestamps ( int *en* )**

Use timestamps when evaluating compass correction gain.

This feature should be used when the MPL is not receiving compass data at a constant rate.

**Parameters**

<i>in</i>	<i>en</i>	1 to enable the feature.
-----------	-----------	--------------------------

**Returns**

INV\_SUCCESS on success or an error code if call was not successful.

**4.14.2.4 inv\_error\_t inv\_disable\_9x\_sensor\_fusion ( )**

Disables the 9 axis sensor fusion algorithm.

Should only be called once per library load when you wish to remove this functionality. See [inv\\_stop\\_9x\\_sensor\\_fusion\(\)](#) if you wish to simply stop the algorithm.

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.14.2.5 `inv_error_t inv_enable_9x_sensor_fusion ( void )`

Enables the 9 axis sensor fusion algorithm.

This should only be called once per library load. See [inv\\_start\\_9x\\_sensor\\_fusion\(\)](#) and [inv\\_stop\\_9x\\_sensor\\_fusion\(\)](#) for starting and stopping. Automatically calls [inv\\_start\\_9x\\_sensor\\_fusion\(\)](#) and [inv\\_init\\_9x\\_fusion\(\)](#).

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.14.2.6 `void inv_init_9x_fusion ( void )`

Initializes the algorithm.

Automatically called by [inv\\_enable\\_9x\\_sensor\\_fusion\(\)](#). Not normally called by users.

#### 4.14.2.7 `inv_error_t inv_start_9x_sensor_fusion ( void )`

Starts the 9 axis sensor fusion.

Automatically called by [inv\\_enable\\_9x\\_sensor\\_fusion\(\)](#) and only needs to be called after stopping with [inv\\_stop\\_9x\\_sensor\\_fusion\(\)](#).

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.14.2.8 `inv_error_t inv_stop_9x_sensor_fusion ( void )`

Stops the 9 axis sensor fusion from running.

See [inv\\_start\\_9x\\_sensor\\_fusion\(\)](#) to start it back up again.

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.



#### 4.14 nine\_axis\_fusion

85

##### 4.14.2.9 int inv\_verify\_9x\_fusion\_data ( float \* *data* )

Verify that the 9-axis quaternion data is correctly encrypted.

##### Parameters

in	<i>data</i>	Quaternion data to be compared with our version stored internally. If encrypted correctly, return 1. If no DMP is used in the 9-axis quaternion, return 2. If encrypted incorrectly, return 0. If quaternion data is identity, return -1.
----	-------------	---

## 4.15 gyro\_tc

Gyro Temperature Compensation algorithm.

### Files

- file [gyro\\_tc.c](#)  
*Gyro bias temperature compensation.*

### Defines

- #define [INV\\_GTC\\_SAVE\\_KEY](#) (308)  
*Change this key if the definition of the struct inv\_gtc changes.*

### Functions

- inv\_error\_t [inv\\_disable\\_gyro\\_tc](#) (void)  
*Enable the gyro temp comp algorithm.*
- inv\_error\_t [inv\\_enable\\_gyro\\_tc](#) (void)  
*Enable the gyro temp comp algorithm.*
- inv\_error\_t [inv\\_init\\_gyro\\_ts](#) (void)  
*Reset the gyro temp slope.*
- inv\_error\_t [inv\\_start\\_gyro\\_tc](#) (void)  
*Registers callback to receive new temperature data.*
- inv\_error\_t [inv\\_stop\\_gyro\\_tc](#) (void)  
*Unregisters callback.*

#### 4.15.1 Detailed Description

Gyro Temperature Compensation algorithm.

#### 4.15.2 Define Documentation

##### 4.15.2.1 #define INV\_GTC\_SAVE\_KEY (308)

Change this key if the definition of the struct inv\_gtc changes.

Previous keys: -none-

## 4.15 gyro\_tc

87

### 4.15.3 Function Documentation

#### 4.15.3.1 `inv_error_t inv_disable_gyro_tc ( void )`

Enable the gyro temp comp algorithm.

##### Returns

INV\_SUCCESS if successful.

#### 4.15.3.2 `inv_error_t inv_enable_gyro_tc ( void )`

Enable the gyro temp comp algorithm.

##### Returns

INV\_SUCCESS if successful.

#### 4.15.3.3 `inv_error_t inv_init_gyro_ts ( void )`

Reset the gyro temp slope.

##### Returns

INV\_SUCCESS if successful.

#### 4.15.3.4 `inv_error_t inv_start_gyro_tc ( void )`

Registers callback to receive new temperature data.

##### Returns

INV\_SUCCESS if successful.

#### 4.15.3.5 `inv_error_t inv_stop_gyro_tc ( void )`

Unregisters callback.

##### Returns

INV\_SUCCESS if successful.

## 4.16 heading\_from\_gyro

A less accurate but fast algorithm for 9 axis sensor fusion.

### Files

- file [heading\\_from\\_gyro.c](#)

### Functions

- `inv_error_t inv_disable_heading_from_gyro (void)`  
*Turns off a heading from gyro.*
- `inv_error_t inv_enable_heading_from_gyro (void)`  
*Turns on a heading from gyro algorithm which performs sensor fusion when the compass bias hasn't been fully solved for.*
- `void inv_init_heading_from_gyro (void)`  
*Initializes/Resets this module.*
- `inv_error_t inv_start_heading_from_gyro (void)`  
*Registers callback to receive gyro and compass data.*
- `inv_error_t inv_stop_heading_from_gyro (void)`  
*Unregisters callback.*

#### 4.16.1 Detailed Description

A less accurate but fast algorithm for 9 axis sensor fusion.

#### 4.16.2 Function Documentation

##### 4.16.2.1 `inv_error_t inv_disable_heading_from_gyro ( void )`

Turns off a heading from gyro.

It is typically only called once per session.

### Returns

INV\_SUCCESS if successful.

#### 4.16 heading\_from\_gyro

89

##### 4.16.2.2 `inv_error_t inv_enable_heading_from_gyro ( void )`

Turns on a heading from gyro algorithm which performs sensor fusion when the compass bias hasn't been fully solved for.

This may be called after `inv_init_mpl()` and before `inv_start_mpl()`. It is typically only called once per session.

##### Returns

INV\_SUCCESS if successful.

##### 4.16.2.3 `void inv_init_heading_from_gyro ( void )`

Initializes/Resets this module.

Called by `inv_enable_heading_from_gyro()`.

##### Returns

INV\_SUCCESS if successful.

##### 4.16.2.4 `inv_error_t inv_start_heading_from_gyro ( void )`

Registers callback to receive gyro and compass data.

##### Returns

INV\_SUCCESS if successful.

##### 4.16.2.5 `inv_error_t inv_stop_heading_from_gyro ( void )`

Unregisters callback.

##### Returns

INV\_SUCCESS if successful.

## 4.17 mag\_disturb

Determines magnetic disturbances and sets compass accuracy appropriately.

### Files

- file [mag\\_disturb.c](#)

### Functions

- `inv_error_t inv_disable_magnetic_disturbance (void)`  
*Turns off a magnetic disturbance algorithm (see [inv\\_enable\\_magnetic\\_disturbance\(\)](#)).*
- `void inv_disable_magnetic_disturbance_logging (void)`  
*Disables the magnetic disturbance algorithm's verbose mode.*
- `inv_error_t inv_enable_magnetic_disturbance (void)`  
*Enables a magnetic disturbance algorithm.*
- `void inv_enable_magnetic_disturbance_logging (void)`  
*Enables the magnetic disturbance algorithm's verbose mode.*
- `inv_error_t inv_start_magnetic_disturbance (void)`  
*Allows the user to start the magnetic disturbance algorithm.*
- `inv_error_t inv_stop_magnetic_disturbance (void)`  
*Allows the user to stop the magnetic disturbance algorithm.*

#### 4.17.1 Detailed Description

Determines magnetic disturbances and sets compass accuracy appropriately.

#### 4.17.2 Function Documentation

##### 4.17.2.1 `inv_error_t inv_disable_magnetic_disturbance ( void )`

Turns off a magnetic disturbance algorithm (see [inv\\_enable\\_magnetic\\_disturbance\(\)](#)).

It is typically only called once per session. See [inv\\_stop\\_magnetic\\_disturbance\(\)](#) to stop the algorithm

### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.17 mag\_disturb

91

##### 4.17.2.2 void inv\_disable\_magnetic\_disturbance\_logging ( void )

Disables the magnetic disturbance algorithm's verbose mode.

Debugging info are typically turned off in a production build as the extensive logging may cause performance degradation.

##### 4.17.2.3 inv\_error\_t inv\_enable\_magnetic\_disturbance ( void )

Enables a magnetic disturbance algorithm.

This may be called after [inv\\_init\\_mpl\(\)](#) and before [inv\\_start\\_mpl\(\)](#). It is typically only called once per session. It does not return a motion state.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.17.2.4 void inv\_enable\_magnetic\_disturbance\_logging ( void )

Enables the magnetic disturbance algorithm's verbose mode.

The verbose mode causes the algorithm to print debugging information at every step of execution. Debugging info are typically turned off in a production build as the extensive logging may cause performance degradation.

##### 4.17.2.5 inv\_error\_t inv\_start\_magnetic\_disturbance ( void )

Allows the user to start the magnetic disturbance algorithm.

It is automatically called in start mode after an enable. This function only needs to be called to start after a stop command generated by [inv\\_stop\\_magnetic\\_disturbance\(\)](#).

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.17.2.6 inv\_error\_t inv\_stop\_magnetic\_disturbance ( void )

Allows the user to stop the magnetic disturbance algorithm.

To start the algorithm back up call [inv\\_start\\_no\\_gyro\\_fusion\(\)](#)

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

## 4.18 motion\_no\_motion

A motion detection algorithm that is used to set gyro bias when the device is not moving.

### Files

- file [motion\\_no\\_motion.c](#)

*A motion detection algorithm that is used to set gyro bias when the device is not moving.*

### Functions

- `inv_error_t inv_disable_motion_no_motion (void)`  
*Turns off Motion/No Motion to set gyro biases (see [inv\\_enable\\_motion\\_no\\_motion\(\)](#)).*
- `inv_error_t inv_enable_motion_no_motion ()`  
*Turns on Motion/No Motion used to set gyro biases.*
- `inv_error_t inv_init_motion_no_motion (void)`  
*Initializes the motion no motion algorithm.*
- `inv_error_t inv_set_no_motion_time (long time_ms)`  
*Allows the user to set the time to be in a no motion state before setting the gyro bias.*
- `inv_error_t inv_start_motion_no_motion (void)`  
*Allows the user to start the no motion algorithm.*
- `inv_error_t inv_stop_motion_no_motion (void)`  
*Allows the user to stop the no motion algorithm.*

### 4.18.1 Detailed Description

A motion detection algorithm that is used to set gyro bias when the device is not moving.

### 4.18.2 Function Documentation

#### 4.18.2.1 `inv_error_t inv_disable_motion_no_motion ( void )`

Turns off Motion/No Motion to set gyro biases (see [inv\\_enable\\_motion\\_no\\_motion\(\)](#)).

It is typically only called once per session. It does not return a motion state. It is mutually exclusive with [inv\\_enable\\_fast\\_nomot\(\)](#).



#### 4.18 motion\_no\_motion

93

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.18.2.2 `inv_error_t inv_enable_motion_no_motion ( )`

Turns on Motion/No Motion used to set gyro biases.

This may be called after `inv_init_mpl()` and before `inv_start_mpl()`. It is typically only called once per session. It does not return a motion state. It is mutually exclusive with `inv_enable_motion_no_motion()`.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.18.2.3 `inv_error_t inv_init_motion_no_motion ( void )`

Initializes the motion no motion algorithm.

Automatically called by `inv_enable_motion_no_motion()`. Not typically called by the user.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.18.2.4 `inv_error_t inv_set_no_motion_time ( long time_ms )`

Allows the user to set the time to be in a no motion state before setting the gyro bias.

##### Parameters

in	<i>time_ms</i>	Time in milliseconds. Default is 8000ms or 8 seconds.
----	----------------	---

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

##### 4.18.2.5 `inv_error_t inv_start_motion_no_motion ( void )`

Allows the user to start the no motion algorithm.

It is automatically called in start mode after an enable. This function only needs to be called to start after a stop command generated by [inv\\_stop\\_motion\\_no\\_motion\(\)](#).

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.18.2.6 `inv_error_t inv_stop_motion_no_motion ( void )`

Allows the user to stop the no motion algorithm.

See [inv\\_start\\_motion\\_no\\_motion\(\)](#) to start the algorithm back up.

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.19 no\_gyro\_fusion

95

### 4.19 no\_gyro\_fusion

Accel/Compass Sensor fusion.

#### Files

- file [no\\_gyro\\_fusion.c](#)  
*Accel/Compass Sensor fusion.*

#### Functions

- `inv_error_t inv_disable_no_gyro_fusion (void)`  
*Turns off a sensor fusion using accel and compass only (see [inv\\_enable\\_no\\_gyro\\_fusion\(\)](#)).*
- `inv_error_t inv_enable_no_gyro_fusion (void)`  
*Enables a sensor fusion using accel and compass only.*
- `inv_error_t inv_init_no_gyro_fusion (void)`  
*Initializes the algorithm.*
- `inv_error_t inv_start_no_gyro_fusion (void)`  
*Allows the user to start the sensor fusion using accel and compass only algorithm.*
- `inv_error_t inv_stop_no_gyro_fusion (void)`  
*Allows the user to stop the sensor fusion using accel and compass only algorithm.*
- `int inv_verify_no_gyro_fusion_data (float *data)`  
*Verify that the 6-axis geomagnetic quaternion data is correctedly encrypted.*

#### 4.19.1 Detailed Description

Accel/Compass Sensor fusion.

#### 4.19.2 Function Documentation

##### 4.19.2.1 `inv_error_t inv_disable_no_gyro_fusion ( void )`

Turns off a sensor fusion using accel and compass only (see [inv\\_enable\\_no\\_gyro\\_fusion\(\)](#)).

It is typically only called once per session. See [inv\\_stop\\_no\\_gyro\\_fusion\(\)](#) to stop the algorithm

#### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.19.2.2 `inv_error_t inv_enable_no_gyro_fusion ( void )`

Enables a sensor fusion using accel and compass only.

This may be called after [inv\\_init\\_mpl\(\)](#) and before [inv\\_start\\_mpl\(\)](#). It is typically only called once per session. It does not return a motion state.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.19.2.3 `inv_error_t inv_init_no_gyro_fusion ( void )`

Initializes the algorithm.

Automatically called by the enable function.

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.19.2.4 `inv_error_t inv_start_no_gyro_fusion ( void )`

Allows the user to start the sensor fusion using accel and compass only algorithm.

It is automatically called in start mode after an enable. This function only needs to be called to start after a stop command generated by [inv\\_stop\\_no\\_gyro\\_fusion\(\)](#).

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.19.2.5 `inv_error_t inv_stop_no_gyro_fusion ( void )`

Allows the user to stop the sensor fusion using accel and compass only algorithm.

See [inv\\_start\\_no\\_gyro\\_fusion\(\)](#) to start the algorithm back up call [inv\\_start\\_no\\_gyro\\_fusion\(\)](#)

##### Returns

INV\_SUCCESS on success or an error code if call was not successful.

#### 4.19 no\_gyro\_fusion

97

##### 4.19.2.6 int inv\_verify\_no\_gyro\_fusion\_data ( float \* data )

Verify that the 6-axis geomagnetic quaternion data is correctly encrypted.

##### Parameters

in	data	Quaternion data to be compared with our version stored internally. If encrypted correctly, return 1. If encrypted incorrectly, return 0. If quaternion data is identity, return -1.
----	------	---

## Index

INV\_GTC\_SAVE\_KEY  
    gyro\_tc, 86

accel\_calibration, 70  
    inv\_disable\_in\_use\_auto\_calibration, 71  
    inv\_enable\_in\_use\_auto\_calibration, 71  
    inv\_start\_in\_use\_auto\_calibration, 71  
    inv\_stop\_in\_use\_auto\_calibration, 71

compass\_fit, 74  
    inv\_disable\_compass\_fit, 74  
    inv\_enable\_compass\_fit, 74  
    inv\_init\_compass\_fit, 75  
    inv\_start\_compass\_fit, 75  
    inv\_stop\_compass\_fit, 75

compass\_vector\_cal, 76  
    inv\_disable\_vector\_compass\_cal, 76  
    inv\_enable\_vector\_compass\_cal, 76  
    inv\_init\_vector\_compass\_cal, 77  
    inv\_start\_vector\_compass\_cal, 77  
    inv\_stop\_vector\_compass\_cal, 77

data\_builder, 3  
    inv\_accel\_was\_turned\_off, 7  
    inv\_apply\_calibration, 7  
    inv\_build\_accel, 8  
    inv\_build\_compass, 8  
    inv\_build\_gyro, 9  
    inv\_build\_quat, 9  
    inv\_build\_temp, 10  
    inv\_compass\_was\_turned\_off, 10  
    inv\_execute\_on\_data, 10  
    inv\_get\_6\_axis\_compass\_accel\_timestamp, 10  
    inv\_get\_6\_axis\_gyro\_accel\_timestamp, 11  
    inv\_get\_9\_axis\_timestamp, 11  
    inv\_get\_accel\_accuracy, 11  
    inv\_get\_accel\_bias, 11  
    inv\_get\_accel\_bias\_dmp\_units, 12  
    inv\_get\_accel\_on, 12  
    inv\_get\_accel\_sensitivity, 12  
    inv\_get\_accel\_set, 12  
    inv\_get\_compass\_bias, 12  
    inv\_get\_compass\_on, 13  
    inv\_get\_compass\_sensitivity, 13  
    inv\_get\_compass\_set, 13  
    inv\_get\_compass\_set\_raw, 13  
    inv\_get\_compass\_soft\_iron\_input\_data, 14  
    inv\_get\_compass\_soft\_iron\_matrix\_d, 14  
    inv\_get\_compass\_soft\_iron\_matrix\_f, 14  
    inv\_get\_compass\_soft\_iron\_output\_data, 14  
    inv\_get\_factory\_accel\_bias\_mask, 14  
    inv\_get\_gyro, 15  
    inv\_get\_gyro\_accuracy, 15  
    inv\_get\_gyro\_bias, 15  
    inv\_get\_gyro\_bias\_dmp\_units, 15  
    inv\_get\_gyro\_on, 16  
    inv\_get\_gyro\_sensitivity, 16  
    inv\_get\_gyro\_set, 16  
    inv\_get\_gyro\_set\_raw, 16  
    inv\_get\_last\_timestamp, 17  
    inv\_get\_mag\_accuracy, 17  
    inv\_get\_mpl\_accel\_bias, 17  
    inv\_get\_mpl\_gyro\_bias, 17  
    inv\_get\_raw\_compass, 17  
    inv\_get\_temp\_set, 18  
    inv\_gyro\_was\_turned\_off, 18

## INDEX

99

inv\_quaternion\_sensor\_was\_turned\_off, 18  
inv\_set\_accel\_accuracy, 18  
inv\_set\_accel\_bandwidth, 18  
inv\_set\_accel\_bias, 19  
inv\_set\_accel\_bias\_mask, 19  
inv\_set\_accel\_orientation\_and\_scale, 19  
inv\_set\_accel\_sample\_rate, 20  
inv\_set\_compass\_bandwidth, 20  
inv\_set\_compass\_bias, 20  
inv\_set\_compass\_disturbance, 20  
inv\_set\_compass\_orientation\_and\_scale, 20  
inv\_set\_compass\_sample\_rate, 21  
inv\_set\_compass\_soft\_iron\_input\_data, 21  
inv\_set\_compass\_soft\_iron\_matrix\_d, 21  
inv\_set\_compass\_soft\_iron\_matrix\_f, 21  
inv\_set\_gyro\_bandwidth, 22  
inv\_set\_gyro\_bias, 22  
inv\_set\_gyro\_orientation\_and\_scale, 22  
inv\_set\_gyro\_sample\_rate, 22  
inv\_set\_mpl\_gyro\_bias, 23  
inv\_set\_quat\_sample\_rate, 23  
inv\_temperature\_was\_turned\_off, 23  
set\_sensor\_orientation\_and\_scale, 23  
fast\_no\_mot, 78  
inv\_disable\_fast\_nomot, 79  
inv\_enable\_fast\_nomot, 79  
inv\_fast\_nomot\_set\_gyro\_bias, 79  
inv\_get\_fast\_nomot\_accel\_param, 79  
inv\_get\_fast\_nomot\_compass\_param, 80  
inv\_init\_fast\_nomot, 80  
inv\_set\_default\_number\_of\_samples, 80  
inv\_set\_fast\_nomot\_accel\_threshold, 80  
inv\_set\_fast\_nomot\_compass\_threshold, 81  
inv\_start\_fast\_nomot, 81  
inv\_stop\_fast\_nomot, 81  
get\_highest\_bit\_position  
ml\_math\_func, 35  
gyro\_tc, 86  
INV\_GTC\_SAVE\_KEY, 86  
inv\_disable\_gyro\_tc, 87  
inv\_enable\_gyro\_tc, 87  
inv\_init\_gyro\_ts, 87  
inv\_start\_gyro\_tc, 87  
inv\_stop\_gyro\_tc, 87  
hal\_outputs, 25  
inv\_enable\_hal\_outputs, 26  
inv\_generate\_hal\_outputs, 26  
inv\_get\_sensor\_type\_accelerometer, 27  
inv\_get\_sensor\_type\_geomagnetic\_rotation\_vector, 27  
inv\_get\_sensor\_type\_gravity, 27  
inv\_get\_sensor\_type\_gyroscope, 28  
inv\_get\_sensor\_type\_gyroscope\_raw, 28  
inv\_get\_sensor\_type\_linear\_acceleration, 29  
inv\_get\_sensor\_type\_magnetic\_field, 29  
inv\_get\_sensor\_type\_magnetic\_field\_raw, 29  
inv\_get\_sensor\_type\_orientation, 30  
inv\_get\_sensor\_type\_rotation\_vector, 31  
inv\_init\_hal\_outputs, 32  
inv\_start\_hal\_outputs, 32  
inv\_stop\_hal\_outputs, 32  
heading\_from\_gyro, 88  
inv\_disable\_heading\_from\_gyro, 88  
inv\_enable\_heading\_from\_gyro, 88  
inv\_init\_heading\_from\_gyro, 89  
inv\_start\_heading\_from\_gyro, 89  
inv\_stop\_heading\_from\_gyro, 89  
inv\_9x\_fusion\_enable\_jitter\_reduction  
nine\_axis\_fusion, 82  
inv\_9x\_fusion\_set\_mag\_fb  
nine\_axis\_fusion, 83  
inv\_9x\_fusion\_use\_timestamps  
nine\_axis\_fusion, 83  
inv\_accel\_was\_turned\_off

data\_builder, 7  
inv\_angle\_diff  
    ml\_math\_func, 35  
inv\_apply\_calibration  
    data\_builder, 7  
inv\_build\_accel  
    data\_builder, 8  
inv\_build\_compass  
    data\_builder, 8  
inv\_build\_gyro  
    data\_builder, 9  
inv\_build\_quat  
    data\_builder, 9  
inv\_build\_temp  
    data\_builder, 10  
inv\_compass\_was\_turned\_off  
    data\_builder, 10  
inv\_convert\_to\_body  
    ml\_math\_func, 35  
inv\_convert\_to\_body\_with\_scale  
    ml\_math\_func, 36  
inv\_convert\_to\_chip  
    ml\_math\_func, 36  
inv\_disable\_9x\_sensor\_fusion  
    nine\_axis\_fusion, 83  
inv\_disable\_compass\_bias\_w\_gyro  
    small\_motion\_compass\_cal, 72  
inv\_disable\_compass\_fit  
    compass\_fit, 74  
inv\_disable\_fast\_nomot  
    fast\_no\_mot, 79  
inv\_disable\_gyro\_tc  
    gyro\_tc, 87  
inv\_disable\_heading\_from\_gyro  
    heading\_from\_gyro, 88  
inv\_disable\_in\_use\_auto\_calibration  
    accel\_calibration, 71  
inv\_disable\_magnetic\_disturbance  
    mag\_disturb, 90  
inv\_disable\_magnetic\_disturbance\_logging  
    mag\_disturb, 90  
inv\_disable\_motion\_no\_motion  
    motion\_no\_motion, 92  
inv\_disable\_no\_gyro\_fusion  
    no\_gyro\_fusion, 95  
inv\_disable\_vector\_compass\_cal  
    compass\_vector\_cal, 76  
inv\_enable\_9x\_sensor\_fusion  
    nine\_axis\_fusion, 84  
inv\_enable\_compass\_bias\_w\_gyro  
    small\_motion\_compass\_cal, 72  
inv\_enable\_compass\_fit  
    compass\_fit, 74  
inv\_enable\_fast\_nomot  
    fast\_no\_mot, 79  
inv\_enable\_gyro\_tc  
    gyro\_tc, 87  
inv\_enable\_hal\_outputs  
    hal\_outputs, 26  
inv\_enable\_heading\_from\_gyro  
    heading\_from\_gyro, 88  
inv\_enable\_in\_use\_auto\_calibration  
    accel\_calibration, 71  
inv\_enable\_magnetic\_disturbance  
    mag\_disturb, 91  
inv\_enable\_magnetic\_disturbance\_logging  
    mag\_disturb, 91  
inv\_enable\_motion\_no\_motion  
    motion\_no\_motion, 93  
inv\_enable\_no\_gyro\_fusion  
    no\_gyro\_fusion, 95  
inv\_enable\_quaternion  
    mpl, 45  
inv\_enable\_vector\_compass\_cal  
    compass\_vector\_cal, 76  
inv\_execute\_mpl\_start\_notification  
    start\_manager, 65  
inv\_execute\_on\_data  
    data\_builder, 10  
inv\_fast\_nomot\_set\_gyro\_bias  
    fast\_no\_mot, 79  
inv\_fast\_sqrt  
    ml\_math\_func, 36  
inv\_generate\_hal\_outputs  
    hal\_outputs, 26  
inv\_generate\_results  
    results\_holder, 51  
inv\_get\_6\_axis\_compass\_accel\_timestamp  
    data\_builder, 10  
inv\_get\_6\_axis\_gyro\_accel\_timestamp  
    data\_builder, 11  
inv\_get\_6axis\_quaternion



## INDEX

101

results\_holder, [51](#)  
inv\_get\_6axis\_quaternion\_float  
    results\_holder, [51](#)  
inv\_get\_9\_axis\_timestamp  
    data\_builder, [11](#)  
inv\_get\_acc\_state  
    results\_holder, [52](#)  
inv\_get\_accel  
    results\_holder, [52](#)  
inv\_get\_accel\_accuracy  
    data\_builder, [11](#)  
inv\_get\_accel\_bias  
    data\_builder, [11](#)  
inv\_get\_accel\_bias\_dmp\_units  
    data\_builder, [12](#)  
inv\_get\_accel\_compass\_confidence\_interval  
    results\_holder, [52](#)  
inv\_get\_accel\_float  
    results\_holder, [52](#)  
inv\_get\_accel\_on  
    data\_builder, [12](#)  
inv\_get\_accel\_quaternion  
    results\_holder, [53](#)  
inv\_get\_accel\_sensitivity  
    data\_builder, [12](#)  
inv\_get\_accel\_set  
    data\_builder, [12](#)  
inv\_get\_compass\_bias  
    data\_builder, [12](#)  
inv\_get\_compass\_bias\_error  
    results\_holder, [53](#)  
inv\_get\_compass\_on  
    data\_builder, [13](#)  
inv\_get\_compass\_sensitivity  
    data\_builder, [13](#)  
inv\_get\_compass\_set  
    data\_builder, [13](#)  
inv\_get\_compass\_set\_raw  
    data\_builder, [13](#)  
inv\_get\_compass\_soft\_iron\_input\_data  
    data\_builder, [14](#)  
inv\_get\_compass\_soft\_iron\_matrix\_d  
    data\_builder, [14](#)  
inv\_get\_compass\_soft\_iron\_matrix\_f  
    data\_builder, [14](#)  
inv\_get\_compass\_soft\_iron\_output\_data  
    data\_builder, [14](#)  
inv\_get\_compass\_state  
    results\_holder, [53](#)  
inv\_get\_earth\_magnetic\_local\_field\_parameter  
    results\_holder, [53](#)  
inv\_get\_factory\_accel\_bias\_mask  
    data\_builder, [14](#)  
inv\_get\_fast\_nomot\_accel\_param  
    fast\_no\_mot, [79](#)  
inv\_get\_fast\_nomot\_compass\_param  
    fast\_no\_mot, [80](#)  
inv\_get\_geomagnetic\_quaternion  
    results\_holder, [54](#)  
inv\_get\_geomagnetic\_quaternion\_float  
    results\_holder, [54](#)  
inv\_get\_gravity  
    results\_holder, [54](#)  
inv\_get\_gyro  
    data\_builder, [15](#)  
inv\_get\_gyro\_accuracy  
    data\_builder, [15](#)  
inv\_get\_gyro\_bias  
    data\_builder, [15](#)  
inv\_get\_gyro\_bias\_dmp\_units  
    data\_builder, [15](#)  
inv\_get\_gyro\_float  
    results\_holder, [55](#)  
inv\_get\_gyro\_on  
    data\_builder, [16](#)  
inv\_get\_gyro\_sensitivity  
    data\_builder, [16](#)  
inv\_get\_gyro\_set  
    data\_builder, [16](#)  
inv\_get\_gyro\_set\_raw  
    data\_builder, [16](#)  
inv\_get\_gyro\_sum\_of\_sqr  
    ml\_math\_func, [36](#)  
inv\_get\_heading\_confidence\_interval  
    results\_holder, [55](#)  
inv\_get\_large\_mag\_field  
    results\_holder, [55](#)  
inv\_get\_last\_timestamp  
    data\_builder, [17](#)  
inv\_get\_linear\_accel  
    results\_holder, [55](#)  
inv\_get\_linear\_accel\_float

results\_holder, [56](#)  
inv\_get\_local\_field\_status  
    results\_holder, [56](#)  
inv\_get\_mag\_accuracy  
    data\_builder, [17](#)  
inv\_get\_mag\_scale  
    results\_holder, [56](#)  
inv\_get\_message\_level\_0  
    message\_layer, [42](#)  
inv\_get\_motion\_state  
    results\_holder, [57](#)  
inv\_get\_mpl\_accel\_bias  
    data\_builder, [17](#)  
inv\_get\_mpl\_gyro\_bias  
    data\_builder, [17](#)  
inv\_get\_mpl\_mag\_field\_status  
    results\_holder, [57](#)  
inv\_get\_mpl\_magnetic\_local\_field\_parameter  
    results\_holder, [57](#)  
inv\_get\_mpl\_state\_size  
    storage\_manager, [67](#)  
inv\_get\_quaternion  
    results\_holder, [57](#)  
inv\_get\_quaternion\_float  
    results\_holder, [58](#)  
inv\_get\_quaternion\_set  
    results\_holder, [58](#)  
inv\_get\_quaternion\_validity  
    results\_holder, [58](#)  
inv\_get\_raw\_compass  
    data\_builder, [17](#)  
inv\_get\_result\_holder\_status  
    results\_holder, [59](#)  
inv\_get\_sensor\_type\_accelerometer  
    hal\_outputs, [27](#)  
inv\_get\_sensor\_type\_geomagnetic\_rotation-  
    \_vector  
    hal\_outputs, [27](#)  
inv\_get\_sensor\_type\_gravity  
    hal\_outputs, [27](#)  
inv\_get\_sensor\_type\_gyroscope  
    hal\_outputs, [28](#)  
inv\_get\_sensor\_type\_gyroscope\_raw  
    hal\_outputs, [28](#)  
inv\_get\_sensor\_type\_linear\_acceleration  
    hal\_outputs, [29](#)  
inv\_get\_sensor\_type\_magnetic\_field  
    hal\_outputs, [29](#)  
inv\_get\_sensor\_type\_magnetic\_field\_raw  
    hal\_outputs, [29](#)  
inv\_get\_sensor\_type\_orientation  
    hal\_outputs, [30](#)  
inv\_get\_sensor\_type\_rotation\_vector  
    hal\_outputs, [31](#)  
inv\_get\_temp\_set  
    data\_builder, [18](#)  
inv\_get\_version  
    mpl, [45](#)  
inv\_got\_accel\_bias  
    results\_holder, [59](#)  
inv\_got\_compass\_bias  
    results\_holder, [59](#)  
inv\_gyro\_was\_turned\_off  
    data\_builder, [18](#)  
inv\_init\_9x\_fusion  
    nine\_axis\_fusion, [84](#)  
inv\_init\_compass\_bias\_w\_gyro  
    small\_motion\_compass\_cal, [73](#)  
inv\_init\_compass\_fit  
    compass\_fit, [75](#)  
inv\_init\_fast\_nomot  
    fast\_no\_mot, [80](#)  
inv\_init\_gyro\_ts  
    gyro\_tc, [87](#)  
inv\_init\_hal\_outputs  
    hal\_outputs, [32](#)  
inv\_init\_heading\_from\_gyro  
    heading\_from\_gyro, [89](#)  
inv\_init\_motion\_no\_motion  
    motion\_no\_motion, [93](#)  
inv\_init\_mpl  
    mpl, [45](#)  
inv\_init\_no\_gyro\_fusion  
    no\_gyro\_fusion, [96](#)  
inv\_init\_quaternion  
    mpl, [45](#)  
inv\_init\_results\_holder  
    results\_holder, [59](#)  
inv\_init\_start\_manager  
    start\_manager, [65](#)  
inv\_init\_storage\_manager  
    storage\_manager, [68](#)

## INDEX

103

inv\_init\_vector\_compass\_cal  
compass\_vector\_cal, [77](#)

inv\_inverse\_sqrt  
ml\_math\_func, [37](#)

inv\_load\_mpl\_states  
storage\_manager, [68](#)

inv\_one\_over\_x  
ml\_math\_func, [37](#)

inv\_orientation\_matrix\_to\_scalar  
ml\_math\_func, [37](#)

inv\_q29\_mult  
ml\_math\_func, [38](#)

inv\_q30\_mult  
ml\_math\_func, [38](#)

inv\_q\_add  
ml\_math\_func, [39](#)

inv\_q\_mult  
ml\_math\_func, [39](#)

inv\_q\_norm4  
ml\_math\_func, [39](#)

inv\_q\_shift\_mult  
ml\_math\_func, [39](#)

inv\_quaternion\_sensor\_was\_turned\_off  
data\_builder, [18](#)

inv\_quaternion\_to\_rotation  
ml\_math\_func, [40](#)

inv\_quaternion\_to\_rotation\_vector  
ml\_math\_func, [40](#)

inv\_register\_load\_store  
storage\_manager, [68](#)

inv\_register\_mpl\_start\_notification  
start\_manager, [66](#)

inv\_save\_mpl\_states  
storage\_manager, [69](#)

inv\_set\_acc\_state  
results\_holder, [60](#)

inv\_set\_accel\_accuracy  
data\_builder, [18](#)

inv\_set\_accel\_bandwidth  
data\_builder, [18](#)

inv\_set\_accel\_bias  
data\_builder, [19](#)

inv\_set\_accel\_bias\_found  
results\_holder, [60](#)

inv\_set\_accel\_bias\_mask  
data\_builder, [19](#)

inv\_set\_accel\_compass\_confidence\_interval  
results\_holder, [60](#)

inv\_set\_accel\_orientation\_and\_scale  
data\_builder, [19](#)

inv\_set\_accel\_sample\_rate  
data\_builder, [20](#)

inv\_set\_compass\_bandwidth  
data\_builder, [20](#)

inv\_set\_compass\_bias  
data\_builder, [20](#)

inv\_set\_compass\_bias\_error  
results\_holder, [60](#)

inv\_set\_compass\_bias\_found  
results\_holder, [61](#)

inv\_set\_compass\_disturbance  
data\_builder, [20](#)

inv\_set\_compass\_orientation\_and\_scale  
data\_builder, [20](#)

inv\_set\_compass\_sample\_rate  
data\_builder, [21](#)

inv\_set\_compass\_soft\_iron\_input\_data  
data\_builder, [21](#)

inv\_set\_compass\_soft\_iron\_matrix\_d  
data\_builder, [21](#)

inv\_set\_compass\_soft\_iron\_matrix\_f  
data\_builder, [21](#)

inv\_set\_compass\_state  
results\_holder, [61](#)

inv\_set\_default\_number\_of\_samples  
fast\_no\_mot, [80](#)

inv\_set\_earth\_magnetic\_local\_field\_parameter  
results\_holder, [61](#)

inv\_set\_fast\_nomot\_accel\_threshold  
fast\_no\_mot, [80](#)

inv\_set\_fast\_nomot\_compass\_threshold  
fast\_no\_mot, [81](#)

inv\_set\_gyro\_bandwidth  
data\_builder, [22](#)

inv\_set\_gyro\_bias  
data\_builder, [22](#)

inv\_set\_gyro\_orientation\_and\_scale  
data\_builder, [22](#)

inv\_set\_gyro\_sample\_rate  
data\_builder, [22](#)

inv\_set\_heading\_confidence\_interval  
results\_holder, [61](#)

inv\_set\_large\_mag\_field  
    results\_holder, 61

inv\_set\_local\_field\_status  
    results\_holder, 62

inv\_set\_local\_magnetic\_field  
    results\_holder, 62

inv\_set\_mag\_scale  
    results\_holder, 62

inv\_set\_message  
    message\_layer, 42

inv\_set\_motion\_state  
    results\_holder, 62

inv\_set\_mpl\_gyro\_bias  
    data\_builder, 23

inv\_set\_mpl\_mag\_field\_status  
    results\_holder, 63

inv\_set\_mpl\_magnetic\_local\_field\_parameters  
    results\_holder, 63

inv\_set\_no\_motion\_time  
    motion\_no\_motion, 93

inv\_set\_quat\_sample\_rate  
    data\_builder, 23

inv\_set\_quaternion  
    mpl, 46

inv\_set\_quaternion\_validity  
    results\_holder, 63

inv\_set\_result\_holder\_status  
    results\_holder, 63

inv\_start\_9x\_sensor\_fusion  
    nine\_axis\_fusion, 84

inv\_start\_compass\_bias\_w\_gyro  
    small\_motion\_compass\_cal, 73

inv\_start\_compass\_fit  
    compass\_fit, 75

inv\_start\_fast\_nomot  
    fast\_no\_mot, 81

inv\_start\_gyro\_tc  
    gyro\_tc, 87

inv\_start\_hal\_outputs  
    hal\_outputs, 32

inv\_start\_heading\_from\_gyro  
    heading\_from\_gyro, 89

inv\_start\_in\_use\_auto\_calibration  
    accel\_calibration, 71

inv\_start\_magnetic\_disturbance  
    mag\_disturb, 91

inv\_start\_motion\_no\_motion  
    motion\_no\_motion, 93

inv\_start\_mpl  
    mpl, 46

inv\_start\_no\_gyro\_fusion  
    no\_gyro\_fusion, 96

inv\_start\_quaternion  
    mpl, 46

inv\_start\_results\_holder  
    results\_holder, 63

inv\_start\_vector\_compass\_cal  
    compass\_vector\_cal, 77

inv\_stop\_9x\_sensor\_fusion  
    nine\_axis\_fusion, 84

inv\_stop\_compass\_bias\_w\_gyro  
    small\_motion\_compass\_cal, 73

inv\_stop\_compass\_fit  
    compass\_fit, 75

inv\_stop\_fast\_nomot  
    fast\_no\_mot, 81

inv\_stop\_gyro\_tc  
    gyro\_tc, 87

inv\_stop\_hal\_outputs  
    hal\_outputs, 32

inv\_stop\_heading\_from\_gyro  
    heading\_from\_gyro, 89

inv\_stop\_in\_use\_auto\_calibration  
    accel\_calibration, 71

inv\_stop\_magnetic\_disturbance  
    mag\_disturb, 91

inv\_stop\_motion\_no\_motion  
    motion\_no\_motion, 94

inv\_stop\_no\_gyro\_fusion  
    no\_gyro\_fusion, 96

inv\_stop\_quaternion  
    mpl, 46

inv\_stop\_vector\_compass\_cal  
    compass\_vector\_cal, 77

inv\_temperature\_was\_turned\_off  
    data\_builder, 23

inv\_unregister\_mpl\_start\_notification  
    start\_manager, 66

inv\_vector\_norm  
    ml\_math\_func, 40

inv\_verify\_6x\_fusion\_data  
    mpl, 46

## INDEX

105

inv\_verify\_9x\_fusion\_data  
    nine\_axis\_fusion, 84  
inv\_verify\_no\_gyro\_fusion\_data  
    no\_gyro\_fusion, 96  
inv\_wrap\_angle  
    ml\_math\_func, 41  
  
mag\_disturb, 90  
    inv\_disable\_magnetic\_disturbance, 90  
    inv\_disable\_magnetic\_disturbance\_logging, 90  
    inv\_enable\_magnetic\_disturbance, 91  
    inv\_enable\_magnetic\_disturbance\_logging, 91  
    inv\_start\_magnetic\_disturbance, 91  
    inv\_stop\_magnetic\_disturbance, 91  
message\_layer, 42  
    inv\_get\_message\_level\_0, 42  
    inv\_set\_message, 42  
ml\_math\_func, 33  
    get\_highest\_bit\_position, 35  
    inv\_angle\_diff, 35  
    inv\_convert\_to\_body, 35  
    inv\_convert\_to\_body\_with\_scale, 36  
    inv\_convert\_to\_chip, 36  
    inv\_fast\_sqrt, 36  
    inv\_get\_gyro\_sum\_of\_sqr, 36  
    inv\_inverse\_sqrt, 37  
    inv\_one\_over\_x, 37  
    inv\_orientation\_matrix\_to\_scalar, 37  
    inv\_q29\_mult, 38  
    inv\_q30\_mult, 38  
    inv\_q\_add, 39  
    inv\_q\_mult, 39  
    inv\_q\_norm4, 39  
    inv\_q\_shift\_mult, 39  
    inv\_quaternion\_to\_rotation, 40  
    inv\_quaternion\_to\_rotation\_vector, 40  
    inv\_vector\_norm, 40  
    inv\_wrap\_angle, 41  
    test\_limits\_and\_scale, 41  
motion\_no\_motion, 92  
    inv\_disable\_motion\_no\_motion, 92  
    inv\_enable\_motion\_no\_motion, 93  
    inv\_init\_motion\_no\_motion, 93  
    inv\_set\_no\_motion\_time, 93  
    inv\_start\_motion\_no\_motion, 93  
    inv\_stop\_motion\_no\_motion, 94  
mpl, 44  
    inv\_enable\_quaternion, 45  
    inv\_get\_version, 45  
    inv\_init\_mpl, 45  
    inv\_init\_quaternion, 45  
    inv\_set\_quaternion, 46  
    inv\_start\_mpl, 46  
    inv\_start\_quaternion, 46  
    inv\_stop\_quaternion, 46  
    inv\_verify\_6x\_fusion\_data, 46  
    nine\_axis\_fusion, 82  
    inv\_9x\_fusion\_enable\_jitter\_reduction, 82  
    inv\_9x\_fusion\_set\_mag\_fb, 83  
    inv\_9x\_fusion\_use\_timestamps, 83  
    inv\_disable\_9x\_sensor\_fusion, 83  
    inv\_enable\_9x\_sensor\_fusion, 84  
    inv\_init\_9x\_fusion, 84  
    inv\_start\_9x\_sensor\_fusion, 84  
    inv\_stop\_9x\_sensor\_fusion, 84  
    inv\_verify\_9x\_fusion\_data, 84  
no\_gyro\_fusion, 95  
    inv\_disable\_no\_gyro\_fusion, 95  
    inv\_enable\_no\_gyro\_fusion, 95  
    inv\_init\_no\_gyro\_fusion, 96  
    inv\_start\_no\_gyro\_fusion, 96  
    inv\_stop\_no\_gyro\_fusion, 96  
    inv\_verify\_no\_gyro\_fusion\_data, 96  
results\_holder, 48  
    inv\_generate\_results, 51  
    inv\_get\_6axis\_quaternion, 51  
    inv\_get\_6axis\_quaternion\_float, 51  
    inv\_get\_acc\_state, 52  
    inv\_get\_accel, 52  
    inv\_get\_accel\_compass\_confidence\_interval, 52  
    inv\_get\_accel\_float, 52  
    inv\_get\_accel\_quaternion, 53  
    inv\_get\_compass\_bias\_error, 53  
    inv\_get\_compass\_state, 53  
    inv\_get\_earth\_magnetic\_local\_field\_parameter, 53

[inv\\_get\\_geomagnetic\\_quaternion, 54](#)  
[inv\\_get\\_geomagnetic\\_quaternion\\_float, 54](#)  
[inv\\_get\\_gravity, 54](#)  
[inv\\_get\\_gyro\\_float, 55](#)  
[inv\\_get\\_heading\\_confidence\\_interval, 55](#)  
[inv\\_get\\_large\\_mag\\_field, 55](#)  
[inv\\_get\\_linear\\_accel, 55](#)  
[inv\\_get\\_linear\\_accel\\_float, 56](#)  
[inv\\_get\\_local\\_field\\_status, 56](#)  
[inv\\_get\\_mag\\_scale, 56](#)  
[inv\\_get\\_motion\\_state, 57](#)  
[inv\\_get\\_mpl\\_mag\\_field\\_status, 57](#)  
[inv\\_get\\_mpl\\_magnetic\\_local\\_field\\_parameter, 57](#)  
[inv\\_get\\_quaternion, 57](#)  
[inv\\_get\\_quaternion\\_float, 58](#)  
[inv\\_get\\_quaternion\\_set, 58](#)  
[inv\\_get\\_quaternion\\_validity, 58](#)  
[inv\\_get\\_result\\_holder\\_status, 59](#)  
[inv\\_got\\_accel\\_bias, 59](#)  
[inv\\_got\\_compass\\_bias, 59](#)  
[inv\\_init\\_results\\_holder, 59](#)  
[inv\\_set\\_acc\\_state, 60](#)  
[inv\\_set\\_accel\\_bias\\_found, 60](#)  
[inv\\_set\\_accel\\_compass\\_confidence\\_interval, 60](#)  
[inv\\_set\\_compass\\_bias\\_error, 60](#)  
[inv\\_set\\_compass\\_bias\\_found, 61](#)  
[inv\\_set\\_compass\\_state, 61](#)  
[inv\\_set\\_earth\\_magnetic\\_local\\_field\\_parameter, 61](#)  
[inv\\_set\\_heading\\_confidence\\_interval, 61](#)  
[inv\\_set\\_large\\_mag\\_field, 61](#)  
[inv\\_set\\_local\\_field\\_status, 62](#)  
[inv\\_set\\_local\\_magnetic\\_field, 62](#)  
[inv\\_set\\_mag\\_scale, 62](#)  
[inv\\_set\\_motion\\_state, 62](#)  
[inv\\_set\\_mpl\\_mag\\_field\\_status, 63](#)  
[inv\\_set\\_mpl\\_magnetic\\_local\\_field\\_parameter, 63](#)  
[inv\\_set\\_quaternion\\_validity, 63](#)  
[inv\\_set\\_result\\_holder\\_status, 63](#)  
[inv\\_start\\_results\\_holder, 63](#)  
[set\\_sensor\\_orientation\\_and\\_scale](#)  
[data\\_builder, 23](#)  
[small\\_motion\\_compass\\_cal, 72](#)  
[inv\\_disable\\_compass\\_bias\\_w\\_gyro, 72](#)  
[inv\\_enable\\_compass\\_bias\\_w\\_gyro, 72](#)  
[inv\\_init\\_compass\\_bias\\_w\\_gyro, 73](#)  
[inv\\_start\\_compass\\_bias\\_w\\_gyro, 73](#)  
[inv\\_stop\\_compass\\_bias\\_w\\_gyro, 73](#)  
[start\\_manager, 65](#)  
[inv\\_execute\\_mpl\\_start\\_notification, 65](#)  
[inv\\_init\\_start\\_manager, 65](#)  
[inv\\_register\\_mpl\\_start\\_notification, 66](#)  
[inv\\_unregister\\_mpl\\_start\\_notification, 66](#)  
[storage\\_manager, 67](#)  
[inv\\_get\\_mpl\\_state\\_size, 67](#)  
[inv\\_init\\_storage\\_manager, 68](#)  
[inv\\_load\\_mpl\\_states, 68](#)  
[inv\\_register\\_load\\_store, 68](#)  
[inv\\_save\\_mpl\\_states, 69](#)  
[test\\_limits\\_and\\_scale](#)  
[ml\\_math\\_func, 41](#)