

Website www.radiodata.com

Switchboard (+2711) 616 7685/3351

Fax (+27 11) 616 1706

Physical address 2nd & 3rd floors, Sovereign House
 cnr Sovereign Street and Mullins Road
 Bedford Gardens
 S: 26° 11' 47"
 E: 28° 07' 12"

Postal address Postnet Suite 79
 Private Bag X19
 Gardenview
 2047

Sales **Lee-Ann Andreka**
 083 377 7045
 leeanne.rdc@mwweb.co.za
 Skype: leeanne.andreka

Deirdré Oberholzer
 deirdre.rdc@mwweb.co.za
 Skype: rdcsales

Monique Taylor
 monique.rdc@mwweb.co.za
 Skype: rdcsales

Technical **24 Hour technical standby**
 082 444 7176

Maurizio Borsato
 maurizio.rdc@mwweb.co.za
 Skype: rdc.technical

Accounts **Deborah Patterson**
 debbie.rdc@mwweb.co.za

Management **Brent Andreka**
 brent.rdc@mwweb.co.za

Lee-Ann Andreka
 leeanne.rdc@mwweb.co.za



REPORTER 8102

RADIO MONITORING STATION



The Reporter 8102 is designed to receive transmitter codes in a control room or operate as a stand alone intelligent repeater. It incorporates a transceiver, decoder, power supply, backup battery and can be used as either a base station or a repeater. The Reporter X20 coding system enables it to receive 20 by 8000 transmitter codes.

Incoming code information can be read off a four line LCD display .

Reporter 8102 is designed to meet all your security monitoring needs. Software upgrades enables the user to upgrade equipment with ease.



USERS MANUAL

CONTENTS	PAGE NO
Introduction	Cover Page
Safety Information	Page 2
Reporter 8102 Features	Page 2
Reporter 8102 Specifications	Page 2
Single User Operation	Page 3
Multi User Operation	Page 3
Unpacking Your Equipment	Page 4
Location Of Controls and Ports	Page 4
Installation	Page 5
Operation	Page 6
<ul style="list-style-type: none"> ● Startup display ● Startup printout ● Volume and Squelch controls ● Monitor and transmit indicators 	
Reset button operation	Page 6
<ul style="list-style-type: none"> ● Time and date printout ● Buzzer reset ● Code received information 	
Time and date set	Page 6 / 7
<ul style="list-style-type: none"> ● Other printouts from Reporter ● Finding switch selection banks 	
Switch Setting Instructions	Page 8
Selecting base or repeater operation	Page 9
<ul style="list-style-type: none"> ● Talk thru setup 	
RS232 Serial Port Protocol	Page 9
RS232 Cable Connection	Page 10
<ul style="list-style-type: none"> ● Telemetry information 	
Trouble Shooting	Page 10
<ul style="list-style-type: none"> ● Loop Test Transmitter 	

RS 232 CABLE CONNECTION TO COMPUTER

REPORTER

DB 9 Female

Pin 3 - Data Tx Pin 2 - Data Rx
Pin 5 - Data Ground --- Pin 5 - Data Ground

COMPUTER

DB 25 Female

Pin 3 - Data Rx
Pin 7 - Data Ground

TELEMETRY INFORMATION	DECODER OUTPUTS	ASCII CONVERSIONS
Telemetry Function	Standard3	Digit Hex Decimal
alarm	0	000 30 48
lock up	1	001 31 49
open up	2	002 32 50
emergency	3	003 33 51
telemetry 1	4	004 34 52
telemetry 2	5	005 35 53
telemetry 3	6	006 36 54
telemetry 4	7	007 37 55
mains fail	8	010 8A 138
mains restore	9	011 8B 139
customer test	A	012 8C 140
engineer test	B	013 8D 141
customer duress	C	014 8E 142
customer error	D	015 8F 143
medical alert	E	016 90 144
power up	F	017 91 145
fire alarm	0	018 92 146
fridge alarm	1	019 93 147
status lock	2	020 94 148
status lock	3	021 95 149
status lock	4	022 96 150
status lock	5	023 97 151
status lock	6	024 98 152
status lock	7	025 99 153
status lock	8	026 9A 154
status lock	9	027 9B 155
status open	A	040 A8 168
status open	B	041 A9 169
status open	C	042 AA 170
status open	D	043 AB 171
status open	E	044 AC 172
status open	F	045 AD 173
status open	0	046 AE 174
status open	1	047 AF 175
telemetry 5	2	060 BC 188
telemetry 8	3	063 BF 191

LOOP TEST TRANSMITTER

In order to test repeater and decoder operation, a loop test transmitter must be installed in the control room. The transmitter can be activated by a switch or remote to send a code to the repeater network in order to determine if all repeaters are receiving and communicating with the base station. The activation can be done manually or with a timing circuit. It is important to note that this operation will assist you to identify repeater network, range or no coding trouble shooting.

TROUBLE SHOOTING

Most problems with your Reporter 8102 can be solved by one or more of the following solutions. If after trying these solutions, you still have problems, contact RDC and one of our service technicians will assist you.

- Check the AC adapter connections to the wall outlet and to the Reporter.
- Be sure the AC 3 pin plug is connected to a live outlet (Test with DVM or AC lamp).
- Be sure that the battery is connected and charging in case of AC failure.
- Check that computer and printer connections are correct and secure (Only use original cables as supplied).
- Do audio checks to ensure that incoming codes are decoded.
- The printer will only operate when Switch Bank (SW) 2 number 1 is switched on.
- Check that your antenna connector to the base station is correct and secure.

BEFORE CALLING FOR TECHNICAL SUPPORT


Before calling Technical Support, please have the following information available. This will assist the Technician in helping you quickly and more efficiently :

- A brief description of the problem.
- Network information : Repeater locations and Numbers, Base station location and antennas installed on all equipment.
- Startup printout from base station (This will indicate software and parity settings).
- Printout of loop test transmitter tested from control room (Indicating repeaters received).

REPORTER 8102 SINGLE USER OPERATION


In standard operation transmitters are received by the Reporter base station followed by the Reporter repeaters which will download the code information in repeater number order. The base and repeaters can store multiple code numbers and download them as free airtime is available. The Reporter base can accommodate eight thousand transmitters which can be extended by another nineteen times eight thousand. In this mode an alpha prefix is used to identify each string of eight thousand transmitter code numbers.

NOTE: The base will transmit a 7999 engineer test to the repeaters if no codes were decoded for 60 minutes.



REPORTER 8102 MULTI USER OPERATION




The solution to the high band frequency shortage



The X20 coding used by the Reporter 8102 accommodates twenty users with eight thousand transmitters each. Each user shares a common repeater network but receive only their own transmitter codes. The service provider Reporter decoder can be programmed to receive all the multi users in order to provide additional backup to the users. In this mode an alpha prefix will be added to the front of the code numbers received in order to identify the individual users.

NOTE: This is a standard feature and there is no additional upgrade required

SWITCH SETTING INSTRUCTIONS



SW2 SWITCH NO 1-4 SETTINGS FOR REPEATER OPERATION

REP 1	1 - ON 2 - OFF 3 - OFF 4 - OFF	REP 2	1 - OFF 2 - ON 3 - OFF 4 - OFF	REP 3	1 - ON 2 - ON 3 - OFF 4 - OFF	REP 4	1 - OFF 2 - OFF 3 - ON 4 - OFF	REP 5	1 - ON 2 - OFF 3 - ON 4 - OFF
REP 6	1 - OFF 2 - ON 3 - ON 4 - OFF	REP 7	1 - ON 2 - ON 3 - ON 4 - OFF						

SW2 SWITCH NO 1-4 SETTINGS FOR BASE OPERATION

BASE	1 - OFF 2 - OFF 3 - OFF 4 - OFF
------	--

OTHER PRINTOUTS
RECEIVED FROM
REPORTER

Code Received Print Out

Mode D	Rep L	Frame 1	Code 4129	Alarm	01-01-97	16:33:10	Count 1
Mode X	Rep 5	Frame 1	Code 4129	Alarm	01-01-97	16:33:12	Count 2
1	2	3	4	5	6	7	8

- 1) Reporter decoding mode: D = Digital local
X = X20 Type coding
d = Digital Repeated
- 2) Repeater Number information: L = Local Reception (Direct)
1 to 7 indicates the repeater received ID number
- 3) Frame No: Indicates frame sent by transmitter.
- 4) Code Number: Code number of transmitter received.
- 5) Telemetry Information:
Indicates telemetry received from transmitter .
- 6) Date: Date stamp when code was received.
- 7) Time: Time stamp when code was received.
- 8) Count: Indicates received count from transmitter.
(Direct + Repeater)

60 Minute self test print out

Indicates when the Reporter performs a 7999 engineer test.


**** 60 Minute Self Test Date 01-01-97 Time 16:30:49 ****

FINDING SWITCHES
AND SWITCH BANKS


There are three sets of switch banks on the CPU of the Reporter 8102. The switches are used to alter the functions or operation of the Reporter.

Here is where you find them.....

Remote Reset
and External Buzzer Connection



Top View - Cover Removed



- Remote Reset : Used for external reset switch / remote connection.
A closed contact is required for reset.
- External Buzzer : Output at 12 volt and 1 ampere maximum load.
Note polarity on terminal block.

UNPACKING YOUR EQUIPMENT

WHAT YOU SHOULD HAVE

BASE STATIONS

Reporter 8102



Power Cable



RS 232 Cable



REPEATERS

Reporter 8102




Power Cable



LOCATION OF CONTROLS AND PORTS


CONTROLS

1. Transmit LED: Indicates when 8102 is transmitting data.
2. Monitor LED: Indicates microprocessor operation.
3. Squelch Control: This control is used to select desired squelch threshold level. It does not affect signal reception.
4. Volume Control: Rotating the control clockwise will increase the volume.
5. Reset Switch: Used to retrieve information from the display and setting up time and date.
6. LCD Display: 4 Line display indicating code and telemetry information with time and date in English.



PORTS

1. Power Jack: Receives 220v AC through 15AMP kettle cord.
2. Printer Port: Accommodates all makes of dot matrix parallel printers.
3. RS232 Port: Communicates in 4 different Protocols.
4. Antenna Connector: Accommodates PL259 connector and 50 OHM antenna's.
5. Time set Switch: Initializes time and date set mode.
6. Optional Extra: Fits socket for external 12v DC input (e.g. Solar Panel).
7. Label: Indicating setup as base or repeater.



INSTALLATION

- 1) Connect Antenna




- 2) Connect Printer



- 3) Connect RS 232 Cable to computer
Note: Do not extend cable longer than 9 meters
Do not connect directly to more than one computer



- 4) Connect battery terminal onto battery
Note: Ensure firm connection without double touch



- 5) Replace lid on base station
Use key supplied with Reporter 8102



- 6) Connect 220v ac cord
Note: Ensure that wall socket is on and operating



**YOU ARE NOW READY
TO RECEIVE INCOMING CODES**

OPERATION

Start Up Display

Reporter 8102 ← a) Reporter Model
\$Revision: 1.2 ← b) Software Version Installed

Start Up Print Out

RADIO DATA COMMUNICATIONS (PTY) LTD
Reporter Model 8102
"Revision" 1.2
Date 06-02-97 Time 7:39:19
Digital Code Prefix = 4
Encoder Type = 5
Number System = D
Rom_ID_1 = 1
Rom_ID_2 = 0
Rom_ID_3 = 1

NOTE: Startup printout information will assist a service technician to check CPU settings.

Volume and Squelch controls

Volume and Squelch controls on the front of the Reporter is available for the user to select a comfortable audio level. It is important to monitor radio signals to ensure that incoming codes are decoded.

NOTE: Adjustment of both these controls have no effect on code reception.

Monitor and Transmit indicators

Monitor LED should flash approximately once every second, indicating that the processor is operating correctly.

Transmit LED indicates when the Reporter initiates a 60 minute repeater engineer test. As a repeater it will indicate when received data is repeated to the base station.

RESET BUTTON

Time and date printout

This is achieved by depressing the reset button and releasing.

Print Out

**** Date 01-01-97 **** Time 15:30:49

Buzzer reset / code acknowledge

After a code is received the buzzer can be reset by depressing the reset button. This feature is enabled with SW 2 number 8 switched on.

Code Acknowledge Print Out

**** 4129 Alarm received 16:33acknowledged 16:38

Code received information check

Information can be retrieved of codes on the display by depressing the reset button and holding it down.

Standard display Display With Reset Switch Depressed

1101 Alarm	12:06	05-02	12	*
5052 Emergency	12:08	05-02	3	*
1219 Open Up	09:01	06-02	9	*
2525 Lock Up	17:25	06-02	6	*

- 1) Code number received by reporter.
- 2) Telemetry received from transmitter.
- 3) Time when code was received.
- 4) Date (DD:MM) code was received.
- 5) Indicates total count received from transmitter. (Direct + Repeater)
- 6) * Appears when code acknowledge has been done with reset button.

TIME AND DATE SET

Time and date set mode is entered by depressing the time set button on the back of the reporter for at least one second. Time and date settings are altered by depressing the reset button.

Decoder will start with a "BEEP" you are now in time and date set mode.

Set Time 15:20	Set Date 01-01-97
----------------	-------------------

The cursor will flash on the time first and move from left to right. When the cursor is on the digit that needs to be altered - press reset button in short intervals to increment the digit until correct setting is achieved. The cursor will then continue moving onto the date where the same procedure can be used to alter the digits.

NOTE: If codes are received during this time they will be displayed, printed and sent to the computer when the Reporter returns to normal operation. In base station mode the reporter will transmit a 7999 engineer test if the date is altered.