

Open Programmer v0.10.0

**An open source USB programmer for PIC micros,
ATMEL micros, I2C-SPI-MicroWire-OneWire-UNIO
EEPROMs, generic I2C/SPI devices and (soon) other
devices**

Quick facts

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)
[How to ... Supported devices Communication protocol](#)
[The circuit Voltage regulator How to contribute Download History Links Contacts](#)

- Completely free and Open Source (including firmware)
- Programs PIC10-12-16-18-24, dsPIC30-33, ATMEL AVR (serial and HV serial programming), serial EEPROMs type 24xxxx (I2C), 25xxx (SPI), 93xx6 (MicroWire), DS24xx (OneWire), 11xxx (UNIO), communicates with generic I2C & SPI devices (see[supported devices](#))
- Can work as [ICD debugger](#)
- USB 2.0 Full Speed interface, HID class (same as keyboards, mice, etc.)
- Self powered
- Doesn't need drivers
- Built from easy to find components (estimated cost ~10€)
- Hardware generated timings for maximum speed and reliability (writes a 18F2550 in 15s)
- Doesn't saturate your CPU and doesn't suffer when other programs are running
- Open source control programs for Linux and Windows
- It's not another PicKit clone

Picture of a prototype:



[Top](#)
[Quick facts](#)
[Another programmer](#)
[USB & HID firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

Another programmer?

In the last few years, as serial and parallel interfaces have almost disappeared, electronics enthusiasts find even more difficult to program microcontrollers; old time programmers don't work any more; common solutions include using USB to serial adapters (which can't accept direct access but only slow API calls), or add-on interface chips, like FTDIxxxx, which appear substantially as serial interfaces and require custom or proprietary drivers.

So why not use PIC controllers and their native USB interface? After searching a while I couldn't find an USB programmer which was at the same time functional, free, and open source, so I decided to design one.

Open source means that all sources and schematics are given free of charge with the rights to modify and release them.

USB & HID firmware (v0.10.0)

In order to use the USB interface included in some PIC devices we need a firmware that implements one of the classes defined by the USB consortium or a new one; I opted for the HID class, which is supported natively by all operating systems and so doesn't need any driver. Maximum allowed speed is 64KB/s, although with my application I measured something in the range 20-40 KB/s, certainly enough to program devices with memory of 100KB at most.

Like all USB devices this one too has a vid and a pid; these are usually obtained under payment; I got a combination for free from [pid.codes](#): 0x1209&0x5432; anyways it's possible to

configure both, so I leave the choice to the user.

The programmer appears to the system as a HID device that exchanges 64 bytes packets every 1 ms.

The USB firmware comes from a nearly unknown open source project, written by Alexander Enzmann, which I modified and adapted to the MCC18 compiler.

I wrote a [brief guide](#) on how to use it; to my knowledge this is the only open source firmware with HID support and GPL license.

My programmer code simply adds a command interpreter that drives the microcontroller's outputs according to a set of instructions.

The main control cycle waits for a packet from USB, then executes commands in sequence while managing communication tasks; at the same time a control function is called periodically by a timer interrupt and keeps the DCDC regulator output voltage constant.

Building the project requires only free programs: MPLAB and MCC18 student version, which are unfortunately only available for the windows (in)operating system.

It's certainly possible to compile with SDCC, but some changes are needed to the source code.

Everything is given under the GPL2 license.

[Here](#) is the complete MPLAB project, [here](#) the hex file only.

[Here](#) a version (0.8.0) for 18F2450 (with reduced functionality, see [the circuit](#)).

Control programs

I initially thought of modifying an existing software, for example winpic or picprog, but I found it would be too difficult because I use packetized communications instead of serial; so I had to write one (two) from scratch.

Unfortunately, or fortunately, since I'm not a professional programmer I kept features at minimum; the result are very small but fast programs that don't use your CPU for nothing.

For most devices the code is verified while programming; for the others immediately following the writing phase.

Ideally you should have the same version number for both software and firmware, except for the last number which indicates minor changes and bug fixes; however I tried to keep the same protocol with each release, so that apart from new features it is often possible to use new software with older firmware and vice versa.

In case you wonder, the reason why it's not possible to program directly from MPLAB is not technical: Microchip does not release specifications of how to interface with its program; if you want them you have to be a commercial manufacturer and sign a non disclosure agreement, which is clearly impossible for a GPL2 open source project.

On the contrary, integration with Piklab is possible and I hope will be done soon; right now the custom programmer interface lacks some essential parameters, but whoever has the ability and time can fix it for sure.


GTK graphical interface for Windows and Linux (v0.10.0)

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)

[How to ...](#)
[Supported devices Communication protocol](#)
[The circuit Voltage regulator](#)
[How to contribute Download History Links Contacts](#)

OPGUI uses the GTK libraries so under Windows it's necessary to install the [GTK Runtime Environment](#).

A screenshot of Opgui:



A quick guide: buttons to read, write, load and save files are on the toolbar.

The "Data" tab shows what the programmer is doing.

On the "Device" tab it's possible to choose the device and modify some programming options, such as writing ID and calibration words, using the eeprom etc.; only settings compatible with the current device are considered.

Under "Options" are various general settings: USB connection, errors, log file, expansion boards; using the "Hardware Test" function and a voltmeter is possible to check that the circuit is working.

The "I2C/SPI" tab is useful for communicating with generic I2C and SPI devices; in case of I2C it's always necessary to specify the control byte (and address, if not zero); RW bit is handled automatically.

For example, to write manually 3 bytes on a 24xx16 at address 64 write: A0 40 1 2 3

From version 0.7.10 it is included an ICD debugger, working more or less like [pdb](#); in addition it supports coff files.

The "I/O" tab allows to control individual I/O lines and the power supplies.

Under "Utility" there are functions to convert a single hex line to data and vice versa.

There is no installer since there aren't any libraries and the executable is very small.

The program accepts hex8 and hex32 files, and also binary files in case of serial memories.

Supported languages are currently English and Italian; to add other languages it's necessary to generate the languages.rc file (-langfile option) and to modify it; the language id is before the respective strings, enclosed in square brackets [].

The language is chosen at startup by matching the system

[Top](#)
[Quick facts](#)
[Another programme](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC](#)
[Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

language (it can also be forced with `-lang`).

To enable access to the programmer under Linux see chapter [Command line interface](#).

You can find more info on the [OpenProg and Opgui user's guide](#) or in the [source code guide](#).

To compile the program from source (optional) you need to install the GTK libraries, GCC and the maketools (MinGW/MSYS in Windows); then write:

```
> make
```

To install it under Linux(if you wish):

```
> make install
```

[Download the compiled program ... or the sources](#).

[Top](#)

[Quick facts](#)

[Another](#)

[programme](#)

[USB &](#)

[HID](#)

[firmware](#)

[Control](#)

[programs](#)

[GTK](#)

[graphical](#)

[interface](#)

[MFC](#)

[Graphica](#)

[interface](#)

[Comman](#)

[line](#)

[interface](#)

[How to ...](#)

[Supported](#)

[devices](#)

[Communica](#)

[protocol](#)

[The circuit](#)

[Voltage](#)

[regulator](#)

[How to](#)

[contribute](#)

[Download](#)

[History](#)


[Links](#)

[Contacts](#)

Graphical interface for Windows (v0.9.1)

OpenProg is a C++ application written with Visual C++ 6 and MFC.

A screenshot of OpenProg:



Only the basic programming functions are implemented; it was the first GUI of the project, but currently development continues on OPGUI, so it may be dismissed in the future.

It has the advantage of working without any additional library.

Usage is the same as OPGUI; works with XP, VISTA, 7, 8.

Command-line options are:

`-d <device>` , selects a target

`-r <file name>` , reads the target and writes to file

`-w <file name>` , writes a file to the target

`-gui` , do not exit after writing or reading (only if `-w` or `-r` are specified)

You can find more info on the [OpenProg and Opgui user's guide](#) or in the [source code guide](#).

It may be of interest the fact that the DDK (driver development kit) is not required for compilation; I link explicitly to the system library `hid.dll` and manually load the functions needed.

[Download application ... or sources](#) (Visual Studio 6 workspace)

Command-line utility (Linux and Windows, v0.10.0)

OP is a command-line executable; the Windows version doesn't need installation; the Linux version searches the programmer between devices /dev/usb/hiddevX (or the one specified as parameter) and needs reading rights for it.

eg. >sudo chmod a+r /dev/usb/hiddev0

To permanently enable a user do the following (on Ubuntu and other Debian based distributions, check for others):

as root create a file /etc/udev/rules.d/10-openprogrammer.rules if you want to enable a user group write:

```
KERNEL=="hiddev[0-9]", ATTRS{idProduct}=="5432",
ATTRS{idVendor}=="1209",          GROUP="<<group>>",
SYMLINK+="openprogrammer"
```

where <group> is one of the user groups (to get a list type "groups"); select a suitable group and if your user doesn't belong to it execute "addgroup <user> <group>"

or, if you want to enable all users, change reading permissions:

```
KERNEL=="hiddev[0-9]", ATTRS{idProduct}=="5432",
ATTRS{idVendor}=="1209",          MODE="0664",
SYMLINK+="openprogrammer"
```

restart udev to apply changes:

```
> udevadm control --reload-rules
```

```
> udevadm trigger
```

Now, every time the system detects the programmer, the corresponding /dev/usb/hiddevX has the correct permissions and also the link /dev/openprogrammer is created.

If after plugging the device /dev/usb/hiddevX is inexistent (and LED2 doesn't blink at 1 Hz), it's sufficient to execute a few times lsusb to force enumeration, or unplug and replug the cable.

If not otherwise specified OP looks for an USB device with vid&pid=0x1209:0x100.

It supports hex8 and hex32 files, and also binary files in case of serial memories.

Using the --HWtest option and a voltmeter is possible to check that the circuit is working.

It is possible to communicate with generic I2C/SPI devices; in case of SPI it's always necessary to specify control byte and address (or addresses); the RW bit is handled automatically.

In case of problems or just for curiosity it's possible to save all data exchanged with the programmer with option -l; its optional parameter must be specified with -l=<file> (who knows why? It may be a bug of getopt).

Supported languages are currently English and Italian; more languages can be added by generating and modifying the file languages.rc.

Options:

| | |
|--------------------|---|
| -BKosccal | load BKosccal from file |
| -calib | load calibration from file |
| -command <message> | send <message> to the programmer and exit |
| -cwX <cw> | force config word X |
| -d, device <dev.> | device |
| -ee | use eeprom |
| -err <max> | max errors during writing |
| -fuse <val> | write fuse low byte (Atmel only) |
| -fuseh <val> | write fuse high byte (Atmel only) |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)
[How to ...](#)
[Supported devices Communication protocol](#)
[The circuit Voltage regulator](#)
[How to contribute Download History Links Contacts](#)

```

-fusex <val>          write extended fuse byte (Atmel only)
-h, help              help
-HWtest              hardware test
-i, info              informations about programmer
-i2c_r <N Ctr Addr>    read N bytes from I2C bus
-i2c_r2 <N Ctr Addr(2)> read N bytes from I2C bus (16b address)
-i2c_w <N Ctr Addr Data> write N bytes to I2C bus
-i2c_w2 <N Ctr Addr(2) Data> write N bytes to I2C bus (16b address)
-i2cspeed <speed>      set I2C speed: 0=100k,1=200k,2=400k,3=800k"
-icd <val>            enable ICD (goto address)
-id                  use ID
-l, log [=file]        save log
-lang <language>       load <language> strings
-langfile            write all strings to file
-lock <val>           write lock byte (Atmel only)
-mode <mode>          SPI mode: 00,01,10,11
-osccl               loads osccl from file instead of using the value saved before erase
-p, path <path>       programmer path [/dev/usb/hiddev0]
-pid <pid>            programmer pid [0x5432]
-r, reserved          read reserved area
-rep <n>              report size [64]
-s1, S1              Multiple programming triggered by S1
-s, save <file>       save Ihex file
-se, saveEE <file>    save EEPROM on Ihex file (ATxxxx only)
-spi_r <N>            read N bytes from SPI bus
-spi_w <N Data>       write N bytes to SPI bus
-spspeed <speed>      set SPI speed: 0=100k,1=200k,2=300k,3=500k" NL
-support             supported devices
-use_BKosccal         copy BKosccal to osccl
-v, version           version
-vid <vid>            programmer vid [0x1209]
-w, write <file>       write Ihex file
-we, writeEE <file>   write EEPROM on Ihex file (ATxxxx only)

```

Examples:

```

> op -h                #help
> op -d 18F2550 -ee -s read.hex    #reads code and EEPROM and saves to file
> op -d 16F628 -ee -w write.hex    #writes
> op -i2c_r 8 A0 0          #reads 8 bytes from I2C bus, control byte A0, address 0

```

A frequent error is to write the device name with lowercase letters instead of uppercase:
write 16**F**628, not 16**f**628

A makefile is included, so to build the application you need GCC and the maketools (MinGW/MSYS on Windows); write:
> make
Then to install it (if you wish):
> make install

You can find more info in the [source code guide](#).
Also included is Hid_test, an utility to send and receive a single 64 bit packet; it can be useful for experimenting with the hardware; in theory one could even write a complete programming script using it.

[Download](#)

[Top](#)

[Quick facts](#)

[Another](#)

[programmer?](#)

[USB &](#)

[HID](#)

[firmware](#)

[Control](#)

[programs](#)

[GTK](#)

[graphical](#)

[interface](#)

[MFC](#)

[Graphical](#)

[interface](#)

[Command-](#)

[line](#)

[interface](#)

[How to ...](#)

[Supported](#)

[devices](#)

[Communication](#)

[protocol](#)

[The circuit](#)

[Voltage](#)

[regulator](#)

[How to](#)

[contribute](#)

[Download](#)

[History](#)

[Links](#)

[Contacts](#)

How to ...

Erase a device: every device is erased before being programmed; however if you still need to erase it it's sufficient to write a hex file with valid data (i.e. <0xFF) beyond the implemented memory.

For example, for PIC12-16:

:0200000040000FA

:0144010000BA

:00000001FF

And for PIC18:

:0200000040002F8

:0200000000000FE

:00000001FF

[Top](#)

[Quick facts](#)

[Another](#)

[programmer](#)

[USB &](#)

[HID](#)

[firmware](#)

[Control](#)

[programs](#)

[GTK](#)

[graphical](#)

[interface](#)

[MFC](#)

[Graphical](#)

[interface](#)

[Command](#)

[line](#)

[interface](#)

[How to ...](#)

[Supported](#)

[devices](#)

[Communication](#)

[protocol](#)

[The circuit](#)

[Voltage](#)

[regulator](#)

[How to](#)

[contribute](#)

[Download](#)

[History](#)

[Links](#)

[Contacts](#)

Change Configuration Word: Config words are usually specified in the hex file, but can be forced for PIC 10-12-16-18 using the related device options (or via command line).

It's also possible to recompile sources, otherwise to change the hex file directly; in case of most PIC16 the config word is at address 0x2007, which is stored at 0x400E; the last byte of the line is a checksum, which can be calculated as the two's complement of the sum of all bytes in the line.

For example:

:02400E00xxxxCC , where xxxx is the new value and CC the checksum

Change configuration of Atmel AVR: unlike PICs, these devices do not map their configuration words in the main memory area (so the hex files don't specify any configuration) and it's necessary to write the desired Fuse/Lock bytes in the device options; don't write anything in case the default value is fine for the application.

Solve the "Synchronization error" with AVR devices: A possible cause is that the SPI speed is too high in relation to the CPU speed; the latter has to be > 4 x SPI speed.

There are many possible CPU speed configurations, so the (new) algorithm varies the SPI speed automatically in order to enter Program Mode.

Obviously the lower the speed the longer it takes to read/write the device; in order to speed up operations you could write an empty file with a fast CPU configuration, then write the final file and configuration at high speed.

Some devices include an extremely low speed setting (16 kHz), which is too low even for the adaptive algorithm; in this case use "write Fuse Low @ 3 kHz" to change Fuse Low to a higher speed setting, then write in the usual way.

Another cause could be that the serial programming is disabled: this can be done only using a parallel programmer, and the same is necessary to enable it again.

The third possibility is that the device is configured for external resonator but X2 cannot move; in case you use the AVR expansion board make sure X2 is not tied to GND.

Check that a device is blank: read it and look at displayed data; only lines with valid data are displayed, so if there are none the device is blank.

Verify that a write was successful: all write algorithms implement write verification, either during write or immediately after; if the program reports 0 errors it means that the code was successfully verified.

If you want to check again you can read the device and compare with the original data; keep in mind that frequently not all bits are implemented; for example in PIC16 a data word is 14 bits long, so even if the source data is 0xFFFF it will be written as 0x3FFF; also the Config Words usually have some bits fixed at 0, which are not checked.

Read the reserved memory area: most PIC devices have a reserved area above the Config Words which is used for test or calibration purposes; to see it use the relative option before read; on PIC24-30-33 the executive memory is read as well.

Correctly use OscCal and other calibration words: some devices (eg. 12F5xx) store the internal oscillator calibration value in the last address of program memory and in a backup location past the ID words; after erasing all memory the control programs restore the calibration value taking it from the backup location, unless specified otherwise; other options are: use the old value (which should be the same as the backup, if none was changed before), use what is specified in the .hex file.

Similarly it's possible to overwrite the backup value with the content of the .hex file, using option "write ID and BKosccal"; in this case the ID locations will be written as well, if specified in the .hex file.

To overwrite the other calibration values use option "write Calib1 and 2".

Supported devices

I tried this programmer with a small number of devices (those I own plus some tested by other users) indicated in **bold**; the other devices are supported but not tested; however, considering that for every device family at least one has been verified, all of them should work without problems.

Please let me know if you verify operation with the untested devices.

Also contact me if you need other algorithms or code new ones by yourself.

Take notice:

LF series PICs are used exactly as the F ones;

Atmel AVR devices with various suffixes are grouped together whenever the programming algorithm is exactly the same, eg. ATmega8 and ATmega8A;

EEPROM memories comprise all versions with VDDmax=5V, eg. 242LC56, 24AA256, etc.;

93x memories use 2 different algorithms, for the 93S series and for all the others, indicated with 93x (93xA have 8 bit organization);

SPI Flash memories need a low voltage adapter (see the [schematic diagrams](#)).

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)
[How to ... Supported devices Communication protocol The circuit Voltage regulator How to contribute Download History Links Contacts](#)

Devices supported for read and write:

10F200, 10F202, 10F204, **10F206**, **10F220**, **10F222**, 10F320, 10F322,
12C508, **12C508A**, **12C509**, **12C509A**, **12F508**, **12F509**, **12F510**, **12F519**,
12F609, **12F615**, **12F617**, **12F629**, **12F635**, **12F675**, **12F683**,
 12F752, 12F529T39, 12F529T48,
 12F1501, 12F1571, 12F1572, **12F1612**, **12F1822**, 12F1840,
16F505, 16F506, 16F526, 16F527, **16F54**, 16F57, 16F570, 16F59,
16F610, 16F616, 16F627, 16F627A, **16F628**, **16F628A**, 16F630, **16F631**, **16F636**, 16F639, **16F648A**, **16F676**,
16F677, **16F684**, 16F685, **16F687**, 16F688, **16F689**, **16F690**,
 16F707, **16F716**, 16F72, 16F720, 16F721, **16F722**, 16F722A, 16F723, 16F723A, 16F724, **16F726**, 16F727, **16F73**, **16F737**,
 16F74, **16F747**, 16F753, 16F76, 16F767, 16F77, 16F777, **16F785**,
16F818, **16F819**, 16C83, 16F83, 16F83A, 16C84, **16F84**, **16F84A**, **16F87**, 16F870, 16F871,
 16F872, **16F873**, **16F873A**, 16F874, 16F874A, **16F876**, **16F876A**, 16F877, **16F877A**, **16F88**, **16F882**, 16F883,
 16F884, 16F886, **16F887**,
16F913, **16F914**, 16F916, 16F917, 16F946,
 16F1454, **16F1455**, 16F1459, 16F1503, **16F1507**, 16F1508, 16F1509, 16F1512, 16F1513, 16F1516, 16F1517, 16F1518,
 16F1519, 16F1526, 16F1527, 16LF1554, 16LF1559, 16F1574, 16F1575, 16F1578, 16F1579, 16F1613, 16F1614, 16F1615,
 16F1618, 16F1619, 16F1703, 16F1704, 16F1705, 16F1707, 16F1708, 16F1709, 16F1713, 16F1716, 16F1717, **16F1718**,
 16F1719, 16F1782, 16F1783, 16F1784, 16F1786, 16F1787, 16F1788, 16F1789, **16F1823**, 16F1824, 16F1825, **16F1826**,
 16F1827, 16F1828, 16F1829, 16F1847, 16LF1902, 16LF1903, 16LF1904, 16LF1906, 16LF1907, 16F1933, **16F1934**,
16F1936, 16F1937, 16F1938, 16F1939, 16F1946, 16F1947, 16F18313, 16F18323, 16F18324, 16F18325,
 16F18326, **16F18344**, 16F18345, 16F18346,
 18F242, 18F248, **18F252**, **18F258**, 18F442, 18F448, 18F452, **18F458**, **18F1220**, 18F1230, **18F1320**, **18F1330**,
 18F13K22, **18F13K50**, 18F14K22, **18F14K50**, 18F2220, **18F2221**, 18F2320, **18F23K20**, 18F23K22,
 18F2321, 18F2331, 18F2410, **18F24J10**, 18F24J11, 18F2420, **18F24K20**, 18F24K22, 18F2423, 18F2431,
 18F2439, **18F2450**, **18F24J50**, 18F24K50, **18F2455**, 18F2458, 18F2480, 18F2510, **18F25J10**, 18F25J11,
 18F2515, **18F2520**, **18F25K20**, 18F25K22, 18F2523, 18F2525, 18F2539, **18F2550**, **18F25J50**, **18F25K50**, **18F2553**,
 18F2580, 18F25K80, 18F2585, 18F2610, **18F26J11**, 18F26J13, 18F2620, 18F26K20, 18F26K22, 18F26J50,
 18F26K50, 18F26J53, **18F2680**, 18F26K80, 18F2682, **18F2685**, **18F27J13**, 18F27J53, 18F4220, 18F4221,
 18F4320, 18F43K20, 18F43K22, 18F4321, 18F4331, 18F4410, 18F44J10, 18F44J11, 18F4420, 18F44K20,
 18F44K22, 18F4423, 18F4431, 18F4439, 18F4450, 18F44J50, 18F4455, 18F4458, 18F4480, 18F4510, 18F45J10, 18F45J11,
 18F4515, **18F4520**, 18F45K20, 18F45K22, 18F4523, 18F4525, 18F4539, **18F4550**, 18F45J50, 18F45K50, 18F4553, 18F4580,
 18F45K80, **18F4585**, 18F4610, 18F46J11, 18F46J13, 18F4620, **18F46K20**, 18F46K22, 18F46J50, 18F46K50,
 18F46J53, **18F4680**, 18F46K80, 18F4682, **18F4685**,

[Top](#)
[Quick facts](#)
[Another programmer](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)
[How to ... Supported devices Communication protocol The circuit Voltage regulator How to contribute Download History Links Contacts](#)

18F47J13, 18F47J53, 18F63J11, 18F63J90, 18F64J11,
 18F64J90, 18F65J10, 18F65J11, 18F65J15, 18F65J50,
 18F65J90, 18F65K80, 18F66J10, 18F66J11, 18F66J15,
 18F66J16, 18F66J50, 18F66J55, 18F66J60, 18F66J65,
 18F66J90, 18F66J93, 18F67J10, 18F67J11, 18F67J50,
 18F67J60, 18F66K80, 18F67J90, 18F67J93, 18F83J11,
 18F83J90, 18F84J11, 18F84J90, 18F85J10, 18F85J11,
 18F85J15, 18F85J50, 18F85J90, **18F8520**, 18F86J10,
 18F86J11, 18F86J15, 18F86J16, 18F86J50, 18F86J55,
 18F86J60, 18F86J65, 18F86J72, 18F86J90, 18F86J93,
 18F8722, 18F87J10, 18F87J11, 18F87J50, 18F87J60,
 18F87J72, 18F87J90, 18F87J93, 18F96J60,
 18F96J65, **18F97J60**,

24F04KA200, 24F04KA201, **24F08KA101**, 24F08KA102,
 24F16KA101, 24F16KA102, **24FJ16GA002**, 24FJ16GA004,
 24FJ32GA002, 24FJ32GA004, 24FJ32GA102, 24FJ32GA104,
 24FJ32GB002, 24FJ32GB004, 24FJ48GA002, 24FJ48GA004,
 24FJ64GA002, 24FJ64GA004, 24FJ64GA006, 24FJ64GA008,
 24FJ64GA010, 24FJ64GA102, 24FJ64GA104, 24FJ64GA306,
 24FJ64GA308, 24FJ64GA310, **24FJ64GB002**,
 24FJ64GB004, 24FJ64GB106, 24FJ64GB108, 24FJ64GB110,
 24FJ64GC006, 24FJ64GC008, 24FJ64GC010, 24FJ96GA006,
 24FJ96GA008, 24FJ96GA010, 24FJ128GA006,
 24FJ128GA008, 24FJ128GA010, 24FJ128GA106,
 24FJ128GA108, 24FJ128GA110, 24FJ128GA306,
 24FJ128GA308, 24FJ128GA310, 24FJ128GB106,
 24FJ128GB108, 24FJ128GB110, 24FJ128GB206,
 24FJ128GB210, 24FJ128GC006, 24FJ128GC008,
 24FJ128GC010, 24FJ128DA106, 24FJ128DA110,
 24FJ128DA206, 24FJ128DA210, 24FJ192GA106,
 24FJ192GA108, 24FJ192GA110, 24FJ192GB106,
 24FJ192GB108, 24FJ192GB110, 24FJ256GA106,
 24FJ256GA108, 24FJ256GA110, 24FJ256GB106,
 24FJ256GB108, 24FJ256GB110, 24FJ256GB206,
 24FJ256GB210, 24FJ256DA106, 24FJ256DA110,

24FJ256DA206, 24FJ256DA210,
 24EP32GP202, 24EP32GP203, 24EP32GP204,
 24EP32MC202, 24EP32MC203, 24EP32MC206,
 24EP32MC204, **24EP64GP202**, 24EP64GP203,
 24EP64GP204, 24EP64GP206, 24EP64MC202,
 24EP64MC203, 24EP64MC204, 24EP64MC206,
 24EP128GP202, 24EP128GP204, 24EP128GP206,
 24EP128MC202, 24EP128MC204, 24EP128MC206,
 24EP256GP202, 24EP256GP204, 24EP256GP206,
 24EP256MC202, 24EP256MC204, 24EP256MC206,
 24EP512GP202, 24EP512GP204, 24EP512GP206,
 24EP512MC202, 24EP512MC204, 24EP512MC206,
 24HJ12GP201, **24HJ12GP202**, 24HJ16GP304,
 24HJ32GP202, 24HJ32GP204, 24HJ32GP302,
 24HJ32GP304, **24HJ64GP202**, 24HJ64GP204, 24HJ64GP206,
 24HJ64GP210, 24HJ64GP502, 24HJ64GP504, 24HJ64GP506,
 24HJ64GP510, 24HJ128GP202, 24HJ128GP204,
 24HJ128GP206, 24HJ128GP210, 24HJ128GP306,
 24HJ128GP310, 24HJ128GP502, 24HJ128GP504,
 24HJ128GP506, 24HJ128GP510, 24HJ256GP206,
 24HJ256GP210, 24HJ256GP610,

30F1010, 30F2010, **30F2011**, 30F2012, **30F2020**, 30F2023,
 30F3010, 30F3011, 30F3012, 30F3013, 30F3014,
 30F4011, **30F4012**, 30F4013, 30F5011, 30F5013, 30F5015,

[Top](#)
[Quick facts](#)
[Another programmer](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)
[How to ... Supported devices Communication protocol The circuit Voltage regulator How to contribute Download History Links Contacts](#)

[Top](#)
[Quick facts](#)
[Another programmer](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)
[How to ... Supported devices Communication protocol The circuit Voltage regulator How to contribute Download History Links Contacts](#)

30F5016, 30F6010, 30F6011, 30F6012, 30F6013, 30F6014, 30F6015,
 33FJ06GS101, 33FJ06GS102, 33FJ06GS202,
 33FJ12GP201, **33FJ12GP202**, 33FJ12MC201, 33FJ12MC202,
 33FJ16GP304, 33FJ16GS402, 33FJ16GS404, 33FJ16GS502,
 33FJ16GS504, 33FJ16MC304, 33FJ32GP202, 33FJ32GP204,
 33FJ32GP302, 33FJ32GP304, 33FJ32GS406, 33FJ32GS606,
 33FJ32GS608, 33FJ32GS610, 33FJ32MC202, 33FJ32MC204,
 33FJ32MC302, 33FJ32MC304, 33FJ64GP202, 33FJ64GP204,
 33FJ64GP206, 33FJ64GP306, 33FJ64GP310, 33FJ64GP706,
 33FJ64GP708, 33FJ64GP710, 33FJ64GP802, 33FJ64GP804,
 33FJ64GS406, 33FJ64GS606, 33FJ64GS608, 33FJ64GS610,
 33FJ64MC202, 33FJ64MC204, 33FJ64MC506,
 33FJ64MC508, 33FJ64MC510, 33FJ64MC706,
 33FJ64MC710, 33FJ64MC802, 33FJ64MC804,
 33FJ128GP202, 33FJ128GP204, 33FJ128GP206,
 33FJ128GP306, 33FJ128GP310, 33FJ128GP706,
 33FJ128GP708, 33FJ128GP710, **33FJ128GP802**,
 33FJ128GP804, 33FJ128MC202, 33FJ128MC204,
 33FJ128MC506, 33FJ128MC510, 33FJ128MC706,
 33FJ128MC708, 33FJ128MC710, 33FJ128MC802,
 33FJ128MC804, 33FJ256GP506, 33FJ256GP510,
 33FJ256GP710, 33FJ256MC510, 33FJ256MC710,
 33EP32GP502, 33EP32GP503, 33EP32GP504,
 33EP32MC202, 33EP32MC203, 33EP32MC204,
 33EP32MC502, 33EP32MC503, 33EP32MC504,
 33EP64GP502, 33EP64GP503, 33EP64GP504,
 33EP64GP506, 33EP64MC202, 33EP64MC203,
 33EP64MC204, 33EP64MC206, 33EP64MC502,
 33EP64MC503, 33EP64MC504, 33EP64MC506,
 33EP128GP502, 33EP128GP504, 33EP128GP506,
 33EP128MC202, 33EP128MC204, 33EP128MC206,
 33EP128MC502, 33EP128MC504, 33EP128MC506,
 33EP256GP502, 33EP256GP504, 33EP256GP506,
 33EP256MC202, 33EP256MC204, 33EP256MC206,
 33EP256MC502, 33EP256MC504, 33EP256MC506,
 33EP512GP502, 33EP512GP504, 33EP512GP506,
 33EP512MC202, 33EP512MC204, 33EP512MC206,
 33EP512MC502, 33EP512MC504, 33EP512MC506,
 AT90S1200, AT90S2313, **AT90S8515**, **AT90S8535**,
ATmega48, **ATmega8**, **ATmega88**, ATmega8515,
 ATmega8535, **ATmega16**, ATmega164, **ATmega168**,
ATmega32, **ATmega324**, **ATmega328**,
 ATmega64, **ATmega644**, **ATmega1284**,
 ATtiny11, **ATtiny12**, **ATtiny13**, **ATtiny2313**, ATtiny24,
 ATtiny25, **ATtiny26**, ATtiny261, ATtiny4313, **ATtiny44**,
 ATtiny45, **ATtiny461**, ATtiny48, **ATtiny84**, ATtiny85,
 ATtiny88, ATtiny861,
2400, **2401**, **2402**, **2404**, **2408**, **2416**, **2432**, **2464**, **24128**,
24256, **24512**, 241024, **241025**,
25010, **25020**, **25040**, **25080**, **25160**, **25320**, **25640**, **25128**,
 25256, 25512, **251024**,
 95010, 95020, 95040, 95080, 95160, **95320**, 95640, 95128,
 95256, 95512, 95M01, 95M02,
251005, 252005, 254005, 258005, **251605**, 25X05, 25X10,
 25X20, **25X40**, 25X80, 25X16, 25X32, 25X64, 25X128,
 25Q40,
 93S46, **93x46**, 93x46A, **93S56**, **93x56**, **93x56A**, 93S66, **93x66**,
93x66A, **93x76**, **93x76A**, **93x86**, **93x86A**,

**DS2430, DS2431, DS2433, DS28EC20, DS1820,
11010, 11020, 11040, 11080, 11160**

devices supported for read only:
12C671, 12C672, **12CE673**, 12CE674

Important!! Don't use 3.3V devices without the 3.3V expansion boards, otherwise permanent damage may occur; the software verifies that such adapters are present before starting to program, but obviously you need to select the proper device; the 3.3V devices are:
12F1xxx, 16F1xxx, 18FxxJxx, 18FxxKxx, 24Fxxx, 24Hxxx, 33Fxxx.
Some of them have 5V variants; if you need to program at 5V you can select the option "Don't require LV boards". Also don't put any 24F-33F on the 30F socket, which works at 5V.

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

Communication protocol

To design a communication protocol we must take into account some often contrasting requirements:

transfer speed and efficiency, code size, adaptability and expandability.

Differently from serial links, USB is packet based; a packet is received altogether, but HID devices can only exchange them every ms, so it is out of question to manage timings directly as with serial ports.

It's necessary to introduce synthetic commands that the microcontroller can use to recreate the proper waveforms.

Furthermore, one objective of a reliable programmer is to be independent from the host speed and CPU occupation, so the task of generating waveforms would anyways be given to the microcontroller.

In general we can find two types of programmers: simple serial programmers only take commands to change voltage levels; host software manages both timings and programming algorithms but needs all the CPU time and is dramatically affected by other processes running on the system.

At the other extreme are "smart" programmers, which autonomously manage timings and algorithms, but must be updated to support new devices and tend to require much memory to store code.

I chose a combination of both: ICSP (In Circuit Serial Programming) commands are implemented in firmware, but the host software manages the algorithms.

In order to increase speed and efficiency some instructions correspond to sequences of frequently repeated commands, such as sequential reads.

The advantage of this approach is that timings are very precise, while the extreme variety of algorithms does not increase the firmware code size.

Another advantage is that once the basic commands are verified the development of algorithms is done on the PC, without the need for frequent firmware updates.

For example, this is the sequence used to enter program mode for 16F628 and read DevID:

```
SET_PARAMETER //set delays to be used by other instructions
SET_T1T2      //T1 & T2
```



```

1          //T1=1us
100        //T2=100us
EN_VPP_VCC //Vpp & Vcc = 0
0x0
SET_CK_D   //Clock and Data as output and 0
0x0
EN_VPP_VCC //Vpp enabled
0x4
NOP        //small delay
EN_VPP_VCC //Vdd+Vpp enabled
0x5
NOP        //small delay
LOAD_CONF  //program counter to 0x2000
0xFF      //fake config
0xFF      //fake config
INC_ADDR_N //increment address by 6
0x06
READ_DATA_PROG //read DevID
...

```

[Top](#)[Quick facts](#)[Another](#)[programmer?](#)[USB &](#)[HID](#)[firmware](#)[Control](#)[programs](#)[GTK](#)[graphical](#)[interface](#)[MFC](#)[Graphical](#)[interface](#)[Command-](#)[line](#)[interface](#)[How to ...](#)[Supported](#)[devices](#)[Communication](#)[protocol](#)[The circuit](#)[Voltage](#)[regulator](#)[How to](#)[contribute](#)[Download](#)[History](#)[Links](#)[Contacts](#)

In addition to ICSP commands other instructions manage the programmer, control programming voltages, execute precise delays, communicate via I2C or SPI bus.

Every instruction is executed in at least 40 us, due to the interpreter loop execution time.

ICSP commands use T1 or T2 as values for delays; all instructions return an echo, with the exception of FLUSH, which immediately sends the output buffer and stops the execution of current packet.

In case an instruction doesn't have enough parameters it returns an error (0xFE) and the execution of current packet is halted.

The state of USB connection is signaled by LED2: it blinks at 4 Hz during enumeration, at 1 Hz in normal operation.

LED1 shows when there are instructions being executed.

Following is the list of all instructions:

| Instruction | Value | Parameters | Answer | Notes |
|-------------|-------|------------|------------|---|
| NOP | 0x00 | none | echo | no operation |
| PROG_RST | 0x01 | none | echo + 10B | programmer reset; sends fw version (3B), ID (3B), "RST" string |
| PROG_ID | 0x02 | none | echo+ 6B | sends fw version (3B), ID (3B) |
| CHECK_INS | 0x03 | 1B | echo + 1B | if specified instruction exists returns its code, otherwise returns error (0xFE) |
| FLUSH | 0x04 | none | none | flushes output buffer (sends 64B) and stops command interpreter for the current packet. |
| VREG_EN | 0x05 | none | echo | turns on the voltage regulator |
| VREG_DIS | 0x06 | none | echo | turns off the voltage regulator |
| | | | | sets internal parameters; byte1: |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | | | | |
|---------------|------|------|----------|---|
| SET_PARAMETER | 0x07 | 1B | echo | parameter to change, byte 2-3 value: SET_T1T2 (=0): T1 & T2 SET_T3 (=1): T3(H,L) SET_timeout (=2): timeout(H,L) SET_MN (=3): M, N |
| WAIT_T1 | 0x08 | none | echo | waits T1 us (1us default) |
| WAIT_T2 | 0x09 | none | echo | waits T2 us (100us default) |
| WAIT_T3 | 0x0A | none | echo | waits T3 us (2ms default) |
| WAIT_US | 0x0B | 1B | echo | waits N us |
| READ_ADC | 0x0C | none | echo +2B | reads regulator voltage (effective 10bits, MSB-LSB); considering the input divider, voltage in V is <value>/1024*5*34/12 |
| SET_VPP | 0x0D | 1B | echo +1B | sets regulator voltage to <parameter>/10; if error is < 200 mV within 15ms returns <parameter>, otherwise error (0xFE) |
| EN_VPP_VCC | 0x0E | 1B | echo | controls Vpp and Vcc on the programmed device; 1 bit for level (0-1), 1bit for impedance (keep at 0); bit 0-1: Vcc, bit 2-3: Vpp |
| SET_CK_D | 0x0F | 1B | echo | controls CK, D, PGM on the programmed device; 1 bit for level (0-1), 1bit for impedance (low-high); bit 0-1: D, bit 2-3: CK, bit 4-5: PGM |
| READ_PINS | 0x10 | none | echo +1B | reads the state of control lines, 1 bit level (0-1), 1bit impedance (low-high); bit 0-1: D, bit 2-3: CK, bit 4-5: PGM |
| LOAD_CONF | 0x11 | 2B | echo | ICSP command: Load configuration (000000), T1 us between command and data; 14 bit data (right aligned, MSB-LSB) |
| | | | | ICSP command: Load |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | | | | |
|-----------------|------|------|----------|--|
| LOAD_DATA_PROG | 0x12 | 2B | echo | Data in Program Memory (000010), T1 us between command and data; 14 bit data (right aligned, MSB-LSB) |
| LOAD_DATA_DATA | 0x13 | 1B | echo | ICSP command: Load Data in Data Memory (000011), T1 us between command and data; 8 bit data |
| READ_DATA_PROG | 0x14 | none | echo +2B | ICSP command: Read Data from Program Memory (000100), T1 us between command and data; 14 bit data (right aligned, MSB-LSB) |
| READ_DATA_DATA | 0x15 | none | echo +1B | ICSP command: Read Data from Data Memory (000101), T1 us between command and data; 8 bit data |
| INC_ADDR | 0x16 | none | echo | ICSP command: Increment Address (000110), T1 us delay at the end |
| INC_ADDR_N | 0x17 | 1B | echo | ICSP command: Increment Address (000110), T1 us delay at the end; repeated N times |
| BEGIN_PROG | 0x18 | none | echo | ICSP command: Begin Programming (001000) |
| BULK_ERASE_PROG | 0x19 | none | echo | ICSP command: Bulk Erase Program Memory (001001) |
| END_PROG | 0x1A | none | echo | ICSP command: End Programming (001010) |
| BULK_ERASE_DATA | 0x1B | none | echo | ICSP command: Bulk Erase Data Memory (001011) |
| END_PROG2 | 0x1C | none | echo | ICSP command: End Programming (001110) |
| ROW_ERASE_PROG | 0x1D | none | echo | ICSP command: Row Erase Program Memory (010001) |
| BEGIN_PROG2 | 0x1E | none | echo | ICSP command: Begin Programming (0011000) |
| | | | | ICSP command |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | | | | |
|---------------|------|---------|-----------|--|
| CUST_CMD | 0x1F | 1B | echo | specified in the parameter |
| PROG_C | 0x20 | 2B | echo +1B | Programs a word following 12Cxxx algorithm: 000010, 001000, 001110, M pulses & N overpulses |
| CORE_INS | 0x21 | 2B | echo | PIC18 ICSP command: Core instruction (0000); 16 bit data (MSB-LSB) |
| SHIFT_TABLAT | 0x22 | none | echo +1B | PIC18 ICSP command: Shift TABLAT (0010); 8 bit data |
| TABLE_READ | 0x23 | none | echo +1B | PIC18 ICSP command: Table read (1000); 8 bit data |
| TBLR_INC_N | 0x24 | 1B | echo+N+NB | PIC18 ICSP command: Table read post-inc (1001); 8 bit data; repeats N times; returns N and NB data |
| TABLE_WRITE | 0x25 | 2B | echo | PIC18 ICSP command: Table write (1100); 16 bit data (MSB-LSB) |
| TBLW_INC_N | 0x26 | (2N+1)B | echo | PIC18 ICSP command: Table write post-inc (1101); 16 bit data (MSB-LSB); repeats N times (N is the first parameter) |
| TBLW_PROG | 0x27 | 4B | echo | PIC18 ICSP command: Table write and program (1111); 16 bit data (MSB-LSB); also executes a NOP with a delay specified in parameters 3-4 (in us) |
| TBLW_PROG_INC | 0x28 | 4B | echo | PIC18 ICSP command: Table write and program post-inc (1110); 16 bit data (MSB-LSB); also executes a NOP with a delay specified in parameters 3-4 (in us) |
| SEND_DATA | 0x29 | 3B | echo | PIC18 ICSP command specified in byte 1; sends 16 bit data (MSB-LSB) |
| | | | | PIC18 ICSP command |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | | | | |
|-----------|------|-------|-----------|--|
| READ_DATA | 0x2A | 1B | echo+1B | specified in byte 1; reads 8 bit data |
| I2C_INIT | 0x2B | 1B | echo | Initializes I2C communication: 0xFF disables I2C; bit 6: slew rate control for speed > 100kbps; bit 5:3 speed: 0=100k, 1=200k, 2=400k, 3=800k, 4=1M; attention: use pull-up resistors according to selected speed; bit 2:0: logic level of A2-A1-A0 (on device) |
| I2C_READ | 0x2C | 3B | echo+1+NB | Reads <parameter 1> bytes from I2C bus using <parameter 2> as control byte and <parameter 3> as address; forces automatically the RW bit in the control byte. Responds with <parameter 1> + Data or with ACK_ERR (0xFD) in case of acknowledge error (eg. if there are no devices on the bus) |
| I2C_WRITE | 0x2D | 3B+NB | echo | Writes <parameter 1> bytes to I2C bus using <parameter 2> as control byte and <parameter 3> as address; forces automatically the RW bit in the control byte. Responds with ACK_ERR (0xFD) in case of acknowledge error (eg. if there are no devices on the bus). For 2 byte addresses just use the 2nd byte of address as the first byte of data. |
| I2C_READ2 | 0x2E | 4B | echo+1+NB | Reads from I2C bus; identical to I2C_READ, but uses 2 bytes for addressing |
| SPI_INIT | 0x2F | 1B | echo | Initializes SPI communication: 0xFF disables SPI bit 1:0 speed: 0=100kbps, |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | | | | |
|--------------|------|-------|------------|---|
| | | | | 1=200kbps, 2=300kbps, 3=500kbps bit 2:3 SPI mode |
| SPI_READ | 0x30 | 1B | echo+1+NB | Reads <parameter 1> bytes from SPI bus. Returns <parameter 1> + Data; If <parameter 1>=0 returns the byte that was last received (during either read or write) |
| SPI_WRITE | 0x31 | 1B+NB | echo+1B | Writes <parameter 1> bytes to SPI bus. |
| EXT_PORT | 0x32 | 2B | echo | Forces levels of communication ports: <parameter 1> = <RB7:RB0> <parameter 2> = <RC7,RC6,RA5:RA3> Does not change signal direction. |
| AT_READ_DATA | 0x33 | 3B | echo+1+2NB | ATMEL command: read program memory (0010H000); reads <parameter 1> words at address <parameter 2> : <parameter 3> via SPI. Returns <parameter 1> + Data |
| AT_LOAD_DATA | 0x34 | 3B+2N | echo+1B | ATMEL command: load program memory page (0100H000); loads <parameter 1> words at address <parameter 2> : <parameter 3> via SPI. Returns <parameter 1> |
| CLOCK_GEN | 0x35 | 1B | echo | Generates a clock signal on RB3 (using CCP1-2 and TIMER1) bit 2:0 frequency: 0=100kHz, 1=200kHz, 2=500kHz, 3=1MHz, 4=2MHz, 5=3MHz, 6=6MHz; Disables PWM1 output (DCDC regulator) |
| SIX | 0x36 | 3B | echo | PIC24 ICSP command: Core instruction (0000); 24 bit data (MSB first) |
| | | | | PIC24 ICSP |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | | | | |
|-----------|------|-------|------------|--|
| SIX_LONG | 0x3E | 3B | echo | command: Core instruction (0000); 24 bit data (MSB first); appends 2 ICSP_NOP at the end |
| SIX_LONG5 | 0x49 | 3B | echo | PIC24 ICSP command: Core instruction (0000); 24 bit data (MSB first); appends 5 ICSP_NOP at the end |
| SIX_N | 0x3F | 1+3NB | echo | PIC24 ICSP command: Core instruction (0000); N * 24 bit data (MSB first); sends N instructions and adds M ICSP_NOP after each one; N=<parameter1>&0x3F, M=<parameter1> >>6 |
| REGOUT | 0x37 | none | echo +2B | PIC24 ICSP command: Shift out VISI register (0001); 16 bit data |
| ICSP_NOP | 0x38 | none | echo | PIC24 ICSP command: Execute NOP (0000) |
| TX16 | 0x39 | 1+2NB | echo+1B | Transmits 16 bit words over ICSP (MSB first); clock period: 2*(T1-1)+1 us |
| RX16 | 0x3A | 1B | echo+1+2NB | Receives 16 bit words over ICSP (MSB first); clock period: 2*(T1-1)+1 us |
| uW_INIT | 0x3B | none | echo | Initializes MicroWire communication |
| uW_TX | 0x3C | 1B+NB | echo+1B | Writes <parameter 1> bits to MicroWire bus. Data is specified MSB first |
| uW_RX | 0x3D | 1B | echo+1+NB | Reads <parameter 1> bits from MicroWire bus. Returns <parameter 1> + Data, MSB first |
| OW_RESET | 0x40 | no | echo+1B | OneWire Reset pulse; detects the slave presence pulse: 1=present 0=absent |
| OW_WRITE | 0x41 | 1B+NB | echo | Writes <parameter 1> bytes on the OneWire bus |

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | | | | |
|--------------|------|----------|-----------|---|
| OW_READ | 0x42 | 1B | echo+1+NB | Reads <parameter 1> bytes from the OneWire bus |
| UNIO_STBY | 0x43 | no | echo | UNIO standby pulse |
| UNIO_COM | 0x44 | 1B+1B+NB | echo+1+NB | Executes a UNIO communication cycle: writes <parameter 1> bytes and reads <parameter 2> bytes; generates a synchronization byte if there are bytes to write |
| SET_PORT_DIR | 0x45 | 2B | echo | Sets the direction on the IO ports (0=out, 1=in): <parameter 1> = <RB7:RB0> <parameter 2> = <RC7,RC6,RA5:RA3> |
| READ_B | 0x46 | no | echo+1B | Reads IO port B |
| READ_AC | 0x47 | no | echo+1B | Reads IO ports A and C: <RC7,RC6,RA5:RA3> |
| AT_HV_RTX | 0x48 | 1B+2NB | echo+1B | Sends 2N*8 bits on RB0/RC7 (PB1/PB0), with CLK on RC6 (PB3) byte N=PB1, byte N+1=PB0 Receives 8 bits from RB1 (PB2) (only the last byte) |
| READ_RAM | 0xF0 | 2B | echo+3B | Reads from host memory; 16 bit address, 8 bit data; echoes address |
| WRITE_RAM | 0xF1 | 3B | echo+3B | Writes to host memory; 16 bit address, 8 bit data; echoes address and data |
| LOOP | 0xF2 | none | none | Resets instruction pointer and executes all instructions again. For test purposes only. |

The circuit (v1.7)

The project is based on a 28 pin 18F2550; about 8.5 KWords are used, so it will fit confortably into the smaller 2455.

The 2458 and 2553 have a 12 bit ADC, so only recompilation is required.

Up to version 0.8.0 I adapted the code to the 2450; since this model lacks the MSSP module I used a software implementation of I2C and SPI; it also lacks the second PWM channel, therefore it can't generate the clock for Atmel chips (for those that are configured with external clock); in this case RB3 can be used to turn on an external oscillator (which would be inserted in a modified Atmel expansion board).

The use of the corresponding 40 pin devices (4450, 4455, 4458, 4550, 4553) requires modification of the PCB.

In order to implement an USB peripheral with a PIC micro we need very few components: the main microcontroller, a quartz, some capacitors, and a USB type B receptacle, exactly as written in application notes from Microchip.


To be able to program PIC devices we need two digital lines for clock and data and two supply voltages, VCC and VPP, which are controlled using three transistors; VPP comes from a [switching voltage regulator](#) formed by Q4, L1, D3 which is described later.

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control](#)
[programs](#)


[GTK](#)
[graphical](#)
[interface](#)
[MFC](#)
[Graphica](#)
[interface](#)
[Comman](#)
[line](#)
[interface](#)

[How to ...](#)
[Supported](#)
[devices](#)
[Communication](#)
[protocol](#)
[The circuit](#)
[Voltage](#)
[regulator](#)
[How to](#)
[contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

[Schematic diagram](#) of main module:



PCB of main module:



Many components are optional, are only needed to program

some types of devices or for future applications: expansion connectors CONN2-3, protection resistors R11:23 (considering their cost why not use them?), I2C pull-up resistors R26-27, S1 switch, ICSP-IN CONN4 (right now it's used to program the main microcontroller without extracting it).

The pcb was optimized to fit the solder side, however a few jumpers are needed on the component side; if you want you can avoid that by using a double side pcb.

Pay attention to the orientation of transistors: Q1's emitter to the left, Q2 up, Q3 and Q4 right.

Once connected to the PC, a working circuit blinks D2 at 4Hz until the enumeration is completed, then at 1Hz.

To verify that everything is working correctly use the "Hardware Test" function in the control program: in this mode, to be executed without target devices, all the outputs (CK, D, PGM, VDDU, VPPU, which can be reached on pins 14-15-12-1-4 of U3, with respect to GND, pin 5) are activated in various combinations; if the measured voltages correspond to what is presented on screen then the hardware is correctly assembled.

VPP voltage could be different from the set value by up to 1V; this is due to the fact that the DCDC converter takes VCC as reference voltage; the latter comes from the USB cable and can vary from 4.75V to 5.25V; in addition the feedback voltage divider (R1-R2) can introduce another 5% of error.

The most common causes of malfunction are:

- incorrect orientation of transistors,
- incorrect inductor value,
- pcb defects like shorts or opens,
- unsoldered capacitors,
- main microcontroller not programmed or incorrectly programmed (with LVP option).

Component list:

U1 12Mhz quartz (also 4, 8, 16, 20; reconfiguration of input divider options is required)

U2 18F2550 (also 2450,2455,2458,2553,4450,4455,4458,4550,4553)

U3 20p socket.

U4 8p socket.

Q1-2 BC557 (or any PNP, pay attention to polarity)

Q3-4 BC547 (or any NPN, pay attention to polarity)

D1-2 LED

D3 1N4148 (or any diode, better if Shottky)

L1 100uH resistor type or other

R1 22K

R2 12K

R3 100K

R4:6 10K

R7 1M

R8-9 2.2K

R10 10K

R11:23 100

R24-25 330K

R26-27 10K

C1 22-100uF 25V

C2-3 22pF

C4 >= 220nF

C5 100nF

C6 10uF

[Top](#)

[Quick facts](#)

[Another programmer?](#)

[USB &](#)

[HID](#)

[firmware](#)

[Control](#)

[programs](#)

[GTK](#)

[graphical](#)

[interface](#)

[MFC](#)

[Graphical](#)

[interface](#)

[Command-](#)

[line](#)

[interface](#)

[How to ...](#)

[Supported](#)

[devices](#)

[Communication](#)

[protocol](#)

[The circuit](#)

[Voltage](#)

[regulator](#)

[How to](#)

[contribute](#)

[Download](#)

[History](#)

[Links](#)


[Contacts](#)

C7-8 100nF
 CONN1 USB type B
 CONN2-3 10 pin female stripline
 CONN4 5 pin stripline

How to use

The basic circuit can host PIC devices with 8, 14, 18, and 20 pins (except 10Fxxx); they should be inserted in U3 with alignment to pin1:

[Top](#)
[Quick facts](#)
[Another programme](#)
[USB & HID](#)
[firmware](#)
[Control](#)
[programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Commanline interface](#)
[How to ...](#)
[Supported devices](#)
[Communic protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)



I2C and UNIO memories go in U4.

One-Wire devices in TO92 package can also be connected on U4: GND lead goes to RB1 (pin 6), IO lead to RB0 (pin 5).

I plan to make an adapter for 10Fxxx with 6 or 8 pins; in the meantime it's possible to get by using wires.

Other devices can be programmed using expansion boards plugged to connectors CONN2-3 (but they're not required for basic operation):

- 28-40 pin PICs + ICSP connector
- 8-20 pin PICs (same as main board, but there's more space for a ZIF socket) + ICSP conn.
- 3.3V PIC16-18 + ICSP conn. (this board has also a 3.3V regulator)
- PIC24-30-33 + ICSP conn. (this board has also a 3.3V regulator)
- I2C, SPI, uW memories and I2C-SPI conn.
- 3.3V SPI memories (this board has also a 3.3V regulator)
- 8-14-20-28-40 pin ATMEL micros and I2C-SPI conn

Components for the expansion boards are indicated in the [schematic diagram](#); diodes can be of any kind; TBD resistors should not be mounted.

In assembling the adapters I suggest to insert the expansion connectors from the component side, and keep their plastic spacer on that side; this improves the solder strength, especially during extraction.


In case of 3.3V devices, the presence of a 3.3V adapter (which has RB1 and RB0 shorted) is checked by the software in order to avoid irreversible damage.


The 16F1xxx could be programmed also without such adapter (only the 16LF1xxx need it), but the check is present for both so there is no chance of confusion.

Due to the impossibility of erasing dsPIC30 protection registers at 3.3V, these devices are now powered at 5V; who already made the adapter (prior to v. 1.7) can easily [modify](#) it.


The following images show how to insert various target devices in the expansion boards:

[Top](#)
[Quick facts](#)
[Another programmer](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)





[Top](#)
[Quick facts](#)
[Another programme](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)



Smaller devices have to be aligned to pin 1 of the respective socket, for example 8 pin PICs in the 20p. socket, or the ATTiny2313 in the 28p. socket.


Target chips can also be programmed in circuit by routing ICSP signals (VPPU,VDDU,ICD,ICK,GND) to the application board; these signals are present in the main module expansion connectors or in some expansion boards as a discrete connector; note that low voltage devices require ICSP signals from a low voltage expansion board.

The ICSP-IN connector is used to program the main micro without extracting it, by means of another programmer.

ATTENTION: the ATMEL AVR board up to version 1.7 has a bug that prevents 28 pin devices (eg. ATMega8) from entering program mode when they are **not** configured with the internal oscillator.


In order to share the same socket with 20 pin devices (eg.

ATTiny2313), pin 10 is forced to VSS; but this pin corresponds to X2 in the bigger devices, and has to be floating when the oscillator is external.
To fix the bug it's sufficient to keep X2 floating, in one of the following ways:
a) bend pin 10 outwards on the target device so that it stays out of the socket.
b) cut the trace between pin 10 and VSS, but reconnect it when using 20 pin devices.



Version 1.8 includes a jumper to short pin 10 to VSS; unfortunately the pcb is not yet updated.

Pin mapping of various connectors in the main and expansion boards:



Map of resources used:

| Pin | Various functions | ICSP | I2C-EEPROM | SPI-EEPROM | SPI-ATMEL | uW-EEPROM | OneWire/UNIO |
|-----|-------------------|------------|------------|-----------------|-----------------|-----------|--------------|
| RB7 | | PGM | | | | | |
| RB6 | | ICSP clock | | | | | |
| RB5 | | ICSP data | A2 | | | W (6) | |
| RB4 | | | A1 | HLD | | S (1) | |
| RB3 | | | A0 | CS | Device clock | PRE (7) | |
| RB2 | expansion | | | | | | |
| RB1 | | | Clock | Clock | SPI Clock | Clock | |
| RB0 | | | Data | Data out (MISO) | Data out (MISO) | Data out | Data IO |

| | | | | | | | |
|-----|-------------------|--|----|----------------|----------------|---------|--|
| RC7 | | | | Data in (MOSI) | Data in (MOSI) | Data in | |
| RC6 | | | WP | WP | RESET | | |
| RC5 | USB D+ | | | | | | |
| RC4 | USB D- | | | | | | |
| RC2 | DCDC PWM | | | | | | |
| RC1 | controls VDD | | | | | | |
| RC0 | controls VPP | | | | | | |
| RA5 | expansion | | | | | | |
| RA4 | expansion | | | | | | |
| RA3 | expansion | | | | | | |
| RA2 | LED 2 | | | | | | |
| RA1 | LED 1 | | | | | | |
| RA0 | ADC for regulator | | | | | | |
| RE3 | S1 switch | | | | | | |

[Top](#)
[Quick facts](#)

[Another programmer?](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)

[GTK graphical interface](#)
[MFC](#)
[Graphical interface](#)

[Command line interface](#)

[How to ...](#)
[Supported devices](#)

[Communication protocol](#)

[The circuit](#)

[Voltage regulator](#)

[How to contribute](#)

[Download](#)

[History](#)

[Links](#)

[Contacts](#)

The schematic diagram was drawn with [KiCad](#) (it was originally created with Gschem, an open source program that comes with [GEDA](#) suite).

PCBs were drawn with [PCB](#); I will eventually convert this to KiCad as well.

With a little effort the circuit can also be mounted on experimental boards, without pcb.

Schematic diagram of base module and expansion boards: [Pdf](#), [KiCad](#), [Gschem](#)

Pcb of main module: [.pdf](#), [.png](#); main module + expansion boards: [.pdf](#) (also [mirrored](#)), [.png](#); everything in PCB format: [Oprog.pcb](#)

[Complete archive](#), includes sources, gerber, pdf, png

How to program the main micro the first time?

This is an interesting problem: a new device can't work as programmer, so it must be programmed in some way.


Apart from asking someone else to do it for you, my advice is to build one of those serial programmers, like JDM, to do the job the first time.

It may seem strange to use a programmer to build another one, but there is no way to interface USB without firmware; I think the effort is worth it because serial programmers are not very reliable, are slow, and of course not portable to new computers that lack serial ports.

Make sure you program the device correctly and do not enable the LVP bit (low voltage programming); this reserves RB5 for program mode entry and RB6-RB7 for communication, and the result is a non functioning programmer.

It would also be a good idea to buy a backup micro, in order to program it with updated firmware versions.

The main circuit and some expansion boards (28-40p PIC, 8-20p PIC with ZIF, 3.3V PIC16-18, 3.3V PIC24-30-33, EEPROM, ATMEL):



Expansion board connected to the main circuit:



OneWire device in TO92 package:



Switching voltage regulator

In order to generate a voltage higher than 5V we need a boost switching converter.

On the market there are thousands of single chip solutions, but I used instead the microcontroller itself and a few external components.


The width of output pulses will vary to keep the output voltage stable over all operating conditions.

In practice this is a digitally controlled regulator, as shown in

[Top](#)
[Quick facts](#)
[Another programmer](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)

[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

the following diagram:



The ADC converter presently uses the 5V supply as a reference, so the output voltage will follow it; it is possible to connect an external reference to RA3 to improve the overall precision.

Switching frequency is 90 kHz, which is well over the cutoff frequency of the output LC filter (~2,3 kHz).

The performance is limited by losses due to the transistor, diode, inductor, but since the load is very low we can use low-cost (even recycled) components; to improve load capability switch to a better transistor, a Shottky diode, a higher rated inductor.

Anyways, in order to design a suitable regulator (block C above) it's necessary to work in s domain and model the converter itself; this has fortunately been done already, some info is available for example [here](#).

With present component values the boost converter operates in discontinuous mode; critical current is:

$$I_{crit} = V_u * T / (16 * L) = 86 \text{ mA}$$

well over expected load, supposed to be 1 mA.

Other parameters:

$$V_i = 5$$

$$V_u = 12.5$$

$$D = (V_u - V_i) / V_o$$

$$L = 100 \text{e-6}$$

$$C = 47 \text{e-6}$$

$$I = 1 \text{e-3}$$

$$R = 12/I$$

$$R_l = 1.6 \text{ (inductor series resistance)}$$

$$T = 1/90 \text{e3}$$

$$\frac{v_u}{D} = G_{do} \frac{1}{1 + s/w_p} \quad \text{where} \quad G_{do} = 2 \frac{v_u}{D} \frac{M-1}{2M-1}, \quad M = \frac{V_u}{V_i}, \quad w_p = \frac{2M-1}{(M-1)RC}$$

Transfer function results to be:

$$\frac{v_u}{D} = \frac{127.58}{0.22031 s + 1}$$

[Top](#)

[Quick facts](#)

[Another](#)

[programmer:](#)

[USB &](#)

[HID](#)

[firmware](#)

[Control](#)

[programs](#)

[GTK](#)

[graphical](#)

[interface](#)

[MFC](#)

[Graphical](#)

[interface](#)

[Command](#)

[line](#)

[interface](#)

[How to ...](#)

[Supported](#)

[devices](#)

[Communication](#)

[protocol](#)

[The circuit](#)

[Voltage](#)

[regulator](#)

[How to](#)

[contribute](#)

[Download](#)


[History](#)

[Links](#)


[Contacts](#)

Which has the following Bode diagram:

$|[Y/U](j\omega)|$, $u=\text{duty-cycle}$, $y=v_u$



$\text{phase}([Y/U](j\omega))$, $u=\text{duty-cycle}$, $y=v_u$



[Top](#)
[Quick facts](#)
[Another programme](#)
[USB & HID](#)
[firmware](#)
[Control](#)
[programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command-line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

It seems that the system, in closed loop, would be stable even by itself; however it would have a steady state error of $1/DC\text{gain}$.

It's better to use a controller with a pole on the origin and a zero to stabilize everything, for example the following controller:

$$C = \frac{D}{err} = \frac{0.25 (s + 50)}{s}$$

Overall transfer function would be:

$$\frac{v_u}{v_i} = \frac{144.77 s + 7238.4}{s^2 + 4.539 s}$$

The system is stable, with a phase margin of $\sim 75^\circ$.

Since we operate in the digital domain we must choose the sampling frequency.

It can't be too high because of execution speed; if too low it limits the regulator bandwidth; a period of 250 μs was a good compromise.

The various transfer functions are converted to z domain using bilinear transformation:

$$\frac{v_u}{v_i} = \frac{0.018199 z^2 + 0.00022607 z - 0.017973}{z^2 - 1.9989 z + 0.99887}$$

The controller is:

$$C = \frac{D}{err} = \frac{0.25156 z - 0.24844}{z - 1} = \frac{C1 - C2 z^{-1}}{1 - z^{-1}}$$


Remember that z^{-1} represents a delay of one clock cycle.

Next we must deal with quantization and calculation errors.

A/D converter is 10 bits wide, and is triggered by timer2; at the end of conversion an interrupt calls the regulation routine, which calculates the new duty cycle for the PWM peripheral, also 10 bits wide.

On the feedback path it's necessary to include a voltage divider in order to limit ADC input voltage to [0,5V]; R1 and R2 do this.

So the block diagram is modified as follows:



$$a=12/34$$

$$V_u = C'H(V_i - aV_u)$$

$$\bar{V}_u = \frac{C'H}{1+aC'H} \bar{V}_i$$

To compare with the previous model we can multiply both terms by a; simply remembering to change the set point we can decide that the new input is V_i/a , and equate with the previous expression:

$$\bar{V}_u = \frac{aC'H}{1+aC'H} \bar{V}_i/a = \frac{CH}{1+CH} \bar{V}_i/a$$

$$aC' = C$$

$$aC' = \frac{aC1' - aC2' z^{-1}}{1 - z^{-1}} = C = \frac{C1 - C2 z^{-1}}{1 - z^{-1}}$$

$$aC1' = C1$$

$$aC2' = C2$$

Since the hardware works with 10 bit digital data we can go from D/err to pwm/[err]:

$$[err] = err * 1024/5$$

$$pwm = D * 1024$$

$$C' = \frac{D}{err} = \frac{pwm/1024}{[err]/1024*5} = \frac{pwm}{[err]*5} = \frac{C1' - C2' z^{-1}}{1 - z^{-1}}$$

$$pwm(1 - z^{-1}) = [err](5*C1/a - 5*C2/a z^{-1}) = [err](3.564 - 3.52 z^{-1})$$

It's clear that integer multiplications can't be used with these coefficients; the easiest solution is to work with fractional values (i.e. divide output by 2^N and multiply coefficients accordingly); considering that pwm output is 10 bits wide and left-aligned, we can easily work with values divided by 64.


$$pwm(1 - z^{-1}) = [err](k1 - k2 z^{-1})/64$$

$$k1 = 5C1/a * 64 = 228.12 \sim 228$$

$$k2 = 5C2/a * 64 = 225.25 \sim 225$$

Following are step responses of continuous-time system (blue), discrete-time system (red), discrete-time system with approximate coefficients (green); As you can see they're almost coincident.

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware Control programs](#)
[GTK graphical interface MFC Graphical interface Command-line interface](#)
[How to ... Supported devices Communication protocol The circuit Voltage regulator How to contribute Download History Links Contacts](#)



[Top](#)
[Quick facts](#)
[Another programme](#)
[USB & HID](#)
[firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)

[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

For all calculations I used [Octave](#), an open source mathematical modeling tool; version 3 has just been released, and it can be used also under the famous windows (almost)operating system.

If someone is interested [these](#) are the modeling scripts I used.


The real code for the control function was written in assembly; this is necessary for performance reasons.

In fact our C compiler calls a library function to perform multiplications, so it has to save many variables on the stack causing a delay; in this case the resulting execution time had reached 50 us, which is a significant fraction of the sampling period.


Instead, by avoiding function calls and manually coding the 16x8 bit multiplication (see k1 & k2), the execution time is down to 12 us.

Some real waveforms:


[Top](#)
[Quick facts](#)
[Another programmer](#)
[USB & HID firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface](#)
[Command line interface](#)
[How to ...](#)
[Supported devices](#)
[Communication protocol](#)
[The circuit](#)
[Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)



Power-up transient, 50 ms/div



Step response to load change (load on top trace, AC coupled output on bottom tr.), 50ms/div



Step response to set point change (from 11,5 to 12,5 V), 50 ms/div

How to contribute

The best way to contribute to this project is to build it, use it, and report bugs or suggestions.

Also there are still many devices to test; check the list in [supported devices](#).

Whoever has the know-how and patience can also expand support to other devices.

Or if you have a device that is not supported you can send it to me so that I can work on it.

If you find this project useful write me a couple of lines:

albertom78@gmail.com, and if you modified it show me your work.

On SourceForge you can find some [forums](#) where you can discuss about this project; you could also [recommend it](#) or write a (hopefully positive) review.

[Top](#)

[Quick facts](#)

[Another](#)

[programmer?](#)

[USB &](#)

[HID](#)

[firmware](#)

[Control](#)

[programs](#)

[GTK](#)

[graphical](#)

[interface](#)

[MFC](#)

[Graphical](#)

[interface](#)

[Command](#)

[line](#)

[interface](#)

[How to ...](#)

[Supported](#)

[devices](#)

[Communication](#)

[protocol](#)

[The circuit](#)

[Voltage](#)

[regulator](#)

[How to](#)

[contribute](#)

[Download](#)

[History](#)

[Links](#)

[Contacts](#)

Downloads

Schematic diagram and pcb: [Pdf](#), [KiCad](#), [complete archive](#).

Firmware: [complete MPLAB project](#) or [compiled firmware](#)(.hex) or [a version for 18F2450 \(0.8.0\)](#) (with reduced functionality, see [the circuit](#)).

opgui (GTK GUI for Linux &

Windows): [sources](#) or [application](#)

OpenProg (windows): [application only](#); [sources](#) (Visual

Studio 6 workspace)

[OP](#) (command-line for Linux & Windows)

[OpenProg and Opgui user's guide](#)

[Octave scripts](#)

History

a long

time ago

need for a reliable and free USB programmer

2007

experiments with USB PIC and varionus firmwares; voltage regulator

2008

first prototypes and software

July 2008

documentation and website, released version 0.3

August

version 0.4: added support for I2C EEPROMs

2008

November

version 0.5: I2C & SPI bus, added some ATMEL devices

2008

January

control programs v0.5.1: added some PIC devices, removed some bugs

2009

March

control programs v0.5.2 and v0.5.3: added some PIC an Atmel devices, removed some bugs

2009

April

schematic diagram and pcb v1.4: changed Atmel adapter

2009

June 2009

version 0.6: fully GPL2 USB firmware, added 93Sx6 MicroWire EEPROMs

September

version 0.6.1: solved some SPI bugs, added some Atmel devices and 93Cx6C

2009

October

control programs v0.6.2: bugfix

2009

January

version 0.7.0: added PIC24 and SPI EEPROMs;

2009

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware](#)
[Control programs](#)
[GTK graphical interface](#)
[MFC Graphical interface Command line interface](#)
[How to ... Supported devices Communication protocol](#)
[The circuit Voltage regulator](#)
[How to contribute](#)
[Download](#)
[History](#)
[Links](#)
[Contacts](#)

| | |
|---------------|--|
| 2010 | circuits v1.5: expansion board for 3.3V PIC24-30-33 |
| February 2010 | control programs v0.7.1: added some PIC18 and Atmel devices; bugfix |
| March 2010 | control programs v0.7.2: added some MicroWire eeproms; bugfix |
| April 2010 | control programs v0.7.3: added PIC16F1xxx; OP works in windows; code rework and bugfix; circuits v1.6: expansion board for 3.3V PIC16-18 |
| May 2010 | control programs v0.7.4: added PIC18FxxJx, PIC18FxxKx, PIC24H, dsPIC30-33, ATtiny2313, 241024; bugfix; circuits v1.7: modified PIC24-30-33 expansion board, PIC30 now at 5V |
| June 2010 | control programs v0.7.5: corrected write bug for 18Fxx config, added "goto ICD" write for 16Fxx, various minor fixes |
| July 2010 | firmware v0.7.6: modified TX16 and RX16 with variable period for communication with ICD; control programs v0.7.6: byte by byte read with 93xx6 for better compatibility; first release of pdb debugger (v0.1); |
| August 2010 | control programs v0.7.7: added 16F72x, some minor fixes; circuits v1.7.1: reduced value of R173 on the PIC16/18 LV expansion board |
| April 2011 | control programs v0.7.8: updated algorithms for 16F87xA and 16F62xA, 16F1822 becomes 12F1822, added 30F1010, 30F2020, 30F2023, 16F1847, 12F1840 16F1516, 16F1517, 16F1518, 16F1519, 16F1526, 16F1527; greater modularity for source code, corrected some bugs |
| June 2011 | control programs v0.7.9: added ATtiny11-12-24-26-261-44-48-461-4313-84-88-861, ATmega48-88-164A-168-324A-328-644A-1284, 16LF1902-3-4-6-7, various minor modifications and fixes; new graphical interface based on GTK for Linux and Windows |
| January 2012 | control programs v0.7.10: added 12F617,12F1501,16F1503-7-8-9,16F720-21,16F72,16F707, 18F13K22,18F14K22,18F23K22,18F43K22,18F24K22,18F44K22,18F25K22, 18F45K22,18F26K22,18F46K22,18F8520,18F66J60,18F66J65,18F67J60, 18F86J60,18F86J65,18F87J60,18F96J60,18F96J65,18F97J60, fixed read/write binary files, various corrections, added support for in-circuit debugging in OPGUI |
| July 2012 | firmware v0.8.0: support for One-Wire and UNIO; control programs v0.8.0: added DS2430,DS2431,DS2433,DS28EC20,DS1820; 11010-20-40-80-160; 251005,252005,254005,258005,251605,25X10,25X20,25X40,25X80, 25X16,25X32,25X64; 16F1782-3-4-6-7,12C508-9; corrected write for 24x1024/5 and 251024; |
| June 2013 | control programs v0.8.1: various user interface improvements; fixed EEPROM write when code protection is active (16F83-84,12F629, 12F675,16F627-28,16F630,16F676,16F870-1-2,16F873-74,16F876-77); fixed read of files > 1MB; modified prog mode entry for AVR; fixed write of 93Sxx6 with protection; firmware v0.9.0: support for ATMEL HV serial programming; new command for PIC24/33; improved DCDC regulator; control programs v0.9.0: Write16F72x requires only config-word 1; added HV serial programming for ATtiny11-12-13-24-25-44-45-84-85; added 24FJ64GA3xx-GCxx,24FJ128GA3xx-GB2xx-GCxx-DAxx,24FJ256DAxx,24EPx,33EPx; added 95xx SPI EEPROM,25X05 FLASH; added 12F1571-72,16F527,16F753,16F1454-55-59; some code rework & minor improvements; |
| March 2014 | |

control programs v0.9.1: various user interface improvements; fixed verification of ATTiny11-12; fixed 24FJ128GA3xx-GB2xx-GCxx-DAxx; added: config force for PIC18, IO lines hardware test, AVR auto speed communication, AVR write fuse @ 3kHz; faster write verification for SPI FLASH memories;

November
2014

added 10F320-22,12F529T39A,12F752,12F1612-13-14-15-18-19, 16F1512-13,16F1574-75-78-79,16F1703-04-05-07-08-09-13-16-17-18-19, 16F1788-89,16F570,16LF1554-59, 18F24K50-25K50-26K50-45K50-46K50, 18F25K80-26K80-45K80-46K80-65K80-66K80, 18F63J11-90,18F64J11-90,18F65J10-11-15-50-90, 18F66J10-11-15-16-50-55-90-93,18F67J10-11-50-90-93, 18F83J11-90,18F84J11-90,18F85J10-11-15-50-90, 18F86J10-11-15-16-50-55-90-93,18F87J10-11-50-72-90-93, 25X128,25Q40

[Top](#)
[Quick facts](#)
[Another programmer?](#)
[USB & HID firmware](#)
[Control programs](#)

June 2016

firmware v0.10.0: added instructions LOAD_PC, LOAD_DATA_INC, READ_DATA_INC, JTAG_SET_MODE, JTAG_SEND_CMD, JTAG_XFER_DATA, JTAG_XFER_F_DATA;
new USB VID&PID (0x1209,0x5432); changed some CK timing; reduced CLOCK_GEN startup time;
control programs v0.10.0: added 16F18313-23-24-25-26-44-45-46; improved USB communication

the future

increase support for PIC and ATMEL micros; add ST72, JTAG, parallel memories; expand ICD support; compile firmware also with SDCC

[GTK graphical interface](#)
[MFC](#)

Links

[Graphical interface Command line interface](#)

[Open Programmer on SourceForge](#)

[USB 2.0 standard](#)

[HID page on USB.org](#)

[pdb](#), a simple ICD debugger for PIC16

[Quick guide](#) to a HID firmware

[How to ...](#)

[USB Central](#)

[Supported devices](#)

[USB & PIC](#)

[Communication protocol](#)

[Microchip](#)

[Atmel](#)

[hiddev documentation](#)

[The circuit](#)

[Winpic](#)

[Voltage regulator](#)

[ICprog](#)

[How to contribute](#)

[Octave](#)

[Download](#)

[KiCad](#)

[History](#)

[gEDA-Gschem](#)

[Links](#)

[PCB](#)

[GNU/GPL](#)

[Piklab IDE for PIC microcontrollers](#)

[Contacts](#)

[USBPicprog](#), another open source programmer

[Cygwin](#), a linux environment inside windows

Contacts

For informations or comments:

Alberto Maccioni albertom78@gmail.com

You can also post your questions on the [forum on sourceforge](#).

Thanks

I'd like to thank all the people that contributed to the growth of this project, in particular: Anselmo for helping with linux/git,

Sandro for the highly professional PCBs, Alessandro for testing many devices, Ken for testing many AVR devices, Luigi for testing OneWire memories, Mihaly for testing SPI Flash memories.

[Top](#)

[Quick facts](#)

[Another](#)

[programmer?](#)

[USB &](#)

[HID](#)

[firmware](#)

[Control](#)

[programs](#)

[GTK](#)

[graphical](#)

[interface](#)

[MFC](#)

[Graphical](#)

[interface](#)

[Command-](#)

[line](#)

[interface](#)

[How to ...](#)

[Supported](#)

[devices](#)

[Communication](#)

[protocol](#)

[The circuit](#)

[Voltage](#)

[regulator](#)

[How to](#)

[contribute](#)

[Download](#)

[History](#)

[Links](#)

[Contacts](#)