

```
start the robot flat on the ground
// compile and load the code
// wait for code to load (look for "done uploading" in the Arduino IDE)
// wait for my LED to flash on board
// gently lift body of rocky to upright position
// this will enable the balancing algorithm
// wait for the buzzer
// let go
//
// The balancing algorithm is implemented in BalanceRocky()
// which you should modify to get the balancing to work
//

#include <Balboa32U4.h>
#include <Wire.h>
#include <LSMG.h>
#include "Balance.h"

extern int32_t angle_accum;
extern int32_t speedLeft;
extern int32_t driveLeft;
extern int32_t distanceRight;
extern int32_t speedRight;
extern int32_t distanceLeft;
extern int32_t distanceRight;
float speedCont = 0;
float displacement_m = 0;
int16_t limitCount = 0;
uint32_t cur_time = 0;
float distLeft_m;
float distRight_m;

extern uint32_t delta_ms;
float measured_speedL = 0;
float measured_speedR = 0;
float desSpeedL=0;
float desSpeedR =0;
float dist_accumL_m = 0;
float dist_accumR_m = 0;
float dist_accum = 0;
float speed_err_left = 0;
float speed_err_right = 0;
float speed_err_left_acc = 0;
float speed_err_right_acc = 0;
float errAccumRight_m = 0;
float errAccumLeft_m = 0;
float prevDistLeft_m = 0;
float prevDistRight_m = 0;
float angle_rad_diff = 0;
float angle_rad; // this is the angle in radians
float angle_rad_accum = 0; // this is the accumulated angle in radians
float angle_prev_rad = 0; // previous angle measurement
extern int32_t displacement;
int32_t prev_displacement=0;
uint32_t prev_time;

#define G_RATIO (162.5)

LSMG imu;
Balboa32U4Motors motors;
Balboa32U4Encoders encoders;
Balboa32U4Buzzer buzzer;
Balboa32U4ButtonA buttonA;

#define FIXED_ANGLE_CORRECTION (0.35) // ***** Replace the value 0.25 with the value you obtained from the Gyro calibration procedure

////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////
// This is the main function that performs the balancing
// It gets called approximately once every 10 ms by the code in loop()
// You should make modifications to this function to perform your
// balancing
////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////
void BalanceRocky()
{
    // *****Enter the control parameters here

    //CONTROL PARAMETERS FOR INITIAL SYSTEM
    float Kp = 1.2151e+06;
    float Ki = 6.3253e+06;
    float J1 = -1.2880e+06;
    float Jp = 1.6871e+05;
    float Ci = -1.3269e+06;

    //CONTROL PARAMETERS FOR STATIONARY SYSTEM
    float Kp = 1.2151e+06;
    float Ki = 6.3253e+06;
    float J1 = -1.2880e+06;
    float Jp = 1.6871e+05;
    float Ci = -1.3269e+06;

    float v_c_L, v_c_R; // these are the control velocities to be sent to the motors
    float v_d = 0; // this is the desired speed produced by the angle controller

    // Variables available to you are:
    // angle_rad - angle in radians
    // angle_rad_accum - integral of angle
    // measured_speedR - right wheel speed (m/s)
    // measured_speedL - left wheel speed (m/s)
    // distLeft_m - distance traveled by left wheel in meters
    // distRight_m - distance traveled by right wheel in meters (this is the integral of the velocities)
    // dist_accum - integral of the distance

    // *** enter an equation for v_d in terms of the variables available ***
    v_d = Kp * angle_rad + Ki * angle_rad_accum; // this is the desired velocity from the angle controller

    // The next two lines implement the feedback controller for the motor. Two separate velocities are calculated.
    //
    //
    // We use a trick here by criss-crossing the distance from left to right and
    // right to left. This helps ensure that the Left and Right motors are balanced
    //
    // *** enter equations for input signals for v_c (left and right) in terms of the variables available ***
    v_c_R = v_d - (Jp * measured_speedR + J1 * distLeft_m) - (Ci * dist_accum);
    v_c_L = v_d - (Jp * measured_speedL + J1 * distRight_m) - (Ci * dist_accum);

    // save desired speed for debugging
    desSpeedL = v_c_L;
    desSpeedR = v_c_R;

    // the motor control signal has to be between +- 300. So clip the values to be within that range
    // here
    if(v_c_L > 300) v_c_L = 300;
    if(v_c_R > 300) v_c_R = 300;
    if(v_c_L < -300) v_c_L = -300;
    if(v_c_R < -300) v_c_R = -300;

    // Set the motor speeds
    motors.setSpeeds((int16_t)(v_c_L), (int16_t)(v_c_R));
    // Serial.println("set!");
}

void setup()
{
    // Uncomment these lines if your motors are reversed.
    // motors.flipLeftMotor(true);
    // motors.flipRightMotor(true);

    Serial.begin(9600);
    prev_time = 0;
    displacement = 0;
    ledYellow(0);
    ledRed(1);
    balanceSetup();
    ledRed(0);
    angle_accum = 0;

    ledGreen(0);
    ledYellow(0);
}

int16_t time_count = 0;
extern int16_t angle_prev;
int16_t start_flag = 0;
int16_t start_counter = 0;
void lyingDown();
extern bool isBalancingStatus;
extern bool balanceUpdateDelayedStatus;

void UpdateSensors()
{
    static uint16_t lastMillis;
    uint16_t ms = millis();

    // Perform the balance updates at 100 Hz.
    balanceUpdateDelayedStatus = ms - lastMillis > UPDATE_TIME_MS + 1;
    lastMillis = ms;

    // call functions to integrate encoders and gyros
    balanceUpdateSensors();

    if (imu.a.x < 0)
    {
        lyingDown();
        isBalancingStatus = false;
    }
    else
    {
        isBalancingStatus = true;
    }
}

void GetMotorAndAngleMeasurements()
{
    // convert distance calculation into meters
    // and integrate distance
    distLeft_m = (((float)distanceLeft)/((float)G_RATIO)/12.0*80.0/1000.0*3.14159;
    distRight_m = (((float)distanceRight)/((float)G_RATIO)/12.0*80.0/1000.0*3.14159;
    dist_accum += (distLeft_m+distRight_m)*0.01/2.0;

    // compute left and right wheel speed in meters/s
    measured_speedL = speedLeft/((float)G_RATIO)/12.0*80.0/1000.0*3.14159*100.0;
    measured_speedR = speedRight/((float)G_RATIO)/12.0*80.0/1000.0*3.14159*100.0;

    prevDistLeft_m = distLeft_m;
    prevDistRight_m = distRight_m;

    // this integrates the angle
    angle_rad_accum += angle_rad*0.01;
    // this is the derivative of the angle
    angle_rad_diff = (angle_rad-angle_prev_rad)/0.01;
    angle_prev_rad = angle_rad;
}

void balanceResetAccumulators()
{
    errAccumLeft_m = 0.0;
    errAccumRight_m = 0.0;
    speed_err_left_acc = 0.0;
    speed_err_right_acc = 0.0;
}

void loop()
{
    static uint32_t prev_print_time = 0; // this variable is to control how often we print on the serial monitor
    int16_t distanceDiff; // this stores the difference in distance in encoder clicks that was traversed by the right vs the left wheel
    static float del_theta = 0;
    char enableLongTermGyroCorrection = 1;

    cur_time = millis(); // get the current time in milliseconds

    if((cur_time - prev_time) > UPDATE_TIME_MS){
        UpdateSensors(); // run the sensor updates.

        // calculate the angle in radians. The FIXED_ANGLE_CORRECTION term comes from the angle calibration procedure (separate sketch available for this)
        // del_theta corrects for long-term drift
        angle_rad = ((float)angle)/1000/180*3.14159 - FIXED_ANGLE_CORRECTION - del_theta;

        if(angle_rad > 0.1 || angle_rad < -0.1) // If angle is not within +- 6 degrees, reset counter that waits for start
        {
            start_counter = 0;
        }

        if(angle_rad > -0.1 && angle_rad < 0.1 && ! start_flag)
        {
            // increment the start counter
            start_counter++;
            // If the start counter is greater than 30, this means that the angle has been within +- 6 degrees for 0.3 seconds, then set the start_flag
            if(start_counter > 30)
            {
                balanceResetEncoders();
                start_flag = 1;
                buzzer.playFrequency(DIV_BY_10 | 445, 1000, 15);
                // Serial.println("Starting");
                ledYellow(1);
            }
        }

        // every UPDATE_TIME_MS, if the start_flag has been set, do the balancing
        if(start_flag)
        {
            // Serial.println("check1");
            GetMotorAndAngleMeasurements();
            if(enableLongTermGyroCorrection)
                del_theta = 0.999*del_theta + 0.001*angle_rad; // assume that the robot is standing. Smooth out the angle to correct for long-term gyro drift

            // Control the robot
            BalanceRocky();
            // Serial.println("balancing");
        }
        prev_time = cur_time;
    }

    // If the robot is more than 45 degrees, shut down the motor
    if(start_flag && angle_rad > .78)
    {
        motors.setSpeeds(0,0);
        start_flag = 0;
        // Serial.println("shut1");
    }
    else if(start_flag && angle < -0.78)
    {
        motors.setSpeeds(0,0);
        start_flag = 0;
        // Serial.println("shut2");
    }

    // kill switch
    if(buttonA.getSingleDebouncePress())
    {
        motors.setSpeeds(0,0);
        while(!buttonA.getSingleDebouncePress());
    }

    if(cur_time - prev_print_time > 103) // do the printing every 105 ms. Don't want to do it for an integer multiple of 10ms to not hog the processor
    {
        Serial.print(angle_rad);
        Serial.print("\n");
        Serial.print(distLeft_m);
        Serial.print("\n");
        Serial.print(measured_speedL);
        Serial.print("\n");
        Serial.print(measured_speedR);
        Serial.print("\n");
        Serial.println(speedCont);
        prev_print_time = cur_time;
    }
}
```