

SDK API User's Guide (Bluetooth)

Version 1.0.0

Display Audio

Solution Team



Release information

The following changes have been made to this document.

Change History

Date	Change
06 Dec 2017	First release for v1.0.0

Proprietary Notice

Information in this document is provided solely to enable system and software implementers to use Nexell products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Nexell reserves the right to make changes without further notice to any products herein.

Nexell makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Nexell assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Nexell data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Nexell does not convey any license under its patent rights nor the rights of others. Nexell products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Nexell product could create a situation where personal injury or death may occur. Should Buyer purchase or use Nexell products for any such unintended or unauthorized application, Buyer shall indemnify and hold Nexell and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Nexell was negligent regarding the design or manufacture of the part.

Copyright© 2017 Nexell Co.,Ltd. All rights reserved.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electric or mechanical, by photocopying, recording, or otherwise, without the prior written consent of Nexell.

Contact us

[11595] BundangYemiji Bldg. 12F, 31 Hwangsaeul-ro 258 beon gil, Bundang-gu, Sungnam-city, Gyeonggi-do, Korea.

TEL: 82-31-698-7400

FAX:82-31-698-7455

<http://www.nexell.co.kr>

Table of contents

Chap 1.	Library information	1
1.1	Overview	1
1.2	INX_BT class instance	1
1.3	List of all members for INX_BT	1
Chap 2.	Pure virtual functions	5
2.1	NXBT manager APIs	5
2.2	NXBT AVK service APIs	12
2.3	NXBT HS service APIs	16
2.4	NXBT PBC service APIs	21
2.5	NXBT MCE service APIs	23
2.6	NXBT UI callback functions.....	25

Chap 1. Library information

1.1 Overview

- Library name : libnxbt.so
- Interface class name : INX_BT
- Interface header : INX_BT.h
- Dependency libraries : libappbt.so (Broadcom BT wrapper), libxml2.so (v2.9.4)
- Operational prerequisites : BSA server daemon (Broadcom BSA server, BT stack)

1.2 INX_BT class instance

The NXBT class provides functions to easily handle the broadcom BT stack

Header	#include <INX_BT.h>
Access class instance	extern INX_BT* getInstance(void)

1.3 List of all members for INX_BT

```

INX_BT() {}
virtual ~INX_BT() {}

/* NXBT manager APIs */
virtual void setRecoveryCommand(const char *command) = 0;
virtual int32_t enableAutoConnection(bool enable) = 0;
virtual bool isAutoConnection(void) = 0;
virtual void autoConnection(bool enable) = 0;
virtual int32_t requestLastAVKConnectedDevIndex(void) = 0;
virtual int32_t requestLastHSConnectedDevIndex(void) = 0;

virtual int32_t acceptPairing(void) = 0;
virtual int32_t rejectPairing(void) = 0;
virtual int32_t unpairDevice(int32_t device_index) = 0;

virtual int32_t enableAutoPairing(bool enable) = 0;
virtual bool isAutoPairing(void) = 0;
virtual int32_t enableDiscoverable(bool enable) = 0;
virtual bool isDiscoverable(void) = 0;

```

```

virtual int32_t renameLocalDevice(const char *name) = 0;

virtual char* getLocalDevName(void) = 0;
virtual char* getLocalAddress(void) = 0;

virtual int32_t getPairedDevCount(void) = 0;
virtual int32_t getPairedDevInfoByIndex(int32_t device_index, char *name, char *bd_addr)
= 0;
virtual int32_t getPairedDevAddrByIndex(int32_t device_index, char *bd_addr) = 0;
virtual int32_t getPairedDevNameByIndex(int32_t device_index, char *name) = 0;
virtual int32_t getPairedDevIndexByAddr(char *bd_addr) = 0;
virtual char* getPairedDevNameByAddr(char *bd_addr) = 0;

virtual void setALSADevName(const char *playback, const char *capture, const char
*playback_bt, const char *capture_bt, bool use_pcm_sync) = 0;

/* NXBT AVK service APIs */
virtual int32_t openAudioAVK(void) = 0;
virtual void closeAudioAVK(void) = 0;
virtual bool isAudioStatusAVK(void) = 0;
virtual bool isConnectedAVK(void) = 0;
virtual int32_t connectToAVK(int32_t device_index) = 0;
virtual int32_t disconnectFromAVK(char *bd_addr) = 0;

virtual int32_t getConnectionNumberAVK(void) = 0;
virtual int32_t getConnectionDevAddrAVK(int32_t connected_index, char *bd_addr) = 0;

virtual int32_t requestGetElementAttr(char *bd_addr) = 0;

virtual int32_t playStartAVK(char *bd_addr) = 0;
virtual int32_t playStopAVK(char *bd_addr) = 0;
virtual int32_t playPauseAVK(char *bd_addr) = 0;
virtual int32_t playNextAVK(char *bd_addr) = 0;
virtual int32_t playPrevAVK(char *bd_addr) = 0;

/* NXBT HS service APIs */
virtual bool isConnectedHS(void) = 0;
virtual int32_t requestIndicator(void) = 0;
virtual void requestCurrentCalls(void) = 0;
virtual int32_t getConnectionDevAddrHS(char *bd_addr) = 0;

virtual int32_t connectToHS(int32_t device_index) = 0;
virtual int32_t disconnectFromHS(void) = 0;

```

```

virtual int32_t pickUpCall(void) = 0;
virtual int32_t hangUpCall(void) = 0;

virtual int32_t openAudioHS(void) = 0;
virtual int32_t closeAudioHS(void) = 0;
virtual bool isOpenedAudioHS(void) = 0;

virtual void muteMicrophoneHS(bool mute) = 0;
virtual bool isMutedMicrophoneHS(void) = 0;

virtual int32_t dialPhoneNumber(const char *number) = 0;
virtual int32_t reDialPhoneNumber(void) = 0;

virtual int32_t setATCommandDTMF(char key) = 0;

virtual int32_t requestCallOperName(void) = 0;

virtual int32_t getCurrentBattChargingStatus(void) = 0;

/* NXBT PBC service APIs */
virtual bool isConnectedPBC(void) = 0;
virtual int32_t connectToPBC(int32_t device_index) = 0;
virtual int32_t disconnectFromPBC(void) = 0;
virtual int32_t abortPBC(void) = 0;

virtual int32_t getContactFromPBC(void) = 0;
virtual int32_t getCallHistoryFromPBC(void) = 0;

/* NXBT MCE service APIs */
virtual bool isConnectedMCE(void) = 0;
virtual int32_t connectToMCE(int32_t device_index) = 0;
virtual int32_t disconnectFromMCE(void) = 0;
virtual int32_t abortMCE(void) = 0;
virtual int32_t startNotifyServerFromMCE(void) = 0;
virtual int32_t stopNotifyServerFromMCE(void) = 0;
virtual int32_t getParserBmsg(char *fullName, char *phoneNumber, char *msgBody) = 0;

/* NXBT UI callback functions */
virtual void registerMGTDIsconnectedCbManager(void *pObj, void (*cbFunc)(void *)) = 0;
virtual void registerPairingFailedCbManager(void *pObj, void (*cbFunc)(void *, int32_t)) = 0;
virtual void registerPairedDevicesCbManager(void *pObj, void (*cbFunc)(void *)) = 0;

```

```

virtual void registerUnpairedDevicesCbManager(void *pObj, void (*cbFunc)(void *)) = 0;
virtual void registerPairingRequestCbManager(void *pObj, void (*cbFunc)(void *, bool, char *, char *, int32_t)) = 0;
virtual void registerLinkDownEventCbManager(void *pObj, void (*cbFunc)(void *, char *, int32_t)) = 0;a
virtual void registerOpenFailedCbAVK(void *pObj, void (*cbFunc)(void *)) = 0;
virtual void registerStreamingStartedCbAVK(void *pObj, void (*cbFunc)(void *, bool)) = 0;
virtual void registerStreamingStoppedCbAVK(void *pObj, void (*cbFunc)(void *)) = 0;
virtual void registerConnectionStatusCbAVK(void *pObj, void (*cbFunc)(void *, bool, char *, char *)) = 0;
virtual void registerConnectionStatusCbAVKRC(void *pObj, void (*cbFunc)(void *, bool)) = 0;
virtual void registerPlayStatusCbAVK(void *pObj, void (*cbFunc)(void *, int32_t)) = 0;
virtual void registerMediaElementCbAVK(void *pObj, void (*cbFunc)(void *, char *, char *, char *, char *, int32_t)) = 0;
virtual void registerPlayPositionCbAVK(void *pObj, void (*cbFunc)(void *, int32_t)) = 0;
virtual void registerOpenFailedCbHS(void *pObj, void (*cbFunc)(void *)) = 0;
virtual void registerConnectionStatusCbHS(void *pObj, void (*cbFunc)(void *, bool, char *, char *)) = 0;
virtual void registerInbandRingSupportedCbHS(void *pObj, void (*cbFunc)(void *, bool)) = 0;
virtual void registerCallStatusCbHS(void *pObj, void (*cbFunc)(void *, int32_t)) = 0;
virtual void registerBatteryStatusCbHS(void *pObj, void (*cbFunc)(void *, int32_t)) = 0;
virtual void registerCallOperNameCbHS(void *pObj, void (*cbFunc)(void *, char *)) = 0;
virtual void registerCurrentCalllsCbHS(void *pObj, void (*cbFunc)(void *, char *)) = 0;
virtual void registerAudioMuteStatusCbHS(void *pObj, void (*cbFunc)(void *, bool, bool)) = 0;
virtual void registerIncommingCallNumberCbHS(void *pObj, void (*cbFunc)(void *, char *)) = 0;
virtual void registerCallIndicatorCbHS(void *pObj, void (*cbFunc)(void *, char *)) = 0;
virtual void registerOpenFailedCbPBC(void *pObj, void (*cbFunc)(void *)) = 0;
virtual void registerConnectionStatusCbPBC(void *pObj, void (*cbFunc)(void *, bool)) = 0;
virtual void registerNotifyGetPhonebookCbPBC(void *pObj, void (*cbFunc)(void *, int32_t)) = 0;
virtual void registerOpenFailedCbMCE(void *pObj, void (*cbFunc)(void *)) = 0;
virtual void registerConnectionStatusCbMCE(void *pObj, void (*cbFunc)(void *, bool)) = 0;
virtual void registerNotifyGetMessageCbMCE(void *pObj, void (*cbFunc)(void *)) = 0;

```

Chap 2. Pure virtual functions

2.1 NXBT manager APIs

2.1.1 setRecoveryCommand

<code>void setRecoveryCommand(const char *command)</code>
Description This function sets the bsa_server command option for recovery
Arguments command : bsa_server command.
Return Value void

2.1.2 enableAutoConnection

<code>int32_t enableAutoConnection(bool enable)</code>
Description This function decides whether or not to apply the automatic connection scenario.
Arguments enable : True or false
Return Value 0 : Success, -1 : Fail

2.1.3 isAutoConnection

<code>bool isAutoConnection(void)</code>
Description This function checks automatic connection is true or false.
Arguments void
Return Value True : Enabled, False : Disabled

2.1.4 autoConnection

void autoConnection(bool enable)
Description This function applies automatic connection.
Arguments enable : True or false
Return Value void

2.1.5 requestLastAVKConnectedDevIndex

int32_t requestLastAVKConnectedDevIndex(void)
Description This function request latest AVK connected device index from the bt_devices.xml.
Arguments void
Return Value Device's index

2.1.6 requestLastHSConnectedDevIndex

int32_t requestLastHSConnectedDevIndex(void)
Description This function request latest HS connected device index from the bt_devices.xml.
Arguments void
Return Value Device's index

2.1.7 acceptPairing

int32_t acceptPairing(void)
Description This function accepts the pairing request.
Arguments void
Return Value 0 : Success, -1 : Fail

2.1.8 rejectPairing

int32_t rejectPairing(void)
Description This function rejects the pairing request.
Arguments void
Return Value 0 : Success, -1 : Fail

2.1.9 unpairDevice

int32_t unpairDevice(int32_t device_index)
Description This function unpairs the paired device.
Arguments device_index : Index of the paired device
Return Value 0 : Success, -1 : Fail

2.1.10 enableAutoPairing

int32_t enableAutoPairing(bool enable)
Description This function decides whether or not to apply automatic pairing.
Arguments enable : True or false
Return Value 0 : Success, -1 : Fail

2.1.11 enableAutoPairing

int32_t enableAutoPairing(bool enable)
Description This function decides whether or not to apply automatic pairing.
Arguments enable : True or false
Return Value 0 : Success, -1 : Fail

2.1.12 isAutoPairing

bool isAutoPairing(void)
Description This function checks the status of auto-pairing.
Arguments void
Return Value True : Enabled, False : Disabled

2.1.13 enableDiscoverable

int32_t enableDiscoverable(bool enable)
Description This function decides whether or not to apply the discoverable mode.
Arguments enable : True or false
Return Value 0 : Success, -1 : Fail

2.1.14 isDiscoverable

bool isDiscoverable(void)
Description This function checks the discoverable mode.
Arguments void
Return Value True : Enabled, False : Disabled

2.1.15 renameLocalDevice

int32_t renameLocalDevice(const char *name)
Description This function changes the local device's name.
Arguments name : Name to be changed
Return Value 0 : Success, -1 : Fail

2.1.16 getLocalDevName

char* getLocalDevName(void)
Description This function reads the local device's name.
Arguments void
Return Value Local device's name

2.1.17 getLocalAddress

char* getLocalAddress(void)
Description This function reads the local device's address.
Arguments void
Return Value Local device's address

2.1.18 getPairedDevCount

int32_t getPairedDevCount(void)
Description This function gets the number of paired devices.
Arguments void
Return Value Number of paired devices

2.1.19 getPairedDevInfoByIndex

int32_t getPairedDevInfoByIndex(int32_t device_index, char *name, char *bd_addr)
Description This function retrieves information about devices paired by index.
Arguments device_index : Index of the paired devices name : Input buffer to store name bd_addr : Input buffer to store 6bytes address
Return Value 0 : Success, -1 : Fail

2.1.20 getPairedDevAddrByIndex

<code>int32_t getPairedDevAddrByIndex(int32_t device_index, char *bd_addr)</code>
Description This function retrieves address about devices paired by index.
Arguments device_index : Index of the paired devices bd_addr : Input buffer to store 6bytes address
Return Value 0 : Success, -1 : Fail

2.1.21 getPairedDevNameByIndex

<code>int32_t getPairedDevNameByIndex(int32_t device_index, char *name)</code>
Description This function retrieves name about devices paired by index.
Arguments device_index : Index of the paired devices name : Input buffer to store name
Return Value 0 : Success, -1 : Fail

2.1.22 getPairedDevIndexByAddr

<code>int32_t getPairedDevIndexByAddr(char *bd_addr)</code>
Description This function retrieves index about devices paired by device's address.
Arguments bd_addr : Input buffer to store 6bytes address
Return Value 0 : Success, -1 : Fail

2.1.23 getPairedDevNameByAddr

<code>char* getPairedDevNameByAddr(char *bd_addr)</code>
Description This function retrieves name about devices paired by devices's address.
Arguments bd_addr : Input buffer to store 6bytes address
Return Value Paired device's name

2.1.24 setALSADevName

```
void setALSADevName(const char *playback, const char *capture, const char *playback_bt,
const char *capture_bt, bool use_pcm_sync)
```

Description

This function sets ALSA device name.

Arguments

playback : Playback device for I2S codec

capture : Capture device for I2S codec

playback_bt : Playback device for I2S BT

capture_bt : Capture device for I2S BT

use_pcm_sync

- True : Sync mode (Using PCM link)
- False : Async mode

* Ref : When using SPDIF output, set it to async mode.

Return Value

void

2.2 NXBT AVK service APIs

2.2.1 openAudioAVK

int32_t openAudioAVK(void)
Description This function opens the AVK ALSA audio device.
Arguments void
Return Value 0 : Succeed, -1 : Failed, -2 : HS audio is currently running

2.2.2 closeAudioAVK

void closeAudioAVK(void)
Description This function closes the AVK ALSA audio device.
Arguments void
Return Value void

2.2.3 isAudioStatusAVK

bool isAudioStatusAVK(void)
Description This function checks whether it is opened with AVK ALSA audio device.
Arguments void
Return Value True : Opened, False : Closed or Not opened

2.2.4 isConnectedAVK(void)

bool isConnectedAVK(void)
Description This function checks whether it is connected with AVK service.
Arguments void

Return Value

True : Connected, False : Disconnected

2.2.5 connectToAVK**int32_t connectToAVK(int32_t device_index)****Description**

This function tries to connect to the AVK profile service.

Arguments

device_index : Index of the paired devices

Return Value

0 : Success, -1 : Fail, -2 : Cancel

2.2.6 disconnectFromAVK**int32_t disconnectFromAVK(char *bd_addr)****Description**

This function tries to disconnect from AVK profile service.

Arguments

bd_addr : Address of AVK connected device

Return Value

0 : Success, -1 : Fail

2.2.7 getConnectionNumberAVK**int32_t getConnectionNumberAVK(void)****Description**

This function gets the number of paired devices.

Arguments

void

Return Value

Number of AVK connected device

2.2.8 getConnectionDevAddrAVK**int32_t getConnectionDevAddrAVK(int32_t connected_index, char *bd_addr)****Description**

This function gets the address of AVK connected device by index.

Arguments

connected_index : Index of AVK connected device
 bd_addr : Input buffer to store 6bytes address

Return Value

0 : Success, -1 : Fail

2.2.9 requestGetElementAttr

int32_t requestGetElementAttr(char *bd_addr)

Description

This function requests for getting elements.

Arguments

bd_addr : Address of AVK connected device

Return Value

0 : Success, -1 : Fail

2.2.10 playStartAVK

int32_t playStartAVK(char *bd_addr)

Description

This function starts audio playback.

Arguments

bd_addr : Address of AVK connected device

Return Value

0 : Success, -1 : Fail

2.2.11 playStopAVK

int32_t playStopAVK(char *bd_addr)

Description

This function stops audio playback.

Arguments

bd_addr : Address of AVK connected device

Return Value

0 : Success, -1 : Fail

2.2.12 playPauseAVK

int32_t playPauseAVK(char *bd_addr)

Description

This function pauses audio playback.

Arguments

bd_addr : Address of AVK connected device

Return Value

0 : Success, -1 : Fail

2.2.13 playNextAVK**int32_t playNextAVK(char *bd_addr)****Description**

This function plays the next song.

Arguments

bd_addr : Address of AVK connected device

Return Value

0 : Success, -1 : Fail

2.2.14 playPrevAVK**int32_t playPrevAVK(char *bd_addr)****Description**

This function plays the previous song.

Arguments

bd_addr : Address of AVK connected device

Return Value

0 : Success, -1 : Fail

2.3 NXBT HS service APIs

2.3.1 isConnectedHS

bool isConnectedHS(void)
Description This function checks whether it is connected with HS service.
Arguments void
Return Value True : Connected, False : Disconnected

2.3.2 requestIndicator

int32_t requestIndicator(void)
Description This function requests indicator call string.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.3 requestCurrentCalls

int32_t requestIndicator(void)
Description This function requests indicator call string.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.4 getConnectionDevAddrHS

int32_t getConnectionDevAddrHS(char *bd_addr)
Description This function gets the address of HS connected device by index.
Arguments bd_addr : Address of HS connected device
Return Value 0 : Success, -1 : Fail

2.3.5 connectToHS

int32_t connectToHS(int32_t device_index)
Description This function tries to connect to the HS profile service.
Arguments device_index : Index of the paired devices
Return Value 0 : Success, -1 : Fail

2.3.6 disconnectFromHS

int32_t disconnectFromHS(void)
Description This function tries to disconnect from HS profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.7 pickUpCall

int32_t pickUpCall(void)
Description This function picks up the call.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.8 hangUpCall

int32_t hangUpCall(void)
Description This function hangs up the call.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.9 openAudioHS

int32_t openAudioHS(void)
Description This function opens HS audio.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.10 closeAudioHS

int32_t closeAudioHS(void)
Description This function closes HS audio.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.11 isOpenedAudioHS

bool isOpenedAudioHS(void)
Description This function checks audio HS is opened.
Arguments void
Return Value True : Enabled, False : Disabled

2.3.12 muteMicrophoneHS

void muteMicrophoneHS(bool mute)
Description This function decides whether or not to mute microphone.
Arguments mute : True or false
Return Value void

2.3.13 isMutedMicrophoneHS

bool isMutedMicrophoneHS(void)
Description This function checks mic is muted.
Arguments void
Return Value True : Enabled, False : Disabled

2.3.14 dialPhoneNumber

int32_t dialPhoneNumber(const char *number)
Description This function tries to dial.
Arguments number : Destination phone number
Return Value 0 : Success, -1 : Fail

2.3.15 reDialPhoneNumber

int32_t reDialPhoneNumber(void)
Description This function tries to redial.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.16 setATCommandDTMF

int32_t setATCommandDTMF(char key)
Description This function sends AT command.
Arguments key : Dial keypad's key
Return Value 0 : Success, -1 : Fail

2.3.17 requestCallOperName

int32_t requestCallOperName(void)
Description This function requests the call operator's name.
Arguments void
Return Value 0 : Success, -1 : Fail

2.3.18 getCurrentBattChargingStatus

int32_t getCurrentBattChargingStatus(void)
Description This function gets battery status value.
Arguments void
Return Value Battery charging status value (0 ~ 5)

2.4 NXBT PBC service APIs

2.4.1 isConnectedPBC

bool isConnectedPBC(void)
Description This function checks whether it is connected with PBC service.
Arguments void
Return Value True : Connected, False : Disconnected

2.4.2 connectToPBC

int32_t connectToPBC(int32_t device_index)
Description This function tries to connect to the PBC profile service.
Arguments device_index : Index of the paired devices
Return Value 0 : Success, -1 : Fail

2.4.3 disconnectFromPBC

int32_t disconnectFromPBC(void)
Description This function tries to disconnect from the PBC profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.4.4 abortPBC

int32_t abortPBC(void)
Description This function tries to abort the PBC profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.4.5 getContactFromPBC

int32_t getContactFromPBC(void)
Description This function imports contacts from PBC profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.4.6 getCallHistoryFromPBC

int32_t getCallHistoryFromPBC(void)
Description This function gets the call log from PBC profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.5 NXBT MCE service APIs

2.5.1 isConnectedMCE

bool isConnectedMCE(void)
Description This function checks whether it is connected with MCE service.
Arguments void
Return Value True : Connected, False : Disconnected

2.5.2 connectToMCE

int32_t connectToMCE(int32_t device_index)
Description This function tries to connect to the MCE profile service.
Arguments device_index : Index of the paired devices
Return Value 0 : Success, -1 : Fail

2.5.3 disconnectFromMCE

int32_t disconnectFromMCE(void)
Description This function tries to disconnect from the MCE profile service.
Arguments device_index : Index of the paired devices
Return Value 0 : Success, -1 : Fail

2.5.4 abortMCE

int32_t abortMCE(void)
Description This function tries to abort the MCE profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.5.5 startNotifyServerFromMCE

int32_t startNotifyServerFromMCE(void)
Description This function starts MNS(Message Notification Server) from the MCE profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.5.6 stopNotifyServerFromMCE

int32_t stopNotifyServerFromMCE(void)
Description This function stops MNS(Message Notification Server) from the MCE profile service.
Arguments void
Return Value 0 : Success, -1 : Fail

2.5.7 getParserBmsg

int32_t getParserBmsg(char *fullName, char *phoneNumber, char *msgBody)
Description This function gets the parsed B message.
Arguments fullName : The sender phoneNumber : Sender's phone number msgBody : Message content
Return Value 0 : Success, -1 : Fail

2.6 NXBT UI callback functions

2.6.1 registerMGTDisonconnectedCbManager

void registerMGTDisonconnectedCbManager(void *pObj, void (*cbFunc)(void *))
Description Notify when MGT is disconnected.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler
Return Value void

2.6.2 registerPairingFailedCbManager

void registerPairingFailedCbManager(void *pObj, void (*cbFunc)(void *, int32_t))
Description Notify when pairing is failed.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler - Fail reason ➔ 0x05 : Rejected
Return Value void

2.6.3 registerPairedDevicesCbManager

void registerPairedDevicesCbManager(void *pObj, void (*cbFunc)(void *))
Description Notify when paired device list is updated.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler
Return Value void

2.6.4 registerUnpairedDevicesCbManager

void registerUnpairedDevicesCbManager(void *pObj, void (*cbFunc)(void *))	
Description Notify when device is unpaired.	
Arguments pObj UI handler cbFunc UI callback stub function - Private handler	
Return Value void	

2.6.5 registerPairingRequestCbManager

void registerPairingRequestCbManager(void *pObj, void (*cbFunc)(void *, bool, char *, char *, int32_t))	
Description Notify when receive the pairing request.	
Arguments pObj UI handler cbFunc UI callback stub function - Private handler - Automatic mode - Device's name - Device's address - Pairing code (6 digits)	
Return Value void	

2.6.6 registerLinkDownEventCbManager

void registerLinkDownEventCbManager(void *pObj, void (*cbFunc)(void *, char *,int32_t))	
Description Notify when receive the link down event.	
Arguments pObj UI handler cbFunc UI callback stub function - Private handler - Device's address - Reason code ➔ 0x08 : RF signal is disconnected	

<ul style="list-style-type: none"> ➔ 0x13 : Turn off the BT module on the remote device or unpair the connected local device ➔ 0x16 : Unpairing connected remote devices from the local device
Return Value void

2.6.7 registerOpenFailedCbAVK

void registerOpenFailedCbAVK(void *pObj, void (*cbFunc)(void *))
Description Notify when AVK open is failed.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler
Return Value void

2.6.8 registerStreamingStartedCbAVK

void registerStreamingStartedCbAVK(void *pObj, void (*cbFunc)(void *, bool))
Description Notify when A2DP streaming is started.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler - True : ALSA open succeed, False : ALSA open failed
Return Value void

2.6.9 registerStreamingStoppedCbAVK

void registerStreamingStoppedCbAVK(void *pObj, void (*cbFunc)(void *))
Description Notify when A2DP streaming is stopped.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler
Return Value

void

2.6.10 registerConnectionStatusCbAVK

<code>void registerConnectionStatusCbAVK(void *pObj, void (*cbFunc)(void *, bool, char *, char *))</code>

Description

Notify when AVK connection status is changed.

Arguments

pObj	UI handler
cbFunc	UI callback stub function
-	Private handler
-	Connection status
-	Device's name
-	Device's address

Return Value

void

2.6.11 registerConnectionStatusCbAVKRC

<code>void registerConnectionStatusCbAVKRC(void *pObj, void (*cbFunc)(void *, bool))</code>

Description

Notify when AVKRC connection status is changed.

Arguments

pObj	UI handler
cbFunc	UI callback stub function
-	Private handler
-	Connection status

Return Value

void

2.6.12 registerPlayStatusCbAVK

<code>void registerPlayStatusCbAVK(void *pObj, void (*cbFunc)(void *, int32_t))</code>
--

Description

Notify when play status is changed.

Arguments

pObj	UI handler
cbFunc	UI callback stub function
-	Private handler
-	Play Status

<p>➔ 0x00 : Stopped</p> <p>➔ 0x01 : Playing</p> <p>➔ 0x02 : Paused</p>
<p>Return Value</p> <p>void</p>

2.6.13 registerMediaElementCbAVK

void registerMediaElementCbAVK(void *pObj, void (*cbFunc)(void *, char *, char *, char *, char *, int32_t))
<p>Description</p> <p>Notify when media elements are updated.</p>
<p>Arguments</p> <p>pObj UI handler</p> <p>cbFunc UI callback stub function</p> <ul style="list-style-type: none"> - Private handler - Title - Artist - Album - Genre - Playing time (milliseconds)
<p>Return Value</p> <p>void</p>

2.6.14 registerPlayPositionCbAVK

void registerPlayPositionCbAVK(void *pObj, void (*cbFunc)(void *, int32_t))
<p>Description</p> <p>Notify when play position is updated.</p>
<p>Arguments</p> <p>pObj UI handler</p> <p>cbFunc UI callback stub function</p> <ul style="list-style-type: none"> - Private handler - Play position (milliseconds)
<p>Return Value</p> <p>void</p>

2.6.15 registerOpenFailedCbHS

void registerOpenFailedCbHS(void *pObj, void (*cbFunc)(void *))	
Description	Notify when HS open is failed.
Arguments	pObj UI handler cbFunc UI callback stub function - Private handler
Return Value	void

2.6.16 registerConnectionStatusCbHS

void registerConnectionStatusCbHS(void *pObj, void (*cbFunc)(void *, bool, char *, char *))	
Description	Notify when HS connection status is changed.
Arguments	pObj UI handler cbFunc UI callback stub function - Private handler - Connection status - Device's name - Device's address
Return Value	void

2.6.17 registerInbandRingSupportedCbHS

void registerInbandRingSupportedCbHS(void *pObj, void (*cbFunc)(void *, bool))	
Description	Notify that in-band ring is supported or not.
Arguments	pObj UI handler cbFunc UI callback stub function - Private handler - Supported or not
Return Value	void

2.6.18 registerCallStatusCbHS

void registerCallStatusCbHS(void *pObj, void (*cbFunc)(void *, int32_t))	
Description Notify when call status is changed.	
Arguments pObj UI handler cbFunc UI callback stub function <ul style="list-style-type: none"> - Private handler - Call status <ul style="list-style-type: none"> ➔ 0x00 : UNKNOWN_CALL ➔ 0x01 : HANG_UP_CALL ➔ 0x02 : INCOMMING_CALL ➔ 0x03 : READY_OUTGOING_CALL ➔ 0x04 : OUTGOING_CALL ➔ 0x05 : PICK_UP_CALL ➔ 0x06 : DISCONNECTED_CALL 	
Return Value void	

2.6.19 registerBatteryStatusCbHS

void registerBatteryStatusCbHS(void *pObj, void (*cbFunc)(void *, int32_t))	
Description Notify when the battery status changes or when the value is requested.	
Arguments pObj UI handler cbFunc UI callback stub function <ul style="list-style-type: none"> - Private handler - Battery charging status value (0 ~ 5) 	
Return Value void	

2.6.20 registerCallOperNameCbHS

void registerCallOperNameCbHS(void *pObj, void (*cbFunc)(void *, char *))	
Description Notify when the operator's name is requested.	
Arguments pObj UI handler cbFunc UI callback stub function	

<ul style="list-style-type: none"> - Private handler - Call operator's name
Return Value void

2.6.21 registerCurrentCallsCbHS

void registerCurrentCallsCbHS(void *pObj, void (*cbFunc)(void *, char *))	
Description Notify when receive the CLCC event.	
Arguments pObj UI handler cbFunc UI callback stub function <ul style="list-style-type: none"> - Private handler - CLCC string <ul style="list-style-type: none"> ➔ <idx>,<dir>,<status>,<mode>,<mpty>[,<number>,<type>] ➔ <idx> ➔ The numbering (starting with 1) of the call given by the sequence of setting up or receiving the calls (active, held or waiting) as seen by the served subscriber. ➔ <dir> ➔ 0 (outgoing), 1 (incoming) ➔ <status> ➔ 0 = Active ➔ 1 = Held ➔ 2 = Dialing (outgoing calls only) ➔ 3 = Alerting (outgoing calls only) ➔ 4 = Incoming (incoming calls only) ➔ 5 = Waiting (incoming calls only) ➔ <mode> ➔ 0 (Voice), 1 (Data), 2 (FAX) ➔ <mpty> ➔ 0 (Not Multiparty), 1 (Multiparty) ➔ <number> – (optional) ➔ Phone number ➔ <type> – (optional) ➔ values 128-143 : The phone number format may be a national or international format, and may contain prefix and/or escape digits. ➔ values 144-159 : The phone number format is an international number, including the country code prefix. 	

➔ values 160-175 : National number. No prefix nor escape digits included.
Return Value void

2.6.22 registerAudioMuteStatusCbHS

void registerAudioMuteStatusCbHS(void *pObj, void (*cbFunc)(void *, bool, bool))
Description Notify when audio HS and mic mute status are changed.
Arguments pObj UI handler cbFunc UI callback stub function <ul style="list-style-type: none"> - Private handler - Mute status - Audio HS status
Return Value void

2.6.23 registerIncommingCallNumberCbHS

registerIncommingCallNumberCbHS(void *pObj, void (*cbFunc)(void *, char *))
Description Notify the phone number when is incomming call.
Arguments pObj UI handler cbFunc UI callback stub function <ul style="list-style-type: none"> - Private handler - CLIP string <ul style="list-style-type: none"> ➔ CLIP string structure (Calling line identification notification) ➔ <number>, type> ➔ <number> ➔ Phone number ➔ <type> ➔ values 128-143: The phone number format may be a national or international format, and may contain prefix and/or escape digits. ➔ values 144-159: The phone number format is an international number, including the country code prefix. ➔ values 160-175: National number. No prefix nor escape digits included.
Return Value void

2.6.24 registerCallIndicatorCbHS

void registerCallIndicatorCbHS(void *pObj, void (*cbFunc)(void *, char *))	
Description	Notify when receive the CIND event.
Arguments	<p>pObj UI handler</p> <p>cbFunc UI callback stub function</p> <ul style="list-style-type: none"> - Private handler - CIND string <ul style="list-style-type: none"> ➔ CIND string structure (Call indicator) ➔ ("call",(0,1)),("callsetup",(0-3)),("service",(0-1)),("signal",(0-5)),("roam",(0,1)),("battchg",(0-5)),("callheld",(0-2))
Return Value	void

2.6.25 registerOpenFailedCbPBC

void registerOpenFailedCbPBC(void *pObj, void (*cbFunc)(void *))	
Description	Notify when PBC open is failed.
Arguments	<p>pObj UI handler</p> <p>cbFunc UI callback stub function</p> <ul style="list-style-type: none"> - Private handler
Return Value	void

2.6.26 registerConnectionStatusCbPBC

void registerConnectionStatusCbPBC(void *pObj, void (*cbFunc)(void *, bool))	
Description	Notify when PBC connection status is changed.
Arguments	<p>pObj UI handler</p> <p>cbFunc UI callback stub function</p> <ul style="list-style-type: none"> - Private handler - Connection status
Return Value	void

2.6.27 registerNotifyGetPhoneBookCbPBC

void registerNotifyGetPhoneBookCbPBC(void *pObj, void (*cbFunc)(void *))
Description Notify when contact or call log is received. It is created as 'pb_data.vcf' file in "/etc/bluetooth/"
Arguments pObj UI handler cbFunc UI callback stub function - Private handler
Return Value void

2.6.28 registerOpenFailedCbMCE

void registerOpenFailedCbMCE(void *pObj, void (*cbFunc)(void *))
Description Notify when MCE open is failed.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler
Return Value void

2.6.29 registerConnectionStatusCbMCE

void registerConnectionStatusCbMCE(void *pObj, void (*cbFunc)(void *, bool))
Description Notify when MCE connection status is changed.
Arguments pObj UI handler cbFunc UI callback stub function - Private handler - Connection status
Return Value void

2.6.30 registerNotifyGetMessageCbMCE

void registerNotifyGetMessageCbMCE(void *pObj, void (*cbFunc)(void *))	
Description Notify when SMS message is received. It is created as 'get_msg.txt' file in "/etc/bluetooth/"	
Arguments pObj UI handler cbFunc UI callback stub function - Private handler	
Return Value void	