

MobaTools – a Arduino Library for Model Railroaders

Documentation for Version 1.1

The MobaTools are a compilation of classes that are useful in the model railway environment (but not only there). They facilitate some standard tasks, thus enabling even beginners to write complex Sketches.

Summary of the classes:

- Servo8** Control of up to 16 servos. The methods are largely compatible with the standard Servolib of the Arduino. However, the speed of movement of the servo can be specified..
- Stepper4** Control of up to 4 unipolar stepper motors. Unlike the standard library 'steppers' the calls are nonblocking. Once a reference point has been established, the stepper motor can be positioned absolutely (in degrees) with nearly the same methods as in the Servo8 Library.
The stepper motor driver A4988 (and all drivers that use a dir and a step input) is supported. With this driver bipolar steppers can be used.
A ramp for accelerating and decelerating the motor can be defined
- SoftLed** Soft switching of LEDs. As connecting pins all digital pins are permitted.
- EggTimer** With this class it is easy to create time delays without blocking the Sketch.

The MobaTools intensively use the Timer1 of Arduino. Therefor all other libraries or functions that also use the Timer1 can not be used simultaneously. This concerns, for example, the standard ServoLib and analog write on pins 9 + 10.

Starting with version 1.0 if timer 3 exists it is used instead. This applies to Arduino Leonardo, Micro and Mega.

Starting with version 0.9 MobaTools also support the STM32F1 platform (stm32duino).

Class Servo8

Creating one Servo object (up to 16 objects are allowed):

```
Servo8        myServo;
```

Functions:

```
byte myServo.attach( int pin );
```

Assigns a pin where the pulses are output. The pin is switched to output, but no pulses are produced yet.

```
byte myServo.attach( int pin, bool autoOff );
```

If the optional parameter 'AutoOff' with the value 'true' is passed, then the pulse is turned off automatically when the length of the pulse does not change for more than 1sec.

```
byte myServo.attach( int pin, int pos0, int pos180, bool autoOff );
```

With the parameters pos0 and pos180 can be specified, which pulse lengths are assigned to the angles '0' or '180'. (The parameter AutoOff is optional)

```
byte myServo.detach();
```

The assignment of the servos to the pin is removed, it will no longer generates pulses.

```
void myServo.setSpeed(int Speed);
```

Set moving speed of the servos. 'Speed', is the value (in 0,5µs units) the pulse length changes every 20ms until target length. Speed = 1 means that 40s are needed to change the pulse width from 1ms to 2ms.

Speed = 0 (default value) means direct change of pulselength (like standard servo Library)

With version 0.9 the resolution of speed ist 4 times better. That means Speed is in units of 0.125µs per 20ms. The lib starts in a compatibility mode where it behaves like the former versions. The new resolution is globally enabled with the command:

```
void myServo.setSpeed(int Speed, HIGHRES );
```

When this command is called once, alle servo objects use the higher resolution.

```
void myServo.write(int angle);
```

Specify arget position. The servo moves with the preset speed to that position. With values from 0 ... 180 the value is interpreted as an angle, and accordingly converted into a pulse length. Values > 180 are interpreted as pulse length in microseconds, where pulse length is limited to the minimum (700µs) or maximum (2300µs).

The write command takes effect immediately, even if the servo has not yet reached its set position of the previous write.

If this is the first 'write' call after an 'attach', the specified pulse length is output immediately (starting position).

```
byte myServo.moving();
```

Information about the state of motion of the servo.

0: The servos rests

> 0: Distance to go until the servo reaches its target position. In% of the total distance since the last 'write'.

```
byte myServo.read();
```

Current position of the servos in degrees.

```
byte myServo.readMicroseconds();
```

Current position of the servo in microseconds (pulse length).

In contrast to standard Lib these values are not necessarily the values passed with the last 'write' call. While the servo is still moving, the actual position is returned.

Although there is no separate 'stop' command, this can be accomplished with the sequence `myServo.write(myServo.readMicroseconds());`

Thus the current position is set as the new target position, which leads to the immediate stop of the servo.

```
byte myServo.attached();
```

Returns 'true' if a pin is assigned.

```
void setMinimumPulse( word length);
```

Defines the pulse length for angle '0'

```
void setMaximumPulse( word length);
```

Defines the pulse length for angle '180'

```
word angle2Pulse( byte angle);
```

Returns the pulse length for the given angle

```
word angle2Pulse( byte angle);
```

Returns the pulse length for the given angle

Class Stepper4

Bipolar and unipolar stepper motors can be controlled. In contrast to the Arduino standard library, the calls are nonblocking. The program in the 'loop' continues to run while the stepper motor is turning.

In addition to the step speed, a starting and braking ramp can also be specified. The ramp length is defined by the number of steps. This means that it is indicated how many steps are required to get from standstill to the set speed.

With ramp length 0 (default) the stepper motor behaves as before (before V1. 1).

If the step speed is changed without specifying a new ramp length, the ramp length is adjusted in such a way that the starting behavior remains approximately the same.

Setting up of the stepper motor:

```
Stepper4 myStepper( int steps360, byte mode );
```

mode specifies whether the engine is activated in FULLSTEP or HALFSTEP mode. If the parameter is omitted, FULLSTEP is assumed.
mode = A4988 indicates that the motor is connected via a stepper motor driver with step and direction input (for example, the A4988).

steps360 is the number of steps the motor takes for one revolution (in the specified Mode)

Functions:

```
byte myStepper.attach( byte spi );
```

```
byte myStepper.attach( byte pin1, byte pin2, byte pin3, byte pin4 );
```

Assignment of the output signals. The signals can be assigned either to 4 individual pins, or to the SPI interface. For the SPI interface the values SPI_1, SPI_2, SPI_3 or SPI_4 are permitted. There are always 16 bit shifted out. The parameters indicate the position of the 4 bits of the assigned motor. SPI_4 are the first pushed out bits and are therefore at the end of the shift register chain. If only a 8-bit shift register connected, only the values of SPI_1 and SPI_2 can be used.

The SPI interface is enabled only if at least one of the stepper motor is connected via SPI. An example of the wiring is shown below.

The function value is 0 ('false') if no mapping was possible.

Both unipolar and (via a double H-bridge) bipolar motors can be controlled via the 4 output pins.

```
byte myStepper.attach( byte pinStep, byte pinDir );
```

Assignment of the outputs ,step' and ,direction' if the A4988 driver is used.

```
void myStepper.detach();
```

The pin assignment is canceled.

```
void myStepper.setSpeed(int rpm10 );
```

Set up rotation speed (in revolutions / min). The value must be specified in rpm*10 .

```
uint16_t myStepper.setSpeedSteps( uint16_t speed10 );
```

Stepping speed of the motor in steps / 10sec. Maximum value is 12500 (1250Steps / sec).

If necessary, the ramp length is adjusted to keep the starting behavior approximately the same.

Function value is the current ramp length.

```
uint16_t myStepper.setSpeedSteps( uint16_t speed10, uint16_t rampLen );
```

Stepping speed of the motor in steps / 10sec.

Ramp length in steps.

The permissible ramp length depends on the step speed. The maximum is 16000 for high step rates. At step speeds below 2steps / sec, no ramp is possible. If rampLen is outside the permitted range, the value is adjusted.

Function value is the current (possibly adapted) ramp length.

```
uint16_t myStepper.setRampLen( uint16_t rampLen );
```

Ramp length in steps.

The permissible ramp length depends on the step speed. Maximum is 16000 for high step rates. At Stepraten below 2steps / sec, no ramp is possible. If rampLen is outside the permitted range, the value is adjusted.

Function value is the current (possibly adapted) ramp length.

```
void myStepper.doSteps( long stepcount );
```

Number of steps to be performed by the engine. The sign indicates the direction of rotation.

The reference point for starting the steps is always the current motor position. This is also true if the engine is already rotating at the time of the command. A new target position is calculated from the number of steps, which is then approached (with ramp). This can cause the motor to overshoot the target and then rotate back to the target position.

doSteps (0) e.g. cause the engine to decelerate and turn back to the position at the time of the command,

```
void myStepper.rotate( int direction );
```

The motor rotates up to the next stop command. (1= forward, -1 = backwards)

Rotate (0) stops the motor (with ramp). The motor stops at the end of the braking ramp.

```
void myStepper.stop( );
```

Stops the motor immediately (emergency stop).

```
void myStepper.setZero( );
```

The current position of the motor is taken as a reference point for the 'write commands with absolute positioning.

```
void myStepper.write( long angle );
```

```
void myStepper.write( long angle, byte factor );
```

The motor moves (measured from SetZero-point) to the specified angle. The passed angle is not limited to 360 °. For example setting angel = 3600 means 10 revolutions from SetZero point. If, for example, next call angel = -360 is passed, this does not mean 1 turn back, but 11 turns back! (-360 ° from SetZero point)

The 2nd call allows to specify the angle as a fraction. With factor = 10 set angle is interpreted in 1/10 °.

```
void myStepper.writeSteps( long stepPos );
```

The motor will move to the position that is stepPos steps away from SetZero point

```
byte myStepper.moving();
```

Information about the state of motion of the stepper.

= 0 when the engine stopped

= 255 when the motor rotates endlessly ('rotate' call)

> 0 ... <= 100 rest of movement to the destination point in% of total distance since last 'write' or 'doSteps' command. This may also include a 'detour'; if the ramp causes the stepper to move beyond the target first and then back again. In this case, values above 100% can occur.

```
long myStepper.stepsToDo();
```

returns the remaining number of steps until reaching the target. This may also include a

'detour'; if the ramp causes the stepper to move beyond the target first and then back again.

```
long myStepper.read();
```

returns to actual position of the stepper in degrees (measured from SetZero point).

```
long myStepper.readSteps();
```

returns to actual position of the stepper in steps (measured from SetZero point).

Absolute and relative commands can be used mixed. Internally, the steps taken are always counted (in a long variable). As long as this variable does not overflow (happens after about two billion steps in one direction), the controller always knows where the stepper is. 'SetZero' sets this counter to 0.

Class SoftLed

The class SoftLED contains methods to switch a LED on and off softly.

Create:

```
SoftLed myLed;
```

Functions:

```
byte myLed.attach( byte pinNo );
```

It is no longer necessary that pinNo is a PWM capable pin.

```
byte myLed.attach( byte pinNo, byte Invert );
```

If Invert ist true the output level is inverted.. That means if the Led is turned on, the output pin goes LOW.

```
void myLed.riseTime( int Wert );
```

The value indicates the time in ms until the Led reaches full brightness or dark.

```
void myLed.on();
```

The LED is turned on.

```
void myLed.off();
```

The LED is turned off.

```
void myLed.toggle();
```

If the LED is on, switch it off and vice versa.

```
void myLed.write( byte State);
```

State = ON oder OFF.

```
void myLed.write(byte Zustand, byte Type );
```

Type can be one of LINEAR or BULB. This changes the switching characteristic.

Class Eggtimer

This class contains methods for non blocking time delays.

Set up:

```
EggTimer myTimer
```

Functions:

```
void myTimer.setTime( long Zeit );
```

Starts the timer. The value specifies the duration of the delay in ms.
Maximum value is 2 billions ms

```
bool myTimer.running();
```

'true' while the timer is running, false otherwise .

```
long myTimer.getTime();
```

returns the remaining time (in ms) or 0 if not running.

Appendix:
Example diagram of the connection of a step motor via the SPI interface:

