


USB-1208HS

USB-based High-Speed Analog Input and Digital I/O Module

User's Guide



USB-1208HS

USB-based High-Speed Analog Input and Digital I/O Module

User's Guide



Document Revision 1, November, 2008
© Copyright 2008, Measurement Computing Corporation

Your new Measurement Computing product comes with a fantastic extra —

Management committed to your satisfaction!

Refer to www.mccdaq.com/execteam.html for the names, titles, and contact information of each key executive at Measurement Computing.

Thank you for choosing a Measurement Computing product—and congratulations! You own the finest, and you can now enjoy the protection of the most comprehensive warranties and unmatched phone tech support. It's the embodiment of our mission:

- To provide PC-based data acquisition hardware and software that will save time and save money.

Simple installations minimize the time between setting up your system and actually making measurements. We offer quick and simple access to outstanding live FREE technical support to help integrate MCC products into a DAQ system.

Limited Lifetime Warranty: Most MCC products are covered by a limited lifetime warranty against defects in materials or workmanship for the life of the product, to the original purchaser, unless otherwise noted. Any products found to be defective in material or workmanship will be repaired, replaced with same or similar device, or refunded at MCC's discretion. For specific information, please refer to the terms and conditions of sale.

Harsh Environment Warranty® Program: Any Measurement Computing product that is damaged due to misuse, or any reason, may be eligible for replacement with the same or similar device for 50% of the current list price. I/O boards face some harsh environments, some harsher than the boards are designed to withstand. Contact MCC to determine your product's eligibility for this program

30 Day Money-Back Guarantee: Any Measurement Computing Corporation product may be returned within 30 days of purchase for a full refund of the price paid for the product being returned. If you are not satisfied, or chose the wrong product by mistake, you do not have to keep it.

These warranties are in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability or fitness for a particular application. The remedies provided herein are the buyer's sole and exclusive remedies. Neither Measurement Computing Corporation, nor its employees shall be liable for any direct or indirect, special, incidental or consequential damage arising from the use of its products, even if Measurement Computing Corporation has been notified in advance of the possibility of such damages.

Trademark and Copyright Information

TracerDAQ, Universal Library, Harsh Environment Warranty, Measurement Computing Corporation, and the Measurement Computing logo are either trademarks or registered trademarks of Measurement Computing Corporation.

Windows, Microsoft, and Visual Studio are either trademarks or registered trademarks of Microsoft Corporation

LabVIEW is a trademark of National Instruments.

CompactFlash is a registered trademark of SanDisk Corporation.

XBee and XBee-PRO are trademarks of MaxStream, Inc.

All other trademarks are the property of their respective owners.

Information furnished by Measurement Computing Corporation is believed to be accurate and reliable. However, no responsibility is assumed by Measurement Computing Corporation neither for its use; nor for any infringements of patents or other rights of third parties, which may result from its use. No license is granted by implication or otherwise under any patent or copyrights of Measurement Computing Corporation.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form by any means, electronic, mechanical, by photocopying, recording, or otherwise without the prior written permission of Measurement Computing Corporation.

Notice

Measurement Computing Corporation does not authorize any Measurement Computing Corporation product for use in life support systems and/or devices without prior written consent from Measurement Computing Corporation. Life support devices/systems are devices or systems which, a) are intended for surgical implantation into the body, or b) support or sustain life and whose failure to perform can be reasonably expected to result in injury. Measurement Computing Corporation products are not designed with the components required, and are not subject to the testing required to ensure a level of reliability suitable for the treatment and diagnosis of people.

Table of Contents

Preface	
About this User's Guide	5
What you will learn from this user's guide	5
Conventions in this user's guide	5
Where to find more information	5
Chapter 1	
Introducing the USB-1208HS	6
Software features	7
Chapter 2	
Installing the USB-1208HS	8
What comes with your USB-1208HS shipment?	8
Hardware	8
Additional documentation	8
Unpacking the USB-1208HS	8
Installing the software	9
Installing the hardware	9
Connecting the USB-1208HS to your system	9
Calibrating the USB-1208HS	9
Chapter 3	
Functional Details	10
Theory of operation - analog input acquisition modes	10
Software paced mode	10
Continuous scan mode	10
External components	10
USB connector	11
Activity LED	11
Status LED	11
Screw terminals	11
Analog input terminals	12
Input configuration	12
External clock I/O terminals	13
Digital I/O terminals	13
Internal pull-up/pull-down capability	14
Counter I/O terminals	16
Timer output terminal	16
Trigger input terminal	16
Retrigger	16
Power terminals	17
Analog ground terminals	17
Common ground terminals	17
Chapter 4	
Specifications	18

About this User's Guide

What you will learn from this user's guide

This user's guide explains how to install, configure, and use the USB-1208HS so that you get the most out of its USB data acquisition features.

This user's guide also refers you to related documents available on our web site, and to technical support resources.

Conventions in this user's guide

For more information on ...

Text presented in a box signifies additional information and helpful hints related to the subject matter you are reading.

Caution! Shaded caution statements present information to help you avoid injuring yourself and others, damaging your hardware, or losing your data.

<#:#> Angle brackets that enclose numbers separated by a colon signify a range of numbers, such as those assigned to registers, bit settings, etc.

bold text **Bold** text is used for the names of objects on the screen, such as buttons, text boxes, and check boxes. For example:
1. Insert the disk or CD and click the **OK** button.

italic text *Italic* text is used for the names of manuals and help topic titles, and to emphasize a word or phrase. For example:
The *InstaCal* installation procedure is explained in the *Quick Start Guide*.
Never touch the exposed pins or circuit connections on the board.

Where to find more information

The following electronic documents provide helpful information relevant to the operation of the USB-1208HS.

- MCC's *Specifications: USB-1208HS* (the PDF version of the *Specifications* chapter in this guide) is available on our web site at www.mccdaq.com/pdfs/USB-1208HS.pdf.
- MCC's *Quick Start Guide* is available on our web site at www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf.
- MCC's *Guide to Signal Connections* is available on our web site at www.mccdaq.com/signals/signals.pdf.
- MCC's *Universal Library User's Guide* is available on our web site at www.mccdaq.com/PDFmanuals/sm-ul-user-guide.pdf.
- MCC's *Universal Library Function Reference* is available on our web site at www.mccdaq.com/PDFmanuals/sm-ul-functions.pdf.
- MCC's *Universal Library for LabVIEW™ User's Guide* is available on our web site at www.mccdaq.com/PDFmanuals/SM-UL-LabVIEW.pdf.

USB-1208HS User's Guide (this document) is also available on our web site at www.mccdaq.com/PDFmanuals/USB-1208HS.pdf.

Introducing the USB-1208HS

This user's guide contains all of the information you need to connect the USB-1208HS to your computer and to the signals you want to measure.

The USB-1208HS is a USB 2.0 high-speed device supported under popular Microsoft® Windows® operating systems. The USB-1208HS is compatible with both USB 1.1 and USB 2.0 ports, (although the speed of the module may be limited when using USB 1.1 ports)

With a multiplexed 13-bit A/D converter for all analog input channels, the USB-1208HS can sample:

- up to eight single-ended analog inputs
- up to four differential analog inputs

A digital trigger lets you start analog input and / or analog output scans.

The USB-1208HS also has 16 digital I/O connections. The port has 47 k Ω resistors that you can configure for pull-up/pull-down using a jumper inside the case. The default configuration is pull-down.

You can configure each digital bit for either input (power on default) or output.

The USB-1208HS also includes two 32-bit counters that can count TTL pulses, and one 32-bit timer.

The USB-1208HS is powered by the +5 volt USB supply from your computer, and requires no external power.

The USB-1208HS is shown below. All I/O connections are made to the screw terminals located along each side of the USB-1208HS.



USB-1208HS functions are illustrated in the block diagram shown here.




Figure 1. USB-1208HS functional block diagram

Software features

For information on the features of *InstaCal* and the other software included with your USB-1208HS, refer to the *Quick Start Guide* that shipped with your device. The *Quick Start Guide* is also available in PDF at www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf.

Check www.mccdaq.com/download.htm for the latest software version.

Installing the USB-1208HS

What comes with your USB-1208HS shipment?

As you unpack your USB-1208HS, verify that the following components are included.

Hardware

- USB-1208HS



- USB cable (2 meter length)



Additional documentation

In addition to this hardware user's guide, you should also receive the *Quick Start Guide* (available in PDF at www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf). This booklet supplies a brief description of the software you received with your USB-1208HS and information regarding installation of that software. Please read this booklet completely before installing any software or hardware.

Unpacking the USB-1208HS

As with any electronic device, you should take care while handling to avoid damage from static electricity. Before removing the USB-1208HS from its packaging, ground yourself using a wrist strap or by simply touching the computer chassis or other grounded object to eliminate any stored static charge.

If your USB-1208HS is damaged, notify Measurement Computing Corporation immediately by phone, fax, or email.

- Phone: 508-946-5100 and follow the instructions for reaching Tech Support.
- Fax: 508-946-9500 to the attention of Tech Support
- Email: techsupport@mccdaq.com

For international customers, contact your local distributor. Refer to the "International Distributors" section on our contact web page (www.mccdaq.com/contact/).

Installing the software

Refer to the *Quick Start Guide* for instructions on installing the software on the *Measurement Computing Data Acquisition Software CD*. This booklet is available in PDF at www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf.

Installing the hardware

Be sure you are using the latest system software

Before you install your USB-1208HS, run Windows Update to update your operating system with the latest USB drivers.


Install the MCC DAQ software before you install your board

The driver needed to run your board is installed with the MCC DAQ software. Therefore, you need to install the MCC DAQ software before you install your board. Refer to the *Quick Start Guide* for instructions on installing the software.

Connecting the USB-1208HS to your system

To connect the USB-1208HS to your system, turn your computer on, and connect the USB cable to a USB port on your computer or to an external USB hub connected to your computer. The USB cable provides power and communication to the USB-1208HS.

When you connect the USB-1208HS for the first time, a **Found New Hardware** dialog opens when the USB-1208HS interface is detected. The "Status" LED on the USB-1208HS turns on at this time, indicating the USB-1208HS is detected and installing on your computer.



When the dialog closes, the installation is complete.

Caution! Do not disconnect **any** device from the USB bus while the computer is communicating with the USB-1208HS, or you may lose data and/or your ability to communicate with the USB-1208HS.

If the Status LED turns off

If the Status LED lights up but then turns off, the computer has lost communication with the USB-1208HS. To restore communication, disconnect the USB cable from the computer, and then reconnect it. This should restore communication, and the LED should light up again.

Calibrating the USB-1208HS

The USB-1208HS is shipped fully calibrated. Calibration coefficients are stored in EEPROM.

Return the device to Measurement Computing Corporation when calibration is required. The normal calibration interval is once per year.

Functional Details

Theory of operation - analog input acquisition modes

The USB-1208HS can acquire analog input data in two basic modes – software paced and continuous scan.

Software paced mode

You can acquire one analog sample at a time in software paced mode. You initiate the A/D conversion by calling a software command. The analog value is converted to digital data and returned to the computer. You can repeat this procedure until you have the total number of samples that you want.

The throughput sample rate in software paced mode is system-dependent, and can range from 33 S/s to 4000 S/s.

Continuous scan mode

You can acquire data from up to eight channels in continuous scan mode. The analog data is continuously acquired, converted to digital values, and written to an onboard FIFO buffer on the USB-1208HS until you stop the scan. The FIFO buffer is serviced in blocks as the data is transferred from the USB-1208HS FIFO buffer to the memory buffer on your computer.

The maximum sampling rate is 1 MS/s aggregate over one-to-eight channels. You can start a continuous scan with either a software command or with an external hardware trigger event.

External components

The USB-1208HS has the following external components, as shown in Figure 2.

- Screw terminal banks (two)
- USB connector
- LEDs




Figure 2. USB-1208HS external components

USB connector

The USB connector provides +5 V power and communication. No external power supply is required.

Activity LED

The Activity LED indicates the communication status of the USB-1208HS. It flashes when data is transferred, and is off when the USB-1208HS is not communicating. This LED uses up to 10 mA of current and cannot be disabled.

Status LED

The Status LED lights up when the USB-1208HS is detected and installed on your computer.

Screw terminals

The USB-1208HS module's screw terminals provide the following connections:

- Eight analog input connections (**AIN0** to **AIN7**)
- 16 digital I/O connections (**DIO0** to **DIO15**)
- 10 analog ground connections (**AGND**)
- Six digital ground connections (**GND**)
- One external clock input (**AICKI**) and one external clock output (**AICKO**) for analog inputs
- One digital trigger input (**TRIG**)
- Two counter inputs (**CTR0**, **CTR1**)
- One timer output (**TMR**)
- Two 5 V power output connections (**+5 V**)




Figure 3. USB-1208HS screw terminal signals

Analog input terminals

You can connect up to eight analog input connections to the screw terminals labeled **AIN0** through **AIN7**.

Input configuration

Analog signals are referenced to analog ground (AGND).

Single-ended mode requires two wires:

- The wire carrying the signal to be measured connects to AINx.
- The second wire connects to AGND.

Differential mode requires two wires plus a ground reference:

- The wire carrying the positive portion of the differential signal to be measured connects to AINx.
- The wire carrying the negative portion of the differential signal to be measured connects to AIN(x+1).
- The analog ground reference wire connects to AGND.

The terminal configurations for single-ended and differential modes are shown in the table below.

Channel #	8 single-ended channels configuration 0		4 differential channels configuration	
	V_{in+}	V_{in-}	V_{in+}	V_{in-}
0	AIN0	AGND	AIN0	AIN1
1	AIN1	AGND	AIN2	AIN3
2	AIN2	AGND	AIN4	AIN5
3	AIN3	AGND	AIN6	AIN7
4	AIN4	AGND	-	-
5	AIN5	AGND	-	-
6	AIN6	AGND	-	-
7	AIN7	AGND	-	-

In single-ended mode, the input voltage ranges are ± 10 V, ± 5 V, ± 2.5 V, 0 to 10 V.

In differential mode, the input voltage ranges are ± 20 V, ± 10 V, and ± 5 V. The voltage level on each AINx input is limited to ± 14 V.

The following image depicts a voltage source connected to a USB-1208HS configured for single-ended mode.




Figure 4. Single-ended measurement connection

The following image depicts a Wheatstone bridge signal source connected to a USB-1208HS configured for differential mode.




Figure 5. Differential measurement connection

For more information on analog signal connections

For more information on single-ended inputs, refer to the *Guide to Signal Connections* (this document is available on our web site at www.mccdaq.com/signals/signals.pdf).

External clock I/O terminals

Use the **AICKI** terminal to receive a sampling clock from an external source.

Use the **AICKO** terminal to output the internal A/D sampling clock. When using an external clock, a pulse output generated by the external clock rising edge is also available at these terminals.

Digital I/O terminals

You can connect up to 16 digital I/O lines to screw terminals **DIO0** through **DIO15**. Refer to the pinout diagram on page 11 for the location of these pins.

The 16 DIO terminals have 47 k resistors that you can configure for pull-up/pull-down using a jumper inside the case. The default configuration is pull-down.

You can use the USB-1208HS digital I/O terminals to detect the state of any TTL-level input. Refer to the switch circuit shown in Figure 6 and the schematic shown in Figure 7. If you set the switch to the +5 V input, DIO0 reads *TRUE* (1). If you move the switch to GND, DIO0 reads *FALSE* (0).




Figure 6. Digital connection DIO0 detecting the state of a switch




Figure 7. Schematic showing switch detection by digital channel DIO0

Internal pull-up/pull-down capability

Each of the 16 DIO bits on the USB-1208HS has a 47 k Ω pull-up/pull-down resistor. To configure these bits for either a +5 V pull-up or a 0 V pull-down option, you must open the USB-1208HS case to access the three-pin jumper labeled W34.

The pull-up/pull-down voltage is common to all of the internal 47 k Ω resistors.

To open the case and set the W34 jumper, do the following.

1. Turn over the USB-1208HS and rest it on its top on a flat, stable surface.
2. Peel off the four rubber feet on the bottom of the module to access the screws.
3. Remove the four screws shown in Figure 8 from the bottom of the module.




Figure 8. Location of screws connecting bottom and top sections of case

4. Holding both the top and bottom sections of the module, turn it back over, rest it on the surface, and carefully remove the top section of the case.
5. Set the jumper to either pull-up or pull-down (see Figure 9 and Figure 10).




Figure 9. Location of W34 jumper (default pull-down setting shown)




Figure 10. W34 jumper – pull-down and pull-up configurations

6. Replace the top section of the case, and then fasten it to the bottom section with the four screws.

For more information on digital signal connections

For general information regarding digital signal connections and digital I/O techniques, refer to the *Guide to Signal Connections* (available on our web site at www.mccdaq.com/signals/signals.pdf).

Counter I/O terminals

The terminals provide connections to each 32-bit counter input channel (**CTR0** and **CTR1**). Each counter can count frequencies of up to 20 MHz.

Timer output terminal

Use the **TMR** terminal to connect to the pulse width modulation (PWM) timer output.

You can set the following timer output parameters through software:

- pulse frequency
- duty cycle (pulse width divided by the pulse period)
- number of pulses to generate
- time delay before starting the timer output after it's enabled
- resting state of the output (*idle high* or *idle low*)

The timer can generate a pulse output with a programmable frequency range of 0.00931 Hz up to 20 MHz.

Both the period and time delay ranges are 50 ns to 107.4 seconds.




Figure 11. USB-1208HS PWM timer channel

Trigger input terminal

The **TRIG** connection is an external digital trigger input. The trigger mode is software selectable for:

- Level-sensitive or edge-sensitive
- Rising or falling edge
- High or low level

The default setting at power up is edge sensitive, rising edge.

Retrigger

The acquisition uses the trigger settings for positive edge/negative edge and level-sensitive/edge-sensitive, but automatically re-arms the trigger after it is activated

Power terminals

You can use the two **+5V** connections to supply power to external devices or circuitry. These terminals can output up to 285 mA. Refer to the pinout diagram on page 11 for the location of this pin.

Caution! The **+5V** terminals are outputs. Do not connect to an external power supply or you may damage the USB-1208HS and possibly the computer.

Analog ground terminals

The 10 analog ground (**AGND**) connections provide a common ground for all analog I/O channels. Refer to the pinout diagram on page 11 for the location of the **AGND** terminal pins.

Common ground terminals

The six ground (**GND**) connections provide a common ground for the digital I/O, timer/counter I/O, timer, clock I/O, and the +5 V terminals. Refer to the pinout diagram on page 11 for the location of the **GND** terminals.

Specifications

All specifications are subject to change without notice.

Typical for 25 °C unless otherwise specified.

Specifications in *italic text* are guaranteed by design.

Analog input

Table 1. Analog input specifications

Parameter	Conditions	Specification
A/D converter		Analog Devices AD7329 - 13-bit successive approximation type
Input ranges	Software-selectable per channel	<ul style="list-style-type: none"> Differential: $\pm 20\text{ V}$, $\pm 10\text{ V}$, $\pm 5\text{ V}$ (The voltage level on each individual AIN input is limited to $\pm 14\text{ V}$.) SE: $\pm 10\text{ V}$, $\pm 5\text{ V}$, $\pm 2.5\text{ V}$, $0 - 10\text{ V}$
Number of channels		4 differential/8 single-ended, software selectable
Input configuration		Multiplexed
Channel gain queue	8 unique consecutive elements	Software configurable range for each channel
<i>Absolute maximum input voltage</i>	<i>CHx IN to GND.</i>	$\pm 25\text{ V}$ maximum (power on) $\pm 12\text{ V}$ maximum (power off)
Input impedance		35 M Ω minimum.
Input bandwidth (-3 db)	All input ranges	2 MHz typical
Input leakage current		$\pm 250\text{ nA}$ typical
Input capacitance		32 pf typical
Offset error drift		5 ppm/°C typical
Gain error drift		25 ppm/°C typical.
Maximum working voltage (signal + common mode)	$\pm 20\text{ V}$	$\pm 14\text{ V}$
	$\pm 10\text{ V}$	$\pm 11\text{ V}$
	$\pm 5\text{ V}$	$\pm 5.5\text{ V}$
Sampling rate		1 S/s to 1 MS/s, software programmable
Sample clock source		Internal A/D clock or AICKI
Burst mode		Software selectable, burst rate = 1 μs
Throughput	Software paced	33 to 4000 S/s typical, system dependent
	Scan to PC memory	1 MS/s maximum
Resolution		13 bits
<i>A/D no missing codes (uncalibrated)</i>	<i>Differential Mode</i>	<i>13 bits</i>
	<i>Single-ended Mode</i>	<i>12 bits</i>
<i>CMRR</i>	<i>60 Hz</i>	<i>74 dB typical</i>
<i>Crosstalk</i>	<i>Single-ended mode, All ranges, 250 kHz input signal</i>	<i>-62 dB typical</i>
	<i>Differential mode, all ranges, 250 kHz input signal</i>	<i>-78 dB typical</i>

Table 2. Calibrated absolute accuracy

Range	Accuracy (mV)
±20 V (differential mode)	±9.55 typical, ±13.18 maximum
±10 V (differential mode)	±4.59 typical, ±6.23 maximum
±5 V (differential mode)	±2.25 typical, ±2.75 maximum
±10 V (single-ended mode)	±5.10 typical, ±8.06 maximum
±5 V (single-ended mode)	±2.63 typical, ±4.03 maximum
±2.5 V (single-ended mode)	±1.59 typical, ±2.70 maximum
0 – 10 V (single-ended mode)	±3.29 typical, ±5.13 maximum

Table 3 summarizes the noise performance for the USB-1208HS. Noise distribution is determined by gathering 50 kS with inputs tied to ground at the user connector. Samples are gathered at the maximum specified sampling rate of 1 MS/s.

Table 3. Noise performance

Range	Typical counts	LSBrms
±20 V (differential mode)	3	0.45
±10 V (differential mode)	3	0.45
±5 V (differential mode)	3	0.45
±10 V (single-ended mode)	5	0.91
±5 V (single-ended mode)	5	0.91
±2.5 V (single-ended mode)	5	0.91
0 – 10 V (single-ended mode)	5	0.91

Table 4. Input settling time in μ s, typical

Condition	Range	±1 LSB	±4 LSB	±8 LSB
+ full-scale to – full-scale channel switch, same range to same range	±10 V	1.5	1.1	1.0
	±5 V	2.1	1.1	1.0
	±2.5 V	2.2	1.1	1.0
	0-10 V	2.6	1.1	1.0

Digital input/output

Table 5. Digital I/O specifications

Digital type	CMOS
Number of I/O	16
Configuration	Each bit may be configured as input (power on default) or output
Pull-up configuration	The port has 47 k Ω resistors configurable as pull-ups or pull-downs via internal jumper (default setting is pull-down.)
Digital I/O transfer rate (system-paced)	33 to 8000 port reads/writes or single bit reads/writes per second typical, system dependent.
Input high voltage	2.0 V minimum 5.5 V absolute maximum
Input low voltage	0.8 V maximum –0.5 V absolute minimum 0 V recommended minimum
Output high voltage	4.4 V minimum (IOH = –50 μ A) 3.76 V minimum (IOH = –24 mA)
Output low voltage	0.1 V maximum (IOL = 50 μ A) 0.44 V maximum (IOL = 24 mA)
Output current	±24 mA maximum per terminal (see "Power" section for additional information)

External trigger

Table 6. External trigger specifications

Parameter	Specification
Trigger source	TRIG input
Trigger mode	Software configurable for edge or level sensitive, rising or falling edge, high or low level. Power on default is edge sensitive, rising edge.
Trigger latency	1 μ s + 1 clock cycle maximum
Trigger pulse width	100 ns minimum
Input type	Schmitt Trigger, 33 Ω series resistor and 47 k Ω pull-down to ground
Schmitt trigger hysteresis	0.4 V to 1.2 V
Input high voltage	2.2 V minimum 5.5 V absolute maximum
Input low voltage	1.5 V maximum -0.5 V absolute minimum 0 V recommended minimum

External clock input/output

Table 7. External clock I/O specifications

Parameter	Specification
Terminal names	AICKI, AICKO
Terminal type	AICKI: Input, active on rising edge AICKO: Output, power on default is 0 V, active on rising edge
Terminal descriptions	AICKI: Receives sampling clock from external source AICKO: Outputs internal sampling clock (A/D clock) or pulse generated from AICKI when in external clock mode
Input clock rate	1 MHz maximum.
Clock pulse width	AICKI: 400 ns minimum AICKO: 400 ns minimum
Input type	Schmitt trigger, 33 Ω series resistor, 47 k Ω pull-down to ground
Schmitt trigger hysteresis	0.4 V to 1.2 V
Input high voltage	2.2 V minimum 5.5 V absolute maximum
Input low voltage	1.5 V maximum -0.5 V absolute minimum 0 V recommended minimum
Output high voltage	4.4 V minimum (IOH = -50 μ A) 3.76 V minimum (IOH = -24 mA)
Output low voltage	0.1 V maximum (IOL = 50 μ A) 0.44 V maximum (IOL = 24 mA)
Output current	\pm 24 mA maximum per terminal (see "Power" section for additional information)

Counters

Table 8. Counter specifications

Counter terminal names	CTR0, CTR1
Counter type	Event counter
Number of channels	2
Input type	Schmitt trigger, 33 Ω series resistor, 47 k Ω pull-down to ground
Schmitt trigger hysteresis	0.4 V to 1.2 V
Input high voltage	2.2 V minimum 5.5 V absolute maximum
Input low voltage	1.5 V maximum -0.5 V absolute minimum 0 V recommended minimum
Resolution	32 bits
Counter read/write rates (software paced)	33 to 8000 reads/writes per second typical, system dependent
High pulse width	25 ns minimum
Low pulse width	25 ns minimum

Timer

Table 9. Timer specifications

Timer terminal name	TMR
Timer type	PWM output with count, period, delay, and pulse width registers
Output value	Default state is idle low with pulses high, software selectable output invert
Internal clock frequency	40 MHz
Register widths	32 bits
High pulse width	20 ns minimum
Low pulse width	20 ns minimum
Output high voltage	4.4 V minimum (IOH = -50 μ A) 3.76 V minimum (IOH = -24 mA)
Output low voltage	0.1 V maximum (IOL = 50 μ A) 0.44 V maximum (IOL = 24 mA)
Output current	\pm 24 mA maximum per terminal (see "Power" section for additional information)

Memory

Table 10. Memory specifications

Data FIFO	4 kS analog input
Non-volatile memory	32 KB (16 KB firmware storage, 16 KB calibration/user data)

Power

Table 11. Power specifications

Parameter	Conditions	Specification
Operating modes		Bus-powered, USB 5 V supply
Supply current (see Note 1)	Suspend mode	<2.5 mA
	Enumeration	<100 mA
	Run mode	<500 mA
Power consumption excluding analog and digital outputs	Run mode	1.05 W maximum (210 mA input current)
Power available for +5 V, AICKO, TMR, digital I/O	Run mode	1.45 W maximum The total power consumption for all external loads must be less than this value and each load must meet the individual specification for the terminal.
Digital output power calculation		Power per output = $I_{out} * 5 \text{ V}$ (for example, @ 24 mA, $P = 0.024 * 5 = 120 \text{ mW/output}$)
+5 V output power calculation		Power (W) = $I_{out} * 5 \text{ V}$
+5 V output voltage range (see Note 2)	Run mode	4.5 V minimum, 5.25 V maximum
	Suspend mode, enumeration	0 V
+5 V output current	Run mode, no other output loads	290 mA maximum (1.45 W).
Fuses	On USB supply	0452.750 - Littelfuse 0.750A NANO2® Slo-Blo® Subminiature Surface Mount Fuse. Spare fuse mounted in holder on PCB.

Note 1: This is the total current consumption for the USB-1208HS including +5 V and digital output currents.

Note 2: Output voltage range assumes input power is within specified limits.

USB specifications

Table 12. USB specifications

USB device type	USB 2.0 (high-speed)
USB device compatibility	USB 1.1, 2.0
USB cable length	5 meters maximum.
USB cable type	A-B cable, UL type AWM 2527 or equivalent (minimum 24 AWG VBUS/GND, minimum 28 AWG D+/D-).

Environmental

Table 13. Environmental specifications

Operating temperature range	0 to 50 °C
Storage temperature range	-40 to 85 °C
Humidity	0 to 90% non-condensing

Mechanical

Table 14. Mechanical specifications

Dimensions	127 mm (L) x 88.9 mm (W) x 35.56 (H)
------------	--------------------------------------

Main connector and pin out

Table 15. Main connector specifications

Connector type	Screw terminal
Wire gauge range	16 AWG to 30 AWG

Table 16. Main connector pin out

Pin	Signal name	Pin	Signal name
1	AIN0	29	NC
2	AGND	30	NC
3	AIN1	31	AGND
4	AGND	32	NC
5	AIN2	33	NC
6	AGND	34	AGND
7	AIN3	35	AICKI
8	AGND	36	AICKO
9	AIN4	37	NC
10	AGND	38	NC
11	AIN5	39	TRIG
12	AGND	40	GND
13	AIN6	41	CTR0
14	AGND	42	CTR1
15	AIN7	43	TMR
16	AGND	44	GND
17	empty	45	empty
18	+5V	46	+5V
19	GND	47	GND
20	DIO0	48	DIO8
21	DIO1	49	DIO9
22	DIO2	50	DIO10
23	DIO3	51	DIO11
24	DIO4	52	DIO12
25	DIO5	53	DIO13
26	DIO6	54	DIO14
27	DIO7	55	DIO15
28	GND	56	GND

Measurement Computing Corporation
10 Commerce Way
Suite 1008
Norton, Massachusetts 02766
(508) 946-5100
Fax: (508) 946-9500
E-mail: info@mccdaq.com
www.mccdaq.com