

# docs

## Control Panel / Overview

Author: Control Concepts, Inc.  
Date: 2025-10-30

# Contents

- Control Panel / Overview ..... 1

# Control Panel / Overview

Control Panel is a free Windows application that allows you to connect to and configure our products over USB or Ethernet. It provides a user-friendly interface to configure parameters, monitor data, and perform diagnostics.

**INFO**[Download Control Panel](#)

The screenshot displays the Control Panel v. 2.9.52 interface for S/N 21200 Atom Digital. The interface is divided into a left sidebar and a main content area.

**Left Sidebar:**

- Control Panel v. 2.9.52
- CONNECT USB
- Combined Dashboard
- S/N 21200 Atom Digital (with device icon)
- Scope
- Data Logger
- View/Edit Config File
- Create Config File
- Modbus TCP
- MFG Unlock
- Settings
- About
- Support
- Help us improve

**Main Content Area:**

- Header:** S/N 21200, A1A080I-0A000-000-00-180-0000, S/N 21200, Id - 212, Ver - 1.0.20. Includes a "Detailed Dashboard" checkbox and a "Search parameters" field.
- AC Line Lock loss:** A red banner indicating a fault.
- Stop / Run State:** A toggle switch set to "STOP".
- Fieldbus Setpoint:** A numeric input field set to 10000.
- Temperature:** A green box displaying 31.5 °C.
- Voltage Feedforward:** A red box displaying 0.0, with a range from 0.0 to 480.0. Below it, "Error" is 0.0 and "Output Duty Cycle" is 0.0 %.
- AC Line:** A blue box displaying 0.8 v and Frequency 0.0 Hz.
- Load:** A red box displaying Voltage 0.0 v, Current 0.0 A, and Resistance 0.0 Ω.
- Control Section:**
  - Setpoint:** A dropdown menu.
  - Alarms:** A status indicator showing "OK".
  - Communication:** A status indicator.
  - Device Profile:** A dropdown menu.
  - Diagnostics:** A status indicator.
- Feedback Section:**
  - Feedback Type:** A dropdown menu set to "Voltage Feedforward".
  - Feedback Read status:** A status indicator showing "OK".
- Firing Mode Section:**
  - Firing Mode:** A dropdown menu set to "SSR - Zero Cross".
- Full Scale Section:**
  - Voltage:** A numeric input field set to 480 V.
  - Current:** A numeric input field set to 80.0 A.
- Limits Section:**
  - Voltage Limit:** A numeric input field set to 700 V.
  - Current Limit:** A numeric input field set to 84.0 A.
  - Current Trip:** A numeric input field set to 240 A.