

Percipio Camport SDK

2.6.3

Generated by Doxygen 1.8.11

Contents

1	Class Index	1
1.1	Class List	1
2	File Index	3
2.1	File List	3
3	Class Documentation	5
3.1	TY_CAMERA_DISTORTION Struct Reference	5
3.1.1	Detailed Description	5
3.2	TY_CAMERA_EXTRINSIC Struct Reference	5
3.2.1	Detailed Description	6
3.3	TY_CAMERA_INTRINSIC Struct Reference	6
3.3.1	Detailed Description	6
3.4	TY_DEVICE_BASE_INFO Struct Reference	6
3.4.1	Detailed Description	7
3.5	TY_DEVICE_NET_INFO Struct Reference	7
3.5.1	Detailed Description	7
3.6	TY_ENUM_ENTRY Struct Reference	7
3.6.1	Detailed Description	7
3.7	TY_EVENT_INFO Struct Reference	8
3.7.1	Detailed Description	8
3.8	TY_FEATURE_INFO Struct Reference	8
3.8.1	Detailed Description	8
3.9	TY_FLOAT_RANGE Struct Reference	9

3.9.1 Detailed Description	9
3.10 TY_FRAME_DATA Struct Reference	9
3.10.1 Detailed Description	9
3.11 TY_IMAGE_DATA Struct Reference	10
3.11.1 Detailed Description	10
3.12 TY_INT_RANGE Struct Reference	10
3.12.1 Detailed Description	10
3.13 TY_TRIGGER_MODE Struct Reference	11
3.13.1 Detailed Description	11
3.14 TY_VECT_3F Struct Reference	11
3.14.1 Detailed Description	11
3.15 TY_VERSION_INFO Struct Reference	11
3.15.1 Detailed Description	11
4 File Documentation	13
4.1 TY_API.h File Reference	13
4.1.1 Detailed Description	18
4.1.2 Enumeration Type Documentation	19
4.1.2.1 TY_DEVICE_COMPONENT_LIST	19
4.1.2.2 TY_FEATURE_ID_LIST	19
4.1.2.3 TY_IMAGE_MODE_LIST	20
4.1.3 Function Documentation	20
4.1.3.1 TYClearBufferQueue(TY_DEV_HANDLE hDevice)	20
4.1.3.2 TYCloseDevice(TY_DEV_HANDLE hDevice)	20
4.1.3.3 TYDeinitLib(void)	20
4.1.3.4 TYDepthToWorld(TY_DEV_HANDLE hDevice, const TY_VECT_3F *depth, T↔ Y_VECT_3F *world, int32_t worldPaddingBytes, int32_t pointCount)	21
4.1.3.5 TYDisableComponents(TY_DEV_HANDLE hDevice, int32_t componentIDs)	21
4.1.3.6 TYEnableComponents(TY_DEV_HANDLE hDevice, int32_t componentIDs)	22
4.1.3.7 TYEnqueueBuffer(TY_DEV_HANDLE hDevice, void *buffer, int32_t bufferSize)	22
4.1.3.8 TYEnterDeveloperMode(TY_DEV_HANDLE hDevice)	22

4.1.3.9	TYErrorString(TY_STATUS errorID)	23
4.1.3.10	TYFetchFrame(TY_DEV_HANDLE hDevice, TY_FRAME_DATA *frame, int32_t timeout)	23
4.1.3.11	TYGetBool(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, bool *value)	23
4.1.3.12	TYGetComponentIDs(TY_DEV_HANDLE hDevice, int32_t *componentIDs)	24
4.1.3.13	TYGetDeviceInfo(TY_DEV_HANDLE hDevice, TY_DEVICE_BASE_INFO *info)	24
4.1.3.14	TYGetDeviceList(TY_DEVICE_BASE_INFO *deviceInfos, int32_t bufferCount, int32_t *filledDeviceCount)	24
4.1.3.15	TYGetDeviceNumber(int32_t *deviceNumber)	25
4.1.3.16	TYGetEnabledComponentIDs(TY_DEV_HANDLE hDevice, int32_t *componentIDs)	25
4.1.3.17	TYGetEnum(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t *value)	25
4.1.3.18	TYGetEnumEntryCount(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t *entryCount)	26
4.1.3.19	TYGetEnumEntryInfo(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_ENUM_ENTRY *entries, int32_t entryCount, int32_t *filledEntryCount)	26
4.1.3.20	TYGetFeatureInfo(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_FEATURE_INFO *featureInfo)	27
4.1.3.21	TYGetFloat(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, float *value)	27
4.1.3.22	TYGetFloatRange(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_FLOAT_RANGE *floatRange)	28
4.1.3.23	TYGetFrameBufferSize(TY_DEV_HANDLE hDevice, int32_t *bufferSize)	28
4.1.3.24	TYGetInt(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t *value)	28
4.1.3.25	TYGetIntRange(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_INT_RANGE *intRange)	29
4.1.3.26	TYGetString(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, char *buffer, int32_t bufferSize)	29
4.1.3.27	TYGetStringBufferSize(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t *size)	30
4.1.3.28	TYGetStruct(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, void *pStruct, int32_t structSize)	30
4.1.3.29	TYIsCapturing(TY_DEV_HANDLE hDevice, bool *isCapturing)	31
4.1.3.30	TYLibVersion(TY_VERSION_INFO *version)	31

4.1.3.31	TYOpenDevice(const char *deviceId, TY_DEV_HANDLE *deviceHandle)	31
4.1.3.32	TYOpenDeviceWithIP(const char *IP, TY_DEV_HANDLE *deviceHandle)	32
4.1.3.33	TYRegisterCallback(TY_DEV_HANDLE hDevice, TY_FRAME_CALLBACK call- back, void *userdata)	32
4.1.3.34	TYRegisterEventCallback(TY_DEV_HANDLE hDevice, TY_EVENT_CALLBA↔ CK callback, void *userdata)	33
4.1.3.35	TYSendSoftTrigger(TY_DEV_HANDLE hDevice)	33
4.1.3.36	TYSetBool(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, bool value)	33
4.1.3.37	TYSetEnum(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t value)	34
4.1.3.38	TYSetFloat(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, float value)	34
4.1.3.39	TYSetInt(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t value)	35
4.1.3.40	TYSetString(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, const char *buffer)	35
4.1.3.41	TYSetStruct(TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, void *pStruct, int32_t structSize)	36
4.1.3.42	TYStartCapture(TY_DEV_HANDLE hDevice)	36
4.1.3.43	TYStopCapture(TY_DEV_HANDLE hDevice)	37
4.1.3.44	TYUndistortImage(const TY_CAMERA_INTRINSIC *cameraIntrinsic, const TY_CAMERA_DISTORTION *cameraDistortion, const TY_CAMERA_INTRINSIC *cameraNewIntrinsic, const TY_IMAGE_DATA *srcImage, TY_IMAGE_DATA *dstImage)	37
4.1.3.45	TYWorldToDepth(TY_DEV_HANDLE hDevice, const TY_VECT_3F *world, TY_VECT_3F *depth, int32_t worldPaddingBytes, int32_t pointCount)	38

Chapter 1

Class Index

1.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

TY_CAMERA_DISTORTION	
Camera distortion parameters	5
TY_CAMERA_EXTRINSIC	5
TY_CAMERA_INTRINSIC	6
TY_DEVICE_BASE_INFO	6
TY_DEVICE_NET_INFO	7
TY_ENUM_ENTRY	7
TY_EVENT_INFO	8
TY_FEATURE_INFO	8
TY_FLOAT_RANGE	9
TY_FRAME_DATA	9
TY_IMAGE_DATA	10
TY_INT_RANGE	10
TY_TRIGGER_MODE	11
TY_VECT_3F	11
TY_VERSION_INFO	11

Chapter 2

File Index

2.1 File List

Here is a list of all documented files with brief descriptions:

TY_API.h	API for Percipio depth cameras	13
--------------------------	--	----

Chapter 3

Class Documentation

3.1 TY_CAMERA_DISTORTION Struct Reference

camera distortion parameters

```
#include <TY_API.h>
```

Public Attributes

- float [data](#) [12]
k1,k2,p1,p2,k3,k4,k5,k6,s1,s2,s3,s4

3.1.1 Detailed Description

camera distortion parameters

Definition at line 404 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.2 TY_CAMERA_EXTRINSIC Struct Reference

```
#include <TY_API.h>
```

Public Attributes

- float **data** [4 *4]

3.2.1 Detailed Description

[r11, r12, r13, t1, r21, r22, r23, t2, r31, r32, r33, t3, 0, 0, 0, 1]

Definition at line 398 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.3 TY_CAMERA_INTRINSIC Struct Reference

```
#include <TY_API.h>
```

Public Attributes

- float **data** [3 *3]

3.3.1 Detailed Description

[fx, 0, cx, 0, fy, cy, 0, 0, 1]

Definition at line 389 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.4 TY_DEVICE_BASE_INFO Struct Reference

Public Attributes

- TY_INTERFACE [devInterface](#)
interface, see TY_INTERFACE_LIST
- char **id** [32]
- char **vendorName** [32]
- char **modelName** [32]
- [TY_VERSION_INFO](#) **hardwareVersion**
- [TY_VERSION_INFO](#) **firmwareVersion**
- [TY_DEVICE_NET_INFO](#) **netInfo**
- TY_STATUS **status**
- char **reserved** [248]

3.4.1 Detailed Description

Definition at line 329 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.5 TY_DEVICE_NET_INFO Struct Reference

Public Attributes

- char **mac** [32]
- char **ip** [32]
- char **netmask** [32]
- char **gateway** [32]
- char **reserved** [256]

3.5.1 Detailed Description

Definition at line 320 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.6 TY_ENUM_ENTRY Struct Reference

Public Attributes

- char **description** [64]
- int32_t **value**
- int32_t **reserved** [3]

3.6.1 Detailed Description

Definition at line 372 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.7 TY_EVENT_INFO Struct Reference

Public Attributes

- TY_EVENT **eventId**

3.7.1 Detailed Description

Definition at line 446 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.8 TY_FEATURE_INFO Struct Reference

Public Attributes

- bool [isValid](#)
true if feature exists, false otherwise
- int8_t [accessMode](#)
feature access mode, see TY_ACCESS_MODE_LIST
- bool [writableAtRun](#)
feature can be written while capturing
- char **reserved0** [1]
- TY_COMPONENT_ID **componentID**
- TY_FEATURE_ID **featureID**
- char **name** [32]
- int32_t [bindComponentID](#)
component ID current feature bind to
- int32_t [bindFeatureID](#)
feature ID current feature bind to
- char **reserved** [252]

3.8.1 Detailed Description

Definition at line 342 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.9 TY_FLOAT_RANGE Struct Reference

Public Attributes

- float **min**
- float **max**
- float **inc**
- float **reserved** [1]

3.9.1 Detailed Description

Definition at line 364 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.10 TY_FRAME_DATA Struct Reference

Public Attributes

- void * [userBuffer](#)
Pointer to user enqueued buffer, user should enqueue this buffer in the end of callback.
- int32_t [bufferSize](#)
Size of userBuffer.
- int32_t [validCount](#)
Number of valid data.
- int32_t [reserved](#) [6]
Reserved.
- [TY_IMAGE_DATA](#) [image](#) [10]
Buffer data, max to 10 images per frame, each buffer data could be an image or something else.

3.10.1 Detailed Description

Definition at line 434 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.11 TY_IMAGE_DATA Struct Reference

Public Attributes

- uint64_t [timestamp](#)
Timestamp in microseconds.
- int32_t [imageIndex](#)
image index used in trigger mode
- int32_t [status](#)
Status of this buffer.
- int32_t [componentID](#)
Where current data come from.
- int32_t [size](#)
Buffer size.
- void * [buffer](#)
Pointer to data buffer.
- int32_t [width](#)
Image width in pixels.
- int32_t [height](#)
Image height in pixels.
- int32_t [pixelFormat](#)
Pixel format, see TY_PIXEL_FORMAT_LIST.
- int32_t [reserved](#) [8]
Reserved.

3.11.1 Detailed Description

Definition at line 419 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.12 TY_INT_RANGE Struct Reference

Public Attributes

- int32_t [min](#)
- int32_t [max](#)
- int32_t [inc](#)
- int32_t [reserved](#) [1]

3.12.1 Detailed Description

Definition at line 356 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.13 TY_TRIGGER_MODE Struct Reference

Public Attributes

- int16_t **mode**
- int8_t **fps**

3.13.1 Detailed Description

Definition at line 409 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.14 TY_VECT_3F Struct Reference

Public Attributes

- float **x**
- float **y**
- float **z**

3.14.1 Detailed Description

Definition at line 379 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

3.15 TY_VERSION_INFO Struct Reference

Public Attributes

- int32_t **major**
- int32_t **minor**
- int32_t **patch**
- int32_t **reserved**

3.15.1 Detailed Description

Definition at line 312 of file TY_API.h.

The documentation for this struct was generated from the following file:

- [TY_API.h](#)

Chapter 4

File Documentation

4.1 TY_API.h File Reference

API for Percipio depth cameras.

```
#include <stddef.h>
#include <stdlib.h>
#include <stdint.h>
```

Classes

- struct [TY_VERSION_INFO](#)
- struct [TY_DEVICE_NET_INFO](#)
- struct [TY_DEVICE_BASE_INFO](#)
- struct [TY_FEATURE_INFO](#)
- struct [TY_INT_RANGE](#)
- struct [TY_FLOAT_RANGE](#)
- struct [TY_ENUM_ENTRY](#)
- struct [TY_VECT_3F](#)
- struct [TY_CAMERA_INTRINSIC](#)
- struct [TY_CAMERA_EXTRINSIC](#)
- struct [TY_CAMERA_DISTORTION](#)
 - camera distortion parameters*
- struct [TY_TRIGGER_MODE](#)
- struct [TY_IMAGE_DATA](#)
- struct [TY_FRAME_DATA](#)
- struct [TY_EVENT_INFO](#)

Macros

- `#define _STDBOOL_H`
- `#define __bool_true_false_are_defined 1`
- `#define bool _Bool`
- `#define true 1`
- `#define false 0`
- `#define TY_DLLIMPORT __attribute__((visibility("default")))`
- `#define TY_DLLEXPORT __attribute__((visibility("default")))`
- `#define TY_STDC`
- `#define TY_CDEC`
- `#define TY_EXPORT TY_DLLIMPORT`
- `#define TY_EXTC`
- `#define TY_LIB_VERSION_MAJOR 2`
- `#define TY_LIB_VERSION_MINOR 6`
- `#define TY_LIB_VERSION_PATCH 3`
- `#define TY_CAPI TY_EXTC TY_EXPORT TY_STATUS TY_STDC`

Typedefs

- `typedef enum TY_STATUS_LIST TY_STATUS_LIST`
- `typedef int32_t TY_STATUS`
- `typedef enum TY_EVENT_LIST TY_ENENT_LIST`
- `typedef int32_t TY_EVENT`
- `typedef void * TY_DEV_HANDLE`
- `typedef enum TY_DEVICE_COMPONENT_LIST TY_DEVICE_COMPONENT_LIST`
- `typedef int32_t TY_COMPONENT_ID`
- `typedef enum TY_FEATURE_TYPE_LIST TY_FEATURE_TYPE_LIST`
- `typedef int32_t TY_FEATURE_TYPE`
- `typedef enum TY_FEATURE_ID_LIST TY_FEATURE_ID_LIST`
- `typedef int32_t TY_FEATURE_ID`
- `typedef enum TY_IMAGE_MODE_LIST TY_IMAGE_MODE_LIST`
- `typedef int32_t TY_IMAGE_MODE`
- `typedef enum TY_TRIGGER_ACTIVATION_LIST TY_TRIGGER_ACTIVATION_LIST`
- `typedef int32_t TY_TRIGGER_ACTIVATION`
- `typedef enum TY_INTERFACE_LIST TY_INTERFACE_LIST`
- `typedef int32_t TY_INTERFACE`
- `typedef enum TY_ACCESS_MODE_LIST TY_ACCESS_MODE_LIST`
- `typedef enum TY_PIXEL_TYPE_LIST TY_PIXEL_TYPE_LIST`
- `typedef enum TY_PIXEL_BITS_LIST TY_PIXEL_BITS_LIST`
- `typedef enum TY_PIXEL_FORMAT_LIST TY_PIXEL_FORMAT_LIST`
- `typedef int32_t TY_PIXEL_FORMAT`
- `typedef enum TY_TRIGGER_MODE_LIST TY_TRIGGER_MODE_LIST`
- `typedef struct TY_VERSION_INFO TY_VERSION_INFO`
- `typedef struct TY_DEVICE_NET_INFO TY_DEVICE_NET_INFO`
- `typedef struct TY_DEVICE_BASE_INFO TY_DEVICE_BASE_INFO`
- `typedef struct TY_FEATURE_INFO TY_FEATURE_INFO`
- `typedef struct TY_INT_RANGE TY_INT_RANGE`
- `typedef struct TY_FLOAT_RANGE TY_FLOAT_RANGE`
- `typedef struct TY_ENUM_ENTRY TY_ENUM_ENTRY`
- `typedef struct TY_VECT_3F TY_VECT_3F`
- `typedef struct TY_TRIGGER_MODE TY_TRIGGER_MODE`
- `typedef struct TY_IMAGE_DATA TY_IMAGE_DATA`
- `typedef struct TY_FRAME_DATA TY_FRAME_DATA`
- `typedef void(* TY_FRAME_CALLBACK) (TY_FRAME_DATA *, void *userdata)`
- `typedef struct TY_EVENT_INFO TY_EVENT_INFO`
- `typedef void(* TY_EVENT_CALLBACK) (TY_EVENT_INFO *, void *userdata)`

Enumerations

- enum **TY_STATUS_LIST** {
TY_STATUS_OK = 0, **TY_STATUS_ERROR** = -1001, **TY_STATUS_NOT_INITED** = -1002, **TY_STATUS_**↵
_NOT_IMPLEMENTED = -1003,
TY_STATUS_NOT_PERMITTED = -1004, **TY_STATUS_DEVICE_ERROR** = -1005, **TY_STATUS_INVA**↵
LID_PARAMETER = -1006, **TY_STATUS_INVALID_HANDLE** = -1007,
TY_STATUS_INVALID_COMPONENT = -1008, **TY_STATUS_INVALID_FEATURE** = -1009, **TY_STATU**↵
S_WRONG_TYPE = -1010, **TY_STATUS_WRONG_SIZE** = -1011,
TY_STATUS_OUT_OF_MEMORY = -1012, **TY_STATUS_OUT_OF_RANGE** = -1013, **TY_STATUS_TIM**↵
EOUT = -1014, **TY_STATUS_WRONG_MODE** = -1015,
TY_STATUS_BUSY = -1016, **TY_STATUS_IDLE** = -1017, **TY_STATUS_NO_DATA** = -1018, **TY_STATU**↵
S_NO_BUFFER = -1019,
TY_STATUS_NULL_POINTER = -1020, **TY_STATUS_READONLY_FEATURE** = -1021 }
- enum **TY_EVENT_LIST** { **TY_EVENT_DEVICE_OFFLINE** = -2001 }
- enum **TY_DEVICE_COMPONENT_LIST** {
TY_COMPONENT_DEVICE = 0x80000000, **TY_COMPONENT_DEPTH_CAM** = 0x00010000, **TY_COMP**↵
ONENT_POINT3D_CAM = 0x00020000, **TY_COMPONENT_IR_CAM_LEFT** = 0x00040000,
TY_COMPONENT_IR_CAM_RIGHT = 0x00080000, **TY_COMPONENT_RGB_CAM_LEFT** = 0x00100000,
TY_COMPONENT_RGB_CAM_RIGHT = 0x00200000, **TY_COMPONENT_LASER** = 0x00400000,
TY_COMPONENT_IMU = 0x00800000, **TY_COMPONENT_BRIGHT_HISTO** = 0x01000000, **TY_COMPO**↵
NENT_RGB_CAM = **TY_COMPONENT_RGB_CAM_LEFT** }
- enum **TY_FEATURE_TYPE_LIST** {
TY_FEATURE_INT = 0x1000, **TY_FEATURE_FLOAT** = 0x2000, **TY_FEATURE_ENUM** = 0x3000, **TY_F**↵
EATURE_BOOL = 0x4000,
TY_FEATURE_STRING = 0x5000, **TY_FEATURE_BYTEARRAY** = 0x6000, **TY_FEATURE_STRUCT** =
0x7000 }
- enum **TY_FEATURE_ID_LIST** {
TY_STRUCT_CAM_INTRINSIC = 0x000 | **TY_FEATURE_STRUCT**, **TY_STRUCT_EXTRINSIC_TO_LEF**↵
T_IR = 0x001 | **TY_FEATURE_STRUCT**, **TY_STRUCT_EXTRINSIC_TO_LEFT_RGB** = 0x002 | **TY_FEA**↵
TURE_STRUCT, **TY_STRUCT_NET_INFO** = 0x005 | **TY_FEATURE_STRUCT**,
TY_STRUCT_CAM_DISTORTION = 0x006 | **TY_FEATURE_STRUCT**, **TY_INT_WIDTH_MAX** = 0x100 | **T**↵
Y_FEATURE_INT, **TY_INT_HEIGHT_MAX** = 0x101 | **TY_FEATURE_INT**, **TY_INT_OFFSET_X** = 0x102 |
TY_FEATURE_INT,
TY_INT_OFFSET_Y = 0x103 | **TY_FEATURE_INT**, **TY_INT_WIDTH** = 0x104 | **TY_FEATURE_INT**, **TY_IN**↵
T_HEIGHT = 0x105 | **TY_FEATURE_INT**, **TY_INT_IMAGE_SIZE** = 0x106 | **TY_FEATURE_INT**,
TY_ENUM_PIXEL_FORMAT = 0x107 | **TY_FEATURE_ENUM**, **TY_ENUM_IMAGE_MODE** = 0x108 | **TY**↵
_FEATURE_ENUM, **TY_BOOL_TRIGGER_MODE** = 0x200 | **TY_FEATURE_BOOL**, **TY_ENUM_TRIGGE**↵
R_ACTIVATION = 0x201 | **TY_FEATURE_ENUM**,
TY_INT_FRAME_PER_TRIGGER = 0x202 | **TY_FEATURE_INT**, **TY_BOOL_AUTO_EXPOSURE** = 0x300 |
TY_FEATURE_BOOL, **TY_INT_EXPOSURE_TIME** = 0x301 | **TY_FEATURE_INT**, **TY_BOOL_AUTO_GAIN**
= 0x302 | **TY_FEATURE_BOOL**,
TY_INT_GAIN = 0x303 | **TY_FEATURE_INT**, **TY_BOOL_AUTO_AWB** = 0x304 | **TY_FEATURE_BOOL**, **T**↵
Y_INT_LASER_POWER = 0x500 | **TY_FEATURE_INT**, **TY_BOOL_LASER_AUTO_CTRL** = 0x501 | **TY_F**↵
EATURE_BOOL,
TY_BOOL_UNDISTORTION = 0x510 | **TY_FEATURE_BOOL**, **TY_BOOL_BRIGHTNESS_HISTOGRAM** =
0x511 | **TY_FEATURE_BOOL**, **TY_INT_R_GAIN** = 0x520 | **TY_FEATURE_INT**, **TY_INT_G_GAIN** = 0x521 |
TY_FEATURE_INT,
TY_INT_B_GAIN = 0x522 | **TY_FEATURE_INT**, **TY_STRUCT_WORK_MODE** = 0x523 | **TY_FEATURE_**↵
STRUCT }
- enum **TY_IMAGE_MODE_LIST** { **TY_IMAGE_MODE_320x240** = (320<<12)+240, **TY_IMAGE_MODE**↵
_640x480 = (640<<12)+480, **TY_IMAGE_MODE_1280x960** = (1280<<12)+960, **TY_IMAGE_MODE_**↵
2592x1944 = (2592<<12)+1944 }
- enum **TY_TRIGGER_ACTIVATION_LIST** { **TY_TRIGGER_ACTIVATION_FALLINGEDGE** = 0, **TY_TRIG**↵
GER_ACTIVATION_RISINGEDGE = 1 }
- enum **TY_INTERFACE_LIST** { **TY_INTERFACE_UNKNOWN** = 0, **TY_INTERFACE_ETHERNET** = 1, **TY**↵
_INTERFACE_USB = 2 }
- enum **TY_ACCESS_MODE_LIST** { **TY_ACCESS_READABLE** = 0x1, **TY_ACCESS_WRITABLE** = 0x2 }

- enum **TY_PIXEL_TYPE_LIST** { **TY_PIXEL_MONO** = 0x10000000, **TY_PIXEL_COLOR** = 0x20000000, **TY_PIXEL_DEPTH** = 0x30000000, **TY_PIXEL_POINT3D** = 0x40000000 }
- enum **TY_PIXEL_BITS_LIST** { **TY_PIXEL_8BIT** = 0x00080000, **TY_PIXEL_16BIT** = 0x00100000, **TY_PIXEL_24BIT** = 0x00180000, **TY_PIXEL_32BIT** = 0x00200000, **TY_PIXEL_96BIT** = 0x00600000 }
- enum **TY_PIXEL_FORMAT_LIST** { **TY_PIXEL_FORMAT_UNDEFINED** = 0, **TY_PIXEL_FORMAT_MONO** = (TY_PIXEL_MONO | TY_PIXEL_8BIT | 0x0000), **TY_PIXEL_FORMAT_RGB** = (TY_PIXEL_COLOR | TY_PIXEL_24BIT | 0x0010), **TY_PIXEL_FORMAT_YUV422** = (TY_PIXEL_COLOR | TY_PIXEL_16BIT | 0x0011), **TY_PIXEL_FORMAT_YVYU** = TY_PIXEL_FORMAT_YUV422, **TY_PIXEL_FORMAT_YUYV** = (TY_PIXEL_COLOR | TY_PIXEL_16BIT | 0x0012), **TY_PIXEL_FORMAT_JPEG** = (TY_PIXEL_COLOR | TY_PIXEL_24BIT | 0x0013), **TY_PIXEL_FORMAT_DEPTH16** = (TY_PIXEL_DEPTH | TY_PIXEL_16BIT | 0x0020), **TY_PIXEL_FORMAT_FPOINT3D** = (TY_PIXEL_POINT3D | TY_PIXEL_96BIT | 0x0030) }
- enum **TY_TRIGGER_MODE_LIST** { **TY_TRIGGER_MODE_CONTINUES** = 0, **TY_TRIGGER_MODE_TRIGGER_SLAVE** = 1, **TY_TRIGGER_MODE_M_SIG** = 2, **TY_TRIGGER_MODE_M_PER** = 3 }

Functions

- **TY_EXTC** **TY_EXPORT** const char ***TY_STDC** [TYErrorString](#) (TY_STATUS errorID)
Get error information.
- **TY_CAPI** [TYDeinitLib](#) (void)
Deinit this library.
- **TY_CAPI** [TYLibVersion](#) (**TY_VERSION_INFO** *version)
Get current library version.
- **TY_CAPI** [TYGetDeviceNumber](#) (int32_t *deviceNumber)
Get number of current connected devices.
- **TY_CAPI** [TYGetDeviceList](#) (**TY_DEVICE_BASE_INFO** *deviceInfos, int32_t bufferCount, int32_t *filledDeviceCount)
Get device info list.
- **TY_CAPI** [TYOpenDevice](#) (const char *deviceID, TY_DEV_HANDLE *deviceHandle)
Open device by device ID.
- **TY_CAPI** [TYOpenDeviceWithIP](#) (const char *IP, TY_DEV_HANDLE *deviceHandle)
Open device by device IP, useful when device not listed.
- **TY_CAPI** [TYCloseDevice](#) (TY_DEV_HANDLE hDevice)
Close device by device handle.
- **TY_CAPI** [TYEnterDeveloperMode](#) (TY_DEV_HANDLE hDevice)
Enable developer mode by device handle.
- **TY_CAPI** [TYGetDeviceInfo](#) (TY_DEV_HANDLE hDevice, **TY_DEVICE_BASE_INFO** *info)
Get base info of the open device.
- **TY_CAPI** [TYGetComponentIDs](#) (TY_DEV_HANDLE hDevice, int32_t *componentIDs)
Get all components IDs.
- **TY_CAPI** [TYGetEnabledComponentIDs](#) (TY_DEV_HANDLE hDevice, int32_t *componentIDs)
Get all enabled components IDs.
- **TY_CAPI** [TYEnableComponents](#) (TY_DEV_HANDLE hDevice, int32_t componentIDs)
Enable components.
- **TY_CAPI** [TYDisableComponents](#) (TY_DEV_HANDLE hDevice, int32_t componentIDs)
Disable components.
- **TY_CAPI** [TYGetFrameBufferSize](#) (TY_DEV_HANDLE hDevice, int32_t *bufferSize)
Get total buffer size of one frame in current configuration.
- **TY_CAPI** [TYEnqueueBuffer](#) (TY_DEV_HANDLE hDevice, void *buffer, int32_t bufferSize)
Enqueue a user allocated buffer.

- TY_CAPI [TYClearBufferQueue](#) (TY_DEV_HANDLE hDevice)
Clear the internal buffer queue, so that user can release all the buffer.
- TY_CAPI [TYStartCapture](#) (TY_DEV_HANDLE hDevice)
Start capture.
- TY_CAPI [TYStopCapture](#) (TY_DEV_HANDLE hDevice)
Stop capture.
- TY_CAPI [TYIsCapturing](#) (TY_DEV_HANDLE hDevice, bool *isCapturing)
Get if the device is capturing.
- TY_CAPI [TYSendSoftTrigger](#) (TY_DEV_HANDLE hDevice)
Send a software trigger when device works in trigger mode.
- TY_CAPI [TYRegisterCallback](#) (TY_DEV_HANDLE hDevice, TY_FRAME_CALLBACK callback, void *userdata)
Register callback of frame. Register NULL to clean callback.
- TY_CAPI [TYRegisterEventCallback](#) (TY_DEV_HANDLE hDevice, TY_EVENT_CALLBACK callback, void *userdata)
Register device status callback. Register NULL to clean callback.
- TY_CAPI [TYFetchFrame](#) (TY_DEV_HANDLE hDevice, TY_FRAME_DATA *frame, int32_t timeout)
Fetch one frame.
- TY_CAPI [TYGetFeatureInfo](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_FEATURE_INFO *featureInfo)
Get feature info.
- TY_CAPI [TYGetIntRange](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_INT_RANGE *intRange)
Get value range of integer feature.
- TY_CAPI [TYGetInt](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t *value)
Get value of integer feature.
- TY_CAPI [TYSetInt](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t value)
Set value of integer feature.
- TY_CAPI [TYGetFloatRange](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_FLOAT_RANGE *floatRange)
Get value range of float feature.
- TY_CAPI [TYGetFloat](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, float *value)
Get value of float feature.
- TY_CAPI [TYSetFloat](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, float value)
Set value of float feature.
- TY_CAPI [TYGetEnumEntryCount](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t *entryCount)
Get number of enum entries.
- TY_CAPI [TYGetEnumEntryInfo](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, TY_ENUM_ENTRY *entries, int32_t entryCount, int32_t *filledEntryCount)
Get list of enum entries.
- TY_CAPI [TYGetEnum](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t *value)
Get current value of enum feature.
- TY_CAPI [TYSetEnum](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, int32_t value)
Set value of enum feature.
- TY_CAPI [TYGetBool](#) (TY_DEV_HANDLE hDevice, TY_COMPONENT_ID componentID, TY_FEATURE_ID featureID, bool *value)

4.1.2 Enumeration Type Documentation

4.1.2.1 enum TY_DEVICE_COMPONENT_LIST

Enumerator

TY_COMPONENT_DEVICE Abstract component stands for whole device, always enabled.
TY_COMPONENT_DEPTH_CAM Depth camera.
TY_COMPONENT_POINT3D_CAM Point3D camera.
TY_COMPONENT_IR_CAM_LEFT Left IR camera.
TY_COMPONENT_IR_CAM_RIGHT Right IR camera.
TY_COMPONENT_RGB_CAM_LEFT Left RGB camera.
TY_COMPONENT_RGB_CAM_RIGHT Right RGB camera.
TY_COMPONENT_LASER Laser.
TY_COMPONENT_IMU Inertial Measurement Unit.
TY_COMPONENT_BRIGHT_HISTO virtual component for brightness histogram of ir

Definition at line 154 of file TY_API.h.

4.1.2.2 enum TY_FEATURE_ID_LIST

Enumerator

TY_STRUCT_CAM_INTRINSIC see [TY_CAMERA_INTRINSIC](#)
TY_STRUCT_EXTRINSIC_TO_LEFT_IR extrinsic from current component to left IR, see [TY_CAMERA_↔EXTRINSIC](#)
TY_STRUCT_EXTRINSIC_TO_LEFT_RGB extrinsic from current component to left RGB, see [TY_CAME↔RA_EXTRINSIC](#)
TY_STRUCT_NET_INFO see [TY_DEVICE_NET_INFO](#)
TY_STRUCT_CAM_DISTORTION see [TY_CAMERA_DISTORTION](#)
TY_ENUM_PIXEL_FORMAT Pixel format, see TY_PIXEL_FORMAT_LIST.
TY_ENUM_IMAGE_MODE Pixel format, see TY_IMAGE_MODE_LIST.
TY_BOOL_TRIGGER_MODE Trigger mode switch.
TY_ENUM_TRIGGER_ACTIVATION Trigger activation, see TY_TRIGGER_ACTIVATION_LIST.
TY_INT_FRAME_PER_TRIGGER Number of frames captured per trigger.
TY_BOOL_AUTO_EXPOSURE Auto exposure switch.
TY_INT_EXPOSURE_TIME Exposure time in percentage.
TY_BOOL_AUTO_GAIN Auto gain switch.
TY_INT_GAIN Gain.
TY_BOOL_AUTO_AWB Auto white balance.
TY_INT_LASER_POWER Laser power level.
TY_BOOL_LASER_AUTO_CTRL Laser auto ctrl.
TY_BOOL_UNDISTORTION Output undistorted image.
TY_BOOL_BRIGHTNESS_HISTOGRAM Output bright histogram.
TY_INT_R_GAIN Gain of R channel.
TY_INT_G_GAIN Gain of G channel.
TY_INT_B_GAIN Gain of B channel.
TY_STRUCT_WORK_MODE mode of trigger

Definition at line 188 of file TY_API.h.

4.1.2.3 enum TY_IMAGE_MODE_LIST

Enumerator

TY_IMAGE_MODE_320x240 1310960
TY_IMAGE_MODE_640x480 2621920
TY_IMAGE_MODE_1280x960 5243840
TY_IMAGE_MODE_2592x1944 10618776

Definition at line 232 of file TY_API.h.

4.1.3 Function Documentation

4.1.3.1 TY_CAPI TYClearBufferQueue (TY_DEV_HANDLE *hDevice*)

Clear the internal buffer queue, so that user can release all the buffer.

Parameters

in	<i>hDevice</i>	Device handle.
----	----------------	----------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_BUSY</i>	Device is capturing.

4.1.3.2 TY_CAPI TYCloseDevice (TY_DEV_HANDLE *hDevice*)

Close device by device handle.

Parameters

in	<i>hDevice</i>	Device handle.
----	----------------	----------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_IDLE</i>	Device has been closed.

4.1.3.3 TY_CAPI TYDeinitLib (void)

Deinit this library.

<i>TY_STATUS_OK</i>	Succeed.
---------------------	----------

Convert points on depth image to world coordinate. format of depth data should be: +---+---+---+---+---
+---+--- | p0.x | p0.y | p0.z | p1.x | p1.y | p1.z | ... +---+---+---+---+---+---+--- and world coordinate
should be: +---+---+---+---+---+---+---+---+---+--- | p0.x | p0.y | p0.z | padding bytes |
p1.x | p1.y | p1.z | padding bytes | ... +---+---+---+---+---+---+---+---+---+---.

- ## Parameters

in	<i>hDevice</i>	Device handle.
in	<i>depth</i>	Depth values.
out	<i>world</i>	World coordinate.
in	<i>worldPaddingBytes</i>	Number of world padding bytes.
in	<i>pointCount</i>	Number of points to be calculated.

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	pDepth or pWorld is NULL.
<i>TY_STATUS_INVALID_PARAMETER</i>	worldPaddingBytes is not 4x.

Disable components.

in	<i>hDevice</i>	Device handle.
in	<i>componentIDs</i>	Components to be disabled.

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Some components specified by componentIDs are invalid.
<i>TY_STATUS_BUSY</i>	Device is capturing.

4.1.3.6 TY_CAPI TYEnableComponents (TY_DEV_HANDLE *hDevice*, int32_t *componentIDs*)

Enable components.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentIDs</i>	Components to be enabled.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Some components specified by componentIDs are invalid.
<i>TY_STATUS_BUSY</i>	Device is capturing.

4.1.3.7 TY_CAPI TYEnqueueBuffer (TY_DEV_HANDLE *hDevice*, void * *buffer*, int32_t *bufferSize*)

Enqueue a user allocated buffer.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>buffer</i>	Buffer to be enqueued.
in	<i>bufferSize</i>	Size of the input buffer.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	buffer is NULL.
<i>TY_STATUS_WRONG_SIZE</i>	The input buffer is not large enough.

4.1.3.8 TY_CAPI TYEnterDeveloperMode (TY_DEV_HANDLE *hDevice*)

Enable developer mode by device handle.

Parameters

in	<i>hDevice</i>	Device handle.
----	----------------	----------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_DEVICE_ERROR</i>	Enter developer mode failed.

4.1.3.9 TY_EXTC TY_EXPORT const char *TY_STDC TYErrorString (TY_STATUS *errorID*)

Get error information.

Parameters

in	<i>errorID</i>	Error id.
----	----------------	-----------

Returns

Error string.

4.1.3.10 TY_CAPI TYFetchFrame (TY_DEV_HANDLE *hDevice*, TY_FRAME_DATA * *frame*, int32_t *timeout*)

Fetch one frame.

Parameters

in	<i>hDevice</i>	Device handle.
out	<i>frame</i>	Frame data to be filled.
in	<i>timeout</i>	Timeout in milliseconds. <0 for infinite.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	frame is NULL.
<i>TY_STATUS_IDLE</i>	Device capturing is not started.
<i>TY_STATUS_WRONG_MODE</i>	Callback has been registered, this function is disabled.
<i>TY_STATUS_TIMEOUT</i>	Timeout.

4.1.3.11 TY_CAPI TYGetBool (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, bool * *value*)

Get value of bool feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>value</i>	Bool value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.

Return values

<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not <i>TY_FEATURE_BOOL</i> .
<i>TY_STATUS_NULL_POINTER</i>	value is NULL.

4.1.3.12 *TY_CAPI* TYGetComponentIDs (*TY_DEV_HANDLE hDevice*, *int32_t * componentIDs*)

Get all components IDs.

Parameters

in	<i>hDevice</i>	Device handle.
out	<i>componentIDs</i>	All component IDs this device has.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	componentIDs is NULL.

4.1.3.13 *TY_CAPI* TYGetDeviceInfo (*TY_DEV_HANDLE hDevice*, *TY_DEVICE_BASE_INFO * info*)

Get base info of the open device.

Parameters

in	<i>hDevice</i>	Device handle.
out	<i>info</i>	Base info out.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	componentIDs is NULL.

4.1.3.14 *TY_CAPI* TYGetDeviceList (*TY_DEVICE_BASE_INFO * deviceInfos*, *int32_t bufferCount*, *int32_t * filledDeviceCount*)

Get device info list.

Parameters

out	<i>deviceInfos</i>	Device info array to be filled.
in	<i>bufferCount</i>	Array size of deviceInfos.
out	<i>filledDeviceCount</i>	Number of filled TY_DEVICE_BASE_INFO .

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_NOT_INITED</i>	TYInitLib not called.
<i>TY_STATUS_NULL_POINTER</i>	deviceInfos or filledDeviceCount is NULL.

4.1.3.15 TY_CAPI TYGetDeviceNumber (int32_t * *deviceNumber*)

Get number of current connected devices.

Parameters

out	<i>deviceNumber</i>	Number of connected devices.
-----	---------------------	------------------------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_NOT_INITED</i>	TYInitLib not called.
<i>TY_STATUS_NULL_POINTER</i>	deviceNumber is NULL.

4.1.3.16 TY_CAPI TYGetEnabledComponentIDs (TY_DEV_HANDLE *hDevice*, int32_t * *componentIDs*)

Get all enabled components IDs.

Parameters

in	<i>hDevice</i>	Device handle.
out	<i>componentIDs</i>	Enabled component IDs.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	componentIDs is NULL.

4.1.3.17 TY_CAPI TYGetEnum (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, int32_t * *value*)

Get current value of enum feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>value</i>	Enum value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not <i>TY_FEATURE_ENUM</i> .
<i>TY_STATUS_NULL_POINTER</i>	value is NULL.

4.1.3.18 TY_CAPI TYGetEnumEntryCount (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, int32_t * *entryCount*)

Get number of enum entries.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>entryCount</i>	Entry count.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not <i>TY_FEATURE_ENUM</i> .
<i>TY_STATUS_NULL_POINTER</i>	<i>entryCount</i> is NULL.

4.1.3.19 TY_CAPI TYGetEnumEntryInfo (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, TY_ENUM_ENTRY * *entries*, int32_t *entryCount*, int32_t * *filledEntryCount*)

Get list of enum entries.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>entries</i>	Output entries.
in	<i>entryCount</i>	Array size of input parameter "entries".
out	<i>filledEntryCount</i>	Number of filled entries.

Return values

<i>TY_STATUS_OK</i>	Succeed.
---------------------	----------

Return values

<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not <i>TY_FEATURE_ENUM</i> .
<i>TY_STATUS_NULL_POINTER</i>	entries or filledEntryCount is NULL.

4.1.3.20 **TY_CAPI** TYGetFeatureInfo (*TY_DEV_HANDLE* *hDevice*, *TY_COMPONENT_ID* *componentID*, *TY_FEATURE_ID* *featureID*, *TY_FEATURE_INFO* * *featureInfo*)

Get feature info.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>featureInfo</i>	Feature info.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_NULL_POINTER</i>	featureInfo is NULL.

4.1.3.21 **TY_CAPI** TYGetFloat (*TY_DEV_HANDLE* *hDevice*, *TY_COMPONENT_ID* *componentID*, *TY_FEATURE_ID* *featureID*, float * *value*)

Get value of float feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>value</i>	Float value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not <i>TY_FEATURE_FLOAT</i> .
<i>TY_STATUS_NULL_POINTER</i>	value is NULL.

4.1.3.22 TY_CAPI TYGetFloatRange (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, TY_FLOAT_RANGE * *floatRange*)

Get value range of float feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>floatRange</i>	Float range to be filled.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_FLOAT.
<i>TY_STATUS_NULL_POINTER</i>	<i>floatRange</i> is NULL.

4.1.3.23 TY_CAPI TYGetFrameBufferSize (TY_DEV_HANDLE *hDevice*, int32_t * *bufferSize*)

Get total buffer size of one frame in current configuration.

Parameters

in	<i>hDevice</i>	Device handle.
out	<i>bufferSize</i>	Buffer size per frame.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	<i>bufferSize</i> is NULL.

4.1.3.24 TY_CAPI TYGetInt (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, int32_t * *value*)

Get value of integer feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>value</i>	Integer value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_INT.
<i>TY_STATUS_NULL_POINTER</i>	value is NULL.

4.1.3.25 TY_CAPI TYGetIntRange (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, TY_INT_RANGE * *intRange*)

Get value range of integer feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>intRange</i>	Integer range to be filled.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_INT.
<i>TY_STATUS_NULL_POINTER</i>	intRange is NULL.

4.1.3.26 TY_CAPI TYGetString (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, char * *buffer*, int32_t *bufferSize*)

Get value of string feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>buffer</i>	String buffer.
in	<i>bufferSize</i>	Size of buffer.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.

Return values

<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_STRING.
<i>TY_STATUS_NULL_POINTER</i>	buffer is NULL.

4.1.3.27 **TY_CAPI** TYGetStringBufferSize (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, int32_t * *size*)

Get internal buffer size of string feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>size</i>	String buffer size.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_STRING.
<i>TY_STATUS_NULL_POINTER</i>	size is NULL.

4.1.3.28 **TY_CAPI** TYGetStruct (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, void * *pStruct*, int32_t *structSize*)

Get value of struct.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
out	<i>pStruct</i>	Pointer of struct.
in	<i>structSize</i>	Size of input buffer pStruct..

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.

Return values

<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_STRUCT.
<i>TY_STATUS_NULL_POINTER</i>	pStruct is NULL.
<i>TY_STATUS_WRONG_SIZE</i>	structSize incorrect.

4.1.3.29 TY_CAPI TYIsCapturing (TY_DEV_HANDLE *hDevice*, bool * *isCapturing*)

Get if the device is capturing.

Parameters

in	<i>hDevice</i>	Device handle.
out	<i>isCapturing</i>	Return capturing status.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	isCapturing is NULL.

4.1.3.30 TY_CAPI TYLibVersion (TY_VERSION_INFO * *version*)

Get current library version.

Parameters

out	<i>version</i>	Version information to be filled.
-----	----------------	-----------------------------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_NULL_POINTER</i>	buffer is NULL.

4.1.3.31 TY_CAPI TYOpenDevice (const char * *deviceId*, TY_DEV_HANDLE * *deviceHandle*)

Open device by device ID.

Parameters

in	<i>deviceId</i>	Device ID string, can be get from TY_DEVICE_BASE_INFO .
out	<i>deviceHandle</i>	Handle of opened device.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_NOT_INITED</i>	TYInitLib not called.
<i>TY_STATUS_NULL_POINTER</i>	deviceId or deviceHandle is NULL.
<i>TY_STATUS_INVALID_PARAMETER</i>	Device not found.
<i>TY_STATUS_BUSY</i>	Device has been opened.
<i>TY_STATUS_DEVICE_ERROR</i>	Open device failed.

4.1.3.32 TY_CAPI TYOpenDeviceWithIP (const char * *IP*, TY_DEV_HANDLE * *deviceHandle*)

Open device by device IP, useful when device not listed.

Parameters

in	<i>IP</i>	Device IP.
out	<i>deviceHandle</i>	Handle of opened device.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_NOT_INITED</i>	TYInitLib not called.
<i>TY_STATUS_NULL_POINTER</i>	IP or deviceHandle is NULL.
<i>TY_STATUS_INVALID_PARAMETER</i>	Device not found.
<i>TY_STATUS_BUSY</i>	Device has been opened, may occupied somewhere else.
<i>TY_STATUS_DEVICE_ERROR</i>	Open device failed.

4.1.3.33 TY_CAPI TYRegisterCallback (TY_DEV_HANDLE *hDevice*, TY_FRAME_CALLBACK *callback*, void * *userdata*)

Register callback of frame. Register NULL to clean callback.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>callback</i>	Callback function.
in	<i>userdata</i>	User private data.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_BUSY</i>	Device is capturing.

4.1.3.34 TY_CAPI TYRegisterEventCallback (TY_DEV_HANDLE *hDevice*, TY_EVENT_CALLBACK *callback*, void * *userdata*)

Register device status callback. Register NULL to clean callback.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>callback</i>	Callback function.
in	<i>userdata</i>	User private data.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_BUSY</i>	Device is capturing.

4.1.3.35 TY_CAPI TYSendSoftTrigger (TY_DEV_HANDLE *hDevice*)

Send a software trigger when device works in trigger mode.

Parameters

in	<i>hDevice</i>	Device handle.
----	----------------	----------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_FEATURE</i>	Not support soft trigger.
<i>TY_STATUS_IDLE</i>	Device has not started capture.
<i>TY_STATUS_WRONG_MODE</i>	Not in trigger mode.

4.1.3.36 TY_CAPI TYSetBool (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, bool *value*)

Set value of bool feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
in	<i>value</i>	Bool value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
---------------------	----------

Return values

<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_NOT_PERMITTED</i>	The feature is not writable.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_BOOL.
<i>TY_STATUS_BUSY</i>	Device is capturing, the feature is locked.

4.1.3.37 TY_CAPI TYSetEnum (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, int32_t *value*)

Set value of enum feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
in	<i>value</i>	Enum value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_NOT_PERMITTED</i>	The feature is not writable.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_ENUM.
<i>TY_STATUS_INVALID_PARAMETER</i>	value is invalid.
<i>TY_STATUS_BUSY</i>	Device is capturing, the feature is locked.

4.1.3.38 TY_CAPI TYSetFloat (TY_DEV_HANDLE *hDevice*, TY_COMPONENT_ID *componentID*, TY_FEATURE_ID *featureID*, float *value*)

Set value of float feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
in	<i>value</i>	Float value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
---------------------	----------

Return values

<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_NOT_PERMITTED</i>	The feature is not writable.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_FLOAT.
<i>TY_STATUS_OUT_OF_RANGE</i>	value is out of range.
<i>TY_STATUS_BUSY</i>	Device is capturing, the feature is locked.

4.1.3.39 **TY_CAPI TYSetInt** (*TY_DEV_HANDLE* *hDevice*, *TY_COMPONENT_ID* *componentID*, *TY_FEATURE_ID* *featureID*, *int32_t* *value*)

Set value of integer feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
in	<i>value</i>	Integer value.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_NOT_PERMITTED</i>	The feature is not writable.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not TY_FEATURE_INT.
<i>TY_STATUS_OUT_OF_RANGE</i>	value is out of range.
<i>TY_STATUS_BUSY</i>	Device is capturing, the feature is locked.

4.1.3.40 **TY_CAPI TYSetString** (*TY_DEV_HANDLE* *hDevice*, *TY_COMPONENT_ID* *componentID*, *TY_FEATURE_ID* *featureID*, *const char ** *buffer*)

Set value of string feature.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
in	<i>buffer</i>	String buffer.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_NOT_PERMITTED</i>	The feature is not writable.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not <i>TY_FEATURE_STRING</i> .
<i>TY_STATUS_NULL_POINTER</i>	buffer is NULL.
<i>TY_STATUS_OUT_OF_RANGE</i>	Input string is too long.
<i>TY_STATUS_BUSY</i>	Device is capturing, the feature is locked.

4.1.3.41 *TY_CAPI* *TYSetStruct* (*TY_DEV_HANDLE* *hDevice*, *TY_COMPONENT_ID* *componentID*, *TY_FEATURE_ID* *featureID*, *void ** *pStruct*, *int32_t* *structSize*)

Set value of struct.

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>componentID</i>	Component ID.
in	<i>featureID</i>	Feature ID.
in	<i>pStruct</i>	Pointer of struct.
in	<i>structSize</i>	Size of struct.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	Invalid component ID.
<i>TY_STATUS_INVALID_FEATURE</i>	Invalid feature ID.
<i>TY_STATUS_NOT_PERMITTED</i>	The feature is not writable.
<i>TY_STATUS_WRONG_TYPE</i>	The feature's type is not <i>TY_FEATURE_STRUCT</i> .
<i>TY_STATUS_NULL_POINTER</i>	<i>pStruct</i> is NULL.
<i>TY_STATUS_WRONG_SIZE</i>	<i>structSize</i> incorrect.
<i>TY_STATUS_BUSY</i>	Device is capturing, the feature is locked.

4.1.3.42 *TY_CAPI* *TYStartCapture* (*TY_DEV_HANDLE* *hDevice*)

Start capture.

Parameters

in	<i>hDevice</i>	Device handle.
----	----------------	----------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_INVALID_COMPONENT</i>	No components enabled.
<i>TY_STATUS_BUSY</i>	Device has been started.
<i>TY_STATUS_DEVICE_ERROR</i>	Start capture failed.

4.1.3.43 TY_CAPI TYStopCapture (TY_DEV_HANDLE *hDevice*)

Stop capture.

Parameters

in	<i>hDevice</i>	Device handle.
----	----------------	----------------

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_IDLE</i>	Device is not capturing.
<i>TY_STATUS_DEVICE_ERROR</i>	Stop capture failed.

4.1.3.44 TY_CAPI TYUndistortImage (const TY_CAMERA_INTRINSIC * *cameraIntrinsic*, const TY_CAMERA_DISTORTION * *cameraDistortion*, const TY_CAMERA_INTRINSIC * *cameraNewIntrinsic*, const TY_IMAGE_DATA * *srcImage*, TY_IMAGE_DATA * *dstImage*)

Correct image for lens distortion Format of source image data should be TY_PIXEL_FORMAT_MONO or TY_PIXEL_FORMAT_RGB Output buffer is allocated by caller. For IR image undistortion, enable TY_BOOL_UNDISTORTION to get better performance.

Parameters

in	<i>cameraIntrinsic</i>	input image camera intrinsic parameters
in	<i>cameraDistortion</i>	input image camera distortion parameters
in	<i>cameraNewIntrinsic</i>	output image camera intrinsic , <i>cameraIntrinsic</i> will be used if is NULL
in	<i>srcImage</i>	input image buffer
out	<i>dstImage</i>	Output image buffer

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_NULL_POINTER</i>	buffer is NULL.
<i>TY_STATUS_INVALID_PARAMETER</i>	parameter is invalid.
<i>TY_STATUS_ERROR</i>	internal error

4.1.3.45 **TY_CAPI** TYWorldToDepth (TY_DEV_HANDLE *hDevice*, const TY_VECT_3F * *world*, TY_VECT_3F * *depth*, int32_t *worldPaddingBytes*, int32_t *pointCount*)

Convert world coordinate to depth coordinate. format of depth data should be: +-----+-----+-----+-----+-----+-----+-----
+--- | p0.x | p0.y | p0.z | p1.x | p1.y | p1.z | ... +-----+-----+-----+-----+-----+-----+----- and world coordinate should
be: +-----+-----+-----+-----+-----+-----+----- | p0.x | p0.y | p0.z | padding bytes | p1.x |
p1.y | p1.z | padding bytes | ... +-----+-----+-----+-----+-----+-----+-----.

- padding bytes could be 0
- for PCL, world coordinate padding size should be calculated based on the point type

Parameters

in	<i>hDevice</i>	Device handle.
in	<i>world</i>	World coordinate.
out	<i>depth</i>	Depth values.
in	<i>worldPaddingBytes</i>	Number of depth padding bytes.
in	<i>pointCount</i>	Number of points to be calculated.

Return values

<i>TY_STATUS_OK</i>	Succeed.
<i>TY_STATUS_INVALID_HANDLE</i>	Invalid device handle.
<i>TY_STATUS_NULL_POINTER</i>	pDepth or pWorld is NULL.
<i>TY_STATUS_INVALID_PARAMETER</i>	worldPaddingBytes is not 4x.

Index

TY_API.h, 13

- TY_BOOL_AUTO_AWB, 19
- TY_BOOL_AUTO_EXPOSURE, 19
- TY_BOOL_AUTO_GAIN, 19
- TY_BOOL_BRIGHTNESS_HISTOGRAM, 19
- TY_BOOL_LASER_AUTO_CTRL, 19
- TY_BOOL_TRIGGER_MODE, 19
- TY_BOOL_UNDISTORTION, 19
- TY_COMPONENT_BRIGHT_HISTO, 19
- TY_COMPONENT_DEPTH_CAM, 19
- TY_COMPONENT_DEVICE, 19
- TY_COMPONENT_IMU, 19
- TY_COMPONENT_IR_CAM_LEFT, 19
- TY_COMPONENT_IR_CAM_RIGHT, 19
- TY_COMPONENT_LASER, 19
- TY_COMPONENT_POINT3D_CAM, 19
- TY_COMPONENT_RGB_CAM_LEFT, 19
- TY_COMPONENT_RGB_CAM_RIGHT, 19
- TY_DEVICE_COMPONENT_LIST, 19
- TY_ENUM_IMAGE_MODE, 19
- TY_ENUM_PIXEL_FORMAT, 19
- TY_ENUM_TRIGGER_ACTIVATION, 19
- TY_FEATURE_ID_LIST, 19
- TY_IMAGE_MODE_1280x960, 20
- TY_IMAGE_MODE_2592x1944, 20
- TY_IMAGE_MODE_320x240, 20
- TY_IMAGE_MODE_640x480, 20
- TY_IMAGE_MODE_LIST, 19
- TY_INT_B_GAIN, 19
- TY_INT_EXPOSURE_TIME, 19
- TY_INT_FRAME_PER_TRIGGER, 19
- TY_INT_G_GAIN, 19
- TY_INT_GAIN, 19
- TY_INT_LASER_POWER, 19
- TY_INT_R_GAIN, 19
- TY_STRUCT_CAM_DISTORTION, 19
- TY_STRUCT_CAM_INTRINSIC, 19
- TY_STRUCT_EXTRINSIC_TO_LEFT_IR, 19
- TY_STRUCT_EXTRINSIC_TO_LEFT_RGB, 19
- TY_STRUCT_NET_INFO, 19
- TY_STRUCT_WORK_MODE, 19
- TYClearBufferQueue, 20
- TYCloseDevice, 20
- TYDeinitLib, 20
- TYDepthToWorld, 21
- TYDisableComponents, 21
- TYEnableComponents, 22
- TYEnqueueBuffer, 22
- TYEnterDeveloperMode, 22

TYErrorString, 23

- TYFetchFrame, 23
- TYGetBool, 23
- TYGetComponentIDs, 24
- TYGetDeviceInfo, 24
- TYGetDeviceList, 24
- TYGetDeviceNumber, 25
- TYGetEnabledComponentIDs, 25
- TYGetEnum, 25
- TYGetEnumEntryCount, 26
- TYGetEnumEntryInfo, 26
- TYGetFeatureInfo, 27
- TYGetFloat, 27
- TYGetFloatRange, 28
- TYGetFrameBufferSize, 28
- TYGetInt, 28
- TYGetIntRange, 29
- TYGetString, 29
- TYGetStringBufferSize, 30
- TYGetStruct, 30
- TYIsCapturing, 31
- TYLibVersion, 31
- TYOpenDevice, 31
- TYOpenDeviceWithIP, 32
- TYRegisterCallback, 32
- TYRegisterEventCallback, 32
- TYSendSoftTrigger, 33
- TYSetBool, 33
- TYSetEnum, 34
- TYSetFloat, 34
- TYSetInt, 35
- TYSetString, 35
- TYSetStruct, 36
- TYStartCapture, 36
- TYStopCapture, 37
- TYUndistortImage, 37
- TYWorldToDepth, 37
- TY_BOOL_AUTO_AWB
 - TY_API.h, 19
- TY_BOOL_AUTO_EXPOSURE
 - TY_API.h, 19
- TY_BOOL_AUTO_GAIN
 - TY_API.h, 19
- TY_BOOL_BRIGHTNESS_HISTOGRAM
 - TY_API.h, 19
- TY_BOOL_LASER_AUTO_CTRL
 - TY_API.h, 19
- TY_BOOL_TRIGGER_MODE
 - TY_API.h, 19

TY_BOOL_UNDISTORTION
 TY_API.h, 19
 TY_CAMERA_DISTORTION, 5
 TY_CAMERA_EXTRINSIC, 5
 TY_CAMERA_INTRINSIC, 6
 TY_COMPONENT_BRIGHT_HISTO
 TY_API.h, 19
 TY_COMPONENT_DEPTH_CAM
 TY_API.h, 19
 TY_COMPONENT_DEVICE
 TY_API.h, 19
 TY_COMPONENT_IMU
 TY_API.h, 19
 TY_COMPONENT_IR_CAM_LEFT
 TY_API.h, 19
 TY_COMPONENT_IR_CAM_RIGHT
 TY_API.h, 19
 TY_COMPONENT_LASER
 TY_API.h, 19
 TY_COMPONENT_POINT3D_CAM
 TY_API.h, 19
 TY_COMPONENT_RGB_CAM_LEFT
 TY_API.h, 19
 TY_COMPONENT_RGB_CAM_RIGHT
 TY_API.h, 19
 TY_DEVICE_BASE_INFO, 6
 TY_DEVICE_COMPONENT_LIST
 TY_API.h, 19
 TY_DEVICE_NET_INFO, 7
 TY_ENUM_ENTRY, 7
 TY_ENUM_IMAGE_MODE
 TY_API.h, 19
 TY_ENUM_PIXEL_FORMAT
 TY_API.h, 19
 TY_ENUM_TRIGGER_ACTIVATION
 TY_API.h, 19
 TY_EVENT_INFO, 8
 TY_FEATURE_ID_LIST
 TY_API.h, 19
 TY_FEATURE_INFO, 8
 TY_FLOAT_RANGE, 9
 TY_FRAME_DATA, 9
 TY_IMAGE_DATA, 10
 TY_IMAGE_MODE_1280x960
 TY_API.h, 20
 TY_IMAGE_MODE_2592x1944
 TY_API.h, 20
 TY_IMAGE_MODE_320x240
 TY_API.h, 20
 TY_IMAGE_MODE_640x480
 TY_API.h, 20
 TY_IMAGE_MODE_LIST
 TY_API.h, 19
 TY_INT_B_GAIN
 TY_API.h, 19
 TY_INT_EXPOSURE_TIME
 TY_API.h, 19
 TY_INT_FRAME_PER_TRIGGER
 TY_API.h, 19
 TY_INT_G_GAIN
 TY_API.h, 19
 TY_INT_GAIN
 TY_API.h, 19
 TY_INT_LASER_POWER
 TY_API.h, 19
 TY_INT_R_GAIN
 TY_API.h, 19
 TY_INT_RANGE, 10
 TY_STRUCT_CAM_DISTORTION
 TY_API.h, 19
 TY_STRUCT_CAM_INTRINSIC
 TY_API.h, 19
 TY_STRUCT_EXTRINSIC_TO_LEFT_IR
 TY_API.h, 19
 TY_STRUCT_EXTRINSIC_TO_LEFT_RGB
 TY_API.h, 19
 TY_STRUCT_NET_INFO
 TY_API.h, 19
 TY_STRUCT_WORK_MODE
 TY_API.h, 19
 TY_TRIGGER_MODE, 11
 TY_VECT_3F, 11
 TY_VERSION_INFO, 11
 TYClearBufferQueue
 TY_API.h, 20
 TYCloseDevice
 TY_API.h, 20
 TYDeinitLib
 TY_API.h, 20
 TYDepthToWorld
 TY_API.h, 21
 TYDisableComponents
 TY_API.h, 21
 TYEnableComponents
 TY_API.h, 22
 TYEnqueueBuffer
 TY_API.h, 22
 TYEnterDeveloperMode
 TY_API.h, 22
 TYErrorString
 TY_API.h, 23
 TYFetchFrame
 TY_API.h, 23
 TYGetBool
 TY_API.h, 23
 TYGetComponentIDs
 TY_API.h, 24
 TYGetDeviceInfo
 TY_API.h, 24
 TYGetDeviceList
 TY_API.h, 24
 TYGetDeviceNumber
 TY_API.h, 25
 TYGetEnabledComponentIDs
 TY_API.h, 25
 TYGetEnum

TY_API.h, [25](#)
TYGetEnumEntryCount
TY_API.h, [26](#)
TYGetEnumEntryInfo
TY_API.h, [26](#)
TYGetFeatureInfo
TY_API.h, [27](#)
TYGetFloat
TY_API.h, [27](#)
TYGetFloatRange
TY_API.h, [28](#)
TYGetFrameBufferSize
TY_API.h, [28](#)
TYGetInt
TY_API.h, [28](#)
TYGetIntRange
TY_API.h, [29](#)
TYGetString
TY_API.h, [29](#)
TYGetStringBufferSize
TY_API.h, [30](#)
TYGetStruct
TY_API.h, [30](#)
TYIsCapturing
TY_API.h, [31](#)
TYLibVersion
TY_API.h, [31](#)
TYOpenDevice
TY_API.h, [31](#)
TYOpenDeviceWithIP
TY_API.h, [32](#)
TYRegisterCallback
TY_API.h, [32](#)
TYRegisterEventCallback
TY_API.h, [32](#)
TYSendSoftTrigger
TY_API.h, [33](#)
TYSetBool
TY_API.h, [33](#)
TYSetEnum
TY_API.h, [34](#)
TYSetFloat
TY_API.h, [34](#)
TYSetInt
TY_API.h, [35](#)
TYSetString
TY_API.h, [35](#)
TYSetStruct
TY_API.h, [36](#)
TYStartCapture
TY_API.h, [36](#)
TYStopCapture
TY_API.h, [37](#)
TYUndistortImage
TY_API.h, [37](#)
TYWorldToDepth
TY_API.h, [37](#)