



## QUICK START GUIDE: HELIUM & COPPER SPEAKER SYSTEMS

FULL MANUAL AVAILABLE AT:  
[WWW.BLUESHIFTPDX.COM/MANUAL](http://WWW.BLUESHIFTPDX.COM/MANUAL)

MORE DOCUMENTATION AT:  
[WWW.BLUESHIFTPDX.COM/OPEN-SOURCE](http://WWW.BLUESHIFTPDX.COM/OPEN-SOURCE)

(571) FLUX-CAP

**Thanks for purchasing a Blueshift speaker system!**

Your speaker is ready to use. All you need to do is plug it in (Copper) or plug it in and wait for it to charge up (Helium).

---

**IMPORTANT: When fully discharged (initial use or following a long period without charging) your Helium speaker will take two to three minutes of charging to do anything.**

It will just sit there with no lights on. This is normal, after about two minutes the charge indicator lights will start to illuminate, beginning with the lowest light.

---

### WARNING!

Electronics can be dangerous. Inside your speaker box, there are exposed conductors charged at up to 30V DC. Additionally, the Helium speakers contain supercapacitors charged at up to 24V, which are capable of discharging completely in a few seconds. This could cause a severe burn or shock, other injury, and/or death. It could also start a fire.

The acoustical port in every cabinet allows direct access to the electronics. **DO NOT ALLOW CHILDREN TO PLAY WITH BLUESHIFT SPEAKER SYSTEMS! DO NOT INSERT ANY BODY PART OR OTHER OBJECT INSIDE THE SPEAKER!** Do not allow water or other liquids to contact the device or charging cable, and do not use this device around flammable materials that could be ignited by an electrical spark. MAINTENANCE SHOULD ONLY BE PERFORMED BY A QUALIFIED TECHNICIAN! Blueshift, LLC is not responsible for any modifications or repairs to your speaker systems, the consequences of any such modifications or repairs, or any injury or damage resulting from accessing the inside of the cabinet in any way, be it through the acoustical port, the speaker mounting hole(s), or the control panel.

Your use of this product constitutes your acknowledgment of and compliance with these terms.