
Saba

Release 1.0

milad

Jul 27, 2022

Contents

1	Electrical	3
1.1	Plc	3
1.2	Panels	5
2	Mechanics	7
3	Softwares	9
3.1	Main Software	9
3.2	Train Software	9
3.3	Setting Software	9
67	Others	4
69	tables and Indices	5
71	Index Module Python	
73	Index	



Contetns:

All electronic equipment is in this section

Contents:

1.1 Plc

1.1.1 About PLC

Category	
Model	Siemens S7 1200c DC/DC/DC
Installation Location	Main Frame
Type of communication	Rj 45 Cooper Cable
Power	DC12v

1.1.2 connections

Name	Count	Description
temperature sensor	2	Taking the temperature of the structure
Limit Switch	4	The integrity of the structure
Projectors	12 block	Enlighten the environment
Cameras	24	Imaging the sheet

1.1.3 Instruction of PLC

کارکرد پی ال سی : به این صورت میباشد که در ابتدا سنسور تشخیص ورق که متصل میباشد فرمان ورود ورق را صادر میکند پس از آن با فاصله زمانی اندکی سیستم نور پردازی (پرژکتورها) و تریگ زدن به دوربین ها آغاز میشود . وظیفه دیگر پی ال سی مدیریت کردن دمای محفظه های بالا و پایین میباشد برای این امر دو سنسور دما تعبیه شده که در لحظه چک میشوند و در صورت نیاز فرمان روشن شدن کولر های هر بخش صادر میشود , در صورتی که دما بیش از حد باشد فرمان خاموش شدن دوربین ها صادر میشود .

1.1.4 Dynamic System Connection

سیستم حرکتی : برای اطمینان از صحت قرار گیری سازه در محل خود دو عدد لیمیت سویچ در انتهای بخش های بالا و پایین و دو عدد در ابتدای بخش های بالا و پایین قرار داده شده است که توسط پی ال سی مقادیر آنها خوانده میشود و در زمان هایی که سیستم به درستی در جای خود قرار ندارد و یا در حال حرکت میباشد به علت جلوگیری از بروز حادثه سیستم به صورت کامل خاموش میشود

1.1.5 Lighting system

سیستم روشنایی : به این صورت میباشد که در ابتدا ۶ بلوک ابتدایی روشن میشوند و پس از آن سیستم پردازی با توجه به عرض ورق که از سیستم های خط تولید دریافت کرده در صورت نیاز فرمان روشن شدن پرژکتور های دیگر را صادر میکند برای این کار یک عدد بین ۰ تا ۳ در خانه حافظه مربوطه نوشته میشود , سیستم روشنایی همواره با فرکانس ۶۶ هرتز مشغول به کار میباشد .. note:: به علت وجود عرض سنج پرژکتور های بالا و پایین مقداری تاخیر نسبت به هم دارند و به این علت میباشد که نور پرژکتور ها تصاویر دوربین های کناری را در هنگام اندازه گیری عرض دچار اختلال میکند

1.1.6 Imaging system

سیستم تصویر برداری : نیز به این صورت میباشد که سیستم پردازی تعداد دوربین های مورد نیاز برای تصویر برداری را در خانه حافظه مربوط به پی ال سی نوشته (یک عدد بین ۰ تا ۶) و پی ال سی با توجه به این عدد دوربین های بالا و پایین را تریگ میزند و تصاویر توسط سیستم پردازی دریافت میشود

Temperature control System

کنترل دما : برای این امر در ابتدا توسط سیستم پردازی حد آستانه بالا و پایین و مدت زمان روشن ماندن کولر تنظیم میشود . عملکرد به این صورت میباشد که دما در لحظه در حال چک شدن توسط پی ال سی میباشد در صورتی که دما از آستانه بالا بیشتر شود سیستم خنک کاری مشغول روشن میشود و تا رسیدن به نقطه حداقل روشن میماند حال به این علت که ممکن است در این مدت فشار زیادی به کولر ها وارد شود در صورتی که مدت زمان روشن ماندن کولر بیشتر از زمان تنظیم شده شود سیستم خنک کاری قطع میشود

1.2 Panels

Contetns:

3.1 Main Software

3.2 Train Software

3.3 Setting Software

3.3.1 Description

کارکرد پی ال سی : به این صورت میباشد که در ابتدا سنسور تشخیص ورق که متصل میباشد فرمان ورود ورق را صادر میکند پس از آن با فاصله زمانی اندکی سیستم نور پردازی (پرژکتورها) و تریگ زدن به دوربین ها آغاز میشود . وظیفه دیگر پی ال سی مدیریت کردن دمای محفظه های بالا و پایین میباشد برای این امر دو سنسور دما تعبیه شده که در لحظه چک میشوند و در صورت نیاز فرمان روشن شدن کولر های هر بخش صادر میشود , در صورتی که دما بیش از حد باشد فرمان خاموش شدن دوربین ها صادر میشود .

3.3.2 Directories

App Logs

Description

کارکرد پی ال سی : به این صورت میباشد که در ابتدا سنسور تشخیص ورق که متصل میباشد فرمان ورود ورق را صادر میکند پس از آن با فاصله زمانی اندکی سیستم نور پردازی (پرژکتورها) و تریگ زدن به دوربین ها آغاز میشود . وظیفه دیگر پی ال سی مدیریت کردن دمای محفظه های بالا و پایین میباشد برای این امر دو سنسور دما تعبیه شده که در لحظه چک میشوند و در صورت نیاز فرمان روشن شدن کولر های هر بخش صادر میشود , در صورتی که دما بیش از حد باشد فرمان خاموش شدن دوربین ها صادر میشود .

Backend

Description

کارکرد پی ال سی : به این صورت میباشد که در ابتدا سنسور تشخیص ورق که متصل میباشد فرمان ورود ورق را صادر میکند پس از آن با فاصله زمانی اندکی سیستم نور پردازی (پرژکتورها) و تریگ زدن به دوربین ها آغاز میشود . وظیفه دیگر پی ال سی مدیریت کردن دمای محفظه های بالا و پایین میباشد برای این امر دو سنسور دما تعبیه شده که در لحظه چک میشوند و در صورت نیاز فرمان روشن شدن کولر های هر بخش صادر میشود , در صورتی که دما بیش از حد باشد فرمان خاموش شدن دوربین ها صادر میشود .

Contetns:

add_default_database_records module

`oxin.backend.add_default_database_records.create_default_records(ui_obj, api_obj)`
this function is used to create default records in database, if not exist

Parameters

- **ui_obj** - (_type_) main ui object
- **api_obj** - (_type_) main api object

camera_funcs module

`oxin.backend.camera_funcs.apply_soft_calibrate_on_image(ui_obj, image, camera_calibration_params, pxcalibration=False)`

this function is used to apply soft calibration params to camera image

Parameters

- **ui_obj** - main ui object
- **image** - input camera image
- **camera_calibration_params** - input camera calibration params (as a dict)
- **pxcalibration** - a boolean determining wheater in pixel calibration step or not

Returns

image: result image that is soft calibrated

`oxin.backend.camera_funcs.assign_existing_serials_to_ui(ui_obj, db_obj, camera_id, available_serials)`

this function is called on every camera selection on camera settngs page, it takes as input available camera serials list, and current camera id, and those serial that not assigned to any camera, and the current camera serial are added to serial combobox on ui

Parameters

- **ui_obj** - main ui object
- **db_obj** - database object
- **camera_id** - current camera id
- **available_serials** - list of available camera serials (list of strings)

Returns

None

`oxin.backend.camera_funcs.connect_disconnect_camera(ui_obj, db_obj, serial_number, connect=True, current_cam_connection=None, calibration=False)`

this function is used to connect/disconnect from camera. in connect mode, a connection to camera with input serial number is returned, while in disconnect mode, the input camera connection is closed

Parameters

- **ui_obj** - main ui object
- **db_obj** - database object
- **serial_number** - camera serial number (in string)
- **connect** - a boolean determining whether to create a new connection to camera, or disconnect from current camera
- **current_cam_connection** - current camera connection object
- **calibration** - a boolean determining if camera connection is for camera calibration page

Returns

on connect: camera_connection: the established camera connection, if failed, return None message: a message determining the error occurred while connecting to camera

Returns

on disconnect: None

`oxin.backend.camera_funcs.convert_cv2_to_qt_image(image)`

this function is used to convert a cv2 image to qt format image

Parameters

image - (_type_) image in cv2 format

Returns

qt_image: image in qt format

`oxin.backend.camera_funcs.draw_grid(image, crosshair=True)`

this function is used to draw align grids on input image

Parameters

- **image** - (_type_) _description_
- **crosshair** - (bool, optional) a boolean determining whether draw crosshair or grid. Defaults to True.

Returns

image: image with grid

`oxin.backend.camera_funcs.get_available_cameras_list_serial_numbers()`

this function is used to get available camera serials that are connected to network

Returns

serial_list: list of available camera serials (in string)

`oxin.backend.camera_funcs.get_camera_calibration_params_from_db(db_obj, camera_id)`

this function is used to get camera calibration params from database, given camera id

Parameters

- **db_obj** - (_type_) database object
- **camera_id** - (_type_) _description_

Returns

camera_calibration_params: in dict

`oxin.backend.camera_funcs.get_camera_calibration_params_from_ui(ui_obj)`

this function returns the camera sot calibration params from ui

Parameters

ui_obj - main ui object

Returns

camera_calibration_params: in dict

`oxin.backend.camera_funcs.get_camera_checkbox_values(ui_obj)`

this function returns a value determining wheareas to apply camera settings/params to only current camera, or multiple cameras in ui, there are two checkboxes for bottom and top cameras. enabling each of them means to apply current settings to all of the cameras on top/bottom

Parameters

ui_obj - main ui object

Returns

a number in range [0, 3], determining wheareas to apply camera settings/params to only current camera, or multiple cameras 0: apply to current camera only 1: apply to top cameras 2: apply to bottom cameras 3: apply to all cameras

`oxin.backend.camera_funcs.get_camera_id(camera_name_label)`

this function is used to get camera id, using camera name label in ui camera settings page

Parameters

camera_name_label - in string

Returns

camera_id: in string

`oxin.backend.camera_funcs.get_camera_params_from_db(db_obj, camera_id)`

this function is used to get camera params from database, using camera id

Parameters

- **db_obj** - database object
- **camera_id** - id of the camera (in string)

Returns

camera_params: a dict containing camera parameters

oxin.backend.camera_funcs.get_camera_params_from_ui(ui_obj)

this function is used to get camera parameters from ui (camera settings page)

Parameters

ui_obj - main ui object

Returns

camera_params

oxin.backend.camera_funcs.get_picture_from_camera(camera_connection)

this function is used to get picture from camera, using its camera connection

Parameters

camera_connection - (_type_) _description_

Returns

live_image: image

oxin.backend.camera_funcs.ip_validation(ui_obj, ip_address)

this function is used to validate ip to be in right format

Parameters

- ui_obj - main ui object
- ip_address - input ip address (in string)

Returns

message: a text message determining if the ip validation is ok or not, 'True' for validation ok

oxin.backend.camera_funcs.rotate_calibration_image(image, angle)

this function is used to rotate image along center by input angle

Parameters

- image - input image
- angle - input angle to rotate image (in degree)

Returns

rotated_image:

oxin.backend.camera_funcs.set_camera_calibration_params_to_db(db_obj, camera_id, camera_calibration_params)

this function is used to set camera calibration params to database

Parameters

- db_obj - (_type_) database object
- camera_id - (_type_) _description_
- camera_calibration_params - (_type_) in dict

Returns

result: boolean determining update ok

```
oxin.backend.camera_funcs.set_camera_calibration_params_to_ui(ui_obj, camera_calibration_params)
```

this functino is used to set camera calibration params returned from dataabse, to ui

Parameters

- **ui_obj** - (_type_) main ui object
- **camera_calibration_params** - (_type_) in dict

Returns

None

```
oxin.backend.camera_funcs.set_camera_params_to_db(db_obj, camera_id, camera_params, checkbox_values)
```

this function is used to update camera params on database, given camera id(s)

Parameters

- **db_obj** - database object
- **camera_id** - current camera id (in string)
- **camera_params** - dict of camera params
- **checkbox_values** - value of camera select checkboxes determing wheareas apply setting to current camera only or to multiple cameras

Returns

result: a boolean value determining if the settings are applied to database or not

```
oxin.backend.camera_funcs.set_camera_params_to_ui(ui_obj, db_obj, camera_params, camera_id, available_serials)
```

this function is used to set input camera params to ui (camera settings page)

Parameters

- **ui_obj** - main ui object
- **db_obj** - main database object
- **camera_params** - input camera parameters (in dict)
- **camera_id** - input camera id (in string)
- **available_serials** - available camera serials (list of strings)

Returns

None

```
oxin.backend.camera_funcs.set_camera_picture_to_ui(ui_image_label, image, with_zoom=False, zoom_min=False)
```

this function is used to set an image to ui label

Parameters

- **ui_image_label** - (_type_) ui lable name
- **image** - (_type_) input image
- **with_zoom** - (_type_) boolean determining wheather to zoom image

Returns

None

`oxin.backend.camera_funcs.set_camera_serial_to_ui(ui_obj, assigned_serial)`

this function takes as input a camera serial and update the serial combobox current value

Parameters

- **ui_obj** - main ui object
- **assigned_serial** - camera serial (in string)

Returns

None

`oxin.backend.camera_funcs.set_widgets_enable_or_disable(ui_obj, api_obj, names, enable=True)`

this function is used to get ui element names in a list, and enable/disable them

Parameters

- **ui_obj** - main ui object
- **api_obj** - main api object
- **names** - ui element names (list of strings)
- **enable** - a boolean determinnig whereas enable or disable ui elements

Returns

None

`oxin.backend.camera_funcs.shift_calibration_image(image, shifth, shiftw)`

this function is used to shift image along y or x (vertical or horizontal)

Parameters

- **image** - input image
- **shifth** - value to shift image horiintaly
- **shiftw** - value to shift image vertically

Returns

shifted_image:

`oxin.backend.camera_funcs.show_calibration_summary(ui_obj, db_obj)`

this function is used to set/update calibration summary params on ui dashboard page

Parameters

ui_obj - (_type_) main ui object

Returns

None

`oxin.backend.camera_funcs.show_cameras_summary(ui_obj)`

this function is used to set/update cameras summary params on ui dashboard page

Parameters

ui_obj - (_type_) main ui object

Returns

None

`oxin.backend.camera_funcs.update_available_camera_serials_on_db(db_obj, available_serials)`

this function is used to update available camera serials on database, it takes as input available camera serial, and checks the database, for each camera, if serial in database not in available cameras, assign 0 as its serial

Parameters

- **db_obj** – (_type_) database object
- **available_serials** – (_type_) list of available camera serials (in string)

Returns

None

`oxin.backend.camera_funcs.update_ui_on_camera_connect_disconnect(ui_obj, api_obj, connect=True, calibration=False)`

this function is used to update ui buttons on camera setting and calibration pages, on camera connect/disconnect on every camera connect, camera take picture button must be enable, while camera connect button must be changed to disconnect on camera disconnect, camera take picture button must set to disable, while camera connect button must be changed to connect

Parameters

- **ui_obj** – main ui object
- **api_obj** – main api object
- **connect** – a boolean determining if camera is connected or disconnected
- **calibration** – a boolean determining if current page on ui is calibration page

Returns

None

`oxin.backend.camera_funcs.validate_camera_ip(ui_obj, db_obj, camera_id, camera_params)`

this function is used to validate camera ip to be valid and not used by other cameras

Parameters

- **ui_obj** – main ui object
- **db_obj** – database object
- **camera_id** – current camera ip
- **camera_params** – camera parameters (dict)

Returns

result: a boolean determining ip validation is ok or not

Returns

message: the error message of ip validation not ok

`oxin.backend.camera_funcs.zoom_in_calibration_image(ui_obj)`

this function is used to zoom in calibration image on button click

Parameters**ui_obj** - (_type_) main ui object**Returns**

None

`oxin.backend.camera_funcs.zoom_out_calibration_image(ui_obj)`

this function is used to zoom out calibration image on button click

Parameters**ui_obj** - (_type_) main ui object**Returns**

None

camera_connection module

```
class oxin.backend.camera_connection.Collector(serial_number, gain=0,
                                              exposure=70000, max_buffer=20,
                                              trigger=True, delay_packet=100,
                                              packet_size=1500,
                                              frame_transmission_delay=0,
                                              width=1000, height=1000,
                                              offet_x=0, offset_y=0,
                                              manual=False,
                                              list_devices_mode=False,
                                              trigger_source='Software')
```

Bases: object

error_window(*msg, level*)**getPictures**(*time_out=50*)**get_cam**(*i*)**listDevices**()

Lists the available devices

serialnumber()**start_grabbing**()**start_grabbing_error_handling**(*error*)**stop_grabbing**()**tempreture**()**trigg_exec**()`oxin.backend.camera_connection.get_threading(cameras)`

chart_funcs module

```
oxin.backend.chart_funcs.create_drive_barchart_on_ui(ui_obj, frame_obj,  
                                                    chart_title='Chart')
```

this function is used to create bar-chart on storage management page

Parameters

- **ui_obj** - (_type_) main ui object
- **frame_obj** - (_type_) ui frame name to create chart in
- **chart_title** - (str, optional) _description_. Defaults to 'Chart'.

Returns

None

```
oxin.backend.chart_funcs.update_drive_barchart(ui_obj, drives_info, storage_thrs,  
                                              warn_storage_thrs)
```

this function is used to update drive statues barchart on storage management page

Parameters

- **ui_obj** - (_type_) main ui object
- **drives_info** - (_type_) statues of the drive (in dict)
- **storage_thrs** - (_type_) an int determining thrshold of storage using in bas statues(for chart colors)
- **warn_storage_thrs** - (_type_) an int determining thrshold of storage using in warning statues(for chart colors)

Returns

None

colors_pallete module

Description

که ورق تشخیصی سنسور ابتدا در که می باشد صورت این به : سی ال پی کارکرد اندکی زمانی فاصله با آن از پس می کند صادر را ورق ورود فرمان می باشد متصل وظیفه . می شود آغاز ها دوربین به زدن تریگ (پرژکتورها) و پردازی نور سیستم امر این برای می باشد پایین و بالا های محفظه دمای کردن مدیریتی سی ال پی دی گر روشن فرمان نیاز صورت در و می شوند چک لحظه در که شده تعبیه دما سنسور دو فرمان باشد حد از بیش دما که صورتی در , می شود صادر بخش هر های کولر شدن . می شود صادر ها دوربین شدن خاموش

date_funcs module

`oxin.backend.date_funcs.get_date(persian=True, folder_path=False)`

this function retrns current date, wheter in persian or miladi.

Parameters

- **persian** - a boolean value determining the foramt of date (in persian or miladi)
- **folder_path** - a boolean value determininng if the date will be used as a folder name or not

Returns

current date (in string)

`oxin.backend.date_funcs.get_datetime(persian=True, folder_path=True)`

this function returns both curent date and time in wheater persian or miladi format

Parameters

- **persian** - a boolean value determining the foramt of date (in persian or miladi)
- **folder_path** - a boolean value determininng if the date will be used as a folder name or not

Returns

date and time: current date and time (in string)

`oxin.backend.date_funcs.get_time(folder_path=False)`

this functionn :returns: current time

Parameters

folder_path - a boolean value determininng if the date will be used as a folder name or not

Returns

time: current time (in string)

defect_management_funcs module

`oxin.backend.defect_management_funcs.add_new_defect_to_db(db_obj,
new_defect_info,
defect_group=False)`

this function is used to add a new defect/defect-group to database

Parameters

- **db_obj** - (_type_) database object
- **new_defect_info** - (_type_) new defect/defect-group info
- **defect_group** - (bool, optional) a boolean determining wheather to add defect-group. Defaults to False.

Returns

resault: a message determining if the add to dabase is done "True": adding ok

```
oxin.backend.defect_management_funcs.assign_existing_defect_colors_to_ui(ui_obj,  
                                                                           db_obj,  
                                                                           current='None')
```

this function is used to set/update existing defect colors to ui combobox. for a color, if the color dont used for any defects, or be the white, it will be added to combo

Parameters

- **ui_obj** – main ui object
- **db_obj** – database object
- **current** – None, or the id of a defect

Returns

None

```
oxin.backend.defect_management_funcs.change_defect_group_id_to_name(db_obj,  
                                                                       defects_list,  
                                                                       reverse=False,  
                                                                       single=False)
```

this function is used to translate defect-group-ids to defect-group-names or reverse

Parameters

- **defects_list** – list of defect_infos (list of dict)
- **reverse** – a boolean determinig wheather to reverse translate or not
- **single** – a boolean determining if the input is only one defect record or not

Returns

translated_defects_list: the same defects_list with defect-group-ids translated

```
oxin.backend.defect_management_funcs.generate_defect_colors(db_obj)
```

this function is used to generate defect colors by number as needed

Parameters

db_obj – (_type_) database object

Returns

None

```
oxin.backend.defect_management_funcs.get_defect_info_from_ui(ui_obj, db_obj, defect_group=False,  
                                                             is_filter=False)
```

this function is used to get defect/defect-group info from ui it can be used to get new defect/defect-group info from ui, or get info from filter/search forms

Parameters

- **ui_obj** – (_type_) main ui object
- **db_obj** – (_type_) database object
- **defect_group** – (bool, optional) a boolean detrtrmines wheather to get defect-group info from ui. Defaults to False.

- **is_filter** - (bool, optional) a boolean determining wheather to get info from filter form in ui. Defaults to False.

Returns

defect/defect-group info: in dict

```
oxin.backend.defect_management_funcs.get_defects_from_db(db_obj,
                                                         defect_groups=False)
```

this function is used to get and return defects/defect-groups list from database

Parameters

defect_groups - a boolean determining wheather to get defect-groups list or defects list

Returns

if defect_groups==False: defects_list: list of dicts

Returns

if defect_groups==True: defect_groups_list: list of defect groups

```
oxin.backend.defect_management_funcs.get_filtered_defects_from_db(db_obj,
                                                                    filter_params,
                                                                    de-
                                                                    fect_groups=False)
```

this function is used to get filtered defects/defect-groups from database

Parameters

- **db_obj** - (_type_) database object
- **filter_params** - (_type_)
- **defect_groups** - (bool, optional) a boolean determining whaeather to search for defect-groups. Defaults to False.

Returns

message: a text message 'all': no filter 'filtered': return filterd resualts

Returns

defects/defect-groups list:

```
oxin.backend.defect_management_funcs.get_selected_defect_groups(ui_obj, de-
                                                                fect_groups_list)
```

this function is used to get selected defect-groups from ui defect-groups table

Parameters

- **ui_obj** - (_type_) main ui object
- **defect_groups_list** - (_type_) list of defect groups rreturned from darabse

Returns

selected_defect_groups: list of selected defect-group ids

```
oxin.backend.defect_management_funcs.get_selected_defects(ui_obj, defects_list)
```

this function is used to get selected defects from ui defects table

Parameters

- **ui_obj** - (_type_) main ui object
- **defects_list** - (_type_) defects list returned from database

Returns

selected_defects: list of selected defects ids

```
oxin.backend.defect_management_funcs.load_defects_from_db(db_obj, defect_id,  
                                                         defect_group=False,  
                                                         defect_group_id=False)
```

this function is used to load defects/defect-groups from database. the function can be used to get defects, get defect-groups, or get those defects with specified defect-group-id

Parameters

- **db_obj** - (_type_) database object
- **defect_id** - (_type_) defect ids list
- **defect_group** - (bool, optional) a boolean determining wheather to load defect-groups. Defaults to False.
- **defect_group_id** - (bool, optional) a boolean to determine wheather to load defects with a specified defect-group-id (send as defect_id). Defaults to False.

Returns

defect_info: list of defects (in dict)

```
oxin.backend.defect_management_funcs.new_defect_info_validation(ui_obj, db_obj,  
                                                             defect_info,  
                                                             on_edit=False,  
                                                             de-  
                                                             fect_group=False)
```

this function is used to validate new defect/defect-group params to have right format and be unique

Parameters

- **ui_obj** - (_type_) main ui object
- **db_obj** - (_type_) database object
- **defect_info** - (_type_) _description_
- **on_edit** - (bool, optional) a boolean to determine if input defect to validate is in edit mode. Defaults to False.
- **defect_group** - (bool, optional) a boolean to determine wheather to validate a defect-group. Defaults to False.

Returns

message: validation message('True': validation ok)

Returns

level: the level of message (in int)

```
oxin.backend.defect_management_funcs.remove_defects_from_db(db_obj, defects_list,  
                                                            defect_group=False,  
                                                            de-  
                                                            fect_group_id=False)
```

this is used to remove defect or defect groups from database. we can determine whethere to remove one or multiple defect groups by id, single or multiple defect by id, or all defects with a specified defect-id

Parameters

- **db_obj** - database object
- **defects_list** - list of ids to remove, for removing defects with specified defect group-id, defect-group-id is the input
- **defect_group** - a boolean for determining to remove a defect-group or defects
- **defect_group_id** - a boolean determining wheather to remove all defects with input defect group id

Returns

resault: a boolean detrtmining if removing from database is done or not

oxin.backend.defect_management_funcs.**set_defect_group_info_on_ui**(*ui_obj, defect_group_info*)

this function is used to set input defect info to ui (for edit defect)

Parameters

- **ui_obj** - (_type_) main ui object
- **defect_group_info** - (_type_) dict of selected defedct-groups infoes

Returns

None

oxin.backend.defect_management_funcs.**set_defect_groups_on_combo**(*ui_obj, defect_groups_list*)

this function is used to update defect-groups combobox according to available defect-groups

Parameters

defect_groups_list - list of defect-groups (in dict)

Returns

None

oxin.backend.defect_management_funcs.**set_defect_groups_on_ui**(*ui_obj, defect_groups_list*)

this function is used to set defect-groups list on ui defect-groups table

Parameters

defect_groups_list - list of defect-groups (in dict)

Returns

None

oxin.backend.defect_management_funcs.**set_defect_info_on_ui**(*ui_obj, db_obj, defect_info*)

this function is used to set input defect info to ui (for edit defect)

Parameters

- **ui_obj** - (_type_) main ui object
- **db_obj** - (_type_) database object
- **defect_info** - (_type_) dict of selected defedct infoes

Returns

None

`oxin.backend.defect_management_funcs.set_defects_on_ui(ui_obj, defects_list, defect_group_name='None')`

this function is used to set input defects list to defects table on ui

Parameters

- **ui_obj** – main ui object
- **defects_list** – list of defects (in dict)
- **defect_group_name** – if not None and have value (in string), those defects with same defect-group-name will be highlighted

Returns

None

`oxin.backend.defect_management_funcs.show_defects_summary_info(ui_obj, db_obj)`

this function is used to show summary info from defects/defect-groups on dashboard page

Parameters

- **ui_obj** – (_type_) main ui object
- **db_obj** – (_type_) database object

Returns

None

`oxin.backend.defect_management_funcs.update_combo_color(ui_obj)`

this function is used to update color combobox

Parameters

- **ui_obj** – (_type_) main ui object

Returns

None

`oxin.backend.defect_management_funcs.update_defects_to_db(db_obj, defects_list, defect_group=False)`

this function is used to update a defect/defect-group on database

Parameters

- **db_obj** – (_type_) database object
- **defects_list** – (_type_) defect/defect-groups list
- **defect_group** – (bool, optional) a boolean determining whether to update defect-group. Defaults to False.

Returns

result: a boolean to determine if update on database is ok

logging_funcs module

```
class oxin.backend.logging_funcs.app_logger(name='saba_setting-app_logger',
                                             log_mainfolderpath='./app_logs',
                                             console_log=True)
```

Bases: object

create_dailyfolder()

this function creates day by day folders in the main folder, to sotring the log files of each day

Returns

None

create_mainfolder()

this function creates the main folder to store log files

Returns

None

create_new_log(message='nothing', level=1)

this function creates a log with input message and log level

Parameters

- **message** - the log message (in string)
- **level** - the log level (in int), an int value between [0, 5] specifying the log level) 0: debug 1: info 2: warning 3: error 4: critical error 5: exception error

Returns

None

set_current_user(current_username=None)

this function sets the input username as the current user of the app and logging

Parameters

current_username - current username logged-in the app (in string)

Returns

None

mainsetting_funcs module

```
oxin.backend.mainsetting_funcs.apply_appearance_params_to_program(ui_obj, con-
                                                                    firm_ui_obj,
                                                                    lo-
                                                                    gin_ui_object,
                                                                    appear-
                                                                    ance_params)
```

this function is used to apply apearance params in setting page to app

Parameters

- **ui_obj** - (_type_) main ui object
- **confirm_ui_obj** - (_type_) _description_

- **appearance_params** - (_type_) in dict

Returns

appearance_params['window_color']: color of the app

Returns

appearance_params['font_size']: font-size of the app

Returns

appearance_params['font_style']: font-style of the app

oxin.backend.mainsetting_funcs.**assign_appearance_existing_params_to_ui**(ui_obj)

this function is used to assign default appearance params to ui (combobox contents in main-setting page)

Parameters

ui_obj - (_type_) main ui object

Returns

None

oxin.backend.mainsetting_funcs.**get_appearance_params_from_ui**(ui_obj)

this function is used to get app appearance params from ui setting page

Parameters

ui_obj - (_type_) main ui object

Returns

appearance params: in dict

oxin.backend.mainsetting_funcs.**get_calibration_params_from_ui**(ui_obj)

this function is used to get calibration params from main-setting page

Parameters

ui_obj - (_type_) main ui object

Returns

calibration_params: in dict

oxin.backend.mainsetting_funcs.**get_defects_params_from_ui**(ui_obj)

this function is used to get defect params from main-setting page

Parameters

ui_obj - (_type_): main ui object

Returns

defects_params: in dict

oxin.backend.mainsetting_funcs.**get_image_procesing_params_from_ui**(ui_obj)

this function is used to get image-preprocessing params from main-setting page

Parameters

ui_obj - (_type_) main ui object

Returns

image_procesing_params: in dict

oxin.backend.mainsetting_funcs.**get_mainsetting_params_from_db**(db_obj,
mode='all')

this function is used to get mainsetting params from database

Parameters

- **db_obj** - (_type_) database object
- **mode** - (str, optional) select mode to return specific parameters from database. Defaults to 'all'.

Returns

depending on mode 'all': all_params, multitasking params 'px_calibration':
rect_areas, rect_acc

oxin.backend.mainsetting_funcs.**get_multitasking_params_from_ui**(ui_obj)

this function is used to get multitasking params from main-setting page

Parameters

ui_obj - (_type_) main ui object

Returns

multitasking_params: in dict

oxin.backend.mainsetting_funcs.**set_appearance_params_to_ui**(ui_obj,
appearance_params,
multi-
task_params=None)

this function is used to set input appearance params to ui setting page elements

Parameters

- **ui_obj** - (_type_) main ui object
- **appearance_params** - (_type_) in dict
- **multitask_params** - (_type_, optional) if not none, set multitask params. Defaults to None.

Returns

None

oxin.backend.mainsetting_funcs.**set_mainsetting_params_to_db**(db_obj,
appearance_params,
is_multitask_params=False)

this function is used to update/set mainsetting params to database

Parameters

- **db_obj** - (_type_) database object
- **appearance_params** - (_type_) params, could be appearance, calibration, image-preprocessing and ...
- **is_multitask_params** - (bool, optional) a boolean determining whether the input params are belong to multitasking or not. Defaults to False.

Returns

result: results of updating on database

oxin.backend.mainsetting_funcs.**update_combo_color**(ui_obj)

this function is used to update setting page color combobox background color by current color

Parameters

ui_obj - (_type_) main ui object

Returns

None

`oxin.backend.mainsetting_funcs.update_combo_fontsize(ui_obj)`

this function is used to update setting page fontsize-combobox font according to current app fontsize

Parameters

ui_obj - (_type_) main ui object

Returns

None

`oxin.backend.mainsetting_funcs.update_combo_fontstyle(ui_obj)`

this function is used to update setting page fontstyle-combobox font according to current app fontstyle

Parameters

ui_obj - (_type_) main ui object

Returns

None

plc_managment module

`class oxin.backend.plc_managment.management(ip, ui_obj)`

Bases: object

this class is used to create and manage opc/plc object

Parameters

- **ip** - plc ip (in string)
- **ui_obj** - main ui object

Returns

PLC object

`connection()`

this function is used to connect to plc

Returns

result: a boolean determining if connected or not

`disconnect()`

this function is used to disconnect from plc

Returns

None

`get_value(path)`

this function is used to get value of a logic from plc using its path

Parameters

path - (_type_) plc logic path (in string)

Returns

value: value stored in path, if failed to load, return '-'

Returns

data_value: if failed to load, return message error

set_file_name(*name*)

this function is used to set json file name to store plc params

Returns

None

set_value(*path, value*)

this function is used to set/update value of a logic, using its path on plc

Parameters

- **path** - (_type_) path of the logic (in string)
- **value** - (_type_) input value to update (digit or boolean)

Returns

None

write(*value*)

this function is used to write plc values on json file

Parameters

value - (_type_) in dict

pxvalue_calibration module

`oxin.backend.pxvalue_calibration.apply_pxvalue_calibration(ui_obj, api_obj, db_obj, image, next=True)`

this function is used in pixel value calibration. the pixel value calibration is done during some steps, in every call of this function, one step (next/prev) is done and the results are updated on ui. this way, we can change between steps and tune parameters to get pixel value results

Parameters

- **ui_obj** - main ui object
- **api_obj** - main api object
- **db_obj** - database object
- **image** - input calibration image
- **next** - a boolean value determining wheater take to next step or previous step

Returns

None

`oxin.backend.pxvalue_calibration.draw_contour(gray, cnts)`

this function is used to draw nput contours on image

Parameters

- **gray** - (_type_) image in gray format
- **cnts** - (_type_) contours

Returns

image: image with drawn contours

`oxin.backend.pxvalue_calibration.draw_rect(gray, cnts, areas)`

this function is used to draw input recangle contours on image

Parameters

- **gray** - (_type_) image in gray format
- **cnts** - (_type_) contours
- **areas** - (_type_) list of areas of rectangles (in mm)

Returns

image: image with drawn contours

```
class oxin.backend.pxvalue_calibration.extract_info(gray, areas_mm,  
                                                    min_area=2000,  
                                                    max_area=50000,  
                                                    accuracy=0.9, gray_thrs=100)
```

Bases: object

this class is used to get pixel-value of camera, using the Dorsa calibrator plate with 6 rectangles (3 pairs)

Parameters

- **gray** - input image in gray format
- **areas_mm** - list of areas of rectangles (in mm), containing 6 area value, first 3 for large rects, and last 3 for small rects
- **min_area** - min area of contours (in pixel)
- **max_area** - max area of contours (in pixel)
- **accuracy** - min rectangular accuracy for contours
- **gray_thrs** - gray threshold for thresholding

Returns

None

`draw_rects(cnts)`

this function is used to draw rectangular contours on image

Parameters

cnts - (_type_) input contours

Returns

img: image with drawn countours

Returns

rects: list of 6 rectangle countours

`filter_acc(x)`

this function is used to filter a countour by its accuracy to be rectangular

Parameters

x - (_type_) _description_

Returns

type: _description_

filter_contours_by_accuracy(*cnts*)

this function is used to filter countours by their accuracy to be rectangular

Parameters

cnts - (_type_) input contours

Returns

img: image with drawn countours

Returns

cnts: rectangle accuracy filtered counturs

filter_contours_by_area(*cnts*)

this function is used to filter founded contours by min and max area

Parameters

cnts - (_type_) input contours

Returns

img: image with drawn countours

Returns

cnts: area filtered counturs

final_decision(*cnts*, *rects*)

this function is used to get pixel-values for each of rrectangle pairs

Parameters

- **cnts** - (_type_) input contours
- **rects** - (_type_) input 6 rectangle contours

Returns

resault: determining if done

Returns

infoes: array of rectangle pair centers and pixel values

Returns

infoes_final: array of rectangle pair centers and pixel values

find_contours(*mask*)

find countours of threshold mask

Parameters

mask - (_type_) threshold mask

Returns

img: image with drawn countours

Returns

cnts: foundeed counturs

solve_equation(*inputs*)

this function is used to solve equation for finding pixel value parameters

Parameters

inputs - (_type_) _description_

Returns

pixel_value_parameters: array of 3 parameters

thrs_map()

get thresholded/mask from input image

Returns

mask: threshold mask of input image

storage_funcs module

oxin.backend.storage_funcs.get_available_drives()

this function is used to get system available drives list

Returns

available_drives: in list

oxin.backend.storage_funcs.get_camera_live_drive_parameters_from_db(db_obj)

this function is used to get camera live drive parameters from database

Parameters

db_obj - (_type_) database object

Returns

drive_infos: app general parameters (in dict)

oxin.backend.storage_funcs.get_camera_live_drive_parameters_from_ui(ui_obj)

this function is used to get default storage setting params from ui

Parameters

ui_obj - (_type_) main ui object

Returns

resault: a boolean determining if the parameters are validated or not

oxin.backend.storage_funcs.get_drivename(driveletter)

this function is used to get drive name using its letter

Parameters

driveletter - (_type_) in string

Returns

drive_name: in string

oxin.backend.storage_funcs.get_files_in_path(dir_path, reverse=False)

this function is used to get all files in a path, sorted by date (old to new)

Parameters

- **dir_path** - (_type_) _description_
- **reverse** - (bool, optional) a boolean to reverse sorting to new to old. Defaults to False.

Returns

file_paths: list of file pathes

oxin.backend.storage_funcs.get_storage_status(disk_path)

this function is used to get storage statues of one drive

Parameters

disk_path - (_type_) drive path (in string)

Returns

drive_info: in dict

```
oxin.backend.storage_funcs.remove_old_files_in_directory(api_obj, ui_obj,  
                                                         drive_path, dir_path,  
                                                         start_ratio, stop_ratio,  
                                                         reverse=False)
```

this function is used to remove old files in a directory

Parameters

- **api_obj** - (_type_) _description_
- **ui_obj** - (_type_) main ui object
- **drive_path** - (_type_) _description_
- **dir_path** - (_type_) directory of the folder in drive
- **start_ratio** - (_type_) _description_
- **stop_ratio** - (_type_) drive usage threshold to stop removing files
- **reverse** - (bool, optional) boolean to reverse sorting files in directory. Defaults to False.

Returns

None

```
oxin.backend.storage_funcs.set_camera_live_drive_parameters_to_db(db_obj,  
                                                                  drive_infos)
```

this function is used to set/update drive setting params on database

Parameters

- **db_obj** - (_type_) database object
- **drive_infos** - (_type_) in dict

Returns

resault: boolean deermining whather set to database is ok

```
oxin.backend.storage_funcs.show_storage_status(ui_obj, db_obj)
```

this functionis used tp update storage info summary on dashboard

Parameters

- **ui_obj** - (_type_) main ui object
- **db_obj** - (_type_) database object

Returns

None

```
oxin.backend.storage_funcs.update_camera_live_drive_combo(ui_obj,  
                                                          available_drives)
```

this function is used to update existing drives combobox on storage setting age

Parameters

- **ui_obj** - (_type_) main ui object
- **available_drives** - (_type_) list of available drives

texts module

Description

که ورق تشخیص سنسور ابتدا در که می باشد صورت این به : سی ال پی کارکرد اندکی زمانی فاصله با آن از پس می کند صادر را ورق ورود فرمان می باشد متصل وظیفه . می شود آغاز ها دوربین به زدن تریگ (پرژکتورها) و پردازش نور سی سی تم امر این برای می باشد پایین و بالا های محفظه دمای کردن مدیریت سی ال پی دی گر روشن فرمان نیاز صورت در و می شوند چک لحظه در که شده تعبیه دما سنسور دو فرمان باشد حد از بیش دما که صورتی در , می شود صادر بخش هر های کولر شدن . می شود صادر ها دوربین شدن خاموش

user_login_logout_funcs module

```
oxin.backend.user_login_logout_funcs.authenticate_user(ui_obj, login_ui_obj,  
                                                       login_api_obj, api_obj)
```

this function is used to authenticate the user, it takes the authentication results from login API, and if user be authenticated, enables/unlocks ui for user to work with

Parameters

- **ui_obj** - main ui object
- **login_ui_obj** -
- **login_api_obj** -
- **api_obj** - main API object

Returns

None

```
oxin.backend.user_login_logout_funcs.logout_user(ui_obj, confirm_ui_obj,  
                                                  login_api_obj)
```

this function is used to logout user from the app, and disable/lock ui after logout

Parameters

- **ui_obj** - main ui object
- **confirm_ui_obj** -
- **login_api_obj** -

Returns

None

```
oxin.backend.user_login_logout_funcs.run_login_window(ui_obj, login_ui_obj,  
                                                       confirm_ui_obj)
```

this function is used to run/show login window for user login

Parameters

- **ui_obj** - the main ui object
- **login_ui_obj** -
- **confirm_ui_obj** -

Returns

None

`oxin.backend.user_login_logout_funcs.set_app_buttons_enable_or_disable(names, enable=True)`

this function is used to enable/disable ui elements, by taking input elements as list of names

Parameters

- **names** – ui element names (list of strings)
- **enable** – a boolean determining wheather to enable/disable the elements

Returns

None

user_management_funcs module

`oxin.backend.user_management_funcs.add_new_user_to_db(db_obj, new_user_info)`

this function is used to add a new user to database

Parameters

- **db_obj** – (_type_) database object
- **new_user_info** – (_type_) in dict

Returns

resault: a boolean determining if the user is added to database

`oxin.backend.user_management_funcs.get_selected_users(ui_obj, users_list)`

this function is used to get selected users from users table in ui

Parameters

- **ui_obj** – (_type_) main ui object
- **users_list** – (_type_) list of users (in dict)

Returns

selected_users: list of selected users user_names

`oxin.backend.user_management_funcs.get_user_info_from_ui(ui_obj)`

this function is used to get user info from ui add user fileds

Parameters

ui_obj – (_type_): main ui object

Returns

user_info: in dict

`oxin.backend.user_management_funcs.get_users_from_db(db_obj)`

this function is used to get users list from database

Returns

users_list: list of users (in dict)

```
oxin.backend.user_management_funcs.new_user_info_validation(ui_obj, db_obj,  
                                                           user_info,  
                                                           default_user=False)
```

this function is used to validate new user info, to be in right format and be unique

Parameters

- **ui_obj** - (_type_) main ui object
- **db_obj** - (_type_) database object
- **user_info** - (_type_) input user_info (in dict)
- **default_user** - (bool, optional) a boolean to determine if input user info is for default admin user. Defaults to False.

Returns

message: the text message of validating user_info

Returns

message_level: an int value in range [0, 2] determining the level of message

```
oxin.backend.user_management_funcs.remove_users_from_db(db_obj, users_list)
```

this function is used to remove input users from database

Parameters

- **db_obj** - (_type_) database object
- **users_list** - (_type_) list of user_names

Returns

results: a boolean determining if the removing is ok

```
oxin.backend.user_management_funcs.set_users_on_ui(ui_obj, users_list)
```

this function is used to set input users list to ui users table

Parameters

- **ui_obj** - main ui object
- **users_list** - list of users (in dict)

Returns

None

```
oxin.backend.user_management_funcs.show_users_summary_info(ui_obj, db_obj)
```

this function is used to show user infoes summary on dashboard

Parameters

- **ui_obj** - (_type_) main ui object
- **db_obj** - (_type_) database object

Calibrational Cal

Description

که ورق تشخیصی سنسور ابتدا در که می باشد صورت این به : سی ال پی کارکرد اندکی زمانی فاصله با آن از پس می کند صادر را ورق ورود فرمان می باشد متصل وظیفه . می شود آغاز ها دوربین به زدن تریگ (پرژکتورها) و پردازش نور سیستم امر این برای می باشد پایین و بالا های محفظه دمای کردن مدیریت سی ال پی دی گر روشن فرمان نیاز صورت در و می شوند چک لحظه در که شده تعبیه دما سنسور دو فرمان باشد حد از بیش دما که صورتی در ، می شود صادر بخش هر های کولر شدن می شود صادر ها دوربین شدن خاموش

Contents:

Division module

```
oxin.calibrationCal.Division.ImageDivision(img, dim, ol)
```

load_recent_images module

```
oxin.calibrationCal.load_recent_images.load_recent_images(path, image_count=3)
```

main module

Noise module

```
oxin.calibrationCal.Noise.NoiseDetection(img, dim, ndim)
```

Preprocessing module

```
oxin.calibrationCal.Preprocessing.EdgeDetection(img)
```

```
oxin.calibrationCal.Preprocessing.ImageEnhancement(img)
```

```
oxin.calibrationCal.Preprocessing.ImageSmoothness(img)
```

```
oxin.calibrationCal.Preprocessing.SmallNoiseRemoval(img)
```

SteelSurfaceInspection module

```
oxin.calibrationCal.SteelSurfaceInspection.CreateHeatmap(gray, img)
oxin.calibrationCal.SteelSurfaceInspection.FindDefectiveBlocks(gray,
                                                                block_size='small',
                                                                defect_th=0,
                                                                noise_th=7,
                                                                noise=True,
                                                                heatmap=False)

oxin.calibrationCal.SteelSurfaceInspection.SSI(img, block_size='Small',
                                                defect_th=0, noise_th=7,
                                                noise=True, heatmap=False)
```

Variance module

```
oxin.calibrationCal.Variance.ImageBlockVariance(img, dim, ol)
oxin.calibrationCal.Variance.ThresholdCalculator(variance)
oxin.calibrationCal.Variance.VarianceCalculator(blocks, dim)
```

Database

Description

که ورق تشخیصی سنسور ابتدا در که می باشد صورت این به : سی ال پی کارکرد اندکی زمانی فاصله با آن از پس می کند صادر را ورق ورود فرمان می باشد متصل وظیفه . می شود آغاز ها دوربین به زدن تریگ (پرژکتورها) و پردازش نور سیستم امر این برای می باشد پایین و بالا های محفظه دمای کردن مدیریتی سی ال پی دیگر روشن فرمان نیاز صورت در و می شوند چک لحظه در که شده تعبیه دما سنسور دو فرمان باشد حد از بیش دما که صورتی در , می شود صادر بخش هر های کولر شدن . می شود صادر ها دوربین شدن خاموش

Utils

Description

که ورق تشخیصی سنسور ابتدا در که می باشد صورت این به : سی ال پی کارکرد اندکی زمانی فاصله با آن از پس می کند صادر را ورق ورود فرمان می باشد متصل وظیفه . می شود آغاز ها دوربین به زدن تریگ (پرژکتورها) و پردازش نور سیستم امر این برای می باشد پایین و بالا های محفظه دمای کردن مدیریتی سی ال پی دیگر روشن فرمان نیاز صورت در و می شوند چک لحظه در که شده تعبیه دما سنسور دو فرمان باشد حد از بیش دما که صورتی در , می شود صادر بخش هر های کولر شدن . می شود صادر ها دوربین شدن خاموش

Contents:**move_on_list module****class** oxin.utils.move_on_list.moveOnList

Bases: object

this function is used to create a list of elements, with option to go next or previous on list and get current object/element

Returns

moveOnList class

add(mylist, name)

this function is used to add a list or elements with name/key

Parameters

- **mylist** - (_type_) _description_
- **name** - (_type_) name of list

Returns

None

build_next_func(name)

this function is used to get a next object for moving next on a list

Parameters

name - (_type_) name/key of list

Returns

next_on_list object

build_prev_func(name)

this function is used to get a previous object for moving next on a list

Parameters

name - (_type_) name/key of list

Returns

prev_on_list object

check(name)

this function is used to check if a key/name is in class

Parameters

name - (_type_): input name

Returns

result: boolean determining if the name is available

get_count(name)

this function is used to get count of elements in a list

Parameters

name - (_type_) name/key of list

Returns

len_list: _description_

get_current(*name*)

this function is used to get current element in a list

Parameters

name - (_type_) name/key of list

Returns

current_element of list:

get_list(*name*)

this function is used to get a list using its name/key

Parameters

name - (_type_) name/key of list

Returns

list: _description_

next_on_list(*name*)

prev_on_list(*name*)

3.3.3 Files

app_settings module

class oxin.app_settings.**Settings**

Bases: object

confirm_UI module

class oxin.confirm_UI.**UI_main_window**(*language='en'*)

Bases: QMainWindow, Ui_confirm_window

activate_()

this function connects the close button to its functionality

Returns

None

buttonClick()

this function is used to connect each button to its functionality, on button click

Returns

None

close_win()

this function is used for closing login window

Returns

None

staticMetaObject = <PySide6.QtCore.QMetaObject object>

confirm_window module

```

class oxin.confirm_window.UI_confirm_window
    Bases: QMainWindow, Ui_confirm_window
    activate_()
    close_win()
    set_language()
    set_text(msg='')
    staticMetaObject = <PySide6.QtCore.QMetaObject object>
    yes()

```

database module

```

class oxin.database.dataBase(username, password, host, database_name,
                             logger_obj=None)

```

Bases: object

this class is used to connect and working with database

Parameters

- **username** – username to connect to database
- **password** – password to connect to database
- **host** – host of the database
- **database_name** – name of the database to work with
- **logger_obj** – the logger object to take logs

Returns

None

```

add_record(data, table_name, params, len_parameters)

```

this function is used to add a new record a specified table of database

Parameters

- **data** – data to be added to database
- **table_name** – in string
- **params** – list of parameters (column names) of the database
- **len_parameters** – number of parameters

Returns

None

```

check_connection()

```

this function is used to check if the connection to database can be established

Returns

a boolean value determining if the connection is established or not

connect()

this function is used for connecting to database

Returns

cursor: the object that is used to work with database by queries

Returns

connection: ?

delete(db_name, table_name)**execute_query(query, cursor, connection, need_data=False, close=False)**

this function is used to execute a query on database

Parameters

- **query** - the input query to execute
- **cursor** -
- **connection** -
- **need_data** - a boolean value
- **close** -

Returns

None

get_all_content(table_name)

this function is used to get/return all contents of a table

Parameters

table_name - in string

Returns

table_content: list of records in table (in dict)

get_col_name(table_name, param_name, value)**get_log(message='nothing', level=1)**

this function is used to get log from database tasks

Parameters

- **message** - (str, optional) _description_. Defaults to 'nothing'.
- **level** - (int, optional) level of log. Defaults to 1.

Returns

None

remove_record(col_name, id, table_name)

this function is used to remove a record from table according to specified column value

Parameters

- **col_name** - name of the column to check for (in string)
- **id** - value of the column (in string)
- **table_name** - name of the table (in string)

Returns

results: a boolean determining if the record is removed or not

report_last(*table_name*, *parametr*, *count*)

search(*table_name*, *param_name*, *value*, *multi=False*)

this function is used to search in table according to one or multiple specific parameter (column name)

Parameters

- **table_name** - in string
- **param_name** - parameter (column) name in string, for multiple parameters, a list of strings
- **value** - value of the parameter to be (in string), for multiple values, a list of strings
- **multi** - a boolean value determining if the search is according to one parameter or multi parameters

Returns

result: a list containing the returned/searched row (record) in table, if failed to connect to database or nothing was found in table, an empty list will be returned

update_record(*table_name*, *col_name*, *value*, *id*, *id_value*)

this function is used to update a parameter (column) in a table record, determining by record id

Parameters

- **table_name** - name of the table in database (in string)
- **col_name** - column name of table to update (in string)
- **value** - value will be assigned to column ((in string))
- **id** - name of id column in table, its used to determine which record to update
- **id_value** - value of the id column

Returns

result: a boolean determining if the update on table is done or not

database_utils module

class oxin.database_utils.dataBaseUtils(*logger_obj=None*)

Bases: object

this class is used as an API to work with database

Parameters

logger_obj - the logger object to take logs

Returns

database object

add_defect(*parms*)

this function is used to add new defect to database

Parameters

parms - (_type_) new defect infoes

Returns

message: determinig if ok or not

add_defect_group(*parms*)

this function is used to add new defect-group to database

Parameters

parms - (_type_) new defect-group infoes

Returns

message: determinig if ok or not

add_user(*parms*)

this function is used to add a new user to users table

Parameters

parms - (_type_) user infoes (in dict)

Returns

resault: a text message determining if the user is added "True": 'Databas Error':

get_dataset_path()**get_image_processing_parms()**

this function is used to set input image processing params for Miss.Abtahi algo to database

Parameters

data - (_type_) image processing params

Returns

image_procesing_params

load_cam_params(*input_camera_id*)

this function is used to load camear parameters from camera tables, using the camera id

Parameters

input_camera_id - id of camera (in string)

Returns

camera_params: a dict containing camera parameters

load_defect_groups()

this function is used to load defect-groups from table

Returns

defect_groups: list of defect-groups (in dict)

load_defects()

this function is used to get all defects from defects table

Returns

defects: list of defects (in dict)

load_general_setting_params(*is_multitasking_params=False*)

this function is used to get general-settings params from table

Parameters

is_multitasking_params - (bool, optional) a boolean determining wheather to load multitasing params from multitasking table. Defaults to False.

Returns

record: list of one dict

load_plc_ip()

this function is used to load plc ip from table on dataabase

Returns

record: plc ip (in string), if failed return False

load_plc_parms()

this function is used to load plc params from table

Returns

plc_params: in dict, if failed to load from dataabse, return None

load_users()

this function is used to load users list from database

Returns

users_list: list of users (in dict)

remove_defect_groups(*defect_ids*)

this function is used to remove defect groups from database by their ids

Parameters

defect_ids - list of input defect-group-ids (in string)

Returns

resault: a boolean determining if the removing is done

remove_defects(*defect_ids*)

this function is used to remove one or multiple defects from database, using their ids

Parameters

defect_ids - list if defect-ids (in string)

Returns

results: a boolean determining if the removing is done

remove_defects_by_group_id(*defect_ids*)

this function is used to remove all defects with a specific defect-group-id

Parameters

defect_ids - input defect-group-id (in string)

Returns

resault: a boolean determining if removig defects is done

remove_users(*users_name*)

this function is used to remove input users from database

Parameters

users_name - (_type_) list of user_names

Returns

None

search_camera_by_ip(*input_camera_ip*)

this function is used to search camera by its ip

Parameters

input_camera_ip - (_type_) in string

Returns

record: dict f camera params of camera with input ip

search_camera_by_serial(*input_camera_serial*)

this function is used to search camera by its serial

Parameters

input_camera_serial - (_type_) in string

Returns

record: dict f camera params of camera with input serial

search_defect_by_color(*input_color*)

this function is used to search a defect in database by its color

Parameters

input_color - string html code

Returns

defect_list: a list with single defect (in dict)

search_defect_by_filter(*parms, cols*)

this function is used to search/filter defects by filter params

Parameters

- **parms** - (_type_) value of columns to filter
- **cols** - (_type_) columns to filter

Returns

defect_info: list of filtered defects

search_defect_by_group_id(*input_defect_id*)

this function is used to search defects with specific defect-group-id

Parameters

input_defect_id - (_type_) input defect-group-id

Returns

defects_info: a list of defect_infos (in dict)

search_defect_by_id(*input_defect_id*)

this function is used to search a defect in database, according to its defect-id

Parameters

input_defect_id - (_type_) in string

Returns

defect_info: a list with single record (in dict)

search_defect_by_name(*input_defect_name*)

this function is used to search a defect by its name in database

Parameters

input_defect_name - in string

Returns

defects_list: a list of one defect record (in dict)

search_defect_by_short_name(*input_defect_name*)

this function is used to search a defect by its short-name in database

Parameters

input_defect_name - in string

Returns

defects_list: a list of one defect record (in dict)

search_defect_group_by_filter(*parms, cols*)

this function is used to search/filter defect-groups by filter params

Parameters

- **parms** - (_type_) value of columns to filter
- **cols** - (_type_) columns to filter

Returns

defect_info: list of filterd defect-groups

search_defect_group_by_id(*input_defect_group_id*)

this function is used to search a defect-group in database with its id

Parameters

input_defect_group_id - in string

Returns

defect_group: list of returned defect groups (since the ids are unique, its a list of one record in dict format)

search_defect_group_by_name(*input_defect_group_name*)

this function is used to search a defect-group in table by its name

Parameters

input_defect_group_name - (_type_) _description_

Returns

record: list of defects with this name (list of dicts)

search_user(*input_user_name*)

this function is used to search if any user is available in users table with input user-name, if username is available, user info are returned, else an empty list is returned

Parameters

input_user_name - input username to search (in string)

Returns

user_info: a dict containing user info: {user_name: username in string, password: password in string}

search_user_by_user_name(*input_user_name*)

this function is used to search a user by its usnam

Parameters

input_user_name - (_type_) in string

Returns

record: user_info (in dict)

set_image_processing_params(*data*)

this function is used to get input image processing params for Miss.Abtahi algo to database

Parameters

data - (_type_) image processing params

Returns

None

update_cam_params(*input_camera_id, input_camera_params*)

this function is used to update camera params of input camera id on table

Parameters

- **input_camera_id** - id of crrent camera (in string)
- **input_camera_params** - camera parameters (in dict)

Returns

result: a boolean value determining if the settings are updated on database or not

update_defect(*input_defect_params*)

this function is used to update a defect on table

Parameters

input_defect_params - (_type_) in dict

Returns

resaults: in boolean to deteriimine if update is ok

update_defect_group(*input_defect_params*)

this function is used to update a defect-group on table

Parameters

input_defect_params - (_type_) in dict

Returns

resaults: in boolean to deteriimine if update is ok

update_general_setting_params(*input_setting_params, is_mutitasking_params=False*)

this function is used to update general-setting params on table

Parameters

- **input_setting_params** - (_type_) _description_
- **is_mutitasking_params** - (bool, optional) a boolean to determine if params are belong to multitask params. Defaults to False.

Returns

resault: a boolean determining if the update is done

update_plc_ip(*ip*)

this function is used to update plc ip on table

Parameters

ip - (_type_) plc ip (in string)

Returns

resalt: a boolean determining wheather database updated

update_plc_parms(*plc_parms*)

this function is used to update plc params on database

Parameters

plc_parms - (_type_) in dict

Returns

resault: a boolean determining wheather update is done

error_window module**class oxin.error_window.UI_eror_window**

Bases: QMainWindow, Ui_MainWindow

activate_()**close_win()**

mouseMoveEvent(*self, event: PySide6.QtGui.QMouseEvent*) → None

mousePressEvent(*self, event: PySide6.QtGui.QMouseEvent*) → None

mouseReleaseEvent(*self, event: PySide6.QtGui.QMouseEvent*) → None

set_text(*msg='□□□□ '□□□□□□, level=3*)

staticMetaObject = <PySide6.QtCore.QMetaObject object>

login_UI module**class oxin.login_UI.UI_main_window(*language='en'*)**

Bases: QMainWindow, Ui_MainWindow

activate_()

this function connects the close button to its functionality

Returns

None

buttonClick()

this function is used to connect each button to its functionality, on button click

Returns

None

close_win()

this function is used for closing login window, also on closing, the password and user-name files are cleared

Returns

None

get_user_pass()

this function is used to get/return entered username and password from fields

Returns

username: in string

Returns

password: in string

set_login_message(text="", level=0, clearable=True, prefix=True)

this function is used to show input message in input label, also there is a message level determining the color of label, and a timer to clear message after a while

Parameters

- **label_name** – label element name to show the message in
- **text** – input message to show (in string)
- **level** – level of the message (in int), its a value between [0, 2] determining the background color of message label
- **clearable** – a boolean value determining whether to clear the message after timeout or not
- **prefix** – a boolean value determining whether to show the message prefix or not

Returns

None

showPassword(show)

this function is used for showing/hiding password text in password lineedit

Returns

None

staticMetaObject = <PySide6.QtCore.QMetaObject object>

login_api module

class oxin.login_api.API(ui, logger_obj=None, language='en')

Bases: object

this class is used as the API for login window, to take login infoes from user and authenticate the user

Parameters

- **ui** – login ui object
- **logger_obj** – logger object to take logs of user authenticating and logging in

- **language** – the language to show notifications of the login

Returns

None

button_connector()

function to connect buttons to their functions

login()

this function is used to authenticate an login the user to app

Returns

result: a boolean value determining if the authentication done or not

Returns

user_info: a dict containing infoes of the user {user_name: username in string, password: password in string}

notif_UI module**class oxin.notif_UI.UI_main_window(order=0)**

Bases: QMainWindow, Ui_confirm_window

activate_()

this function connects the close button to its functionality

Returns

None

buttonClick()

this function is used to connect ui buttons to their functions

Returns

None

check_appear_done()**close_win()**

this function is used for closing login window

Returns

None

close_win_2()

this function is used for closing login window, also stopping progressbar and appear timers and start disappear timers

Returns

None

progressbar()

this function is used to update the progressbar value, by a timer. progressbar determines the remained time to finish and close the notification

Returns

None

staticMetaObject = <PySide6.QtCore.QMetaObject object>

unlock_move_flag()

update_current_position()

win_appear(*use_current_pos=False*)

this function is used to appear/show the notification window with an sliding animation, notification window will be appeared from top left of the screen in sliding way

Returns

None

win_disappear(*use_current_pos=False*)

this function is used to disappear/hide the notification window with an sliding animation, notification window will be disappeared from top left of the screen in sliding way

Returns

None

win_move_down()

this function is used to move the notification down vertically, on any new notification is created

Returns

None

win_move_down_run_timer(*reverse=False*)

this function is used to move notification vertically, if a new notification is created or a previous notification is closed on default, it is used to move down the notifications, but it can be used to move up the notifications by the reverse flag

Parameters

reverse – a boolean value determining if the movement is reversly (move to top)

Returns

None

win_move_top()

this function is used to move the notification up vertically, if any top notification is closed

Returns

None

win_startpoint()

this function is used to determine the startpoint of the notification window (showing from top right of the screen)

Returns

None

class oxin.notif_UI.notification_manager

Bases: object

this class is used to create and handle pop-up notifications of the app, it has functions to create new notification, and manage actived notificaions

Returns

None

check_active_notifs()

on every notification creation, this function is called to check the states of previous notifications, and if the last notification is deactivated/finished, it must be removed from the actived notifications list

Returns

None

create_new_notif(*message=""*, *win_color=None*, *font_size=None*, *font_style=None*, *level=0*)

this function is used to create a new pop-up notification, by taking as input the notification message and some other params

Parameters

- **message** - the notification message (in string)
- **win_color** - color of the window (same as the main app default color)
- **font_size** - font size of the message (same as the main app default)
- **font_style** - font style of the message (same as the main app default)
- **level** - the level of the message, in range of [0, 2], determinnig statues and importance of the message: 0: good statues, only notification 1: warning message 2: error message

Returns

None

`oxin.notif_UI.rearange_active_notifes()`

on every call of this function, all notifications in notification list are checked, and if a notifiacton is deactivated (finished), the other actived notifications rearranged and moved to take right position

Returns

None

setting_UI module

class `oxin.setting_UI.UI_main_window`

Bases: `QMainWindow`, `Ui_MainWindow`

activate_()

This function will activate ui operating buttons and connect theme to their functions

Returns

None

animation_move(*label_name*, *lenght*)

this function is used to shiw/hide an element (frame) with an sliding effect

Returns

None

buttonClick()

this function will connect each button in ui to its function

Returns

None

change_camera_btn_icon(*camera_id*, *active=False*)

this function is used to change the current camera icon in camera settings page

Parameters

- **camera_id** - id of the cameras (in string)
- **active** - a boolean value determining wheater the camera is selected or deselected

Returns

None

check_box_state(*b*)

this function is used to change checkbox text to enable/disable by checkbox state

Parameters

b - checkbox element

Returns

None

clear_line_edits(*line_edits*)

this function is used to clear the linedit texts

Returns

None

close_app_force(*message='An Error occured while runnung the app',
change_language=False*)

this function closes the app in force situations (app errors or excetions), also a log will be written determining the cause for closing the app, and an alert window will be appeared to warn the app closing

Parameters

- **message** - message to log on app close (in string)
- **change_language** - a boolean determines if the app close is for changing the app language

Returns

None

close_win()

this function closes the app

Returns

None

combo_image_preccess(*s*)

disable_camera_settings()

this function will disable all camera params fileds in camera setting page, on camera disable/change or stackwidjet change

Returns

None

get_image_processing_parms()

this function is used to take and return entered image calibration parms of Miss.Abtahi algo from ui

Returns

dict{block_size, defect, noise, noise_flag}

get_label(*label_name*)

this function is used to take and return the text content of a label elemnt

Parameters**label_name** - name of label element**Returns**

None

get_plc_ip()

this function takes anf returns input PLC IP from ui

Returns

PLC ip: (in string)

get_plc_parms()

this function will take and :returns: the input PLC parameters and addreses from ui

Returns

dict: {limitswitch_top_plc, limitswitch_bottom_plc, thermometer_min_plc, thermometer_max_plc, cooler_uptime_plc, system_operating_plc, air_valve_plc, camera_limit_plc':[camera_limit_path, -1, -1], camera_frate_plc, projector_limit_plc, detect_sensor_plc

get_user_pass()

this function is used to get and return entered username and password from login window

Returns

username: in string

Returns

password: in string

get_width_guage_parms()

this function will returns the user slected camera in calibration page

Return: camrera id (in string)

leftmenu()

this function s used to show/hide the left side bar with an sliding effect

Returns

None

maximize_minimize()

this function chages the window size of app

Returns

None

minimize_win()

this function minimizes the app to taskbar

Returns

None

mouseMoveEvent(*self, event: PySide6.QtGui.QMouseEvent*) → None

mousePressEvent(*self, event: PySide6.QtGui.QMouseEvent*) → None

mouseReleaseEvent(*self, event: PySide6.QtGui.QMouseEvent*) → None

selected_camera(*s*)

this function is used to change the camera icon in calibration page

Parameters

s – id of camera (in int)

Returns

None

set_button_enable_or_disable(*names, enable=True*)

this function will enable or disable all the ui elements in the input list

Parameters

- **names** – ui elements (in list)
- **enable** – a boolean value determining whether to enable/disable the elements

set_checkboxes()

this function is used to connect checkboxes in ui to their functions

Returns

None

set_combo_boxes()

this function is used to set the content of comboboxes in ui

Returns

None

set_default_image_process(*value*)

set_image_label(*label_name, img*)

this function is used to set/fit an image to a label element

Parameters

- **label_name** – name of the label element
- **img** – input image to fit/set to label

Returns

None

set_image_processing_params_to_ui(*image_processing_params*)

this function is used to take and return entered image calibration params of Miss.Abtahi algo from ui

Returns

dict{block_size, defect, noise, noise_flag}

set_label(*label_name, msg, color='black'*)

this function will set a text message to a label element, with text color

Parameters

- **label_name** – label element name
- **msg** – input message (in string)

- **color** – message/text color (in string, html code or color name)

Returns

None

set_login_message(*text, color*)

this function is used to set login message on login window

Parameters

- **text** – message to show (in string)
- **color** – color of the message text (in string, html code without #, or color name)

Returns

None

set_plc_ip(*text*)

this function will set input PLC IP from database to ui field

Parameters**text** – PLC ip (in string)**Returns**

None

set_size(*frame_name, size, minimum=False, maximum=False*)

this function is used to set maximum or minimum height for an element (frame)in ui

Parameters

- **frame_name** – name of frame element
- **size** – height/size of elemen
- **minimum** – a boolean value determning wheater the input height/size is minimumheight or not
- **maximum** – a boolean value determning wheater the input height/size is maximumheight or not if both minimum and maximum be False, the size will be applied as both minimumheight and maximumheight

Returns

None

set_sliders()

this function is used to connect siders in ui to their functions

Returns

None

show_mesaggess(*label_name, text="", level=0, clearable=True, prefix=True*)

this function is used to show input message in input label, also there is a message level determining the color of label, and a timer to clear meesage after a while

Parameters

- **label_name** – label element name to show the message in
- **text** – input message to show (in string)
- **level** – level of the message (in int), its a value between [0, 2] determining the bakground color of message label

- **clearable** - a boolean value determining whater to clear the message after timeout or not
- **prefix** - a boolean value determininign wheater to show the message prefix or not

Returns

None

show_value(*value*)

this function is used to show slider value in an label/textbox

Parameters

value - value of the slider (in int)

Returns

None

staticMetaObject = <PySide6.QtCore.QMetaObject object>

translate_headers_list(*header_list*)

this function is used to translate table headers or generally, all texts in and list, to ui default language

Parameters

header_list - a list of texts that will be translated

Returns

header_list: translated list of texts

translate_ui()

This function translate ui to selected language in settings page

Returns

None

setting_api module

class oxin.setting_api.**API**(*ui*)

Bases: object

the API class has the main functionalities of oxin setting app, it takes as input the ui object, and other ui objects like login window, alert window and notification windows are initialized in this class

Parameters

ui - the ui file of the app

Returns

None

add_defect(*default_defect={}*)

this function is used to add a new defect returned from ui to database. it is also used to add/update edited defect on dataabse

Parameters

default_defect - (dict, optional) if not empty, it is used as new defect to add to database, else the new defect info is returned from ui. Defaults to {}.

Returns

None

add_defect_group(*default_defectgroup*={})

this function is used to add a defect group returned from ui/user to database.

Parameters**default_defectgroup** - (dict, optional) if not empty, it is used as input to add to database if not, the info returned from ui is used. Defaults to {}.**Returns**

None

add_user(*default_user*={})

this function is used to add new user to database. the user info is returned from ui, and used as input to add to database

Parameters**default_user** - (dict, optional) if not empty, this dict is use as input to add to database. if empty, new user_infos are get from ui**Returns**

None

apply_calibration_on_image(*image*)

this function is used to apply soft-calibration on image and then update results on ui

Parameters**image** - (_type_) input calibration image from camera**Returns**

None

apply_changed_appearance_params(*mode*='appearance')

this functino is used to apply returned setting parameters in setting page, to app/database according to mode. we can select which parameters to apply/set

Parameters**mode** - (str, optional): it is used to select which parameters to apply/set. Defaults to 'appearance'. 'appearance': apply appearance params like font, color or ... 'calibration': apply calibration params 'imageprocessing': apply image preprocessing parasms 'multitasking': 'defects':**Returns**

None

button_connector()

this function is used to connect ui buttons to their functions

Returns

None

check_all_plc_parms()

this function is used to check all plc logic pathes values

Returns

values: a dict of plc values

check_plc_parms(*name*)

this function is used to check/get value of a path on plc

Parameters

name - (*_type_*) check button name of the path

Returns

value: value stored in path

check_storage_status()

this function is used to check storage statues

Returns

None

confirm_yes()

this function is the event for confirm window yes button, according to message of the confirm window, the function decides to take right action

Returns

None

connect_disconnect_to_camera(*calibration=False*)

this function is used to connect/disconnect to camera

Parameters

calibration - a boolean determining if the current page is calibration page

Returns

None

connect_plc()

this function is used to connect to plc

Returns

None

control_list_image(*input_img_path*)

this function is used to load image processing directory containing images

Parameters

input_img_path (*str*) - input image directory

Returns

None

disconnect_camera_on_ui_change()

this function is used to disconnect camera if any of camera parameters in camera setting page are changed, or stackwidget current page change

Returns

None

disconnect_plc(*on_close=False*)

this function is used to disconnect from plc

Parameters

on_close - (bool, optional) a boolean determining if function is called on app close. Defaults to False.

edit_defects(*defect_group=False*)

this function is used to edit selected defect/defect-group and change its parameters

Parameters

defect_group – (bool, optional) a boolean determining whether to edit defect-group. Defaults to False.

Returns

None

filter_defects(*defect_group=False*)

this function is used to filter/search in defect table

Parameters

defect_group – (bool, optional) a boolean determining whether to search in defect-groups. Defaults to False.

Returns

None

force_clear_camera_live_storage()

this function is used to make True the flag for force clearing storage

Returns

None

image_processing_calibration(*params_changed=False*)

this function is used to apply image processing algo on input image

Parameters

params_changed – (bool, optional) a boolean to determine if algo params changed. Defaults to False.

Returns

None

load_appearance_params_on_start(*mainsetting_page=False*)

this function is used to load appearance params from database and apply to program on start-up or function call

Parameters

mainsetting_page – (bool, optional) a boolean determining whether on mainsetting page or not. Defaults to False.

Returns

None

load_camera_params_from_db_to_UI()

this function is used every time a camera is selected in camera settings page, and tries to load camera settings and parameters of that camera from database. at every camera selection, the previous camera will be disconnected if it is connected

Returns

None

load_plc_params()

this function is used to load plc params from database, and set to ui plc page

Returns

result: a boolean determining if params loaded from database

next_image_processing()

this function is used to load next image for image processing calibration

Returns

None

on_close_operations()

this function is used to check/do some functions before closing the app

Returns

None

previous_image_preprocessing()

this function is used to load prev image for image processing calibration

Returns

None

refresh_dashboard_page()

this function is used to do some tasks that are related to dashboard page. the tasks are almost the dashboard parameters

Returns

None

refresh_defects_table(*only_defects=False, only_defect_groups=False*)

this function is used to refresh defect/defect-group tables from database to ui tables

Parameters

- **only_defects** - a boolean determining only update defect table
- **only_defect_groups** - a boolean determining only update defect-groups table

Returns

None

refresh_storage_page(*only_chart=False*)

this function is used to refresh storage page

Parameters

only_chart - (bool, optional) if true, only the storage chart is updated. Defaults to False.

refresh_users_table()

this function is used to refresh users table on ui

Returns

None

remove_defects(*defect_group=False*)

this function is used to remove selected defects/defect groups from database

Parameters

defect_group - (bool, optional) a boolean determining whether to remove defect_groups or not. Defaults to False.

Returns

None

remove_users()

this function is used to remove selected users in ui users table, from database

Returns

None

run_storage_check_timer(*storage_check_interval=60, stop=False*)

this function is used to initailize and run timer for checking storage statues

Parameters

- **storage_check_interval** – (int, optional) check interval (in seconds). Defaults to 60.
- **stop** – (bool, optional) a boolean determining to stop the timer. Defaults to False.

Returns

None

save_changed_calibration_params()

this function is used to update camera calibration params to database. the input params are returned from ui

Returns

None

save_changed_camera_params(*apply_to_multiple=False*)

save input camera parameters entered on UI camera setting page to database

Parameters**apply_to_multiple** – a boolean determining wheter apply settings to multiple cameras or only current camera**Returns**

None

save_image_processing_parms()

this function is used to save image processing params from Miss.Abtahi algo to database

Returns

None

save_plc_ip()

this function is used to get plc ip from ui and update on database

Returns

None

save_plc_parms()

this function is used to save plc params to database

Returns

None

select_image_procesing_directory()

this function is used to select image processing drectory containg images to fix image processing params with

Returns

None

set_plc_ip_to_ui()

this function is used to get plc ip from database and set to ui

Returns

None

set_plc_value()

this function is used to update/set a path calue on plc

Returns

None

show_camera_picture(*calibration=False*)

this function is used to start image grabbing from camera, and update image on ui

Parameters

calibration - a boolean detrmining if current page is calibration or not

Returns

None

show_related_defects()

this function is used to show related defects to a selected defect-group

Returns

None

tabledefectgroups_onHeaderClicked(*logicalIndex*)

this function is used to sort items accoading to one column, if clicked on that column

Parameters

logicalIndex - (*_type_*) *_description_*

Returns

None

tabledefects_onHeaderClicked(*logicalIndex*)

this function is used to sort items accoading to one column, if clicked on that column

Parameters

logicalIndex - (*_type_*) *_description_*

Returns

None

things_to_do_on_stackwidjet_change()

this function performs tasks needed to done on ui stackwidjet (page) change

Returns

None

update_camera_live_storage_parms()

this function is used to update/set defalt storage params returned from ui, to database

Returns

None

update_path_plc()

this function is used to get value of a path on plc, everytime pathes-combobox has changed

Returns

None

update_plc_dashboard_parms()

this function is used to update plc summary satues on dashboard

Returns

None

write_parms()**translate_ui module**

```
oxin.translate_ui.translate_ui(language='fa', ui_file_path_en='main_window.ui',  
                               ui_file_path_fa='main_window_fa.ui')
```

This function takes as input the default english version ui file, and translate it to input language

Parameters

- **language** - input language to translate ui to (in string), default is fa (stands for farsi/persian)
- **ui_file_path_en** - path of the default english ui file (in string)
- **ui_file_path_fa** - path of the output translated ui file to save (in string)

Returns

None

4

Others

Indices and tables

- `genindex`
- `modindex`
- `search`

Python Module Index

O

oxin.app_settings, 40
oxin.backend.add_default_database_records, 10
oxin.backend.camera_connection, 17
oxin.backend.camera_funcs, 10
oxin.backend.chart_funcs, 18
oxin.backend.date_funcs, 19
oxin.backend.defect_management_funcs, 19
oxin.backend.logging_funcs, 25
oxin.backend.mainsetting_funcs, 25
oxin.backend.plc_managment, 28
oxin.backend.pxvalue_calibration, 29
oxin.backend.storage_funcs, 32
oxin.backend.user_login_logout_funcs, 34
oxin.backend.user_management_funcs, 35
oxin.calibrationCal.Division, 37
oxin.calibrationCal.load_recent_images, 37
oxin.calibrationCal.main, 37
oxin.calibrationCal.Noise, 37
oxin.calibrationCal.Preprocessing, 37
oxin.calibrationCal.SteelSurfaceInspection, 38
oxin.calibrationCal.Variance, 38
oxin.confirm_UI, 40
oxin.confirm_window, 41
oxin.database, 41
oxin.database_utils, 43
oxin.error_window, 49
oxin.login_api, 50
oxin.login_UI, 49
oxin.notif_UI, 51
oxin.setting_api, 58
oxin.setting_UI, 53
oxin.translate_ui, 65
oxin.utils.move_on_list, 39

Index

A

`activate_()` (*oxin.confirm_UI.UI_main_window* method), 40
`activate_()` (*oxin.confirm_window.UI_confirm_window* method), 41
`activate_()` (*oxin.error_window.UI_error_window* method), 49
`activate_()` (*oxin.login_UI.UI_main_window* method), 49
`activate_()` (*oxin.notif_UI.UI_main_window* method), 51
`activate_()` (*oxin.setting_UI.UI_main_window* method), 53
`add()` (*oxin.utils.move_on_list.moveOnList* method), 39
`add_defect()` (*oxin.database_utils.dataBaseUtils* method), 43
`add_defect()` (*oxin.setting_api.API* method), 58
`add_defect_group()` (*oxin.database_utils.dataBaseUtils* method), 44
`add_defect_group()` (*oxin.setting_api.API* method), 59
`add_new_defect_to_db()` (in module *oxin.backend.defect_management_funcs*), 19
`add_new_user_to_db()` (in module *oxin.backend.user_management_funcs*), 35
`add_record()` (*oxin.database.dataBase* method), 41
`add_user()` (*oxin.database_utils.dataBaseUtils* method), 44
`add_user()` (*oxin.setting_api.API* method), 59
`animation_move()` (*oxin.setting_UI.UI_main_window* method), 53
API (class in *oxin.login_api*), 50
API (class in *oxin.setting_api*), 58
`app_logger` (class in *oxin.backend.logging_funcs*), 25
`apply_appearance_params_to_program()` (in module *oxin.backend.mainsetting_funcs*), 25
`apply_calibration_on_image()` (*oxin.setting_api.API* method), 59
`apply_changed_appearance_params()` (*oxin.setting_api.API* method), 59
`apply_pxvalue_calibration()` (in module

oxin.backend.pxvalue_calibration), 29
`apply_soft_calibrate_on_image()` (in module *oxin.backend.camera_funcs*), 10
`assign_appearance_existing_params_to_ui()` (in module *oxin.backend.mainsetting_funcs*), 26
`assign_existing_defect_colors_to_ui()` (in module *oxin.backend.defect_management_funcs*), 19
`assign_existing_serials_to_ui()` (in module *oxin.backend.camera_funcs*), 10
`authenticate_user()` (in module *oxin.backend.user_login_logout_funcs*), 34

B

`build_next_func()` (*oxin.utils.move_on_list.moveOnList* method), 39
`build_prev_func()` (*oxin.utils.move_on_list.moveOnList* method), 39
`button_connector()` (*oxin.login_api.API* method), 51
`button_connector()` (*oxin.setting_api.API* method), 59
`buttonClick()` (*oxin.confirm_UI.UI_main_window* method), 40
`buttonClick()` (*oxin.login_UI.UI_main_window* method), 49
`buttonClick()` (*oxin.notif_UI.UI_main_window* method), 51
`buttonClick()` (*oxin.setting_UI.UI_main_window* method), 53

C

`change_camera_btn_icon()` (*oxin.setting_UI.UI_main_window* method), 53
`change_defect_group_id_to_name()` (in module *oxin.backend.defect_management_funcs*), 20
`check()` (*oxin.utils.move_on_list.moveOnList* method), 39
`check_active_notifs()` (*oxin.notif_UI.notification_manager* method), 52

[check_all_plc_parms\(\)](#) (*oxin.setting_api.API method*), 59
[check_appear_done\(\)](#) (*oxin.notif_UI.UI_main_window method*), 51
[check_box_state\(\)](#) (*oxin.setting_UI.UI_main_window method*), 54
[check_connection\(\)](#) (*oxin.database.dataBase method*), 41
[check_plc_parms\(\)](#) (*oxin.setting_api.API method*), 59
[check_storage_status\(\)](#) (*oxin.setting_api.API method*), 60
[clear_line_edits\(\)](#) (*oxin.setting_UI.UI_main_window method*), 54
[close_app_force\(\)](#) (*oxin.setting_UI.UI_main_window method*), 54
[close_win\(\)](#) (*oxin.confirm_UI.UI_main_window method*), 40
[close_win\(\)](#) (*oxin.confirm_window.UI_confirm_window method*), 41
[close_win\(\)](#) (*oxin.error_window.UI_error_window method*), 49
[close_win\(\)](#) (*oxin.login_UI.UI_main_window method*), 49
[close_win\(\)](#) (*oxin.notif_UI.UI_main_window method*), 51
[close_win\(\)](#) (*oxin.setting_UI.UI_main_window method*), 54
[close_win_2\(\)](#) (*oxin.notif_UI.UI_main_window method*), 51
[Collector](#) (*class in oxin.backend.camera_connection*), 17
[combo_image_preccess\(\)](#) (*oxin.setting_UI.UI_main_window method*), 54
[confirm_yes\(\)](#) (*oxin.setting_api.API method*), 60
[connect\(\)](#) (*oxin.database.dataBase method*), 41
[connect_disconnect_camera\(\)](#) (*in module oxin.backend.camera_funcs*), 11
[connect_disconnect_to_camera\(\)](#) (*oxin.setting_api.API method*), 60
[connect_plc\(\)](#) (*oxin.setting_api.API method*), 60
[connection\(\)](#) (*oxin.backend.plc_managment.management method*), 28
[control_list_image\(\)](#) (*oxin.setting_api.API method*), 60
[convert_cv2_to_qt_image\(\)](#) (*in module oxin.backend.camera_funcs*), 11
[create_dailyfolder\(\)](#) (*oxin.backend.logging_funcs.app_logger method*), 25
[create_default_records\(\)](#) (*in module oxin.backend.add_default_database_records*), 10
[create_drive_barchart_on_ui\(\)](#) (*in module oxin.backend.chart_funcs*), 18
[create_mainfolder\(\)](#) (*oxin.backend.logging_funcs.app_logger method*), 25
[create_new_log\(\)](#) (*oxin.backend.logging_funcs.app_logger method*), 25
[create_new_notif\(\)](#) (*oxin.notif_UI.notification_manager method*), 53
[CreateHeatmap\(\)](#) (*in module*

oxin.calibrationCal.SteelSurfaceInspection), 38

D

[dataBase](#) (*class in oxin.database*), 41
[dataBaseUtils](#) (*class in oxin.database_utils*), 43
[delete\(\)](#) (*oxin.database.dataBase method*), 42
[disable_camera_settings\(\)](#) (*oxin.setting_UI.UI_main_window method*), 54
[disconnect\(\)](#) (*oxin.backend.plc_managment.management method*), 28
[disconnect_camera_on_ui_change\(\)](#) (*oxin.setting_api.API method*), 60
[disconnect_plc\(\)](#) (*oxin.setting_api.API method*), 60
[draw_contour\(\)](#) (*in module oxin.backend.pxvalue_calibration*), 29
[draw_grid\(\)](#) (*in module oxin.backend.camera_funcs*), 11
[draw_rect\(\)](#) (*in module oxin.backend.pxvalue_calibration*), 29
[draw_rects\(\)](#) (*oxin.backend.pxvalue_calibration.extract_info method*), 30

E

[EdgeDetection\(\)](#) (*in module oxin.calibrationCal.Preprocessing*), 37
[edit_defects\(\)](#) (*oxin.setting_api.API method*), 60
[error_window\(\)](#) (*oxin.backend.camera_connection.Collector method*), 17
[execute_quary\(\)](#) (*oxin.database.dataBase method*), 42
[extract_info](#) (*class in oxin.backend.pxvalue_calibration*), 30

F

[filter_acc\(\)](#) (*oxin.backend.pxvalue_calibration.extract_info method*), 30
[filter_contours_by_accuracy\(\)](#) (*oxin.backend.pxvalue_calibration.extract_info method*), 30
[filter_contours_by_area\(\)](#) (*oxin.backend.pxvalue_calibration.extract_info method*), 31
[filter_defects\(\)](#) (*oxin.setting_api.API method*), 61
[final_decision\(\)](#) (*oxin.backend.pxvalue_calibration.extract_info method*), 31
[find_contours\(\)](#) (*oxin.backend.pxvalue_calibration.extract_info method*), 31
[FindDefectiveBlocks\(\)](#) (*in module oxin.calibrationCal.SteelSurfaceInspection*), 38
[force_clear_camera_live_storage\(\)](#) (*oxin.setting_api.API method*), 61

G

[generate_defect_colors\(\)](#) (*in module oxin.backend.defect_management_funcs*), 20

get_all_content() (oxin.database.dataBase method), 42
 get_appearance_params_from_ui() (in module oxin.backend.mainsetting_funcs), 26
 get_available_cameras_list_serial_numbers() (in module oxin.backend.camera_funcs), 12
 get_available_drives() (in module oxin.backend.storage_funcs), 32
 get_calibration_params_from_ui() (in module oxin.backend.mainsetting_funcs), 26
 get_cam() (oxin.backend.camera_connection.Collector method), 17
 get_camera_calibration_params_from_db() (in module oxin.backend.camera_funcs), 12
 get_camera_calibration_params_from_ui() (in module oxin.backend.camera_funcs), 12
 get_camera_checkbox_values() (in module oxin.backend.camera_funcs), 12
 get_camera_id() (in module oxin.backend.camera_funcs), 12
 get_camera_live_drive_parameters_from_db() (in module oxin.backend.storage_funcs), 32
 get_camera_live_drive_parameters_from_ui() (in module oxin.backend.storage_funcs), 32
 get_camera_params_from_db() (in module oxin.backend.camera_funcs), 12
 get_camera_params_from_ui() (in module oxin.backend.camera_funcs), 13
 get_col_name() (oxin.database.dataBase method), 42
 get_count() (oxin.utils.move_on_list.moveOnList method), 39
 get_current() (oxin.utils.move_on_list.moveOnList method), 39
 get_dataset_path() (oxin.database_utils.dataBaseUtils method), 44
 get_date() (in module oxin.backend.date_funcs), 19
 get_datetime() (in module oxin.backend.date_funcs), 19
 get_defect_info_from_ui() (in module oxin.backend.defect_management_funcs), 20
 get_defects_from_db() (in module oxin.backend.defect_management_funcs), 21
 get_defects_params_from_ui() (in module oxin.backend.mainsetting_funcs), 26
 get_drivename() (in module oxin.backend.storage_funcs), 32
 get_files_in_path() (in module oxin.backend.storage_funcs), 32
 get_filtered_defects_from_db() (in module oxin.backend.defect_management_funcs), 21
 get_image_processing_parms() (oxin.setting_UI.UI_main_window method), 54
 get_image_processing_params_from_ui() (in module oxin.backend.mainsetting_funcs), 26
 get_image_processing_parms() (oxin.database_utils.dataBaseUtils method), 44
 get_label() (oxin.setting_UI.UI_main_window method), 55
 get_list() (oxin.utils.move_on_list.moveOnList method), 40
 get_log() (oxin.database.dataBase method), 42
 get_mainsetting_params_from_db() (in module oxin.backend.mainsetting_funcs), 26
 get_multitasking_params_from_ui() (in module oxin.backend.mainsetting_funcs), 27
 get_picture_from_camera() (in module oxin.backend.camera_funcs), 13
 get_plc_ip() (oxin.setting_UI.UI_main_window method), 55
 get_plc_parms() (oxin.setting_UI.UI_main_window method), 55
 get_selected_defect_groups() (in module oxin.backend.defect_management_funcs), 21
 get_selected_defects() (in module oxin.backend.defect_management_funcs), 21
 get_selected_users() (in module oxin.backend.user_management_funcs), 35
 get_storage_status() (in module oxin.backend.storage_funcs), 32
 get_threading() (in module oxin.backend.camera_connection), 17
 get_time() (in module oxin.backend.date_funcs), 19
 get_user_info_from_ui() (in module oxin.backend.user_management_funcs), 35
 get_user_pass() (oxin.login_UI.UI_main_window method), 50
 get_user_pass() (oxin.setting_UI.UI_main_window method), 55
 get_users_from_db() (in module oxin.backend.user_management_funcs), 35
 get_value() (oxin.backend.plc_managment.management method), 28
 get_width_guage_parms() (oxin.setting_UI.UI_main_window method), 55
 getPictures() (oxin.backend.camera_connection.Collector method), 17

I
 image_processing_calibration() (oxin.setting_api.API method), 61
 ImageBlockVariance() (in module oxin.calibrationCal.Variance), 38
 ImageDivision() (in module oxin.calibrationCal.Division), 37
 ImageEnhancement() (in module oxin.calibrationCal.Preprocessing), 37
 ImageSmoothness() (in module oxin.calibrationCal.Preprocessing), 37
 ip_validation() (in module oxin.backend.camera_funcs), 13

L
 leftmenu() (oxin.setting_UI.UI_main_window method), 55
 listDevices() (oxin.backend.camera_connection.Collector method), 17
 load_appearance_params_on_start() (oxin.setting_api.API method), 61

load_cam_params() (oxin.database_utils.dataBaseUtils method), 44
load_camera_params_from_db_to_UI() (oxin.setting_api.API method), 61
load_defect_groups() (oxin.database_utils.dataBaseUtils method), 44
load_defects() (oxin.database_utils.dataBaseUtils method), 44
load_defects_from_db() (in module oxin.backend.defect_management_funcs), 22
load_general_setting_params() (oxin.database_utils.dataBaseUtils method), 44
load_plc_ip() (oxin.database_utils.dataBaseUtils method), 45
load_plc_params() (oxin.database_utils.dataBaseUtils method), 45
load_plc_params() (oxin.setting_api.API method), 61
load_recent_images() (in module oxin.calibrationCal.load_recent_images), 37
load_users() (oxin.database_utils.dataBaseUtils method), 45
login() (oxin.login_api.API method), 51
logout_user() (in module oxin.backend.user_login_logout_funcs), 34

M

management (class in oxin.backend.plc_managment), 28
maximize_minimize() (oxin.setting_UI.UI_main_window method), 55
minimize_win() (oxin.setting_UI.UI_main_window method), 55
module
 oxin.app_settings, 40
 oxin.backend.add_default_database_records, 10
 oxin.backend.camera_connection, 17
 oxin.backend.camera_funcs, 10
 oxin.backend.chart_funcs, 18
 oxin.backend.date_funcs, 19
 oxin.backend.defect_management_funcs, 19
 oxin.backend.logging_funcs, 25
 oxin.backend.mainsetting_funcs, 25
 oxin.backend.plc_managment, 28
 oxin.backend.pxvalue_calibration, 29
 oxin.backend.storage_funcs, 32
 oxin.backend.user_login_logout_funcs, 34
 oxin.backend.user_management_funcs, 35
 oxin.calibrationCal.Division, 37
 oxin.calibrationCal.load_recent_images, 37
 oxin.calibrationCal.main, 37
 oxin.calibrationCal.Noise, 37
 oxin.calibrationCal.Preprocessing, 37
 oxin.calibrationCal.SteelSurfaceInspection, 38
 oxin.calibrationCal.Variance, 38
 oxin.confirm_UI, 40
 oxin.confirm_window, 41
 oxin.database, 41
 oxin.database_utils, 43

 oxin.error_window, 49
 oxin.login_api, 50
 oxin.login_UI, 49
 oxin.notif_UI, 51
 oxin.setting_api, 58
 oxin.setting_UI, 53
 oxin.translate_ui, 65
 oxin.utils.move_on_list, 39
mouseMoveEvent() (oxin.error_window.UI_error_window method), 49
mouseMoveEvent() (oxin.setting_UI.UI_main_window method), 55
mousePressEvent() (oxin.error_window.UI_error_window method), 49
mousePressEvent() (oxin.setting_UI.UI_main_window method), 55
mouseReleaseEvent() (oxin.error_window.UI_error_window method), 49
mouseReleaseEvent() (oxin.setting_UI.UI_main_window method), 56
moveOnList (class in oxin.utils.move_on_list), 39

N

new_defect_info_validation() (in module oxin.backend.defect_management_funcs), 22
new_user_info_validation() (in module oxin.backend.user_management_funcs), 35
next_image_precessing() (oxin.setting_api.API method), 61
next_on_list() (oxin.utils.move_on_list.moveOnList method), 40
NoiseDetection() (in module oxin.calibrationCal.Noise), 37
notification_manager (class in oxin.notif_UI), 52

O

on_close_operations() (oxin.setting_api.API method), 62
oxin.app_settings module, 40
oxin.backend.add_default_database_records module, 10
oxin.backend.camera_connection module, 17
oxin.backend.camera_funcs module, 10
oxin.backend.chart_funcs module, 18
oxin.backend.date_funcs module, 19
oxin.backend.defect_management_funcs module, 19
oxin.backend.logging_funcs module, 25
oxin.backend.mainsetting_funcs module, 25
oxin.backend.plc_managment module, 28
oxin.backend.pxvalue_calibration module, 29
oxin.backend.storage_funcs module, 32

oxin.backend.user_login_logout_funcs
 module, 34
 oxin.backend.user_management_funcs
 module, 35
 oxin.calibrationCal.Division
 module, 37
 oxin.calibrationCal.load_recent_images
 module, 37
 oxin.calibrationCal.main
 module, 37
 oxin.calibrationCal.Noise
 module, 37
 oxin.calibrationCal.Preprocessing
 module, 37
 oxin.calibrationCal.SteelSurfaceInspection
 module, 38
 oxin.calibrationCal.Variance
 module, 38
 oxin.confirm_UI
 module, 40
 oxin.confirm_window
 module, 41
 oxin.database
 module, 41
 oxin.database_utils
 module, 43
 oxin.error_window
 module, 49
 oxin.login_api
 module, 50
 oxin.login_UI
 module, 49
 oxin.notif_UI
 module, 51
 oxin.setting_api
 module, 58
 oxin.setting_UI
 module, 53
 oxin.translate_ui
 module, 65
 oxin.utils.move_on_list
 module, 39

P

prev_on_list() (oxin.utils.move_on_list.moveOnList
 method), 40
 previous_image_precessing() (oxin.setting_api.API
 method), 62
 progressbar() (oxin.notif_UI.UI_main_window
 method), 51

R

rearrange_active_notifes() (in module
 oxin.notif_UI), 53
 refresh_dashboard_page() (oxin.setting_api.API
 method), 62
 refresh_defects_table() (oxin.setting_api.API
 method), 62
 refresh_storege_page() (oxin.setting_api.API
 method), 62
 refresh_users_table() (oxin.setting_api.API
 method), 62
 remove_defect_groups()
 (oxin.database_utils.dataBaseUtils method),
 45

remove_defects()
 (oxin.database_utils.dataBaseUtils method),
 45
 remove_defects() (oxin.setting_api.API method), 62
 remove_defects_by_group_id()
 (oxin.database_utils.dataBaseUtils method),
 45
 remove_defects_from_db() (in module
 oxin.backend.defect_management_funcs),
 22
 remove_old_files_in_directory() (in module
 oxin.backend.storage_funcs), 33
 remove_record() (oxin.database.dataBase method),
 42
 remove_users() (oxin.database_utils.dataBaseUtils
 method), 45
 remove_users() (oxin.setting_api.API method), 62
 remove_users_from_db() (in module
 oxin.backend.user_management_funcs), 36
 report_last() (oxin.database.dataBase method), 43
 rotate_calibration_image() (in module
 oxin.backend.camera_funcs), 13
 run_login_window() (in module
 oxin.backend.user_login_logout_funcs), 34
 run_storage_check_timer() (oxin.setting_api.API
 method), 63

S

save_changed_calibration_params()
 (oxin.setting_api.API method), 63
 save_changed_camera_params()
 (oxin.setting_api.API method), 63
 save_image_processing_parms()
 (oxin.setting_api.API method), 63
 save_plc_ip() (oxin.setting_api.API method), 63
 save_plc_parms() (oxin.setting_api.API method), 63
 search() (oxin.database.dataBase method), 43
 search_camera_by_ip()
 (oxin.database_utils.dataBaseUtils method),
 46
 search_camera_by_serial()
 (oxin.database_utils.dataBaseUtils method),
 46
 search_defect_by_color()
 (oxin.database_utils.dataBaseUtils method),
 46
 search_defect_by_filter()
 (oxin.database_utils.dataBaseUtils method),
 46
 search_defect_by_group_id()
 (oxin.database_utils.dataBaseUtils method),
 46
 search_defect_by_id()
 (oxin.database_utils.dataBaseUtils method),
 46
 search_defect_by_name()
 (oxin.database_utils.dataBaseUtils method),
 46
 search_defect_by_short_name()
 (oxin.database_utils.dataBaseUtils method),
 47
 search_defect_group_by_filter()
 (oxin.database_utils.dataBaseUtils method),
 47
 search_defect_group_by_id()
 (oxin.database_utils.dataBaseUtils method),
 47

```

search_defect_group_by_name()
    (oxin.database_utils.dataBaseUtils method),
    47
search_user() (oxin.database_utils.dataBaseUtils
    method), 47
search_user_by_user_name()
    (oxin.database_utils.dataBaseUtils method),
    47
select_image_procesing_directory()
    (oxin.setting_api.API method), 63
selected_camera() (oxin.setting_UI.UI_main_window
    method), 56
serialnumber()
    (oxin.backend.camera_connection.Collector
    method), 17
set_app_buttons_enable_or_disable() (in module
    oxin.backend.user_login_logout_funcs), 35
set_appearance_params_to_ui() (in module
    oxin.backend.mainsetting_funcs), 27
set_button_enable_or_disable()
    (oxin.setting_UI.UI_main_window method),
    56
set_camera_calibration_params_to_db() (in
    module oxin.backend.camera_funcs), 13
set_camera_calibration_params_to_ui() (in
    module oxin.backend.camera_funcs), 13
set_camera_live_drive_parameters_to_db() (in
    module oxin.backend.storage_funcs), 33
set_camera_params_to_db() (in module
    oxin.backend.camera_funcs), 14
set_camera_params_to_ui() (in module
    oxin.backend.camera_funcs), 14
set_camera_picture_to_ui() (in module
    oxin.backend.camera_funcs), 14
set_camera_serial_to_ui() (in module
    oxin.backend.camera_funcs), 15
set_checkboxes() (oxin.setting_UI.UI_main_window
    method), 56
set_combo_boxes() (oxin.setting_UI.UI_main_window
    method), 56
set_current_user()
    (oxin.backend.logging_funcs.app_logger
    method), 25
set_default_image_process()
    (oxin.setting_UI.UI_main_window method),
    56
set_defect_group_info_on_ui() (in module
    oxin.backend.defect_management_funcs),
    23
set_defect_groups_on_combo() (in module
    oxin.backend.defect_management_funcs),
    23
set_defect_groups_on_ui() (in module
    oxin.backend.defect_management_funcs),
    23
set_defect_info_on_ui() (in module
    oxin.backend.defect_management_funcs),
    23
set_defects_on_ui() (in module
    oxin.backend.defect_management_funcs),
    23
set_file_name()
    (oxin.backend.plc_managment.management
    method), 28
set_image_label() (oxin.setting_UI.UI_main_window
    method), 56
set_image_processing_parms_to_ui()
    (oxin.setting_UI.UI_main_window method),
    56
set_image_processing_parms()
    (oxin.database_utils.dataBaseUtils method),
    48
set_label() (oxin.setting_UI.UI_main_window
    method), 56
set_language()
    (oxin.confirm_window.UI_confirm_window
    method), 41
set_login_message() (oxin.login_UI.UI_main_window
    method), 50
set_login_message()
    (oxin.setting_UI.UI_main_window method),
    57
set_mainsetting_params_to_db() (in module
    oxin.backend.mainsetting_funcs), 27
set_plc_ip() (oxin.setting_UI.UI_main_window
    method), 57
set_plc_ip_to_ui() (oxin.setting_api.API method),
    63
set_plc_value() (oxin.setting_api.API method), 64
set_size() (oxin.setting_UI.UI_main_window
    method), 57
set_sliders() (oxin.setting_UI.UI_main_window
    method), 57
set_text() (oxin.confirm_window.UI_confirm_window
    method), 41
set_text() (oxin.error_window.UI_error_window
    method), 49
set_users_on_ui() (in module
    oxin.backend.user_management_funcs), 36
set_value()
    (oxin.backend.plc_managment.management
    method), 29
set_widgets_enable_or_disable() (in module
    oxin.backend.camera_funcs), 15
Settings (class in oxin.app_settings), 40
shift_calibration_image() (in module
    oxin.backend.camera_funcs), 15
show_calibration_summary() (in module
    oxin.backend.camera_funcs), 15
show_camera_picture() (oxin.setting_api.API
    method), 64
show_cameras_summary() (in module
    oxin.backend.camera_funcs), 15
show_defects_summary_info() (in module
    oxin.backend.defect_management_funcs),
    24
show_mesagges() (oxin.setting_UI.UI_main_window
    method), 57
show_related_defects() (oxin.setting_api.API
    method), 64
show_storage_status() (in module
    oxin.backend.storage_funcs), 33
show_users_summary_info() (in module
    oxin.backend.user_management_funcs), 36
show_value() (oxin.setting_UI.UI_main_window
    method), 58
showPassword() (oxin.login_UI.UI_main_window
    method), 50
SmallNoiseRemoval() (in module
    oxin.calibrationCal.Preprocessing), 37
solve_equation()
    (oxin.backend.pxvalue_calibration.extract_info
    method), 31
SSI() (in module
    oxin.calibrationCal.SteelSurfaceInspection),
    38

```

start_grabbing()
 (*oxin.backend.camera_connection.Collector*
 method), 17
start_grabbing_error_handling()
 (*oxin.backend.camera_connection.Collector*
 method), 17
staticMetaObject (*oxin.confirm_UI.UI_main_window*
 attribute), 40
staticMetaObject
 (*oxin.confirm_window.UI_confirm_window*
 attribute), 41
staticMetaObject
 (*oxin.eror_window.UI_eror_window*
 attribute), 49
staticMetaObject (*oxin.login_UI.UI_main_window*
 attribute), 50
staticMetaObject (*oxin.notif_UI.UI_main_window*
 attribute), 51
staticMetaObject (*oxin.setting_UI.UI_main_window*
 attribute), 58
stop_grabbing()
 (*oxin.backend.camera_connection.Collector*
 method), 17

T

tabledefectgroups_onHeaderClicked()
 (*oxin.setting_api.API method*), 64
tabledefects_onHeaderClicked()
 (*oxin.setting_api.API method*), 64
tempreture()
 (*oxin.backend.camera_connection.Collector*
 method), 17
things_to_do_on_stackwidject_change()
 (*oxin.setting_api.API method*), 64
ThresholdCalculator() (in module
 oxin.calibrationCal.Variance), 38
thrs_map()
 (*oxin.backend.pxvalue_calibration.extract_info*
 method), 31
translate_headers_list()
 (*oxin.setting_UI.UI_main_window method*),
 58
translate_ui() (in module *oxin.translate_ui*), 65
translate_ui() (*oxin.setting_UI.UI_main_window*
 method), 58
trigg_exec()
 (*oxin.backend.camera_connection.Collector*
 method), 17

U

UI_confirm_window (class in *oxin.confirm_window*),
 41
UI_eror_window (class in *oxin.eror_window*), 49
UI_main_window (class in *oxin.confirm_UI*), 40
UI_main_window (class in *oxin.login_UI*), 49
UI_main_window (class in *oxin.notif_UI*), 51
UI_main_window (class in *oxin.setting_UI*), 53
unlock_move_flag() (*oxin.notif_UI.UI_main_window*
 method), 51
update_available_camera_serials_on_db() (in
 module *oxin.backend.camera_funcs*), 15
update_cam_params()
 (*oxin.database_utils.dataBaseUtils method*),
 48
update_camera_live_drive_combo() (in module
 oxin.backend.storage_funcs), 33

update_camera_live_storage_parms()
 (*oxin.setting_api.API method*), 64
update_combo_color() (in module
 oxin.backend.defect_management_funcs),
 24
update_combo_color() (in module
 oxin.backend.mainsetting_funcs), 27
update_combo_fontsize() (in module
 oxin.backend.mainsetting_funcs), 27
update_combo_fontstyle() (in module
 oxin.backend.mainsetting_funcs), 28
update_current_position()
 (*oxin.notif_UI.UI_main_window method*), 52
update_defect() (*oxin.database_utils.dataBaseUtils*
 method), 48
update_defect_group()
 (*oxin.database_utils.dataBaseUtils method*),
 48
update_defects_to_db() (in module
 oxin.backend.defect_management_funcs),
 24
update_drive_barchart() (in module
 oxin.backend.chart_funcs), 18
update_general_setting_params()
 (*oxin.database_utils.dataBaseUtils method*),
 48
update_path_plc() (*oxin.setting_api.API method*), 64
update_plc_dashboard_parms()
 (*oxin.setting_api.API method*), 65
update_plc_ip() (*oxin.database_utils.dataBaseUtils*
 method), 48
update_plc_parms()
 (*oxin.database_utils.dataBaseUtils method*),
 49
update_record() (*oxin.database.dataBase method*),
 43
update_ui_on_camera_connect_disconnect() (in
 module *oxin.backend.camera_funcs*), 16

V

validate_camera_ip() (in module
 oxin.backend.camera_funcs), 16
VarianceCalculator() (in module
 oxin.calibrationCal.Variance), 38

W

win_appear() (*oxin.notif_UI.UI_main_window*
 method), 52
win_disappear() (*oxin.notif_UI.UI_main_window*
 method), 52
win_move_down() (*oxin.notif_UI.UI_main_window*
 method), 52
win_move_down_run_timer()
 (*oxin.notif_UI.UI_main_window method*), 52
win_move_top() (*oxin.notif_UI.UI_main_window*
 method), 52
win_startpoint() (*oxin.notif_UI.UI_main_window*
 method), 52
write() (*oxin.backend.plc_managment.management*
 method), 29
write_parms() (*oxin.setting_api.API method*), 65

Y

yes() (*oxin.confirm_window.UI_confirm_window*
 method), 41

Z

`zoom_in_calibration_image()` (*in module*
oxin.backend.camera_funcs), [16](#)
`zoom_out_calibration_image()` (*in module*
oxin.backend.camera_funcs), [17](#)